Computer Networks

Lab_2 Assignment Documentation

Lab 3: Router Configuration (Creating Passwords, Configuring Interfaces)

Router Configuration with Cisco Packet Tracer

Experiment Overview:

In this experiment, you will configure a router and two PCs using Cisco Packet Tracer. The computers are connected to the router using copper straight-through cables. After setting up the network, you will test the connectivity by sending a simple PDU from PC0 to PC1. The successful simulation will demonstrate the router's capability to handle data transfers between multiple devices.

Procedure:

Step 1: Configuring Router1


- 1. Select the router and open CLI.
- 2. Press ENTER to start configuring Router1.
- 3. Activate privileged mode:
 - o Type enable
- 4. Access the configuration menu:
 - Type config t (configure terminal)
- 5. Configure interfaces of Router1:
 - o FastEthernet0/0:
 - Type interface FastEthernet0/0
 - Configure with the IP address 192.168.10.1 and Subnet mask 255.255.255.0
 - o FastEthernet0/1:
 - Type interface FastEthernet0/1
 - Configure with the IP address 192.168.20.1 and Subnet mask

255.255.255.0

6. Finish configuration:

O Type no shutdown to activate the interfaces

ROUTER1 Command Line Interface:



Step 2: Configuring PCs

1. Assign IP addresses to each PC:


o PCO:

■ Go to the desktop, select IP Configuration, and assign the following:

■ IP address: 10.10.10.1

■ Subnet Mask: 255.0.0.0

■ Default Gateway: 10.10.10.100




○ PC5:

■ Go to the desktop, select IP Configuration, and assign the following:

■ IP address: 192.168.1.3

■ Subnet Mask: 255.255.255.0


■ Default Gateway: 192.168.1.100



Step 3: Connecting PCs with Router

- 1. Connect the devices using copper straight-through cables:
 - Connect FastEthernet0 port of switch0 to gigabitEthernet0/0/0 port of Router1
 - Connect FastEthernet0 port of switch1 to gigabitEthernet0/0/1 port of Router1


Network Topology Design:



Simulation of Designed Network Topology

Sending a PDU from PC0 to PC5


- 1. Open the simulation mode in Packet Tracer.
- 2. Send a PDU from PC0 to PC5:
- Observe the packet traveling from PC0 to the router and then to PC5.




Acknowledgment from PC5 to PC0

1. Observe the acknowledgment packet:

 Ensure that the acknowledgment packet travels back from PC5 to PC0, confirming successful communication.





Basic router setup:



Basic router setup

Lab instructions

The aim of this lab is to test your ability to perform a basic router setup. You have 15 minutes to complete this simulation.

- 1. Configure the LAPTOP terminal software with the right console parameters.
- 2. Configure the router hostname to "GATEWAY"
- 3. Configure the enable password and secret to "cisco"
- 4. Configure password encryption on the router to secure stored passwords
- 5. Configure the console access:

- Login: yes

- Password: "cisco"


- History: 10 commands

- Logging synchronous

- Timeout : 2 minutes 45 seconds.

PROCEDURE:

1. Configure the laptop terminal software



- 2. Configure the router's name
- 3. Configure the enable password and secret to "cisco"
- 4. Configure password encryption for this router
- 5. Configure the console access

