User Manual of SKMEI Model #1251



Features:

- 13 Digits, Hour, Minutes, Seconds, Month, Day and Week
- Daily Alarm, Chime Hourly and Snooze Function
- 2 / 24H format selectable, Auto Calendar
- 1/100 second Chronograph with split functions
- Count Down (Upper limit: 24H)
- **Dual Time**
- EL backlight

B . Operational Manual :



1.At any state, press A key EL backlight for 3s

2.Real Time:

- - a) Press and hold C key for 2s to time setting state and "Second" flashing, press D key to zero; Press B key to select item as following sequence:

Second → Hour → Minute → Year → Month → Day

- b). Press D key to adjust the flashing item,
- c). Press C key to return to Real Time Mode.
- d). Press D key while the seconds are in the range of 30 to 59 resets them to 00 and adds 1 to the minutes . In the range of 00 to 59 resets them to 00 and adds to the minutes. In the range of 00 to 29, the minutes are unchanged.
- e) 12/24-Hour format :In the timekeeping Mode, Use D to toggle between 12-hour (12H) and 24-hour (24H) timekeeping.

3.Daily Alarm:

- In Real Time Mode, press B key enter into Alarm Mode
- Press C key to turn on/off Alarm(4) and Snooze(Snz), In Alarm Mode, press button D, then C to turn on/off (A) hourly chime
- Alarm setting Press and hold C key for 2s to select "Hour" setting; Press B key to select "Minute" setting; Press D key to adjust the flashing item. → Minute Hour -

4.Chronograph:

- In Real Time Mode, press B key twice enter into Chronograph Mode
- Press D key to Start/Stop running; When stop, press C key to zero.
- When running , press C key to split Counting. Then press D key to exit split count , and stop counting ; When exit split count , press C key to zero.

5. Dual Time:

In Real Time mode, Press B key 3 times to enter Dual Time Mode, Press and hold C key for 2s to select "Hour" setting, Press B key to select "Minute" setting, Press D key to adjust the flashing item, Press C key again to finish setting, and return to Dual Time displaying mode

6.Timer Mode:

- In Real Time Mode, press 8 key four times enter into Timer mode
- Press D key to Start/Stop countdown
- When stop the countdown, press C key back to the first setting time
- Timer alarm sounds for about 10s when counting down to 0:00:00. The timer is automatically reset to its starting value after the alarm stops
- Press C key 2s enter into countdown time setting
 a) Press B key to adjust "Hour" and then "Minute"
 Hour Minute
 - b). Press D key to adjust the flashing item
 - c) Press C key to confirm