

Global Memory Bandwidth

1 Overview

1.1 Location \$<APPSDKSamplesInstallPath>\samples\opencl\benchmark\

1.2 How to Run

See the Getting Started guide for how to build samples. You first must compile the sample.

Use the command line to change to the directory where the executable is located. The default executables are placed in $$<APPSDKSamplesInstallPath>\$ samples opencl bin x86 for 32-bit builds and $$<APPSDKSamplesInstallPath>\$ samples opencl bin x86_64\ for 64-bit builds.

Type the following command(s).

- GlobalMemoryBandwidth
 Measures the peak bandwidth from a hardware-constant buffer using various access
 patterns.
- 2. GlobalMemoryBandwidth -h This prints the help message.

1.3 Command Line Options

Table 1 lists, and briefly describes, the command line options.

Table 1 Command Line Options

Short Form	Long Form	Description
-h	help	Shows all command options and their respective meaning.
	device	Devices on which the program is to be run. Acceptable values are cpu or gpu.
- q	quiet	Quiet mode. Suppresses all text output.
-e	verify	Verify results against reference implementation.
-t	timing	Print timing.
	dump	Dump binary image for all devices.
	load	Load binary image and execute on device.
	flags	Specify compiler flags to build the kernel.
-р	platformId	Select platformId to be used (0 to N-1, where N is the number of available platforms).
-d	deviceId	Select deviceld to be used (0 to N-1, where N is the number of available devices).
-V	version	AMD APP SDK version string.
-i	iterations	Number of iterations for kernel execution.
-c	components	Number of vector components (vector-width to be used in the kernel).

2 Implementation Details

The sample measures the peak-bandwidth of the global buffer using the following sub-tests. it shows peak bandwidth for the device buffer. For devices on OpenCL version 2.0 and higher, it additionally shows peak bandwidth for the Shared Virtual Memory (SVM) buffer.

- 1. Read Bandwidth (single access) All threads are read from a single memory location.
- 2. Read Bandwidth (linear access) Threads read from global memory in a sequential access pattern.
- 3. Write Bandwidth (linear access) Threads write to global memory in a sequential access pattern.
- 4. Read bandwidth (linear access and uncached) Threads read from global memory in a sequential access pattern and ensure that the cache is not used.

If vector-width is not specified at command-line using the "-c" option, the preferred vector-width for the device will be queried and used. The "--dump" and "--load" options will always dump and load kernel binaries for vector-width 1 irrespective of the vector-width that was passed using the command-line.

Contact

Advanced Micro Devices, Inc. One AMD Place P.O. Box 3453 Sunnyvale, CA, 94088-3453 Phone: +1.408.749.4000 For AMD Accelerated Parallel Processing:

URL: developer.amd.com/appsdk
Developing: developer.amd.com/

Support: developer.amd.com/appsdksupport
Forum: developer.amd.com/openclforum



The contents of this document are provided in connection with Advanced Micro Devices, Inc. ("AMD") products. AMD makes no representations or warranties with respect to the accuracy or completeness of the contents of this publication and reserves the right to make changes to specifications and product descriptions at any time without notice. The information contained herein may be of a preliminary or advance nature and is subject to change without notice. No license, whether express, implied, arising by estoppel or otherwise, to any intellectual property rights is granted by this publication. Except as set forth in AMD's Standard Terms and Conditions of Sale, AMD assumes no liability whatsoever, and disclaims any express or implied warranty, relating to its products including, but not limited to, the implied warranty of merchantability, fitness for a particular purpose, or infringement of any intellectual property right.

AMD's products are not designed, intended, authorized or warranted for use as components in systems intended for surgical implant into the body, or in other applications intended to support or sustain life, or in any other application in which the failure of AMD's product could create a situation where personal injury, death, or severe property or environmental damage may occur. AMD reserves the right to discontinue or make changes to its products at any time without notice.

Copyright and Trademarks

© 2014 Advanced Micro Devices, Inc. All rights reserved. AMD, the AMD Arrow logo, ATI, the ATI logo, Radeon, FireStream, and combinations thereof are trademarks of Advanced Micro Devices, Inc. OpenCL and the OpenCL logo are trademarks of Apple Inc. used by permission by Khronos. Other names are for informational purposes only and may be trademarks of their respective owners.