Firewall Bible

FMC/FTD 7.0.1

Setting up FMC + FMC configuration

- Deploy OVA/Upgrade HW FMC to latest Gold-star FMC version
- Create local admin for config and 2^{nd} admin for API use
- License FMC
- Install latest patches and hotfixes
- Base Configuration (SNMP, SMTP, NTP)
- Setup external auth + user roles (RADIUS)
- Setup recurring rule and Geolocation updates
- Configure/Join AD realm, pxgrid integration with ISE
- Configure eStreamer with Splunk
- Build AMP and Threat grid Connections to FMC
- Configure Backup/restore under Tools
- Realm integration

Screenshots of FMC standard config:

FMC Initial Configuration:

Access List:

Control which computers can access the system on specific ports




Access Control Preferences:

Configure the system to prompt users for a comment when they add or modify an access control policy




Audit Log:

Configure the system to send an audit log to an external host




Audit Log Certificate:

As part of audit log secure streaming, require mutual authentication between Classic devices and the audit log server




Change Reconciliation:

Configure the system to send a detailed report of changes to the system over the last 24 hours



DNS Cache:

Configure the system to resolve IP addresses automatically on event view pages




Dashboard:

Enable Custom Analysis widgets on the dashboard




Database:

Specify the maximum number of each type of event that the Firepower Management Center can store



Email Notification:

Configure a mail host, select an encryption method, and supply authentication credentials for email-based notifications and reporting




External Database Access:

Enable external read-only access to the database, and provide a client driver to download




HTTPS Certificate:

Request an HTTPS server certificate, if needed, from a trusted authority and upload certificates to the system



Intrusion Policy Preferences:

Configure the system to prompt users for a comment when they modify an intrusion policy



Login Banner:

Create a custom login banner that appears when users log in




Management Interfaces:

Change options such as the IP address, hostname, and proxy settings of the appliance



Network Analysis Policy Preferences:

Configure the system to prompt users for a comment when they modify a network analysis policy



Process:

Shut down, reboot, or restart Firepower System-related processes



REST API Preferences:

Enabling the REST API

Enable REST API	✓		
-----------------	---	--	--

Remote Storage Device:

Configure remote storage for backups and reports



SNMP:

Enable Simple Network Management Protocol (SNMP) polling



Session Timeout:

Leave default, at 60 for browser session and 0 for CLI.


Time:

View the current time setting and, if the time synchronization setting in the current system configuration is set to Manually in Local Configuration, change the time


Either use Defaults or if they have NTP servers, place them here.

<u>Time Synchronization</u>:


Manage time synchronization on the system



UCAPL/CC Compliance:



User Configuration:



VMware Tools:


Enable and use VMware Tools on a Firepower Management Center Virtual




https://www.cisco.com/c/en/us/td/docs/security/firepower/60/configuration/guide/fpmc-config-guide-v60/Management Center System Configuration.html#ID-2241-00000a50

Vulnerability Mapping:

Map vulnerabilities to a host IP address for any application protocol traffic received or sent from that address



Users:




Domains:



<u>Integration – Cloud Services:</u>

We want these cloud services on so we can connect to the Cisco cloud for URL filtering, AMP for networks, and also our event configuration.




<u>Integration – Realms</u>:

Realms are connections between the Firepower Management Center and the user accounts on the servers you monitor. They specify the connection settings and authentication filter settings for the server. Realms can:

Specify the users and user groups whose activity you want to monitor.


Query the user repository for user metadata on authoritative users, as well as some non-authoritative users: POP3 and IMAP users detected by traffic-based detection and users detected by traffic-based detection, a user agent, a TS Agent, or ISE/ISE-PIC.

You can add multiple domain controllers as directories in a realm, but they must share the same basic realm information. The directories in a realm must be exclusively LDAP or exclusively Active Directory (AD) servers. After you enable a realm, your saved changes take effect next time the Firepower Management Center queries the server.



<u>Integration – Identity Sources:</u>

If they have ISE. If not, leave as none.



https://www.cisco.com/c/en/us/support/docs/security/identity-services-engine-24/214481-configure-ise-2-4-and-fmc-6-2-3-pxgrid-i.html

<u>Integration – High Availability</u>:

HA for FMC. Most cases, we only have one instance. Leave as standalone.



<u>Integration – eStreamer:</u>

Before the Management Center or managed device you want to use as an eStreamer server can begin streaming events to a client application, you must configure the eStreamer server to send events to clients, provide information about the client, and generate a set of authentication credentials to use when establishing communication. You can perform all of these tasks from the Management Center or managed device user interface.

As of now, we do not configure for most customers unless specifically asked.

https://www.cisco.com/c/en/us/td/docs/security/firepower/60/api/eStreamer/EventStreamerIntegrationGuide/ConfiguringEstreamer.html


Integration - Host Input Client:

In addition to accepting host input commands from users on the Management Center, the Management Center's host input service also accepts batch import files from authenticated host input clients on external hosts. You can use a host input client to process import files created for the host input import tool and then send the data to the Management Center to add the information to your network map.

Most customers we leave default (turned off) unless specifically asked about it.


https://www.cisco.com/c/en/us/td/docs/security/firepower/60/api/host-input/HostInputAPIGuide/Configuring-HostInputClient.html

<u>Integration – Smart Software Manager On-Prem:</u>




<u>Updates – Product Updates</u>:

Here you can upload and download new updates to FMC/FTD.




<u>Updates – Rule Updates:</u>

You can update rules for snort rule update versioning here. You can also see the rule updates log.




<u>Updates – Geolocation updates:</u>

You can import/install geolocation updates here.



<u>Licensing – Smart Licensing</u>:

This page is pretty important. You can see all of your licensing structured and what licenses are good or need renewed. You can also sync your Cisco smart software manager as well to see product registration and usage registration.



Health Monitor:

You can view the health of your FMC and any FTDs in this window. It will show any Health status errors, warnings, etc. You can then click on your FTDs and see a bunch of graphs with statistics for what the FTDs are using, critical processes, etc. If you go to View System & Troubleshooting details on the FTDs, there are two main areas that you need to know about. One is generating Troubleshooting Files. You will need to do this if problems occur and Cisco TAC gets involved and wants troubleshooting files. The other link is Advanced Troubleshooting. Here you can do file downloads, get into the FTD CLI, run packet tracers, and run packet

Captures.

Moritoring

Pleasith: 10.111.111.4 (Acros)

Power System & Troubleshoot Deals - Connections

Power System & Troubleshoot Deals - Connections

No Data Available

Memory

Duta collection for CPU module is disabled in the health policy, partial or no

Throughput Memory


Duta collection for CPU module is disabled in the health policy, partial or no

Ween System Aug 27th Secont Aug 27th Second Secon

Back Download


Health Policy:

We can see a multitude of categories in which monitoring is on for most by default. We can then go in and decide to either remove monitoring for that specific category or change thresholds related to that category.



Health Events:

Here we can see different health events such as memory usage, smart licensing monitoring, FMC HA status, etc.




Health Exclude:

We can remove health monitoring off certain devices if needed.




Health Monitor Alerts:

We can configure our own Health monitor alerts by choosing the severity that triggers the alert, the module, and then the alert itself with an optional threshold timeout.



Security Analytics and Logging:

This would be a Stealth watch integration where you can send your logging to an SMC or Stealth watch management console. Provides logging storage for centralized events. Or, you can send it to a Flow collector to a SMC.



Monitoring Audit:

Your traditional audit log with GET requests show activity.



Monitoring Syslog:

Monitoring syslog events.



Monitoring statistics:

Can view memory usage, load average, disk usage, and other statistics here.




Tools – Backup/Restore:

Here we can set up Backup profiles to backup the FMC and FTDs. Then, you can manually download the backups to your PC. I would recommend always having a backup downloaded to the PC and not just storing the backups on the device you are taking a backup from. Storage location is set to default at /var/sf/backup/.



<u>Tools – Scheduling</u>:

Here, you can schedule events such as Backups, deploying policies, Nmap scanning, installing latest updates, etc.




<u>Tools – Import/Export</u>:

Here we can import/export a multitude of things such as Dashboard statistics, different policies, NAT, SSL, ACP, and more.



Data Purge:

You can purge Discovery and Identity events, hosts, user activity, connection events, connection summary events, and SI events.



AFTER FMC CONFIGURATION

Putting Base IP config on FTDs that customer sends in workbooks

Joining FTDs to FMC (configure manager add)

Upgrade FTD/FMC to compatible versioning

Licensing (checking if connected to EA/smart account, licensing is correct)

If you were sold HA pair, bring up FTDs into HA.

HA Pair:

High Availabi	lity Link	State Link		
Interface:*	Ethernet1/7 ▼	Interface:*	Ethernet1/8 ▼	
ogical Name:*	Failover	Logical Name:*	Stateful Link	
Primary IP:*	fd00:f00d::1/64	Primary IP:*	fd00:f00f::1/64	
	✓ Use IPv6 Address		✓ Use IPv6 Address	
Secondary IP:*	fd00:f00d::2/64	Secondary IP:*	fd00:f00f::2/64	
Subnet Mask:		Subnet Mask:		
Psec Encryp	tion			
Enabled				
Key Generation:	Auto	*		
	ink is used to sync configura Selected interface links and e			ontent

Follow the screenshot to what config to put. You can use the exact IPv6 addresses in the screenshot as your failover/state link. Change interfaces when needed.

Running Migration tool... (Everything should be migrated other than S2S as of version 2.4.1)

After Migration tool is ran.....


POLICIES

ACLS:

Rules-

Making sure all destination zones are inputted in the rules after the migration. Combining/deleting any rules that can be combined or removed. Creating categories and organizing ACLs based off of Zones.

Best Practice to add for inside – outside ACLS for every customer. See SS below.




Make sure when all of your policies are created, add your intrusion/malware and file policies to your specific rules that you want the policies on. (Add IPS rules on pretty much all the allow rules. File/malware rules will be applied on any catch all rules or rules regarding not encrypted/secure protocols like http, ftp, etc.

Also add your Prefilter Policy, SSL policy, and Identity Policy if you have one to the ACP.

Security Intelligence –


Make sure you block the appropriate Networks and URLs and put them in your DNS policy Block list. See screenshot below.

(From Attackers to Tor_exit_node in the list)




HTTP Responses -

This can be default, make sure System-provided is selected in the interactive block response page.




Logging -

Check the syslog settings configured in the FTD platform Settings policy deployed on the device. (I would use the severity of EMERG)




Advanced -



Intrusion Policy:


Create an Intrusion Policy Best practice in SS.



After creating intrusion policy to screenshot above, we will come back to applying/editing the policy. We need traffic to start flowing so it can be analyzed. Then, we can go into snort 3 later to see what Cisco recommends as best practice to remove/add snort rules in based off the traffic it sees.

Malware & File Policy:

Create your Malware & File Policy Best practice in screenshot below.




After creating the policy to screenshot above, we will come back to applying the policy to certain ACL rules.


DNS Policy:

Because we already added our networks and urls into our DNS policy block list from the ACP – security intelligence page, we can skip this. Make sure the DNS policy is applied to the ACP however.

Identity Policy:

See screenshots below for the passive identity rule in our policy.





This is all we need to do for best practice. You can use identity policies to detect the user who is associated with a connection. By identifying the user, you can correlate threat, endpoint, and network intelligence with user identity information. By linking network behavior, traffic, and events directly to individual users, the system can help you identify the source of policy breaches, attacks, or network vulnerabilities. All you need is a realm configured first (in configuration, integration, then realms in the fmc cog wheel) Once a realm is configured, then you can create a rule in the policy, name it passive identity, then connect the rule with the action of passive authentication and the realm you are using.

SSL Policy:

How you handle SSL and encrypted traffic on the network. The SSL policy will handle the decryption of encrypted traffic coming in on TCP connections only.

Generally skipped, however is customer wants this policy to be applied, you can follow this here to build a policy out (You need a cert built out as well): http://www.labminutes.com/sec0228 asa firepower 60 ssl decryption 1

Prefilter Policy:

Make sure a default prefilter policy is created and applied to ACP. Can add rules in per customer request. (For instance, offsite backups.)

Like an ACL however it provides early access control which allows a flow to bypass the snort engine completely. Traffic will not be analyzed by the snort engine.

https://www.cisco.com/c/en/us/support/docs/security/firepower-management-center/212700-configuration-and-operation-of-ftd-prefi.html

Network Discovery:



Best practice ^ The rest is default under Users and Advanced as well. Its applied to your FMC, does not need to be pushed down to a device. Policy is applied by default.

Application Detectors:

Correlation:

DEVICES

<u>Device Management:</u>

<u>Device Upgrade:</u>

NAT:

<u>VPN – S2S:</u>

First step would be going to the ASA and running the command "show vpn-sessiondb detail I2I". Log all the active connections to notepad ++. Then, go into object management, network, and start creating a list of all the objects. Here is a picture for example.

You will find these connections in the ipsec: sections in the notepad. They will be labeled local address and remote address. Once imported into fmc, start creating the ikev1, ikev2, and ipsec policies/proposals. You will find these in the notepad as well under ipsec/ikev1/ikev2 and copy all the parameters to the fmc to create new policies you will use when building your site to site.

Next, it is time to create your s2s. First, create new FTD vpn. Then, mark if it is IKEv1 or IKEv2. Node A device will be your firewall and interface will most likely be your outside interface. This should auto-generate your IP address. Then, add you local object to the protected networks list. You will find this in your IPsec details. Should be called your Local Address: X.X.X.X/255.255.255.0 for example. Then, Node B should be extranet. Node B's IP address will your peer's public/outside address. Then, under protected networks, should be your peer's local networks you are wanting to tunnel to. Endpoints should be done from here, now you go to the IKE tab. Whether its IKEv1 or IKEv2, connect to the right policy you have created beforehand. Then for pre-shared key, choose manual key. You can find the manual key in the ASA if you do a more system:running-config beg tunnel-group. Log this to Notepad ++. Cntrl – find with the connection IP (Peers public IP). There you will find a unencrypted pre-share key. Put it into your Ike settings. Then, click on the IPsec tab. Make sure your mode is correct with the right Ikev1/2 IPsec Proposals that you have created before. Check to see if PFS is on, if it is, click the checkbox to enable it. If you have a ton of S2S, you can leave Access Control for VPN traffic checked however best practice would be to leave it off (Better security practice). Then, you are finished creating your s2s! The next steps are then to create an ACL for the S2S you have just created. If you have an Inside to any, you will only need to create one ACL for your outside – inside zone rule. It would be like this...



Source zone is outside, destination zone is inside. Source network is your peer's local network object you are trying to reach. Your destination object is your local network object it needs to reach. Enable IPS inspection and make sure it is in the right ACL category. Save your rule. Then, you need to check NAT. Usually the NAT rules are migrated successfully, however, it is good to check just in case. It should look like this just like the example...



After making sure NAT is good, you have successfully created a s2s tunnel with an attached ACL and NAT rule!

VPN-RA:

Dynamic Access Policy:

Troubleshooting:

Qos:

Platform Settings:

ARP Inspection:

(Usually not set up unless specifically asked)

By default, all ARP packets are allowed between bridge group members. You can control the flow of ARP packets by enabling ARP inspection.

ARP inspection prevents malicious users from impersonating other hosts or routers (known as ARP spoofing). ARP spoofing can enable a "man-in-the-middle" attack. For example, a host sends an ARP request to the gateway router; the gateway router responds with the gateway router MAC address. The attacker, however, sends another ARP response to the host with the attacker MAC address instead of the router MAC address. The attacker can now intercept all the host traffic before forwarding it on to the router.

Step 1 Select Devices > Platform Settings and create or edit a FTD policy Step 2 Select ARP Inspection Step 3 Add entries to the ARP inspection table. a. Click Add to create a new entry, or click Edit if the entry already exists b. Select the desired options. Inspect Enabled-To perform ARP inspection on the selected interfaces and zones. Flood Enabled—Whether to flood ARP requests that do not match static ARP entries out all interfaces other than the originating interface or the dedicated management interface. This is the default behavior. To you do not less to fload APP requests, then only those requests that exactly match static ARP entries are allowed. Security Zones-Add the zones that contain the interfaces on which to perform the selected actions. The zones must be switched zones. For interfaces not in a zone, you can type the interface name into the field below the Selected Security Zone list and click Add. These rules will be applied to a device only if the device included the selected interfaces or zone. c. Click OK. Step 4 Add static ARP entries according to Add a Static ARP Entry. Step 5 Click Save. can now click **Deploy** and deploy the policy to assigned devices. The changes are not active until you deploy them.

DNS:

(Usually not set up unless specifically asked to)

Configure **DNS**

The Domain Name System (DNS) servers are used to resolve hostnames to IP addresses. There are two DNS server settings that apply to different types of traffic: data and special management traffic. Data traffic includes any services that use FQDNs for which a DNS lookup is necessary, such as Access Control Rules and Remote Access VPN. Special management traffic includes traffic originating on the Management interface such as FMC management and database updates. This procedure only applies to data DNS servers. For management DNS settings, see the CLI configure network dns servers and configure network dns searchdomains commands.

To determine the correct interface for DNS server communications, the FTD uses a routing lookup, but which routing table is used depends on the interfaces for which you enable DNS. See the interface settings below for more information

Before you begin

- Ensure you have created a DNS server group. For instructions, see Creating DNS Server Group Objects.
- Ensure that the FTD has appropriate static or dynamic routes to access the DNS servers.

Procedure

Step 6

- Step 1 Select Devices > Platform Settings and create or edit a Firepower Threat Defense policy. Step 2 Step 3 Check Enable DNS name resolution by device. Step 4 Choose the DNS Server Group that you have already created Step 5 (Optional) Enter the Expiry Entry Timer and Poll Timer values in minutes. These options apply to FQDNs that are specified in network objects only. These do not apply to FQDNs used in other features. • Expire Entry Timer specifies the time limit to remove the IP address of a resolved FQDN from the DNS lookup table after its time-to-live (TTL) expires. Removing an entry requires the table to be recompiled, so frequent removals can increase the processing load on the device. This setting virtually extends the TTL.
 - Poll Timer specifies the time limit after which the device queries the DNS server to resolve the FQDN that was defined in a network object. An FQDN is resolved periodically either when the poll timer has expired, or when the TTL of the resolved IP entry has expired, whichever
 - occurs first.
 - Enable DNS lookups on all interfaces or on specific interfaces. These choices also affect which routing tables are used. Note that enabling DNS lookups on an interface is not the same as specifying the source interface for lookups. The FTD always uses a route
 - No interfaces selected-Enables DNS lookups on all interfaces, including Management and management-only interfaces. The FTD checks the data routing table, and if no route is found, falls back to the management-only routing table.
 - Specific interfaces selected but not the Enable DNS Lookup via diagnostic interface also option—Enables DNS lookups on the specified interfaces. The FTD checks the data routing table only.
 - Specific interfaces selected plus the Enable DNS Lookup via diagnostic interface also option—Enables DNS lookups on the specified interfaces and the interface. The FTD checks the data routing table, and if no route is found, falls back to the management-only routing
 - Only the Enable DNS Lookup via diagnostic interface also option—Enables DNS lookups on . The FTD checks only the management-only routing table. Be sure to configure an IP address for the Diagnostic interface on the Devices > Device Management > edit device > Interfaces page

Step 7 Click Save

External Authentication:

This would be for your configuration with ISE to do any external authentication.




Fragment Settings:

By default, the FTD device allows up to 24 fragments per IP packet, and up to 200 fragments awaiting reassembly. You might need to let fragments on your network if you have an application that routinely fragments packets, such as NFS over UDP. However, if you do not have an application that fragments traffic, we recommend that you do not allow fragments by setting Chain to 1. Fragmented packets are often used as Denial of Service (DoS) attacks.



HTTP:

If you want to allow HTTPS connections to one or more interfaces on the FTD device, configure HTTPS settings. You can use HTTPS to download packet captures for troubleshooting.



<u>ICMP</u>:

To protect the device from attacks, you can use ICMP rules to limit ICMP access to interfaces to particular hosts, networks, or ICMP types. ICMP rules function like


access rules, where the rules are ordered, and the first rule that matches a packet defines the action.

If you configure any ICMP rule for an interface, an implicit deny ICMP rule is added to the end of the ICMP rule list, changing the default behavior. Thus, if you want to simply deny a few message types, you must include a permit any rule at the end of the ICMP rule list to allow the remaining message types.




Secure Shell:

You can add SSH tunnels to your available Zones/interfaces.



SMTP Server:

You must identity an SMTP server if you configure email alerts in the Syslog settings. The source email address you configure for Syslog must be a valid account on the SMTP servers.



SNMP:

Simple Network Management Protocol (SNMP) defines a standard way for network management stations running on PCs or workstations to monitor the health and status of many types of devices, including switches, routers, and security appliances. You can use the SNMP page to configure a firewall device for monitoring by SNMP management stations.

The Simple Network Management Protocol (SNMP) enables monitoring of network devices from a central location. Cisco security appliances support network monitoring using SNMP versions 1, 2c, and 3, as well as traps and SNMP read access.




SSL:

Procedure	
Step 1	Select Devices > Platform Settings and create or edit a Firepower Threat Defense policy.
Step 2	Select SSL.
Step 3	Add entries to the Add SSL Configuration table.
	a. Click Add to create a new entry, or click Edit if the entry already exists.b. Select the required security configurations from the drop-down list .
	 Protocol Version—Specifies the TLS protocols to be used while establishing remote access VPN sessions. Security Level—Indicates the kind of security positioning you would like to set up for the SSL.
Step 4	Select the Available Algorithms based on the protocol version that you select and click Add to include them for the selected protocol. For more information, seeAbout SSL Settings
	The algorithms are listed based on the protocol version that you select. Each security protocol identifies unique algorithm for setting up the security level.
Step 5	Click OK to save the changes.


Syslog:

Here, we can add our Syslog servers.



Timeouts:

These consist of SIP timeouts, console timeouts, Connection timeouts, etc. Choose your liking.




Time Synchronization:

Can either set NTP from Management Center or if you have NTP servers, set it to there.

Set My Clock
Via NTP from Management Center
○ Via NTP from
1 This setting is unsupported on firepower 9300 and Firepower 4100 platforms. Please use Firepower Chassis Manager instead to set NTP time synchronization

Time Zone:

Generally, you can leave blank and it will default to UTC. If not, you can specify your time zone.



FlexConfig:

Certificates:

Objects

Object Management:

Access List:

You can put standard/extended access lists in these categories revolving around your objects/object groups.

Address Pools:

These will usually contain your VPN pools.



Application filters:

You can organize your applications by creating a filter based on certain characteristics.

AS Path:

Mandatory for BGP config, don't need unless you are doing BGP. AS path is a sequence of AS numbers between source and destination routers that form a directed route for packets to travel.

Cipher Suite List:

Object compromised of several cipher suites. Each cipher suite value represents a cipher suite used to negotiate SSL or TLS encryption sessions. You can use these cipher suite lists in SSL rules to control encrypted traffic based on whether the client and server negotiated the SSL session using that suite.

Community List:

Transitive BGP attribute. Groups of destinations that share some common attribute, used for route tagging. The community list is an ordered list of matching statements. Destinations are matched against the rules until a match is found.

Individual Objects:

Distinguished name object represents the distinguished name listed for a public key certificate's subject or issuer. You can use distinguished name objects in SSL rules to control encrypted traffic based on whether the client and server negotiated the SSL session using a server certificate with the distinguished name as subject or issuer.

Object Groups:

Each distinguished name object represents the distinguished name listed for a public key certificate's subject or issuer. You can use distinguished name object groups in SSL rules to control encrypted traffic based on

whether the client and server negotiated the SSL session using a server certificate with the distinguished name as subject or issuer.

DNS Server Group:

A DNS server group is a list of one or more DNS servers and connection settings to use for connecting.

File list:

f you use AMP for Firepower, and the AMP cloud incorrectly identifies a file's disposition, you can add the file to a file list to better detect the file in the future. There are two predefined categories of file lists, Clean List - System treats it as if the AMP cloud assigned a clean disposition Custom Detection List - System treats it as if the AMP cloud assigned a malware disposition.

FlexConfig object:

FlexConfig Object include device configuration commands, variables, and scripting language instructions. It is used in FlexConfig polices.

FlexConfig Text Object:

Text objects define free-form text strings that you use as variables in a FlexConfig object. These objects can have single values or be a list of multiple values.

Geolocation:

Geolocation represents one or more countries or continents that the system has identified as the source or destination of traffic on your monitored network. It is used in various places like access control policies, SSL policies, and event searches.

Interface:

Interface objects segment your network to help you manage and classify traffic flow. An interface object simply groups interfaces. These groups may span multiple devices; you can also configure multiple interface objects on a single device.

You want to make sure the zones we create are tied to the correct interface group. Afterwards, go to your device management and look at your ftd's interfaces. Make sure the zone matches your interface group.

Key Chain:

A list of keys that allows you to use in different policies.


Network:

A network object represents one or more IP addresses. Network objects are used in various places, including access control policies, network variables, intrusion rules, identity rules, network discovery rules, event searches, reports, and so on.

PKI Cert enrollment:

A certificate enrollment object contains the Certification Authority (CA) server information and enrollment parameters that are required for creating Certificate Signing Requests (CSRs) and obtaining Identity Certificates from the specified CA. These activities occur in your Private Key Infrastructure (PKI).





External Cert Groups:

External certificate object represents a server public key certificate that does not belong to your organization. You can use external certificate objects in SSL rules to control traffic encrypted with the server certificate.

External Certs:

External certificate object represents a server public key certificate that does not belong to your organization. You can use external certificate objects in SSL rules to control traffic encrypted with the server certificate.

Internal CA Groups:

Internal certificate authority (CA) object represents the CA public key certificate of a CA your organization controls. You can use internal CA objects in SSL rules to decrypt outgoing encrypted traffic by re-signing the server certificate with the internal CA.

Internal CAs:

Internal certificate authority (CA) object represents the CA public key certificate of a CA your organization controls. You can use internal CA objects in SSL rules to decrypt outgoing encrypted traffic by re-signing the server certificate with the internal CA.

Internal Cert Groups:

Internal certificate object represents a server public key certificate belonging to your organization. You can use internal certificate objects and groups in SSL rules, ISE/ISE-PIC connection and captive portal configuration.

<u>Internal Certs:</u>

Internal certificate object represents a server public key certificate belonging to your organization. You can use internal certificate objects and groups in SSL rules, ISE/ISE-PIC connection and captive portal configuration.

Trusted CA Groups:

Trusted certificate authority (CA) object represents a CA public key certificate belonging to a trusted CA. You can use external CA objects in SSL policy, realm configurations and ISE/ISE-PIC connection.

Trusted CAs:

Trusted certificate authority (CA) object represents a CA public key certificate belonging to a trusted CA. You can use external CA objects in SSL policy, realm configurations and ISE/ISE-PIC connection.

Policy List:

Policy list objects is used when configuring route maps. When a policy list is referenced within a route map, all of the match statements within the policy list are evaluated and processed.

Port:


Port objects or groups represent different protocols. You can use port objects and groups in various places in the systems web interface, including access control policies, identity rules, network discovery rules, port variables, and event searches.

IPv4 Prefix List:

Prefix lists work like access lists for route advertisements (prefixes). You can create prefix list objects for IPv4 to use when you are configuring route maps, policy maps, OSPF Filtering, or BGP Neighbor Filtering

Radius Server Group:

RADIUS Server Group objects contain one or more references to RADIUS Servers. These AAA servers are used to authenticate users logging in through Remote Access VPN connections.



Route Map:

Route maps are used when redistributing routes into any routing process. They are also used when generating a default route into a routing process. A route map defines which of the routes from the specified routing protocol are allowed to be redistributed into the target routing process.

Security Group Tag:

A Security Group Tag (SGT) object specifies a single SGT value. You can use SGT objects in rules to control traffic with SGT attributes that were not assigned by Cisco ISE. You cannot group or override SGT objects.

DNS Lists and Feeds:

DNS lists and feeds helps you quickly filter traffic by collecting Domain Names. Its used in DNS policies to blacklist and whitelist as part of Security Intelligence

Name	Туре	
Cisco-DNS-and-URL-Intelligence-Feed Last Updated: 2021-11-15 18:10:01	Feed	/ ₩
Global-Blacklist-for-DNS	List	1
Global-Whitelist-for-DNS	List	/ ii

Network Lists and Feeds:

Network lists and feeds helps you quickly filter traffic by collecting IP address and address blocks. Its used in access control policies to blacklist and whitelist as part of Security Intelligence.



URL Lists and Feeds:

URL lists and feeds help you quickly filter traffic by collecting URLs. Its used in access control policies to blacklist and whitelist as part of Security Intelligence. You can also use URL lists in access control and QoS rules, whose analysis and traffic handling phases occur after Security Intelligence.



Sinkhole:

A sinkhole object represents either a DNS server that gives non-routeable addresses for all domain names within the sinkhole, or an IP address that does not resolve to a server. You can reference the sinkhole object within a DNS policy rule to redirect matching traffic to the sinkhole.

SLA Monitor:

SLA monitor defines a connectivity policy to a monitored address and tracks the availability of a route to the address. The SLA Monitor object is used in the Route Tracking field of an IPv4 Static Route Policy. IPv6 routes do not have the option to use SLA monitor via route tracking.

Time Range:

Time range object represents the time interval. You can use it to apply a policy only during times you specify.

Time Zone:

Time range objects in supported policies are applied based on the time zone specified in device platform settings.

Tunnel Zone:

A tunnel zone represents certain types of plaintext, passthrough tunnels that you explicitly tag for special analysis. A tunnel zone is not an interface object, even though you can use it as an interface constraint in some configurations.


URL:

URL object represents a single URL or IP address. You can use URL objects and groups in various places, including access control policies and event searches. For example, you could write an access control rule that blocks a specific website.



Variable Set:

Variables represent values commonly used in intrusion rules to identify source and destination IP addresses and ports. You can also use variables in intrusion policies to represent IP addresses in rule suppressions, adaptive profile updates, and dynamic rule states.



VLAN Tag:

VLAN tag object represents a VLAN tag or range of tags.

VPN AnyConnect File:

File objects represent files used in configurations, typically for remote access VPN policies. They can contain AnyConnect Client Profile and AnyConnect Client Image files.




VPN Certificate Map:

Certificate Map Object is used to provide an association between a received certificate and a Remote Access VPN connection profile. If a received certificate matches the rules contained in the certificate map, the connection is associated with the specified connection profile.

VPN Group Policy:

A Group Policy is a set of attribute and value pairs, stored in a group policy object, that define the remote access VPN experience. The RADIUS authorization server assigns the group policy or it is obtained from the current connection profile.



IKEv1 IPsec Proposal:

IPsec security association negotiation with ISAKMP, the peers agree to use a particular proposal to protect a particular data flow. In IKEv1 IPsec Proposal object, single encryption and Hash algorithm is allowed.



IKEv1 Policy:

Internet Key Exchange (IKE) is a key management protocol that is used to authenticate IPsec peers, negotiate and distribute IPsec encryption keys, and automatically establish IPsec security associations (SAs). IKEv1, IKE proposals contain a single set of algorithms and a modulus group.

IKEv2 IPsec Proposal:

IPsec security association negotiation with ISAKMP, the peers agree to use a particular proposal to protect a particular data flow. In IKEv2 IPsec Proposal object, you can select multiple encryption and Hash Algorithms are allowed. During IKEv2 negotiations, the peers select the most appropriate options that each support.

IKEv2 Policy:

Internet Key Exchange (IKE) is a key management protocol that is used to authenticate IPsec peers, negotiate and distribute IPsec encryption keys, and automatically establish IPsec security associations (SAs). IKEv2 proposal, you can select multiple algorithms and modulus groups in one policy

Intrusion Rules:

You can view the exact rules here if you want to manually touch them. However, it is best just to go to your intrusion policy and edit rules there.

https://www.cisco.com/c/en/us/td/docs/security/firepower/60/configuration/guide/fpmc-config-guide-v60/Tuning Intrusion Policies Using Rules.html

AMP

AMP Management:

Connects to the US Cloud for AMP for Endpoints/AMP for Networks. (Sometimes, you may need to remove the AMP cloud connection and reinitiate it for it to sync properly) Sign into your CCO account and the integration will take place.

Dynamic Analysis Connections:

Connects to Threat-grid for dynamic analysis and sending SHAs to sandboxes for further inspection. You can hit the associate button to sign

into your CCO account to initiate the integration between firepower and Threat-grid.

<u>Intelligence</u>	
Incidents:	
Sources:	
Elements:	
Settings:	

Context Explorer:

Analysis

Acts like a main summary page of all the analysis subsections of events. Includes context about the status of your network. Includes graphs about indications of compromise, network information, application protocol information, security intelligence, intrusion information, etc.

https://www.cisco.com/c/en/us/td/docs/security/firepower/60/configuration/guide/fpmc-config-guide-v60/Using the Context Explorer.html

Connection Events:

This is where you can see all of your connections with application details. You can see the first to last packet, initiator and responder IPs, ingress and egress security zones, ports, application protocol, etc. This can be a super helpful area if you are doing threat hunting and wanted to search a specific traffic flow that happened.

You can also click on a specific host profile and see things like the Device name, Mac addresses, Ioc, Operating system, servers it has touched, Applications it has touched, etc.

https://www.cisco.com/c/en/us/td/docs/security/firepower/620/configura tion/guide/fpmc-config-guidev62/connection and security intelligence events.html

<u>Connection Security Intelligence Events:</u>

These events are focused on your blocks. If you have geolocation on for instance, it will show mostly blocked IPs from countries you don't want connections to. (Ex. Russia IP attempts, North Korea IP connection attempts, etc.) You can see the initiator IP, responder IP, and the type of intelligence category that was blocked. You can also see the egress/ingress zones as well as the port.

You can also open the host view as well from the received IP and see any IOC, device name, MAC address, etc that was involved in the blocking event.

https://www.cisco.com/c/en/us/td/docs/security/firepower/660/configura tion/guide/fpmc-config-guidev66/connection and security intelligence events.html

Intrusion Events:

All of your intrusion events will be in this section. There you can go into threat hunting to analyze who was the target, what exactly was vulnerable, what was the vulnerability, was the event blocked/stopped, etc. You can then use the Intrusion event packet view. The packet view indicates why a specific packet was captured by providing information about the intrusion event that the packet triggered, including the event's time stamp, message, classification, priority, and, if the event was generated by a standard text rule, the rule that generated the event. The packet view also provides general information about the packet, such as its size.

If intrusion events occur... It is best practice to go into your intrusion policy to add any rules to the drop and generate event rule section to make sure the intrusion event that occurred does not occur again. You will also see a Firepower Recommendations section that can help auto update your rules as well to match the traffic/events you have been seeing.

https://www.cisco.com/c/en/us/td/docs/security/firepower/60/configuration/guide/fpmc-config-guide-v60/fpmc-config-guide-v60 chapter 01110000.html

Intrusion Reviewed Events:

Once an event goes under some analysis, you can push that intrusion event to your reviewed events for organization. You can also make notes to what you have done such as added an intrusion policy rule after seeing the event, etc.

Intrusion Clipboard:

Clipboard — To add an event to the clipboard so you can transfer it to the incidents at a later time, click Copy to copy the event whose packet you are viewing or click Copy All to copy all the events whose packets you previously selected.

Intrusion Incidents:

These are intrusion events that you suspect are involved in a possible violation of your security. This leads into the topic of incident handling which can be more discussed here:

https://www.cisco.com/c/en/us/td/docs/security/firepower/620/configura tion/guide/fpmc-config-guide-v62/incidents.html

File Malware Events:

These are different events that will show attempted malware in your environment caught by the fmc. It will show the file name, file SHA256, file type, and hit count. If you click into the file name, you will see the receiving IP, the user who tried to access it, the event type (blocked or allowed), the event subtype, and more.

https://www.cisco.com/c/en/us/td/docs/security/firepower/60/configuration/guide/fpmc-config-guide-v60/fpmc-config-guide-v60 chapter 01110001.html

File events:

Similar to malware events, file events show a type of file, disposition, action, and hit count of them. You can then click on the type and see all the malware cloud lookups for that file. It will show you the sending IP, country, receiving IP, port, receiving protocol, user, the file name, and the cloud disposition of the SHA lookup.

https://www.cisco.com/c/en/us/td/docs/security/firepower/60/configuration/guide/fpmc-config-guide-v60/fpmc-config-guide-v60 chapter 01110001.html

File captured files:

This shows a summary of your captured files, each with a rating threat score of low to high. It shows you the type of file and the category the file belongs in, as well as the hit count. If you click on the type or category, you can then filter your events by that attribute to see all the file names, SHAs, threat score, types, etc your fmc has found sifting through traffic.

https://www.cisco.com/c/en/us/td/docs/security/firepower/60/configuration/guide/fpmc-config-guide-v60/fpmc-config-guide-v60 chapter 01110001.html

File Network File Trajectory:

To further target your analysis, you can use a malware file's network file trajectory (a map of how the file traversed your network, passing among hosts, as well as various file properties) to track the spread of an individual threat across hosts over time, allowing you to concentrate outbreak control and prevention efforts where most useful.

If you configure local malware analysis or dynamic analysis in a file rule, the system preclassifies files matching the rule and generates a file composition report.

If your organization has deployed AMP for Endpoints and integrated that deployment with your Firepower Management Center, you can also import records of scans, malware detections, and quarantines, as well as indications of compromise (IOC) identified by that product. This data is displayed alongside event data gathered by Firepower for a more complete picture of malware on your network.

https://www.cisco.com/c/en/us/td/docs/security/firepower/60/configuration/guide/fpmc-config-guide-v60/fpmc-config-guide-v60 chapter 01110001.html#concept 5511F4FCC2504C54A8A759136F7FE 17D

Hosts Network Map:

Here, you can see all of your hosts based on the IP, IPv6, or MAC. You can then click on a certain IP and it will list its host profile, IOC, OS, applications, etc.

Network devices contains the same layout except with this case, it is network devices, not hosts. You can also search IPs for mobile hosts as well to see any devices that are phones attached to your network, given an IP in your subnet.

Can search by Indications of Compromise as well, application protocols, vulnerabilities, and host attributes.

https://www.cisco.com/c/en/us/td/docs/security/firepower/60/configuration/guide/fpmc-config-guide-v60/Using the Network Map.html#ID-2222-00000068

Hosts:

The host category breaks hosts down in groups. You start with a summary of OS names, then OS version, down to OS details with IP, and then

whatever host is connected with that IP. It is a really great category to see what OS versions are connected in your network if your IT department is trying to get rid of WIN 7 machines and needs to tie it to a host for example.

Indications of Compromise:

Here, you can see categories and hit counts of IoC. Some categories will be malware Downloaded, CnC connected, impact 2 attacks, malware detection and malware execution, etc. You can then click on the category and see all of your IP addresses that match that category of compromise. It will list the event type, description, first seen and last seen time variables.

From here, you can see the exact IPs with these compromised events. You will want to click on the red host profile. You will be able to do a deep dive on the IoC event to further threat hunt.

Applications:

You can see all the applications that your FMC/FTDs have identified. It will also show the host count that have hit those applications such as SSL clients, Microsoft apps, O365 apps, etc.

Application Details:

This section is just like the Application section however it specifies the web application, application protocol, and client group with the hit count. (Not just the application and hit count)

Servers:

The Servers Section of the host profile lists servers either detected on hosts on your monitored network, added from exported NetFlow records, or added through an active source like a scanner or the host input feature. The list can include up to 100 servers per host. After that limit is reached, new server information from any source, whether active or passive, is discarded until you delete a server from the host or a server times out.

If you scan a host using Nmap, Nmap adds the results of previously undetected servers running on open TCP ports to the Servers list. If you perform an Nmap scan or import Nmap results, an expandable Scan Results section also appears in the host profile, listing the server information detected on the host by the Nmap scan. In addition, if the host is deleted from the network map, the Nmap scan results for that server for the host are discarded.

https://www.cisco.com/c/en/us/td/docs/security/firepower/640/configura tion/guide/fpmc-config-guide-v64/using host profiles.html#ID-2218-00000207

Host Attributes:

You can use host attributes to classify hosts in ways that are important to your network environment. he Firepower Management Center provides two predefined host attributes:

Host Criticality

Use this attribute to designate the business criticality of a given host and to tailor correlation responses to host criticality. For example, if you consider your organization's mail servers more critical to your business than a typical user workstation, you can assign a value of High to your mail servers and other business-critical devices and Medium or Low to other hosts. You can then create a correlation policy that launches different alerts based on the criticality of an affected host.

Notes

Use this host-specific attribute to record information about the host that you want other analysts to view. For example, if you have a computer on the network that has an older, unpatched version of an operating system that you use for testing, you can use the Notes feature to indicate that the system is intentionally unpatched.

https://www.cisco.com/c/en/us/td/docs/security/firepower/640/configura tion/guide/fpmc-config-guide-v64/using host profiles.html#ID-2218-00000493

Discovery Events:

The Discovery Statistics page displays a summary of the hosts, events, protocols, application protocols, and operating systems detected by the system.

The page lists statistics for the last hour and the total accumulated statistics. You can choose to view statistics for a particular device, or all devices. You can also view events that match the entries on the page by clicking the event, server, operating system, or operating system vendor listed within the summary.

https://www.cisco.com/c/en/us/td/docs/security/firepower/640/configura tion/guide/fpmc-config-guide-v64/working_with_discovery_events.html

Vulnerabilities:

Here we can see all the vulnerabilities that the snort engine has gathered by analyzing traffic/packets. You can also see vulnerabilities in detail and "on the network" as well. It will list an IP address, the snort ID, title of the CVE, vulnerability impact, description, etc. You can click on the specific vulnerability to filter all the IPs that have it or you can filter based on vulnerability impact score and tackle each one from there.

https://www.cisco.com/c/en/us/td/docs/security/firepower/640/configura tion/guide/fpmc-config-guide-v64/using host profiles.html#ID-2218-000006a7

<u>Third-Party Vulnerabilities:</u>

Same as above except more focused on adding a mapping to a vulnerability. If you had more information about a CVE from a third party

resource, you can create a new vulnerability map set and enter the identification of the vulnerability ID and enter a description. https://www.cisco.com/c/en/us/td/docs/security/firepower/630/configuration/guide/fpmc-config-guide-v63/host_identity_sources.html#ID-2219-00000344

Users Active Sessions:

Here, you will be able to see VPN authentication types. Whenever a user signs onto the vpn, it will log it in the Users active sessions area. You can see current IPs, time stamps, and discover identities of the user. You can also see the discovery application (most likely LDAP if it is a vpn authentication) and the device (most likely firewall).

User:

This is a list of discovered users in your network, found by the FTDs and mapping logon usernames to the discovery application.

User Activity:

Like above, you can see users signing into an application with the VPN authentication type. It will contain time stamps, event types, users, discovery application, IP addresses, the VPN session type, what VPN group policy attached, VPN connection profile, vpn client public IP, etc.

User indications of Compromise:

Same as the other indications of compromise category except specifically with users.

<u>Correlation Events:</u>

You can use the correlation feature to respond in real time to threats to your network, using correlation policies. A correlation policy violation occurs when the activity on your network triggers either a correlation rule or compliance white list within an active correlation policy. For example,

you can create a correlation rule that <u>a discovery event</u> occurs and an <u>new IP host is detected</u> and it meets the following conditions: IP address is in 10.4.0.0/16. Generally used for creating whitelists as well.

https://www.cisco.com/c/en/us/td/docs/security/firepower/60/configuration/guide/fpmc-config-guide-v60/Correlation Policies.html#ID-2204-0000011a

Allow List Events:

Events that hit the allowed list.

https://www.cisco.com/c/en/us/td/docs/security/firepower/70/configuration/guide/fpmc-config-guide-v70/correlation and compliance events.pdf

Allow List Violations:

Events that violated the allow list.

https://www.cisco.com/c/en/us/td/docs/security/firepower/70/configuration/guide/fpmc-config-guide-v70/correlation_and_compliance_events.pdf

Status:

Shows current status of events.

https://www.cisco.com/c/en/us/td/docs/security/firepower/70/configuration/guide/fpmc-config-guide-v70/correlation and compliance events.pdf

Advanced Custom Workflows:

If the predefined and Cisco-provided custom workflows do not meet your needs, you can create and manage custom workflows.

Custom workflows are workflows that you create to meet the unique needs of your organization. When you create a custom workflow, you choose the kind of event (or database table) on which the workflow is based. On the Firepower Management Center, you can base a custom workflow on a custom table. You can also choose the pages a custom workflow contains; custom workflows can contain drill-down, table view, and host or packet view pages. Defaults are down below...

Table 1. Saved Custom Workflows

Workflow Name	Description
Events by Impact, Priority, and Host Criticality	You can use this workflow to quickly pick out and focus in on hosts that are important to your network, currently vulnerable, and possibly currently under attack.
	This workflow is based on the Intrusion Events with Destination Criticality custom table.
Events by Priority and Classification	This workflow lists events and their type in order of event priority, along with a count showing how many times each event has occurred.
	This workflow is based on the Intrusion Events custom table.
Events with Destination, Impact, and Host Criticality	You can use this workflow to find the most recent attacks on hosts that are important to your network and currently vulnerable.
	This workflow is based on the Intrusion Events with Destination Criticality custom table.
Hosts with Servers Default Workflow	You can use this workflow to quickly view the basic information in the Hosts with Servers custom table.
	This workflow is based on the Hosts with Servers custom table.
Intrusion Events with Destination Criticality Default Workflow	You can use this workflow to quickly view the basic information in the Intrusion Events with Destination Criticality custom table.
	This workflow is based on the Intrusion Events with Destination Criticality custom table.
Intrusion Events with Source Criticality Default Workflow	You can use this workflow to quickly view the basic information in the Intrusion Events with Source Criticality custom table.
	This workflow is based on the Intrusion Events with Source Criticality custom table.
Server and Host Details	You can use this workflow to determine what servers are most frequently used on your network and which hosts are running those servers.
	This workflow is based on the Hosts with Servers custom table.

https://www.cisco.com/c/en/us/td/docs/security/firepower/650/configuration/guide/fpmc-config-guide-v65/custom workflows.html

Custom Tables:

You can create custom tables in Analysis, advanced, custom tables. Click view to see the custom table you want to view, then customize the table. If you want to create your own, at the top right, you can click create your own custom table. You can then select fields such as applications, business relevance, versioning, web applications, etc.

https://www.cisco.com/c/en/us/td/docs/security/firepower/650/configura tion/guide/fpmc-config-guide-v65/custom_workflows.html#ID-2191-00000bf5

GeoLocation:

You can search up specific IPs to find the country, country code, continent, etc of a public IP.

https://www.cisco.com/c/en/us/td/docs/security/firepower/620/configuration/guide/fpmc-config-guide-v62/using lookups.html

URL:

You can search urls to get a reputation score as well as a category list. For instance, you can enter google.com. The category will come up as a search engine and the reputation comes up as Trusted.

https://www.cisco.com/c/en/us/td/docs/security/firepower/620/configuration/guide/fpmc-config-guide-v62/using lookups.html

Whois:

Can enter in a public ip address to get a whole whois report on the public IP. Everything from ISP provider name, address information, org handlers, CIDR range, etc.

https://www.cisco.com/c/en/us/td/docs/security/firepower/622/configuration/guide/fpmc-config-guide-v622/using_lookups.html

Contextual Cross-Launch:

Allows for boosted threat hunting by increasing our threat research vector by combining cisco/third party security solutions to gather more data. This makes external integrations with the FMC event views possible. There are dozens of cross-launch integration links included and you can even create your own custom links. Very handy for pivoting to other systems to gain additional context around a Firepower event.

https://www.cisco.com/c/en/us/td/docs/security/firepower/630/configura tion/guide/fpmc-config-guidev63/analyze events using external tools.html

https://www.ciscolive.com/c/dam/r/ciscolive/emea/docs/2019/pdf/BRKSE C-3328.pdf

Troubleshooting Commands for Cut:

packet-tracer input INSIDE icmp 192.168.103.1 8 0 192.168.101.1 packet-tracer input (interface) (protocol) (source address) (icmp type) (icmp code) (destination IP address)

capture CAPI interface INSIDE match icmp host 192.168.103.1 host 192.168.101.1 capture (name of capture) interface (name of interface) match (protocol) host (Source IP)

Turn crypto debugging on, then generate your packet tracer.

<u>Show Commands for ASA/FTD commands for IPsec VPN:</u>

show crypto ipsec stats
show vpn-sessiondb license-summary
show Version
show run crypto map
more system:running-config
show run crypto ikev2
show crypto isakmp sa
show vpn-sessiondb anyconnect
show vpn-sessiondb detail I2I

IKE S2S w/ IPsec show commands:

show crypto isakmp policy

show crypto engine connections active show crypto isakmp keys show crypto map show crypto isakmp sa debug crypto isakmp debug crypto ipsec

DMVPN Show commands:

show dmvpn show ip nhrp show crypto engine conenctions active show ip route show crypto mapshow ip cef [network] show crypto ipsec sashow crypto isakmp sa

Flex VPN:

show crypto ikev2 proposal show crypto ikev2 sashow crypto ipsec transform-set show crypto ipsec profile show crypto ipsec sa show crypto map

GET VPN w/ Key Server:

show crypto gdoi show crypto gdoi ks show crypto isakmp sa detail show crypto ipsec sa

Remote Access VPNs:

show crypto pki cert show ip int bri show ip route show crypto ikev2 sa show vpn-sessiondb remote