postprocess.m

This script uses the K96 matrix obtained from calibration.m to process the CSV files obtained from LabVIEW during the slosh experiments. It creates plots for the forces and torques of the system, and of the liquid only.

Parameters:

- (Int) **percentageToPlot**: Percentage of the total data to trim the x axis of the plot (0-100).
- (Int) **ssPercentage**: Percentage of what is considered to be the steady state portion of the entire cycles.
- (Boolean) **logParamsBool**: Whether to print to the console the parameters of each file that is being processed (true/false).
- (Boolean) **plotBoolSystem**: Whether to create a window displaying the loads of the system. If looping for several tests, it's recommended to set it to 'false'.
- (Boolean) **plotBoolSlosh**: Whether to create a window displaying the loads caused by the liquid. If looping for several tests, it's recommended to set it to 'false'.
- (Boolean) saveBoolSystem: Whether save the figure of the loads of the system as a 'jpeg' image to storage. If set to 'true', it saves the images to './Plots/'.
- (Boolean) saveBoolSlosh: Whether save the figure of the loads caused by the liquid as a 'jpeg' image to storage. If set to 'true', it saves the images to './Plots/'.
- (Vector) **loadsToPlotSystem**: Vector including the loads to include in the plot of the system loads (where [1,2,3,4,5,6] corresponds to [Fx,Fy,Fz,Tx,Ty,Tz]). (E.g., If plotting all 6: loadsToPlot= [1,2,3,4,5,6], if plotting only Fx and Ty: loadsToPlot=[1,5]).
- (Vector) **loadsToPlotSlosh**: Vector including the loads to include in the plot of the loads caused by the liquid (where [1,2,3,4,5,6] corresponds to [Fx,Fy,Fz,Tx,Ty,Tz]). (E.g., If plotting all 6: loadsToPlot=[1,2,3,4,5,6], if plotting only Fx and Ty: loadsToPlot=[1,5]).
- (Int) **sr**: Sampling rate in Hz.
- (Float) cutoff_f: Cutoff frequency of the filter in Hz.
- (Int) filt order: Order of the filter.
- (Array) **K96**: 9x6 matrix obtained from calibration.m. Change the path to this file if needed.
- (Cell) **fileNamesCell**: Cell containing the data read from "Filenames.xlsx". Change the path to this file if needed.
- (String) empty_files_path: Path to where the empty tank CSVs are.
- (Array) ma: Moment arms for the three sensors. No need to change unless the force sensors are mounted elsewhere in the system.

- (Array) **cyclesPerFreq**: Array relating the frequency of the test (in Hz) to the number of cycles performed at that frequency.
- (Vector) **filterParams**: Vector including the sampling rate, cutoff frequency, and order of the filter.
- (Vector) **grayTestNumbers**: Vector including the test numbers to not process.

Processing

- Change the for loop range to iterate over the desired range of tests.
- The following will iterate for all tests.
 - The if statement inside the for loop will make the script ignore the CSVs in grayTestNumbers .
 - The script uses readtable to import force data from the CSVs.
 - This force data is then passed to <code>getCalibratedLoadsK96</code> where it's detrended, filtered, and converted to a 6 column array containing <code>Fx,Fy,Fz,Tx,Ty,Tz</code>. This is stored in <code>ftArray</code>.
 - The createFTplots function is then used to plot/save this data.
 - Using getThFreqAccDoubleAmpFill, the target frequency, acceleration, double amplitude, and fill percentage are stored in thFreq, thAcc, thDoubleAmp, and thFill.
 - The CSV file name for the empty tank log is obtained using <code>empty_files_path</code> , <code>thFreq</code> , and <code>thAcc</code> . It is stored in <code>empty_file</code> .
 - The location of the peaks of ftArray are obtained using the findStartEndCycles function. This provides information of when the cycles begin and when they end.
 - Using the location of the beginning and the end of the cycles, the location of the beginning and end of the 'steady state' cycles is obtained by making use of ssPercentage. These indexes are saved in ssStart and ssEnd, and the steady state portion of the data is saved in ssLoads.
 - The duration of a single cycle (in number of data points) is obtained using the sample rate and the target frequency. This value is stored in singleCycleDuration.
 - Using getSimpleEmptyTankCycle, a single cycle of the empty tank data is stored in singleEmptyCycle.
 - This data is then used to create a repeated array of greater length than ssLoads. This is then modified to match the length of ssLoads, and to also match the peaks. This is stored in reshapedData.
 - The liquid forces are obtained by subtracting reshapedData from ssLoads.
 - The createFTplots function is then used to plot/save this data.