Pipelining

E. Sanchez


Politecnico di Torino Dipartimento di Automatica e Informatica

Introduction

Pipelining is an implementation technique whereby multiple instructions are overlapped in execution.

In a pipeline, different units (called pipe stages or segments) are completing different parts of different instructions in parallel.

Example



Definitions

The throughput of a pipelined processor is the number of instructions which exit the pipeline in the time unit.

All the pipeline stages are synchronized (they proceed to executing a new task all together); the time for executing one step is called *machine cycle*, and normally corresponds to one clock cycle.

The length of the machine cycle is determined by the slowest stage.

CPI clock cycles per instruction.

Ideal pipeline

In an ideal pipeline, all the stages are perfectly balanced (i.e., they require the same time).

The throughput of an ideal pipeline (i.e., the number of instructions completed in a given time period) is


being n the number of pipeline stages.

Example processor: Unpipelined Implementation


The execution of each instruction may be composed of at most five clock cycles:

- Instruction fetch cycle (IF)
- Instruction decode/register fetch cycle (ID)
- Execution/effective address cycle (EX)
- Memory access/branch completion cycle (MEM)
- Write-back cycle (WB).

The Datapath




Instruction Fetch cycle



Instruction Decode/






Instruction Decode/ Register Fetch

```
A \leftarrow Regs[IR_{6..10}]
B \leftarrow Regs[IR_{11..15}]
Imm \leftarrow (([IR]_{16})^{16} \# IR_{16..31})
```

0 5	6	10	11 15	16 20	25	31
OPcode		rs	rt	rd	sa	function

Instruction Decode/ Register Fetch



Fixed-field decoding: allows for decoding to be performed while registers are read

Execution/Effective Address

Cycle

Memory reference

ALUOutput \leftarrow A + Imm;

Register-Register ALU instruction


ALUOutput \leftarrow A op B;

Register-Immediate ALU instruction

ALUOutput \leftarrow A op Imm;

Branch

ALUOutput \leftarrow NPC + Imm; \blacksquare Cond \leftarrow (A op 0); \blacksquare




Memory Access/Branch Completion Cycle

• Memory reference

LMD ← Mem[ALUOutput] or
Mem[ALUOutput] ← B;

Branch

```
if (cond)
    PC ← ALUOutput
else
    PC ← NPC;
```



Write-back Cycle

Register-Register ALU instruction


Regs[IR_{16..20}] \leftarrow ALUOutput;

Register-Immediate ALU instruction


Regs[IR_{11..15}] \leftarrow ALUOutput;

Load instruction


Regs[IR_{11...15}] \leftarrow LMD;




The Datapath – arithmetic instructions



The Datapath – branch instruction



The Datapath – load/store instruction




Behavior and optimizations

- All instructions require 5 clock cycles, unless branch instructions, which require 4 clock cycles
- Optimizations could be done for reducing the average CPI: as an example, the ALU instructions could be completed during the MEM cycle
- Hardware resources could be optimized by avoiding duplications (e.g., for ALUs, and memory)
- An alternative single-clock architecture (i.e., executing an instruction per clock cycle) can also be considered
- A simple control unit is required to produce the signals required by the datapath.


Example processor: basic pipelined version

- A new instruction is started at each clock cycle
- Different resources work on different instructions at the same time
- At every clock cycle, each resource can be used for one purpose, only. This means that
 - Separate instruction and data memories (i.e., caches)
 must be used
 - The register file is used in two stages: for reading (second half of the cc) in ID and for writing (first half of the cc) in WB. It must be designed to satisfy these requests during the same clock cycle.
 - The PC must be changed in the IF stage. What about branches?
- Pipeline registers must be added between stages.

Pipelined data path



Evolution in time



Pipeline performance

- Pipelining increases the processor throughput without making single instructions faster.
- Single instruction processing is made slower due to the pipeline control overheads.
- The depth of a pipeline is limited by
 - the need for balanced stages
 - pipelining overhead (pipeline register delay and clock skew).

Example

Consider the unpipelined processor, and suppose that

- The clock cycle is 1 ns
- ALU operations and branches require 4 cycles
- Memory operations require 5 cycles
- The relative frequency of these operations is 40%, 20%, and 40%, respectively.

The average instruction execution time is

Example (II)

Suppose that moving to the pipelined architecture slows down the clock of the slowest stage by 20%.

The average instruction execution time is therefore 1.2 ns.

The speedup introduced by pipelining is speedup = 4.4 ns / 1.2 ns = 3.7 times

Pipeline Hazards

Hazards are situations that prevent an instruction from executing during its designated clock cycle.

There are three classes of hazards:

- structural hazards: coming from resource conflict
- data hazards: an instruction depends on the result of a previous instruction
- control hazards: depend on pipelining branches and other instructions that change the PC.

Stalls

One way of dealing with hazards is to force the pipeline to stall, i.e., to block instructions for one or more clock cycles.

When an instruction is stalled:

- the instructions following the stalled instruction are also stalled
- the instructions preceding the stalled instruction continue.

A stall causes the introduction of a *bubble* in the pipeline.

Examp

Suppose that only one access to memory can happen during each clock cycle: therefore, fetch of instruction i+3 can not be performed here and must be delayed.

				Clock cycle num			be delayed.			
Instruction	1	2	3	4	5			8	9	10
Load instruction	IF	ID	EX	MEM	WB	7/				
Instruction $i + 1$		IF	ID	EX	M	WB				
Instruction $i + 2$			IF	ID	EX	MEM	WB			
Instruction $i + 3$				stall	IF	ID	EX	MEM	WB	
Instruction $i + 4$						IF	ID	EX	MEM	WB
Instruction $i + 5$							IF	ID	EX	MEM
Instruction $i + 6$								IF	ID	EX

Examp

As a consequence of the stall, no instruction is completed at clock cycle #8.

			_							
Instruction	1	2	3	4	5	6	7	8		10
Load instruction	IF	ID	EX	MEM	WB					
Instruction $i + 1$		IF	ID	EX	MEM	WB				
Instruction $i + 2$			IF	ID	EX	MEM	WB	,		
Instruction $i + 3$				stall	IF	ID	EX	MEM	WB	
Instruction $i + 4$						IF	ID	EX	MEM	WB
Instruction $i + 5$							IF	ID	EX	MEM
Instruction $i + 6$								IF	ID	EX

STRUCTURAL HAZARDS

They may happen when some pipeline unit is not able to execute all the operations scheduled for a given cycle.

Examples:

- A given unit is not able to complete its task in one clock cycle
- The pipeline owns only one register-file write port, but there are cycles in which two register writes are required
- The pipeline refers to a single-port memory, and there are cycles in which different instructions would like to access to the memory together.

Example

	Clock cycle number											
Instruction	1	2	3	4	5	6	7	8	9	10		
Load instruction	IF	ID	EX	MEM	WB							
Instruction $i + 1$		IF	ID	EX	MEM	WB						
Instruction $i + 2$			IF	ID	EX	MEM	WB					
Instruction $i + 3$				stall	IF	ID	EX	MEM	WB			
Instruction $i + 4$						IF	ID	EX	MEM	WB		
Instruction $i + 5$							IF	ID	EX	MEM		
Instruction $i + 6$								IF	ID	EX		

Example

	Clock cycle number										
Instruction	1	2	3	4	5	6	7	8	9	10	
Load instruction	IF	ID	EX	MEM	WB						
Instruction $i + 1$		IF	ID	EX	MEM	WB					
Instruction $i + 2$			IF	ID	EX	MEM	WB				
Instruction $i + 3$				stall	IF	ID	EX	MEM	WB		
Instruction $i + 4$						IF	ID	EX	MEM	WB	
Instruction $i + 5$							IF	ID	EX	MEM	
Instruction $i + 6$								IF	ID	EX	

Removing Structural Hazards

This requires adding new hardware or improving the existing one.

The designer has to trade-off between performance and cost, basing on the frequency of occurrence of structural hazards.

Example

Load structural hazards happen when two instructions contemporarily try to make a memory access to a single-port memory.

Assume that:

- 40% of instructions make access to memory
- the machine with structural hazard has a clock 1.05 times faster than the one without.

How much faster is the machine without structural hazard?

Solution

For the machine without structural hazard:

Average Instruction Time = $CPI \times clock$ cycle time For the machine with structural hazard:

$$Clock_{str} = \frac{Clock_{ideal}}{1.05} \rightarrow Clock_{ideal} = Clock_{str} *1.05$$

$$Avg\ Instr\ Time_{struct} = CPI_{ideal} + Instr_freq \times Stall_{penalty}$$

Avg Instr Time_{struct} =
$$(1 + 0.4 \times 1) \times Clock_{ideal}[t]/1.05$$

= $1.33 \times Clock_{ideal[t]}$

DATA HAZARDS

Overlapping the execution of instructions, as it is done by pipelining, changes the order of read/write accesses to operands.

This can result in:

- wrong results
- undeterministic behavior.

Example

Let consider the following code fragment:


```
ADD R1, R2, R3
```


SUB R4, R1, R5


AND R6, R1, R7


OR R8, R1, R9


XOR R10, R1, R11











Interrupt effects

If an interrupt occurs during the execution of a critical piece of code (from the point of view of data hazards) correctness may be restored.

This may cause an undeterministic behavior.

Overcoming data hazards effects

The wrong results produced by data hazards can be avoided:

- by stalling the instructions requiring the data until they are available
- by implementing a *forwarding* (or *bypassing*) technique.


Forwarding


A special hardware in the datapath detects when a previous ALU operation should write the register corresponding to the source of the current ALU operation.


In this case, the hardware selects the ALU result as the ALU input rather than the value from the register file.

The hardware must be able

- to forward a data from any of the previously started instructions (provided that they didn't already write the data in its final location)
- not to forward anything, if the following instruction is stalled, or an interrupt occurred.







Generalizing the forward technique

In order to always avoid stalling, forwarding should be made possible between any pipeline register to any input of any functional unit.


Example

ADD R1, R2, R3

LD R4, 0(R1)

SD R4, 12(R1)

Forwarding must occur to ALU and data memory inputs.



Causes of Data Hazards

A hazard is created whenever there is dependence between instructions, and they are close enough that the overlap caused by pipelining would change the order of access to an operand.

In general, this can happen for

- register operands
- memory operands: this is possible if
 - accesses to memory by load and store are not made in the same stage
 - execution can proceed while an instruction waits for a cache miss to be solved.

Data Hazards Requiring Stalls

Not all potential data hazards can be solved through data forwarding.

Example


```
LD R1, 0(R2)
```

SUB R4, R1, R5


AND R6, R1, R7

OR R8, R1, R9

Forwarding-based solution



Solution with stall



Implementing the Control

This requires that at each clock cycle:

- All tests for detecting a possible data hazard concerning an instruction are performed when this is in the ID stage
- If a data hazard is detected, two actions can be alternatively taken:
 - the appropriate forwarding is activated
 - the instruction is stalled before entering the stage where operands are not available (i.e., before being *issued*).

Load Interlock Detection

Situation	Exan sequ	nple code ence	Action
No dependence	LD DADD DSUB OR	Market and the second of the s	No hazard possible because no dependence exists on R1 in the immediately following three instructions.
Dependence requiring stall	LD DADD DSUB OR	R1,45(R2) R5,R1,R7 R8,R6,R7 R9,R6,R7	Comparators detect the use of R1 in the DADD and stall the DADD (and DSUB and OR) before the DADD begins EX.
Dependence overcome by forwarding	LD DADD DSUB OR	R1,45(R2) R5,R6,R7 R8,R1,R7 R9,R6,R7	Comparators detect use of R1 in DSUB and forward result of load to ALU in time for DSUB to begin EX.
Dependence with accesses in order	LD DADD DSUB OR	R1,45(R2) R5,R6,R7 R8,R6,R7 R9,R1,R7	No action required because the read of R1 by 0R occurs in the second half of the ID phase, while the write of the loaded data occurred in the first half.

Load Interlock Detection (cont'd)

The following checks have to be performed when a Load instruction is in the EX stage and another instruction exploiting the loaded value is in the ID stage.

Opcode field of ID/EX (ID/EX.IR ₀₅)	Opcode field of IF/ID (IF/ID.IR ₀₅)	Matching operand fields
Load	Register-register ALU	ID/EX.IR[rt] == IF/ID.IR[rs]
Load	Register-register ALU	ID/EX.IR[rt] == IF/ID.IR[rt]
Load	Load, store, ALU immediate, or branch	ID/EX.IR[rt] == IF/ID.IR[rs]

If operands match, a data hazard is detected and as a result, the control unit must insert a pipeline stall and prevent the instructions in IF and ID stages for advancing.

Introducing a stall

Given an instruction currently in the ID stage, introducing a stall in the EX stage can be done:

- forcing all 0s in the ID/EX pipeline register (corresponding to a nop instruction)
- forcing the IF/ID pipeline register to maintain the current value
- Program counter must be freezed (maintain unaltered IF status).

Forwarding Logic

Forwarding can be implemented

- from the ALU or data memory output
- to ALU inputs, data memory inputs, or the zero detection unit (branch instructions).


The forwarding logic must compare:

- the destination fields of the IR contained in the EX/MEM and MEM/WB registers with
- the source fields of the IR contained in the IF/ID, ID/EX and EX/MEM registers.

Forwarding to the ALU inputs

Pipeline register containing source instruction	egister r ontaining Opcode c ource of source c astruction instruction i		Opcode of destination instruction	Destination of the forwarded result	Comparison (if equal then forward)	
EX/MEM	Register- register ALU	ID/EX	Register-register ALU, ALU immediate, load, store, branch	Top ALU input	EX/MEM.IR ₁₆₂₀ = ID/EX.IR ₆₁₀	
EX/MEM	Register- register ALU	ID/EX	Register-register ALU	Bottom ALU input	EX/MEM.IR ₁₆₂₀ = ID/EX.IR ₁₁₁₅	
MEM/WB	Register- register ALU	ID/EX	Register-register ALU, ALU immediate, load, store, branch	Top ALU input	MEM/WB.IR ₁₆₂₀ = ID/EX.IR ₆₁₀	
MEM/WB	Register- register ALU	ID/EX	Register-register ALU	Bottom ALU input	MEM/WB.IR ₁₆₂₀ = ID/EX.IR ₁₁₁₅	
EX/MEM	ALU immediate	ID/EX	Register-register ALU, ALU immediate, load, store, branch	Top ALU input	EX/MEM.IR ₁₁₁₅ = ID/EX.IR ₆₁₀	
EX/MEM	ALU immediate	ID/EX	Register-register ALU	Bottom ALU input	EX/MEM.IR ₁₁₁₅ = ID/EX.IR ₁₁₁₅	
MEM/WB	ALU immediate	ID/EX	Register-register ALU, ALU immediate, load, store, branch	Top ALU input	MEM/WB.IR ₁₁₁₅ = ID/EX.IR ₆₁₀	
MEM/WB	ALU immediate	ID/EX	Register-register ALU	Bottom ALU input	MEM/WB.IR ₁₁₁₅ = ID/EX.IR ₁₁₁₅	
MEM/WB	Load	ID/EX	Register-register ALU, ALU immediate, load, store, branch	Top ALU input	MEM/WB.IR ₁₁₁₅ = ID/EX.IR ₆₁₀	
MEM/WB	Load	ID/EX	Register-register ALU	Bottom ALU input	MEM/WB.IR ₁₁₁₅ = ID/EX.IR ₁₁₁₅	

Hardware changes to support forwarding to ALU inputs



CONTROL HAZARDS

They are due to branches (conditional and unconditional), which may change the PC after the following instruction has been fetched already.

In the case of conditional branches, the decision on whether the PC should be modified (branch *taken*) or not (branch *untaken*) can be taken even later.


In the MIPS implementation, the PC is written with the target address (if the jump is *taken*) at the end of the ID stage.

Basic solution


A possible solution is based on stalling the pipeline as soon as a branch instruction is detected (ID stage) by:

- decide earlier whether the branch has to be taken or not
- compute earlier the new PC value.


Basic pipelined data path




Modified pipeline




Modified pipeline



Modified pipeline





The branch instruction is taken.

Branch instruction IF ID EX
Branch successor
Branch successor+1
Branch successor+2

MEM WB
ID EX MEM WB
IF ID EX MEM
IF ID EX

This stage fetches the following instruction (as if the branch is not taken).

Branch instruction
Branch successor
Branch successor+1
Branch successor+2

IF ID IF


EX MEM WB

IF ID EX MEM WB

IF ID EX MEM

IF ID EX

This stage fetches the right instruction (which depends on the branch result).



This operation is ALWAYS useless.

Improved solutions

There are several techniques for reducing the performance degradation due to branches:

- freezing the pipeline
- predict untaken
- predict taken
- delayed branch.

Freezing the pipeline

It is the previously proposed solution: the pipeline is stalled (or flushed) as soon as a branch instruction is detected, and until the decision about the branch is known.

It is the simplest solution to implement.

This technique

- assumes the branch is not taken
- avoid any change in the pipeline status until the branch decision has been taken
- undo all the performed operations if the branch turns out to be taken.

Untaken branch instruction	IF	ID	EX	MEM	WB				
Instruction $i + 1$		IF	ID	EX	MEM	WB			
Instruction $i + 2$			IF	ID	EX	MEM	WB		
Instruction $i + 3$				IF	ID	EX	MEM	WB	
Instruction $i + 4$					IF	ID	EX	MEM	WB
Taken branch instruction	IF	ID	EX	MEM	WB				
Instruction $i + 1$		IF	idle	idle	idle	idle			
Branch target			IF	ID	EX	MEM	WB		
Branch target + 1				IF	ID	EX	MEM	WB	
Branch target + 2					IF	ID	EX	MEM	WB

Untaken branch instruction	IF	ID	EX	MEM	WB				
Instruction $i + 1$		IF	ID	EX	MEM	WB			
Instruction $i + 2$			IF	ID	EX	MEM	WB		
Instruction $i + 3$				IF	ID	EX	MEM	WB	
Instruction $i + 4$					IF	ID	EX	MEM	WB

Taken branch instruction	IF	ID	EX	MEM	WB				
Instruction $i + 1$		IF	idle	idle	idle	idle			
Branc			IF	ID	EX	MEM	WB		
Bran This result of	can also	be be		IF	ID	EX	MEM	WB	
Bran obtained by	turnino	tho			IF	ID	EX	MEM	WB

obtained by turning the already fetched instruction into a nop.

Untaken branch instruction	IF	ID	EX	MEM	WB			
Instruction $i + 1$		IF	ID	EX	MEM	WB		
Instruction $i + 2$			IF	ID	EX	MEM	WB	
Instruction $i + 3$								
Instruction <i>i</i> + 4								WB
Taken branch instruction Instruction $i + 1$ Branch target	IF					ch instr g wheth	ruction is ner the	
Branch target + 1				_	•	n or no		
Branch target + 2								WB

If the target address is known before the branch outcome, it may be possible to assume the branch as taken.

Compiler role

If the hardware supports the predict taken or predict untaken scheme, the compiler can improve performance by generating code which maximizes the chance for the processor to make the right prediction.

Example


Considering the loop implementation, the for scheme is suitable for the predict untaken scheme, the do while for the predict taken.

Delayed branch

This technique is based on filling the slot after the branch instruction (named *branch-delay slot*) with instructions which have to be executed no matter the branch outcome.

It is up to the compiler to fill each branch-delay slot with the right instructions.

The processor does nothing special when a branch instruction is decoded.



80 E. Sanci

Delayed-branch scheduling effectiveness

It depends on the compiler ability in finding the right instructions to put in the delay slots.

Using this technique, only about 30% of branches do produce a penalty.

Trend

With the advent of deeply pipelined processors, the delay slots are becoming longer, and the advantages of delayed-branches smaller.

Therefore, several current RISC architectures do not support any more delayed branches.