Automatic Car Wash controller

Project 4, ESDM

Short description

- 1. Create and test Simulink model with a state machine implementing the logic behind a drive-though automatic Car Wash.
- 2. Write a small report on the project:
 - a. briefly describe the overall design you chose (states, transitions etc).
 - b. put screenshots from the tests, to prove the tests work



Figure 1: Automatic Car Wash

Requirements

- 1. The washing machine has 3 programs:
 - quick wash:
 - spray foam for 1 minutes
 - wait another 1 minutes
 - optionally brush for 1 minute
 - rinse for 3 minutes
 - normal wash
 - spray foam for 1 minutes
 - wait another 3 minutes
 - optionally brush for 2 minute
 - rinse for 6 minutes
 - hard wash
 - spray foam for 2 minutes
 - wait another 10 minutes
 - optionally brush for 5 minute
 - rinse for 10 minutes
- 2. The Simulink model has the following inputs and outputs:

Inputs:

- ProgramSelection (number, 0 to 3)
 - -0 = no program selected
 - -1/2/3 = the three programs above
- BrushOption (boolean): if TRUE, brushing is done. If not, the brushing is replaced by waiting for the same amount of time.
- WaterLevel (real number, 0 to 2000 liters): amount of water in the reservoir
- FoamLevel (real number, 0 to 50 liters): amount of foam in the reservoir

Outputs:

- ActivateWaterPump (boolean): when TRUE, water is poured
- ActivateFoamPump (boolean): when TRUE, foam is sprayed
- ActivateBrushMotors (boolean): when TRUE, the brushes are activated
- Machine Status (integer):
 - -0 = IDLE
 - -1 = FOAMING
 - -2 = WAITING
 - -3 = BRUSHING

- -4 = RINSING
- -5 = ERROR
- 3. No program is allowed to start if there is less than 100 liters of water available, or less than 3 liter of Foam. In this case set the output status to ERROR.
- 4. If the ProgramSelection input becomes 0 during an ongoing program, then stop the ongoing program and stop
- 5. If the ProgramSelection input changes to a different program during an ongoing program, then stop the ongoing program and set the output status ERROR.
- 6. Error Control:
 - If foam level does not decrease by at least 1 liter after the first 15 seconds of the foaming phase, there is an error. Stop the program and set the output status ERROR.
 - If water level does not decrease by at least 5 liters after 1 minute of the washing phase, there is an error. Stop the program and set the output status ERROR.
- 7. Use parameters from Matlab whenever for all values you deem necessary (e.g. duration of times etc.). Our customer may want to adjust the parameters at any time.
- 8. Test as many behaviors of your state machine as possible (use one/multiple separate test models if necessary)