



### Data Communications and Networking Fourth Edition

# **Chapter 8**Switching

Figure 8.1 Switched network



#### Figure 8.2 Taxonomy of switched networks



#### 8-1 CIRCUIT-SWITCHED NETWORKS

A circuit-switched network consists of a set of switches connected by physical links. A connection between two stations is a dedicated path made of one or more links. However, each connection uses only one dedicated channel on each link. Each link is normally divided into n channels by using FDM or TDM.

### Topics discussed in this section:


**Three Phases** 

**Efficiency** 

**Delay** 

**Circuit-Switched Technology in Telephone Networks** 

Figure 8.3 A trivial circuit-switched network






**Note** 

In circuit switching, the resources need to be reserved during the setup phase; the resources remain dedicated for the entire duration of data transfer until the teardown phase.

### Example 8.1

As a trivial example, let us use a circuit-switched network connect eight telephones in a small area. Communication is through 4-kHz voice channels. We assume that each link uses FDM to connect a maximum of two voice channels. The bandwidth of each link is then 8 kHz. Figure 8.4 shows the situation. Telephone 1 is connected to telephone 7; 2 to 5; 3 to 8; and 4 to 6. Of course the situation may change when new connections are made. The switch controls the connections.

#### Figure 8.4 Circuit-switched network used in Example 8.1



### Example 8.2

As another example, consider a circuit-switched network that connects computers in two remote offices of a private company. The offices are connected using a T-1 line leased from a communication service provider. There are two  $4 \times 8$  (4 inputs and 8 outputs) switches in this network. For each switch, four output ports are folded into the input ports to allow communication between computers in the same office. Four other output ports allow communication between the two offices. Figure 8.5 shows the situation.

#### Figure 8.5 Circuit-switched network used in Example 8.2





Figure 8.6 Delay in a circuit-switched network



### -

### Note

Switching at the physical layer in the traditional telephone network uses the circuit-switching approach.

### Blocking or Non-blocking

### Blocking

- A blocking network is unable to connect endpoints because the critical paths are in use and there are no alternative paths
- Used on voice systems
  - Short duration calls
- Non-blocking
  - Permits all stations to connect (in pairs) at once
  - Used for some data connections


### Circuit-Switched Routing

- Many connections will need paths through more than one switch
- Need to find a route
  - Efficiency
  - Resilience
- Public telephone switches are a tree structure
  - Static routing uses the same approach all the time
- Dynamic routing allows for changes in routing depending on traffic
  - Uses a peer structure for nodes

### **Alternate Routing**

- Possible routes between end offices predefined
- Originating switch selects appropriate route
- Routes listed in preference order
- Different sets of routes may be used at different times

### Alternate Routing Diagram




(a) Topology

Time Period	First route	Second route	Third route	Fourth and final route
Morning	a	b	c	d
Afternoon	a	d	b	c
Evening	a	d	c	b
Weekend	a	с	b	d

### **Control Signaling Functions**

- Audible communication with subscriber
- Transmission of dialed number
- Call can not be completed indication
- Call ended indication
- Signal to ring phone
- Billing info
- Equipment and trunk status info
- Diagnostic info
- Control of specialist equipment

### **Control Signals**



Note: A broken line indicates repetition of a signal at each office, whereas a solid line indicates direct transmittal through intermediate offices.

### Location of Signaling

- Subscriber to network
  - Depends on subscriber device and switch
- Within network
  - Management of subscriber calls and network
  - More complex

### **In-Channel Signaling**

- Use same channel for signaling and call
  - Requires no additional transmission facilities
- Inband
  - Uses same frequencies as voice signal
  - Can go anywhere a voice signal can
  - Impossible to set up a call on a faulty speech path
- Out-of-band
  - Voice signals do not use full 4kHz bandwidth
  - Narrow signal band within 4kHz used for control
  - Can be sent whether or not voice signals are present
  - Need extra electronics
  - Slower signal rate (narrow bandwidth)


## Drawbacks of In-Channel Signaling


- Limited transfer rate
- Delay between entering address (dialing) and connection
- Overcome by use of common channel signaling

### Common Channel Signaling


- Control signals carried over paths independent of voice channel
- One control signal channel can carry signals for a number of subscriber channels
- Common control channel for these subscriber lines
- Associated Mode
  - Common channel closely tracks interswitch trunks
- Disassociated Mode
  - Additional nodes (signal transfer points)
  - Effectively two separate networks

# Common vs. In-Channel Signaling





### Signaling Modes



### Signaling System Number 7

- SS7
- Most widely used common channel signaling scheme
- Internationally standardized and general purpose

### SS7

- SS7 network and protocol used for:
  - Basic call setup, management, tear down
  - Wireless services such as PCS, roaming, authentication
  - Toll free and toll (900) wireline services
  - Enhanced features such as call forwarding, caller ID, 3-way calling
  - Efficient and secure worldwide telecommunications

### 8-2 DATAGRAM NETWORKS

In data communications, we need to send messages from one end system to another. If the message is going to pass through a packet-switched network, it needs to be divided into packets of fixed or variable size. The size of the packet is determined by the network and the governing protocol.

### Topics discussed in this section:

**Routing Table** 

**Efficiency** 

**Delay** 

**Datagram Networks in the Internet** 

8.27

## Two Basic Forms of Packet Switching

- Packets handled in two ways
  - Datagram (covered in this section)
  - Virtual circuit (covered in the next section)


### Datagram

- Each packet treated independently
- Packets can take any practical route
- Packets may arrive out of order
- Packets may get lost or delayed
- Up to receiver to re-order packets and recover from missing packets

### Virtual Circuit

- Preplanned route established before any packets sent
- Call request and call accept packets establish connection (handshake)
- Each packet contains a virtual circuit identifier instead of destination address
- No routing decisions required for each packet
- Clear request to drop circuit
- Not a dedicated

# Internal Virtual Circuit and Datagram Operation



#### Figure 8.7 A datagram network with four switches (routers)




Figure 8.8 Routing table in a datagram network

	stination address		Output port	
	1232 4150 : 9130		1 2 : 3	
1	1			
	2	3		

### Note


# A switch in a datagram network uses a routing table that is based on the destination address.

### -

### Note

The destination address in the header of a packet in a datagram network remains the same during the entire journey of the packet.

### Figure 8.9 Delay in a datagram network



# -

# Note

Switching in the Internet is done by using the datagram approach to packet switching at the network layer.

## 8-3 VIRTUAL-CIRCUIT NETWORKS


A virtual-circuit network is a cross between a circuitswitched network and a datagram network. It has some characteristics of both.

# Topics discussed in this section:

Addressing
Three Phases
Efficiency
Delay
Circuit Switch

**Circuit-Switched Technology in WANs** 

#### Figure 8.10 Virtual-circuit network



### Figure 8.11 Virtual-circuit identifier




Figure 8.12 Switch and tables in a virtual-circuit network







Figure 8.13 Source-to-destination data transfer in a virtual-circuit network



#### Figure 8.14 Setup request in a virtual-circuit network



#### Figure 8.15 Setup acknowledgment in a virtual-circuit network




# -

# *Note*

In virtual-circuit switching, all packets belonging to the same source and destination travel the same path; but the packets may arrive at the destination with different delays if resource allocation is on demand.

Figure 8.16 Delay in a virtual-circuit network





# Note

Switching at the data link layer in a switched WAN is normally implemented by using virtual-circuit techniques.



A virtual circuit can be either switched or permanent.

If permanent, an outgoing VCI is given to the source, and an incoming VCI is given to the destination.

The source always uses this VCI to send frames to this particular destination.

The destination knows that the frame is coming from that particular source if the frame carries the corresponding incoming VCI.

If a duplex connection is needed, two virtual circuits are established.



#### A PVC has several drawbacks:

- 1. Always connected, so always paying
- 2. Connection is between two parties only. If you need a connection to another point, you need another PVC.

Don't like these disadvantages? Use an SVC.


## 8-4 STRUCTURE OF A SWITCH

We use switches in circuit-switched and packetswitched networks. In this section, we discuss the structures of the switches used in each type of network.


# Topics discussed in this section:

Structure of Circuit Switches Structure of Packet Switches


Figure 8.17 Crossbar switch with three inputs and four outputs



#### Figure 8.18 Multistage switch




# Three Stage Switch




8.53


#### Figure 8.19 Time-slot interchange




### Figure 8.20 Time-space-time switch




### Figure 8.21 Packet switch components




#### Figure 8.22 Input port




### Figure 8.23 Output port




#### Figure 8.24 A banyan switch



#### Figure 8.25 Examples of routing in a banyan switch



a. Input 1 sending a cell to output 6 (110)



b. Input 5 sending a cell to output 2 (010)

# In Summary

- What are the differences between a circuit switched network and a packet switched network?
- Where can the control signals travel in a telephone network?
- What is a non-blocking switch/network?
- What are the differences between datagram packet switched and virtual circuit packet switched?

# In Summary

What are the differences between a circuit switch and a packet switch?