SPIRou Data Reduction Software

Developer Guide

0.0.1

For DRS SPIRou0.0.1

N. Cook, F. Bouchy, E. Artigau, I. Boisse, M. Hobson, C. Moutou 2017-11-27



Abstract

This is the guide to coding the DRS (including installation, running, rules and stardisation approaches). This document is not intended for the general used of the DRS, instead it is intended for those who wish to develop the software further and understand the changes between this version and previous versions.

Contents

In	trod	uction	iii
	Cod	e blocks	iii
1	Installation		
	1.1	Introduction	1
	1.2	Download	1
	1.3	Prerequisites	2
		1.3.1 Anaconda python distribution	2
		1.3.2 Separate python installation	2
	1.4	Installation Linux and macOS	3
		1.4.1 Extraction	3
		1.4.2 Modify environmental settings	3
		1.4.3 Make recipes executable	3
	1.5	Installation Windows	4
		1.5.1 How to modify environmental settings in windows	4
	1.6	Setting up the DRS	5
	1.7	Validating Installation on Linux and macOS	6
	1.8	Validating Installation on Windows	7
2	Data Architecture		
	2.1	Installed file structure	8
	2.2	The Installation root directory	9
		2.2.1 The bin directory	9
		2.2.2 The SPIROU module directory	10
3	Usi	ng the DRS	11
	~		
4	Sun	nmary of changes (from version AT-4)	12
5	Cod	ling rules and standardisation practises	13
6	Req	uired input header keywords	14
7	Description of Constants and Variables		15
8	The	Recipes	16
9	The	DRS Module	17

Introduction

Code blocks

Certain sections will be written in code blocks, these imply text that is written into a text editor, the command shell console, or a python terminal/script. Below explains how one can distinguish these in this document.

The following denotes a line of text (or lines of text) that are to be edited in a text editor.

```
# A variable name that can be changes to a specific value
VARIABLE_NAME = "Variable Value"
```

These can also be shell scripts in a certain language:

```
#!/usr/bin/bash
# Find out which console you are using
echo $0
# Set environment Hello
export Hello="Hello"
```

```
#!/usr/bin/tcsh
# Find out which console you are using
echo $0
# Set environment Hello
setenv Hello "Hello"
```

The following denotes a command to run in the command shell console

```
CMD input

>>> cd ~/Downloads
```

The following denotes a command line print out

```
Command line output

This is a print out in the command line produced by using the echo command
```

The following denotes a python terminal or python script

```
Python/Ipython

import numpy as np
print("Hello world")
print("{0} seconds".format(np.sqrt(25)))
```

Installation

1.1 Introduction

Once finialised the installation should just be a download, run setup.py and configure the DRS directories, however, during development the following stages are required.

Note: Currently the download repositry on github is private and requires a github account, and the user to be added to the list of collaborators. To be added to the collaborators please email neil.james.cook@gmail.com with your github username.

1.2 Download

Get the latest version of the DRS (for SPIRouversion 0.0.1). Use any of the following ways:

- manually download from here: https://github.com/njcuk9999/spirou_py3
- use Git:

```
CMD input

>>> git checkout https://github.com/njcuk9999/spirou_py3.git
```

• use SVN:

```
CMD input

>>> svn checkout https://github.com/njcuk9999/spirou_py3.git
```

• use ssh:

```
CMD input

>>> scp -r git@github.com:njcuk9999/spirou_py3.git
```

1.3 Prerequisites

It is recommended to install the latest version of Anaconda python distribution, available for Windows, macOS and Linux (here: https://www.anaconda.com/download/). However one can run the DRS on a native python installation.

We recommend python 3 over python 2 for long term continued support (however the latest version of the DRS supports the newest versions of python 2.7).

Note: Before installing the DRS you must have one of the following:

- Latest version of Anaconda (for python 2 or python 3) RECOMMENDED
- An Up-to-date version of python (python 2 or python 3)

1.3.1 Anaconda python distribution

A valid version of the Anaconda python distribution (for python2 or python3) Currently tested version of python are:

- Python 2.7.13 and Anaconda 4.4.0
- Python 3.6.3 and Anaconda 5.0.1 RECOMMENDED

1.3.2 Separate python installation

An up-to-date version of python (either python 2 or python 3) and the following python modules (with version of python they were tested with).

- Python 3.6
 - ASTROPY (tested with version 2.0.2)
 - MATPLOTLIB (tested with version 2.1.0)
 - NUMPY (tested with version 1.13.3)
 - and the following built-in modules (comes with python): DATETIME, FILECMP, GLOB,
 OS, PKG_RESOURCES, SHUTIL, SYS, TIME, WARNINGS
- Python 2.7
 - astropy (tested with version 1.3.2)
 - matplotlib (tested with version 2.0.2)
 - numpy (tested with version 1.12.1)
 - and the following built-in modules (comes with python): ___FUTURE___, COLLECTIONS,
 DATETIME, FILECMP, GLOB, OS, PKG RESOURCES, SHUTIL, SYS, TIME, WARNINGS

1.4 Installation Linux and macOS

Currently the DRS has to be installed manually. This involves the following steps:

- 1. Extraction (Section 1.4.1)
- 2. Modify environmental settings (Section 1.4.2)
- 3. Make recipes executable (Section 1.4.3)

1.4.1 Extraction

The first step is to extract the DRS into a folder (the {INSTALL_DIR}). Do this by using the following commands:

```
CMD input

>>> cd {INSTALL_DIR}

>>> unzip DRS.zip
```

1.4.2 Modify environmental settings

The next step is to modify your PATH and PYTHONPATH environmental variables (to include the {INSTALL DIR}. This depends which shell you are using (type 'echo \$0' to find out which).

In bash open the '.bashrc' text file in your home (∼) directory (or create it if it doesn't exist)

```
bash

export PATH={INSTALL_DIR}/bin/:$PATH

export PYTHONPATH={INSTALL_DIR}:{INSTALL_DIR}/bin/:$PYTHONPATH
```

• In csh /tcsh open the '.cshrc' or '.tcshrc' text file in your home (\sim) directory (or create it if it doesn't exist)

```
tcsh/csh
setenv PATH {INSTALL_DIR}/bin/:${PATH}
setenv PYTHONPATH {INSTALL_DIR}:{INSTALL_DIR}/bin/:${PYTHONPATH}
```

1.4.3 Make recipes executable

To run the recipes from the command line (without starting python) one must make them executable. Do this by using the following command:

```
CMD input

>>> chmod +x {INSTALL_DIR}/bin/*.py
```

1.5 Installation Windows

This is very similar currently to the Linux/macOS installation (in the future a '.exe' file will be given).

- 1. Extract to {INSTALL DIR} with your favourite unzipping softwear.
- 2. Add {INSTALL DIR}to your PYTHONPATH (Section 1.5.1)

1.5.1 How to modify environmental settings in windows

This process is a little more convoluted than on Linux or macOS system.

- 1. Go to 'My computer > Properties > Advanced System Settings > Environmental Variables'.
- 2. if under system variable 'PythonPath' exists click edit and add '{INSTALL_DIR};' to the end.

i.e.

```
text
C:\Python27;{INSTALL_DIR};
```

3. if under system variables 'PythonPath' does not exist create a new variable called 'PythonPath' and add:

```
text
%PYTHONPATH%;{INSTALL_DIR};{INSTALL_DIR}\bin\;
```

For problems/troubleshooting see here: https://stackoverflow.com/questions/3701646/how-to-add-to-the-pythonpath-in-windows-7.

1.6 Setting up the DRS

Before running the DRS one must set the data paths.

```
The 'config.txt' file is located in the {INSTALL_DIR} in the config folder. i.e. at {INSTALL_DIR}/config/config.txt
```

The following keywords **must** be changed (and must be a valid path):

```
= /drs/data/
{TDATA}
                                             / Define the DATA directory
{DRS_ROOT}
                         = /drs/INTROOT/
                                               Define the installation direc-
                                               tory ({INSTALL DIR})
{DRS_DATA_RAW}
                         = /drs/data/raw
                                               Define the folder with the raw
                                               data files in
{DRS DATA REDUC}
                         = /drs/data/reduced /
                                               Define the directory that the
                                               reduced data should be saved
                                               to/read from
{DRS_CALIB_DB}
                         = /drs/data/calibDB /
                                               Define the directory that the
                                               calibration files should be
                                               saved to/read from
{DRS DATA MSG}
                         = /drs/data/msg
                                               Define the directory that the
                                               log messages are stored in
{DRS DATA WORKING} = /drs/data/tmp/
                                               Define the working directory
```

The directories here are for linux and macOS systems another example would be '/home-/user/INTROOT' for the {INSTALL_DIR} directory.

On Windows machines this would be equivalent to 'C:\Users\<username>\INTROOT' in Windows Vista, 7, 8 and 10 or 'C:\Documents and Settings\<username>\INTROOT' on

The following keywords can be changed:

early versions of Windows.

```
{DRS_PLOT} = 1 / Whether to show plots
{PRINT_LEVEL} = "all" / Level at which to print
{LOG_LEVEL} = "all" / Level at which to log in log file
```

For the '{PRINT LEVEL} and {LOG LEVEL} keywords the values are set as follows:

- "all" prints all events
- "info" prints info, warning and error events
- "warning" prints warning and error events
- "error" print only error events

1.7 Validating Installation on Linux and macOS

Note: One must install the DRS (Section 1.4) AND set up the DRS (Section 1.6) before validation will be successful.

There are four ways to run the DRS in Linux and macOS (thus four ways to verify installation was correct).

• To validate running from command line type:

```
CMD input

>> cal_validate_spirou.py
```

• To validate running from python/ipython from the command line type:

```
CMD input

>>> python cal_validate_spirou.py

>>> ipython cal_validate_spirou.py
```

• To validate running from ipython, open ipython and type:

```
Python/Ipython

run cal_validate_spirou.py
```

• To validate running from import from python/ipython, open python/ipython and type:

```
Python/Ipython

import cal_validate_spirou
cal_validate_spirou.main()
```

If validation is successful the following should appear:

```
Command line output
HH:MM:SS.S -
              | | **********************
HH:MM:SS.S -
              || * SPIROU @(#) Geneva Observatory (0.0.1)
              || ***********************
HH:MM:SS.S -
HH:MM:SS.S -
              ||(dir_data_raw)
                                  DRS_DATA_RAW=/scratch/Projects/spirou_py3/data/raw
HH:MM:SS.S -
              ||(dir_data_reduc)
                                  DRS_DATA_REDUC=/scratch/Projects/spirou_py3/data/reduced
HH:MM:SS.S -
              ||(dir_calib_db)
                                  DRS_CALIB_DB=/scratch/Projects/spirou_py3/data/calibDB
HH:MM:SS.S - ||(dir_data_msg)
                                  DRS_DATA_MSG=/scratch/Projects/spirou_py3/data/msg
HH:MM:SS.S - ||(print_level)
                                  PRINT_LEVEL=all
                                                          %(error/warning/info/all)
HH:MM:SS.S -
              ||(log_level)
                                  LOG_LEVEL=all
                                                        %(error/warning/info/all)
HH:MM:SS.S -
              ||(plot_graph)
                                  DRS_PLOT=1
                                                        %(def/undef/trigger)
HH:MM:SS.S -
              ||(used_date)
                                  DRS_USED_DATE=undefined
HH:MM:SS.S -
              ||(working_dir)
                                  DRS_DATA_WORKING=/scratch/Projects/spirou_py3/data/tmp/
HH:MM:SS.S -
                                  DRS_INTERACTIVE is not set, running on-line mode
HH:MM:SS.S -
HH:MM:SS.S -
              ||Validation successful. DRS installed corrected.
```

1.8 Validating Installation on Windows

Note: One must install the DRS (Section 1.5) AND set up the DRS (Section 1.6) before validation will be successful.

In windows there are currently 3 ways to run the RS (running in python/ipython).

• To validate running from python/ipython from the command line type:

```
CMD input

>>> python cal_validate_spirou.py

>>> ipython cal_validate_spirou.py
```

• To validate running from ipython, open ipython and type:

```
Python/Ipython

run cal_validate_spirou.py
```

• To validate running from import from python/ipython, open python/ipython and type:

```
Python/Ipython

import cal_validate_spirou
cal_validate_spirou.main()
```

If validation is successful the following should appear:

```
Command line output
HH:MM:SS.S -
              || *********************
HH:MM:SS.S -
              || * SPIROU @(#) Geneva Observatory (0.0.1)
HH:MM:SS.S -
              || *********************
HH:MM:SS.S -
                                   DRS_DATA_RAW=/scratch/Projects/spirou_py3/data/raw
              ||(dir_data_raw)
HH:MM:SS.S -
              ||(dir_data_reduc)
                                   DRS_DATA_REDUC=/scratch/Projects/spirou_py3/data/reduced
HH:MM:SS.S -
              ||(dir_calib_db)
                                   DRS_CALIB_DB=/scratch/Projects/spirou_py3/data/calibDB
HH:MM:SS.S -
              ||(dir_data_msg)
                                   DRS_DATA_MSG=/scratch/Projects/spirou_py3/data/msg
HH:MM:SS.S -
              ||(print_level)
                                   PRINT_LEVEL=all
                                                          %(error/warning/info/all)
HH:MM:SS.S -
              ||(log_level)
                                   LOG_LEVEL=all
                                                        %(error/warning/info/all)
HH:MM:SS.S -
              ||(plot_graph)
                                   DRS_PLOT=1
                                                        %(def/undef/trigger)
HH:MM:SS.S -
              ||(used_date)
                                   DRS_USED_DATE=undefined
HH:MM:SS.S -
              ||(working_dir)
                                   DRS_DATA_WORKING=/scratch/Projects/spirou_py3/data/tmp/
HH:MM:SS.S -
                                   DRS_INTERACTIVE is not set, running on-line mode
HH:MM:SS.S -
              ||Validation successful. DRS installed corrected.
HH:MM:SS.S -
```

Data Architecture

Described below is the file structure, after correct installation (Chapter 1).

2.1 Installed file structure

The file structure should look as follows:

```
{dir}
  _{DRS_ROOT}
    _{\tt bin}
            ......Recipes
              documentation
            SpirouDRS
                 ......The DRS Module
 {DATA_ROOT}*
   calibDB
  msg
   raw
    YYYYMMDD ......Observation directory
          reduced
  _tmp
* This is the recommended file structure and raw, reduced, calibDB, msg and tmp
can be changed using the {DATA_ROOT_RAW}, {DATA_ROOT_REDUCED},
{DATA ROOT CALIB}, {DATA ROOT MSG}, and {DATA ROOT TMP} variables
in Section 1.6.
```

i.e. for the paths given in Section 1.6 this would be:

```
drs
 INTROOT
  _bin
   documentation
   _ ...... Documentation files
  SpirouDRS
   data
  calibDB
  msg
  raw
   YYYYMMDD ......Observation directory
       ......Raw observation files
  reduced
  _tmp
```

2.2 The Installation root directory

The {INSTALL_ROOT} contains all the installed recipes, modules functions, documentation and configuration files needed to run the DRS. The file structure is set up as below:

2.2.1 The bin directory

The bin directory is located in the {INSTALL_ROOT} directory. This contains all the recipes that can be used. A detailed description of all recipes can be found in Chapter 8 but are listed here for completeness.

- cal DARK spirou.py
- cal DRIFT RAW spirou.py
- cal extract RAW spirou.py
- cal_extract_RAW_spirouAB.py
- \bullet cal_extract_RAW_spirouC.py
- \bullet cal_FF_RAW_spirou.py
- cal_loc_RAW_spirou.py
- cal SLIT spirou.py
- cal validate spirou.py

2.2.2 The SPIROU module directory

The SpirouDRS directory is the SPIROU DRS package, it contains all sub-packages that contain all the worker functions and code associated with the recipes. The file structure is as follows:

```
SpirouDRS
 spirouBACK
  __....The SPIRou background module
 spirouCDB
   _____The SPIRou calibration database module
 spirouConfig
   ......The SPIRou configuration tools module
 spirouEXTOR
   ______The SPIRou extraction module
 spirouFLAT
   _____The SPIRou Flat field module
 spirouImage
  spirouLOCOR
  _.....The SPIRou localization module
 spirouRV
  \_ ...... The SPIRou radial velocity module
 spirouStartup
  _ ..... The SPIRou start up tools module
```

Using the DRS

Summary of changes (from version AT-4)

Coding rules and standardisation practises

Required input header keywords

Description of Constants and Variables

The Recipes

The DRS Module