

Feed your yarn through the yarn guide and then through the needle.



Firmly press your gun against the stretched tufting cloth.



Press the trigger to start. Move the gun in the direction of the foot (like a sewing machine).



Make straight lines, bottom to top. If you are well practiced, try making curves.



Remember, think safety, be carefull with electric appliances and sharp items.

For the extended manuals, videos and safety instructions go to tuftingshop.com