POWER8 in-core Cryptography The Unofficial Guide

Jeffrey Walton Dr. William Schmidt

POWER8 in-core Cryptography: The Unofficial Guide by Jeffrey Walton and Dr. William Schmidt Extensive review and rough drafts: Segher Boessenkool

Publication date 1 April 2018

Table of Contents

1. Introduction
Organization
Compile Farm
2. Vector programming
PowerPC compilers
Altivec headers
Machine endianness
Memory allocation
Vector datatypes
Vector shifts
Vector dereferences
Aligned loads
Unaligned loads
Big-endian loads
Const pointers
3. Runtime features
AIX features
Linux features
SIGILL probes
L1 Data Cache
4. Advanced Encryption Standard
AES encryption
AES decryption
AES key schedule
5. Secure Hash Standard
Sigma functions
Ch function
Maj function
SHA-256
SHA-512
6. Polynomial multiplication
CRC-32 and CRC-32C
GCM mode
7. Assembly language
Cryptogams
sha2-le
8. References
Cryptogams
GitHub
IBM website
NIST website
Stack Exchange
Index

Chapter 1. Introduction

This document is a guide to using IBM's POWER8 in-core cryptography [https://www.ibm.com/develop-erworks/learn/security/index.html]. The purpose of the book is to document in-core cryptography more completely for developers and quality assurance personnel who wish to take advantage of the features.

POWER8 in-core cryptography includes CPU instructions to acclerate AES, SHA-256, SHA-512 and polynomial multiplication. This document includes treatments of AES, SHA-256 and SHA-512. It does not include a discussion of polynomial multiplication at the moment, but the chapter is stubbed-out (and waiting for a contributor).

The POWER8 extensions for in-core cryptography find its ancestry in Altivec SIMD coprocessor. The POWER8 vector unit includes Vector Multimedia Extension (VSX) and the instruction set for in-core cryptography are part it. You can find additional information on VSX at IBM's website at TODO [https://www.ibm.com/developerworks/].

The source code in the book is a mix of C and C++. The SHA-256 and SHA-512 samples were written in C++ to avoid compile errors due to the SHA API requiring 4-bit literal constants. We could not pass parameters through functions and obtain the necessary constexpr-ness so template parameters were used instead.

Organization

The book proceeds in six parts. First, administriva is discussed, like how to determine machine endianness and how to load and store a vector from memory. A full treatment of vector programming is its own book, but the discussion should be adequate to move on to the more interesting tasks.

Second, AES is discussed. AES is specified in FIPS 197, Advanced Encryption Standard (AES) [https://nvlpubs.nist.gov/nistpubs/fips/nist.fips.197.pdf]. You should read the standard if you are not familiar with the block cipher.

Third, SHA is discussed. SHA is specified in FIPS 180-4, Secure Hash Standard (SHS) [https://nvlpubs.nist.gov/nistpubs/fips/nist.fips.180-4.pdf]. You should read the standard if you are not familiar with the hash.

Fourth, polynomial multiplication is discussed. Polynomial multiplications is important for CRC-32, CR-C-32C and GCM mode of operation for AES.

Fifth, performance is discussed. The implementations are compared against C and C++ routines and assembly language routines from OpenSSL. The OpenSSL routines are high quality and written by Andy Polyakov.

Finally, assembly language integration is discussed. Andy Polyakov dual licenses his cryptographic implementations and you can use his routines once you know how to integrate them.

Compile Farm

The book makes frequent references to gcc112 and gcc119 from the GCC Compile Farm. The Compile Farm offers four 64-bit PowerPC machines, and gcc112 and gcc119 are the POWER8 iron (the other two are POWER7 hardware). gcc112 is a Linux PowerPC, 64-bit, little-endian machine (ppc64-le), and gcc119 is an AIX PowerPC, 64-bit, big-endian machine (ppc64-be).

Both POWER8 machines are IBM POWER System S822 with two CPU cards. gcc112 has 160 logical CPUs and runs at 3.4 GHz. gcc119 has 64 logical CPUs and runs at 4.1 GHz. At 4.1 GHz and 192 GB of RAM gcc119 is probably a contender for one of the fastest machine you will work on.

If you are a free and open software developer then you are eligible for a free GCC Compile Farm [https://cfarm.tetaneutral.net/] account. The Cfarm provides machines for different architectures, inlcuding MIPS64, Aarch64 and PowerPC64. Access is provided through SSH.

TODO: This book is free software. If you see an opportunity for improvement, and error or an omission then submit a pull request or open a bug report.

Chapter 2. Vector programming

Several topics need to be discussed to minimize trouble when using the Ativec and POWER8 extensions. They include PowerPC compilers and options, Altivec headers, machine endianness, vector datatypes, memory and alignment, and loads and stores. It is enough information to get to the point you can use AES and SHA but not much more.

Memory alignment, loads, stores and shifts will probably cause the most trouble for someone new to PowerPC vector programming. If you are new to the platform you may want to read this chapter twice. If you are experienced with the platform then you probably want to skip this chapter.

PowerPC compilers

Two compilers are used for testing. The first is GCC and the second is IBM XL C/C++. The compilers are mostly the same but slightly different with their options.

Compiling a test program with GCC will generally look like below. The important part is -mcpu=power8 which selects the POWER8 Instruction Set Architecture (ISA).

```
$ g++ -mcpu=power8 test.cxx -o test.exe
```

Complimentary, compiling a test program with IBM XL C/C++ will generally look like below. The important parts are the C++ compiler name of xlC, and -qarch=pwr8 which selects the POWER8 ISA.

```
$ xlC -qarch=pwr8 -qaltivec test.cxx -o test.exe
```

When compiling source code to examine the quality of code generation the program should be compiled with -03. Both compilers consume -03.

Altivec headers

The header required for datatypes and functions is <altivec.h>. To support compiles with a C++ compiler __vector keyword is used rather than vector. A typical Altivec include looks as shown below.

```
#if defined(__ALTIVEC__)
# include <altivec.h>
# undef vector
# undef pixel
# undef bool
#endif
```

In addition to __ALTIVEC__ preprocessor macro you will see the following defines depending on the platform:

- __powerpc__ and __powerpc on AIX
- __powerpc__ and __powerpc64__ on Linux
- _ARCH_PWR3 through _ARCH_PWR9 on AIX and Linux
- __linux___, __linux and linux on Linux
- _AIX, and _AIX32 through _AIX72 on AIX
- __xlc__ and __xlc__ when using IBM XL C/C++

Machine endianness

You will experience both little-endian and big-endian machines in the field when working with a modern PowerPC architecture. Linux is generally little-endian, while AIX is big-endian.

When writing portable source code you should check the value of preprocessor macros __LIT-TLE_ENDIAN__ or __BIG_ENDIAN__ to determine the configuration. The value of the macros __BIG_ENDIAN__ and __LITTLE_ENDIAN__ are defined to non-0 to activate the macro. Source code checking endianness should look similar to the code shown below.

```
#if __LITTLE_ENDIAN__
# error "Little-endian system"
#else
# error "Big-endian system"
#endif
```

The compilers can show the endian related preprocessor macros available on a platform. Below is from GCC on gcc112 from the compile farm, which is ppc64-le.

```
$ g++ -dM -E test.cxx | grep -i endian
#define __ORDER_LITTLE_ENDIAN__ 1234
#define _LITTLE_ENDIAN 1
#define __FLOAT_WORD_ORDER__ _ORDER_LITTLE_ENDIAN__
#define __ORDER_PDP_ENDIAN__ 3412
#define __LITTLE_ENDIAN__ 1
#define __ORDER_BIG_ENDIAN__ 4321
#define __BYTE_ORDER__ _ORDER_LITTLE_ENDIAN__
```

And the complimentary view from IBM XL C/C++ on gcc112 from the compile farm, which is ppc64-le.

```
$ xlC -qshowmacros -E test.cxx | grep -i endian
#define _LITTLE_ENDIAN 1
#define _BYTE_ORDER__ _ORDER_LITTLE_ENDIAN__
#define __FLOAT_WORD_ORDER__ _ORDER_LITTLE_ENDIAN__
#define __LITTLE_ENDIAN__ 1
#define __ORDER_BIG_ENDIAN__ 4321
#define __ORDER_LITTLE_ENDIAN__ 1234
#define __ORDER_PDP_ENDIAN__ 3412
#define __VEC_ELEMENT_REG_ORDER__ _ORDER_LITTLE_ENDIAN__
```

However, below is gcc119 from the compile farm, which is ppc64-be. It runs AIX and notice __BYTE_ORDER_, __ORDER_BIG_ENDIAN__ and __ORDER_LITTLE_ENDIAN__ are not present.

```
$ xlC -qshowmacros -E test.cxx | grep -i endian
#define __BIG_ENDIAN__ 1
#define _BIG_ENDIAN 1
#define __THW_BIG_ENDIAN__ 1
#define __HHW_BIG_ENDIAN__ 1
```

Memory allocation

System calls like malloc and calloc (and friends) are used to acquire memory from the heap. The system calls *do not* guarantee alignment to any particular boundary on all platforms. Linux generally returns

a pointer that is at least 16-byte aligned on all platforms, including ARM, PPC, MIPS and x86. AIX *does not* provide the same alignment behavior [http://stackoverflow.com/q/48373188/608639].

To avoid unexpected surprises when using heap allocations you should use posix_memalign [http://pubs.opengroup.org/onlinepubs/009695399/functions/posix_memalign.html] to acquire heap memory aligned to a particular boundary and free to return it to the system.

AIX provides routines for vector memory allocation and alignment. They are vec_malloc and vec_free, and you can use then like _mm_malloc on Intel machines with Streaming SIMD Extensions (SSE).

Vector datatypes

Three vector datatypes are needed for in-core programming. The three types used for crypto are listed below.

```
    __vector unsigned char
```

- __vector unsigned int
- __vector unsigned long

__vector unsigned char is arranged as 16 each 8-bit bytes, and it is typedef'd as uint8x16_p8. __vector unsigned int is arranged as 4 each 32-bit words, and it is typedef'd as uint32x4_p8.

POWER8 added __vector unsigned long and associated vector operations. __vector unsigned long is arranged as 2 each 64-bit double words, and it is typedef'd as uint64x2_p8.

The typedef naming was selected to convey the arrangement, like 32x4 and 64x2. The trailing _p8 was selected to avoid collisions with ARM NEON vector data types. The suffix _p (for POWER architecture) or _v (for Vector) would work just as well.

Vector shifts

Altivec shifts and rotates are performed using *Vector Shift Left Double by Octet Immediate*. The vector shift and rotate built-in is vec_sld and it compiles/assembles to vsldoi. Both shift and rotate operate on a concatenation of two vectors. Bytes are shifted out on the left and shifted in on the right. The instructions need an integral constant in the range 0 - 15, inclusive.

Vector shifts and rotates perform as expected on big-endian machines. Little-endian machines need a special handling to produce correct results and the IBM manuals don't tell you about it [http://www.ibm.com/support/knowledgecenter/SSXVZZ_13.1.4/com.ibm.xlcpp1314.lelin-ux.doc/compiler_ref/vec_sld.html]. If you are like many other developers then you will literally waste hours trying to figure it out what happened the first time you experience it.

The issue is shifts and rotates are endian sensitive [http://stackoverflow.com/q/46341923/608639], and you have to use 16-n and swap vector arguments on little-endian systems. The C++ source code provides the following template function to compensate for the little-endian behavior.

```
template <unsigned int N, class T>
T VectorShiftLeft(const T val1, const T val2)
{
#if __LITTLE_ENDIAN__
    enum {R = (16-N)&0xf};
```

```
return vec_sld(val2, val1, R);
#else
    enum {R = N&Oxf};
    return vec_sld(val1, val2, R);
#endif
}
```

A VectorRoatetLeft would be similar to the code below, if needed. Rotate is a special case of shift where both vector arguments are the same value.

```
template <unsigned int N, class T>
T VectorRotateLeft(const T val)
{
#if __LITTLE_ENDIAN__
    enum {R = (16-N)&0xf};
    return vec_sld(val, val, R);
#else
    enum {R = N&0xf};
    return vec_sld(val, val, R);
#endif
}
```

Vector dereferences

The OpenPOWER manual recommends using vector pointers and dereferences to perform loads and stores [http://openpowerfoundation.org/wp-content/uploads/resources/leabi/content/dbdo-clet.50655244_39970.html]. According to the manual, "the preferred way to access vectors at an application-defined address is by using vector pointers and the C/C++ dereference operator *." The manual then provides the following example.

```
vector char vca;
vector char vcb;
vector int via;
int a[4];
void *vp;
via = *(vector int *) &a[0];
vca = (vector char) via;
vcb = vca;
vca = *(vector char *)vp;
*(vector char *)&a[0] = vca;
```

The technique in the OpenPOWER manual requires aligned memory addresses so use it with care. In fact running the example with int a[4] initialized to {1,2,3,4} produces incorrect results [http://stack-overflow.com/q/47743384/608639] because alignment requirements for int and vector are different. The easiest way to ensure trouble free vector programming is POWER7 unaligned loads and stores.

Aligned loads

Altivec loads and stores have traditionally been performed using vec_ld and vec_st since at least the POWER4 days in the early 2000s. vec_ld and vec_st are sensitive to alignment of the memory address and the offset into the address. The effective address is the sum address+offset rounded down or masked to a multiple of 16.

Altivec *does not* raise a SIGBUS to indicate a misaligned load or store. Instead, the bottom 4 bits of the sum address+offset are masked-off and then the memory at the effective address is loaded.

You can use the Altivec loads and stores when you *control* buffers and ensure they are 16-byte aligned, like an AES key schedule table. Otherwise just use unaligned loads and stores to avoid trouble.

The C/C++ code to perform a load using vec_ld should look similar to below. Notice the assert to warn you of problems in debug builds.

```
template <class T>
uint32x4_p8 VectorLoad(const T* mem_addr, int offset)
#ifndef NDEBUG
    uintptr_t maddr = ((uintptr_t)mem_addr)+offset;
    uintptr_t mask = ~(uintptr_t)0xf;
    uintptr t eaddr = maddr & mask;
    assert(maddr == eaddr);
#endif
    return (uint32x4 p8)vec ld(offset, (uint8 t*)mem addr);
The C/C++ code to perform a store using vec st should look similar to below.
template <class T>
void VectorStore(T* mem_addr, int offset)
#ifndef NDEBUG
    uintptr_t maddr = ((uintptr_t)mem_addr)+offset;
    uintptr t mask = \sim(uintptr t)0xf;
    uintptr t eaddr = maddr & mask;
    assert(maddr == eaddr);
#endif
    vec_st(offset, (uint8_t*)mem_addr);
```

Casting away const-ness on mem_addr is discussed in const pointers below.

Unaligned loads

POWER7 introduced unaligned loads and stores that avoid the aligned memory requirements. The instructions for unaligned loads and stores are vec_vsx_ld and vec_vsx_st for GCC; and vec_xl and vec_xst for XLC.

You should use the POWER7 loads and stores whenever you *do not control* buffers or their alignments, like messages supplied by user code.

The C/C++ code to perform a load using vec_xl and vec_vsx_ld should look similar to below. The function name has a u added to indicate unaligned.

```
template <class T>
uint32x4_p8 VectorLoadu(const T* mem_addr, int offset)
{
#if defined(__xlc__) || defined(__xlc__)
```

```
return (uint32x4_p8)vec_xl(offset, (uint8_t*)mem_addr);
#else
    return (uint32x4_p8)vec_vsx_ld(offset, (uint8_t*)mem_addr);
#endif
}
The C/C++ code to perform a store using vec_xst and vec_vsx_st should look similar to below.
template <class T>
void VectorStoreu(T* mem_addr, int offset)
{
#if defined(__xlc__) || defined(__xlc__)
    vec_xst((uint8x16_p8)val, offset, (uint8_t*)mem_addr);
#else
    vec_vsx_st((uint8x16_p8)val, offset, (uint8_t*)mem_addr);
#endif
}
```

Casting away const-ness on mem addr is discussed in const pointers below.

Big-endian loads

POWER7 introduced vec_xl_be and vec_st_be which performs big-endian loads and stores. The big-endian load compiles/assembles to lxvw4x/lxvd2x, and the store compiles/assembles to stxvw4x/stxvd2x. The big-endian variants can save two instructions on little-endian systems when the little-endian byte swap is not needed. This usually happens when you need to immediately permute the data after a load or before a store.

Access to vec_xl_be and vec_st_be was provided for IBM XL C/C++ but GCC support is ongoing [https://gcc.gnu.org/ml/gcc-patches/2018-01/msg01753.html]. GCC must use inline assembly to replace the missing built-ins with VEC_XL_BE and VEC_ST_BE.

Const pointers

The Altivec built-ins have unusual behavior when using const pointers during a load operation. A program runs slower when the memory is marked as const. The behavior has been witnessed in two libraries on different machines and the decrease in perfromance is measurable. For example, AES runs 0.3 cycles per byte (cpb) faster [http://github.com/randombit/botan/pull/1459] when non-const pointers are used for loads. 0.3 cpb may not sound like much but it equates to 200 MiB/s for AES-128 on gcc112.

Source code using the non-const pointers should look similar to below:

```
template <class T>
uint32x4_p8 VectorLoad(const T* mem_addr, int offset)
{
    // mem_addr must be aligned to 16-byte boundary
    return (uint32x4_p8)vec_ld(offset, (uint8_t*)mem_addr);
}
```

Chapter 3. Runtime features

Runtime feature detections allows code to switch to a faster implementation when the hardware permits. This chapter shows you how to determine in-core crypto availability at runtime on AIX and Linux PowerPC platforms.

AIX features

TODO: find out how to perform runtime feature detection on AIX. We checked getsystemcfg and sysconf for ISA 2.07, polynomial multiply, AES and SHA (and crypto) bits but they are missing.

The only thing we have found is SIGILL probes and signal handlers. It would be nice to avoid the nastiness.

Linux features

Some versions of Glibc and the kernel provide ELF auxiliary vectors with the information. AT_HWCAP2 will show the vcrypto flag when in-core crypto is available. TODO: which versions?

```
$ LD_SHOW_AUXV=1 /bin/true
AT_DCACHEBSIZE: 0x80
AT_ICACHEBSIZE:
                 0x80
AT_UCACHEBSIZE: 0x0
AT_SYSINFO_EHDR: 0x3fff877c0000
AT_HWCAP:
                 ppcle true_le archpmu vsx arch_2_06 dfp ic_snoop
                 smt mmu fpu altivec ppc64 ppc32
AT_PAGESZ:
                  65536
                  100
AT_CLKTCK:
AT_PHDR:
                  0x10000040
                  56
AT_PHENT:
AT_PHNUM:
                  0x3fff877e0000
AT_BASE:
AT_FLAGS:
                  0x0
AT_ENTRY:
                  0x1000145c
                 10455
AT_UID:
AT_EUID:
                  10455
                 10455
AT_GID:
AT_EGID:
                 10455
AT_SECURE:
                  0x3fffeaeaa872
AT_RANDOM:
AT_HWCAP2:
                 vcrypto tar isel ebb dscr htm arch_2_07
AT_EXECFN:
                  /bin/true
AT_PLATFORM:
                 power8
AT_BASE_PLATFORM:power8
```

Linux systems with Glibc version 2.16 can use getauxval to determine CPU features. Runtime code to perform the check should look similar to below. The defines were taken from the Lin-

ux kernel's cputable.h [https://git.kernel.org/pub/scm/linux/kernel/git/torvalds/linux.git/tree/arch/power-pc/include/asm/cputable.h].

```
#ifndef AT_HWCAP2
# define AT_HWCAP2 26
#endif
#ifndef PPC_FEATURE2_ARCH_2_07
# define PPC_FEATURE2_ARCH_2_07
                                   0x80000000
#endif
#ifndef PPC_FEATURE2_VEC_CRYPTO
# define PPC_FEATURE2_VEC_CRYPTO 0x02000000
#endif
bool HasPower8()
    if (getauxval(AT_HWCAP2) & PPC_FEATURE2_ARCH_2_07 != 0)
        return true;
    return false;
bool HasPower8Crypto()
    if (getauxval(AT_HWCAP2) & PPC_FEATURE2_VEC_CRYPTO != 0)
        return true;
    return false;
```

SIGILL probes

TODO: show this nasty technique.

L1 Data Cache

The L1 data cache line size is an important security parameter that can be used to avoid leaking information through timing attacks. IBM POWER System S822, like gcc112 and gcc119, have a 128-byte L1 data cache line size.

qcc119 runs AIX and a program can query the L1 data cache line size as shown below.

```
#include <sys/systemcfg.h>
int cacheLineSize = getsystemcfg(SC_L1C_DLS);
if (cacheLineSize) <= 0)
    cacheLineSize = DEFAULT_L1_CACHE_LINE_SIZE;</pre>
```

gcc112 runs Linux and a program can query the L1 data cache line size as shown below.

```
#include <sys/sysconf.h>
```

```
int cacheLineSize = sysconf(_SC_LEVEL1_DCACHE_LINESIZE);
if (cacheLineSize) <= 0)
    cacheLineSize = DEFAULT_L1_CACHE_LINE_SIZE;</pre>
```

It is important to check the return value from sysconf on Linux. gcc112 runs CentOS 7.4 and the machine returns 0 for the L1 cache line query. Also see sysconf and SC_LEVEL1_DCACHE_LINESIZE returns 0? [https://lists.centos.org/pipermail/centos/2017-September/166236.html] on the CentOS mailing list.

Chapter 4. Advanced Encryption Standard

AES is the Advanced Encryption Standard. AES is specified in FIPS 197, Advanced Encryption Standard (AES) [https://nvlpubs.nist.gov/nistpubs/fips/nist.fips.197.pdf]. You should read the standard if you are not familiar with the block cipher.

Three topics are discussed for AES. The first is encryption, the second is decryption, and the third is keying. Keying is discussed last because encryption and decryption uses the golden key schedule from FIPS 197.

AES encryption

TODO

AES decryption

TODO

AES key schedule

TODO

Chapter 5. Secure Hash Standard

SHA is the Secure Hash Standard. SHA is specified in FIPS 180-4, Secure Hash Standard (SHS) [https://nvlpubs.nist.gov/nistpubs/fips/nist.fips.180-4.pdf]. You should read the standard if you are not familiar with the hash family.

Sigma functions

POWER8 provides a sigma instruction to accelerate SHA calculations. The instruction takes two integer arguments and the constants are used to select among Sigma0, Sigma1, sigma0 and sigma1.

Ch function

POWER8 provides the vsel instruction and it is SHA's Ch function. The implementation for the 32x4 arrangement is shown below. The code is the same for the 64x2 arrangement, but the function takes uin-t64x2_p8 arguments. The important piece of information is x used as the selector.

```
uint32x4_p8
VectorCh(uint32x4_p8 x, uint32x4_p8 y, uint32x4_p8 z)
{
    return vec_sel(z, y, x);
}
```

Maj function

POWER8 provides the vsel instruction and it can be used for SHA's Maj function. The implementation for the 32x4 arrangement is shown below. The code is the same for the 64x2 arrangement, but the function takes uint $64x2_p8$ arguments. The important piece of information is x^y used as the selector.

```
uint32x4_p8
VectorCh(uint32x4_p8 x, uint32x4_p8 y, uint32x4_p8 z)
{
    return vec_sel(y, z, vec_xor(x, y));
}
```

SHA-256

TODO

SHA-512

TODO

Chapter 6. Polynomial multiplication

The chapter of the document should discuss polynomial multiplication used with CRC codes and the GCM mode of operation for AES. However we have no experience with polynomial multiplication. Please refer to GitHub CRC32/vpmsum [https://github.com/antonblanchard/crc32-vpmsum].

CRC-32 and CRC-32C

No content.

GCM mode

No content.

Chapter 7. Assembly language

This chapter demonstrates building and linking against projects that provide SHA assembly language routines. The steps show you the integration of the routines without the baggage of a full blown library.

Cryptogams

Cryptogams [https://www.openssl.org/~appro/cryptogams/] is Andy Polyakov's incubator to develop assembly language routines for OpenSSL. Andy dual licenses his implementations, so a more permissive license is available for the assembly language source code. This section will show you how to build Andy's software.

sha2-le

The PPC64 team on GitHub [https://github.com/PPC64/sha2-le/] provide a SHA-256 assembly implementation built using m4 macros. This section explains how to build the assembly source file, create a test program and link against the assembly-based object file.

The team only provides little-endian so you will need to modify the source files for big-endian. There is a pull request [https://github.com/PPC64/sha2-le/pull/6] that will be useful if you want both little-endian and big-endian support.

The steps that follow were carried out on gcc112, which is ppc64-le. To begin clone the project, build the sources and test the program.

```
$ git clone https://github.com/PPC64/sha2-le.git
$ cd sha2-le
$ make COMPILERS=gcc
$ make test COMPILERS=gcc
______
Testing gcc
______
./bin/test256_gcc
./bin/test512 gcc
CC=gcc ./blackbox-test.sh
Running tests for SHA-256:
                          libcrypto is Ok c is Ok
Test #1:
            sha2-le is Ok
Test #2:
             sha2-le is Ok
                          libcrypto is Ok c is Ok
                          libcrypto is Ok c is Ok
Test #3:
             sha2-le is Ok
Test #4:
             sha2-le is Ok
                          libcrypto is Ok c is Ok
```

Next, create the assembly language source file from m4 sources, and then create the object file by assembling the source file.

```
$ make clean
...
$ m4 common.m4 sha256_compress_ppc.m4 > sha256_compress.s
$ as -mpower8 sha256_compress.s -o sha256_compress.o

You can examine the disassembly with the following command. The output below shows round calculations.
```

\$ objdump --disassemble sha256_compress.o file format elf64-powerpcle sha256_compress.o: Disassembly of section .text: 0000000000000000 <sha256_compress_ppc>: 6a 73 Of 10 144: vsel v0, v15, v14, v13 c4 54 29 10 148: vxor v1, v9, v10 14c: 82 fe 6d 10 vshasigmaw v3,v13,1,15 150: 80 d0 c0 10 vadduwm v6,v0,v26 154: 80 18 b0 10 vadduwm v5,v16,v3 158: 6a 58 2a 10 vsel v1,v10,v11,v1 80 30 e5 10 vadduwm v7,v5,v6 15c: 160: 82 86 49 10 vshasigmaw v2, v9, 1, 0 vadduwm v8,v2,v1 164: 80 08 02 11 168: 80 38 8c 11 vadduwm v12,v12,v7

The comments in sha256_compress.s state the public API for the function is as follows. The documentation does not state the alignment requirements of state, input or keys. When in doubt you should align the memory to a 16-byte boundary.

vadduwm v16, v7, v8

```
void sha256_compress_ppc(
    uint32_t *state,
    const uint8_t *input,
    const uint32_t *keys)
```

80 40 07 12

16c:

Finally, a program that links to sha2-le's sha256_compress_ppc might look like the following.

```
0x428A2F98, 0x71374491, 0xB5C0FBCF, 0xE9B5DBA5,
    0x3956C25B, 0x59F111F1, 0x923F82A4, 0xAB1C5ED5,
    0xD807AA98, 0x12835B01, 0x243185BE, 0x550C7DC3,
    0x72BE5D74, 0x80DEB1FE, 0x9BDC06A7, 0xC19BF174,
    0xE49B69C1, 0xEFBE4786, 0x0FC19DC6, 0x240CA1CC,
    0x2DE92C6F, 0x4A7484AA, 0x5CB0A9DC, 0x76F988DA,
    0x983E5152, 0xA831C66D, 0xB00327C8, 0xBF597FC7,
    0xC6E00BF3, 0xD5A79147, 0x06CA6351, 0x14292967,
    0x27B70A85, 0x2E1B2138, 0x4D2C6DFC, 0x53380D13,
    0x650A7354, 0x766A0ABB, 0x81C2C92E, 0x92722C85,
    0xA2BFE8A1, 0xA81A664B, 0xC24B8B70, 0xC76C51A3,
    0xD192E819, 0xD6990624, 0xF40E3585, 0x106AA070,
    0x19A4C116, 0x1E376C08, 0x2748774C, 0x34B0BCB5,
   0x391C0CB3, 0x4ED8AA4A, 0x5B9CCA4F, 0x682E6FF3,
   0x748F82EE, 0x78A5636F, 0x84C87814, 0x8CC70208,
    0x90BEFFFA, 0xA4506CEB, 0xBEF9A3F7, 0xC67178F2
  };
int main(int argc, char* argv[])
  /* empty message with padding */
 ALIGN16 uint8_t message[64];
 memset(message, 0x00, sizeof(message));
 message[0] = 0x80;
  /* initial state */
 ALIGN16 uint32_t state[8] = {
   0x6a09e667, 0xbb67ae85, 0x3c6ef372, 0xa54ff53a,
   0x510e527f, 0x9b05688c, 0x1f83d9ab, 0x5be0cd19
 };
 sha256_compress_ppc(state, message, K256);
 const uint8_t b1 = (uint8_t)(state[0] >> 24);
 const uint8 t b2 = (uint8 t)(state[0] >> 16);
 const uint8_t b3 = (uint8_t)(state[0] >> 8);
 const uint8 t b4 = (uint8 t)(state[0] >> 0);
 const uint8_t b5 = (uint8_t)(state[1] >> 24);
 const uint8_t b6 = (uint8_t)(state[1] >> 16);
 const uint8_t b7 = (uint8_t)(state[1] >> 8);
 const uint8 t b8 = (uint8 t)(state[1] >> 0);
  /* e3b0c44298fc1c14... */
 printf("SHA256 hash of empty message: ");
 printf("%02X%02X%02X%02X%02X%02X%02X...\n",
         b1, b2, b3, b4, b5, b6, b7, b8);
  int success = ((b1 == 0xE3) \&\& (b2 == 0xB0) \&\&
                 (b3 == 0xC4) \&\& (b4 == 0x42) \&\&
                 (b5 == 0x98) \&\& (b6 == 0xFC) \&\&
                 (b7 == 0x1C) \&\& (b8 == 0x14));
 if (success)
   printf("Success!\n");
```

```
else
    printf("Failure!\n");

return (success != 0 ? 0 : 1);
}

Compiling and linking to sha256_compress_ppc.o would look similar to below.

$ g++ test.cxx -o test.exe sha256_compress.o
$ ./test.exe
SHA256 hash of empty message: E3B0C44298FC1C14...
Success!
```

Chapter 8. References

Cryptogams

CRYPTOGAMS: low-level cryptographic primitives collection [https://www.openssl.org/~appro/cryptogams/]

GitHub

- AES Intrinsics [https://github.com/noloader/AES-Intrinsics]
- SHA Intrinsics [https://github.com/noloader/SHA-Intrinsics]
- CRC32/vpmsum [https://github.com/antonblanchard/crc32-vpmsum]
- sha2-le [https://github.com/PPC64/sha2-le]

IBM website

- Recommended debug, compiler, and linker settings for Power processor tuning [https://www.ib-m.com/support/knowledgecenter/en/linuxonibm/liaal/iplsdkrecbldset.htm]
- AIX vector programming [https://www.ibm.com/support/knowledgecenter/en/ssw_aix_61/com.ib-m.aix.genprogc/vector_prog.htm]
- POWER8 in-core cryptography [https://www.ibm.com/developerworks/library/se-power8-in-core-cryptography/index.html]

NIST website

- FIPS 197, Advanced Encryption Standard (AES) [https://nvlpubs.nist.gov/nistpubs/fips/nist.fip-s.197.pdf]
- FIPS 180-4, Secure Hash Standard (SHS) [https://nvlpubs.nist.gov/nistpubs/fips/nist.fips.180-4.pdf]

Stack Exchange

- Detect Power8 in-core crypto through getauxval? [https://stackoverflow.com/q/46144668/608639]
- Is vec_sld endian sensitive? [https://stackoverflow.com/q/46341923/608639]

Index

A
Administriva, 1
AES, 1, 12
Decryption, 12
Encryption, 12
Key schedule, 12
Andy Polyakov, 15
Assembly language, 1, 15
C
•
C/C++, 1
Compile farm, 1
gcc112, 1
gcc119, 1
POWER8, 2
CRC-32, 14
Cryptogams, 15, 19
Andy Polyakov, 15
F
Feature detection, 9
AIX, 9
Glibc, 9, 9
Linux, 9
SIGILL probe, 10
SIGILL proce, 10
G
GCM mode, 14
GitHub, 19
Gustavo Serra Scalet, 15
IBM website, 19
Introduction, 1
introduction, 1
L
L1 data cache, 10
AIX, 10
Linux, 10
N
- -
NIST website, 19
Б
P
Polynomial multiplication, 1, 14
CRC-32, 14
GCM mode, 14

R

References, 19

S

SHA, 1, 13 Ch function, 13 Maj function, 13 SHA-256, 13 SHA-512, 13 Sigma functions, 13 SHA-256 sha2-le, 15 Sha2-le, 15 Gustavo Serra Scalet, 15 Stack Exchange, 19