Contents

eek 6
Objectives
Light up the other leds
Create a program
Testing on other mchines:
Windows
Linux
Understanding the SRAM I need to communicate to
What is a should i be writting to
The bus architecture
My ideas
Goal for next week
Question

Week 6

Objectives

- 1. Light up the other leds of the column
- 2. Create a program that will make all the process easier
- 3. Check on other architecture if it works
- 4. Start understanding the RAM

Light up the other leds

The first thing I have done this week was to be able to light up the other leds, before only the first 3 leds could be lighted up.

To be able to choose the colors of the 10 leds in a column I augmented the size of the registers in the chain1 to 30 bits (3 RGB bits per leds). Hence we now have to shift 30 bits using the JTDI. The format of the data sent also changed:

- data[9:0]: the **red** bits of all the leds
- data[9:0]: the green bits of all the leds
- data[9:0]: the **blue** bits of all the leds

All the signals are active low thus 0 lights up the led, 1 shut it off. For an example let's try to light up one led out of two to cyan:

- 1. For a single led in CYAN is red=1, blue=0, green=0 thus [0,0,1] (remember active low)
- 2. For a completely shut off a led: red=1, blue=1, green=1 thus [0,0,1]
- 3. The red part of the data shift will be: [1,1,1,1,1,1,1,1,1,1]
- 4. The green part of the data shift will be: [0,1,0,1,0,1,0,1,0,1]
- 5. The blue part of the data shift will be: [0,1,0,1,0,1,0,1,0,1]

Create a program

The second step here was to create a simple program that will make the communication more intuitive without having to use directly low level openOCD commands such as irscan and drscan. The program connect lunch the openOCD server using the config file, and connects to it. This program offers an interactive interface where we can use few commands:

- 1. led <number/all> <color>: lights up the light located at number (or all of them) with the selected color. The color available are :
 - 1. red, r
 - 2. blue, b
 - 3. green, g
 - 4. yellow, y
 - 5. cyan, c
 - 6. magenta, m
 - 7. black, k
 - 8. white, w
- 2. column <number>: set the column number
- 3. help: display the help message
- 4. exit: exit the program

Testing on other mchines:

Windows

- 1. Install wsl and attach the board to it using the tuto on the moodle page
- 2. Stay here for the moment

Linux

I don't have access to a physical linux machines and trying on different vm i encounters issues to : maps the USB to the vm and accessing the oss-cad-suite

The easiest way to test it would be to use a physical linux machine

Understanding the SRAM I need to communicate to

What is a should i be writting to

The goal would be to use the JTAG interface to read and write in this SRAM?

Synchronous Dynamic random Access Memory: DRAM that is connected to the clock of the processor. Allows faster it to be faster and more efficient than a non synchronized one. It is a volatile memeory thus when shutting down the board the data is not remain

The actual sdram component looks like this:

```
module sdramController #( parameter [31:0] baseAddress = 32'h000000000,
                                            systemClockInHz = 40000000 ) // supports up to 100MHz
                          parameter
                       ( input wire
                                             clock,
                                             clockX2,
                                             reset,
                         input wire [5:0]
                                             memoryDistanceIn,
                         output wire
                                             sdramInitBusy,
                         input wire [1:0]
                                             sdramDelay,
                          // here the bus interface is defined
                         input wire
                                             beginTransactionIn,
                                             endTransactionIn,
                                             readNotWriteIn,
                                             dataValidIn,
                                             busErrorIn.
                                             busyIn,
                         input wire [31:0] addressDataIn,
                          input wire [3:0]
                                             byteEnablesIn,
```

```
input wire [7:0] burstSizeIn,
output wire
                   endTransactionOut,
                   dataValidOut,
                   busyOut,
output reg
                   busErrorOut,
output wire [31:0] addressDataOut,
// here the off-chip signals are defined
output wire
                   sdramClk,
output wire
                   sdramCke.
                   sdramCsN.
                   sdramRasN,
                   sdramCasN,
                   sdramWeN,
output wire [1:0] sdramDqmN,
                   sdramBa,
output wire [12:0] sdramAddr,
inout wire [15:0] sdramData);
```

We can clearly see that it is connected to the bus architecture of the openRISC. But also has some signals to off-chip signals

The bus architecture

The idea is to exchange the data from one part to the other one. (Transport information)

- 1. Memory access
- 2. Type of access
- 3. The data
- 4. Some handshake

In our system we have a shared bus: it uses transactions and allow some **burst** We have master devices and Slave devices

Masters initiate the transaction: (I guess the IP core will be a master device, and the sdram controller will be the salve)

All device has two ports: a bus-in where the signal enters and a bus-out where the signals goes out. Unidirectionnal communication.

All the bus-out are OR together that forms the in-port. Put all zeroes when not communicating

Be very carefull about the cycles or otherwise every can become shit

- byte_enable: how many 32 bits words do i want to transfer
- read_n_write: From a master point of view: do i want to read or wirte to a slave
- Data valid: is the data valid?
- Busy: Slave indicating that it is busy and the data is comming to fast
- Error: If the address is not mapped

The address will always be a byte address (8bits)

SDRAM will always but the busy bit because:

- 1. The initialisation
- 2. The SDRAM is 16bit addressable but we are reading 32bits on the bus

My ideas

How do I give the address, the size, the data to the instruction chain?

Simple bus architectures

- ▶ So which signals are defined in our bus?
 - **address data**: 32-bit channel that transports the address or data.
 - **byte enables**: 4-bit channel that indicates in a single transfer which bytes are valid.
 - **burst_size**: 8-bit channel that indicates the number of words to transfer (value+1).
 - **read_n_write**: 1-bit channel indicates a read (when 1) or write transaction (when 0).
 - **begin_transaction**: 1-bit channel that indicates the beginning of a transaction.
 - end_transaction: 1-bit channel that indicates the end of a transaction.
 - **data_valid**: 1-bit channel that indicates a valid datum on the *address_data* lines.
 - **busy**: 1-bit channel that indicates that the receiver cannot process yet the datum.
 - error: 1-bit channel that indicates a bus error.
- All signals (50-bits) are active-high and should be forced to 0 when not in use (due to the or-gates).

Channel:	master		slave	
	Bus-in	Bus-out	Bus-in	Bus-out
address_data	required	required	required	required
byte_enables	Х	required	required	Х
burst_size	X	required	required	X
read_n_write	X	required	required	X
begin_transaction	X	required	required	X
end_transaction	required	required	required	required
data_valid	required	required	required	required
busy	required	optional	required	optional
error	required	X	X	optional

Figure 1: Signals for the bus

- Use a very specific order for example first 10 bits are the size, the next 32 is the address, the rest is the data
- Since i only have a single input: The tdi => I think it's the only option
- Since I have two chains one could be the writting the other could be the readin
- I need a big shift register that's is used to buffer the data before sending it

Goal for next week

- Think about all details needed for communicating wiht the SDRAM
- Think about how to do it
- Start working on a new version of the IP core that write in the memory

Question

- 1. What are the off-chip signals of the sdram? Are they usefull for my project
- 2. What is this file? udev file for linux systems (place in /etc/udev/rules.d) what does it do
- 3. The presentation will be next week: what could be a title for this project since it has multiples parts?
- 4. From what i unserstood our bus architecture is a simple one (the first in the course) right?
- 5. Where can i find the inforantion about the SDRAM (like the size the adress)
- 6. What is the request signal used by the master to initiate transaction? I did'nt see it in the signals.
- 7. What is the Byte_enable signal?
- 8. How do concretely add my master to the bus architecture
- 9. Can you quickly explain me the pw3 and can it be usefull in my case?
- 10. where can i find the address of the different slaves?
- 11. You talked about DMA in your course I just wanted to make sure that i do not need it right? (beacause it is used to transfert chunk of data btw different slaves).