

Writing a Simple USB Driver

Software (/taxonomy/term/17) by Greg Kroah-Hartman on March 31, 2004

Since this column began, it has discussed how a Linux driver writer can create various types of kernel drivers, by explaining the different kernel driver interfaces including TTY, serial, I2C and the driver core. It is time to move on now and focus on writing real drivers for real hardware. We start by explaining how to determine what kind of kernel driver interface to use, tricks to help figure out how the hardware actually works and a lot of other real-world knowledge.

Let's begin with a goal of making a simple USB lamp device work well with Linux. Editor Don Marti pointed out a neat device, the USB Visual Signal Indicator, manufactured by Delcom Engineering and shown in Figure 1. I have no relationship with this company; I just think they make nice products. This device can be ordered online from the Delcom Web site, www.delcom-eng.com (http://www.delcom-eng.com). Don challenged me to get the

You ! Like



source-so develope

us)

device working on Linux, and this article explains how I did it.



/linuxjournal.com/linuxjournal/articles/073/7353/7353f1.resized.jpg)
Figure 1. Delcom's USB Visual Signal Indicator is a simple first
USB programming project.

The Hardware Protocol

The first goal in trying to write a driver for a device is to determine how to control the device. Delcom Engineering is nice enough to ship the entire USB protocol specification their devices use with the product, and it also is available on-line for free. This documentation shows what commands the USB controller chip accepts and how to use them. They also provide a Microsoft Windows DLL to help users of other operating systems write code to control the device.

The documentation for this device is only the documentation for the USB controller in the lamp. It does not explicitly say how to turn on the different color LEDs. For this, we have to do a bit of research.

No Docs? Reverse Engineer It!

If the USB protocol for this device had not been documented or available to me, I would have had to reverse engineer this information from the device itself. A handy tool for this kind of work



(/content/ othmanegilje-jaatu edgar-we empirical software-

is a free program called USB Snoopy, www.wingmanteam.com/usbsnoopy

(http://www.wingmanteam.com/usbsnoopy); another version of it is SnoopyPro, usbsnoop.sourceforge.net

(http://usbsnoop.sourceforge.net). These programs are both Windows programs that allow users to capture the USB data that is sent to and received from any USB device on a Windows system. All a developer needs to do is find a Windows machine, install the Windows driver provided by the manufacturer for the device and run the snoop program. The data is captured to a file to be analyzed later. Perl scripts can help filter some of the extra noise in the output of these snoop programs into an easier format to understand.



(/content/ softwareadventure

Another method a few people have used to reverse engineer the USB protocol of a device is to run a Windows instance using VMware on top of Linux. VMware enables the Windows instance to talk to all of the USB devices plugged in to the Linux machine by sending data to Linux though the usbfs. A simple modification to the usbfs causes all data flowing though it to be logged to the kernel log. Using this, the full USB traffic stream can be captured and later analyzed.

After opening up the lamp device, making sure not to lose the spring that easily pops out when unscrewing the device, the circuit board can be inspected (Figure 2). Using an ohmmeter, or any kind of device for detecting a closed circuit, it was determined that the three different LEDs are connected to the first three pins of port 1 on the main controller chip.

In reading the documentation, the USB command to control the levels of the port 1 pins is Major 10, Minor 2, Length 0. The command writes the least significant byte of the USB command packet to port 1, and port 1 is defaulted high after reset. So, that is the USB command we need to send to the device to change the different LEDs.



(/content /softmake freeoffice



/linuxjournal.com/linuxjournal/articles/073/7353/7353f2.resized.jpg)

Figure 2. The three LEDs are connected to the first three pins of the controller chip.

Which LED Is Which?

Now that we know the command to enable a port pin, we need to determine which LED color is connected to which pin. This is easy to do with a simple program that runs through all possible combinations of different values for the three port pins and then sends the value to the device. This program enabled me to create a table of values and LED colors (Table 1).

Table 1. Port Values and the Resulting LED Patterns

Port value in hex	Port value in binary	LEDs on
0x00	000	Red, Green, Blue
0x01	001	Red, Blue
0x02	010	Green, Blue
0x03	011	Blue
0x04	100	Red, Green
0x05	101	Red
0x06	110	Green
0x07	111	No LEDs on

So, if all pins on the port are enabled (a value of 0x07 hex), no

LEDs are on. This matches up with the note in the data sheet that stated, "Port 1 is defaulted high after reset." It would make sense not to have any LEDs enabled when the device is first plugged in. This means we need to turn port pins low (off) in order to turn on the LED for that pin. Using the table, we can determine that the blue LED is controlled by pin 2, the red LED by pin 1 and the green LED by pin 0.

A Kernel Driver

Armed with our new-found information, we set off to whip up a quick kernel driver. It should be a USB driver, but what kind of interface to user space should we use? A block device does not make sense, as this device does not need to store filesystem data. but a character device would work. If we use a character device driver, however, a major and minor number needs to be reserved for it. And how many minor numbers would we need for this driver? What if someone wanted to plug 100 different USB lamp devices in to this system? To anticipate this, we would need to reserve at least 100 minor numbers, which would be a total waste if all anyone ever used was one device at a time. If we make a character driver, we also would need to invent some way to tell the driver to turn on and off the different colors individually. Traditionally, that could be done using different local commands on the character driver, but we know much better than ever to create a new joctl command in the kernel.

As all USB devices show up in their own directory in the sysfs tree, so why not use sysfs and create three files in the USB device directory, blue, red and green? This would allow any user-space program, be it a C program or a shell script, to change the colors on our LED device. This also would keep us from having to write a character driver and beg for a chunk of minor numbers for our device.

To start out our USB driver, we need to provide the USB subsystem with five things:

 A pointer to the module owner of this driver: this allows the USB core to control the module reference count of the driver

properly.

- The name of the USB driver.
- A list of the USB IDs this driver should provide: this table is used by the USB core to determine which driver should be matched up to which device; the hot-plug user-space scripts use it to load that driver automatically when a device is plugged in to the system.
- A probe() function called by the USB core when a device is found that matches the USB ID table.
- A disconnect() function called when the device is removed from the system.

The driver retrieves this information with the following bit of code:

The id table variable is defined as:

The led_probe() and led_disconnect() functions are described later.

When the driver module is loaded, this led_driver structure must be registered with the USB core. This is accomplished with a single call to the usb_register() function:

```
retval = usb_register(&led_driver);
if (retval)
    err("usb_register failed. "
        "Error number %d", retval);
```

Likewise, when the driver is unloaded from the system, it must unregister itself from the USB core:

```
usb_deregister(&led_driver);
```

The led_probe() function is called when the USB core has found our USB lamp device. All it needs to do is initialize the device and create the three sysfs files, in the proper location. This is done with the following code:

```
/* Initialize our local device structure */
dev = kmalloc(sizeof(struct usb_led), GFP_KERNEL);
memset (dev, 0x00, sizeof (*dev));

dev->udev = usb_get_dev(udev);
usb_set_intfdata (interface, dev);

/* Create our three sysfs files in the USB
* device directory */
device_create_file(&interface->dev, &dev_attr_blue
device_create_file(&interface->dev, &dev_attr_red)
device_create_file(&interface->dev, &dev_attr_gree)

dev_info(&interface->dev,
    "USB LED device now attached\n");
return 0;
```

The led_disconnect() function is equally as simple, as we need only to free our allocated memory and remove the sysfs files:

```
dev = usb_get_intfdata (interface);
usb_set_intfdata (interface, NULL);

device_remove_file(&interface->dev, &dev_attr_blue
device_remove_file(&interface->dev, &dev_attr_red)
device_remove_file(&interface->dev, &dev_attr_gree

usb_put_dev(dev->udev);
kfree(dev);

dev_info(&interface->dev,
    "USB LED now disconnected\n");
```

When the sysfs files are read from, we want to show the current value of that LED; when it is written to, we want to set that specific LED. To do this, the following macro creates two functions for each color LED and declares a sysfs device attribute file:

```
#define show_set(value)
static ssize t
show_##value(struct device *dev, char *buf)
{
   struct usb interface *intf =
      to_usb_interface(dev);
   struct usb_led *led = usb_get_intfdata(intf);
   return sprintf(buf, "%d\n", led->value);
}
static ssize_t
set_##value(struct device *dev, const char *buf,
            size_t count)
{
   struct usb interface *intf =
      to_usb_interface(dev);
   struct usb_led *led = usb_get_intfdata(intf);
   int temp = simple_strtoul(buf, NULL, 10);
   led->value = temp;
   change_color(led);
   return count;
}
static DEVICE_ATTR(value, S_IWUGO | S_IRUGO,
                   show_##value, set_##value);
show_set(blue);
show_set(red);
show_set(green);
```

This creates six functions, show_blue(), set_blue(), show_red(), set_red(), show_green() and set_green(); and three attribute structures, dev_attr_blue, dev_attr_red and dev_attr_green. Due to the simple nature of the sysfs file callbacks and the fact that we need to do the same thing for every different value (blue, red and

green), a macro was used to reduce typing. This is a common occurrence for sysfs file functions; an example of this in the kernel source tree is the I2C chip drivers in drivers/i2c/chips.

So, to enable the red LED, a user writes a 1 to the red file in sysfs, which calls the set_red() function in the driver, which calls the change color() function. The change color() function looks like:

```
#define BLUE
                 0x04
#define RED
                 0x02
#define GREEN
                 0x01
   buffer = kmalloc(8, GFP_KERNEL);
   color = 0x07;
   if (led->blue)
      color &= ~(BLUE);
   if (led->red)
      color &= ~(RED);
   if (led->green)
      color &= ~(GREEN);
   retval =
      usb_control_msg(led->udev,
                       usb_sndctrlpipe(led->udev, 0
                       0x12,
                       0xc8,
                       (0x02 * 0x100) + 0x0a,
                       (0x00 * 0x100) + color,
                       buffer,
                       8,
                       2 * HZ);
   kfree(buffer);
```

This function starts out by setting all bits in the variable color to 1. Then, if any LEDs are to be enabled, it turns off only that specific bit. We then send a USB control message to the device to write that color value to the device.

It first seems odd that the tiny buffer variable, which is only 8-bytes long, is created with a call to kmalloc. Why not simply declare it on the stack and skip the overhead of dynamically allocating and then destroying it? This is done because some architectures that run Linux cannot send USB data created on the kernel stack, so all data that is to be sent to a USB device must be created dynamically.

LEDs in Action

With this kernel driver created, built and loaded, when the USB lamp device is plugged in, the driver is bound to it. All USB devices bound to this driver can be found in the sysfs directory for the driver:

```
$ tree /sys/bus/usb/drivers/usbled/
/sys/bus/usb/drivers/usbled/
`-- 4-1.4:1.0 ->
../../../devices/pci0000:00/0000:00:0d.0/usb4/4
```

The file in that directory is a symlink back to the real location in the sysfs tree for that USB device. If we look into that directory we can see the files the driver has created for the LEDs:

```
$ tree /sys/bus/usb/drivers/usbled/4-1.4:1.0/
/sys/bus/usb/drivers/usbled/4-1.4:1.0/
|-- bAlternateSetting
|-- bInterfaceClass
|-- bInterfaceNumber
|-- bInterfaceProtocol
|-- bInterfaceSubClass
|-- bNumEndpoints
|-- blue
|-- detach_state
|-- green
|-- iInterface
|-- power
| `-- state
`-- red
```

Then, by writing either 0 or 1 to the blue, green and red files in that directory, the LEDs change color:

```
$ cd /sys/bus/usb/drivers/usbled/4-1.4:1.0/
$ cat green red blue
0
0
0
$ echo 1 > red
[greg@duel 4-1.4:1.0]$ echo 1 > blue
[greg@duel 4-1.4:1.0]$ cat green red blue
0
1
1
```

This produces the color shown in Figure 3.

Is There a Better Way?



/linuxjournal.com/linuxjournal/articles/073/7353/7353f3.resized.jpg)
Figure 3. The Device with the Red and Blue LEDs On

Now that we have created a simple kernel driver for this device, which can be seen in the 2.6 kernel tree at drivers/usb /misc/usbled.c or on the *Linux Journal* FTP site at (ftp.linuxjournal.com/pub/lj/listings/issue120/7353.tgz (ftp://ftp.linuxjournal.com/pub/lj/listings/issue120/7353.tgz)), is this really the best way to talk to the device? What about using something like usbfs or libusb to control the device from user space without any special device drivers? In my next column, I will show how to do this and provide some shell scripts to control the

If you would like to see kernel drivers written for any other types of devices, within reason—I'm not going to try to write an NVIDIA video card driver from scratch—please let me know.

USB lamp devices plugged in to the system easily.

Thanks to Don Marti for bugging me to get this device working on Linux. Without his prodding it would have never gotten finished. Greg Kroah-Hartman currently is the Linux kernel maintainer for a variety of different driver subsystems. He works for IBM, doing Linux kernel-related things, and can be reached at

greg@kroah.com (mailto:greg@kroah.com).

No comments yet. Be the first! (https://www.linuxjournal.com/article/7353#disq



Subscribe to Linux Journal's Digital Edition >>

Join a community with a deep appreciation for open-source philosophies, digital freedoms an

(/subscribe)

Connect With Us



(https://youtube.com/linuxjournalonline)

f (https://www.facebook.com



(https://twitter.com/linuxjournal)

Linux Journal, currently celebrating its 24th year of publication, is the original magazine of the global Oper community.

© 2018 Linux Journal, LLC. All rights reserved.

PRIVACY POLICY (/CONTENT/PRIVACY-STATEMENT) | TERMS OF SERVICE (/TERMS-SERVICE) | ADVERTISE (/SPONSORS)

SUBSCRIBE (/SUBSCRIBE) RENEW (/RENEW)

BACKISSUES (/DIGITAL)

CUSTOMER SERVICE (/SUBS /CUSTOMER_SERVICE)

MASTHEAD (/CONTENT /MASTHEAD)

FAQ (/CONTENT /LINUX-JOURNAL-20-FAQ)

AUTHORS (/AUTHOR)

LETTERS TO **EDITOR** (/CONTACT)

RSS FEEDS (/RSS_FEEDS)

NEWSLETTERS (/ENEWSLETTERS)

MERCHANDISE (HTTP://WWW.LINUXJOURNA

CONTACT US (/ABOUTUS)

Powered By



(http://www.privat /pages/buyvpn/linuxjournal)