Arduino is an open-source electronics prototyping platform based on flexible, easy-to-use hardware and software. It's intended for artists, designers, hobbyists, and anyone interested in creating interactive objects or environments.

Source: http://www.arduino.cc/

Microcontroller

Arduino is a microcontroller on a circuit board which makes it easy to receive inputs and drive outputs.

A microcontroller is a integrated computer on a chip.

Inputs

Some examples of inputs would be a temperature sensor, a motion sensor, a distance sensor, a switch and so forth.

Outputs

Some examples of outputs would be a light, a screen, a motor and so forth.

TL;DR

Arduino is a small computer that you can program to read and control electrical components connected to it.

Obtaining an Arduino Board

There are several online distributors that stock Arduino boards.

Often boards are bundled up with starter kits. Kits include a wide variety of inputs, outputs, resistors, wires and breadboards. Breadboards are solderless circuit prototyping boards that you can plug wires and components into.

Arduinos come in different flavours. Most people starting off go for the UNO board. It's current revision is the third, hence the R3 listed by stockists.

Most enthusiasts use sites like Adafruit and Element14.


You can even pick up one from your local RadioShack.

A more complete list of distributors can be found on the Arduino Distributors page.

If you're just getting a single Arduino board or starter kit be sure you have a USB A to B cable. Most, if not all, starter kits come with the USB A to B cable. Most printers have this type of interface so you may have this cable already lying around. The reason you need the cable is to program the device so it's best to double check when ordering.

Programming Arduino

For the example I'm showing you'll *only* need the Arduino UNO R3 board itself and the required USB cable to transfer the program from your computer to the board.



Arduino UNO R3

On the board left of the Arduino logo there's an LED, short for Light Emitting Diode, a small light, with the letter L next to it.

We're going to switch it on and off and then look in to making it blink on and off for 2 seconds at a time.


When you first plug your USB cable in to your Arduino and your computer, you may notice that this LED is blinking. Not to worry! It's the default program stored on the chip. We're going to override this.

The USB cable powers the device. Arduinos can run standalone by using a power supply in the bottom left of the board. Once you're done programming and don't require it to be constantly connected to your machine you can opt to power it separately. This is entirely dependant on the use case and circumstances you want to use the device in.

Download Arduino Software

You'll need to download the Arduino Software package for your operating system from the Arduino download page.

When you've downloaded and opened the application you should see something like this:




Arduino Software

This is where you type the code you want to compile and send to the Arduino board.

The Initial Setup

We need to setup the environment to **Tools** menu and select **Board**.



Tools Menu < Board

Then select the type of Arduino you want to program, in our case it's the Arduino Uno.

✓ Arduino Uno

Arduino Duemilanove w/ ATmega328

Arduino Diecimila or Duemilanove w/ ATmega168

Arduino Nano w/ ATmega328

Arduino Nano w/ ATmega168

Arduino Mega 2560 or Mega ADK

Arduino Mega (ATmega1280)

Arduino Leonardo

Arduino Esplora

Arduino Micro

Arduino Mini w/ ATmega328

Arduino Mini w/ ATmega168

Arduino Ethernet

Arduino Fio

Arduino BT w/ ATmega328

Arduino BT w/ ATmega168

LilyPad Arduino USB

LilyPad Arduino w/ ATmega328

LilyPad Arduino w/ ATmega168

Arduino Pro or Pro Mini (5V, 16 MHz) w/ ATmega328

Arduino Pro or Pro Mini (5V, 16 MHz) w/ ATmega168

Arduino Pro or Pro Mini (3.3V, 8 MHz) w/ ATmega328

Arduino Pro or Pro Mini (3.3V, 8 MHz) w/ ATmega168

Arduino NG or older w/ ATmega168

Arduino NG or older w/ ATmega8

Arduino Uno

The Code

The code you write for your Arduino are known as **sketches**. They are written in C++.

Every sketch needs two void type functions, setup() and loop(). A void type function doesn't return any value.


The setup() method is ran once at the just after the Arduino is powered up and the loop() method is ran continuously afterwards.

The setup() is where you want to do any initialisation steps, and in loop() you want to run the code you want to run over and over again.

So, your basic sketch or program should look like this:

Now we have the basic skeleton in place we can now do the Hello, World program of microcontrollers, a blinking an LED.

Headers and Pins



Arduino UNO R3

If you notice on the top edge of the board there's two black rectangles with several squares in. These are called **headers**. Headers make it easy to connect components to the the Arduino. Where they connect to the board is called **pins**. Knowing what pin something is connected to is essential for programming an Arduino.

The pin numbers are listed next to the headers on the board in white.

The onboard LED we want to control is on pin 13.

In our code above the setup() method let's create a variable called ledPin. In C++ we need to state why type our variable is before hand, in this case it's an integer, so it's of type int.

```
1 int ledPin = 13;
2
3 void setup()
4 {
5
6 }
7
8 void loop()
9 {
10
11 }
```

Each line is ended with a semicolon (;).

In the setup() method we want to set the ledPin to the output mode. We do this by calling a special function called pinMode() which takes two variables, the first the pin number, and second, whether it's an input or output pin. Since we're dealing with an output we need to set it to a constant called OUTPUT. If you were working with a sensor or input it would be INPUT.

```
int ledPin = 13;
1
2
    void setup()
3
4
    {
             pinMode(ledPin, OUTPUT);
5
    }
6
    void loop()
8
9
    {
10
11
```

In our loop we are going to first switch off the LED to make sure our program is being transferred to the chip and overriding the default.

We do this by calling another special method called digitalWrite(). This also takes two values, the pin number and the level, HIGH or the on state or LOW the off state.

```
int ledPin = 13;
1
    void setup()
3
4
    {
5
             pinMode(ledPin, OUTPUT);
    }
6
7
    void loop()
8
9
    {
             digitalWrite(ledPin, LOW);
10
11
```

Next we want to compile to machine code and deploy or upload it to the Arduino.

Compiling the Code

If this is your first time you've ever compiled code to your Arduino before plugging it in to the computer go to the **Tools** menu, then **Serial Port** and take note of what appears there.

Here's what mine looks like before plugging in the Arduino UNO:

```
/dev/tty.Bluetooth-PDA-Sync
/dev/cu.Bluetooth-PDA-Sync
/dev/tty.Bluetooth-Modem
/dev/cu.Bluetooth-Modem
```

Serial Port menu previous to Arduino being plugged in

Plug your Arduino UNO board in to the USB cable and into your computer. Now go back to the **Tools > Serial Port** menu and you should see at least 1 new option. On my Mac 2 new serial ports appear.

```
/dev/tty.Bluetooth-PDA-Sync
/dev/cu.Bluetooth-PDA-Sync
/dev/tty.Bluetooth-Modem
/dev/cu.Bluetooth-Modem

✓/dev/tty.usbmodem1411
/dev/cu.usbmodem1411
```

Serial Port menu after the Arduino plugged in

They *tty* and *cu* are two ways that computers can talk over a serial port. Both seem to work with the Arduino software so I selected the tty.* one. On Windows you should see *COM* followed by a number. Select the new one that appears.

Once you have selected your serial or COM port you can then press the button with the arrow pointing to the right.

```
sketch_jan01a | Arduino 1.0.3

| Sketch_jan01a | Sketch_jan01a
```

Arduino Software with button highlighted

Once that happens you should see the **TX** and **RX** LEDs below the **L**LED flash. This is the communication going on between the computer and the Arduino. The **L** may flicker too. Once this dance is complete your program should be running. And your LED should be off.

Now let's try and switch it on using the HIGH constant.

```
8 void loop()
9 {
10 digitalWrite(ledPin, HIGH);
11 }
```

Press Upload again and you should see your LED is now on!

Let's make this a little more interesting now. We're going to use another method called delay() which takes an integer of a time interval in milliseconds, meaning the integer of 1000 is 1 second.

So after where we switch the LED on let's add delay(2000) which is two seconds, then digitalWrite(ledPin, LOW) to switch it off and delay(2000) again.

```
int ledPin = 13;
1
2
    void setup()
3
    {
4
            pinMode(ledPin, OUTPUT);
5
    }
6
7
    void loop()
8
    {
9
            digitalWrite(ledPin, HIGH);
10
            delay(2000);
11
            digitalWrite(ledPin, LOW);
12
            delay(2000);
13
```

Press Upload and you should see