

# RISC-V ECE253 ONE-PAGE CHEATSHEET

## Subroutine Template (Fully Commented)

```
myfunc:  
    addi sp, sp, -16 # allocate stack frame  
    sw ra, 12(sp) # save return address  
    sw s0, 8(sp) # save s0 (callee-saved)  
  
    # function body here  
  
    lw s0, 8(sp) # restore s0  
    lw ra, 12(sp) # restore ra  
    addi sp, sp, 16 # deallocate stack  
    ret # return to caller
```

## Recursive Sum $n + (n-1) + \dots + 1$

```
sum:  
    addi sp, sp, -16 # make stack frame  
    sw ra, 12(sp) # save ra  
  
    beq a0, x0, base # if n == 0, go to base case  
    addi a0, a0, -1 # compute n-1  
    jal ra, sum # recursive call  
    add a0, a0, a1 # add returned value to n  
    j done # skip base case  
  
base:  
    mv a0, x0 # return 0  
  
done:  
    lw ra, 12(sp) # restore ra  
    addi sp, sp, 16 # pop frame  
    ret
```

## Recursive Fibonacci

```
fib:  
    addi sp, sp, -32 # big frame for storage  
    sw ra, 28(sp) # save ra  
    sw a0, 24(sp) # save n  
  
    li t0, 1  
    ble a0, t0, base # if n <= 1 return n  
  
    addi a0, a0, -1  
    jal ra, fib # fib(n-1)  
    mv t1, a0 # store fib(n-1)  
  
    lw a0, 24(sp)  
    addi a0, a0, -2  
    jal ra, fib # fib(n-2)  
  
    add a0, a0, t1 # fib(n) = f(n-1) + f(n-2)  
    j done  
  
base:  
    lw a0, 24(sp) # return n  
  
done:  
    lw ra, 28(sp)  
    addi sp, sp, 32  
    ret
```

## Interrupt Enabling

```
li t0, 0x80  
csrs mie, t0 # enable machine timer interrupt  
  
li t0, 0x8  
csrs mstatus, t0 # set global MIE bit
```

## Check Cause of Interrupt

```
csrr t0, mcause # bit31 = interrupt flag, lower bits=cause
```

## FULLY COMMENTED POLLING EXAMPLE

```
.equ TIMER, 0xFF202000 # base addr timer
.equ TEMP, 0xFFFF0010 # temperature sensor
.equ TRANSMIT, 0xFFFF0080 # transmitter base

_start:
    la s0, TIMER # s0 = timer base address

    li t0, 50000000 # 0.5 seconds at 100MHz
    slli t1, t0, 16 # move low half up (prep masking)
    srli t1, t0, 16 # extract low 16 bits
    sw t1, 8(s0) # store low start count

    srli t0, t0, 16 # extract high 16 bits
    sw t0, 12(s0) # store high start count

    li t0, 0x6 # START + CONT bits = 0110
    sw t0, 4(s0) # write control register

polling_loop:
    lw t0, 0(s0) # read status register
    and t0, t0, 0x1 # check timeout bit
    beqz t0, polling_loop # wait until done

    sw zero, 0(s0) # acknowledge timer timeout

    la s1, TEMP
    lw t0, 0(s1) # read temperature

    la s2, TRANSMIT # transmitter base

polling_transmit:
    lw s3, 0(s2) # read status (ready bit)
    and s3, s3, 0x1 # isolate ready bit
    beqz s3, polling_transmit# wait until ready

    sw t0, 4(s2) # write temperature to transmit reg
    j polling_loop # repeat forever
```