


To setup, follow these steps



- 1 Select from the list, a serial COM port connected to device.
- 2 Press **<Connect>** button.






- 3 Press these checkboxes to remove the checkmark
- 4 Keep these items checked




- 5 Click < Add > button
- 6 Click < Send > button


Use your device and check any response here



Remap device buttons



- If enabled; **<dominance>**, **<pulse>** and **<active>** should toggle when the device buttons 7, 8 or 9 are clicked.




if enabled, it remaps device buttons to F13,...F24 function keys.



F1 to F4 keys displayed. F13-F24 are not present on a generic keyboard. However, you can change the settings of some target application to use these keys as shortcut. The keystrokes will be generated by SBW.



Tick <remap ball state> checkbox and uncheck the second



Once AutoHotkey software installed. Run Microsoft Explorer and double-click on the AutoBridge-Blender3D.ank file.


Download AutoHotkey on https://autohotkey.com/



The script is now running and active to answer the commands from SBW tool.



AutoBridge text is the window title of running script on Windows OS.



Type in the <Text in title> editbox the text AutoBridge. (case-sensitive)

If all is correct, you will see a hexadecimal number (Handle) below it. This is a "random" number.

Run Blender 3D and the commands will be sent to it.