Introduction to Embedded Systems



CS 4833: Embedded Systems

Lecture Outline

- What are **embedded** systems?
 - > NOT seen/noticed unless something goes wrong
- Why do we care about embedded systems?
 - > From iPhone to Boing 787, to space shuttle and satellites
- Typical Characteristics
- Constraints and design tradeoffs:
 - > cost, performance, time etc.
- Design challenges & metrics
- Summary

2 UT

General Computing Systems

- Personal Computers (PCs)
 - Desktops
 - Laptops
- Mainframes
- Servers











Embedded (Computing) Systems

- Computing systems embedded within another devices/systems
- Computing system other than a desktop computer/ laptop
- Perhaps 50 per household and per automobile
- Billions of units produced yearly, versus millions of desktop units













CS 4833: Embedded Systems

4 UTSA

Embedded Systems: Broad Range

- Pocket remote control RF transmitter
 - > 100 KIPS, crush-proof, long battery life
 - Software optimized for size
- Industrial equipment controller
 - > 1 MIPS, 1 MB memory; safety-critical
 - Software control loops
- Military signal processing
 - > 1 GFLOPS, 1 GB/sec IO, 32 MB
 - Software for high performance







CS 4833: Embedded Systems

UTS

Embedded Systems: Components

- Hardware
 - > Buttons, signal light and touch panel etc
 - > No mouse, keyboard or screen
- Software
 - Dedicated software
 - ➤ Simple (or no) operating systems (compare to **Windows**)



Typical Characteristics (vs. PCs)

Single-Functioned

> A single or tightly knit set of functions

Tightly-Constrained

Power, size, cost and reliability are important attributes


Reactive and real-time

- Continually reacts to changes in the system's environment
- Must compute certain results in real-time without delay

CS 4833: Embedded Systems

UTSA

Digital Camera: An Example



- Single-functioned take photos (or movies)
- Tightly-constrained -- Low cost, low power, small, fast
- Reactive and real-time -- only to a small extent

CS 4833: Embedded Systems

UTSA

Definition: An Embedded System

Key points:

- Employs a combination of hardware & software to perform a single/specific function
- Part of a larger system (not a "computer")
- Works in a *reactive* and *time-constrained* environment.
- Software provides features and flexibility
- Hardware = {Processors, ASICs, Memory,...} is used for performance (& sometimes security)

CS 4833: Embedded Systems

9 UTSA

Why are Embedded Systems Important?

- Market reasons (dollar is important ②)
 - > 90% of processors → "non-computers"
 - ➤ E.g., modern cars: tens of cpus, cost about \$2,000/car
 - ➤ Market is **around billions** of \$
- Engineering reasons
 - > Devices can be controlled by a microprocessor
 - ➤ Why does a satellite need a Windows prompt ?
 - ➤ Does McDonald's POS terminal need MacOS?
- Embedded system designers
 - ➤ Broad knowledge: hardware, software, and combination of networking, control theory and signal processing



Typical Constraints: Size and Power

- Small Size, Low Weight
 - > Handheld electronics: PDAs, cell phones, Laptops
 - Transportation and consumer: weight costs money
- Low Power
 - Longer battery life; more safe







CS 4833: Embedded Systems



Typical Constraints: Safety and Cost

- Safety critical operations
 - Must function correctly in harsh environment
 - Heat, vibration, shock
 - > Power fluctuations, RF interference, lightning
 - Water, corrosion, physical abuse
 - Out space and radiations
- Cost sensitivity
 - NRE (Non-Recurring Engineering cost): One-time monetary cost of designing and developing a new system
 - Unit cost: the monetary cost of manufacturing each copy of the system (excluding NRE cost)



Cost: NRE and Unit Cost vs. Number

Costs:

- NRE cost (Non-Recurring Engineering cost): The one-time monetary cost of designing the system
- Unit cost: the monetary cost of manufacturing each copy of the system, excluding NRE cost
- > total cost = NRE cost + unit cost * # of units
- per-product cost = total cost / # of units
 = (NRE cost / # of units) + unit cost

Example

- > NRE=\$2000, unit=\$100
- > For 10 units
 - ✓ total cost = \$2000 + 10*\$100 = \$3000
 - ✓ per-product cost = \$2000/10 + \$100 = \$300


Amortizing NRE cost over all the units


CS 4833: Embedded Systems

UTSA

NRE and Unit Cost

- Compare technologies by costs -- best depends on quantity
 - > Technology A: NRE=\$2,000, unit=\$100
 - > Technology B: NRE=\$30,000, unit=\$30
 - > Technology C: NRE=\$100,000, unit=\$2






But, must also consider time-to-market

CS 4833: Embedded Systems

4 UTS



Typical Constraints (cont.)


- **Time-to-prototype**
 - > The time needed to build a working version of the system
- Performance
 - > Response/execution time
 - > Throughput
- Flexibility and maintainability
 - Ability to change the functionality of a system without incurring heavy NRE cost


CS 4833: Embedded Systems

UTSA



- Improving one metric may worsen others
- Expertise with both software and hardware is needed to optimize design metrics
- Various technologies in order to choose the best for a given application and constraints





UTSA

Performance Design Metrics

- Widely-used measures of system (widely-abused)
 - > Clock frequency: instructions per second
 - ➤ E.g., digital camera a user cares about how fast it processes images, not clock speed or instructions per second
- Latency (response time)
 - > Time between task start and end
 - > e.g., Camera's A and B process images in 0.25 seconds

Introughput: improve on concurrency

- > Tasks per second, e.g. Camera A processes 4 images/second
- Camera B may process 8 images per second (by capturing a new image while previous image is being stored).
- Speedup of B over A: S =8/4 = 2

18




Trends in Embedded Systems

- Increasing code size
 - average code size: 16-64KB in 1992, 64K-512KB in 1996
 - migration from hand (assembly) coding to high-level languages
- Reuse of hardware and software components
 - > processors (micro-controllers, DSPs)
 - > software components (drivers)
 - Proprietary designs
- Increasing integration and system complexity
 - > integration of RF, DSP, network interfaces
 - > 32-bit processors, IO processors


CS 4833: Embedded Systems

19





Graphical Illustration of Moore's law



- Something that doubles frequently grows more quickly than most people realize!
 - > A 2002 chip can hold about 15,000 1981 chips inside itself
 - underestimation the pyramid schemes


CS 4833: Embedded Systems

21



Design Productivity Gap

- 1981 leading edge chip required 100 designer months
 - > 10,000 transistors / 100 transistors/month
- 2002 leading edge chip requires 30,000 designer months
 - > 150,000,000 / 5000 transistors/month
- Designer cost increase from \$1M to \$300M




CS 4833: Embedded Systems

22



The Mythical Man-Month

- The situation is even worse than the productivity gap indicates
- In theory, adding designers to team reduces project completion time
- In reality, productivity per designer decreases due to complexities of team management and communication
- At some point, can actually lengthen project completion time! ("Too many cooks")
- 1M transistors, 1 designer=5000 trans/month
- Each additional designer reduces for 100 trans/month
- So 2 designers produce 4900 trans/month each



Summary

- What is an embedded system?
 - ➤ More than just a computer it's a complete **system**
- Why do we care about embedded systems?
 - > From iPhone to Boing 787, to space shuttle and satellite
- Typical Characteristics
 - > Single-function, tightly-constrained, real-time and reactive
- What makes embedded systems different?
 - Many constraints on designs: Size, Power, Cost, and Performance etc.
- Design challenges & metrics

UTSA