Module Interface Specification for SynthEddy

Phil Du (Software) Nikita Holyev (Theory)

April 15, 2024

1 Revision History

Date	Version	Notes
2024-03-18 2024-03-21	1.0 1.1	Initial MIS Feedbacks by domain expert addressed

2 Symbols, Abbreviations and Acronyms

See SRS Documentation at GitHub repo

Contents

1	Revision History	j			
2	Symbols, Abbreviations and Acronyms				
3 Introduction 4 Notation					
5	Module Decomposition	2			
6	MIS of Main Control Module	3			
	6.1 Module	3 3 3			
	6.3.2 Exported Access Programs	3			
	6.4 Semantics 6.4.1 State Variables 6.4.2 Environment Variables 6.4.3 Assumptions 6.4.4 Access Routine Semantics 6.4.5 Local Functions	3 3 4 4 4			
7	MIS of Query Interface Module	5			
	7.1 Module	5 5 5 5 5			
	7.4.2 Environment Variables	6 6 7			
8	MIS of Eddy Profile Module	8			
	8.1 Module	8 8			

		8.3.1	Exported Constants	8
		8.3.2	Exported Access Programs	8
	8.4	Seman	tics	8
		8.4.1	State Variables	8
		8.4.2	Environment Variables	8
		8.4.3	Assumptions	8
		8.4.4	Access Routine Semantics	Ć
		8.4.5	Local Functions	Ć
9	MIS	of Flo	ow Field Module	10
	9.1	Modul	e	10
	9.2	Uses		10
	9.3	Syntax	<u> </u>	10
		9.3.1	Exported Constants	10
		9.3.2	Exported Access Programs	10
	9.4	Seman	tics	10
		9.4.1	State Variables	10
		9.4.2	Environment Variables	11
		9.4.3	Assumptions	11
		9.4.4	Access Routine Semantics	11
		9.4.5	Local Functions	13
10	MIS	of Ed	ldy Module	1 4
			e	14
	10.2	Uses		14
	10.3	Syntax	·	14
		10.3.1	Exported Constants	14
			Exported Access Programs	14
	10.4		tics	14
		10.4.1	State Variables	14
		10.4.2	Environment Variables	14
		10.4.3	Assumptions	14
			Access Routine Semantics	14
		10.4.5	Local Functions	15
11	MIS	of Sh	ape Function Module	16
			e	16
				16
			· · · · · · · · · · · · · · · · · · ·	16
	5		Exported Constants	16
			Exported Access Programs	16
	11.4		tics	16
	11.1		State Variables	16

	11.4.2 Environment Variables				. 16
	11.4.3 Assumptions				. 17
	11.4.4 Access Routine Semantics				. 17
	11.4.5 Local Functions				. 17
12 M	IS of File I/O Module				18
	.1 Module				. 18
	.2 Uses				
12	3 Syntax				. 18
	12.3.1 Exported Constants				
	12.3.2 Exported Access Programs				
12	4 Semantics				
	12.4.1 State Variables				
	12.4.2 Environment Variables				. 18
	12.4.3 Assumptions				
	12.4.4 Access Routine Semantics				. 19
	12.4.5 Local Functions				. 19
13 M	IS of Visualization Module				20
	IS of Visualization Module				20 . 20
13	.1 Module				. 20
13 13	.1 Module				. 20 . 20
13 13	.1 Module				. 20 . 20 . 20
13 13	1 Module		 	 	. 20 . 20 . 20 . 20
13 13 13	.1 Module	 	 	 	. 20 . 20 . 20 . 20 . 20
13 13 13	.1 Module	 	 	 	. 20 . 20 . 20 . 20 . 20 . 20
13 13 13	1 Module	 	 	 	. 20 . 20 . 20 . 20 . 20 . 20 . 20
13 13 13	1 Module	 	· · · · · · · · · · · · · · · · · · ·	 	. 20 . 20 . 20 . 20 . 20 . 20 . 20 . 20
13 13 13	1 Module	 		 	. 20 . 20 . 20 . 20 . 20 . 20 . 20 . 20
13 13 13	1 Module	 		 	. 20 . 20 . 20 . 20 . 20 . 20 . 20 . 20
13 13 13 13	1 Module	 		 	. 20 . 20 . 20 . 20 . 20 . 20 . 20 . 20

3 Introduction

The following document details the Module Interface Specifications for SynthEddy, a software to artificially generate flow field that mimics turbulent flow, which can be use as starting point for CFD simulation.

Complementary documents include the System Requirement Specifications and Module Guide. The full documentation and implementation can be found at SRS, MG.

4 Notation

The structure of the MIS for modules comes from Hoffman and Strooper (1995), with the addition that template modules have been adapted from Ghezzi et al. (2003). The mathematical notation comes from Chapter 3 of Hoffman and Strooper (1995). For instance, the symbol := is used for a multiple assignment statement and conditional rules follow the form $(c_1 \Rightarrow r_1|c_2 \Rightarrow r_2|...|c_n \Rightarrow r_n)$.

The following table summarizes the primitive data types used by SynthEddy.

Data Type	Notation	Description
character	char	a single symbol or digit
integer	\mathbb{Z}	a number without a fractional component in $(-\infty, \infty)$
natural number	N	a number without a fractional component in $[1, \infty)$
real	\mathbb{R}	any number in $(-\infty, \infty)$
boolean	\mathbb{B}	true or false

The specification of SynthEddy uses some derived data types: sequences (array), records, strings (str), and tuples. Sequences are lists filled with elements of the same data type. Strings are sequences of characters. Tuples contain a list of values, potentially of different types. In addition, SynthEddy uses functions, which are defined by the data types of their inputs and outputs. Local functions are described by giving their type signature followed by their specification.

4.1 Variable Name Traceability

To help program development and understanding, some notations regarding the eddy profile from the SRS TM and DD are altered in the MIS to better reflect their usage in the code:

- intensity: magnitude of the eddy intensity vector (α) [SRS: DD3].
- ullet orientation: unit vector direction of the eddy intensity vector ($oldsymbol{lpha}$) [SRS: DD3].

4.2 Abstract Data Types

As several modules listed in Section 5 are Abstract Data Types (ADTs), this documents use their types as follows:

- **VectorT**: 3-element NumPy array \mathbb{R}^3 , representing a 3D position or velocity vector and vector/matrix operation methods [MG: M9].
- EddyProfileT: Eddy profile object, stores a Record of different types of eddies with their parameters (intensity, length_scale), and weights for random generation [MIS8].
- FlowFieldT: Flow field object, stores all EddyT objects in that field, with methods for velocity sum calculation, see Flow Field Module [MIS9].
- QueryT: Query interface object, handles the request to query a field, see Query Interface Module [MIS7].

5 Module Decomposition

The following table is taken directly from the Module Guide document for this project.

Level 1	Level 2	
Hardware-Hiding Module		
Behaviour-Hiding Module	Main Control Module Query Interface Eddy Profile Module Flow Field Module Eddy Module Shape Function Module	
Software Decision Module	File I/O Module Vector Module Visualization Module	

Table 1: Module Hierarchy

6 MIS of Main Control Module

6.1 Module

main

6.2 Uses

- Query Interface [MIS7]
- Flow Field Module [MIS9]
- Eddy Profile Module [MIS10]

6.3 Syntax

6.3.1 Exported Constants

None.

6.3.2 Exported Access Programs

Name	In	Out	Exceptions
new	${ t profile name str},$	-	unrecognized arguments,
	${\tt field_name} \ {\rm str},$		required args not inputted
	dimensions $\mathbb{R}^3,$		
	${\tt avg_vel} \; \mathbb{R}$		
query	${ t field_name str},$	-	unrecognized arguments,
	$ exttt{query_name str},$		required args not inputted
	${\tt shape_func_name\ str},$		
	$\mathtt{cutoff}\ \mathbb{R}$		

6.4 Semantics

6.4.1 State Variables

- profile: EddyProfileT, the eddy profile object to be used for generating the flow field.
- field: FlowFieldT, the flow field object to be generated.
- query: QueryT, the query interface object to handle the request.

6.4.2 Environment Variables

• console: str, the command line console display.

6.4.3 Assumptions

None.

6.4.4 Access Routine Semantics

new(profile_name, field_name, dimensions, avg_vel):

- transition:
 - profile := eddy_profile.load(profile_name) load the eddy profile.
 - field:= flow_field.init(profile, field_name, dimensions, avg_vel) create a new field.
 - Call flow_field.save() to save itself.
 - console := "Field (field_name) generated and saved."
- exception: exc := (∄ profile_name ∨ ∄ field_name ∨ ∄ dimensions⇒ "Required arguments not inputted"). avg_vel has default value of 0.0 so it can be omitted.
- exception: exc := (input ∉ {profile_name, field_name, dimensions, avg_vel} ⇒ "Unrecognized arguments")

query(field_name, query_name, shape_func_name, cutoff):

- transition:
 - field := flow_field.load(field_name) load a saved field.
 - query := query.init(field) initialize the query interface with the field.
 - if shape_func_name is passed, call shape_func_nametion.set_active(shape_func_name) to set the active shape function.
 - if cutoff is passed, call shape_func_nametion.set_cutoff(cutoff) to set the cutoff value.
 - console := query.handle_request(query_name) to get the velocity vectors at the queried positions and times specified in query_name, and output an operation summary (where the raw result and plot are saved).
- exception: exc := (∄ field_name ∨ ∄ query_name ⇒ "Required arguments not inputted").
- exception: exc := (input ∉ {field_name, query_name, shape_func_name, cutoff} ⇒ "Unrecognized arguments")

6.4.5 Local Functions

7 MIS of Query Interface Module

7.1 Module

query

7.2 Uses

- Flow Field Module [MIS9]
- Visualization Module [MIS13]
- File I/O Module [MIS12]

7.3 Syntax

7.3.1 Exported Constants

None.

7.3.2 Exported Access Programs

Name	In	Out	Exceptions
init	field FlowFieldT	-	-
$handle_request$	$ extsf{query_name} ext{ str}$	${ t response str}$	${\tt InvalidRequest}$

7.4 Semantics

7.4.1 State Variables

- field: FlowFieldT, the flow field object to be queried.
- request: Record from request File
 - mode: str, query mode, ("meshgrid" or "points").
 - params
 - * (meshgrid mode) low_bounds: VectorT, lower bound of the meshgrid.
 - * (meshgrid mode) high_bounds: VectorT, upper bound of the meshgrid.
 - * (meshgrid mode) step_size: \mathbb{R} , step size of the meshgrid.
 - * (meshgrid mode) chunk_size: N, grid size in each chunk.
 - * (points mode) coords: {VectorT}, array of points to query.
 - * time: \mathbb{R} , time to query.
 - plot (only in meshgrid mode to save a slice cross-section plot)

- * axis: str, axis perpendicular to plot slice ("x", "y", "z").
- * index: N, index along the axis to get the slice.
- * size: \mathbb{N}^2 , pixel size of the saved image.
- velocities: array of VectorT velocities at the queried positions.
- figure: figure object outputted by Visualization Module (if requested).

7.4.2 Environment Variables

- query_file: JSON file containing the query, named after query_name.
- result_file: NumPy (.npy) file containing the raw computing result of the query.
- plot_file: PNG file containing the visualizing plot, if requested.

The reason behind using a JSON file for the query is related to the expected use case. For large meshgrid, each run will likely be submitted to a cluster. The JSON file allow users to easily pre-define the query, instead of having to input it in command line each time. The JSON file can also be easily generated by other scripts or programs. Directly passing a JSON string is also supported if this module imported by other programs.

At current stage, the program does not do much after obtaining the raw result, other than saving it to a file. In the future, more processing and analysis can be added.

7.4.3 Assumptions

None.

7.4.4 Access Routine Semantics

init(field):

• transition: field := as inputted

handle_request(query_name):

Currently, points mode is a placeholder. An array of points is handled as many single point meshgrids.

- transition:
 - request := file_io.read(query_name) parse query_file into a Record.
 - velocities := field.sum_vel_mesh(request.params) get the velocity vectors
 at the queried meshgrid and time.
 - result_file := file_io.write('results', velocities) save the result.
 - figure := visualize.plot_mesh(velocities, plot) render plot if requested.

- plot_file := file_io.write('plots', figure) save the plot if requested.
- output: response := str, operation summary, where the raw result and plot are saved.
- exception: exc := (request is not a Record or does not have expected parameters \Rightarrow InvalidRequest)

More request methods to be implemented in the future.

7.4.5 Local Functions

8 MIS of Eddy Profile Module

8.1 Module

 $eddy_profile$

8.2 Uses

• File I/O Module [MIS12]

8.3 Syntax

8.3.1 Exported Constants

None.

8.3.2 Exported Access Programs

Name	In	Out	Exceptions
init	profile_name str	-	InvalidProfile
$\mathtt{get_density}$	-	densities array of $\mathbb{R}+$	-
${\tt get_length_scale}$	-	$\texttt{length_scales} \ \mathrm{array} \ \mathrm{of} \ \mathbb{R} +$	-
${\tt get_intensity}$	-	intensities array of $\mathbb{R}+$	-

8.4 Semantics

8.4.1 State Variables

- name: str, name of the eddy profile (is also filename).
- variants: array of Records, each containing {density, length_scale, intensity}
 - density: \mathbb{R} +, how many eddies in a unit volume.
 - length_scale: $\mathbb{R}+$, the length scale (σ) of the eddy variant.
 - intensity: $\mathbb{R}+$, the intensity magnitude ($|\alpha|$) of the eddy variant.

8.4.2 Environment Variables

• profile_file: JSON file containing the eddy profile, named after profile_name.

8.4.3 Assumptions

8.4.4 Access Routine Semantics

init(profile_name):

- transition:
 - name := profile_name
 - variants := file_io.read('profiles', profile_name) load the eddy profile
 from profile_file.
- exception: $exc := ((\nexists density \lor \nexists length_scale \lor \nexists intensity) \forall variants \Rightarrow InvalidProfile)$
- exception: exc := $(\neg \forall \{\text{density}, \text{length_scale}, \text{intensity} \in \text{variants}\} > 0 \Rightarrow \text{InvalidProfile})$ get_density():
- output: densities := [density ∈ variants]
 get_length_scale():
- $\bullet \ \, {\rm output:} \ \, {\tt length_scales} := [{\tt length_scale} \in {\tt variants}] \\ \\ {\tt get_intensity():} \\$
 - output: intensities := [intensity ∈ variants]

8.4.5 Local Functions

9 MIS of Flow Field Module

9.1 Module

flow_field

9.2 Uses

- Eddy Module [MIS10]
- Vector Module [NumPy]
- File I/O Module [MIS12]

9.3 Syntax

9.3.1 Exported Constants

None.

9.3.2 Exported Access Programs

Name	In	Out	Exceptions
init	profile EddyProfileT,	-	InvalidDimensions
	${\tt field_name} \; str,$		${\tt InvalidAvgVelocity}$
	dimensions VectorT,		EddyScaleTooLarge
	${ t avg_vel} \; \mathbb{R}$		
load	${\tt field_name} \; {\rm str}$	${\tt field} \ {\tt FlowFieldT}$	-
save	-	-	-
sum_vel_mesh	high_bounds VectorT,	velocities	OutOfBoundary
	low_bounds VectorT,	array of VectorT	InvalidStepSize
	$\mathtt{step_size} \ \mathbb{R}+,$		${\tt InvalidChunkSize}$
	$\mathtt{chunk_size}\ \mathbb{N},$		InvalidTime
	time $\mathbb R$		

9.4 Semantics

9.4.1 State Variables

- profile: EddyProfileT, eddy profile to be used to generate the flow field.
- name: str, name of the flow field (is also filename).
- dimensions: VectorT, size of the flow field, with x being the axial direction, y horizontal and z vertical.

- avg_vel: \mathbb{R} , average flow velocity along x-axis.
- N: N, total number of eddies in the field.
- init_x: array of \mathbb{R} , initial x-coordinates of all eddies in the field.
- y: set {array of \mathbb{R} }, y-coordinates of all eddies in the field at each flow iteration.
- z: set {array of \mathbb{R} }, z-coordinates of all eddies in the field at each flow iteration.
- sigma: array of $\mathbb{R}+$, length scales (σ) of all eddies in the field.
- alpha: array of VectorT, intensity vector (α) of all eddies in the field.

9.4.2 Environment Variables

• field_file: binary file containing the flow field object, named after field_name.

9.4.3 Assumptions

• External flow [SRS: A4, MG: AC2]

9.4.4 Access Routine Semantics

init(profile, field_name, dimensions, avg_vel, eddy_count):

Initialize the flow field with given eddy profile. Randomly generate eddies based on their parameters and associated weights, and give them initial positions within the flow field.

- transition:
 - profile, name, dimensions, avg_vel := as inputted
 - N := \sum (profile.get_density() $\times \prod$ dimensions)
 - init_x := [-dimensions(0)/2 \leq random $\mathbb{R} \leq$ dimensions(0)/2] of size N
 - $-y := [-dimensions(1)/2 \le random \mathbb{R} \le dimensions(1)/2]$ of size N, for first 3 flow iterations
 - $-z := [-dimensions(2)/2 \le random \mathbb{R} \le dimensions(2)/2]$ of size N, for first 3 flow iterations
 - sigma := array of size N, the sigma (length scale) of each eddy variant is repeated in this array by its density \times field volume.
 - alpha := array of size N, the magnitude of alpha (intensity) of each eddy variant is repeated in this array by its density × field volume. Then this array is multiplied by an array of random unit vector to get the alpha vectors of all eddies.
- exception:

```
\begin{aligned} &-\text{ exc} := (\text{any } d \in \text{dimensions} \leq 0 \Rightarrow \text{InvalidDimensions}) \\ &-\text{ exc} := (\text{avg\_vel} < 0 \Rightarrow \text{InvalidAvgVelocity}) \\ &-\text{ exc} := (\text{any } 2 \times \sigma \in \text{sigma} > \text{any } d \in \text{dimensions} \Rightarrow \text{EddyScaleTooLarge}) \end{aligned}
```

load(field_name):

• output: field := file_io.read('fields', field_name) load the flow field from field_file.

save():

• transition: field_file := file_io.write('fields', field) save the field object.

sum_vel(low_bounds, high_bounds, step_size, chunk_size, time):

This function calculates the velocity at each position within a queried meshgrid, by summing the influence by all nearby eddies at a given time. Due to practical considerations compared to the theoretical models in SRS, it is very hard to explain this part with only formal notations. I had to use nature language.

- First, use the queried time to get its corresponding flow iteration and offset. A flow iteration (fi) is defined as when an entire x-length of the field dimension has passed due to the average flow velocity in x-direction. The offset is the x-difference compared to the start of current iteration.
- Position array of eddy centers := get_eddy_centers(fi). In this function, if the y and z positions of the input flow iteration is saved in state variables y and z, they will be returned, otherwise they will be randomly generated and stored. Then, the offset is applied to the init_x. Now the center positions of all eddies at the queried time are obtained.
- To satisfy conservation of mass, eddies that are partially outside the field need to be wrapped around to the other side. In the x-direction, the previous and next flow iterations are added. In the y and z directions, the current field is copied to outside of each side and diagonally (function get_wrap_arounds()). To save computational resources, only the eddies that are within the field or outside but touching the field are kept (function within_margin()).
- The queried region within the field is bounded by low_bounds and high_bounds. Using a resolution of step_size, this region is turned into a meshgrid. Velocity need to be calculated at each point in this meshgrid.
- To avoid repeatedly calculating influence by eddies that are far away from any given point, the field is divided into chunks of size chunk_size in each direction. For each chunk, only eddies that are either inside the chunk or outside but touching the chunk are considered (function within_margin()).

- Call eddy.sum_vel_chunk() for each chunk to get the velocity at each point in the chunk. This chunk velocity array is then merged to the entire meshgrid velocity array.
- output: velocities := array of VectorT, the velocity vectors at each point in the meshgrid.

9.4.5 Local Functions

get_eddy_centers(flow_iteration):

• output: centers := array of VectorT, eddy center positions at the queried flow iteration. See description above.

get_wrap_arounds():

• output: centers, sigma, alpha := the center position of each eddy and after wrapping, with its corresponding sigma and alpha. See description above.

within_margin(value, margin, low_bound, high_bound):

• output: out := \mathbb{B} , (value < high_bound + margin) \land (value > low_bound - margin)

10 MIS of Eddy Module

10.1 Module

eddy

10.2 Uses

• Shape Function Module [MIS11]

10.3 Syntax

10.3.1 Exported Constants

None.

10.3.2 Exported Access Programs

Name	In	Out	Exceptions
sum_vel_chunk	centers array of VectorT,	velocities	-
	sigma array of $\mathbb{R}+$,	array of VectorT	
	alpha array of VectorT,		
	x_{-} coords array of \mathbb{R} ,		
	y_{-} coords array of \mathbb{R} ,		
	z _coords array of $\mathbb R$		

10.4 Semantics

10.4.1 State Variables

None.

10.4.2 Environment Variables

None.

10.4.3 Assumptions

• All eddies are spherical (currently the only function available). Additional functions can be added to this library to support oblong/fat eddies.

10.4.4 Access Routine Semantics

sum_vel_chunk(centers, sigma, alpha, x_coords, y_coords, z_coords):

• output: velocities := array of VectorT, the velocity vectors at each point in the chunk due to spherical influence by each eddy. See [SRS: GD1].

10.4.5 Local Functions

11 MIS of Shape Function Module

11.1 Module

shape_func_nametion

11.2 Uses

• Vector Module [NumPy]

11.3 Syntax

11.3.1 Exported Constants

None.

11.3.2 Exported Access Programs

Name	In	Out	Exceptions
set_active	${ t shape_func_name\ str}$	-	FunctionNotDefined
$\mathtt{set_cutoff}$	$\mathtt{cutoff_value}\ \mathbb{R}$	-	InvalidCutoff
$\mathtt{get_cutoff}$	-	$\mathtt{cutoff_value}\ \mathbb{R}$	-
active	dk $\mathbb{R},$	$\mathtt{shape_val}\ \mathbb{R}$	-
	$\texttt{sigma} \; \mathbb{R}$		
quadratic	dk $\mathbb{R},$	$\mathtt{shape_val}\ \mathbb{R}$	-
	lsigma $\mathbb R$		
gaussian	dk $\mathbb{R},$	$\mathtt{shape_val}\ \mathbb{R}$	-
	lsigma $\mathbb R$		
	dk $\mathbb{R},$	$\mathtt{shape_val}\ \mathbb{R}$	-
	$\texttt{sigma} \; \mathbb{R}$		

User can modify this module to add more shape functions.

11.4 Semantics

11.4.1 State Variables

- active: the function that is currently designated as the active shape function.
- cutoff: \mathbb{R} , the cutoff value for the shape function.

11.4.2 Environment Variables

11.4.3 Assumptions

• sigma is always passed as input. Some shape functions may not use it, but it is always assumed to be passed by the caller so that any shape function can be used interchangeably without needing to modify the caller's module.

11.4.4 Access Routine Semantics

set_active(shape_func_name):

- transition: active := the function in this module with name shape_func_name, so that other modules can always call shape_func_nametion.active() to use the designated function.
- exception: $exc := (shape_func_name \notin \{functions in library\} \Rightarrow FunctionNotDefined)$

set_cutoff(cutoff_value):

- transition: cutoff := cutoff_value
- exception: exc := (cutoff_value ≤ 0 ⇒ InvalidCutoff)

get_cutoff():

• output: cutoff_value := cutoff

active(dk, sigma):

• output: $shape_val := \mathbb{R}$, depending on the currently active function, calls the active shape function with the inputted parameters to get output value.

quadratic(dk, sigma):

• output: $shape_val := sigma \times (1 - dk)^2$ if dk < 1 otherwise 0. See [SRS: TM1]. This function is not affected by change of cutoff value, otherwise the output will be negative when dk is greater than 1.

gaussian(dk, sigma):

• output: $shape_val := Ce^{0.5\pi dk}$ if dk < 1 otherwise 0, where C = 3.6276 (provided by Nikita)

11.4.5 Local Functions

12 MIS of File I/O Module

12.1 Module

 ${\tt file_io}$

12.2 Uses

• Hardware Hiding Module [OS]

12.3 Syntax

12.3.1 Exported Constants

None.

12.3.2 Exported Access Programs

Name	In	Out	Exceptions
read	type str, name str	Record or Array	FileNotExist
write	type str, name str, content Record or Array	-	FailToWrite

12.4 Semantics

12.4.1 State Variables

None.

12.4.2 Environment Variables

• Files on disk.

12.4.3 Assumptions

- The field name or profile name is the same as the filename.
- \bullet Saved fields are in ./fields/ and saved profiles are in ./profiles/ directories

12.4.4 Access Routine Semantics

read(type, name):

- output: out := Record or Array, the parsed content of the file.
- exception: exc := (file cannot be found at ./<type>/<name>.json \Rightarrow FileNotExist) write(type, name, content):
 - transition: write the serialized JSON string to the file on disk.
 - exception: $exc := (file cannot be written to disk \Rightarrow FailToWrite)$

12.4.5 Local Functions

13 MIS of Visualization Module

THIS IS A PLACEHOLDER [MG: AC5]

13.1 Module

visualize

13.2 Uses

• None

13.3 Syntax

13.3.1 Exported Constants

None.

13.3.2 Exported Access Programs

Name	In	Out	Exceptions
•••			

13.4 Semantics

13.4.1 State Variables

?

13.4.2 Environment Variables

?

13.4.3 Assumptions

7

13.4.4 Access Routine Semantics

?

13.4.5 Local Functions

?

References

Carlo Ghezzi, Mehdi Jazayeri, and Dino Mandrioli. Fundamentals of Software Engineering. Prentice Hall, Upper Saddle River, NJ, USA, 2nd edition, 2003.

Daniel M. Hoffman and Paul A. Strooper. Software Design, Automated Testing, and Maintenance: A Practical Approach. International Thomson Computer Press, New York, NY, USA, 1995. URL http://citeseer.ist.psu.edu/428727.html.

14 Appendix

[Extra information if required —SS]

15 Reflection

The information in this section will be used to evaluate the team members on the graduate attribute of Problem Analysis and Design. Please answer the following questions:

- 1. What are the limitations of your solution? Put another way, given unlimited resources, what could you do to make the project better? (LO_ProbSolutions)
- 2. Give a brief overview of other design solutions you considered. What are the benefits and tradeoffs of those other designs compared with the chosen design? From all the potential options, why did you select the documented design? (LO_Explores)