TATION.





PLEASE READ

USAGE COMMENTS

This PCB file was generated by the Acheron Setup script Joker template, an automated tool to generate design—ready KICAD schematic and PCB files for keyboard pr

The files generated are compatible with KICAD v6.0.1-2 version.

These files should also be accompanied of a libraries folder where the used libraries are added as submodules which last commit should point to the remote's HEAD. Please note that the files need such libraries to fully work.

You can safely delete this message, as long as you keep these comments in mind while using these files.

For requests/issues please submit a issue in the github folder. Do not attempt to contact the developers directly.

We ask that bugs/problems be reported through the issues page too.

NOTES ON TOLERANCES

The manufacturing tolerances used for PCBs in the Acheron Project are a way to uniformize the design settings of the projects. These settings were obtained using mainly three manufacturers: PCBWay, Elecrow and JLCPCB (see their capabilities pages on references [1-3]). These are big players in the asian PCB manufact

market and the tolerances practiced by them are accepted industry—wide; hence, the values used here should be enough for most manufacturers.

It must also be kept in mind that, since the Acheron Project is heavily DIY—oriented, the tolerance settings used were the easiest or cheapest available. For insta Electrow offers "standard PCB" and "advanced PCB" services ([2]), while PCBWay offers "normal difficulty", "medium difficulty" and "high difficulty" processes ([3]) In both manufacturers, the advanced settings have smaller tolerances and better manufacturing features but are significantly more expensive, specially when paired with PCB assembly services. Such settings are meant for more complex projects (high-speed or analog signal processing, finer electronic comp high-density designs etc) and are completely unnecessary for keyboard projects.

Therefore, it must always be understood that a single body of uniform tolerances throughout a wide spectrum of projects is unfeasible due to the very nature and requirements of the different PCB projects. The values suggested here used in these files are only "recommendations" based on experience, having been used in a myriad of projects throughout the Acheron Project and in Gondolindrim's personal and professional projects.

The tolerances used might seem too loose or big, but these are the bare large-scale manufacturable values found through experience using multiple factories Adjust the values at your own discretion, but be very mindful of these tolerances as they are imperative for the manufacturing process and feasibility of the final PCB. The values used divide into two groups: the "factory minimums" and the "recommended minimum" ones.

- "Factory" are the values minimally feasible needed by factories. Different ones will inevitably have different numbers, but through using multiple a common denominator was found. These values should not be used often, but seldomly at the designer's discretion and in ultimate case. Their use will incurr in highe enufacturing fees, larger lead times, more quality check issues (PCBs failing after large production).

- Recommended are the smalles tolerances double with no fabrication or quality control issues. These can be safely used without incurring in higher costs or major large-scale production issues. There is no particular reason for any of these but experience through usage of many factories. This KICAD file was set to use the recommended values in its Design Rule Checks and routines: these values were used successfully throughout the Acheron Project and

Keep in mind that these are, after all, minimum values. Always try to stray away from them when there is chance, so as to give you and the factory headroom to work with The actually used values can very well vary according to your specifications and the capabilities of the factory being used. For the actual values, check references [1-3].



- Such values *should* be enough for keyboard PCBs
- Manufacturing parameters might change in which case the tolerance values will change accordingly
 You can freely change these parameters around but make sure what those changes entail to, cost and production—wise
- If you are beggining on PCB design or are using a new fab, it might be wise to just use the values here for now

NOTES ON COPPER POURS:

while I (gondolindrim) disagree with the former I agree with the latter in some respects. Ground pours are an integral part of digital high-speed signal design; since most (if not all) modern keyboards work under USB communication which uses differential pair topology, a ground copper pour is absolutely needed to ensure proper return currents paths, low ground impedance, EMI resistance, efficiency in ESD protection, protection from overheating, and so on. Particularly in keyboard PCBs, however, the copper pours make the PCBs stiffer, reducing what is known as "flex". The way to countermeasure that is by deploying flex cuts (also known as relief cuts) or leaf-spring mounting points.

Use copper pours are your discretion but I (Gondolindrim) recommend always using them. My designs make liberal use of such pours even for other signals. At the bottom-right of the page there is a copper polygon with the settings generally used for the Acheron Project. The values are tuned for general use, but adjustments can be made. Thermal spoke width and relief gap can be adjusted according to the thermal needs -- for THT components or connectors, it is recommended to use higher gaps (0.5mm will do the trick) to avoid bad solder joints.

Avoid using hatched-pattern copper pours. They have their reason to be, but not on keyboard PCBs. They are ugly (yeah, fight me) and don't do what we want them to do here. Always use solid fills. The drawback is that they can make the PCB stiffer, so use flex cuts on the PCB.

IMPORTANT

The values and observations here listed consider a two-layer, 1 A change in manufacturing parameters (layers and copper weigh Values also pertain to the cheapest setting on the referenced m Therefore even for a 2-layer 1oz/ft2 PCB tolerances can be dif DO NOT use these values in other settings; always coordinate pr For clarification, read the NOTES ON TOLERANCES.

USED TOLERANC

REC

VIA HOLE: 0.3

VIA DIAMETER:

COPPER-TO-E

HOLE-TO-HOLE

SILKSCREEN CH

SILKSCREEN TR

SILKSCREEN CH

PAD-TO-SILKS

SOLDERMASK E

MINIMUM SOLDE

FACTORY MINIMUMS

COPPER CLEARANCE: 0.15 (see [i]) VIA HOLE: 0.2 VIA ANNULAR WIDTH: 0.13 VIA DIAMETER: 0.4 COPPER-TO-HOLE CLEARANCE: 0.3 (see [iii]) COPPER-TO-EDGE CLEARANCE: 0.2 MINIMUM THROUGH HOLE DRILL: 0.2

HOLE-TO-HOLE CLEARANCE: 0.5 SILKSCREEN CHARACTER HEIGHT: 0.8

SILKSCREEN TRACE WIDTH: 0.15 SILKSCREEN CHARACTER TRACE-TO-HEIGHT RATIO: 1:6 (see [ii])

PAD-TO-SILKSCREEN CLEARANCE: 0.15 SOLDERMASK EXPANSION: 0.05

MINIMUM SOLDERMASK BRIDGE: 0.2

ALL VALUES IN MM

- [i] Official copper-copper clearances are 0.2mm but not exactly "all copper". Pad-to-pad minimums are 0. [ii] The recommended ratio between silkscreen character height and its trace width so they are clearly legible
- [iii] The hole-to-copper clearance changes on occasion, For instance, via-to-track and NPTH-to-track cle
- [iv] The distance of copper-to-edge is a big problem for fabs in designs where traces need to be close to
- where the PCB traces need to be routed close to the flex cuts for lack of real-estate. This is why this v
- [v] The 1:6 ratio for silkscreen is OK for large characters but can become unreadable to the naked eye on a

OVERALL DESIGN RECOMI

good PCB designer, and there is always something to learn. Since PCB design is a highly techn some sorte of black magic. Do not stray from resilience. The best way to learn PCB design is d electronics and embedded systems is also recommended, but higher education in maths and end

Sharing your design and knowledge is one of the most fruitful and effective ways to learn design and talk to other designers. This ensures a collective knowledge is achieved both in hard and soft s

PCB design involves a lot of creativity and not everyone understands your codes and conventions. Take

- (1) Make liberal use of the F.Fab and B.Fab layers. Those should be used for documentation wh and polarity, values, designators, everything goes to make the fab's job easier -- and yo (2) Treat the silkscreen layers with very good care. Make sure that the component designators a
- visible. Also make sure that the silkscreen indicates the polarity of components either thr does not accompany its files; when someone looks at the PCB, component designators an (3) KiCAD allows custom user layers. Use those to indicate screw hole anchors/sizes, plate may
- or Discord conversations.
- a PCB, much like a computer code or a maths test, requires knowledge that is either a c
- Even though keyboard PCB design is very forgiving in terms of the mistakes and errors you can make, The most common problems for first-timers in keyboard PCB design are (1) USB data traces routi
- and routing. In this order, they are the most problematic parts of designing a keyboard PCB and a (1) USB DATA TRACES: make sure to route them as short as possible, parallel to one another. Also breaking and VIA'ing them as much as possible. If those are needed, do so in a simmetrical mo
- communication (see [4], pages 331-344). (2) CRYSTAL TRACES: these are the highest frequency traces on the PCB and should be handled wit the MCU (in its vicinities) and if possible sharing the same ground (ideally islanded).
- (3) BYPASS CAPACITORS: the precise function and nature of bypass (also called decoupling) capaci and engineering. In layman's terms, bypass capacitors are placed to mitigate noise inherently of traces and the switching characteristic of digital circuitry, Failure to properly place and rou to work properly. In the specific case of keyboard PCBs, there are plenty of digital circuits that LEDs and level shifters. Treat bypass capacitors like you would a crystal; as close to the main datasheets, reference manuals and application notes which will generally inform how many cap

- grapabilities link: https://www.nchway.com/canabilities.html last access august 21 2021
- [2] JLCPCB manufacturing capabilities. Link: https://jlcpcb.com/capabilities/Capabilities. Last accessed august 21, 2021.
- [3] Elecrow manufacturing capabilities. Link: https://www.elecrow.com/download/quote/PCB_Specification_FAQ.pdf. Last access august 21, 2021.
 [4] Sanjeeb Mishra, Neeraj Kumar Singh, Vijayakrishnan Rousseau. System on Chip Interfaces for Low Power Design. Morgan Kaufmann, 2016. ISBN 9780128016305. Accessible via https://www.sciencedirect.com/science/article/pii/B9780128016305000104)
- [5] Seeedstudio manufacturing capabilities. Link: https://support.seeedstudio.com/knowledgebase/articles/447362-fusion-pcb-specification. Last accessed august 21, 2021