

Document Title	Specification of MACsec Key Agreement
Document Owner	AUTOSAR
Document Responsibility	AUTOSAR
Document Identification No	1066

Document Status	published
Part of AUTOSAR Standard	Classic Platform
Part of Standard Release	R22-11

Document Change History			
Date	Release	Changed by	Description
		AUTOSAR	
2022-11-24	R22-11	Release Management	Initial release



Disclaimer

This work (specification and/or software implementation) and the material contained in it, as released by AUTOSAR, is for the purpose of information only. AUTOSAR and the companies that have contributed to it shall not be liable for any use of the work.

The material contained in this work is protected by copyright and other types of intellectual property rights. The commercial exploitation of the material contained in this work requires a license to such intellectual property rights.

This work may be utilized or reproduced without any modification, in any form or by any means, for informational purposes only. For any other purpose, no part of the work may be utilized or reproduced, in any form or by any means, without permission in writing from the publisher.

The work has been developed for automotive applications only. It has neither been developed, nor tested for non-automotive applications.

The word AUTOSAR and the AUTOSAR logo are registered trademarks.



Contents

1	Introduction and functional overview		
2	Acronyms and Abbreviations		
3	Related documentation		
	3.1 3.2	Input documents & related standards and norms	8 8
4	Cons	straints and assumptions	9
	4.1 4.2	Limitations	9 9
5	Depe	endencies to other modules	10
	5.1 5.2	Connection to Ethernet Interface (EthIf)	10
	5.3	Driver	11 11
6		uirements Tracing	12
	•		
7	Fund	ctional specification	14
	7.1 7.2	Background and rationale	14 14
	1.2	7.2.1 Functional components	16
		7.2.1.1 Port Access Entity (PAE)	16
		7.2.1.2 MACsec Key Agreement Entity (KaY)	17
	7.3	General Requirements	17
	7.4	Limitations	20
		7.4.1 Limitations on MKA Entity	20
	7.5	Cryptographic requirements	20
	7.6	Communication with MACsec Entity (SecY)	21
	7.7	Configurable behavior of MKA	22
		7.7.1 MKA behavior	23
		7.7.2 MKA Error Handling	23
	7.8	Error Classification	24
		7.8.1 Development Errors	24
		7.8.2 Runtime Errors	24
		7.8.3 Transient Faults	24
		7.8.4 Production Errors	24
		7.8.5 Extended Production Errors	25
		7.8.5.1 MKA_E_TIMEOUT_INSTANCE	25
		7.8.5.2 MKA_E_KEY_NOT_PRESENT_INSTANCE	26
		7.8.5.3 MKA_E_KEY_MISMATCH_INSTANCE	26
		7.8.5.4 MKA_E_ALGO_MISMATCH_INSTANCE	27



8	API	specificatio	n 28
	8.1	Imported	l types
	8.2		initions
		8.2.1	Mka_MacSecConfigType
		8.2.2	Mka_ValidateFramesType
		8.2.3	Mka_ConfidentialityOffsetType
		8.2.4	Mka_Stats_Tx_SecYType
		8.2.5	Mka_Stats_Rx_SecYType
		8.2.6	Mka_Stats_Tx_ScType
		8.2.7	Mka_Stats_Rx_ScType
		8.2.8	Mka_SakKeyPtrType
		8.2.9	Mka_PermissiveModeType
		8.2.10	Mka_Stats_SecYType
		8.2.11	Mka_PaeStatusType
		8.2.12	Mka_MkaStatusType
		8.2.13	Mka_ConfigType
	8.3	Function	definitions
		8.3.1	Mka_Init
		8.3.2	Mka_GetVersionInfo
		8.3.3	Mka_SetCknStatus
		8.3.4	Mka_GetCknStatus
		8.3.5	Mka_SetEnable
		8.3.6	Mka_GetEnable
		8.3.7	Mka_GetPaeStatus
		8.3.8	Mka_SetPaePermissiveMode 40
		8.3.9	Mka_StartPae
		8.3.10	Mka_GetMacSecStatistics
		8.3.11	Mka_LinkStateChange
	8.4	Callback	notifications
		8.4.1	Mka_GetMacSecStatisticsNotification
		8.4.2	Mka_RxIndication
		8.4.3	Mka_TxConfirmation
		8.4.4	Mka_MacSecUpdateSecYNotification
		8.4.5	Mka_MacSecAddTxSaNotification
		8.4.6	Mka_MacSecAddRxSaNotification
	8.5		ed functions
		8.5.1	Mka_MainFunction
	8.6	•	d interfaces
		8.6.1	Mandatory interfaces
		8.6.2	Optional interfaces
		8.6.3	Configurable interfaces
	8.7	Service I	nterfaces
9	Seq	uence diag	rams 48
	9.1	Commun	nication initialization with MACsec
	9.2	Commur	nication initialization with MACsec and Switch 50





10	Configuration specification	51
	10.1 How to read this chapter	51
	10.2 Containers and configuration parameters	51
	10.2.1 Mka	51
	10.2.2 MkaGeneral	52
	10.2.3 MkaPaeConfiguration	55
	10.2.4 MkaCryptoAlgoConfig	57
	10.2.5 MkaCipherSuites	61
	10.2.6 MkaPaeInstance	62
	10.2.7 MkaKay	65
	10.2.8 MkaKayParticipant	68
	10.2.9 MkaKayDemEventParameterRefs	74
	10.3 Published Information	75
Α	Not applicable requirements	76



1 Introduction and functional overview

This specification describes the functionality, API and the configuration for the AUTOSAR Basic Software module MKA.



2 Acronyms and Abbreviations

The glossary below includes acronyms and abbreviations relevant to the MKA module that are not included in the [1, AUTOSAR glossary].

Abbreviation / Acronym:	Description:	
AN	Association Number	
CA	Secure Connectivity Association	
CAK	Secure Connectivity Association Key	
DA	Destination Address	
ICV	Integrity Check Value	
KaY	MAC Security Key Agreement Entity	
MACsec	Media Access Control Security	
MKA	MACsec Key Agreement protocol (IEEE Std 802.1X)	
MKPDU	MACsec Key Agreement Protocol Data Unit	
MPDU	MACsec Protocol Data Unit	
PAE	Port Access Entity	
PN	Packet Number	
SA	Secure Association or Source Address, as applicable	
SAI	Secure Association Identifier	
SAK	Secure Association Key	
SC	Secure Channel	
SCI	Secure Channel Identifier	
SecTAG	MAC Security TAG	
SecY	MAC Security Entity	
SL	Short Length	
SSCI	Short Secure Channel Identifier	
TLV	Tag-Length-Value	

Table 2.1: Acronyms and abbreviations used in the scope of this Document



3 Related documentation

3.1 Input documents & related standards and norms

- [1] Glossary AUTOSAR_TR_Glossary
- [2] General Specification of Basic Software Modules AUTOSAR SWS BSWGeneral
- [3] Requirements on MACsec AUTOSAR_RS_MACsec
- [4] IEEE Standard for Local and metropolitan area networks-Media Access Control (MAC) Security https://ieeexplore.ieee.org/document/8585421
- [5] IEEE Standard for Local and Metropolitan Area Networks—Port-Based Network Access Control https://ieeexplore.ieee.org/document/9018454
- [6] Advanced Encryption Standard (AES) Key Wrap Algorithm https://tools.ietf.org/html/rfc3394

3.2 Related specification

AUTOSAR provides

- a General Specification on Basic Software modules [2, SWS BSW General], which is also valid for MKA.
- a MACsec Requirements Specification [3, RS MACsec] which is also valid for MKA.

Thus, the specification [2, SWS BSW General] shall be considered as additional and required specification for MKA.



4 Constraints and assumptions

4.1 Limitations

This document does not cover the integration neither requirements of the MACsec protocol as it is an IEEE published standard [4, IEEE 802.1AE-2018].

The AUTOSAR MACsec implementation currently has the following limitations:

- Only participants authentication based on Connectivity Association pre-shared keys (CAKs) is supported. (EAP-TLS, EAP-IKEv2, and other variants are not supported).
- Only MACsec between direct peers is supported (e.g. Point-to-Point configurations).
- Point-to-Multipoint configurations are not supported.
- In-service upgrades with EAPoL-MKA frames are not supported.
- Temporary suspension of MKA operation is not supported.
- MACsec Cipher Suites is the only currently supported EAPoL-Announcement TLV.

The following EAPoL Announcements are currently not required:

- Access Information → TLV Type 111
- Key Management Domain → TLV Type 113
- NID → TLV Type 114
- Dynamic Key Server election based on Key Server priority is not supported (Roles are set per configuration and fixed).
- The following MKPDU Parameter sets are currently not required:
 - Distributed CAK → Parameter set type 5
 - KMD → Parameter set type 6
 - ICV Indicator → Parameter set type 255

4.2 Applicability to car domains

Automotive systems require quicker start-up times for the devices connected to the on-board network, hence the protocol convergence time must be tuned accordingly.



5 Dependencies to other modules

The MACsec Key Agreement (MKA) Module has interfaces with the following modules:

- 1. EthIf \rightarrow To configure, control, and monitor the MACsec Entity (per SW or HW).
- 2. CSM:
 - Protect outgoing MKA messages and validate incoming MKA messages.
 - Generate, encrypt, and decrypt session keys (SAKs).

5.1 Connection to Ethernet Interface (Ethlf)

The MKA module and the Ethlf are connected in order to:

- Receive and send MKA messages.
- Provide MACsec specific parameters to the lower layers.
- Orchestrate the Link-Up and Link-Down signaling of the interfaces for upper layers (i.e. through the EthSM).

In case an Ethernet Interface is MACsec protected, it will use a specific MKA module instance to configure the MACsec Entities (HW or SW) for transmission and reception.

In case the MACsec protected Ethernet Interface is required to be ACTIVE by the EthSM, after the signaling of the physical Link-up from the specific transceiver or Switch port(ETH_MODE_ACTIVE), the EthIf will delegate the establishment of at least one Secure Channel with the communication peers, to the referred MKA instance. Once the MACsec Secure Channel is established and both participants can successfully receive and transmit, the Ethernet Interface will signal the Link-Up to the upper layers (e.g. through the Ethernet State Manager).

During the lifetime of the established SCs, the MKA module will maintain them alive by communicating with the MACsec Entities through the Ethernet Interface module. That means, updating the SC specific parameters in the MACsec Entities (Phy, Switch, or SW Entity).

Detailed information: The trigger to the MKA module to start the MACsec SC establishment is done after the EthTrcv or EthSwt mode indication to ACTIVE and before indicating this state to the EthSM (that means, the EthSM will stay in the ETHSM_STATE_WAIT_TRCVLINK state, as in this state the EthSM and the underlying EthIf is starting up the physical network interface, but the upper layer protocols (e.g., in TCP/IP) are not started yet).

Once triggered, the MKA module can start the needed actions to establish a MACsec



Secure Channel through the provided port. If MACsec is not configured in the port, the MKA module call will be skipped.

5.2 Indirect connection to EthDriver, EthSwitchDriver and Eth-TransceiverDriver

In case the MACsec Entity is offloaded to a HW device, the MKA module is indirectly connected to the EthDriver, EthSwitchDriver, and EthTranceiverDriver through the EthInterface. This connection is needed in order to establish, configure, and manage the needed MACsec Secure Channels. There are functions in the interface of the EthDriver, EthSwitchDriver and EthTransceiverDriver for that purpose.

Establishing a Secure Channel is done via the MACsec Key Agreement protocol, the MKA module will handle all protocol steps. These specific protocol datagrams are setup and organized by the MKA module. Thus, the MKA module provides via the existing function call the datagram to the Ethernet Interface, which then sends the datagram to the communication peer. This behavior is handled via a specific pair EtherType and message type, and is set via the interface. With this EtherType, the Ethernet Interface will handle the datagram on Rx and Tx trace.

5.3 Connection to Crypto Service Manager (CSM)

The MKA module requires a connection to the cryptographic BSW modules of AUTOSAR. This allows the MKA module to derive and use the needed keys and to interact with the cryptographic algorithms as specified in [5, IEEE-802.1X-2020] and [4, IEEE-802.1AE-2018].

For cryptographic usage, the MKA module needs following support from the BSW crypto:

- KDF (as described in [5, IEEE-802.1AE-2018] chapter 6.2.1) to derive ICK and KEK from CAK.
- AES-CMAC, which uses AES CMAC with 128bits, using ICK to generate and validate MKA message ICVs.
- A function to generate random data (for SAK and Member Identifier).
- AES-KEYWRAP based on [6, RFC 3394] to encrypt keys for transmission.



6 Requirements Tracing

The following tables reference the requirements specified in the documents listed in section 3.2 and links to the fulfillment of these. Please note that if column "Satisfied by" is empty for a specific requirement this means that this requirement is not fulfilled by this document.

Requirement	Description	Satisfied by
[FO_RS_MACsec 00001]	MACsec Protocol support	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00002]	MACsec Key Agreement Protocol support	[CP_SWS_Mka_00001] [CP_SWS_Mka_00002] [CP_SWS_Mka_00003] [CP_SWS_Mka_00004] [CP_SWS_Mka_00004] [CP_SWS_Mka_00006] [CP_SWS_Mka_00006] [CP_SWS_Mka_00007] [CP_SWS_Mka_00008] [CP_SWS_Mka_000015] [CP_SWS_Mka_00011] [CP_SWS_Mka_00015] [CP_SWS_Mka_00016] [CP_SWS_Mka_00017] [CP_SWS_Mka_00024] [CP_SWS_Mka_00031] [CP_SWS_Mka_00032] [CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00003]	Using MACsec on external communication links	[CP_SWS_Mka_00001] [CP_SWS_Mka_00002] [CP_SWS_Mka_00006] [CP_SWS_Mka_00008] [CP_SWS_Mka_00011] [CP_SWS_Mka_00024]
[FO_RS_MACsec 00004]	Configure which Ethernet ports use MACsec	[CP_SWS_Mka_00002]
[FO_RS_MACsec 00005]	MACsec status control	[CP_SWS_Mka_00026] [CP_SWS_Mka_00027] [CP_SWS_Mka_00028] [CP_SWS_Mka_00029] [CP_SWS_Mka_00030]
[FO_RS_MACsec 00006]	MACsec support for Adaptive AUTOSAR Platform	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00007]	Configuration of unprotected traffic (for Software-based MACsec)	[CP_SWS_Mka_00003] [CP_SWS_Mka_00004]
[FO_RS_MACsec 00008]	Configuration of unprotected traffic (for Hardware-based MACsec)	[CP_SWS_Mka_00003] [CP_SWS_Mka_00004]
[FO_RS_MACsec 00009]	MACsec Security Events	[CP_SWS_Mka_00025]
[FO_RS_MACsec 00010]	Support of integrity and confidentiality	[CP_SWS_Mka_00008]
[FO_RS_MACsec 00011]	MAC Security TAG	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00012]	MACsec EtherType	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00017]	Support of Extended Packet Number (XPN)	[CP_SWS_Mka_00008]
[FO_RS_MACsec 00018]	Secure Channel Identifier (SCI)	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00019]	Secure Data	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00020]	Integrity Check Value (ICV)	[CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00021]	Protect function in software solution	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00022]	Validation function in software solution	[CP_SWS_Mka_00999]





 \triangle

Requirement	Description	Satisfied by
[FO_RS_MACsec 00023]	Support of MKA Packets	[CP_SWS_Mka_00001] [CP_SWS_Mka_00008]
[FO_RS_MACsec 00024]	Pre-shared key support	[CP_SWS_Mka_00001] [CP_SWS_Mka_00005] [CP_SWS_Mka_00016]
[FO_RS_MACsec 00025]	Key selection via CKN	[CP_SWS_Mka_00001] [CP_SWS_Mka_00005] [CP_SWS_Mka_00006]
[FO_RS_MACsec 00026]	GCM-based cipher support	[CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00027]	Support of AES ciphers with at least 128 bits of key length	[CP_SWS_Mka_00009] [CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00028]	Support of AES ciphers with 256 bits of key length	[CP_SWS_Mka_00009] [CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00029]	Support of Key Encryption Key (KEK)	[CP_SWS_Mka_00001] [CP_SWS_Mka_00006] [CP_SWS_Mka_00022] [CP_SWS_Mka_00023] [CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00030]	Support of Integrity Check Value Key (ICK)	[CP_SWS_Mka_00006] [CP_SWS_Mka_00022]
[FO_RS_MACsec 00031]	Support of Key Derivation Function (KDF)	[CP_SWS_Mka_00007]
[FO_RS_MACsec 00032]	List of minimal supported cipher suites	[CP_SWS_Mka_00009] [CP_SWS_Mka_CONSTR_00019] [CP_SWS_Mka_CONSTR_00020]
[FO_RS_MACsec 00033]	Validation function for ICVs	[CP_SWS_Mka_00001] [CP_SWS_Mka_00006]
[FO_RS_MACsec 00034]	Generation function for ICVs	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00035]	Key Handling with combined HSM and MACsec functionality	[CP_SWS_Mka_00023]
[FO_RS_MACsec 00036]	Interframe gap configuration of Ethernet controller	[CP_SWS_Mka_00999]
[FO_RS_MACsec 00037]	MACsec participants per link	[CP_SWS_Mka_00015]
[FO_RS_MACsec 00038]	MKA SC establishment retry phase	[CP_SWS_Mka_00012]
[FO_RS_MACsec 00039]	MKA rekey conditions	[CP_SWS_Mka_00013] [CP_SWS_Mka_00014]
[SRS_BSW_00323]	All AUTOSAR Basic Software Modules shall check passed API parameters for validity	[CP_SWS_Mka_91035]
[SRS_BSW_00337]	Classification of development errors	[CP_SWS_Mka_00200] [CP_SWS_Mka_00201] [CP_SWS_Mka_00202] [CP_SWS_Mka_00203] [CP_SWS_Mka_91035]
[SRS_BSW_00385]	List possible error notifications	[CP_SWS_Mka_00200] [CP_SWS_Mka_00201] [CP_SWS_Mka_00202] [CP_SWS_Mka_00203] [CP_SWS_Mka_91035]

Table 6.1: RequirementsTracing



7 Functional specification

7.1 Background and rationale

A detailed description of the MACsec and MACsec Key Agreement protocols is included in [3, RS MACsec] chapter 4.1.

7.2 Motivation

The aim of this document is to specify how to integrate the MKA Module in the Software Layered Architecture of the AUTOSAR Classic Platform.

The purpose of the MACsec Key Agreement Module is to provide a method for discovering MACsec peers and negotiate the security keys needed to secure the link. The MKA Module is responsible for:

- Generating (outgoing) and processing (incoming) MKPDUs.
- Identify and authenticate other partners belonging to the same Connectivity Association (CA).
- Configure and supply the parameters and cryptographic data to the MACsec Entity (per SW or HW) for the respective Secure Channel and Secure Associations established.
- Keep the established Secure Channel (SC) and Secure Association (SA) information updated.
- Refresh keys for an specific Secure Channel to allow exchanging Secure Association Keys (SAKs) without disrupting the communication channel.

The MKA module supports:

- The configuration, initialization, and maintenance of Port Access Entities (PAEs).
- The configuration, initialization, shutdown, and maintenance of MKA Entities (KaYs) which belong to an specific PAE.
- The communication with other AUTOSAR Modules to initialize, update, and shutdown MACsec related parameters into the MACsec Entity (SecY).

The limitations of the referred IEEE standards are included in chapter 4.

Figure 7.1 depicts the MACsec Key Agreement protocol parameter sets exchanged to establish a Secure Channel and finally enable MACsec protected secure communication.






Figure 7.1: fig: MACsec Key Agreement sequence with pre-shared key

Figure 7.2 provides an architecture overview of the AUTOSAR MKA module in the Layered Software Architecture.




Figure 7.2: MKA module in the SW Architecture of AUTOSAR CP



Based on the IEEE standards ([4, IEEE-802.1AE-2018] and [5, IEEE-802.1X-2020]), the system allows to configure, setup, and run integrity protected and/or encrypted data communication per Ethernet port. This implies that the architecture, specification, and the later implementation enables MACsec on each port when this is configured via AUTOSAR configuration. Additionally, this configuration is not only restricted towards ports. MACsec allows to "bypass" traffic based on EtherType or VLAN-ID. This means that MACsec lets selected traffic pass unprotected.

The usage of MACsec will be statically configured in advance for the entities supporting the protocol, the configuration will be based on rules. This includes rules for determining the bypassed traffic. Since the bypassed traffic can be based on VLAN IDs, the handling of MACsec protected networks interacts with VLAN-based communication. Bypassed traffic is available as soon as a link-up of the transceiver occurs, while protected traffic needs to wait for MACsec and its Key-Agreement sequence to finish first.

The Ethernet Interface will behave different for protected and unprotected traffic. The Ethernet Interface (EthIf) sequence is modified in case the controller (and therefore EthSwt and/or EthTrcv) has to deal with a MACsec protected port.

After receiving a Link-up indication from a MACsec protected port (which could be after a Switch), the Ethernet Interface will trigger the MKA Module to start the MKA Sequence for the corresponding port. Once the MKA module signals the success of the MKA sequence and therefore the proper configuration of MACsec on the port, the Link-Up is propagated to the upper layers (i.e., EthSM or others through the corresponding UL_LinkStateChg method). This is essential to start the upper layer protocols (e.g., SOME/IP-SD) as soon as the MACsec protected link is ready to be used.

This applies as well in case Groups of Ports are defined for the respective network.

7.2.1 Functional components

7.2.1.1 Port Access Entity (PAE)

In the [5, IEEE-802.1X-2020] standard the Port Access Entity (PAE) describes the (SW) entity that controls an Ethernet port. This includes allowing traffic to flow or not to flow but also controlling the MACsec functionality based on the MACsec Key Agreement protocol (MKA).

[5, IEEE-802.1X-2020] defines port based authentication over EAP and, as a particular use case, the MACsec Key Agreement protocol over EAP. In the current version of this document, authentication over EAP is not supported and therefore only authentication based on pre-shared CA Keys (CAKs) is relevant.

The PAE will take care of orchestrating the initialization and shutdown of MKA instances (defined in next section) and setting the status (enabled/disabled) of the physical or virtual controlled port based on the feedback provided by the underlying KaYs.



For a better understanding of the PAE structure, refer to [5, IEEE-802.1X-2020] chapter 12.

7.2.1.2 MACsec Key Agreement Entity (KaY)

Each PAE can have one or multiple MACsec Key Agreement participants (KaY participants) depending on the CKNs assigned to the Port Access Entity.

Each KaY is responsible of recognizing peers which belong to the same CA, distribute and/or install SAKs, and keep the MACsec information up to date during the SC lifetime.

The KaY handles the MKA protocol behavior, including the generation and process of MKPDUs, the control of the cipher suites to use and, the maintenance of the MACsec related parameters of the MACsec Entity (SecY), including Keys (SAKs).

7.3 General Requirements

[CP_SWS_Mka_00001]{DRAFT} [The MKA Module shall implement the EAP-MKA protocol version 3 as specified in [5, IEEE-802.1X-2020] chapter 9 and AUTOSAR Foundation [3, RS_MACsec].](FO_RS_MACsec_00002, FO_RS_MACsec_00003, FO_RS_MACsec_00023, FO_RS_MACsec_00024, FO_RS_MACsec_00025, FO_RS_MACsec_00029, FO_RS_MACsec_00033)

Note: The MKA Module should be modeled as described in [5, IEEE-802.1X-2020] chapter 12.

For the excluded parts please refer to section 4.1.

[CP_SWS_Mka_00002]{DRAFT} The MKA Module shall support 1 to n independent Port Access Entities (PAEs) running at the same time through different ports. (FO_-RS_MACsec_00002, FO_RS_MACsec_00003, FO_RS_MACsec_00004)

Note: Each physical (Switch port or transceiver) or virtual (MACsec per SW) port will support 0 (No MACsec) or 1 PAE.

[CP_SWS_Mka_00003]{DRAFT} The MKA Module shall support a list of VLANs to get MACsec bypassed per PAE (i.e. per physical (Switch port or transceiver) or virtual (MACsec per SW) port).

The list of bypassed VLANs shall be provided per configuration (MkaBypassVlan).] (FO RS MACsec 00002, FO RS MACsec 00007, FO RS MACsec 00008)

Note: The MACsec by-passed traffic will be unprotected traffic through the port.

[CP_SWS_Mka_00004]{DRAFT} The MKA Module shall support a list of EtherTypes to get MACsec bypassed per PAE (i.e. per physical (Switch port or transceiver) or virtual (MACsec per SW) port).

The list of bypassed EtherTypes shall be provided per configuration (MkaBypas-



sEtherType).] (FO_RS_MACsec_00002, FO_RS_MACsec_00007, FO_RS_MACsec_00008)

Note: The MACsec bypassed traffic will be unprotected traffic through the port.

[CP_SWS_Mka_00005]{DRAFT} The MKA Module shall support configuring 1 to n CKNs in an specific Port Access Entity (PAE).

Each configured CKN will start a parallel MACsec participant entity (i.e. MkaKayParticipant) through the mentioned PAE.

Repeated CKNs shall be treated as one for an specific PAE. [FO_RS_MACsec_00002, FO_RS_MACsec_00024, FO_RS_MACsec_00025]

Note: It is recommended to implement a configuration check to avoid duplicated CKNs referred under the same MkaKay instance.

[CP_SWS_Mka_00006]{DRAFT} [An MKA KaY participant (MkaKayParticipant) shall not start transmitting or processing MKPDUs until its respective CAK is available and the derived keys (ICK and KEK) are ready.](FO_RS_MACsec_00002, FO_RS_MACsec_00003, FO_RS_MACsec_00025, FO_RS_MACsec_00029, FO_RS_MACsec_00030, FO_RS_MACsec_00033)

[CP_SWS_Mka_00007]{DRAFT} The MKA Module shall support generation of SAKs based on:

- Key Derivation Function (KDF), see [5, IEEE-802.1X-2020] chapter 9.8.1.
- Random Number Generator (RNG)

(FO RS MACsec 00002, FO RS MACsec 00031)

[CP_SWS_Mka_00008]{DRAFT} [The MKA Module shall support the following MKPDU Parameter sets:

- Basic Parameter Set
- Live Peer List → Parameter set type 1
- Potential Peer List → Parameter set type 2
- MACsec SAK Use → Parameter set type 3
- Distributed SAK → Parameter set type 4
- Announcement → Parameter set type 7
- XPN → Parameter set type 8

[FO_RS_MACsec_00002, FO_RS_MACsec_00003, FO_RS_MACsec_00010, FO_RS_MACsec_00017, FO_RS_MACsec_00023]

[CP_SWS_Mka_00009]{DRAFT} [The MKA Module shall implement the EAPoL-MKA-Announcement with TLV type 112 (MACsec cipher suites) as specified in [5, IEEE-



802.1X-2020] chapter 11.12.3. \((FO_RS_MACsec_00002, FO_RS_MACsec_00027, FO_RS_MACsec_00028, FO_RS_MACsec_00032) \)

Note: The MACsec cipher suite announcement serves for the Key Server to recognize the ciphers supported by the other end.

The EAPoL-Announcement TLV shall be transmitted as a parameter on an EAPoL-MKA Announcement Parameter Set as defined in Figure 11-15 of [5, IEEE-802.1X-2020].

[CP_SWS_Mka_00011]{DRAFT} [The role of an MKA instance (MkaKay) shall be set per configuration (i.e. MKA_KEY_SERVER or MKA_PEER) (MkaRole).

The Key Server priority shall be configurable (MkaKeyServerPriority), in case it is not specifically provided in configuration the following values shall be used:

- Key Server = 0
- Peer = 255

(FO RS MACsec 00002, FO RS MACsec 00003)

[CP_SWS_Mka_00012]{DRAFT} The MKA Module shall support retry for the MKA sequence.

If an MKA KaY participant (MkaKayParticipant) cannot successfully identify or successfully establish a SC with any participant in the link, it should retry the MKA sequence following a per configuration parametrized retry base delay with Exponential Back-off (MkaRetryBaseDelay) until a retry cyclic delay (MkaRetryCyclicDelay). | (FO_RS_MACsec_00038)

Note: As an example, in case MkaRetryBaseDelay = 0.02 and MkaRetryCyclicDelay = 0.5, the retry sequence will be as follows 20ms, 40ms, 80ms, 160ms, 320ms, 500ms, 500ms, ...

[CP_SWS_Mka_00013]{DRAFT} [The MKA Instances (MkaKay) configured with the Key Server (MKA_KEY_SERVER) role shall support re-keying distributed SAKs after a configurable time span (MkaSakRekeyTimeSpan).|(FO RS MACsec 00039)

Note: The time span is set per configuration.

[CP_SWS_Mka_00014]{DRAFT} [The MKA Instances configured with the Key Server (MKA_KEY_SERVER) role shall rekey distributed SAKs in case the packet number space of one direction (sending or receiving) exceeds:

- 0xC000 0000 for 32-bit PNs.
- 0xC000 0000 0000 0000 for 64-bit PNs (XPN mode).

(FO RS MACsec 00039)

Note: This is required in the [5, IEEE-802.1X-2020] standard, chapter 9.8.



[CP_SWS_Mka_00015]{DRAFT} [Each MKA instance shall assume exactly two participants per link. Therefore, having exactly one peer.] (FO_RS_MACsec_00002, FO_-RS_MACsec_00037)

Note: This implies, that one must take the Key Server role and the other the peer role. This requirement permits a MKA instance to immediately continue with the MKA sequence after detecting and successfully authenticating another participant in the link which belongs to the same CA, avoiding start-up delays.

7.4 Limitations

An overview of non-supported features can be found in chapter 4.

7.4.1 Limitations on MKA Entity

[CP_SWS_Mka_00016]{DRAFT} [The MKA Module may support authentication based on EAP as detailed in [5, IEEE-802.1X-2020] chapter 8.] (FO_RS_MACsec_-00002, FO_RS_MACsec_00024)

Note: Authentication based on EAP is not required as the mutual authentication of participants is achieved based on pre-shared Keys.

[CP_SWS_Mka_00017]{DRAFT} [The MKA Module shall support only one MKA Participant (MkaKayParticipant) to success per port (i.e. per PAE MkaPaeInstance). If one KaY participant is able to correctly establish a SC, the other started participants (MkaKayParticipant) of the same PAE shall give up. | (FO RS MACsec 00002)

Note: As specified in [CP_SWS_Mka_00005], a PAE instance can initiate 1 to n MKA participant instances (MkaKayParticipant) but only one of them shall succeed configuring a Secure Channel in the port (Point-to-Multipoint architecture is not supported).

7.5 Cryptographic requirements

[CP_SWS_Mka_CONSTR_00019]{DRAFT} The MKA Module shall support the following Cipher suites to be configured in the MACsec Entity (either per SW or HW):

- GCM-AES-128
- GCM-AES-256
- GCM-AES-XPN-128
- GCM-AES-XPN-256



[FO_RS_MACsec_00002, FO_RS_MACsec_00020, FO_RS_MACsec_00026, FO_RS_MACsec_00027, FO_RS_MACsec_00028, FO_RS_MACsec_00029, FO_RS_MACsec_00032)

Note: The MKA Module shall support announcing and configuring the listed ciphers (MkaMacSecCipherSuite).

Detailed information can be found in [5, IEEE-802.1X-2020] Figure 11-12 and [4, IEEE-802.1AE-2018] chapter 14.3.

[CP_SWS_Mka_CONSTR_00020]{DRAFT} [The MKA Module shall support configuring 1 to 4 cipher suites per MkaCryptoAlgoConfig, each of them with an unique MkaMacSecCipherSuitePrio.

The MkaMacSecCipherSuitePrio shall accept the value 1 to 4, being 1 the higher priority and 4 the lowest priority. \([FO_RS_MACsec_00002, FO_RS_MACsec_00020, FO_RS_MACsec_00026, FO_RS_MACsec_00027, FO_RS_MACsec_00028, FO_RS_MACsec_00029, FO_RS_MACsec_00032)

Note: The MkaMacSecCipherSuitePrio parameter shall be used by a MkaKay-Participant with MkaRole = MKA_KEY_SERVER to select the cipher suite to use for MACsec with the other participant within the common cipher suites supported (shared with the EAPoL-MKA-Announcement "MACsec cipher suites").

The cryptographic operations like the derivation of MACsec keys and authentication based on CAK pre-shared keys should be delegated to the CSM Module.

Note: For detailed information, refer to [5, IEEE-802.1X-2020] chapter 9.3.

[CP_SWS_Mka_00022]{DRAFT} [Derived keys (specifically ICKs and KEKs) may get pre-calculated and stored in tamper proof manner to optimize the initialization time of the module.

SAKs are implicitly excluded from this requirement. SAKs must not be pre-calculated neither reused. | (FO RS MACsec 00029, FO RS MACsec 00030)

[CP_SWS_Mka_00023]{DRAFT} [It shall be supported that Secure Association Keys (SAKs) can directly be installed from a HSM to a MACsec Entity (SecY).](FO_RS_-MACsec 00029, FO RS MACsec 00035)

7.6 Communication with MACsec Entity (SecY)

The MKA Module, and particularly a specific MKA Entity (KaY) running over a PAE, shall initialize and maintain a Secure Channel for MACsec over an specific MACsec Entity (SecY). The mentioned MACsec Entity can be a SW implementation of MACsec in lower layers or a HW implementation in a Phy or Switch.

This shall be achieved with the API specified in chapter 8.



[CP_SWS_Mka_00024]{DRAFT} [The MKA Module shall propagate the MACsec Entity specific parameters as needed by means of the EthIf API.

This requirement applies for the initialization, shutdown and, maintenance of MACsec related parameters. | (FO_RS_MACsec_00002, FO_RS_MACsec_00003)

[CP_SWS_Mka_00025]{DRAFT} The MKA Module shall collect the MACsec Entity (SecY) statistics when requested by means of the EthIf API. (FO_RS_MACsec_00009)

Note: Other modules may request port specific MACsec statistics in order to set DTCs, answer to Diagnostics, and for monitoring.

7.7 Configurable behavior of MKA

[CP_SWS_Mka_00026]{DRAFT} [The status and behavior of a specific MkaPaeIn-stance shall be configurable per initial configuration. | (FO_RS_MACsec_00005)

Note: In case the proposal from [5, IEEE-802.1X-2020] chapter 12.5 is used, the variable *useEAP* is currently not supported (that means, the value shall be per default set to *Never*).

[CP_SWS_Mka_00027]{DRAFT} [It shall be possible to set the configuration of a specific PAE dynamically through the MKA module API.

The change shall apply in the next power cycle.

If a configuration parameter (e.g. through Mka_SetPaePermissiveMode, Mka_-SetCknStatus, or Mka_SetEnable) is changed by means of the API, the original per configuration set value shall be ignored and the in NVRAM persisted value shall be used from the next power cycle onwards. $(FO_RS_MACsec_00005)$

[CP_SWS_Mka_00028]{DRAFT} [In case MkaOnFailPermissiveMode == TIME-OUT and MkaParticipantActivate == TRUE for a specific MkaKayParticipant, it shall determine that the MKA has failed when all these conditions are met:

- MKA sequence did not succeed → The participants could not reach the state in which the SAK is installed for Rx and Tx.
- MKA timeout (MkaOnFailPermissiveModeTimeout) is exceeded.

If all these conditions are met, the error MKA_E_TIMEOUT shall be triggered. \((FO_-RS_MACsec_00005) \)

Note: The MKA timeout value is set per configuration with the MkaOnFailPermissiveModeTimeout parameter.

[CP_SWS_Mka_00029]{DRAFT} [The MKA timer for MkaOnFailPermissiveMode-Timeout shall start counting after LinkUp (ETH_MODE_ACTIVE) of the referred physical or virtual port.] (FO_RS_MACsec_00005)

[CP_SWS_Mka_00030]{DRAFT} [The MkaOnFailPermissiveModeTimeout value shall be reset if any of the following conditions is met:



- After start up.
- On the transition from LinkDown (*ETH_MODE_DOWN*) to LinkUp (*ETH_MODE_ACTIVE*) of the referred physical or virtual port.

(FO RS MACsec 00005)

7.7.1 MKA behavior

[CP_SWS_Mka_00031]{DRAFT} [A MKA Entity (KaY) shall start the MKA sequence(s) through the referred EthIf (MkaEthIfControllerRef) immediately after receiving the port link-up signal with the Mka_LinkStateChange function.] (FO_RS_-MACsec 00002)

[CP_SWS_Mka_00032]{DRAFT} [A MKA Entity (KaY) shall signal the successful configuration of the MACsec protected port to the Ethlf with the Ethlf_MacSecOperational or Ethlf_SwitchMacSecOperational function.] (FO_RS_MACsec_-00002)

Note: A MKA Entity determines that the MACsec protected port is successfully configured as soon as MACsec protected frames can be transmitted and received from both participants.

7.7.2 MKA Error Handling

To ease complexity of the implementation, the MKA module may heal certain extended production errors automatically at start-up.

[CP_SWS_Mka_00033]{DRAFT} [If one or more CAKs referenced by MkaCryptoCk-nCakKeyRef is/are not initialized, MKA_E_KEY_NOT_PRESENT_INSTANCE shall be set to "Fail".]()

Note: Also see CSM Return Code CRYPTO E KEY NOT AVAILABLE.

[CP_SWS_Mka_00034]{DRAFT} [If the verification of the ICV of MKPDUs or the unwrapping of keys fails for one or more CKNs because of a wrong key, MKA E KEY MISMATCH INSTANCE shall be set to "Fail". | ()

[CP_SWS_Mka_00035]{DRAFT} [If the MKA peer only supports incompatible cipher suites, MKA_E_ALGO_MISMATCH_INSTANCE shall be set to "Fail".]()



Note: If an implementer chooses to not implement [CP_SWS_Mka_00036], the mentioned errors shall be healed on start-up of the MKA module.

7.8 Error Classification

Section "Error Handling" of the document [2] "General Specification of Basic Software Modules" describes the error handling of the Basic Software in detail. Above all, it constitutes a classification scheme consisting of five error types which may occur in BSW modules.

Based on this foundation, the following section specifies particular errors arranged in the respective subsections below.

7.8.1 Development Errors

[CP_SWS_Mka_91035]{DRAFT}

Type of error	Related error code	Error value
MKA Component initiated with null configuration	MKA_E_CFG_NULL_PTR	0x01
API called with invalid parameter value.	MKA_E_INVALID_PARAMETER	0x04
API called with a NULL pointer.	MKA_E_PARAM_POINTER	0x05
API called prior module is initialized.	MKA_E_UNINIT	0x06

(SRS BSW 00337, SRS BSW 00385, SRS BSW 00323)

7.8.2 Runtime Errors

There are no runtime errors.

7.8.3 Transient Faults

There are no transient faults.

7.8.4 Production Errors

There are no production errors.



7.8.5 Extended Production Errors

7.8.5.1 MKA_E_TIMEOUT_INSTANCE

[CP_SWS_Mka_00200] [

Error Name:	MKA_E_TIMI	EOUT_INSTANCE	
Short Description:	MKA timeout while negotiating with remote peer.		
Long Description:	MKA timeout	while negotiating with remote peer.	
	In case MkaO	nFailPermissiveMode == TIMEOUT and	
	MkaOnFailP	PermissiveModeTimeout is overflowed, the error	
	will be set.		
Detection Criteria:	Fail	If the PAE instance's	
		MkaOnFailPermissiveMode == TIMEOUT and	
		MkaOnFailPermissiveModeTimeout is	
		overflowed, the error will be set.	
	Pass	If the PAE instance's	
		MkaOnFailPermissiveMode == NEVER	
		or	
		If the PAE instance's	
		MkaOnFailPermissiveMode == TIMEOUT,	
		and the MkaKay could establish a transmission	
	and reception SC with a peer before		
		MkaOnFailPermissiveModeTimeout is reached,	
	the error is not set.		
Secondary	Not Applicable		
Parameters:			
Time Required:	The time to detect the error is linked to the		
	MkaOnFailPermissiveMode and		
	MkaOnFailPermissiveModeTimeout.		
Monitor Frequency:	Once after port's link-up per port.		
MIL illumination:	Not Applicable		

\(\((SRS_BSW_00385, SRS_BSW_00337\)\)



7.8.5.2 MKA_E_KEY_NOT_PRESENT_INSTANCE

[CP_SWS_Mka_00201] [

Error Name:	MKA_E_KEY_NOT_PRESENT_INSTANCE	
Short Description:	Necessary keys not present to initiate MKA negotiation.	
Long Description:	Pre-shared keys (i.e. CAK, ICK or KEK) to start the MKA sequence are not present in at least one of the active configured Kay Participants.	
Detection Criteria:	Fail The pre-shared keys of an active MkaKayParticipant are not present.	
	Pass All Kay participants have the needed pre-shared keys present.	
Secondary Parameters:	Not Applicable	
Time Required:	0.5	
Monitor Frequency:	once-per-trip	
MIL illumination:	Not Applicable.	

(SRS_BSW_00385, SRS_BSW_00337)

7.8.5.3 MKA E KEY MISMATCH INSTANCE

[CP_SWS_Mka_00202] [

Error Name:	MKA_E_KEY_MISMATCH_INSTANCE		
Short Description:	MKA negotiation failed due to key mismatch with remote peer (MKPDUs ICV mismatch).		
Long Description:	MKA negotiation failed due to key mismatch with remote peer (MKPDUs ICV mismatch). Triggered in case MKPDU cannot be validated for received MKPDUs which distribute a matching CKN.		
Detection Criteria:	Fail	A received MKPDU with matching CKN cannot be successfully validated.	
	Pass All received MKPDUs with matching CKN are successfully validated.		
Secondary Parameters:	Not Applicable		
Time Required:	Not Applicable.		
Monitor Frequency:	Continuous		
MIL illumination:	Not Applicable.		

(SRS_BSW_00385, SRS_BSW_00337)



7.8.5.4 MKA_E_ALGO_MISMATCH_INSTANCE

[CP_SWS_Mka_00203] [

Error Name:	MKA_E_ALG	MKA_E_ALGO_MISMATCH_INSTANCE		
Short Description:	MKA negotiation failed due to incompatible cipher suite with remote peer.			
Long Description:	MKA Negotiation failed due to incompatible cipher suite with remote peer. Triggered in case the participants in the MKA communication do not support any MACsec cipher suite in common and therefore cannot distribute neither install a valid SAK.			
Detection Criteria:	Fail The KaY participants of a communication (local and remote) do not support a common MACse cipher suite.			
	Pass The KaY participants of a communication (local and remote) support one or more common MACsec cipher suites.			
Secondary Parameters:	Not Applicable			
Time Required:	Not Applicable.			
Monitor Frequency:	Continuous			
MIL illumination:	Not Applicabl	Not Applicable.		

(SRS_BSW_00385, SRS_BSW_00337)



8 API specification

8.1 Imported types

In this chapter all types included from the following files are listed.

[CP_SWS_Mka_91005]{DRAFT}

Module	Header File	Imported Type
ComStack_Types	ComStack_Types.h	BufReq_ReturnType
Eth	Eth_GeneralTypes.h	Eth_BufldxType
	Eth_GeneralTypes.h	Eth_FrameType
EthSwt	Eth_GeneralTypes.h	EthSwt_MgmtInfoType
EthTrcv	Eth_GeneralTypes.h	EthTrcv_LinkStateType
ldsM	ldsM_Types.h	ldsM_SecurityEventIdType
NvM	Rte_NvM_Type.h	NvM_BlockIdType
Std	Std_Types.h	Std_ReturnType
	Std_Types.h	Std_VersionInfoType

]()

8.2 Type definitions

8.2.1 Mka_MacSecConfigType

[CP_SWS_Mka_91002]{DRAFT}

Name	Mka_MacSecConfigType (DRAFT)		
Kind	Structure		
Elements	ProtectFrames		
Liements	Туре	boolean	
	Comment	Indicates status if the MACsec protection of the frames is active or not	
	ReplayProtect		
	Туре	boolean	
	Comment Indicates status if replay protection is enable or disable		
	ReplayWindow		
	Туре	uint32	
	Comment	If ReplayProtect is enable, indicates the used replay protect window	
	ValidateFrames Type Mka_ValidateFramesType		
	Comment	Status of the validation of the frames. See Mka_ValidateFramesType for possible values	
	CurrentCipherSuite		
	Туре	uint64	





 \triangle

	Comment	Indicates which cipher suite is used in the SecY to update.		
	ConfidentialityOffset	•		
	Туре	Mka_ConfidentialityOffsetType		
	Comment	Set the Confidentiality Offset. See Mka_ConfidentialityOffsetType for possible values		
	ControlledPortEnabled			
	Туре	boolean		
	Comment	Status if the controlled port is enabled or disabled		
	BypassedVlanPtrs	BypassedVlanPtrs		
	Туре	const uint16*		
	Comment	Pointer to the list of bypassed VLANs		
	BypassedVlansLength			
	Туре	uint8		
	Comment	Length of the list of bypassed VLANs		
	BypassedEtherTypesPtr			
	Туре	const uint16*		
	Comment	Pointer to the list of the bypassed Ethernet Types		
	BypassedEtherTypesLength Type uint8			
	Comment	Length of the list of the bypassed Ethernet Types		
Description	Structure to configure a r	eferred SecY		
	Tags: atp.Status=DRAFT			
Available via	Mka.h			

]()

8.2.2 Mka_ValidateFramesType

[CP_SWS_Mka_91004]{DRAFT}

Name	Mka_ValidateFramesType (DRAFT)		
Kind	Enumeration		
Range	MKA_VALIDATE_ DISABLED	0	Disable validation, remove SecTAGs and ICVs (if present) from received frames.
	MKA_VALIDATE_ CHECKED	1	Enable validation, do not discard invalid frames
	MKA_VALIDATE_STRICT	2	Enable validation and discard invalid frames
Description	Controls validation of received frames		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		



8.2.3 Mka_ConfidentialityOffsetType

$\hbox{\tt [CP_SWS_Mka_91003]} \{ {\tt DRAFT} \} \; \lceil \;$

Name	Mka_ConfidentialityOffsetType (DRAFT)		
Kind	Enumeration		
Range	MKA_CONFIDENTIALITY_ NONE	0	Confidentiality protection disabled
	MKA_CONFIDENTIALITY_ OFFSET_0	1	Zero initial octets of each user data without confidentiality protection
	MKA_CONFIDENTIALITY_ OFFSET_30	2	30 initial octets of each user data without confidentiality protection
	MKA_CONFIDENTIALITY_ OFFSET_50	3	50 initial octets of each user data without confidentiality protection
Description	Indicates the offset in case of integrity with confidentiality		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

]()

8.2.4 Mka_Stats_Tx_SecYType

$\hbox{\tt [CP_SWS_Mka_91008]} \{ {\tt DRAFT} \} \; \lceil \;$

Name	Mka_Stats_Tx_SecYType (DRAFT)			
Kind	Structure			
Elements	OutPkts_Untagged			
	Туре	uint64		
	Comment	The number of packets transmitted without a SecTAG		
	OutPkts_TooLong			
	Туре	uint64		
	Comment The number of transmitted packets discarded because their length is greater than the accepted maximum length (mtu) of the Port			
	OutOctets_Protected			
	Type uint64 Comment The number of plain text octets integrity protected but not encrypted transmitted frames			
	OutOctets_Encrypted			
	Type uint64			
	Comment	The number of plain text octets integrity protected and encrypted in transmitted frames		
Description	MACsec Entity (SecY) transmission statistics			
	Tags: atp.Status=DRAFT			
Available via	Mka.h			



8.2.5 Mka_Stats_Rx_SecYType

$\hbox{\tt [CP_SWS_Mka_91010]} \{ {\tt DRAFT} \} \; \lceil \;$

Name	Mka_Stats_Rx_SecYType (DRAFT)		
Kind	Structure		
	InPkts_Untagged		
Elements	Туре	uint64	
	Comment	The number of packets without the MACsec tag (SecTAG) received if Mka_ValidateFrames was not 'MKA_VALIDATE_STRICT'	
	InPkts_NoTag		
	Туре	uint64	
	Comment	The number of received packets without a SecTAG discarded because Mka_ValidateFrames was 'MKA_VALIDATE_STRICT'	
	InPkts_BadTag		
	Туре	uint64	
	Comment	The number of received packets discarded with an invalid SecTAG, zero value PN, or invalid ICV	
	InPkts_NoSa		
	Туре	uint64	
	Comment	The number of received packets with an unknown SCI or for an unused SA by the security entity	
	InPkts_NoSaError		
	Туре	uint64	
	Comment	The number of packets discarded because the received SCI is unknown or the SA is not in use	
	InPkts_Overrun		
	Туре	uint64	
	Comment	The number of packets discarded because they exceeded cryptographic performance capabilities	
	InOctets_Validated		
	Туре	uint64	
	Comment	The number of plaintext octets recovered from packets that were integrity protected but not encrypted	
	InOctets_Decrypted		
	Туре	uint64	
	Comment	The number of plaintext octets recovered from packets that were integrity protected and encrypted	
Description	MACsec Entity (SecY) re	ception statistics	
	Tags: atp.Status=DRAF	Г	
Available via	Mka.h		



8.2.6 Mka_Stats_Tx_ScType

$\hbox{[CP_SWS_Mka_91009]} \{ \hbox{DRAFT} \} \; \lceil \;$

Name	Mka_Stats_Tx_ScType (DRAFT)			
Kind	Structure			
Elements	OutPkts_Protected			
	Туре	uint64		
	Comment The number of integrity protected but not encrypted packets for this transmit SC OutPkts_Encrypted			
	Туре	Type uint64		
	Comment The number of integrity protected and encrypted packets for this transmit SC			
Description	Secure Channel transmission statistics			
	Tags: atp.Status=DRAFT			
Available via	Mka.h			

]()

8.2.7 Mka_Stats_Rx_ScType

$\textbf{[CP_SWS_Mka_91011]} \{ \texttt{DRAFT} \} \; \lceil \;$

Name	Mka_Stats_Rx_ScType (DRAFT)		
Kind	Structure		
Elements	InPkts_Ok		
Liements	Туре	uint64	
	Comment	The number of packets received for this secure channel successfully validated and within the replay window	
	InPkts_Unchecked		
	Туре	uint64	
	Comment The number of packets received for this secure channel, if Mka_ValidateFrames was 'MKA_VALIDATE_DISABLED'		
	InPkts_Delayed		
	Туре	uint64	
	Comment	The number of received packets, for this secure channel, with packet number (PN) lower than the lowest acceptable packet number (Lowest Pn) and ReplayProtect was false	
	InPkts_Late		
	Type uint64		
	Comment	The number of packets discarded, for this secure channel, because the received packet number (PN) was lower than the lowest acceptable packet number (LowestPn) and ReplayProtect was true	
	InPkts_Invalid		
	Туре	uint64	





 \triangle

	Comment	The number of packets, for this secure channel, that failed validation but could be received because ValidateFrames was 'MKA_VALIDATE_CHECKED' and the data was not encrypted (so the original frame could be recovered)
	InPkts_NotValid	
	Туре	uint64
	Comment	The number of packets discarded, for this secure channel, because validation failed and ValidateFrames was 'MKA_VALIDATE_STRICT' or the data was encrypted (so the original frame could not be recovered)
Description	Secure Channel reception statistics	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

]()

8.2.8 Mka_SakKeyPtrType

$\hbox{\tt [CP_SWS_Mka_91013]} \{ {\tt DRAFT} \} \; \lceil \;$

Name	Mka_SakKeyPtrType (DRAFT)	
Kind	Structure	
Elements	HashKeyPtr	
	Туре	const uint8*
	Comment	Pointer to the Hash Key
	SakKeyPtr	
	Туре	const uint8*
	Comment	Pointer to the SAK
	SaltKeyPtr	
	Туре	const uint8*
	Comment	Pointer to the Salt
Description	SAK key reference	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

10



8.2.9 Mka_PermissiveModeType

$\hbox{\tt [CP_SWS_Mka_91012]} \{ {\tt DRAFT} \} \; \lceil \;$

Name	Mka_PermisiveModeType (DRAFT)		
Kind	Enumeration		
Range	NEVER	0	The controlled port will never be set to enabled if the participants cannot establish and successfully use a MACsec Secure Channel.
	TIMEOUT	1	The controlled port will be set to enabled and MACsec will not be used in the referred port if the timeout value (MkaOnFailPermissive Mode Timeout) is reached and none MKA instance under the PAE instance could success the following conditions: - A participant belonging to the same CA was recognized and authenticated A secure channel could be established Both participants can transmit and receive MACsec protected traffic through the SC.
Description	Permissive modes of MKA		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

10

8.2.10 Mka_Stats_SecYType

[CP_SWS_Mka_91028]{DRAFT}

Name	Mka_Stats_SecYType (DRAFT)		
Kind	Structure		
Elements	StatsTxPhy		
2.0	Туре	Mka_Stats_Tx_SecYType	
	Comment	Set of statistics in the Security Entity Phy by transmision	
	StatsRxPhy		
	Туре	Mka_Stats_Rx_SecYType	
	Comment	Set of statistics in the Security Entity Phy by reception	
	StatsTxSc		
	Туре	Mka_Stats_Tx_ScType	
	Comment	Set of statistics in the Security Entity's Secure Channel by reception	
	StatsRxSc		
	Туре	Mka_Stats_Rx_ScType	
	Comment	Set of statistics in the Security Entity's Secure Channel by reception	
Description	Security Entity statistics		
	Tags: atp.Status=DRAF1	Г	
Available via	Mka.h		

10



8.2.11 Mka_PaeStatusType

$\hbox{\tt [CP_SWS_Mka_91027]} \{ {\tt DRAFT} \} \; \lceil \;$

Name	Mka_PaeStatusType (DRAFT)		
Kind	Structure		
Elements	ConnectionStatus		
	Туре	Mka_MkaStatus	
	Comment	Status of the MKA	
	PeerSci		
	Туре	uint64	
	Comment	SCI includes the peer's MAC and port	
	CknInUse		
	Type Array of unsigned char[32]		
	Size	32	
	Comment	CKN used for the establishment of the MACsec Secure Channel	
Description	Structure with the specific information of a PAE		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

]()

8.2.12 Mka_MkaStatusType

$\hbox{\tt [CP_SWS_Mka_91025]} \{ {\tt DRAFT} \} \; \lceil \;$

Name	Mka_MkaStatus (DRAFT)		
Kind	Enumeration		
Range	MKA_STATUS_MACSEC_ RUNNING	0	MKA session key has been agreed and MACsec link is currently up
	MKA_STATUS_WAITING_ PEER_LINK	1	MKA is waiting for a link up of the underlying device to begin negotiation
	MKA_STATUS_WAITING_ PEER	2	MKA is waiting for a remote peer to transmit MKPDU's to begin negotiation
	MKA_STATUS_IN_ PROGRESS	3	MKA negotiation is ongoing
	MKA_STATUS_AUTH_ FAIL_UNKNOWN_PEER	4	MKA negotiation is not possible because ICV's of remote peer are invalid (ICK and therefore CAK keys are different)
	MKA_STATUS_ UNDEFINED	0xFF	Undefined state, reported when the given bus is disabled
Description	Status of the MKA instance.		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		



8.2.13 Mka_ConfigType

$\hbox{[CP_SWS_Mka_91026]} \{ \hbox{DRAFT} \} \; \lceil \;$

Name	Mka_ConfigType (DRAFT)	
Kind	Structure	
Description	Implementation specific structure of the post build configuration	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

]()

8.3 Function definitions

8.3.1 Mka_Init

[CP_SWS_Mka_91001]{DRAFT}

Service Name	Mka_Init (DRAFT)		
Syntax	<pre>Std_ReturnType Mka_Init (const Mka_ConfigType* ConfigPtr)</pre>		
Service ID [hex]	0x1		
Sync/Async	Synchronous		
Reentrancy	Non Reentrant		
Parameters (in)	ConfigPtr	Points to the implementation specific structure	
Parameters (inout)	None		
Parameters (out)	None		
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted	
Description	Initializes the MKA module		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

]()

8.3.2 Mka_GetVersionInfo

[CP_SWS_Mka_91014]{DRAFT}

Service Name	Mka_GetVersionInfo (DRAFT)
Syntax	Std_ReturnType Mka_GetVersionInfo (Std_VersionInfoType* VersionInfoPtr)
Service ID [hex]	0x2





Sync/Async	Synchronous		
Reentrancy	Reentrant	Reentrant	
Parameters (in)	None		
Parameters (inout)	None		
Parameters (out)	VersionInfoPtr	VersionInfoPtr Version information of this module	
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted	
Description	Returns the version information of this module		
	Tags: atp.Status=DRAFT		
Available via	Mka.h	Mka.h	

10

8.3.3 Mka_SetCknStatus

[CP_SWS_Mka_91015]{DRAFT}

Service Name	Mka_SetCknStatus (DRAFT)		
Syntax	Std_ReturnType Mka_SetCknStatus (uint8 MkaPaeIdx, boolean Enable, const uint8* Ckn, uint8 CknLength)		
Service ID [hex]	0x3		
Sync/Async	Synchronous		
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx		
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module	
	Enable	Boolean to control the Mka Participant Activate status.	
		True -> The MKA Participant exchanges MKPDUs.	
		False -> The MKA Participant does not exchange MKPDUs.	
	Ckn	Connectivity Association Key Name to identify the KaY participant	
	CknLength	Length of the CKN parameter provided	
Parameters (inout)	None	None	
Parameters (out)	None		
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted	
Description	Set status of a CKN from a PAE		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

10

[CP_SWS_Mka_01001]{DRAFT} [The function Mka_SetCknStatus shall set the activation status of the MkaKayParticipant which contains the provided Ckn under the provided MkaPaeldx.

The new activation status shall be persistently stored in NVM and used from next power cycle onwards (as required in [CP_SWS_Mka_00030]).



The per configuration provided activation status (MkaParticipantActivate) of the MkaKayParticipant shall not be used if a valid value is stored on the NVM.] ()

8.3.4 Mka_GetCknStatus

[CP_SWS_Mka_91016]{DRAFT}

Service Name	Mka_GetCknStatus (DRAF	T)	
Syntax	<pre>Std_ReturnType Mka_GetCknStatus (uint8 MkaPaeIdx, const uint8* Ckn, uint8 CknLength, boolean* EnablePtr)</pre>		
Service ID [hex]	0x4		
Sync/Async	Synchronous	Synchronous	
Reentrancy	Reentrant for different Mka	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx	MkaPaeldx Index of the PAE within the context of the MKA module	
	Ckn	Connectivity Association Key Name to identify the KaY participant	
	CknLength	Length of the CKN parameter provided	
Parameters (inout)	None	None	
Parameters (out)	EnablePtr	Pointer to the Mka Participant activation status	
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted	
Description	Get Status of a CKN from a PAE		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

10

8.3.5 Mka_SetEnable

$\hbox{\tt [CP_SWS_Mka_91020]} \{ \hbox{\tt DRAFT} \} \; \lceil \;$

Service Name	Mka_SetEnable (DRAFT)	
Syntax	Std_ReturnType Mka_SetEnable (uint8 MkaPaeIdx, boolean Enable)	
Service ID [hex]	0x8	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module
	Enable	Boolean to control the Mka activation of a PAE.
Parameters (inout)	None	
Parameters (out)	None	





Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted
Description	Set the MKA activation status of a PAE	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

10

[CP_SWS_Mka_01002]{DRAFT} [The function Mka_SetEnable shall set the activation status of the MkaKay of the provided MkaPaeldx.

The new activation status shall be persistently stored in NVM and used from next power cycle onwards (as required in [CP_SWS_Mka_00030]). | ()

8.3.6 Mka_GetEnable

[CP SWS Mka 91017]{DRAFT}

Service Name	Mka_GetEnable (DRAFT)	
Syntax	Std_ReturnType Mka_GetEnable (uint8 MkaPaeIdx, boolean* EnablePtr)	
Service ID [hex]	0x5	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module
Parameters (inout)	None	
Parameters (out)	EnablePtr	Pointer to the Mka activation status of a PAE.
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted
Description	Get the MKA activation status of a PAE	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

10

8.3.7 Mka_GetPaeStatus

[CP_SWS_Mka_91018]{DRAFT}

Service Name	Mka_GetPaeStatus (DRAFT)
Syntax	<pre>Std_ReturnType Mka_GetPaeStatus (uint8 MkaPaeIdx, Mka_PaeStatusType* PaeStatusPtr)</pre>





Service ID [hex]	0x6	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different MkaF	Paeldx, Non reentrant for the same MkaPaeldx
Parameters (in)	MkaPaeldx Index of the PAE within the context of the MKA module	
Parameters (inout)	None	
Parameters (out)	PaeStatusPtr	Pointer to the status structure, which includes detailed information of a PAE.
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted
Description	Get detailed information of a PAE	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

 $\rfloor ()$

8.3.8 Mka SetPaePermissiveMode

[CP_SWS_Mka_91021]{DRAFT}

Service Name	Mka_SetPaePermissiveMo	Mka_SetPaePermissiveMode (DRAFT)	
Syntax	uint8 MkaPaeIdx,	Std_ReturnType Mka_SetPaePermissiveMode (uint8 MkaPaeIdx, Mka_PermisiveModeType PermisiveMode)	
Service ID [hex]	0x9		
Sync/Async	Synchronous	Synchronous	
Reentrancy	Reentrant for different Mka	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module	
	PermisiveMode	Permissive mode to set in the PAE.	
Parameters (inout)	None		
Parameters (out)	None		
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted	
Description	Set Permissive Mode of a k	Set Permissive Mode of a KaY	
	Tags: atp.Status=DRAFT	Tags: atp.Status=DRAFT	
Available via	Mka.h	Mka.h	

 $\rfloor ()$

[CP_SWS_Mka_01003]{DRAFT} [The function Mka_SetPaePermissiveMode shall set the PermisiveMode of the MkaPaeInstance referred with the MkaPaeIdx.

The new PermisiveMode shall be persistently stored in NVM and used from next power cycle onwards (as required in [CP_SWS_Mka_00030]).

The per configuration provided MkaOnFailPermissiveMode of the MkaPaeInstance shall not be used if a valid value is stored on the NVM. | ()



8.3.9 Mka StartPae

[CP_SWS_Mka_91022]{DRAFT} [

Service Name	Mka_StartPae (DRAFT)	
Syntax	Std_ReturnType Mka_StartPae (uint8 MkaPaeIdx)	
Service ID [hex]	0x10	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx	Index of the PAE within the context of the MKA module
Parameters (inout)	None	
Parameters (out)	None	
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted
Description	Manual start of the PAE instace. (In case MkaPaeConfiguration.Autostart = False this method starts the PAE operation) Tags: atp.Status=DRAFT	
Available via	Mka.h	

10

[CP_SWS_Mka_01004]{DRAFT} [The function $Mka_StartPae$ shall start the operation of the MkaPaeInstance referred with the MkaPaeIdx if the MkaAutoStart configuration parameter is TRUE.

If the MkaAutoStart configuration parameter is FALSE, $Mka_StartPae$ will not have any effect on the referred MkaPaeInstance. ()

8.3.10 Mka_GetMacSecStatistics

[CP_SWS_Mka_91019]{DRAFT}

Service Name	Mka_GetMacSecStatistics (Mka_GetMacSecStatistics (DRAFT)	
Syntax	<pre>Std_ReturnType Mka_GetMacSecStatistics (uint8 MkaPaeIdx, const uint8* Ckn, uint8 CknLength)</pre>		
Service ID [hex]	0x7		
Sync/Async	Asynchronous		
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx		
Parameters (in)	MkaPaeldx Index of the PAE within the context of the MKA module		
	Ckn	Connectivity Association Key Name to identify the KaY participant	
	CknLength	Length of the CKN parameter provided	
Parameters (inout)	None		
Parameters (out)	None		
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted	





Description	Get Statistics of a PAE
	Tags: atp.Status=DRAFT
Available via	Mka.h

]()

8.3.11 Mka_LinkStateChange

[CP_SWS_Mka_91023]{DRAFT}

Service Name	Mka_LinkStateChange (DR	Mka_LinkStateChange (DRAFT)	
Syntax	uint8 MkaPaeIdx,	Std_ReturnType Mka_LinkStateChange (uint8 MkaPaeIdx, EthTrcv_LinkStateType TransceiverLinkState)	
Service ID [hex]	0x1d		
Sync/Async	Synchronous	Synchronous	
Reentrancy	Reentrant for different Mkal	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx Index of the PAE within the context of the MKA module		
	TransceiverLinkState	The Ethernet link state of a physical Ethernet connection.	
Parameters (inout)	None	None	
Parameters (out)	None	None	
Return value	Std_ReturnType	E_OK: The request has been accepted E_NOT_OK: The request has not been accepted	
Description	To inform MKA that a dedic	To inform MKA that a dedicated Trcv/Switch/PAC port link state has changed	
	Tags: atp.Status=DRAFT	Tags: atp.Status=DRAFT	
Available via	Mka.h		

]()

8.4 Callback notifications

This is a list of functions provided for other modules.

8.4.1 Mka_GetMacSecStatisticsNotification

[CP_SWS_Mka_91024]{DRAFT}

Service Name	Mka_GetMacSecStatisticsNotification (DRAFT)	
Syntax	<pre>void Mka_GetMacSecStatisticsNotification (uint8 MkaPaeIdx, const Mka_Stats_SecYType* MacSecStatsPtr)</pre>	





Service ID [hex]	0x1e	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different Mkal	Paeldx, Non reentrant for the same MkaPaeldx
Parameters (in)	MkaPaeldx Index of the PAE within the context of the MKA module	
	MacSecStatsPtr	Pointer to a structure including the MACsec statistics of an MKA participant
Parameters (inout)	None	
Parameters (out)	None	
Return value	None	
Description	Callback to notify that Mka_GetMacSecStatistics finished and provide the requested statistics.	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

]()

8.4.2 Mka_RxIndication

[CP_SWS_Mka_91029]{DRAFT}

Service Name	Mka_RxIndication (DRAFT)			
Syntax	void Mka_RxIndication (uint8 CtrlIdx, Eth_FrameType FrameType, boolean IsBroadcast, const uint8* PhysAddrPtr, const uint8* DataPtr, uint16 LenByte			
Service ID [hex]	0x1f			
Sync/Async	Synchronous			
Reentrancy	Reentrant			
Parameters (in)	Ctrlldx	Index of the physical Ethernet controller within the context of the Ethernet Interface		
	FrameType Frame type of received Ethernet frame			
	IsBroadcast parameter to indicate a broadcast frame			
	PhysAddrPtr Pointer to Physical source address (MAC address in network byte order) of received Ethernet frame			
	DataPtr Pointer to payload of received Ethernet frame.			
	LenByte Length (bytes) of the payload in received frame.			
Parameters (inout)	None			
Parameters (out)	None			
Return value	None			
Description	To inform Mka about the reception of MKA Frames			
	Tags: atp.Status=DRAFT			
Available via	Mka.h			

]()



8.4.3 Mka_TxConfirmation

$\hbox{\tt [CP_SWS_Mka_91030]} \{ {\tt DRAFT} \} \; \lceil \;$

Service Name	Mka_TxConfirmation (DRA	Mka_TxConfirmation (DRAFT)	
Syntax	uint8 CtrlIdx, Eth_BufIdxType Buf	<pre>void Mka_TxConfirmation (uint8 CtrlIdx, Eth_BufIdxType BufIdx, Std_ReturnType Result)</pre>	
Service ID [hex]	0x20		
Sync/Async	Synchronous	Synchronous	
Reentrancy	Reentrant	Reentrant	
Parameters (in)	Ctrlldx	Index of the physical Ethernet controller within the context of the Ethernet Interface	
	Bufldx	Index of the transmitted buffer	
	Result E_OK: The transmission was successful E_NOT_OK: The transmission failed.		
Parameters (inout)	None	None	
Parameters (out)	None	None	
Return value	None		
Description	To inform MKA about the correct transmition of MKA Frames.		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

]()

8.4.4 Mka_MacSecUpdateSecYNotification

$\hbox{[CP_SWS_Mka_91031]} \{ \hbox{DRAFT} \} \; \lceil \;$

Service Name	Mka_MacSecUpdateSecYNotification (DRAFT)		
Syntax	void Mka_MacSecUpdateSecYNotification (uint8 MkaPaeIdx)		
Service ID [hex]	0x21	0x21	
Sync/Async	Synchronous		
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx		
Parameters (in)	MkaPaeldx Index of the PAE within the context of the MKA module		
Parameters (inout)	None		
Parameters (out)	None		
Return value	None		
Description	Callback to notify that Ehtlf_MacSecUpdateSecY finished.		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

]()



8.4.5 Mka MacSecAddTxSaNotification

[CP_SWS_Mka_91032]{DRAFT}

Service Name	Mka_MacSecAddTxSaNotification (DRAFT)		
Syntax	<pre>void Mka_MacSecAddTxSaNotification (uint8 MkaPaeIdx)</pre>		
Service ID [hex]	0x22	0x22	
Sync/Async	Synchronous		
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx		
Parameters (in)	MkaPaeldx Index of the PAE within the context of the MKA module		
Parameters (inout)	None		
Parameters (out)	None		
Return value	None		
Description	Callback to notify that EthIf_MacSecAddTxSa finished.		
	Tags: atp.Status=DRAFT		
Available via	Mka.h		

10

8.4.6 Mka_MacSecAddRxSaNotification

[CP_SWS_Mka_91033]{DRAFT}

Service Name	Mka_MacSecAddRxSaNotification (DRAFT)	
Syntax	<pre>void Mka_MacSecAddRxSaNotification (uint8 MkaPaeIdx)</pre>	
Service ID [hex]	0x23	
Sync/Async	Synchronous	
Reentrancy	Reentrant for different MkaPaeldx, Non reentrant for the same MkaPaeldx	
Parameters (in)	MkaPaeldx Index of the PAE within the context of the MKA module	
Parameters (inout)	None	
Parameters (out)	None	
Return value	None	
Description	Callback to notify that Ethlf_MacSecAddRxSa finished.	
	Tags: atp.Status=DRAFT	
Available via	Mka.h	

]()

8.5 Scheduled functions

These functions are directly called by Basic Software Scheduler. The following functions shall have no return value and no parameter. All functions shall be non reentrant.



8.5.1 Mka MainFunction

[CP SWS Mka 91034]{DRAFT}

Service Name	Mka_MainFunction (DRAFT)
Syntax	void Mka_MainFunction (void)
Service ID [hex]	0x24
Description	Main function for cyclic call.
	Tags: atp.Status=DRAFT
Available via	Mka.h

]()

[CP_SWS_Mka_01005]{DRAFT} [The frequency of invocations of Mka_MainFunction is determined by the configuration parameter MkaMainFunctionPeriod. | ()

8.6 Expected interfaces

In this chapter all interfaces required from other modules are listed.

8.6.1 Mandatory interfaces

Note: This section defines all interfaces, which are required to fulfill the core functionality of the module.

[CP SWS Mka 91006]{DRAFT}

API Function	Header File	Description
EthIf_ProvideTxBuffer	Ethlf.h	Provides access to a transmit buffer of the specified Ethernet controller.
EthIf_Transmit	Ethlf.h	Triggers transmission of a previously filled transmit buffer
NvM_EraseNvBlock	NvM.h	Service to erase a NV block.
NvM_ReadBlock	NvM.h	Service to copy the data of the NV block to its corresponding RAM block.
NvM_WriteBlock	NvM.h	Service to copy the data of the RAM block to its corresponding NV block.

10

8.6.2 Optional interfaces

This section defines all interfaces, which are required to fulfill an optional functionality of the module.



[CP_SWS_Mka_91007]{DRAFT}

API Function	Header File	Description
Det_ReportError	Det.h	Service to report development errors.
Det_ReportRuntimeError	Det.h	Service to report runtime errors. If a callout has been configured then this callout shall be called.
EthIf_GetPhysAddr	Ethlf.h	Obtains the physical source address used by the indexed controller
Ethlf_SetSwitchMgmtInfo	Ethlf.h	Provides additional management information along to an Ethernet frame that requires special treatment within the Switch. It has to be called between EthIf_ProvideTxBuffer() and EthIf_Transmit() of the related frame.
IdsM_SetSecurityEvent	ldsM.h	This API is the application interface to report security events to the IdsM.

10

8.6.3 Configurable interfaces

There are no configurable interfaces defined.

8.7 Service Interfaces

There are no service interfaces defined.



9 Sequence diagrams

The sequence diagrams show the basic operations carried out during operation. The purpose of the sequence diagrams is to depict the expected behavior of the communication stack at a glance.

The communication initialization sequence diagrams illustrate how the MKA module gets involved in the Ethernet stack start-up including upper and lower layer modules.



9.1 Communication initialization with MACsec




Figure 9.1: Communication initialization with MACsec protected Ethlf



9.2 Communication initialization with MACsec and Switch




Figure 9.2: Communication initialization with MACsec protected Ethlf and Switch



10 Configuration specification

In general, this chapter defines configuration parameters and their clustering into containers. In order to support the specification Chapter 10.1 describes fundamentals. It also specifies a template (table) you shall use for the parameter specification. We intend to leave Chapter 10.1 in the specification to guarantee comprehension.

Chapter 10.2 specifies the structure (containers) and the parameters of the module MKA.

Chapter 10.3 specifies published information of the module MKA.

10.1 How to read this chapter

For details refer to the chapter 10.1 "Introduction to configuration specification" in SWS BSWGeneral.

10.2 Containers and configuration parameters

The following chapters summarize all configuration parameters. The detailed meanings of the parameters describe Chapter 7 and Chapter 8.

10.2.1 Mka

SWS Item	[ECUC_Mka_00001]
Module Name Mka	
Description	Configuration of the MACsec Key Agreement module.
Post-Build Variant Support	false
Supported Config Variants	VARIANT-PRE-COMPILE

Included Containers					
Container Name	Multiplicity	Scope / Dependency			
MkaCryptoAlgoConfig	1255	Cryptography configuration for MACsec.			
		Tags: atp.Status=draft			
MkaGeneral	1	This container holds the general parameters of the MKA protocol which apply to ports that are referencing this container.			
		Tags: atp.Status=draft			
MkaPaeConfiguration	1255	Common MKA configuration for a PAE.			
		Tags: atp.Status=draft			
MkaPaeInstance	1255	MKA configuration of a controlled port.			
		Tags: atp.Status=draft			






Figure 10.1: Mka

10.2.2 MkaGeneral

SWS Item	[ECUC_Mka_00002]
Container Name	MkaGeneral
Parent Container	Mka
Description	This container holds the general parameters of the MKA protocol which apply to ports that are referencing this container.
	Tags: atp.Status=draft
Configuration Parameters	

SWS Item	[ECUC_Mka_00034]			
Parameter Name	MkaDevErrorDetect	MkaDevErrorDetect		
Parent Container	MkaGeneral			
Description	Switches the development error detection and notification on or off true: detection and notification is enabled false: detection and notification is disabled.			
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	EcucBooleanParamDef			
Default value	false			
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00007]
Parameter Name	MkaHelloTime
Parent Container	MkaGeneral
Description	Interval [s] between MKPDUs when two participants have an active MKA communication (the participants are included in the Live Peer list of each other).
	Tags: atp.Status=draft
Multiplicity	1





Туре	EcucFloatParamDef		
Range	[0 INF]		
Default value	2		
Value Configuration Class	Pre-compile time X All Variants		
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00009]			
Parameter Name	MkaLifeTime			
Parent Container	MkaGeneral			
Description	Time span [s] since last MKPDU was received from the other participant, to consider it alive. \newline In case no valid MKPDU from the other participant is received after Mka LifeTime, the Secure Channel is shut down.			
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	EcucFloatParamDef	EcucFloatParamDef		
Range	[0 INF]			
Default value	6			
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time	_		
Scope / Dependency	scope: local	•		

SWS Item	[ECUC_Mka_00035]			
Parameter Name	MkaMainFunctionPeriod			
Parent Container	MkaGeneral			
Description	The cycle time of the periodic mai	n function	of MKA. Defined in seconds.	
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1			
Туре	EcucFloatParamDef			
Range	[0 INF]			
Default value	-			
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00010]		
Parameter Name	MkaSakRetireTime		
Parent Container	MkaGeneral		
Description	During an SAK rekey, time [s] to retire the previous SAK in use.		
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	EcucFloatParamDef		
Range	[0 INF]		
Default value	3		





Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	-	
	Post-build time	-	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00036]			
Parameter Name	MkaVersionInfoApi			
Parent Container	MkaGeneral			
Description	Enables / Disables version info API.			
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	EcucBooleanParamDef			
Default value	false	false		
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

No Included Containers




Figure 10.2: MkaGeneral



10.2.3 MkaPaeConfiguration

SWS Item	[ECUC_Mka_00033]
Container Name	MkaPaeConfiguration
Parent Container	Mka
Description	Common MKA configuration for a PAE.
	Tags: atp.Status=draft
Configuration Parameters	

SWS Item	[ECUC_Mka_00012]		
Parameter Name	MkaAutoStart		
Parent Container	MkaPaeConfiguration		
Description	Autostart or manual start of the PAE Instance. True := Autostart False := Manual Start If Autostart = False, the method Mka_StartPae is used to start the PAE instance.		
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	EcucBooleanParamDef		
Default value	true		
Value Configuration Class	Pre-compile time X All Variants		
	Link time –		
	Post-build time	_	
Scope / Dependency	scope: local		-

SWS Item	[ECUC_Mka_00037]		
Parameter Name	MkaPaeConfigurationIdx		
Parent Container	MkaPaeConfiguration		
Description	Instance ID of the MkaPaeConfigura	ation.	
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	EcucIntegerParamDef (Symbolic Name generated for this parameter)		
Range	0 255		
Default value	<u> </u>		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time –		
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00004]		
Parameter Name	MkaRetryBaseDelay		
Parent Container	MkaPaeConfiguration		
Description	The base delay in seconds for the retry phase of MKA. The retry have an exponential back off delay (1x base delay, 2x base delay, 4x base delay,) until the retry delay overflows the MkaRetryCyclicDelay value.		
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	EcucFloatParamDef		
Range	[0 INF]		







Default value	_		
Value Configuration Class	Pre-compile time X All Variants		
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local	-	

SWS Item	[ECUC_Mka_00005]			
Parameter Name	MkaRetryCyclicDelay			
Parent Container	MkaPaeConfiguration			
Description	Interval in seconds between retries	after base	e delay with exponential back off.	
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1			
Туре	EcucFloatParamDef			
Range	[0 INF]			
Default value	-	-		
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00024]			
Parameter Name	MkaSakRekeyTimeSpan	MkaSakRekeyTimeSpan		
Parent Container	MkaPaeConfiguration			
Description	Time [s] to trigger the rekey of an in use SAK. If set to 0, the rekey will not be triggered after a time span.			
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	EcucFloatParamDef			
Range	[0 INF]			
Default value	-			
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

No Included Containers






Figure 10.3: MkaPaeConfiguration

10.2.4 MkaCryptoAlgoConfig

SWS Item	[ECUC_Mka_00021]	
Container Name	MkaCryptoAlgoConfig	
Parent Container	Mka	
Description	Cryptography configuration for MACsec.	
	Tags: atp.Status=draft	
Configuration Parameters		

SWS Item	[ECUC_Mka_00053]			
Parameter Name	MkaCryptoAlgoConfigldx	MkaCryptoAlgoConfigldx		
Parent Container	MkaCryptoAlgoConfig			
Description	Instance ID of the configured Crypto	configur	ation.	
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	EcucIntegerParamDef (Symbolic Name generated for this parameter)			
Range	0 255			
Default value	-			
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		





	Post-build time	ı	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00025]			
Parameter Name	MkaMacSecCapability			
Parent Container	MkaCryptoAlgoConfig			
Description	MACsec capability to use for MACse	ec.		
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	EcucEnumerationParamDef			
Range	INTEGRITY_AND_ CONFIDENTIALITY	- Tags: atp.Status=draft		
	INTEGRITY_WITHOUT_ CONFIDENTIALITY			
Default value	INTEGRITY_WITHOUT_CONFIDE	NTIALITY	,	
Value Configuration Class	Pre-compile time	X All Variants		
	Link time	_		
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00026]				
Parameter Name	MkaMacSecConfidentialityOffset				
Parent Container	MkaCryptoAlgoConfig	MkaCryptoAlgoConfig			
Description	The confidentiality Offset is only appronn-XPN cipher suite is selected.	The confidentiality Offset is only applicable if "Integrity and confidentiality" with a non-XPN cipher suite is selected.			
	Tags: atp.Status=draft				
Multiplicity	01				
Туре	EcucEnumerationParamDef				
Range	CONFIDENTIALITY_OFFSET_0 -				
	Tags: atp.Status=draft				
	CONFIDENTIALITY_OFFSET_30	FIDENTIALITY_OFFSET_30 -			
	Tags: atp.Status=draft				
	CONFIDENTIALITY_OFFSET_50	_			
	Tags: atp.Status=draft				
Default value	CONFIDENTIALITY_OFFSET_0				
Value Configuration Class	Pre-compile time	X All Variants			
	Link time	_			
	Post-build time –				
Scope / Dependency	scope: local				

SWS Item	[ECUC_Mka_00027]
Parameter Name	MkaMacSecReplayProtection
Parent Container	MkaCryptoAlgoConfig







Description	MACsec replay protection parameter for MACsec.\newline The Replay Protection parameter is defined in the IEEE 802.1AE-2018 document, on chapter 10.4. It enables the replay protection if a packet is received with PacketNumber outside of the Window = PN - ProtectionWindow.			
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	EcucBooleanParamDef	EcucBooleanParamDef		
Default value	false	false		
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time	Link time –		
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00028]			
Parameter Name	MkaMacSecReplayProtectionWindo	MkaMacSecReplayProtectionWindow		
Parent Container	MkaCryptoAlgoConfig			
Description	In case replay protection is active, replay protection window. The Protection Window is a positive integer between 0 and 2^32-1 (No XPN) or 2^30-1 (XPN).			
	Tags: atp.Status=draft			
Multiplicity	01	01		
Туре	EcucIntegerParamDef			
Range	0 18446744073709551615			
Default value	-			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

Included Containers		
Container Name	Multiplicity	Scope / Dependency
MkaCipherSuites	14	Cipher Suite configuration to use with MACsec. MkaCipherSuite Prio is present in case the MKA instance acts as a Key Server to select the cipher suite to use for MACsec.






Figure 10.4: MkaCryptoAlgoConfig




10.2.5 MkaCipherSuites

SWS Item	[ECUC_Mka_00050]
Container Name	MkaCipherSuites
Parent Container	MkaCryptoAlgoConfig
Description	Cipher Suite configuration to use with MACsec. MkaCipherSuitePrio is present in case the MKA instance acts as a Key Server to select the cipher suite to use for MACsec.
Configuration Parameters	

SWS Item	[ECUC_Mka_00052]			
Parameter Name	MkaMacSecCipherSuite			
Parent Container	MkaCipherSuites			
Description	Cipher Suite to use for MACsec.			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	EcucEnumerationParamDef			
Range	GCM_AES_128	-		
		Tags: atp.Status=draft		
	GCM_AES_256	-		
		Tags: atp.Status=draft		
	GCM_AES_XPN_128	-		
		Tags: atp.Status=draft		
	GCM_AES_XPN_256	-		
		Tags: atp.Status=draft		
Default value	GCM_AES_128			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00051]	[ECUC_Mka_00051]		
Parameter Name	MkaMacSecCipherSuitePrio			
Parent Container	MkaCipherSuites			
Description	Suite to use with MACsec fror	In case the MKA instance acts as a Key Server, the priority is used to select the Cipher Suite to use with MACsec from the common supported Ciphers (with the client in the link). Value of 1 means the highest priority. Value of 4 means the lowest priority.		
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	EcucIntegerParamDef	EcucIntegerParamDef		
Range	1 4	14		
Default value	-			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	-		
	Post-build time	-		
Scope / Dependency	scope: local		·	

No Included Containers



10.2.6 MkaPaeInstance

SWS Item	[ECUC_Mka_00003]
Container Name	MkaPaeInstance
Parent Container	Mka
Description	MKA configuration of a controlled port.
	Tags: atp.Status=draft
Configuration Parameters	

SWS Item	[ECUC_Mka_00018]		
Parameter Name	MkaOnFailPermissiveMode		
Parent Container	MkaPaeInstance		
Description	Sets the behavior of the PAE in cas	e MKA d	oes not succeed when MKA is enabled.
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	EcucEnumerationParamDef		
Range	NEVER	The controlled port will never be set to enabled the participants cannot establish and successfully use a MACsec Secure Channel.	
		Tags: atp.Status=draft	
	TIMEOUT	The controlled port will be set to enabled and MACsec will not be used in the referred port if the timeout value (MkaOnFailPermissiveMode Timeout) is reached and none MKA instance under the PAE instance could success the following conditions: - A participant belonging to the same CA was recognized and authenticated - A secure channel could be established Both participants can transmit and receive MACsec protected traffic through the SC.	
Value Configuration Class	Pre-compile time	X	atp.Status=draft All Variants
value Configuration Class	Link time	_	/ w variants
	Post-build time	-	
Scope / Dependency			
Scope / Dependency	scope: local		-

SWS Item	[ECUC_Mka_00019]		
Parameter Name	MkaOnFailPermissiveModeTimeou	t	
Parent Container	MkaPaeInstance		
Description	Timeout in seconds to enable the controlled port in case MkaOnFailPermissiveMode is set to Timeout.		
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	EcucFloatParamDef		
Range	[0 INF]		
Default value	255		
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		



SWS Item	[ECUC_Mka_00011]			
Parameter Name	MkaPaeldx			
Parent Container	MkaPaeInstance			
Description	Instance ID of the configured PAE.			
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	EcucIntegerParamDef (Symbolic Na	EcucIntegerParamDef (Symbolic Name generated for this parameter)		
Range	0 255			
Default value	-			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00013]			
Parameter Name	MkaEthIfControllerRef	MkaEthIfControllerRef		
Parent Container	MkaPaeInstance	MkaPaeInstance		
Description	A reference to the EthlfController which is used for transmitting / receiving EAP frames (to configure the controlled port).			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	Symbolic name reference to EthIfController			
Value Configuration Class	Pre-compile time X All Variants			
	Link time	_		
	Post-build time	-		
Scope / Dependency	scope: local	•		

SWS Item	[ECUC_Mka_00054]			
Parameter Name	MkaPaeConfRef			
Parent Container	MkaPaeInstance			
Description	Reference to the applicable	PAE configurat	ion.	
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	Reference to MkaPaeConfig	Reference to MkaPaeConfiguration		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local	•		

SWS Item	[ECUC_Mka_00014]
Parameter Name	MkaSwitchPortRef
Parent Container	MkaPaeInstance
Description	A reference to the EthSwtPort enabled and set only in case PAE is attached to a switch port.
	Tags: atp.Status=draft
Multiplicity	01
Туре	Symbolic name reference to EthSwtPort





Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local	-	

Included Containers		
Container Name	Multiplicity	Scope / Dependency
MkaKay	1	MKA instance (KaY) for a controlled port (PaE).
		Tags: atp.Status=draft




Figure 10.5: MkaPaeInstance



10.2.7 MkaKay

SWS Item	[ECUC_Mka_00017]	
Container Name	MkaKay	
Parent Container	MkaPaeInstance	
Description	MKA instance (KaY) for a controlled port (PaE).	
	Tags: atp.Status=draft	
Configuration Parameters		

SWS Item	[ECUC_Mka_00016]			
Parameter Name	MkaBypassEtherType	MkaBypassEtherType		
Parent Container	MkaKay			
Description	Bypassed EtherType. The EtherTyp	es includ	ed will not be MACsec protected.	
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	0255			
Туре	EcucIntegerParamDef	EcucIntegerParamDef		
Range	0 65535			
Default value	-	-		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00015]	[ECUC_Mka_00015]		
Parameter Name	MkaBypassVlan	MkaBypassVlan		
Parent Container	MkaKay			
Description	Bypassed VLAN-ID. The VLAN-IDs included will not be MACsec protected. (VLAN-ID 0 is interpreted as no-VLAN -> Bypass untagged traffic)			
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	0255	0255		
Туре	EcucIntegerParamDef	EcucIntegerParamDef		
Range	0 4094	0 4094		
Default value	-	*		
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	-		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00032]	
Parameter Name	MkaDstMacAddress	
Parent Container	MkaKay	
Description	Destination MAC address to use by the MKA instance. The destination MAC addresses to use are defined in the IEEE 802.1X-2020 chapter 11.1.1 (Table 11-1).	
	Tags: atp.Status=draft	
Multiplicity	1	
Туре	EcucStringParamDef	
Default value	-	





Regular Expression	-		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00022]			
Parameter Name	MkaKeyServerPriority	MkaKeyServerPriority		
Parent Container	MkaKay			
Description	Key Server Priority of the MKA participants. In case it is not provided, the default value is 0 for an MKA_KEY_SERVER and 255 for an MKA_PEER.			
	Tags: atp.Status=draft			
Multiplicity	01			
Туре	EcucIntegerParamDef			
Range	0 255			
Default value	_			
Value Configuration Class	Pre-compile time	X	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00029]			
Parameter Name	MkaRole	MkaRole		
Parent Container	MkaKay			
Description	Role of the MKA instance.			
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	EcucEnumerationParamDef			
Range	MKA_KEY_SERVER –			
		Tags:	atp.Status=draft	
	MKA_PEER –			
	Tags: atp.Status=draft			
Value Configuration Class	Pre-compile time	Х	All Variants	
	Link time	_		
	Post-build time	_		
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00031]	
Parameter Name	MkaSrcMacAddress	
Parent Container	MkaKay	
Description	Source MAC address to use by the MKA instance.	
	Tags: atp.Status=draft	
Multiplicity	1	
Туре	EcucStringParamDef	
Default value	-	
Regular Expression	-	





Specification of MACsec Key Agreement AUTOSAR CP R22-11

Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	-	
	Post-build time	-	
Scope / Dependency	scope: local		

Included Containers			
Container Name	Multiplicity	Scope / Dependency	
MkaKayDemEventParameterRefs	1	Container for the references to DemEventParameter elements which shall be invoked using the API Dem_SetEventStatus in case the corresponding error occurs. The EventId is taken from the referenced DemEventParameter's DemEventId symbolic value. The standardized errors are provided in this container and can be extended by vendor-specific error references. Tags: atp.Status=draft	
MkaKayParticipant	1255	MKA participant configuration.	
		Tags: atp.Status=draft	






Figure 10.6: MkaKay

10.2.8 MkaKayParticipant

SWS Item	[ECUC_Mka_00038]
Container Name	MkaKayParticipant
Parent Container	MkaKay
Description	MKA participant configuration.
	Tags: atp.Status=draft
Configuration Parameters	



SWS Item	[ECUC_Mka_00049]			
Parameter Name	MkaParticipantActivate	MkaParticipantActivate		
Parent Container	MkaKayParticipant			
Description	Enabled/Disabled status of the MKA participant True = The MKA Participant exchanges MKPDUs - False = The MKA participant does not exchange MKPDUs.			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	EcucBooleanParamDef			
Default value	false			
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00048]			
Parameter Name	MkaCryptoAlgoRef			
Parent Container	MkaKayParticipant			
Description	Reference to the cryptography to us	Reference to the cryptography to use (MkaAlgoConfiguration Container).		
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	Reference to MkaCryptoAlgoConfig			
Value Configuration Class	Pre-compile time	Х	All Variants	
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00040]			
Parameter Name	MkaCryptoCknCakKeyRef	MkaCryptoCknCakKeyRef		
Parent Container	MkaKayParticipant	MkaKayParticipant		
Description	Reference to the CKN (min. 1 & max. 32 characters) assigned to the KaY Participant in the CSM.			
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	Symbolic name reference to CsmKey			
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00042]	
Parameter Name	MkaCryptolckDeriveJobRef	
Parent Container	MkaKayParticipant	
Description	Reference to a CSM job for ICK Derivation.	
	Tags: atp.Status=draft	
Multiplicity	1	
Туре	Symbolic name reference to CsmJob	





Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	-	
	Post-build time	-	
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00043]	[ECUC_Mka_00043]		
Parameter Name	MkaCryptolcvGenerateJobRef	MkaCryptolcvGenerateJobRef		
Parent Container	MkaKayParticipant			
Description	Reference to a CSM job for ICV ge 128 bits).	Reference to a CSM job for ICV generation (according to IEEE_802.x ICV is always 128 bits).		
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	Symbolic name reference to CsmJo	ob		
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time	Link time –		
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00044]			
Parameter Name	MkaCryptolcvVerifyJobRef	MkaCryptoIcvVerifyJobRef		
Parent Container	MkaKayParticipant			
Description	Reference to a CSM job for ICV ver 128 bits).	Reference to a CSM job for ICV verification (according to IEEE_802.x ICV is always 128 bits).		
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	Symbolic name reference to CsmJo	b		
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00045]			
Parameter Name	MkaCryptoKekDeriveJobRef	MkaCryptoKekDeriveJobRef		
Parent Container	MkaKayParticipant			
Description	Reference to a CSM job for KEK Derivation. (Note: CAK needs to be set as the KEK Derive job CsmJobKeyRef)			
	Tags: atp.Status=draft			
Multiplicity	1	1		
Туре	Symbolic name reference to CsmJ	ob		
Value Configuration Class	Pre-compile time X All Variants			
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			



SWS Item	[ECUC_Mka_00060]			
Parameter Name	MkaCryptoKeyUnwrapJobRef	MkaCryptoKeyUnwrapJobRef		
Parent Container	MkaKayParticipant			
Description	Reference to a CSM job for SAK ur	Reference to a CSM job for SAK unwrap (to perform the Decrypt part of RFC3394).		
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	Symbolic name reference to CsmJob			
Value Configuration Class	Pre-compile time	Х	All Variants	
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00047]			
Parameter Name	MkaCryptoKeyWrapJobRef	MkaCryptoKeyWrapJobRef		
Parent Container	MkaKayParticipant			
Description	Reference to a CSM job for SAK	wrap (to p	erform the Encrypt part of RFC3394).	
	Tags: atp.Status=draft	Tags: atp.Status=draft		
Multiplicity	1	1		
Туре	Symbolic name reference to Csm	Symbolic name reference to CsmJob		
Value Configuration Class	Pre-compile time	Pre-compile time X All Variants		
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00041]			
Parameter Name	MkaCryptoRandomJobRef	MkaCryptoRandomJobRef		
Parent Container	MkaKayParticipant			
Description	Reference to a CSM job for random	numbe	r generation.	
	Tags: atp.Status=draft			
Multiplicity	1			
Туре	Symbolic name reference to CsmJc	b		
Value Configuration Class	Pre-compile time	Х	All Variants	
	Link time –			
	Post-build time –			
Scope / Dependency	scope: local			

SWS Item	[ECUC_Mka_00046]		
Parameter Name	MkaCryptoSakKeyRef		
Parent Container	MkaKayParticipant		
Description	Reference to a CSM key where SAK shall be stored.		
	Tags: atp.Status=draft		
Multiplicity	1		
Туре	Symbolic name reference to CsmKey		
Value Configuration Class	Pre-compile time	Х	All Variants
	Link time	_	
	Post-build time	_	





Specification of MACsec Key Agreement AUTOSAR CP R22-11

 \triangle

Scope / Dependency	scope: local
--------------------	--------------

No Included Containers






Figure 10.7: MkaKayParticipant



10.2.9 MkaKayDemEventParameterRefs

SWS Item	[ECUC_Mka_00055]
Container Name	MkaKayDemEventParameterRefs
Parent Container	MkaKay
Description	Container for the references to DemEventParameter elements which shall be invoked using the API Dem_SetEventStatus in case the corresponding error occurs. The Event Id is taken from the referenced DemEventParameter's DemEventId symbolic value. The standardized errors are provided in this container and can be extended by vendor-specific error references.
	Tags: atp.Status=draft
Configuration Parameters	

SWS Item	[ECUC_Mka_00059]		
Parameter Name	MKA_E_ALGO_MISMATCH_INSTANCE		
Parent Container	MkaKayDemEventParameterRefs		
Description	Reference to the DemEventParameter which shall be issued when the MkaKay Instance does not successfully agree on MACsec keys and at least one MkaKay Participant does not support a common MACsec cipher suite. Tags: atp.Status=draft		
Multiplicity	01		
Туре	Symbolic name reference to DemEventParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time X All Variants		
	Link time	_	
	Post-build time	_	
Value Configuration Class	onfiguration Class Pre-compile time X All Variants		All Variants
	Link time	_	
	Post-build time –		
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00058]		
Parameter Name	MKA_E_KEY_MISMATCH_INSTANCE		
Parent Container	MkaKayDemEventParameterRefs		
Description	Reference to the DemEventParameter which shall be issued when the MkaKay Instance does not successfully agree on MACsec keys and at least one exchange for this MkaKay Instance encounters an ICV validation failure.		
	Tags: atp.Status=draft		
Multiplicity	01		
Туре	Symbolic name reference to DemEventParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time	_	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time –		
	Post-build time –		





Scope / Dependency	scope: local

SWS Item	[ECUC_Mka_00057]		
Parameter Name	MKA_E_KEY_NOT_PRESENT_INSTANCE		
Parent Container	MkaKayDemEventParameterRefs		
Description	Reference to the DemEventParameter which shall be issued when the MkaKay Instance does not successfully agree on MACsec keys and at least one of the keys (CAK) for this MkaKay Instance is not present.		
	Tags: atp.Status=draft		
Multiplicity	01		
Туре	Symbolic name reference to DemEventParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time X All Variants		
	Link time	_	
	Post-build time	_	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time –		
Scope / Dependency	scope: local		

SWS Item	[ECUC_Mka_00056]		
Parameter Name	MKA_E_TIMEOUT_INSTANCE		
Parent Container	MkaKayDemEventParameterRefs		
Description	Reference to the DemEventParameter which shall be issued when the MkaKay Instance does not successfully agree on MACsec keys and at least one exchange for this MkaKay Instance encounters a timeout.		
	Tags: atp.Status=draft		
Multiplicity	01		
Туре	Symbolic name reference to DemEventParameter		
Post-Build Variant Multiplicity	false		
Post-Build Variant Value	false		
Multiplicity Configuration Class	Pre-compile time X All Variants		
	Link time	_	
	Post-build time	_	
Value Configuration Class	Pre-compile time	X	All Variants
	Link time	_	
	Post-build time –		
Scope / Dependency	scope: local		

No Included Containers

10.3 Published Information

For details refer to the chapter 10.3 "Published Information" in SWS_BSWGeneral.



A Not applicable requirements

[CP_SWS_Mka_00999] [These requirements are not applicable to this specification.] (FO_RS_MACsec_00001, FO_RS_MACsec_00006, FO_RS_MACsec_00011, FO_RS_MACsec_00012, FO_RS_MACsec_00018, FO_RS_MACsec_00019, FO_RS_MACsec_00021, FO_RS_MACsec_00022, FO_RS_MACsec_00034, FO_RS_MACsec_00036)