# Summary - FMCOMMS2/3 TX Worker

Package Prefix	ocpi.core
Component	tx
Name	fmcomms_2_3_tx
Authoring Model	rcc
Version	1
OpenCPI Release	v1.5 (released 4/2019)
Tested Platforms	Zedboard (xilinx13_3), ML605 (x86_64 CentOS 7)
Slaves	-
ACI "Slaves"	
	• ad9361_config_proxy.rcc
	• ad9361_data_sub.hdl

## **Functionality**

This worker is an endpoint proxy used to control a single TX channel of an instance of the FMCOMMS2 or the FMCOMMS3 RF transceiver card. Multiple TX channels on the same FMCOMMS2/3 card are not yet supported. This worker has two parameterized build configurations: one for FMCOMMS2 (TYPE\_p parameter property value of 'fmcomms2') and one for FMCOMMS3 (TYPE\_p parameter property value of 'fmcomms3'). Each property has a max, min, and step value associated with it. These associated properties are available to be used by application developers for reading back information about the functionality of the interface during runtime if necessary.

This worker implements a common interface that is intended to be used across multiple platforms. All platforms will have the same property interface to allow applications to be ported seamlessly to other platforms. It is also intended to be a simple interface that encompasses functionality that all TX interfaces will have but not any specialty functionality that only some TX interfaces will have.

# Worker Implementation Details

This worker controls the filtering, gain, tuning frequency, and the sample rate of the AD9361 on the FMCOMMS2/3 RF transciever card. Each of these are described below in their own section.

#### Clock Generation

The AD9361 contains multiple PLLs which all use the same external-to-the-AD9361 clock source. This external source can be either:

- a crystal connected to the AD9361 XTALP/N pins (a 40 MHz [nominal] crystal is connected on FMCOMMS2/3), or
- an external clock source connected to the AD9361 XTALN pin (the REF\_CLK SMA connector is connected on FMCOMMS2/3).

This worker's config property's reference\_clk\_rate\_Hz struct member should contain the value of the clock frequency in Hz (whether crystal or external). If the default FMCOMMS2/3 hardware is to be used (i.e. crystal used), the config property's are\_using\_REF\_CLK\_SMA value should be left to its default value (of false). If the FMCOMMS2/3 has an external clock connected, the config property's are\_using\_REF\_CLK\_SMA value must be set to true. Only the default settings (i.e. crystal used) have been verified.

#### **Filtering**

In the RF section of the AD9361 transceiver, there are no filtering elements.

The AD9361's baseband Tx signal path is composed of two programmable analog low-pass filters, a 12-bit DAC, and four stages of digital interpolation filters [1]. The baseband filters are as follows:

- PROG TX FIR (disabled by this worker)
  - digital filter whose interpolation factor is configurable to 1, 2, or 4, and whose taps are customizable with 16-bit values up to 128 taps
- Tx HB1 filter (Half-Band)
  - digital half-band interpolation filter with fixed-coefficient tap set with interpolation factor of 2 (or can bypass filter, effectively interpolating by 1)
- Tx HB2 filter (Half-Band)
  - digital half-band interpolation filter with fixed-coefficient tap set with interpolation factor of 2 (or can bypass filter, effectively interpolating by 1)
- Tx HB3/INT3 filter (Half-Band / Interpolation)
  - digital half-band interpolation filter with selectable fixed-coefficient tap sets with interpolation factors of 1 (bypasses filter), 2, or 3
- Tx BB LPF (BaseBand Low-Pass Filter)
  - analog third-order Butterworth low-pass filter with a programmable 3dB corner frequency
- Tx Secondary LPF (Low-Pass Filter)
  - analog single-pole low-pass filter with a programmable 3dB corner frequency

Changes to the AD9361 TX sample rate (via the sample\_rate\_MHz property) or the RX sample rate can affect the TX HB digital filter settings. Note that the setting of both the analog and the digital filters will determine the overall effective baseband bandwidth. Values written to the bb\_cutoff\_frequency\_MHz property are rounded to the nearest Hz and passed to the No-OS ad9361\_set\_tx\_rf\_bandwidth() API call, which attempts to set the overall baseband -3dB bandwidth to approximately the requested (rounded to nearest Hz) value. Read requests to the bb\_cutoff\_frequency\_MHz property will simply return the value of the No-OS ad9361\_get\_tx\_rf\_bandwidth() API call, which is known to not have floating-point precision as well as to represent a crude approximation of the current nominal value. Work is expected to be done in the future to modify read requests to return the double floating point-precision nominal value instead of using the No-OS API.

#### Gain

The AD9361 supports a manual (non-automatic) TX attenuation setting. The vendor does not document whether the TX attenuation setting is pre-mixer (baseband), post-mixer (RF), or both, so it was arbitrarily chosen to map the rf\_gain\_dB property (as opposed to the bb\_gain\_dB property) to the AD9361 TX attenuation setting. This worker's rf\_gain\_dB property sets the AD9361 TX attenuation (as the negative of the gain) and reads back the nominal value with exact precision.

#### **Tuning**

The AD9361 has a mixer for upconverting from baseband to RF. The mixer LO is source by a PLL which is sourced by the external-to-the-AD9361 reference clock, which is a 40 MHz crystal on the FMCOMMS2/3 PCB. This worker's frequency\_MHz property sets the AD9361 TX center frequency and reads back the nominal value with double floating point precision.

## Sample Rate

The AD9361 TX sampling clock is generated by an on-AD9361 PLL which is sourced by the external-to-the-AD9361 reference clock, which is a 40 MHz crystal on the FMCOMMS2/3 PCB. This worker's sample\_rate\_MHz property sets the AD9361 TX sample rate and reads back the nominal value with double floating point precision. Note that the sample\_rate\_MHz property as it currently exists corresponds to the post-TX FIR complex sample rate, and the FIR is always disabled by this worker.

## Source Dependencies

- $\bullet \ assets/hdl/cards/fmcomms\_2\_3\_tx.rcc/fmcomms\_2\_3\_tx.cc\\$
- assets/hdl/cards/fmcomms\_2\_3\_rx.rcc/include/ad9361/ad9361\_common.h
- $\bullet \ assets/hdl/cards/fmcomms\_2\_3\_rx.rcc/include/ad9361/readers\_ad9361\_bb\_pll.h$
- $\bullet \ assets/hdl/cards/fmcomms\_2\_3\_rx.rcc/include/ad9361/readers\_ad9361\_bb\_rx\_adc.h$
- assets/hdl/cards/fmcomms\_2\_3\_rx.rcc/include/ad9361/readers\_ad9361\_bb\_rx\_filters\_digital.h
- assets/hdl/cards/fmcomms\_2\_3\_tx.rcc/include/ad9361/readers\_ad9361\_bb\_tx\_dac.h
- assets/hdl/cards/fmcomms\_2\_3\_tx.rcc/include/ad9361/readers\_ad9361\_bb\_tx\_filters\_analog.h
- $\bullet \ assets/hdl/cards/fmcomms\_2\_3\_tx.rcc/include/ad9361/readers\_ad9361\_bb\_tx\_filters\_digital.h$
- $\bullet \ assets/hdl/cards/fmcomms\_2\_3\_rx.rcc/include/ad9361/readers\_ad9361\_cfg.h$
- assets/hdl/cards/fmcomms\_2\_3\_tx.rcc/include/ad9361/readers\_ad9361\_rf\_tx\_pll.h
- $\bullet \ assets/hdl/cards/fmcomms\_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_dac.hdl/cards/fmcomms_2\_3\_tx.rcc/include/ad9361/writers\_ad9361/writer$
- assets/hdl/cards/fmcomms\_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_bb\_tx\_filters\_analog.h
- $\bullet \ assets/hdl/cards/fmcomms\_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_rf\_tx\_pll.h$
- assets/hdl/cards/fmcomms\_2\_3\_tx.rcc/include/ad9361/writers\_ad9361\_tx\_gain.h
- $\bullet \ assets/hdl/cards/fmcomms\_2\_3\_tx.rcc/include/ocpi\_component\_prop\_type\_helpers.h$
- assets/hdl/cards/fmcomms\_2\_3\_tx.rcc/include/worker\_prop\_parsers\_ad9361\_config\_proxy.h

# Component Spec Properties

Name	Type	Sequence	Array	Accessibility	Valid Range	Default	Usage
		Length	Dimensions				
rf_gain_dB	double	-	-	Readable, Writable	-	0	The value of the RF gain stage of the receiver
rf_gain_max_dB	double	-	-	Volatile, Writable	-	0	Maximum valid value for RF gain
rf_gain_min_dB	double	-	-	Volatile, Writable	-	0	Minimum valid value for RF gain
rf_gain_step_dB	double	-	-	Volatile, Writable	-	0	Minimum granularity for changes in RF gain
bb_gain_dB	double	-	-	Readable, Writable	-	0	The value of the baseband gain stage of the receiver
bb_gain_max_dB	double	-	-	Volatile, Writable	-	0	Maximum valid value for baseband gain
bb_gain_min_dB	double	-	-	Volatile, Writable	-	0	Minimum valid value for baseband gain
bb_gain_step_dB	double	-	-	Volatile, Writable	-	0	Minimum granularity for changes in baseband gain
frequency_MHz	double	-	-	Readable, Writable	-	0	The value for the tuned center frequency of the incoming RF sam-
							ples
frequency_max_MHz	double	-	-	Volatile, Writable	-	0	Maximum valid value for frequency
frequency_min_MHz	double	-	-	Volatile, Writable	-	0	Minimum valid value for frequency
frequency_step_MHz	double	-	-	Volatile, Writable	-	0	Minimum granularity for changes in frequency
sample_rate_MHz	double	-	-	Readable, Writable	-	0	Sample rate of the incoming RF samples
sample_rate_max_MHz	double	-	-	Volatile, Writable	-	0	Maximum valid value for sample rate
sample_rate_min_MHz	double	-	-	Volatile, Writable	-	0	Minimum valid value for sample rate
sample_rate_step_MHz	double	-	-	Volatile, Writable	-	0	Minimum granularity for changes in sample rate
rf_cutoff_frequency_MHz	double	-	-	Readable, Writable	-	0	The effective cutoff frequency, i.e. half of the bandwidth, for all
							filtering that is done in the RF stage of the receiver.
rf_cutoff_frequency_max_MHz	double	-	-	Volatile, Writable	-	0	Maximum valid value for RF cutoff frequency
rf_cutoff_frequency_min_MHz	double	-	-	Volatile, Writable	-	0	Minimum valid value for RF cutoff frequency
rf_cutoff_frequency_step_MHz	double	-	-	Volatile, Writable	-	0	Minimum granularity for changes in RF cutoff frequency
bb_cutoff_frequency_MHz	double	-	-	Readable, Writable	-	0	The effective cutoff frequency, i.e. half of the bandwidth, for all
							filtering that is done in the baseband stage of the receiver.
bb_cutoff_frequency_max_MHz	double	-	-	Volatile, Writable	-	0	Maximum valid value for baseband cutoff frequency
bb_cutoff_frequency_min_MHz	double	-	-	Volatile, Writable	-	0	Minimum valid value for baseband cutoff frequency
bb_cutoff_frequency_step_MHz	double	-	-	Volatile, Writable	-	0	Minimum granularity for changes in baseband cutoff frequency

# Worker Properties

## tx.rcc

уре	Name	Type	Sequence Length	Array Dimensions	Accessibility/ Advanced	Valid Range	Default	Usage
roperty	fmcomms_num	UShort	-	-	Parameter	2, 3	3	Valid values are 2 or 3.
Property	TYPE_p	Enum	-	-	Parameter	fmcomms2, fmcomms3	fmcomms_num == 2 ? fm- comms2 : fmcomms3	The purpose of this property is to provide the option for an application XML to specify this property in order to enforce use of a parameterized build for a particular frontend type.
Property	NOT_SUPPORTED_p	Double	-	-	Parameter	-1	-1	This value, when assigned to a frontend property, e.g. rf_gain_dB, indicates that the frontend setting corresponding to said property is not supported by the frontend hardware controlled by this worker.
Property	AD9361_TX_BBBW_NO_OS_MAX_MHZ_p	Double	-	-	Parameter	Standard	20	AD9361_Reference_Ma 570.pdf "BBBW is half the complex bandwidth and coerced between 20 MHz to 0.625 MHz" - for No-OS's enforcement of this fact, see No-OS ad9361_tx_bb_analog_fi
Property	AD9361_TX_BBBW_NO_OS_MIN_MHZ_p	Double	-	-	Parameter	Standard	0.625	AD9361_Reference_Ma 570.pdf "BBBW is half the complex bandwidth and coerced between 20 MHz to 0.625 MHz" - for No-OS's enforcement of this fact, see No-OS ad9361_tx_bb_analog_fi
Property	AD9361_TX_ATTENUATION_MAX_MILLID		-	-	Parameter	89.75	89.75	-
roperty	AD9361_TX_ATTENUATION_MIN_MILLID		-	-	Parameter	0	0	-
roperty	RF_GAIN_MAX_DB_p	Double	-	-	Parameter	- AD9361_TX_ATTENUATION_MIN_MILL	- IDAD_9361_TX_ATTENUATION_MIN_MILL	- IDB_P
Property	RF_GAIN_MIN_DB_p	Double	-	-	Parameter		- IDAD_9361_TX_ATTENUATION_MAX_MILL	- IDB_P
Property	RF_GAIN_STEP_DB_p	Double	-	-	Parameter	0.25	0.25	-
Property	BB_GAIN_MAX_DB_p	Double	-	-	Parameter	NOT_SUPPORTED_p	NOT_SUPPORTED_p	-
Property	BB_GAIN_MIN_DB_p	Double	-	-	Parameter	NOT_SUPPORTED_p	NOT_SUPPORTED_p	-
Property	BB_GAIN_STEP_DB_p	Double	-	-	Parameter	NOT_SUPPORTED_p	NOT_SUPPORTED_p	-

Property	FREQUENCY_MAX_MHZ_P	Double	-	-	Parameter	-1	fmcomms_num == 2 ? 2500 :	-
D	EDEGUENAY MIN MUZ	Devilate		_	Demonstra	1	6000 fmcomms_num == 2 ? 2400 : 70	
roperty roperty	FREQUENCY_MIN_MHZ_p SAMPLE_RATE_MAX_MHZ_p	Double Double	-	-	Parameter Parameter	-1 -1	61.44	-
Property	SAMPLE_RATE_MIN_MHZ_p	Double	-	-	Parameter	-1	2.08334	Note that the AD9361 precision is double(25/12), and the No-OS implementation's precision is 2.083334,
								but we set it to 2.08334 to avoid confusion since an OpenCPI bug does not correctly implement the precision for 2.083334 (OpenCPI rounds it to 2.08334)
Property	RF_CUTOFF_FREQUENCY_MAX_DB_p	Double	-	-	Parameter	NOT_SUPPORTED_p	NOT_SUPPORTED_p	-
Property	RF_CUTOFF_FREQUENCY_MIN_DB_p	Double	-	-	Parameter	NOT_SUPPORTED_p	NOT_SUPPORTED_p	-
Property	RF_CUTOFF_FREQUENCY_STEP_DB_p BB_CUTOFF_FREQUENCY_MAX_DB_p	Double Double	-	-	Parameter Parameter	NOT_SUPPORTED_p  AD9361_TX_BBBW_NO_OS_MAX_MHZ	NOT_SUPPORTED_p AD9361_TX_BBBW_NO_OS_MAX_MHZ	The maximum
Property	BB_CUTOFF_FREQUENCY_MIN_DB_D	Double		-	Parameter	* 1.6  AD9361_TX_BBBW_NO_OS_MIN_MHZ	* 1.6  AD9361_TX_BBBW_NO_OS_MIN_MHZ	off frequency in MHz of the FM-COMMS2/3's AD9361's third-order Butterworth Tx anti-imaging filter. The Tx filter is normally calibrated to 1.6x the BBBW. For more information, see AD9361_Reference_Ma570_pdf p. 9.
						* 1.6	* 1.6	configurable cut- off frequency in MHz of the FM- COMMS2/3's AD9361's third- order Butterworth Tx anti-imaging filter. The Tx filter is normally cali- brated to 1.6x the BBBW. For more information, see AD9361_Reference_Ma 570 .pdf p. 9.

SpecProperty	rf_gain_dB	Double			Volatile,	see rf_gain_min_dB,	-1	The value of the
Spectroperty	ri_gain_db	Double	-	-	ReadSync,	rf_gain_max_dB	-1	RF gain stage
					WriteSync	II_gaIII_max_db		of the receiver.
					Willesync			Note this is not
								NOT_SUPPORTED_p,
								-1 is a perfectly
								valid value. When
								a write to the prop-
								erty occurs, this
								property's written
								value is applied to
								hardware. When a
								read of this prop-
								erty occurs, the read
								value is the (nom-
								inal) in-situ value
								(actual value which
								is currently assigned
								in hardware, which
								may be slightly
								different than a
								previously written
								property value due
								to rounding that oc-
								curs before writing
								hardware register
								values and/or No-
								OS API rounding)
								with double floating
								point precision.
SpecProperty	bb_gain_dB	Double	-	-	WriteSync	see bb_gain_min_dB,	NOT_SUPPORTED_P	The value of the
						bb_gain_max_dB		baseband gain stage
								of the receiver.
								When a write to
								the property occurs,
								this property's writ-
								ten value is applied
								to hardware. When
								a read of this prop-
								erty occurs, the read
								value is the (nom-
								inal) in-situ value
								(actual value which
								is currently assigned
								in hardware, which
								in hardware, which may be slightly
								in hardware, which may be slightly different than a
								in hardware, which may be slightly different than a previously written
								in hardware, which may be slightly different than a previously written property value due
								in hardware, which may be slightly different than a previously written
								in hardware, which may be slightly different than a previously written property value due
								in hardware, which may be slightly different than a previously written property value due to rounding that oc-
								in hardware, which may be slightly different than a previously written property value due to rounding that oc- curs before writing
								in hardware, which may be slightly different than a previously written property value due to rounding that occurs before writing hardware register
								in hardware, which may be slightly different than a previously written property value due to rounding that occurs before writing hardware register values and/or No-
								in hardware, which may be slightly different than a previously written property value due to rounding that occurs before writing hardware register values and/or No-OS API rounding)

SpecProperty	frequency_MHz	Double	-	-	Volatile,	see frequency_min_MHz,	2400	The value for
					ReadSync,	frequency_max_MHz		the tuned center
					WriteSync			frequency of the in-
								coming RF samples.
								When a write to
								the property occurs,
								this property's writ-
								ten value is applied
								to hardware. When
								a read of this prop-
								erty occurs, the read
								value is the (nom-
								inal) in-situ value
								(actual value which
								is currently assigned
								in hardware, which
								may be slightly
								different than a
								umerent than a
								previously written
								property value due
								to rounding that oc-
								curs before writing
								hardware register
								values and/or No-
								OS API rounding)
								with double floating
								point precision.
SpecProperty	sample rate MHz	Double	_	_	Volatile	see sample rate min MHz	30.72	
SpecProperty	sample_rate_MHz	Double	-	-	Volatile,	see sample_rate_min_MHz,	30.72	Sample rate of
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,	see sample_rate_min_MHz, sample_rate_max_MHz	30.72	Sample rate of the incoming RF
SpecProperty	sample_rate_MHz	Double	-	-			30.72	Sample rate of the incoming RF samples. When a
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the prop-
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the prop- erty occurs, this
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the prop- erty occurs, this property's written
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the prop- erty occurs, this
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the prop- erty occurs, this property's written
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the prop- erty occurs, this property's written value is applied to hardware. When a
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the prop- erty occurs, this property's written value is applied to hardware. When a read of this prop-
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the prop- erty occurs, this property's written value is applied to hardware. When a read of this prop- erty occurs, the read
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the prop- erty occurs, this property's written value is applied to hardware. When a read of this prop- erty occurs, the read value is the (nom-
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which may be slightly
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which may be slightly different than a
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which may be slightly different than a previously written
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which may be slightly different than a
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which may be slightly different than a previously written property value due to rounding that oc-
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which may be slightly different than a previously written property value due to rounding that oc-
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which may be slightly different than a previously written property value due to rounding that occurs before writing
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which may be slightly different than a previously written property value due to rounding that occurs before writing hardware register
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which may be slightly different than a previously written property value due to rounding that occurs before writing hardware register values and/or No-
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which may be slightly different than a previously written property value due to rounding that occurs before writing hardware register values and/or No-OS API rounding)
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which may be slightly different than a previously written property value due to rounding that occurs before writing hardware register values and/or No-OS API rounding) with double floating
SpecProperty	sample_rate_MHz	Double	-	-	ReadSync,		30.72	Sample rate of the incoming RF samples. When a write to the property occurs, this property's written value is applied to hardware. When a read of this property occurs, the read value is the (nominal) in-situ value (actual value which is currently assigned in hardware, which may be slightly different than a previously written property value due to rounding that occurs before writing hardware register values and/or No-OS API rounding)

When a write to

WriteSync

NOT\_SUPPORTED\_p

SpecProperty

10

rf\_cutoff\_frequency\_MHz

Double

SpecProperty	bb_gain_step_dB	Double	-	-	WriteSync	BB_GAIN_STEP_DB_p	BB_GAIN_STEP_DB_p	Minimum granular- ity for changes in
								baseband gain
SpecProperty	frequency_max_MHz	Double	-	-	WriteSync	FREQUENCY_MAX_MHZ_p	FREQUENCY_MAX_MHZ_p	Maximum valid value for frequency
SpecProperty	frequency_min_MHz	Double	-	-	WriteSync	FREQUENCY_MIN_MHZ_p	FREQUENCY_MIN_MHZ_p	Minimum valid value for frequency
SpecProperty	frequency_step_MHz	Double	-	-	ReadSync, WriteSync	LO frequency-dependent	-	Minimum granular- ity for changes in frequency
SpecProperty	sample_rate_max_MHz	Double	-	-	WriteSync	SAMPLE_RATE_MAX_MHZ_P	SAMPLE_RATE_MAX_MHZ_p	Maximum valid value for sample rate
SpecProperty	sample_rate_min_MHz	Double	-	-	WriteSync	SAMPLE_RATE_MIN_MHZ_p	SAMPLE_RATE_MIN_MHZ_p	Minimum valid value for sample rate
SpecProperty	sample_rate_step_MHz	Double	-	-	ReadSync, WriteSync	Runtime-variable		Indicates the precision which will be used to evaluate the value written to this worker's sample_rate_MHz property before that value is applied to hardware. For example if the step is 2, the value written is rounded to the nearest multiple of 2 in order to be applied to hardware. The precision in this case is determined by the precision of the ad9361_config_proxy.: worker's rx_sampling_freq property.
SpecProperty	rf_cutoff_frequency_max_MHz	Double	-	-	WriteSync	RF_CUTOFF_FREQUENCY_MAX_MHZ_p	RF_CUTOFF_FREQUENCY_MAX_MHZ_p	Maximum valid value for RF cutoff frequency.
SpecProperty	rf_cutoff_frequency_min_MHz	Double	-	-	WriteSync	RF_CUTOFF_FREQUENCY_MIN_MHZ_P	RF_CUTOFF_FREQUENCY_MIN_MHZ_P	Minimum valid value for RF cutoff frequency.
SpecProperty	rf_cutoff_frequency_step_MHz	Double	-	-	WriteSync	RF_CUTOFF_FREQUENCY_STEP_MHZ_p	RF_CUTOFF_FREQUENCY_STEP_MHZ_p	Minimum granular- ity for changes in RF cutoff frequency.
SpecProperty	bb_cutoff_frequency_max_MHz	Double	-		WriteSync	BB_CUTOFF_FREQUENCY_MAX_MHZ_P	BB_CUTOFF_FREQUENCY_MAX_MHZ_P	Maximum valid value for baseband cutoff frequency
SpecProperty	bb_cutoff_frequency_min_MHz	Double	-	-	WriteSync	BB_CUTOFF_FREQUENCY_MIN_MHZ_p	BB_CUTOFF_FREQUENCY_MIN_MHZ_p	Minimum valid value for baseband cutoff frequency
SpecProperty	bb_cutoff_frequency_step_MHz	Double	-	-	ReadSync, WriteSync	Runtime-variable	-	Maximum granular- ity for changes in baseband cutoff fre- quency

ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			
ı			

Property	app_inst_name_ad9361_config_proxy	String	-	128	Initial,	Standard	ad9361_config_proxy	Value must match
					Readable,			the name of the
					WriteSync			ad9361_config_proxy
								application in-
								stance.
Property	app_inst_name_ad9361_data_sub	String	-	128	Initial,	Standard	ad9361_data_sub	Value must match
					Readable,			the name of the
					WriteSync			ad9361_data_sub ap-
								plication instance.
Property	config	Struct	-	-	Initial,	Standard	reference_clk_rate_Hz	Value must match
		(see			Volatile,		40e6,duplex_mode	the name of the
		Table			ReadSync,		FDD,are_using_REF_CLK_SMA	ad9361_adc_sub ap-
		1)			WriteSync		false,SMA_channel TX1A	plication instance.
Property	LO_source	Enum	-	-	Readable,	internal, external	internal	The value 'external'
					Writable,			should only be used
					WriteSync			if an external-to-
								the-FMCOMMS2/3
								clock drives the
								TP102 test point on
								the FMCOMMS2/3
								PCB.

Table 1: Structure declaration for tx.rcc config property type.

Туре	Name	Type	Sequence Length	Array Dimensions	Accessibility/ Advanced	Valid Range	Default	Usage
Property	reference_clk_rate_Hz	Double	-	-	-	Standard	-	Schematic crystal Y101 frequency.
Property	duplex_mode	Enum	-	-	-	TDD, FDD	-	-
Property	are_using_REF_CLK_SMA	Boolean	-	-	-	Standard	-	-
Property	SMA_channel	Enum	-	-	-	TX1A, TX2A	-	Indicates which SMA connector on the FMCOMMS2/3 PCB that the TX data stream controlled by an instance of this worker corresponds to.

# Performance and Resource Utilization

### $fmcomms\_2\_3\_tx.rcc$

Processor Type	Processor Frequency	Run Function Time
TBD	TBD	TBD

## Test and Verification

No unit test for this worker exists. However, a hardware-in-the-loop application (which is NOT a unit test) exists for testing purposes (see applications/fmcomms\_2\_3\_tx\_test).

## References

[1] AD9361 Reference Manual UG-570 AD9361\_Reference\_Manual\_UG-570.pdf