SReadWord Page 1

SReadWord Return a 16-bit ID value

#include <<u>Slots.h</u>> <u>Slot Manager</u>

OSErr SReadWord(spBlkPtr);

<u>SpBlockPtr</u> spBlkPtr; address of 56-byte <u>Slot Parameter Block</u>

structure

returns Error Code; 0=no error

SReadWord returns a 16-bit value identified by spID.

spBlkPtr is the address of a 56-byte **Slot Parameter Block** structure. The relevant fields are as follows:

Out-In Name		<u>Type</u>	Size Offset		<u>Description</u>
\leftarrow	spResult	<u>long</u>	4	0	FUNCTION result
\rightarrow	spsPointer	<u>Ptr</u>	4	4	Structure pointer
\rightarrow	spID	<u>char</u>	1	50	sResource list ID

Other parameters affected are:

spsOffsetData long 4 12 Offset/data field

spByteLanes char 1 53 ByteLanes from format block in card ROM

Returns: an operating system Error Code. It will be one of:

noErr (0) No error smEmptySlot (-300) No card in slot. smCRCFail (-301) CRC check failed.

smFormatErr (-302) FHeader format is not Apple's

smRevisionErr (-303) The revision of the card's declaration ROM is wrong.

smNoDir (-304) Directory offset is NIL

smNosInfoArray (-306) The SDM could not allocate memory for the sInfo

array.

smResrvErr (-307) A reserved field of the declaration ROM was used.

smUnExBusErr (-308) An unexpected bus error occurred. smBLFieldBad (-309) A valid <u>ByteLanes</u> field was not found.

smDisposePErr (-312) An error occurred during execution of DisposPointer.

smNoBoardSRsrc (-313) There is no board sResource.

smGetPRErr (-314) Error during execution of sGetPRAMRec.

smNoBoardId (-315) There is no board ID.

smlnitStatVErr (-316) The InitStatus_V field was negative after Primary or

Secondary Init.

smInitTblVErr (-317) Error while trying to initialize the sResource Table.

smNoJmpTbl (-318) Slot Manager jump table could not be created

smBadBoardId (-319) Board ID was wrong; reinit the PRAM record

Notes: The trap macro **SReadWord** finds a data structure in slot card firmware. It returns in spResult a 16-bit value identified by <u>spID</u> from the sResource list pointed to by <u>spsPointer</u>. This routine can return non-fatal error reports, which will be one of the following:

smBadRefId (-330) Reference ID was not found in the given sResource

list.

smBadsList (-331) The IDs in the sResource list are not in ascending

order.

smReservedErr (-332) A reserved field was not zero.

smCodeRevErr (-333) Wrong revision of the code to be executed by sExec.

smCPUErr (-334) The CPU field of the code was wrong.

smsPointerNil (-335) LPointer is nil From sOffsetData. If this error occurs;

SReadWord Page 2

		check sInfo rec for more information.
smNilsBlockErr	(-336)	The physical block size (of an sBlock) was zero.
smSlotOOBErr	(-337)	The given slot was out of bounds (or does not exist).
smSelOOBErr	(-338)	Selector out of bounds error
smNewPErr	(-339)	An error occurred during execution of NewPointer.
smCkStatusErr	(-341)	Status of slot is bad (InitStatus_A,V).
smGetDrvrNamErr	(-342)	An error occurred during execution of
		sGetDrvrName.
smNoMoresRsrcs	(-344)	No more sResources.
smsGetDrvrErr	(-345)	An error occurred during execution of sGetDrvr.
smBadsPtrErr	(-346)	A bad sPointer was presented to sCalcsPointer.
smByteLanesErr	(-347)	NumByteLanes was determined to be zero.
smSRTOvrFIErr	(-350)	Slot Resource Table overflow.
smRecNotFnd	(-351)	Record not found in the Slot Resource Table.