# Memory Hierarchy and SRAM Cache Design

Mainak Chaudhuri
Indian Institute of Technology Kanpur


#### Sketch


- Abstract model of computer
- Locality principle
- Memory and storage hierarchy
- Basics of SRAM caches
  - Organization
  - Protocol for cache lookup
  - Cache hits and misses
- Cache performance and AMAT equation
- Multi-level cache hierarchy

- Computer has an ISA
- The implementation of the ISA is an abstract five-state synchronous FSM
  - Each state change happens on posedge clock
  - State 0: fetch the instruction pointed to by program counter from memory; update program counter to point to the next instruction
  - State 1: decode the instruction to extract various fields and read source register operands
  - State 2: execute the instruction in ALU; compute address of load/store instructions; update program counter if control transfer instruction
  - State 3: access memory if load/store instruction
  - State 4: write result to destination register if the instruction produces a result

- Fetching an instruction requires accessing memory with the program counter as addr.
- Decoding an instruction for MIPS is simple due to small number of formats and fixed position of the register specifiers
- Reading operands from register file requires exercising the read ports
- Executing an instruction and computing address of a load/store instruction requires an arithmetic logic unit (ALU)
- Load/store instructions access memory with the computed address
- Writing result to register file requires exercising the write ports

 The SRAM cache on processor chip helps improve the average memory access time






# **Locality principles**

- Principles of locality exhibited by programs
  - Code and data accessed now are likely to be accessed again in near-future
    - Any interesting program would have loops and/or recursions
      - Justifies why code and data accesses may be repeated
      - Example: reuse of rows of A and columns of B when multiplying matrices A and B
    - Known as temporal locality
  - Code and data allocated close to the code and data being accessed now are likely to be accessed in near-future
    - Sequential code access
    - Sequential data access (e.g., walking over an array)
    - Known as spatial locality

- Locality principles imply an important corollary
  - Programs usually work on a small portions of code and data at a time
    - The code and data needed over a time window of length t could be a subset of the code and data needed over a bigger time window of length t'
    - Think about nested loops
- This corollary is exploited to build a hierarchy of memory and storage structures
  - Keep most recently used code and data close to the processor because this is needed now
  - Keep increasingly larger supersets of code and data gradually away from the processor

- Why not keep everything in a large on-chip SRAM?
  - Expensive and slow
- Memory and storage parts are usually arranged in a hierarchy
  - SRAM caches are closest to the processor logic, smallest in size, and fastest
    - Total on-chip cache is usually few tens of MBs
  - DRAM is outside processor chip, much larger in size, much slower than SRAM caches
    - Tens to hundreds of GBs
  - Hard disk holds everything, non-volatile, very large, very slow
    - Tens to hundreds of TBs


- Hierarchical organization allows very fast access to a small subset of code and data needed now from the SRAM cache
- Later this code and data can be exchanged to bring something else from DRAM
  - SRAM caches have finite capacity, so something must be replaced to bring something new if the cache is already full
- Also, code and data in DRAM can be swapped with something else from hard disk on demand
  - Less frequent than exchange between SRAM and DRAM



#### Example

- Suppose a program's load/store instructions and instruction fetcher generate N memory accesses
- Nx accesses find the requested data in on-chip SRAM cache (x < 1)</li>
- -N(1-x)y accesses find the requested data in DRAM (y < 1)
- Remaining accesses fetch data from hard disk
- An access to SRAM cache requires time t1 (hit)
- An access to DRAM requires time t2 (cache miss)
- An access to hard disk requires time t3
- Average access time = (Nxt1 + N(1 x)yt2 + N(1 x)(1 y)t3)/N
  - Since t1 << t2 << t3, as x and/or y increase(s), the average access time goes down</li>


# Memory and storage hierarchyHard disk organization



- Hard disk organization
  - Metal platters are coated with magnetic recording material and arranged vertically on a spindle
    - One side or both sides of each platter can have recording capability
  - Each platter or disk has a head for reading and writing data
  - Each platter has concentric circles called tracks
  - All heads read from the same track of all platters at the same time
    - A particular track of all platters together forms a cylinder
  - Each track is divided into small contiguous data chunks called sectors (of size 512 to 4096 bytes)

- Hard disk organization
  - Anticipating good spatial locality in the running program, at a time a full sector is read out and filled in DRAM
    - The read sector necessarily contains the data that was demanded by the processor logic
  - Three components in accessing a target sector
    - Move the head assembly of all platters to the correct cylinder
      - Completely mechanical process and very slow
      - The time required is known as the seek latency
    - Rotate the platters to move the correct sector under the head
      - Also mechanical and slow; adds rotational latency
    - Read the sector and transfer to DRAM
      - Adds transfer latency determined by read & copy bandwidths

- Start with a simple design
  - Array of code and data items
  - A block is fetched at a time
    - A block is a spatial segment of contiguous bytes





- Start with a simple design
  - Array of code and data items
  - Any instruction or data element accessed will be fetched from DRAM and allocated a free slot in the cache, if it is not already in the cache
    - Hope is that due to temporal locality, this item will be accessed soon and at that time, it will be found in the cache resulting in much shorter access time
    - Drawback: doesn't exploit spatial locality
  - To exploit spatial locality, we could fetch a bigger block of code or data from DRAM containing the requested item
    - Mimics what the hard disk to DRAM interface does
    - Every SRAM cache fixes this fetch size and this is called the block size of the cache

- Cache is looked up in two events
  - State 0 of FSM generates an access for instruction using program counter as the address
  - State 3 of FSM generates an access for data using the address computed in state 2
  - Requested block is searched in the cache
    - Needs to store the address along with each block
      - Need to define block address (sequence number of a block)
      - If block size is 2<sup>n</sup> bytes, block address is (Address >> n)
    - Block address is the search key
    - This searching time can be very large if done sequentially
    - A parallel search would require a large number of comparators (equal to number of blocks in the cache)
      - Would consume a lot of power and area

Start with a simple design

Address >> log<sub>2</sub>(Block size)


	, L	Block addr.	Code block
		Block addr.	Code block
		Block addr.	Data block
		Block addr.	Code block
		Block addr.	Data block
Searc		Block addr.	Data block
		Block addr.	Data block
		Block addr.	Data block
		Block addr.	Code block
— Block size			

Address is either the PC or the load/store address

- If the looked up block is found in the cache, it is called a cache hit; otherwise it is a cache miss
  - Cache miss requests are forwarded to the DRAM controller for further handling
  - Eventually the DRAM controller will respond with the requested block and it will be allocated in the cache
    - What if the cache is full?
      - Needs to replace a block
    - Which block to replace?
      - Maybe the block that is not used recently (least-recently-used or LRU replacement algorithm)
      - Maybe a random block (random replacement algorithm)
      - LRU replacement requires keeping track of time of access
      - Random replacement requires a random number generator

- Cache hits need to be much faster than cache misses to be useful
- To optimize the search time of a cache block, caches are typically organized as hash tables
  - Each hash element has a block, a block address or tag, and a few state bits (e.g., valid/invalid)
  - The blocks in a cache are logically divided into disjoint sets (these are hash buckets)
    - Each set can have a maximum number of valid blocks
    - This maximum number is known as the associativity of the cache
    - For example, a 16 KB cache with 64-byte blocks can have 32 sets each with associativity 8

# 2-way set associative cache




Block address = {TAG,INDEX}; TAG bits can uniquely identify a block in a set

- A cache with associativity A is often called an A-way set-associative cache
- To look up a cache with an address
  - The set index is first determined by passing the address through a hash function
  - Within the set, the block addresses are searched in parallel for the target address
    - Number of comparators is equal to the associativity of the cache (which is usually small)
  - Critical path of lookup: determine set index, decode set index, read all block addresses in a set, parallel comparison, select at most one data block based on comparison outcome (needs a multiplexor)


- Determining set index
  - Many possible hash functions exist; we will discuss the simplest and the most popular one
  - Suppose there are N sets in the cache
  - To evenly distribute the block addresses among all sets, one possible mapping of block addresses to sets would map every N<sup>th</sup> block address to the same set
    - Set 0 gets block addresses 0, N, 2N, 3N, ...
    - Set 1 gets block addresses 1, N+1, 2N+1, 3N+1, ...
  - Set index can be determined by (block address) mod N
    - N is always a power of two; therefore, (block address) mod N = (block address) & (N 1) [avoids a division]

# 2-way set associative cache



Block address = {TAG,INDEX}; TAG bits can uniquely identify a block in a set TAG0 and TAG1 are compared again TAG in parallel; at most one will match

# 2-way set associative cache



#### Observations

- If associativity is one, number of sets is equal to the number of blocks in cache
  - A given block address has a unique location in cache
  - Known as direct-mapped cache (a given block address directly maps to a unique location in cache)
  - Needs a single comparator and no multiplexing needed for data selection on critical path
    - Faster hit time than set-associative designs
  - Simple design, but may suffer from large number of collisions between blocks (known as conflicts)
    - Block addresses 0, N, 2N, 3N, ... all map to set 0 if there are N blocks in the cache
    - Can increase the number of cache misses compared to a setassociative design
  - This is the minimum possible associativity

- Observations
  - If associativity is equal to the number of blocks in the cache, then the number of sets is one
    - Need to search all blocks in the cache during a lookup
      - Restricts the number of blocks in the cache; otherwise too many comparators and a large multiplexor would be needed consuming power and area
    - Known as fully associative cache (usually small in size)
    - Since number of sets is one, there are no index bits and the entire block address is the tag
    - Also, a given block can be placed anywhere in the cache
      - Significantly reduces conflicts
    - This is the maximum possible associativity for a given cache capacity
      - Cache capacity = no. of blocks x block size = no. of sets x no. of ways x block size  $^{28}$

- Total number of bits in cache
  - Data bits + Tag bits + valid bit = (Block size + Tag length + 1) x no. of sets x no. of ways
- Observation
  - For a fixed cache capacity, doubling of associativity halves number of sets
    - Decreases set index bits by one and increases tag length by one (total number of address bits is constant)
    - Number of comparators doubles, width of comparators increases by one bit, width of multiplexor increases by one bit
  - For a fixed cache capacity and associativity,
     doubling of block size also halves the no. of sets

#### Example

- 32-bit address, block size 64 bytes, directmapped, number of blocks (or sets) 512.
   Calculate the total number of bits in cache
- Tag length = 32 6 9 = 17 bits
- Tag and valid bits  $= 512 \times 18$  bits
- Total cache bits =  $512 \times (64 \times 8 + 17 + 1)$  bits

#### Example

- 32 KB cache with 64-byte block size and two ways. Calculate the size of the set index decoder.
- Number of sets =  $32 \times 2^{10}/(64 \times 2) = 2^{8}$
- Set index decoder size = 8 bits to 256 bits

#### Example

- 32 KB fully associative cache with 64-byte block size. Calculate the data selection multiplexor and comparator widths. Assume 32-bit address.
- Number of ways = 32 x  $2^{10}/64 = 2^9 = \text{number of comparators}$
- Width of multiplexor = 512 to 1
- Tag length = 32 6 = 26 bits = comparator width

- Handling writes to cache
  - Store instructions write new data to cache; should DRAM be also updated immediately?
    - If the DRAM is updated immediately, it is called a write-through cache
      - Remember that the cache to DRAM controller interface is defined in terms of a cache block
      - Modifying even one byte of a 64-byte cache block will require writing the whole block to DRAM
      - Same byte or different bytes of the same block may be written multiple times
      - Writes can also be done from a write buffer later
    - Alternate option: write to DRAM only when a modified block is replaced from the cache
      - Called a writeback cache; saves a lot of writes to DRAM
      - Needs an extra bit per cache block to remember if the block has been modified; known as the dirty bit

32

- Handling write misses
  - A store instruction missing in a cache may or may not allocate the block in the cache
    - If the block is not allocated in the cache, this protocol is known as no write-allocate; makes sense for writethrough caches under the assumption that the block will not be accessed in near future
    - If the block is allocated in the cache, this protocol is known as write-allocate; routinely used with writeback caches

#### Definitions

- Hit rate = number of hits / number of accesses
  - Bigger the better
- Miss rate = number of misses / number of accesses = 1 - hit rate
  - Smaller the better
- Average memory access time (AMAT) = hit/miss detection time + miss rate x miss penalty
- Decreasing any of the three terms would improve AMAT
- Miss rate x miss penalty is often referred to as the memory stall time
- Overall execution time = CPU time + memory
   stall time

 To avoid interference between code and data, processors have separate caches for instruction and data

#### Example

- Icache miss rate 2%, Dcache miss rate 4%, processor CPI is 2 when memory stalls are ignored, miss penalty is 100 cycles, load/store instructions constitute 36% of all instructions. If the caches are made perfect (0% miss rate), what is the performance speedup?
  - With perfect cache, CPI would be 2
  - Actual CPI =  $2 + 0.02 \times 100 + 0.04 \times 100 \times 0.36 = 5.44$
  - Speedup = 5.44/2 = 2.72

- Techniques to improve hit/miss detection time
  - Choose a simple design e.g., direct-mapped or low associativity
- Techniques to improve miss rate
  - High associativity or large capacity
    - contradicts with low hit/miss detection time
  - Larger block size
    - Helps if program has spatial locality
    - For fixed capacity and associativity, this reduces the number of distinct blocks in the cache and therefore, may increase miss rate beyond a certain block size
      - A program may need a certain minimum number of blocks

- Techniques to improve miss penalty
  - Early restart
    - Start the processor as soon as the requested bytes arrive; no need to wait for the entire block
    - The remaining bytes of the block will fill in the cache in background while processor continues execution
  - Critical word first
    - Configure DRAM module to return the 64-bit chunk containing the requested bytes in the first burst
    - Combine it with early restart
  - Multi-level cache hierarchy
    - Put increasingly bigger and slower on-chip SRAM caches between processor and DRAM (better than going all the way to DRAM on a cache miss)

- All commercial processors have two or three levels of SRAM cache on chip today
  - L1 is the closest to the processor and L2, L3, ...
     are further away, get gradually bigger and slower
  - The levels are designed such that the latency of fetching a block from the last level SRAM cache is still much smaller than fetching from DRAM
    - Typical sizes: L1: < 100 KB, L2: < 1 MB, L3: 2-32 MB
    - Associativity typically increases with increasing level
    - Block size may increase or may remain constant
    - Typical round-trip latencies could be L1: <1 ns, L2: ~5 ns, L3: ~10 ns, DRAM: 50-100 ns</li>
    - Missing in last-level cache can be highly detrimental for performance

- Processor FSM and logic injects code/data requests to L1 instruction/data cache
- L1 cache hits are returned immediately to the processor; L1 cache misses are forwarded to the L2 cache
- L2 cache hits are returned to the L1 cache, which forwards the requested bytes to the processor and also fills the block in L1 cache
  - Future accesses can be satisfied from the L1 cache until the block is replaced from L1 cache
- L2 cache misses are forwarded to L3 cache or DRAM depending on the number of SRAM cache levels

#### Example

- Processor with frequency 4 GHz and one level of SRAM cache, CPI 1.0 if all accesses hit in L1 cache, round-trip DRAM access latency is 100 ns, combined L1 miss rate per instruction is 2%.
   Calculate speedup if an L2 cache is added with round-trip access latency 5 ns and 25% miss rate per L2 access.
  - Overall CPI of base processor =  $1 + 0.02 \times 100/0.25$  = 9
  - Overall CPI with L2 cache =  $1 + 0.02 \times 0.25 \times 100/0.25 + 0.02 \times 0.75 \times 5/0.25 = 1 + 2 + 0.3 = 3.3$
  - Speedup = 9/3.3 = 2.72

- Updated AMAT equation
  - Average memory access time (AMAT) = L1
     hit/miss detection time + L1 miss rate x L2
     hit/miss detection time + L1 miss rate x L2 miss
     rate x L3 hit/miss detection time + L1 miss rate x
     L2 miss rate x L3 miss rate x DRAM fetch latency