Lab of EMIot Welcome!

Objective and organization

- Logistics: In-class lab
 - 1 laptop per person
 - May be useful to bring portable multiple sockets
- Necessary software:
 - -C
 - MATLAB
 - You can get a free student licence <u>https://www.areait.polito.it/supporto/risultato_serv.as</u> <u>p?serv=matlab&dettaglio=S&id_progetto_servizio=331</u>

LAB schedules

- 20% of the final score
 - 9 points maximum
- Assignments will be evaluated
 - Each student has to deliver his/her own assignment
 - No groups allowed!
 - 1 report per lab
 - Any extension to the minimum assignment may lead to an increase in the evaluation
 - Make sure you meet all requirements
 - Do not go out of topic

LAB delivery

- Lab deadline is 23:59 of the day before the 2nd exam
 - No exception
 - Late delivery implies <u>zero score</u> for labs
- Format: one archive
 - File name = report.zip
 - One subfolder per lab (Lab1/ Lab2/ Lab3/)




LAB delivery

- What to deliver for each lab:
 - Source code
 - All code you modified and/or consider necessary
 - Report
 - 5-10 pages per lab, depending on the depth of experiments
 - PDF format
 - Analysis of results
 - This is what gives you points!
 - Implementing the code is not enough!



LAB delivery

- How to deliver:
 - Through the didattica web site
 - «Elaborati» tag





Lab 1 Dynamic Power Management

Objective and organization

- Understanding of the basics of DPM
 - Use and modify a simple power state machine simulator in C
 - Evaluation of power management policies
- 1 report and 3 days

- Dynamic Power Management
 - Reduce power by turning devices to low power when peak performance is not needed
 - Devices abstracted as power state machines
 - Several internal states corresponding to modes of operation
 - Different power and service levels





- Power manager (PM)
 - Monitors requestor's activity and sets state of provider according to some policy
 - E.g., shuts down component after some inactivity time

 Given a PSM and a workload, determine the optimal allocation of power states over time that minimizes power under performance constraints


- Non-idealities make the problem non-trivial!
 - Transitions costs (time & power) are not zero
 - Transitions must be amortized!
 - Length of idle periods often unknown

- Goal of the lab:
 - Evaluate on a case study how energy saving changes as a function of
 - The applied DPM policies
 - The distribution of idle times
 - The PSM parameters
 - ...

- C program with the following basic operations
 - Read a power model → a PSM
 - Read a workload profile
 - Simulate two power management policies
 - Timeout
 - History-based prediction


- dpm_simulator [-help] [-t|-h] [-psm
 <psm file>][-wl <wl file>]
 - -help: prints command line instructions and returns
 - -t <Timeout>: use a timeout policy with <Timeout>
 - -h <Value1> ...<ValueN>: use a history-based predictive policy. <Value1-N> are additional policy parameters
 - -psm <psm file>: the name of the file describing
 the power state machine (PSM) of the resource
 - -wl <wl file>: the workload file name

Format of the PSM



States power
Transitions costs

(energy/time)




Transition does not exist:

- 0/0: Self-loops (i.e., state does not transition to itself)
- -1/-1: There is no transition between states


Default time, power, and energy units are: ms, mW and mJ

Format of the PSM



States power

Transitions costs (energy/time)



FROM STATE...

	RUN	IDLE	SLEEP
RUN			
IDLE			
SLEEP	2/4		

TO STATE...

ENERGY / TIME 2 mJ / 4ms


Workload format

- The workload is given as a list of idle intervals
 - Values are in μs

268	341	
609	656	
1010	1065	
1196	1273	
1541	1629	
2056	2139	


START/END OF 1st IDLE PERIOD
START/END OF 2nd IDLE PERIOD

...



DPM policies

- Timeout policy
 - Observe the first part of the current idle period to predict the length of the remaining part
 - Put the device in off state T_{TO} time units after it has entered the idle state



Compile and execute

Compile (requires gcc):

make

Generate Documentation (requires doxygen):

doxygen Doxyfile

- Generates «docs» folder with HTML documentation
- Execute:

```
./dpm_simulator -t 20 -psm example/psm.txt -wl example/wl.txt
```

Timeout policy with timeout value 20ms


Compile and execute

• Compile (requires acc).

```
(base) → dpm-simulator git:(master) x ./dpm_simulator -psm example/psm.txt -wl example/wl.txt -t 20
[psm] State Run: power = 27.6000mW
[psm] State Idle: power = 0.5700mW
[psm] State Sleep: power = 0.0900mW
[psm] Run -> Idle transition: energy = 0.0100mJ, time = 0.4000ms
[psm] Run -> Sleep transition: energy = 0.0200mJ, time = 1.0000ms
[psm] Idle -> Run transition: energy = 0.0100mJ, time = 0.4000ms
[psm] Sleep -> Run transition: energy = 2.0000mJ, time = 4.0000ms
[sim] Active time in profile = 300.130000s
[sim] Inactive time in profile = 244.066000s
\lceil \text{sim} \rceil Total time = 544.196000s
[sim] Timeout waiting time = 24.679000s
[sim] Total time in state Run = 324.809000s
[sim] Total time in state Idle = 219.387000s
[sim] Total time in state Sleep = 0.000000s
[sim] Time overhead for transition = 0.910800s
\lceil \text{sim} \rceil N. of transitions = 2277
[sim] Energy for transitions = 0.0227700000J
[\sin] Energy w/o DPM = 15.0198095999J, Energy w DPM = 9.1125489900J
(base) → dpm-simulator git:(master) x
```

Workloads

- 1. Two workloads provided on the course page
 - Similar structure (typical IoT workloads)
 - Read some data from sensors (polling)
 - Elaborate the data (e.g. Neural Network inference)
 - Repeat every 2 minutes




Workloads

- 1. Two workloads provided on the course page
 - Workloads generated using an embedded system simulator called JUMPER: https://docs.jumper.io/
 - You don't have to use JUMPER directly for the lab, but you can (if you want) use it to generate additional workloads
 - Instructions and a basic simulation setup are provided on the Polito website.

Workloads

1. Two workloads provided on the course page


- workload_1.txt: "fast" sensors → 4ms to return a value
- workload_2.txt: "slow" sensors → 100ms to return a value
- Does this have an impact on DPM? It's your job to find it out



Part 1 Default Timeout Policy

Assignment 1 – Part 1


- 1. Compile the DPM simulator
- 2. Test it with the two workloads, using the default timeout policy
 - Only transitions between RUN and IDLE states
 - Try different timeout values and see what happens. Discuss in your report <u>why</u> it happens!



Part 2 Extension of the timeout policy

- The DPM simulator supports a timeout policy with transitions from ACTIVE to IDLE
 - Never goes to SLEEP state
 - Moving to SLEEP may save even more energy...

```
[sim] Active time in profile = 300.130000s
[sim] Inactive time in profile = 244.066000s
[sim] Total time = 544.196000s
[sim] Timeout waiting time = 24.679000s
[sim] Total time in state Run = 324.809000s
[sim] Total time in state Idle = 219.387000s
[sim] Total time in state Sleep = 0.000000s
[sim] Time overhead for transition = 0.910800s
[sim] N. of transitions = 2277
[sim] Energy for transitions = 0.0227700000J
[sim] Energy w/o DPM = 15.0198095999J, Energy w
DPM = 9.1125489900J
```





- Policy implementation
 - Modify the timeout-based policy

Assignment 1 – Part 2

- Modify the timeout policy to enable transitions also to SLEEP
 - Must modify the implementation of the DPM simulator

break;





The DPM simulator

- print_command_line()(src/utilities.c)
 - Prints the command line to invoke the tool
- parse_arg() (src/utilities.c)
 - Parses the inputs you provide via command line
 - For the timeout policy:
 *selected_policy = DPM_TIMEOUT;
 tparams->timeout = atof(argv[++cur]);

May have to be modified, too

value passed as parameter after -t

The DPM simulator


- dpm_decide_state()(src/dpm_policies.c)
 - Provided system state
 - Workload status (active/idle)
 - Current simulation time
 - Adopted policy (i.e., timeout)
 - Determines what is the state at the next time step

The DPM simulator


- dpm_simulate()(src/dpm_policies.c)
 - Emulates policy application to the PSM given the workload
 - For all instants in the current (active and idle) period
 - Invoke dpm_decide_state() to apply the policy and determine transitions
 - Check the state returned and update energy consumption accordingly

Power State Machine

- Note that there is **no transition** between IDLE and SLEEP in the PSM
 - This system can only go to IDLE or SLEEP from the RUN state.
 - With a timeout policy only one of the two low-power states can be selected
 - The story is different for predictive policies.




Timeout Policy



NOTE: There is actually a way to use both low-power states. Which one? [Possible Extra]

Assignment 1 – Part 2


- Report assignment:
 - Comparison between RUN-> IDLE timeout policy and RUN->SLEEP timeout policy
 - What changes?
 - What's the best T_{TO} value in the two cases?
 - Which of the two results in the overall lower power?
 What changes for the two workloads provided?
 - What changes in terms of the timing overheads?
 - Why?




This is the most important!!!

Assignment 1 – Part 2

- Extra: Make your analysis automatic and systematic
 - Don't just try some "random" T_{TO} values
 - Compare things in a reasonable and meaningful way





Part 3 Predictive Policy




- Policy implementation
 - Implement a predictive policy

- So far we worked with timeout policies...
 - Put the device in off state T_{TO} time units after it has entered the idle state






- So far, we worked with timeout policies...
 - Put the device in off state T_{TO} time units after it has entered the idle state



Can we do better?




- Predictive policies
 - Predict inactive period $T_{pred} \sim T_{idle}$
 - Go to sleep state if T_{pred} is long enough to amortize state transition cost

- History-based policies:
 - Predictive policies that use previous history of T_{active} and/or T_{idle}
 - Example: non-linear regression equation


$$T_{idle}[i] = \mathbf{K} + \mathbf{K}_1 \cdot T_{idle}[i-1] + \mathbf{K}_2 \cdot T_{active}[i] + \mathbf{K}_3 \cdot T_{active}[i]^2$$

Goal of predictive policies



- Drawback of predictive policies
 - Under-prediction









- Drawback of predictive policies
 - Over-prediction


Drawback: will my guess be right?



- But remember our workloads:
 - Pretty easy to predict (roughly) the duration of the next inactive phase.
 - How?



 A predictive policy also allows us to use both lowpower states in the PSM:



Here I'm in RUN, I can go to either IDLE or SLEEP

- Currently the simulator contains data structures and functions to implement a regression-based policy:
 - Something like:


$$T_{idle}[i] = \mathbf{K} + \mathbf{K_1} \cdot T_{idle}[i-1] + \mathbf{K_2} \cdot T_{active}[i] + \mathbf{K_3} \cdot T_{active}[i]^2$$

- Mainly for «historical reasons»
- May not be the best type of history-based policy to implement

```
int parse_args(...) {
    //...
    if(strcmp(argv[cur], "-h") == 0) {
       *selected_policy = DPM_HISTORY;
       if(argc > cur + DPM_HIST_WIND_SIZE + 2){
         int i;
         for(i = 0; i < DPM_HIST_WIND_SIZE; i++) {</pre>
           hparams->alpha[i] = atof(argv[++cur]);
         hparams->threshold[0] = atof(argv[++cur]);
         hparams->threshold[1] = atof(argv[++cur]);
      } else return 0;
```

```
/* update idle time history */
void dpm_update_history(...) {
    for (int i=0; i<DPM_HIST_WIND_SIZE-1; i++){
        h[i] = h[i+1];
    }
    h[DPM_HIST_WIND_SIZE-1] = new_idle;
}</pre>
```


- Do we really need a polynomial?
- ...or can we make our decision simpler?
 - What determines if the next inactive period will be long or short?



Assignment 1 – Part 3


- Modify the simulator to implement a predictive policy
 - It can be of any kind, you decide
 - Trying and comparing more than one policy is also good
 - Of course, motivate your choices.

```
case DPM_HISTORY:
    /* Day 3: EDIT */
    if(curr_time < idle_period.start) {
        *next_state = PSM_STATE_ACTIVE;
    } else {
        *next_state = PSM_STATE_ACTIVE;
    }
    break;</pre>
```




Assignment 1 - Part 3

- Report assignment
 - Description of implemented predictive policy
 - Result of implemented predictive policy with the workload profiles
 - Analysis on effect of policy parameters (if any)



Assignment 1 – Part 3

- Report assignment:
 - Comparison between predictive policy and timeout policies
 - What changes?
 - Which approach is the best for the two workloads?
 - Why does a predictive approach work better/worse on one workload than the other (if it does)?
 - What changes in terms of the timing overheads?
 - Why?




This is the most important!!!

Assignment 1 - Part 2

• Extras:


- Any extra analysis/experiment is well appreciated
 - Show your creativity and desire to explore the topic
- Extras are **not** mandatory, but can give additional points:
 - If you only do the mandatory points of the previous slides, perfectly, you'll still get max score



Assignment 1 - Part 2

Extras: some suggestions

- Change the PSM (i.e., the target system)
- Change the workload:
 - Generate new "synthetic" workloads using any tool of your choice (MATLAB, Python, etc).
 - You can simply generate the sequence of inactive intervals, but they should make sense.
 - Install and use **Jumper** to generate workloads starting from real embedded code.
- Try other policies...
- Etc.



End of Lab 1! Now you're ready to prepare the first report...