

## 香港中文大學

The Chinese University of Hong Kong

# CSCI2510 Computer Organization


### Lecture 08: Cache Performance



## Recall: Cache Usage



Cache Read (or Write) Hit/Miss: The read (or write)
 operation can/cannot be performed on the cache.



- Cache Block / Line: The unit composed multiple successive memory words (size: cache block > word).
  - The contents of a cache block (of memory words) will be loaded into or unloaded from the cache at a time.
- Mapping Functions: Decide how cache is organized and how addresses are mapped to the main memory.
- Replacement Algorithms: Decide which item to be unloaded from cache when cache is full.

#### **Outline**



- Performance Evaluation
  - Cache Hit/Miss Rate and Miss Penalty
  - Average Memory Access Time

- Performance Enhancements
  - Prefetch
  - Memory Module Interleaving
  - Load-Through

## Cache Hit/Miss Rate and Miss Penalty

- A successful access to data in a cache is a hit.
  - Hit Rate: The ratio of number of hits to all accesses.
  - Miss Rate: The ratio of number of misses to all accesses.

#### Cache Hit:

- The access can be done in the cache.
- Hit rates over 0.9 are essential for high-performance PCs.


#### Cache Miss:

- When cache miss occur, extra time is needed to <u>bring</u>
   blocks from the slower main memory to the faster cache.
- During that time, the processor is stalled.
  - The waiting time depends on the cache operation details.
- Miss Penalty: the total access time passed through (seen by the processor) when a cache miss occurs.

### Class Exercise 8.1

Student ID:	Date:
Name:	

- In the working examples discussed in Lecture 07, the program will lead to
  - -2 cache hits (when i = 9 and 8) for direct mapping.
  - 8 cache hits (when i = 9, 8, ..., 2) for associative mapping.
  - 4 cache hits (when i = 9, 8, ..., 6) for 4-way set associative.
- What are the cache hit rates for each case?



### **An Example of Miss Penalty**



Memory

- Miss Penalty: the total access time passed through (seen by the processor) when a cache miss occurs.
- Consider a system with only one level of cache with following parameters:
  - Word access time to the cache: t
  - Word access time to the main memory: 10t
  - When a cache miss occurs, a cache block of <u>8 words</u> will be transferred from the main memory to the cache.
    - Time to transfer the first word: 10t
    - Time to transfer one word of the rest 7 words: t (hardware support!)
- The miss penalty can be derived as:

$$t + 10t + 7 \times t + t = 19t$$

The initial cache access that results in a miss.

CSCI2510 Led

CPU access the requested data in the cache.

**CPU** 

Cache

#### **Outline**




- Performance Evaluation
  - Cache Hit/Miss Rate and Miss Penalty
  - Average Memory Access Time

- Performance Enhancements
  - Prefetch
  - Memory Module Interleaving
  - Load-Through
  - Write Buffer

### **Average Memory Access Time**



- Consider a system with only one level of cache:
  - h: Cache Hit Rate
  - -1-h: Cache Miss Rate
  - C: Cache Access Time
  - M: Miss Penalty
    - It mainly consists of the time to access a block in the main memory.
- The average memory access time can be defined as:



- For example, given h = 0.9, C = 1 cycle, M = 19 cycles:
- $\rightarrow$  Avg. memory access time:  $0.9 \times 1 + 0.1 \times 19 = 2.8$  (cycles)

# Performance Improved by Cache (1/2)



- Consider the system with only one level of cache:
  - Word access time to the cache: 1 cycle
  - Word access time to the main memory: 10 cycles
  - When a cache miss occurs, a cache block of <u>8 words</u> will be transferred from the main memory to the cache.
    - Time to transfer the first word: 10 cycles
    - Time to transfer one word of the rest 7 words: 1 cycle
  - Miss Penalty:  $1 + 10 + 7 \times 1 + 1 = 19$  (cycles)
- Assume there are total 130 memory accesses:
  - 100 memory accesses for instructions with hit rate 0.95
  - -30 memory access for data (operands) with hit rate =0.90

# Performance Improved by Cache (2/2)



Total execution cycles without cache:

$$t_{without} = 100 \times 10 + 30 \times 10 = 1300 \ cycles$$

- All of the memory accesses will result in a reading of a memory word (of latency 10 cycles).
- Total execution cycles with cache:

Avg. memory access time for instructions: 
$$h \times C + (1-h) \times M$$

$$t_{with} = 100 \times \left[ (0.95 \times 1 + 0.05 \times 19) \right] +$$

$$30 \times \left[ (0.9 \times 1 + 0.1 \times 19) \right] = 274 \ cycles$$
Avg. memory access time for data:  $h \times C + (1-h) \times M$ 

The performance improvement:

$$\frac{t_{without}}{t_{with}} = \frac{1300}{274} = 4.74 \ (speed \ up!)$$

#### Class Exercise 8.2



- Consider the same system with one level of cache.
  - Word access time to the cache: 1 cycle
  - Word access time to the main memory: 10 cycles
  - Miss Penalty:  $1 + 10 + 7 \times 1 + 1 = 19$  (cycles)
- What is the performance difference between this cache and an ideal cache?
  - Ideal Cache: All the accesses can be done in cache.

### Real-life Example: Intel Core 2 Duo




- Number of Processors
- Number of Cores
- Number of Threads
- Name
- Code Name
- Specification
- Technology
- Core Speed
- Multiplier x Bus speed
- Front-Side-Bus speed
- Instruction Sets

- : 1
- : 2 per processor
- : 2 per processor
- : Intel Core 2 Duo E6600
- : Conroe
- : Intel(R) Core(TM)2 CPU 6600@2.40GHz
- : 65 nm
- : 2400 MHz
- $: 9.0 \times 266.0 \text{ MHz} = 2400 \text{ MHz}$
- $: 4 \times 266.0 \text{MHz} = 1066 \text{ MHz}$
- : MMX, SSE, SSE2, SSE3, SSSE3, EM64T

- L1 Cache
  - Data Cache: 2 x 32 KBytes, 8-way set associative, 64-byte line size
  - Instruction Cache: 2 x 32 KBytes, 8-way set associative, 64-byte line size
- L2 Cache: 4096 KBytes, 16-way set associative, 64-byte line size

### Real-life Example: Intel Core 2 Duo





### Cache on Real-life Processor



- In high-performance processors, two levels of caches are normally used, L1 and L2.
  - L1 Cache: Must be very fast as they determine the memory access time seen by the processor.
  - L2 Cache: Can be slower, but it should be much larger than the L1 cache to ensure a high hit rate.
- The avg. memory access time of two levels of caches:

$$t_{avg} = h_1 \times C_1 + (1 - h_1) \times [h_2 \times C_2 + (1 - h_2) \times M],$$

- $h_1$ : L1 cache hit rate
- $h_2$ : L2 cache hit rate
- $C_1$ : access time to L1 cache
- C<sub>2</sub>: time to transfer data from L2 to L1
- M: miss penalty to transfer data from memory  $\rightarrow$  L2  $\rightarrow$  L1

The avg. memory access time of one level of cache:

$$t_{avg} = h \times C + (1 - h) \times M$$

#### Class Exercise 8.3



- Given a system with one level of cache, and a system with two level of caches.
- Assume the hit rates of L1 cache and L2 cache (if any) are both 0.9.
- What are the probabilities that miss penalty has to be paid to read a block from memory in both systems?

#### **Outline**



- Performance Evaluation
  - Cache Hit/Miss Rate and Miss Penalty
  - Average Memory Access Time

- Performance Enhancements
  - Prefetch
  - Memory Module Interleaving
  - Load-Through

### How to Improve the Performance?



- Recall the system with only one level of cache:
  - h: Cache Hit Rate
  - -1-h: Cache Miss Rate
  - C: Cache Access Time
  - M: Miss Penalty
    - It mainly consists of the time to access a block in the main memory.
- The average memory access time can be defined as:

$$t_{avg} = h \times C + (1 - h) \times M$$

- Possible ways to further reduce  $t_{avg}$ :
  - Use faster cache (i.e., C ↓)? \$\$\$...
  - Improve the hit rate (i.e.,  $h \uparrow$ )?
  - Reduce the miss penalty (i.e.,  $M \downarrow$ )?

#### **Outline**




- Performance Evaluation
  - Cache Hit/Miss Rate and Miss Penalty
  - Average Memory Access Time

- Performance Enhancements
  - Prefetch
  - Memory Module Interleaving
  - Load-Through

## **How to Improve Hit Rate?**




- How about larger block size?
  - Larger blocks take more advantage of the spatial locality.
    - Spatial Locality: If all items in a larger block are needed in a computation, it is better to load them into cache in a single miss.
  - Larger blocks are effective only up to a certain size:
    - Too many items will remain unused before the block is replaced.
    - It takes longer time to transfer larger blocks, and may also increase the miss penalty.
  - Block sizes of 16 to 128 bytes are most popular.



## **Prefetch: More rather than Larger**



- Prefetch: Load more (rather than larger) blocks into the cache before they are needed, while CPU is busy.
  - Prefetch instruction can be put by programmer or compiler.
- Some data may be loaded into the cache without being used, before the prefetched data are replaced.
  - The overall effect on performance is positive.
  - Most processors support the prefetch instruction.



#### **Outline**




- Performance Evaluation
  - Cache Hit/Miss Rate and Miss Penalty
  - Average Memory Access Time

- Performance Enhancements
  - Prefetch
  - Memory Module Interleaving
  - Load-Through

## **Memory Module Interleaving (1/3)**



- How to reduce the miss penalty?
  - The main memory is slow in essence …
- Idea: Hide the memory access latency by interleaving memory accesses across several memory modules.
  - Each module has own Address Buffer Register (ABR) and
     Data Buffer Register (DBR) to access memory contents.




Without Memory Module Interleaving

With Memory Module Interleaving

## Memory Module Interleaving (2/3)




 Multiple memory modules (usually a multiple of 2) can be installed in modern computers.



## **Memory Module Interleaving (3/3)**



- Which scheme below can be better interleaved?
  - Scheme (a): Consecutive words in the same module.
  - Scheme (b): Consecutive words in successive module.
    - Keep multiple modules busy at any on time.




CSCI2510 Lec08: Cache Performance

(a) Consecutive words in the same module

(b) Consecutive words in **successive** modules

## **Example of Memory Module Interleaving**

- Consider a cache read miss, and we need to load a block of 8 words from main memory to the cache.
- Assume consecutive words will be assigned to successive modules for the better interleaving.
- For every memory module:
  - Address Buffer Register & Data Buffer Register
  - Module Operations:
    - Send an address to ABR: 1 cycle
    - ↑ Read the first word from module into DBR: 6 cycles
    - ↑ Read a subsequent word from module into DBR: 4 cycles
    - ♠ Read the data from DBR: 1 cycle
    - *Assume these operations can be performed in parallel (i.e. concurrently).*
- It only allows to access ( or ) one module at a time.




## Without Interleaving (Single Module)



Total cycles to read a single word from the module:

- 1 6 1
- 1 cycle to send the address
- 6 cycles to read the first word

- Send an address to ABR: 1 cycle
- Read the first word: 6 cycles
- Read a subsequent word: 4 cycles
- Read the data from DBR: 1 cycle
- 1 cycle to read the data from DBR → 1+6+1=8 cycles
- Total cycles to read an 8-word block from the module:




### With Interleaving

Total cycles to read a

- Send an address to ABR: 1 cycle
- Read the first word: 6 cycles
- ↑ Read <u>a subsequent word</u>: 4 cycles
- ★ Read the data from DBR: 1 cycle

8-word block from four interleaved memory modules:




#### Class Exercise 8.4



 What is the number of total cycles to read a 8-word block from two interleaved memory modules?

- Send an address to ABR: 1 cycle
- Read the first word: 6 cycles
- Read a subsequent word: 4 cycles
- Read the data from DBR: 1 cycle



#### **Outline**




- Performance Evaluation
  - Cache Hit/Miss Rate and Miss Penalty
  - Average Memory Access Time

- Performance Enhancements
  - Prefetch
  - Memory Module Interleaving
  - Load-Through

## Load-through



- Consider a read cache miss:
  - Copy the block containing the requested word to the cache.
  - Then forward to CPU after the entire block is loaded.
- Load-through: Instead of waiting the whole block to be transferred, send the requested word to the processor as soon as it is ready.
  - Pros: Reduce the CPU's waiting time (i.e., miss paneity)
  - Cons: At the expense of more complex circuitry (\$)



## **Summary**



- Performance Evaluation
  - Cache Hit/Miss Rate and Miss Penalty
  - Average Memory Access Time

- Performance Enhancements
  - Prefetch
  - Memory Module Interleaving
  - Load-Through