

Fred L S

To G. B. Herzog/R. O. Winder Location

Date 26 December 1974

From J. A. Weisbecker and Location
P. K. Baltzer

Telephone 2933

Subject COSMAC Coin Machine - Status Report

The coin operated amusement device market was discussed in an earlier report. This market includes pinball machines, video games, etc. We have been looking at the application of COSMAC in this area. So far, things look very promising. This report discusses our philosophy, approach, progress, plans, etc.

Philosophy and Approach

A variety of amusement-type coin machines could be developed using COSMAC. We have initially decided to build on our FRED experience. This requires the minimum development effort and yields the shortest lead time for a final product.

Our initial machine will be a general purpose computer system. We will plan to exploit the computer theme via styling, game design, etc. A minimum cost system will be developed first. This lets us have a product prototype in the shortest time. The minimum cost system also provides a reference with which future enhanced machines can be compared.

The machine will utilize ROM for program storage. 2K bytes appear to be sufficient initially. The ROM will be contained on a small plug-in card. A variety of different ROM cards can be sold. Each ROM card will convert the machine to a different set of games. This will give the basic machine a long life. New games will not require redesigning the machine because operators (users) can easily convert the machine to play new games in the field.

I/O approaches must be carefully chosen to maintain low final product cost, minimize development effort, and achieve a general purpose machine. A dot matrix TV display of the type used in the FRED project satisfies our requirements. Alpha-numeric displays are not as flexible, require higher resolution circuits (more costly), and extend development time. Such extension of development time would have included postponement of software effort until the new display formats could be evaluated, designed, and constructed. Prior experience has already verified the usefulness of the FRED type display format for a wide variety of games. Hardware design is completed and an LSI chip already exists for the required interface. For the coin machine, the display will be expanded to provide an array of 32x64 dots. This will almost fill the TV screen and greatly enhances display capability. This display circuitry has been tested with a monitor (versus a standard TV set) and yielded excellent results.

A number of game machine input approaches are possible. These include simple pushbuttons, keyboards, light guns, joy sticks, steering wheels, etc. Our initial choice was limited by considerations of flexibility, development effort,

and end cost. Other considerations must include ruggedness and reliability. Input transducers for coin-operated machines receive severe abuse by players and vandals. We have looked at keyboards, buttons, light guns, card readers, and joy sticks. Simple pushbuttons are the least expensive, most rugged, and most general-purpose input transducers. They are readily available and have already been life tested. They are also consistent with our computer theme philosophy. Initially, we are providing 5 buttons for each player. This seems sufficient for a number of 1 and 2 player games. Interface circuitry is trivial.

A prototype of a minimum-cost, general-purpose, game-playing machine will be constructed during the first half of 1975. A number of sample programs will be developed concurrently for demonstration and field testing. Alternative I/O approaches and enhanced systems will be investigated at a later date.

Hardware

Three distinct hardware development efforts are required. First, a system suitable for program development and debug is required. A suitable system has been designed and constructed and is currently being used for software development. It includes 2K bytes of RAM which simulate the ROM of a final machine. This RAM can be loaded by a self-contained cassette unit or HEX keyboard (initial program entry). The ability to record program cassettes and extensive program preparation/debug facilities are also provided.

A second hardware system will be required as a breadboard prototype for the final product. This system will simulate the final system exactly. It differs from the first system in that no program preparation or debug facilities are included. It will also be packaged to simulate a final system and can be used for demonstration/field testing. It will differ from the final system in its use of PROM rather than ROM and will be hand-wired rather than using a printed-circuit board. Physical packaging will be in the form of a table top unit and optional pedestal to facilitate transportation and demonstration. This system is currently being designed for construction in the first half of 1975.

The third hardware system will be the final product. All electronics will be packaged on a single 8"x10" P.C. board. A socket will be provided to accept a variety of ROM plug-in cards. The design of the final system should be completed by a product line group. Final product design could start as early as the first quarter of 1975 and run concurrently with prototype testing and software development. The mechanical design (box, control panel, etc) would benefit greatly from an early start. We do not currently plan to proceed to a final product design within our group.

Figure 1 illustrates the block diagram of the proposed minimum system. Figure 2 illustrates the input panel layout. Figure 3 shows a proposed package.

The final system will require about 40 chips (excluding ROM). 2K bytes of ROM can be provided on 1 chip. 512 bytes of RAM will be required for TV display and variables. Four 256x4 RAM chips will suffice. Other LSI chips include the 2 COSMAC chips and a custom TV chip (available from FRED project). All other chips are readily available - SSI and MSI types (mixed 4000 COS/MOS and 7400 TTL).

Assuming \$50. for the COSMAC chip set, \$30. for the custom LSI TV chip, \$30. for ROM, and \$20. for RAM, a total chip cost of \$180. is possible. These could all be mounted on a single 8"x10" P.C. card for a total electronics package cost of \$250. Adding \$140. for a TV monitor (includes system power supply and audio amplifier) results in a cost of under \$400. This leaves \$200. for cabinet, switch panel, coin box, and assembly. The resulting \$600. manufacturing cost is consistent with a competitive selling price target of \$1200.

Software

We are simultaneously trying to do two things in the area of coin-machine software. First, we are developing a number of game programs for demonstration and test of the prototype hardware system. Two games have been designed, and others are in development. These games (unlike home games) must be quick to learn and fast to play. Two minutes is normal for a 25¢ machine to maximize return. These games must be novel and simple enough to prevent frustration on the part of new players. They must also provide continuing challenge for experienced players. They must appeal to the maximum range of age and sex. They must stay within the memory and I/O capability of our low-cost general-purpose hardware. Satisfying this unique set of criteria is a non-trivial task.

Concurrent with game development is the design of new game programming languages. Such languages facilitate developing and experimenting with new games and provide more efficient use of our small memory capacity. These interpretive languages will also be invaluable to future programmers of the coin machine. It is anticipated that programming will become a continuing effort in order to satisfy the secondary market for new ROM's. Rather than spending an inordinate amount of time on one inefficient general-purpose language, we are developing a number of special-purpose ones. Each is suitable for a group of games. So far, two such languages have been developed. Others will be investigated as the need arises.

All software is being developed exactly as it will go into the prototype PROM and/or final product ROM. This will eliminate the future need for recoding and resulting unexpected problems and costs.

Conclusions

For a new understaffed project, a great deal has been accomplished:

- a. A market study has been completed,
- b. Useful contacts within the trade established,
- c. Specifications developed for a practical minimum system,
- d. Hardware system designed and built for program preparation/testing,
- e. Product prototype design underway, and
- f. Software development underway with several demonstration programs now running.

The project to date is considered to be a very healthy one, for the following

26 December 1974

reasons:

- a. Marketing and distribution problems and costs will be minimal because of existing industry-wide distribution systems.
- b. Ideal initial COSMAC application since the system is completely self-contained, requiring only 5 volts and 20 μ sec instruction time.
- c. The general-purpose hardware estimate (40 chips) compares very favorably with existing special-purpose machines (~125 chips).
- d. Only cabinet and software are now unknowns, and no major problems are expected for either one.




FIGURE 1 - COIN MACHINE BLOCK DIAGRAM




FIGURE 2 - SWITCH LAYOUT





FIGURE 3


JW

COSMAC COIN GAME PANEL LOGIC




JAW 11-20-74

COIN GAME CKTS.
COSMAC CARD A9.



JAW 11-20-74

COSMAC CARD A9



LOADING PROGRAMS

Place all front panel toggle switches in the down position. Pushing the upper right hand corner switch, turns the computer on or off. Turn it on. Select the desired game cassette and put it in the cassette player. All cassette controls are labeled. REWIND the cassette. Set the yellow computer LOAD switch to the up position. Now PLAY the cassette. After several seconds, flashing display lights under the load switch will indicate that the program on the cassette is being transferred to memory. The computer will automatically stop the tape and turn off the green tape light after the cassette program has been transferred to the computer memory. Loading programs will take between 20 and 40 seconds. When the green TAPE light goes out, return the LOAD switch to its down position.

To summarize, loading a program requires the following steps:

1. All switches down
2. REWIND cassette
3. LOAD switch up
4. PLAY cassette
5. LOAD switch down (After TAPE light is off)

After the program is loaded the computer is ready to run. The loaded program remains in memory until power is turned off or a new program is loaded.

Incorrect program loading will prevent proper computer operation. If the display lights (under the load switch) don't flicker while loading then check to make sure that the cassette was properly rewound. If the red ERROR light comes on during the program load operation, rewind the cassette and repeat the load procedure. If problems persist, then the tape in the cassette may have been damaged and will have to be replaced.

For all games the TV should be tuned to channel 8 with sound turned all the way down. Adjust TV fine tuning, brightness, and contrast for best picture (black background with white dots). Make these adjustments after loading and running the Jackpot Game.

JACKPOT GAME (Programmed by Joyce Weisbecker)

Load the jackpot cassette program as described above. With LOAD down, place the green RUN switch in its up position. STOP the cassette. "\$10" should appear on the TV screen. Adjust TV for best picture.

Pushing any keyboard position (labeled 0, 1, 2, 3, 4, 5, 6, 7, 8, 9, A, B, C, D, E, F on front panel) will cause \$1 to be subtracted from your initial \$10. Three changing symbols will also appear on TV. Pressing any keyboard position will freeze the first symbol. Press two more times to freeze the remaining two symbols. If you freeze three different symbols you win \$2. If you freeze three identical symbols you win \$5 or \$10. After the computer shows whether you won or lost, press any keyboard position to play again. The computer shows how much money you have. If you go broke, you lose. If you accumulate \$50 you break the bank. To play a new game just flip the green RUN switch down - then up again.

SPACE WAR GAME (Programmed by C.T. Wu)

Load the space war cassette program, leave the cassette on PLAY. With LOAD down, flip RUN up. Two spots representing enemy space ships will appear on TV. The right spot is controlled by the computer. Your spot/ship is on the left. Move it up and down by pressing keyboard positions 1 or 3. Fire at computer ship by pressing 2. If you hit the computer ship 16 times first, you win. Sound effects are recorded on the cassette. Adjust the front panel VOLUME knob (next to ON button) for desired loudness. After 16 hits by either ship, flip RUN down then up to start a new game.

MATCH GAME (Programmed by A. Marcantonio)

Load the match cassette. STOP the cassette. This game is for two players (1 and 2). The object is to find matching pairs of symbols. With LOAD down, flip RUN up. Press keyboard position 1 to start game. A 4 x 4 array of symbols will flash on TV screen. The 16 keyboard positions represent symbol positions on the TV. Player 1 presses two keyboard positions trying to find two matching symbols. If he finds two that match, they are replaced by 1 on the TV. He then gets another turn. If he doesn't find two matching symbols it is player 2's turn next. Turns alternate in this fashion until all symbols have been matched. Players always get extra turns for finding matching symbols. Count 1's and 2's showing to determine winner of game. Flip RUN down then up and press 1 to start a new game. Pressing keyboard positions other than 1 to start provide different sets of starting symbols.

ACEY-DUECY (Programmed by Joe Weisbecker)

Load the Acey-Duecy program. STOP the cassette. With LOAD down flip RUN up. Two playing card values appear in the upper left corner of the TV. \$25 appears in the upper right corner. This is the money you have. The flashing question marks mean that the computer is waiting for you to place your bet. You will bet that the value of the next card dealt by the computer lies between the two card values shown (not equal to either). Bet by pressing any keyboard position (2 = \$2, 8 = \$8, A = \$10, F = \$15). You can bet a maximum of \$15 (Press F) and a minimum of \$1 (Press 1). You can't bet more than you have. You have to get \$100 to break the bank. Flip RUN down then up to play again.

SPOT SPEEDWAY (Programmed by A. Robbi)

Load the program and STOP the cassette. With LOAD down flip RUN up. You must maneuver a moving spot from the small gap in center of left edge of race course to matching gap at right edge. Pressing keyboard position 2 starts moving spot and clock. Pressing keyboard positions 6, 8, B, and D will change direction of spot (6-up, 8-left, B-down, D-right). Press C and spot will gradually decelerate. Press A and spot will gradually accelerate until you lose control. Spot starts in the accelerate mode so press C before spot speeds out of control. If spot hits an obstacle you lose. After skill is developed, players can compete for fastest times. Press 2 to restart.

DEDUCE (Programmed by Joe Weisbecker)

Load the program and STOP the cassette. With LOAD down flip RUN up. The computer will choose a 4 digit random number which you must guess within 15 turns to win. No two digits in the number are the same. Enter your first guess by pressing 4 keyboard digits. The computer than provides some clues. 0 2 means 2 of the digits you entered match two digits of the unknown number but are not in the correct position. 0 means none of your digits are in the correct position. 2 1 means you have 2 digits right and in the proper position and 1 digit right but in the wrong position. Can you develop a strategy for always guessing the number within 15 tries? Flip the RUN switch down then up to play again.

LIFE (Programmed by M. Blecker)

Load the program and STOP the cassette. With LOAD down flip RUN up. A flashing dot appears in the upper left corner of the TV screen. Press keyboard positions 1, 2, 3, and 5 to move the dot within a 32 x 32 position field (1-left, 2-up, 3-right, 5-down). Press 4 to permanently write a spot on the TV screen in the position of the flashing dot. Move the flashing dot to a permanent spot position and press 6 to erase the permanent spot from the TV screen. TV pictures can be created in this manner.

The game of LIFE has been described in Scientific American. A cell colony is represented by a group of dots on the TV screen. For example, draw an array of dots in the shape of a "T" in the center of the screen. Use 5 dots for the top and 7 down. Now press "0". The computer will now calculate a new generation of cells based on adjacency relationships of the previous generation. For example, a single cell with no neighbors will die. A cell with 3 immediate neighbors results in the birth of a new cell. New generations are shown at 30 second intervals.

This program shows how computers can be used for simulation. It is easy to change cell birth and death rules to observe long term effects over many generations of a starting cell colony.

BOWL/TAG GAME (Programmed by Joe Weisbecker)

This program requires the attachment of the optional switch box (see Fig. 1). After connecting this switch box, load the program. STOP the cassette. With LOAD down, flip RUN up. Adjust the sound VOLUME to the desired level. The computer is now simulating the type of TV game machine found in shopping centers, restaurants, school recreation rooms, etc. Normally you put in 25 cents to play. Hold down one of the small red buttons on the sides of the switch box to simulate putting your quarter in the machine. Press 1 or 2 on the A side of the switch box to select the tag game or the bowling game.


The tag game assigns moving arrows to two players who can then chase each other around the TV screen by pressing their direction switches. Catching the other players arrow before he catches you gives you one point. The game ends after several minutes and you must put in another quarter to play again.

The bowling game lets two players compete at a simple, simulated, TV bowling alley. Button 3 rolls the ball. Buttons 2 and 4 let you move the ball up or down after you've rolled. This game ends after 6 frames have been played.

CONCLUSION

There is virtually no limit to the number of different uses for this computer. A variety of additional recreational and educational programs are available and new ones are being developed. The above games represent only a small sample of what is possible. Uses other than games are discussed elsewhere.

COSMAC COIN GAME PANEL



COSMAC COIN GAME INSTRUCTIONS

INPUT ($6E = \text{BIT } \phi-7 \text{ SWITCHES} \rightarrow M(x)$)
 $(\text{SW. PRESSED} = 1) - (x+\phi)$)

DISPLAY ($61 + M(x) = \phi 2$ SELECTS TV OUTPUT CHANNEL
 $62 + M(x) = \phi 3$ TURNS ON 32×64 DISPLAY AFTER TV SELECT)

TONE OUTPUT ($63 + M(x) = \phi 4$ SETS $EFF = 1$)
 $63 + M(x) = \phi \phi$ SETS $EFE = 0$) \Rightarrow EFF FED TO SPEAKER
 $(x+1)$ $EFE = 1$ FOR PROGRAMMED TONES
 $(x+1)$ $EFE = 0$ DISABLES PRESET TONE GENERATOR)

PRESET TONE GENERATOR ($65 + M(x) = KK$ EXTERNAL
 $(x+1)$ SETS A TONE GENERATOR FREQUENCY
 $66 + M(x) = \phi \phi$ EFF MUST = ϕ (NORMAL RESET STATE))
 $66 + M(x) = \phi \phi$ DISABLES TONE GEN.
 $(x+1)$ ENABLES TONE GEN.)

PARAMETER INPUT ($6D = \phi P$ (FROM 4 PARAMETER BIT SWITCHES) $\rightarrow M(x)$)
 $(x+\phi)$)