
MOS transistors (in subthreshold)



- Poll for lecture 1+Lab exercise sessions update
- Revisiting the cost of digital computation with real example of recurrent neural network hardware accelerator
- Quiz for lecture 1
- Standards for lab exercise reports
- Preview of this week's lab exercise: Measuring subthreshold FET IV characteristics
- History of MOSFET
- Review of Semiconductors
- What is a MOSFET? CMOS?
- Relation between physics of transistors and voltage-sensitive nerve membrane channels
- MOS capacitor structure
- Surface: accumulation, depletion, inversion
- Capacitive dividers: The *back-gate/body effect* parameter κ
- MOS transistor in *subthreshold / weak inversion* operation

Feedback poll and lab sessions update

1. Was the pace satisfactory? (Single Choice)

Answer 1: Too slow

Answer 2: About right

Answer 3: Too fast

2. Were you already familiar with the material? (Sir

Answer 1: Yes, with most of it

Answer 2: Knew about some of it

Answer 3: Didn't know about most of it

3. Did you sign up for exercises? You must complete the exercises to take the exam. (Single Choice)

Answer 1: Yes

Answer 2: No


4. If you did not sign up for exercises, why not? (Single Choice)

Answer 1: Just auditing (you must be registered)

Answer 2: No slot suits me


	Sep 24 THU 8:00 AM 10:00 AM	Sep 24 THU 10:00 AM 12:00 PM	Sep 24 THU 1:00 PM 3:00 PM	Sep 24 THU 3:00 PM 5:00 PM	Sep 25 FRI 8:00 AM 10:00 AM	Sep 25 FRI 10:00 AM 12:00 PM	Sep 28 MON 8:00 AM 10:00 AM	Sep 28 MON 10:00 AM 12:00 PM
32 participants	✓ 0/8	√ 2/8	~ 4/8	✓5/8	√ 0/8	✓5/8	√ 8/8	√ 8/8

Energy consumption of EdgeDRNN digital recurrent neural network





2L-768 unit GRU RNN



Throughput: 8 PEs * 2 Op/PE/clk * 125 MHz =2 GOp/s 2 GOp/s / 87mW \rightarrow E_{Op}=45pJ/Op

28 nm technology $t_{\text{ox}} = 1.4 \text{nm}$ $C_{\text{ox}} = 4*8.8 \text{e} - 12 \text{F/m/t}_{\text{ox}} = 25 \text{e} - 3 \text{F/m}^2$ $A_{\text{chan}} = 28 \text{nm x } 35 \text{nm} = \text{e} - 15 \text{m}^2$ $C_{\text{chan}} = C_{\text{ox}} * A_{\text{chan}} = 2.5 \text{e} - 17 \text{F}$ Energy to activate a transistor $E_{\text{FET}} = C_{\text{chan}} (\Delta V)^2 / 2$ $V_{\text{dd}} = 1 V, \ \Delta V = V \text{dd} / 2$ $E_{\text{FET}} = 3 \text{e} - 18 \text{J}$


Equiv # transistor activations for each 8*16 bit SRAM memory IO + math operations: $E_{Op}/E_{FET}=45e-12 \text{ J/Op / 3e-18 J/FET}$ = 1.5e7 FET/Op

Any questions about device physics?


Let's do a quiz

Quiz on device physics


Without looking at periodic table, is Phosphorus a donor or acceptor?



Preview of lab exercise



W/L=1/(0.18, .36, .054..... 2.7, 2.88) um/um



$$\delta T = \frac{\beta C (V_{refH} - V_{refL})}{\alpha I_{mon}}$$

$$\beta = 10$$

$$\alpha = 1 \text{ or } 10$$

$$V_{refH,L} = ?,?$$

Qiao, N., and G. Indiveri. 2016. "An Auto-Scaling Wide Dynamic Range Current to Frequency Converter for Real-Time Monitoring of Signals in Neuromorphic Systems." In 2016 IEEE Biomedical Circuits and Systems Conference (BioCAS), 160–63. https://doi.org/10.1109/BioCAS.2016.7833756.

Avoid these common mistakes in your lab reports


- Not discussing your data sufficiently. Think about a publication. The readers want to understand your reasoning with you. They want to be able to reproduce your results.
- Using axes/plot fonts that are too small. Use set(gca,'fontsize',18)
- Not using cross-hair axes when 0,0 is relevant as the origin.
- Forgetting to mention what your plot shows.
- Forgetting units on your axes.
- Not labeling your figures with a caption, e.g., "Fig. 1: Transistor drain current vs. gate voltage, Experiment 1."
- **Insufficiently labeling your data.** It's good to annotate your plots to indicate the slope of the curve, or the x / y intercepts.
- Using identical markers for all plots. Your curves must be distinguishable.
- **Forgetting units on measurements**, e.g. "our conductance is 1.000653e-10". What are the units? is the reader supposed to guess?
- **Giving your measurements too many digits of precision**; see previous error. Do your instruments really give you 7 digits of precision?
- **Tip: Use notebooks cell editing mode**, where sections are separated to generate your measurements and plots. That way, you can quickly change and repeat your measurements and plotting.

Blackboard summary of subthreshold FET operation

History of the Transistor


The term "transistor" is a generic name for a solid-state device with 3 or more terminals.

The field-effect transistor structure was first described in a patent by J. Lilienfeld in the 1930s! It took more than 40 years before MOS transistors were in mass production.





The first transistor (point-contact bipolar) fabricated at Bell Labs in 1947 (Bardeen, Brattain, Shockley). MOS transistors were not commericalized until mid 1970's.

Cross-section of a complementary pair of Field-Effect Transistors (FETs)




Top and Side Views of Field-Effect Transistor (FET)







Alternative symbols for transistors




nFET terminology




pFET terminology




The built-in potential barrier in a FET channel arise from *pn* junction potentials






Review on Semiconductors

Intrinsic silicon is undoped Extrinsic silicon is doped




Majority carriers are holes Minority carriers are electrons Majority carriers are electrons Minority carriers are holes


Review on Energy Band Diagrams



Equilibrium in a p-n Junction



Reverse-biased p-n Junction



Electrostatics in 1-D

Relationship between E-field and charge density (Gauss' Law)

$$\frac{\partial \xi}{\partial x} = \frac{\rho}{\varepsilon}$$
Charge density
Permittivity

Relationship between electrical potential voltage and electric field


$$\frac{\partial V}{\partial x} = -\xi \quad \text{Electric field}$$

Electric field boundary condition at a dielectric interface


$$\varepsilon_1 \xi_1 = \varepsilon_2 \xi_2$$

Mechanisms of Carrier Transport


<u>Drift</u>: Movement of charge carriers due to an external field




<u>Diffusion</u>: Movement of carriers due to a concentration gradient



The built-in potentials in the *pn* junctions create an *energy* barrier. In *subthreshold*, controlling the barrier height controls the diffusion current.





Energy

Small Vgs, Vds=0


Source Drain Channel

Is the scale realistic at room temperature?


No!


Barrier height is about 700mV

kT/c (the e-folding voltage for concentration) is only 25mV, which is 30X smaller.



Larger Vgs, Vds=0









FIGURE 4.5 Schematic of the arrangement used by Hodgkin, Huxley, and Katz to measure the current through the membrane of a squid axon under conditions where the membrane potential was controlled precisely. The sense electrode assumes the potential of the cytoplasm. The amplifier generates a current *I* proportional to the difference between the actual potential and the desired potential. This current is in the direction to move the actual potential toward the desired value. The current is sensed by an oscilloscope, shown as a meter on the diagram; the extracellular fluid is ground for the entire arrangement. (*Source:* [Hodgkin et al., 1952a].)

The waveforms shown are a simplification of records taken, using this apparatus, for a step increase in membrane potential. The initial transient is the current required to charge the membrane capacitance. Curve A is the total current as a function of time. Curve B is the potassium current alone. The difference, A - B, is thus attributed to the sodium current, which rises to a maximum and then decays.

Measuring voltage-dependent nerve membrane currents




Hodgkin & Huxley 1952

Neuron channels and Transistors

Both depend on exponential Boltzmann distributions of Concentration vs. Energy.


Neurons

- Membrane ionic conductance is exponentially dependent on the voltage across the neuron membrane.
- The population of open channels depends exponentially on potential across barrier.




Transistors

- Current flow in transistors is exponentially dependent on barrier height.
- The **population of carriers** depends exponentially on the barrier height.



Comparing transistor and membrane channel currents



How can biology achieve such a high exponential transconductance?

Hint: Biological voltage sensitive channels carry multiple charges that sense the voltage.






FIGURE 4.6 Exponential current–voltage characteristic of voltage-dependent channels. At high voltages, the fraction of channels that are open approaches unity, causing a saturation of the curves. (*Source:* [Hodgkin et al., 1952b, p. 464].)

Cross-section of Field-Effect Transistor (FET)



n-type MOSFET



Regimes of operation for FET (dependent on V_{gs})


•Cutoff - Surface is accumulated

Subthreshold (Weak Inversion) Regime


Current flows through diffusion

Above threshold (Strong Inversion) Regime


Current flows through drift



Subthreshold nFET: Current is diffusion current



Subthreshold nFET: Current is diffusion current



$$N_d = N_o e^{-\theta_d/U_T}$$

N=carrier density per unit volume

W=channel width

L=channel length

D=diffusion constant

 θ_{o} =built-in potential barrier


 N_s =built in concentration

 I_0 =subthreshold leakage current

Fwd Rev

Reminder: The Fermi-Dirac distribution

States above Fermi level (e.g. in conduction band) are occupied with Boltzmann distribution




Probability of occupation of a state

We have equation for subthreshold current, but we don't directly control the surface potential


$$I = -qWD_{n} \frac{dN}{dz} = I_{0}e^{\psi_{s}/U_{T}} \left(e^{-V_{d}/U_{T}} - e^{-V_{s}/U_{T}}\right)$$

How is the <u>surface potential</u> related to the <u>gate voltage</u>?


We need to understand effect of gate on surface potential




MOS capacitor structure




MOS capacitor structure: accumulation




MOS capacitor structure: flat band



MOS capacitor structure: depletion



MOS capacitor structure: inversion





What is "subthreshold"?

There are multiple <u>equivalent</u> definitions of subthreshold


- The current changes exponentially with V_g and V_s
- Nearly all the gate charge field lines terminate on fixed ions in the depletion region
- The current is dominated by diffusion current, not drift current

 The mobile carrier density is tiny compared with the dopant density







Electrostatics of the MOS Structure




Electrostatics of the MOS Structure (II)




Electrostatics of MOS structure (III)



What is a <u>depletion capacitor</u>?



Influence of gate on surface potential ψ_s



 ψ_{s} is controlled <u>only</u> by V_{g} and the bulk voltage (ground for n-fet), through the capacitive divider C_{ox} and C_{dep}

$$\Psi_{S} = Surface \ potential \\ \kappa(kappa) = \frac{\partial \Psi_{s}}{\partial V_{g}} = \frac{C_{ox}}{C_{ox} + C_{dep}}$$

Gate-depletion capacitive divider

How does changing V_g change ψ_s ?

1.
$$CV=Q$$

- 3. Change V, hold Q constant

Cox Charge Q on
$$\psi_s$$
 is constant

Cox Charge Q on ψ_s is constant

Change V, hold Q constant

$$C_{ox} = \frac{C_{ox}}{C_{ox}} = \frac{C_{ox}}{C_{ox}} = \frac{C_{dep}}{C_{dep}} \Delta \Psi_s$$

$$C_{dep} = \frac{C_{ox}}{C_{ox}} = \frac{C_{ox}}{C_{ox}} = K$$

$$\frac{\Delta \Psi_{\rm s}}{\Delta V_{g}} = \frac{C_{\rm ox}}{C_{\rm ox} + C_{\rm dep}} \equiv \mathbf{K}$$

Equations for Subthreshold nFET

$$V_s \stackrel{\bigsqcup^{V_g}}{\stackrel{}{=}} V_d$$


$$I_f$$
 = forward current
 I_r = reverse current
 I_0 = off current

$$I = I_0 e^{\kappa V_g / U_T} (e^{-V_s / U_T} - e^{-V_d / U_T})$$


$$= I_f - I_r$$

$$I_{f} = I_{0}e^{\kappa V_{g}/U_{T}}e^{-V_{s}/U_{T}}$$
 $I_{r} = I_{0}e^{\kappa V_{g}/U_{T}}e^{-V_{d}/U_{T}}$


Surface potential as function of V_g



nFET curve: I vs V_{gs}



nFet Threshold



Regimes of Subthreshold Operation (dependence on V_{ds})

Triode/Linear Region

$$I = I_0 e^{(\kappa V_g - V_s)/U_T} (1 - e^{-(V_d - V_s)/U_T})$$

Saturation Region (Vds>few UT)

$$I = I_f = I_0 e^{(\kappa V_g - V_s)/U_T}$$

nFET subthreshold Operation V in units of U_T


Triode/Linear/Ohmic Region

$$I = I_0 e^{\kappa V_g - V_s} (1 - e^{-V_{ds}})$$

Saturation Region, V_{ds} a few U_T

$$I = I_f = I_0 e^{\kappa V_g - V_s}$$

nFET drain curve: I vs V_{ds} for long transistors



What about the pre-exponential I_0 ?

$$I = I_f = I_0 e^{(\kappa V_g - V_s)/U_T}$$


 I_0 comes from the built-in barrier and the doping concentrations. It takes the form

$$I_0 = N_s U_T^2 \beta \left(T\right) \exp \left(\frac{-\kappa V_T}{U_T}\right)$$
 Dimensionless source concentration
$$U_T \beta : \text{diffusivity}$$

$$U_T : \text{factor for density of states}$$

Concentration at source reduced by barrier


Band Diagram for subthreshold nFET




p-type MOSFET

All voltages are referenced to $V_w = V_{dd}$

p



Band Diagram for subthreshold pFET



Equations for Subthreshold pFET

$$V_s \stackrel{\bigcup^{V_g}}{=} V_d$$
 $I_f I_r$

$$I = I_0 e^{-\kappa V_g / U_T} (e^{V_s / U_T} - e^{V_d / U_T})$$
 $I_f = forward \ current$ $I_f = reverse \ current$

$$I_f = forward\ current$$
 $I_f = reverse\ current$

$$I_{f} = I_{0}e^{-\kappa V_{g}/U_{T}}e^{V_{s}/U_{T}}$$
 $I_{r} = I_{0}e^{-\kappa V_{g}/U_{T}}e^{V_{d}/U_{T}}$

pFET subthreshold Operation V in units of U_T


Triode/Linear Region

$$I = I_0 e^{-\kappa V_g + V_s} (1 - e^{+V_{ds}})$$


Saturation Region, $V_{ds} > a$ few U_T

$$I = I_f = I_0 e^{-\kappa V_g + V_s}$$


nFET functional behavior



pFET functional behavior



Circuit question




- •What is $V_{out} vs. V_{in}$?
- •Why is this circuit called a *source follower*?
- •How can you use this circuit to measure kappa?

THE END

Next transistor lecture (Mellika):
What is the transistor threshold?
Above threshold operation.
Drain conductance-Early effect

Next lecture after this (Giacomo):
Static circuits in subthreshold
Current mirror
Differential pair
Bump and Anti-Bump circuits

Measured temperature dependence of $I_{\rm d}$ vs $V_{\rm gs}$




Quiz on device physics

```
Do you know these constants?
q (elementary charge of electron)
    1.6e-19 C
U_T = kT/q (thermal voltage)
   25 \text{mV}
\varepsilon(permittivity of vacuum)
   8.85e-12 F/m
\varepsilon_{Si} and \varepsilon_{SO2} (relative permittivities of silicon and silicon dioxide)
   \varepsilon_{\rm Si}~12 \varepsilon_{\rm SO2}~4
```

Quiz on device physics

If we create an N to N++ doping profile, which way does the electric field point? Is there a space charge region or junction?

Gradient of electron density causes electrons to diffuse leftwards, resulting in electric field pulling them rightwards, so there will be a built in E field pointing to the left. There will be space charge, but no depletion region.



Doping profiles are often used to build in electric fields to push minority carriers in a desired direction, e.g towards a photodiode junction, or away from a switch transistor

Good lab examples

Neuromorphic Engineering I, Lab 05 (04b), Report

Experiment 03

In this experiment, the output current versus differential input voltage characteristics of the transconductance amplifiers for different bias currents are measured. Specifically, the output current versus input voltage for two different bias currents in the sub threshold region and one bias current in the above threshold regions are considered.

The plots for the simple transconductance amplifier are shown below in 1. We can see from the plot that

Subthre


1 Exper


1.1 Descr


The purpose of function of the a well transistor process, therefore

while for well t

In the above e instead refer th and revert the







(b) Plot for a bias current above threshold

Figure 1: Output currents vs input voltage for different bias currents, in a simple transconductance amplifier, with linear fits to specify the regions of linear behavior. Note that the voltage scales in two subplots are different.

Bad exar

Experiment 3, Gate Oxide Tunneling


Figure 3 i According For nFET,

For pFE

 $\beta = 5.6$

In this experiment the dependence of tunneling current on the oxide voltage. The linear scale plot and the scale plot of the dependence is shown in 3. The curve is fitted to the theoretical function $I = I_0 e^{-\frac{V_0}{V_{ox}}}$. The parameter I_0 is the maximum possible tunneling current when the oxide voltage moves to infinity, while parameter V_0 is the oxide voltage at which the tunneling current reaches 1/e = 0.3679 times the maxim current I_0 .

Not a sentence



We can clearly see that are at roughly the sa on Vref. The smaller

0.02

74