# Mastering Embedded Systems Diploma

https://www.learn-in-depth.com/

Submitted To: Eng/ Keroles Shenoda

S2S Automotive Solutions Technical Lead at Mentor Graphics

# First Term Project 1

Case Study: Pressure Monitoring System Inside Airplane Cabin



Submitted By : Eng/ Peter Moner Goda

My Diploma Profile

**GitHub Project** 

LinkedIn Profile

## Case Study: Pressure Monitoring System Inside an Airplane Cabin

## • Specifications:

- If pressure value inside Airplane cabin is more than 20 bar >>> An Alarm System is going to turn on.
- Alarm system stills ON for a 60 Second duration time.

## • Assumption :


- Pressure sensor never fails
- Alarm never fails
- The controller never faces power cutting
- The controller setting up and shutting down are not modeled
- The controller maintenance is not modeled

# • Versioning:


- V1.0 ===> Output Product is a pressure monitoring system can informing cabin crew if there is a high pressure inside the cabin by turning Alarm system ON for 60 second Only.

#### • Method:


Using a V-model as the requirements and understanding of the software's functionality are well-defined from the beginning. The project scope is clear, and the development team has a solid understanding of the requirements.




# • System Requirement:




- Space Exploration and Partitioning
  - Selected Microcontrollers is STM32F103C6
    - ❖ ARM 32-bit Cortex-M3 Microcontroller
    - ❖ Up to 72MHz Frequency
    - ❖ 32kB Flash
    - ❖ 10kB SRAM, PLL
    - ❖ Embedded Internal RC 8MHz and 32kHz
    - ❖ Real-Time Clock
    - ❖ Nested Interrupt Controller, Power Saving Modes, JTAG and SWD, 2 Synch.
    - ❖ 16-bit Timers with Input Capture, Output Compare and PWM, 16-bit 6-ch Advanced Timer, 16-bit Watchdog Timers, SysTick Timer
    - ❖ SPI, I2C, 2 USART, USB 2.0 Full Speed Interface, CAN 2.0B Active
    - ❖ 2 12-bit 10-ch A/D Converter
    - ❖ Fast I/O Ports.
- System Analysis:
  - Case Diagram




# - Activity Diagram




# - Sequence Diagram




- System Design:
  - Full System Block Diagram




- State machine of Pressure Sensor Driver




- State machine of Alarm Monitor




- State machine of Alarm System Driver




- State machine of Main Algorithm



# • System Design Logic Simulation





### • C Files

- Driver.c

```
#include "driver.h"
 #include <stdint.h>
#include <stdio.h>
void Delay(int nCount)
⊒ {
      for(; nCount != 0; nCount--);
L}
jint getPressureVal(){
      return (GPIOA IDR & OxFF);
L}
void Set_Alarm_actuator(int i) {
    if (i == HIGH) {
          RESET_BIT (GPIOA_ODR, 13);
      else if (i == LOW) {
          SET_BIT (GPIOA_ODR, 13);
L}
∃void GPIO INITIALIZATION () {
     SET_BIT (APB2ENR, 2);
      GPIOA CRL &= 0xFF0FFFFF;
     GPIOA_CRL | = 0 \times 0000000000;
      GPIOA_CRH &= 0xFF0FFFFF;
     GPIOA CRH | = 0x222222222;
 }
```

- Main.c

```
#include <stdint.h>
 #include <stdio.h>
 #include "driver.h"
 #include "Platform_Types.h"
 #define Threshold val 20
∃int main (){
     uint32 Pressure_value=0;
     GPIO INITIALIZATION();
     Set_Alarm_actuator(LOW);
     while (1)
         Pressure_value = getPressureVal();
         if(Pressure_value >= Threshold_val)
             Set_Alarm_actuator(HIGH);
             Delay(1000000);
         }
         else{
             Set_Alarm_actuator(LOW);
     }
}
```

### - Driver.h

```
#include <stdint.h>
#include <stdio.h>
#define SET BIT(ADDRESS, BIT) ADDRESS |= (1<<BIT)</pre>
#define RESET BIT (ADDRESS, BIT) ADDRESS &= ~(1<<BIT)
#define TOGGLE BIT(ADDRESS, BIT) ADDRESS ^= (1<<BIT)
#define READ BIT(ADDRESS,BIT) ((ADDRESS) & (1<<(BIT)))</pre>
#define HIGH 1
#define LOW 0
#define GPIO PORTA 0x40010800
#define BASE RCC 0x40021000
#define APB2ENR *(volatile uint32_t *)(BASE_RCC + 0x18)
#define GPIOA_CRL *(volatile uint32_t *)(GPIO_PORTA + 0x00)
#define GPIOA_CRH *(volatile uint32_t *)(GPIO_PORTA + 0X04)
#define GPIOA IDR *(volatile uint32 t *)(GPIO PORTA + 0x08)
#define GPIOA ODR *(volatile uint32 t *)(GPIO PORTA + 0x0C)
void Delay(int nCount);
int getPressureVal();
void Set Alarm actuator(int i);
void GPIO_INITIALIZATION ();
```

- Startup.c
- LinkerScript.ld
- Makefile

#### Section Table

#### - Driver.o

```
DELL@Peter-Moner MINGW32 /d/Embedded Systems K.S/UNIT 5/First_Te
 arm-none-eabi-objdump.exe -h driver.o
driver.o:
                file format elf32-littlearm
Sections:
                     Size
                                                          File off
Idx Name
                                  VMA
                                              I MA
                                                                       Algn
  0 .text
                     0000010c
                                  00000000
                                              00000000
                                                          00000034
                                                                       フェネフ
                                 ALLOC, LOAD, READONLY, CODE
00000000 00000000 0000014
                     CONTENTS,
                                                          00000140
                                                                       2**0
  1 .data
                     00000000
                     CONTENTS,
                                  ALLOC, LO
00000000
                                         LOAD, DATA
00 00000000
                     00000000
                                                          00000140
  2 .bss
                                                                       2**0
                     ALLOC
00000103
  3 .debug_info
                                  00000000
                                              00000000
                                                          00000140
                                                                       2**0
                                  RELOC, READONLY, DEBUGGING 00000000 00000000 00000000
                      CONTENTS,
                     0000009d
                                                          00000243
                                                                       2**0
  4 .debug_abbrev
                                  READONLY,
                     CONTENTS,
                                              DEBUGGING
  5 .debug_loc
                     000000c8
                                  00000000
                                              00000000
                                                          000002e0
                                                                       2**0
  CONTENTS,
6 .debug_aranges 00000020
                                 READONLY, DEBUGGING
00000000 00000000
                                              00000000
                                                           000003a8
                                                                        2**0
                     CONTENTS,
                                 RELOC, READONLY, DEBUGGING
00000000 00000000 000003c8
                     00000099
                                                                       2**0
  7 .debug_line
                                 RELOC, READONLY, DEBUGGING 00000000 00000000 00000000
                     CONTENTS,
                                                                       2**0
  8 .debug_str
                     0000012b
                                                          00000461
                     CONTENTS,
00000012
                                 READONLY,
                                              DEBUGGING
                                                          0000058c
  9 .comment
                                  00000000
                                              00000000
                                                                       2**0
 CONTENTS, I
10 .ARM.attributes 00000033
                                 READONLY
                                    00000000
                                                00000000
                                                            0000059e
                                                                         2**0
                     CONTENTS, READONLY
 11 .debug_frame
                     00000078
                                  00000000
                                              00000000
                                                          000005d4
                                                                       2**2
                     CONTENTS, RELOC, READONLY, DEBUGGING
```

#### - Main.o

```
DELL@Peter-Moner MINGW32 /d/Embedded Systems K.S/UNIT 5/First_Term
 arm-none-eabi-objdump.exe -h main.o
              file format elf32-littlearm
main.o:
Sections:
Idx Name
                                  VMA
                                                          File off
                     Size
                                              IMA
                                                                      Algn
                                                          00000034
                     00000048
  0 .text
                                  00000000
                                              00000000
                                                                       2**2
                                  ALLOC, LOAD, RELOC, 00000000 00000000
                     CONTENTS,
                                                          READONLY,
                                                                      CODE
                     00000000
                                                                       2**0
  1 .data
                                                          0000007c
                     CONTENTS,
                                  ALLOC, LOAD, DATA 00000000 00000000
  2 .bss
                     00000000
                                              00000000
                                                          0000007c
                                                                       2**0
                     ALLOC
  3 .debug_info
                     000000ad
                                  00000000
                                             00000000
                                                          0000007c
                                                                       2**0
                                  RELOC, READONLY, DEBUGGING 00000000 00000000 00000000 000001
                     CONTENTS,
                     0000005e
  4 .debug_abbrev
                                                          00000129
                                                                       2**0
                     CONTENTS,
                                  READONLY,
                                              DEBUGGING
  5 .debug_loc
                     00000038
                                  00000000
                                              00000000
                                                          00000187
                                                                       2**0
  CONTENTS, READONLY, DEBUGGING
6 .debug_aranges 00000020 00000000 00000000
                                                           000001bf
                                                                        2**0
                     CONTENTS,
                                 RELOC, READONLY, DEBUGGING 00000000 00000000 00000000 000001df
                     00000052
  7 .debug_line
                                                                       2**0
                                 RELOC, READONLY, DEBUGGING 00000000 00000000 00000000
                     CONTENTS,
  8 .debug_str
                     000000f8
                                                          00000231
                                                                       2**0
                     CONTENTS, READONLY, 00000012 00000000
                                              DEBUGGING
                                              00000000
                                                          00000329
                                                                       2**0
  9 comment
CONTENTS, READONLY
10 .ARM.attributes 00000033 000000
                                    00000000
                                               00000000
                                                            0000033b
                                                                        2**0
                     CONTENTS, READONLY
                     00000030
                                 00000000
                                             00000000 00000370
                                                                       2**2
 11 .debug_frame
                     CONTENTS, RELOC, READONLY, DEBUGGING
```

### - Startup.o

```
MINGW32 /d/Embedded Systems K.S/UNIT 5/First_Term
 arm-none-eabi-objdump.exe -h startup.o
startup.o:
                  file format elf32-littlearm
Sections:
                                                          File off
                                                                       Algn
2**2
Idx Name
                     Size
                                  VMA
                                              LMA
                     000000bc
  0 .text
                                  00000000
                                             00000000
                                                          00000034
                                  ALLOC, LOAD, RELOC,
                                                          READONLY,
                                                                      CODE
                     CONTENTS,
                     00000000
                                  00000000 00000000
                                                          000000f0
  1 .data
                                  ALLOC, LOAD, DATA
                     CONTENTS,
                                  00000000
                     00000000
                                              00000000
                                                          000000f0
  2 .bss
                                                                       2**0
                      ALLOC
                      0000001c
                                                          000000f0
  3 .vectors
                                  00000000
                                              00000000
                                  ALLOC, LOAD, RELOC, 00000000 00000000
                      CONTENTS,
                                                          DATA
                                                          0000010c
  4 .debug_info
                     00000182
                                                                       2**0
                                  RELOC, READONLY, DEBUGGING
00000000 00000000 000002
                      CONTENTS,
                                                                       2**0
  5 .debug_abbrev
                     000000cb
                                                          0000028e
                                  READONLY,
                     CONTENTS, 00000064
                                             DEBUGGING
  6 .debug_loc
                                  00000000
                                              00000000
                                                          00000359
                                                                       2**0
                     CONTENTS,
                                 READONLY, DEBUGGING 00000000 00000000
  7 .debug_aranges 00000020
                                                           000003hd
                                                                        2**0
                                 RELOC, READONLY, DEBUGGING
00000000 00000000 000003dd
                     CONTENTS,
0000007b
  8 .debug_line
                                                                       2**0
                     CONTENTS,
00000159
                                  RELOC, READONLY, DEBUGGING
00000000 00000000 00000458
  9 .debug_str
                                                                       2**0
                     CONTENTS,
00000012
                                  READONLY,
                                              DEBUGGING
                                  00000000
 10 .comment
                                              00000000
                                                          000005b1
 CONTENTS, I
11 .ARM.attributes 00000033
                                 READONLY
                                  00000000
                                                00000000 000005c3
                                                                         2**0
                     CONTENTS, READONLY
0000004c 00000000
 12 .debug_frame
                                             00000000 000005f8
                      CONTENTS, RELOC, READONLY, DEBUGGING
```

## - Pressure Dection System.elf

```
DELL@Peter-Moner MINGW32 /d/Embedded Systems K.S/UNIT 5/First_Term
 arm-none-eabi-objdump.exe -h Pressure_Detection_System.elf
                                      file format elf32-littlearm
Pressure_Detection_System.elf:
Sections:
                                                     File off
Idx Name
                   Size
                              VMA
                                          LMA
                                                                Algn
                              08000000
  0 .text
                    0000022c
                                         08000000
                                                     00008000
                                                                2**2
                   CONTENTS, ALLOC, LOAD, READONLY, CODE
  1 .debug_info
                   00000332
                              00000000 00000000
                                                     0000822c
                                                                2**0
                   CONTENTS, READONLY, DEBUGGING 000001c6 00000000 00000000 CONTENTS, READONLY, DEBUGGING 00000164 00000000 00000000
  2 .debug_abbrev 000001c6
                                                     0000855e
                                                                2**0
  3 .debug_loc
                                                     00008724
                                                                2**0
                   CONTENTS, READONLY, DEBUGGING
  4 .debug_aranges 00000060
                               00000000 00000000
                                                                 2**0
                                                      00008888
                    CONTENTS, READONLY, DEBUGGING
  5 .debug_line
                              00000000
                                                                2**0
                    00000166
                                          00000000
                                                     000088e8
                              READONLY,
                    CONTENTS,
                                         DEBUGGING
                              00000000
  6 .debug_str
                                                                2**0
                    0000019b
                                         00000000
                                                     00008a4e
                    CONTENTS, READONLY, DEBUGGING
  7 .comment
                    00000011
                              00000000
                                         00000000
                                                     00008be9
                                                                2**0
                   CONTENTS, READONLY
  8 .ARM.attributes 00000033 00000000
                                           00000000
                                                       00008bfa
                    CONTENTS, READONLY
  9 .debug_frame
                   000000f4
                              00000000
                                         00000000
                                                     00008c30 2**2
                    CONTENTS, READONLY, DEBUGGING
```

- Symbol Table
  - Individual files symbol table

```
DELL@Peter-Moner MINGW32 /d/Embedded
arm-none-eabi-nm.exe driver.o
00000000 T Delay
00000024 T getPressureVal
0000008c T GPIO_INITIALIZATION
0000003c T Set_Alarm_actuator
DELL@Peter-Moner MINGW32 /d/Embedded
$ arm-none-eabi-nm.exe main.o
              U Delay
              U getPressureVal
U GPIO_INITIALIZATION
T main
00000000
              U Set_Alarm_actuator
DELL@Peter-Moner MINGW32 /<mark>d/Embedded</mark>
$ arm-none-eabi-nm.exe startup.o
             U _E_bss
U _E_data
U _E_text
U _S_bss
U _S_data
              ш
                 _stack_top
000000b0 W Bus_Fault_Handler
000000b0 T Default_Handler
000000b0 W Hard_Fault_Handler
              U main
000000b0 W MM_Fault_Handler
000000b0 W NMI_Handler
00000000 T Reset_Handler
                 Reset_Handler
000000b0 W Usage_Fault_Handler
00000000 D vectors
```

- Pressure Dection System.elf

```
DELL@Peter-Moner MINGW32 /d/Embedded Systems K.S/UNIT 5
$ arm-none-eabi-nm.exe Pressure_Detection_System.elf
20000000 T _E_bss
200000000 T _E_data
0800022c T _E_rodata
0800022c T _E_text
20000000 T _S_bss
20000000 T _S_data

0800022c T _S_rodata


20001000 T _stack_top
080000cc W Bus_Fault_Handler
080000cc T Default_Handler
08000120 T Delay
08000144 T getPressureVal
080001ac T GPIO_INITIALIZATION
080000cc W Hard_Fault_Handler
080000d8 T main
080000cc W MM_Fault_Handler
080000cc W NMI_Handler
0800001c T Reset_Handler
0800015c T Set_Alarm_actuator
080000cc W Usage_Fault_Handler
08000000 T vectors
```

## • Map File

```
Memory Configuration
Name
                  Origin
                                      Length
                                                          Attribute
                                      0x00020000
                  0x08000000
FLASH
                                                          xr
SRAM
                  0x20000000
                                      0x00005000
                                                          xrw
*default*
                  0x00000000
                                      0xffffffff
Linker script and memory map
                 0x08000000
                                  0x22c
.text
 *(.vectors*)
 .vectors
                 00000080x0
                                   0x1c startup.o
                 0x08000000
                                            vectors
 *(.text)
                                   0xbc startup.o
 .text
                 0x0800001c
                 0x0800001c
                                             Reset Handler
                 0x080000cc
                                            MM Fault Handler
                 0x080000cc
                                             Bus_Fault_Handler
                 0x080000cc
                                             Default_Handler
                 0x080000cc
                                             Usage Fault Handler
                 0x080000cc
                                             Hard Fault Handler
                 0x080000cc
                                            NMI Handler
 .text
                 0x080000d8
                                   0x48 main.o
                 0x080000d8
                                            main
 .text
                 0x08000120
                                  0x10c driver.o
                 0x08000120
                                            Delav
                 0x08000144
                                             getPressureVal
                 0x0800015c
                                             Set Alarm actuator
                                             GPIO_INITIALIZATION
                 0x080001ac
                 0x0800022c
                                             . = \overline{ALIGN} (0x4)
                 0x0800022c
                                             _{\rm E\_text} = .
.data
                 0x20000000
                                     0x0 load address 0x0800022c
                 0x20000000
                                             . = ALIGN (0x4)
                                             _S_data = .
                 0x20000000
 *(.data*)
                 0x20000000
                                     0x0 startup.o
 .data
 .data
                 0x20000000
                                     0x0 main.o
 .data
                 0x20000000
                                     0x0 driver.o
                 0x20000000
                                             . = ALIGN (0x4)
                 0x20000000
                                             E data = .
.igot.plt
                 0x20000000
                                     0x0 load address 0x0800022c
 .igot.plt
                 0x00000000
                                     0x0 startup.o
                 0x0800022c
.rodata
                                     0 \times 0
                 0x0800022c
                                             . = ALIGN (0x4)
                 0x0800022c
                                             _S_rodata = .
 *(.rodata*)
                 0x0800022c
                                              . = ALIGN (0x4)
                 0x0800022c
                                             _{\rm E\_rodata} = .
                 0x20000000
.bss
                                     0x0
                 0x20000000
                                             . = ALIGN (0x4)
                 0x20000000
                                             _S_bss = .
 *(.bss*)
 .bss
                 0x20000000
                                    0x0 startup.o
                 0x20000000
 .bss
                                     0x0 main.o
                                     0x0 driver.o
                 0x20000000
 .bss
                 0x20000000
                                              = ALIGN (0x4)
 * (COMMON*)
                 0x20000000
                                              . = ALIGN (0x4)
                 0x20000000
                                             _E_bss = .
                                             = ALIGN (0x4)
                 0x20000000
                                             . = (. + 0x1000)
                 0x20001000
                 0x20001000
                                             stack\ top = .
```

## • Hardware Simulation

- AT pressure value < Predefined Threshold value



- AT pressure value >= Predefined Threshold value

