DESIGNING AN OPTIMIZED AIRFRAME

Nathan Pettit

1 Introduction

This report covers the research done in learning how airframes work, specifically how the shape of the airfoil affects airfoil polar, how the shape of the airframe affects airfoil polar, and how the efficiency of the airframe is related to all of this. The knowledge gained from this research was then used to design an airframe to solve a real world problem.

2 Airfoil Design

This section reviews research done on airfoils. There are 5 areas that are covered in this research. First, it explores the effect of airfoil angle of attack on lift, drag, and moment. Second, it compares data collected by Xfoil to experimental data. Third, it explores the effect of different Reynold's numbers on airfoil polar. Fourth, it explores the effect of airfoil thickness. And fifth, it explores the effect of airfoil camber. The results of this research came from evaluating airfoils using the Xfoil library in the Julia language.

2.1 Airfoil Angle of Attack

One of the most stressed parts of this research was seeing how different airfoil angles of attack affected the lift, drag, and moment on the airfoil. In order to see those relationships, only the coefficients of drag, lift, and moment needed to evaluated, rather than the moment and the forces of lift and drag. This is because those coefficients are dimensionless numbers. Figure 1 shows the relationships between lift, drag, and moment and α for a NACA 2412 airfoil.




Fig. 1: The coefficients of lift, drag, and moment plotted against angle of attack for a NACA 2412 airfoil.

The coefficients of lift (c_{ℓ}) and drag (c_d) both increase as angle of attack (α) increases, because as the angle increases, the pressure differential between the top and bottom of the airfoil becomes larger. This also increases coefficient of moment (c_m) . It is also important to note that figure 1 establishes that lift is negative when α is less than zero, which makes sense because the pressure differential goes from having greater pressure on the bottom (positive lift) to greater pressure on the top of the airfoil (negative lift). It can also be seen that the zero-lift angle of attack is somewhere between 0 and 0.5 degrees, which is where the lift changes from negative to positive. It appears that stall takes place at an angle of attack of about 10 degrees, which is where the angle of attack becomes too great for the airfoil to produce lift. This can be cleary seen on the lift and drag plots.

2.2 Airfoil Polar Comparison

The results gained from Xfoil were plotted against experimental data from a study done on the NACA 2412 airfoil (see figure 2).




Fig. 2: The comparison of data collected experimentally to data collected from Xfoil.

It is interesting to see that the experimental lift curve looks very similar to the one obtained from Xfoil, except shifted up. Also, the drag curves between experimental and Xfoil are very different. The reason for this is unknown, although it might be an error in Xfoil calculations.

2.3 Effect of Reynold's Number

The purpose of the Reynold's number is to compare inertial forces to viscous forces. It is an indicator of how viscous the fluid that an airfoil is traveling through is. A high Reynold's number is an indicator that fluid flow will be turbulent, where as a low Reynold's number is an indicator of laminar flow. In figure 3, the relationships between Reynold's number and the coefficients are shown.




Fig. 3: The lift, drag, and moments against angle of attack for varying Reynold's numbers.

As the Reynold's number increases, the lift curves become more steep. However, it is the opposite with drag and moment. As the Reynold's number increases, the curves of drag and moment become more leveled out. These results make logical sense, because whether with turbulent or laminar flow, lift generally is not affected significantly across varying angles of attack. On the other hand, higher Reynold's numbers and therefore more turbulent flow decreases the drag and moment at more extreme angles of attack (see figure 3).

2.4 Effect of Airfoil Thickness and Camber

The thickness of an airfoil is the greatest distance between the upper and the lower surfaces of an airfoil. In figure 4, the relationship between airfoil thickness and the coefficients of lift, drag, and moment can be seen.




Fig. 4: The ratio of lift to drag coefficients and coefficient of lift against angle of attack.

As the thickness of the airfoil increases, the ratio of lift to drag curve becomes more shallow. This is because increasing thickness leads to lift and drag becoming closer and closer to each other. It is interesting to see though that no matter the thickness, the zero lift angle of attack remains the same (see figure 4).

The camber of an airfoil is the asymmetry between the two acting surfaces of an airfoil. An airfoil with zero camber is symmetric. In figure 5, the effect of different cambers can be seen.




Fig. 5: The ratio of lift to drag coefficients and coefficient of lift against angle of attack.

As the camber of the airfoil increases, the lift to drag ratio becomes higher and the whole curve is shifted upwards. This also happened with the coefficient of lift. This also means that the zero lift angle of attack became greater with increasing camber.

3 Airframe Analysis

This section covers research done on airframes using the VortexLattice.jl library, specifically how aspect ratio and efficiency are related, how tail volume ratios affect stability derivatives, and how angle of attack affects the lift coefficient. The results of this research came from evaluating airframes using VortexLattice.jl.

3.1 Aspect Ratio vs. Efficiency

In order to see the relationship between aspect ratio and the efficiency, the wing_efficiency() function was used. When it was run, it calculated the inviscid span efficiency (see equation 1) for airframes with aspect ratios (see equation 2) ranging from 3 to 15.

$$e_{inv} = \frac{C_L^2}{\pi ARC_D} \tag{1}$$

$$AR = \frac{b}{c} = \frac{b^2}{S_{ref}} \tag{2}$$

After the program calculated the efficiency, it produced a plot shown in figure 6.




Fig. 6: The relationship between aspect ratio and inviscid span efficiency.

In reality, there is actually no physical relationship between an airframe's aspect ratio and its efficiency, but figure 6 does mathematically plot it correctly. However, that plot is simply the definition of inviscid span efficiency.

3.2 Tail Volume Ratios vs Stability Derivatives

Another characteristic of these airframes that was observed was their stability derivatives. Stability derivatives were calculated for airframes with different tail volume ratios, both vertical and horizontal. The definitions of those ratios are equations 3 and 4. The stability derivatives that are affected by a change in vertical tail volume ratio are $C_{\ell b}$ and C_{nb} . $C_{\ell b}$ is the stability derivative associated with roll stability. C_{nb} is the stability derivative associated with yaw stability. An airframe is stable if $C_{\ell b}$ is less than 0 and C_{nb} is greater than 0.

$$V_v = \frac{l_v S_v}{Sb} \tag{3}$$

$$V_{v} = \frac{l_{v}S_{v}}{Sb}$$

$$V_{h} = \frac{l_{t}S_{t}}{SC_{ma}}$$

$$(3)$$

In figure 7, we can see that the airframe is stable for vertical tail volume ratios greater than 0.003, but it becomes unstable when the ratio is less than 0.003, at around 0.002. The stability derivatives that are affected by a change in horizontal tail volume ratio are C_{La} and C_{ma} . An airframe is stable if C_{La} is greater than 0 and C_{ma} is less than 0. Figure 8 shows that the airframe is stable for horizontal tail volume ratios greater than 0.05, but becomes unstable when the ratio is less than 0.05, at around 0.025.




Fig. 7: This diagram shows the relationship between vertical tail volume ratio, $C_{\ell b}$, and C_{nb} .

, 9




Fig. 8: The relationship between horizontal tail volume ratio, C_{La} , and C_{ma} .

These ratios are arbitrary and will be different among models, but they are still extremely important.

3.3 Angle of attack vs lift coefficient

In previous research about airfoils, I found that as angle of attack increases, the lift coefficient also increases, up to a certain point. At that point, the lift coefficient sharply drops, and this is where stall takes place. In that previous research, Xfoil.jl was used to calculate the lift coefficient for varying angles of attack. A relationship between angle of attack and lift was also tried to be found here, but instead of using Xfoil.jl, VortexLattice.jl was used. A plot was produced showing the relationship between angle of attack and lift (see figure 9).




Fig. 9: The relationship between angle of attack and lift for an airframe.

In comparison to the plot created using Xfoil.jl (see figure 1), figure 9 looks very similar between angles of attack of -10 and 10. However, past those angles of attack is where it differs. In the Xfoil plot, it shows very clearly where stall would take place, but in this VortexLattice plot, the plot continues linearly and never drops off, never indicating stall. This is why the Vortex Lattice method is not always a great choice for investigating airframes. It is only accurate when the angle of attack is small, because it assumes that the flow is inviscid at all angles of attack. This is why in figure 9 it looks very linear and does not indicate where stall would take place, where as the Xfoil plot does.

4 Airframe Aerodynamic Design

This section discusses the designing of an airframe that can lift 0.5 kilograms, has a wingspan no greater than 1.5 meters, and is stable. In doing this, research done previously was employed. The results of this research came from evaluating potential airframe solutions using VortexLattice.jl.

In order to optimize the airframe, the process, discussed in the introduction to "Engineering Design Optimization" by Joaquim R.R.A. Martins and Andrew Ning, was followed. The objective function that was minimized was the equation used to calculate the velocity needed to produce the necessary lift to carry 0.5 kilograms (see equation 5).

$$V = \sqrt{\frac{L}{(0.5)(C_L)(\rho)(S_{ref})}}$$

$$\tag{5}$$

- \bullet L the lift needed to take off with 0.5 kilograms, in this case 4.905 N
- ρ the density of the air $(1.225 \ kg/m^3)$
- S_{ref} the reference area, in this case the wing area

The design variables that were altered in order to minimize that function was the mean aerodynamic chord length of the wing and the length from wing to tail on the airframe. The reason I chose these design variables was because I knew that the airframe that would generate the most lift would have the max wingspan possible (so in this case 1.5 m), and so altering the chord length would help me find the wing that needed the least speed to takeoff. I also chose the length from wing to tail as a design variable because I knew altering it would change how stable the airframe was.

However, as I worked with these design variables, it was discovered that the greater the length from wing to tail, the more stable the airframe. For this reason, I put an upper limit on that length to be 2.0 m, so that the found airframe would be realistic. I also put a constraint on the aspect ratio of the wing, which was that it had to be greater than 2.0. The way that I found the optimal airframe was I changed those design variables together, so that it found the airframe that took off at the least velocity, but was the most stable. The efficiency of the airframe with different wing taper ratios was also evaluated by plotting the lift coefficient distribution against the optimal distribution, which was a ellipse. The ideal taper ratio was the one that produced a lift coefficient distribution closest to that elliptical distribution. This was done so that the final airframe design not only optimized my objective function, but was also the most efficient design.

After running the optimize_airframe() function, it found that the most optimized airframe was one that had the following characteristics (figure 10 shows what the design looks like):

Span (m)	Mean Chord Length (m)	Wing to Tail Length (m)
1.5	0.7222	2

C _L	Wing Taper Ratio	Takeoff Velocity (m/s)
0.046166	1	12.6539

. 12




Fig. 10: The design of the optimized airframe.

The aforementioned necessary lift was 4.905 Newtons. This number was found by multiplying 0.5 kilograms by 9.81 m/s^2 , which is the acceleration due to gravity. It is also important to note that the optimize_airframe() function accounts for stability and makes sure that the airframe is the most stable, and so this airframe is the most stable one under the given constraints. In order to show that this airframe has been optimized, other airframes have been evaluated in order to show correctness.

4.1 Altered Mean Chord Length

When evaluating an airframe that has a mean chord length that is less than 0.7222 m (I used 0.6 m for comparison), it was found that the velocity needed to generate the necessary lift was 13.049496968197154 m/s, which is greater than than the velocity needed for the optimized airframe. This shows that airframes with smaller mean chord lengths are not more optimized, as they need a greater velocity to lift the 0.5 kilograms.




Fig. 11: The design of an airframe with a chord length of 0.6 m.

An airframe with a greater chord length was not evaluated for comparison, because of the constraint I put on the aspect ratio. 0.7222 m was the largest possible chord length that kept the aspect ratio of the wing greater than 2.0.

Plots showing the lift coefficient vs. angle of attack and drag coefficient vs. angle of attack for these 2 designs are given (see figure 12).




Fig. 12: The lift and drag coefficients for varying angles of attack for the 2 designs evaluated using different mean chord lengths.

4.2 Altered Length from Wing to Tail

When evaluating an airframe that has a length from wing to tail that is less than 2.0 m (I used 1.0 m), it was found that the velocity needed to generate the necessary lift does not change. However, the airframe is less stable as the yaw stability derivative (C_{nb}) is less than the yaw stability derivative for the optimized airframe. Therefore, as the length from wing to tail is decreased, the airframe becomes less stable.

Figures showing the lift and drag coefficients vs. angle of attack for the 2 designs are given (see figure 13).




Fig. 13: The lift and drag coefficient vs. angle of attack for the 2 designs evaluated.

Figure 14 shows the design of an airframe with a length from wing to tail of 1.0 m.




Fig. 14: The design of an airframe with a length from wing to tail of 1.0 m.

4.3 Altered Wing Taper

The wing taper ratio of an airframe is found using equation 6.

$$Taper\ Ratio = \frac{tip\ chord\ length}{base\ chord\ length} \tag{6}$$

When evaluating an airframe that has a wing taper ratio that is less than 1.0 (I used 0.5), it was found that the velocity needed to calculate the necessary lift was 13.215339717762241 m/s. While this is close to the velocity needed for the optimized airframe, it is still larger; therefore, it is not as optimal. This shows that as the wing taper ratio is decreased, the velocity needed to lift 0.5 kilograms increases, making it sub-optimal. You can also see that an airframe with a wing taper ratio of 1.0 has a lift coefficient distribution that is closer to the optimal elliptical distribution than the airframe with a wing taper ratio of 0.5 (see figures 15 and 16).




Fig. 15: The lift coefficient distribution for a taper ratio of 1.0 vs. the optimal elliptical distribution.




Fig. 16: The lift coefficient distribution for a taper ratio of 0.5 vs. the optimal elliptical distribution.

Plots showing the lift coefficients and drag coefficients vs. angle of attack for these 2 designs are given (see figure 17).




Fig. 17: The lift and drag coefficients for varying angles of attack for the 2 designs evaluated using different wing tip tapers

The design of an airframe with a wing taper ratio of 0.5 is shown in figure 18.




Fig. 18: The design of an airframe with a wing taper ratio of 0.5.

5 Conclusion

Here are some key findings from all of my research done on airframe design:

- Higher Reynolds numbers cause the lift curves to become more steep and the drag and moment curves to become more leveled out for an airfoil.
- As the thickness of the airfoil increases, the airfoil's ratio of lift to drag curve becomes more shallow. As the camber of the airfoil increases, the lift to drag ratio becomes higher and the whole curve is shifted upwards.
- The larger the tail of an airframe, the more stable it will be. However, bigger does not always mean better in this case.
- The Vortex Lattice Method for evaluating airframes in only accurate for small angles of attack, but is very powerful when used.
- The airframe that will generate the most lift will have a large wingspan and a large mean chord length. However, when designing an airframe, a lot more factors go into the design other than how much lift it produces.
- The most efficient airframe is one that has a wing taper ratio of 1.0, as it produces a lift coefficient distribution that is elliptical.