INSTRUCTIONS:

Fill out the hazard analysis and risk assessment below.

HA-001 should be for the lane departure warning function as discussed in the lecture.

HA-002 should be for the lane keeping assistance function as discussed in the lecture.

Then come up with your own situations and hazards for the lane assistance system. Fill in When finished, export your spreadsheet as a pdf file so that a reviewer can easily see your

Hazard ID				Situational Ana
	Operational Mode	Operational Scenario	Environmental Details	Situation Details
HA-001	OM03 - Normal driving	OS04 - Highway	EN06 - Rain (slippery road)	SD02 - High speed
HA-002	OM03 - Normal driving	OS05 - Mountain Pass	EN07 - Snow (slippery road)	SD01 - Low speed
HA-003	OM03 - Normal driving	OS04 - Highway	EN03 - Fog (degraded view)	SD02 - High speed
HA-004	OM03 - Normal driving	OS08 - Road with bump	EN05 - Cross-wind (lateral force)	SD02 - High speed

the HA-003 and HA-004 rows. work.

alysis			
Other Details (optional)	Item Usage (function)	Situation Description	Function
	IU01 - Correctly used	normal driving on a highway during rain with high speed and correctly used system.	Lane Departure Warning (LDW) function shall apply an oscillating steering torque to provide the driver with haptic feedback
	IU01 - Correctly used	normal driving on a hilly and snowy road	Lane Keeping Assistance (LKA) function shall apply the steering torque when active in order to stay in ego lane
	IU01 - Correctly used	normal driving on a highw during fog	Lane Keeping Assistance (LKA) function shall apply the steering torque when active in order to stay in ego lane
	IU01 - Correctly used	normal driving on a bumpy road	Lane Keeping Assistance (LKA) function shall apply the steering torque when active in order to stay in ego lane

	Hazard Identification		
Deviation	Deviation Details	Hazardous Event (resulting effect)	
DV04 - Actor effect is too much	The function applies an oscillating torque with too high torque.		
		EV00 - Collision with other vehicle	
DV13 - Sensor sensitivity is too	the camera does not see the lane marking anymore		
low		EV00 - Collision with other vehicle	
DV13 - Sensor sensitivity is too	the camera does not see the lane marking anymore		
iow		EV-05 - Front collision with ahead traffic	
DV11 - Actor effect is wrong	The car might leave the current lane due to the bumpy road combined with heavy lateral wind	EV-06 - Front collision with oncoming traffic	

Event Details	Hazardous Event Description	Exposure (of situation)
Due to the heavily oscillating steering wheel the driver could lose control and crash into another car.	too high oscillating torque	E3 - Medium probability
lane keeping not guaranteed by the item and therefore car crashes into oposing traffic	sensors not working properly	E1 - Very low probability
lanes and traffic in front can't be recognized properly anymore	sensors not working properly due to fog	E3 - Medium probability
collision with opposing traffic	Actors might not react quickly enough on sudden car movement	E1 - Very low probability

	Hazardous Event Classification		
Rationale	Severity	Rationale	Controllability
(for exposure)	(of potential harm)	(for severity)	(of hazardous event)
high speed while raining happens frequently	S3 - Life-threatening or fatal injuries	car crashes end often fatal	C3 - Difficult to control or uncontrollable
does not occur often	S3 - Life-threatening or fatal injuries	if the situation occurs ist fatal	C3 - Difficult to control or uncontrollable
does occur frequently	S2 - Severe and life- threatening injuries	severe crashes can occur	C3 - Difficult to control or uncontrollable
does not occur often	S2 - Severe and life- threatening injuries	severe crashes can occur	C3 - Difficult to control or uncontrollable

	Determination of ASIL and Safety Goals	
Rationale (for controllability)	ASIL Determination	Safety Goal
Especially during rain and high speed the driver will struggle to control the vehicle with too high oscillating torque	С	Limit the mgnitude and frequency of the oscillating torque
System does not react correctly anymore	А	System must switch off if lanes are not corrected by the camera. Responsibility needs to be passed to the driver.
System does not react correctly anymore	В	System must inform the driver that the senors are not working properly anymore, slow down and pass the responsibility to the driver
if the car suddenly deviates from the planned path, it is difficult for the LKA to keep the car in the lane	QM	The controlling unit / execution model needs to publish steering and acceleration values at least values every 30ms