

# 703308 VO High-Performance Computing Energy in HPC

Philipp Gschwandtner

#### Overview

#### motivation / indications

- supercomputers
- Green500 & accelerators

#### basics

- power & energy
- instrumentation, measurement and modeling
- control mechanisms


#### consequences & applications

multi-objective optimization, workload co-scheduling, MPI slack optimization, etc.


# Why is energy consumption relevant in HPC?

- ▶ Current No. 1 in Top500: El Capitan
  - > 30 MW of power
  - But how much is that?

- ▶ 78% Aurora supercomputer (No. 3 world-wide)
- ▶ 41% of Innsbruck
- 9x University of Innsbruck
- 4,5x University of Vienna



# Power consumption projected to 1 exaflop



https://www.hpcwire.com/2021/07/15/15-years-later-the-green500-continues-its-push-for-energy-efficiency-as-a-first-order-concern-in-hpc/

### TOP500 & Green500

Rank	System	Cores	Rmax (PFlop/s)	Rpeak (PFlop/s)	Power (kW)
1	El Capitan - HPE Cray EX255a, AMD 4th Gen EPYC 24C 1.8GHz, AMD Instinct MI300A, Slingshot-11, TOSS, HPE DOE/NNSA/LLNL United States	11,039,616	1,742.00	2,746.38	29,581
2	Frontier - HPE Cray EX235a, AMD Optimized 3rd Generation EPYC 64C 2GHz, AMD Instinct MI250X, Slingshot-11, HPE Cray OS, HPE D0E/SC/Oak Ridge National Laboratory United States	9,066,176	1,353.00	2,055.72	24,607
3	Aurora - HPE Cray EX - Intel Exascale Compute Blade, Xeon CPU Max 9470 52C 2.4GHz, Intel Data Center GPU Max, Slingshot-11, Intel DOE/SC/Argonne National Laboratory United States	9,264,128	1,012.00	1,980.01	38,698
4	Eagle - Microsoft NDv5, Xeon Platinum 8480C 48C 2GHz, NVIDIA H100, NVIDIA Infiniband NDR, Microsoft Azure Microsoft Azure United States	2,073,600	561.20	846.84	
5	HPC6 - HPE Cray EX235a, AMD Optimized 3rd Generation EPYC 64C 2GHz, AMD Instinct MI250X, Slingshot-11, RHEL 8.9, HPE Eni S.p.A. Italy	3,143,520	477.90	606.97	8,461


Rank	TOP500 Rank	System	Cores	Rmax (PFlop/ s)	Power (kW)	Energy Efficiency (GFlops/ watts)
1	222	JEDI - BullSequana XH3000, Grace Hopper Superchip 72C 3GHz, NVIDIA GH200 Superchip, Quad-Rail NVIDIA InfiniBand NDR200, ParTec/ EVIDEN EuroHPC/FZJ Germany	19,584	4.50	67	72.733
2	122	ROMEO-2025 - BullSequana XH3000, Grace Hopper Superchip 72C 3GHz, NVIDIA GH200 Superchip, Quad-Rail NVIDIA InfiniBand NDR200, Red Hat Enterprise Linux, EVIDEN ROMEO HPC Center - Champagne-Ardenne France	47,328	9.86	160	70.912
3	440	Adastra 2 - HPE Cray EX255a, AMD 4th Gen EPYC 24C 1.8GHz, AMD Instinct MI300A, Slingshot-11, RHEL, HPE Grand Equipement National de Calcul Intensif - Centre Informatique National de L'Enseignement Suprieur (GENCI-CINES)	16,128	2.53	37	69.098
4	155	Isambard-Al phase 1 - HPE Cray EX254n, NVIDIA Grace 72C 3.1GHz, <u>NVIDIA GH200</u> Superchip, Slingshot-11, HPE University of Bristol United Kingdom	34,272	7.42	117	68.835

### Why are we using accelerators?


- All top 10 systems above 10GFLOPS/Watt use accelerators
  - Nov '21 data

#### **Exceptions:**

- Fugaku: ARM-based, no accelerators
- Tianhe-2A: Matrix 2000 accelerators (128 core RISC CPUs)




# Power Efficiency of all Top 500 Systems




#### Market share

- Accelerator market share in HPC has been steadily increasing and will likely continue to do so
  - 10 out of top 10 on Green500 list (Nov. 2024)
- Application developers need to use accelerators to get high performance on modern systems



#### Market share cont'd

- Problem: No market competition
  - Nvidia is predominant
  - originally also Cell processor (Playstation 3!)
    and Intel Xeon Phi
  - disappeared since ~2015
  - right now (2024): AMD comeback, new Intel attempts
- Nvidia encourages using CUDA
  - vendor lock-in
- ▶ There are alternatives!
  - SYCL, ROCm/HIP, OpenMP, etc.






#### Disclaimer

- ▶ Yes, according to thermodynamics, there is no energy "consumption"
  - We are just efficiently converting electricity to heat
  - Computational result is a side-product
- We're still going to call it "power consumption" and "energy consumption" for practical purpose

### Power vs. energy

- Power is instantaneous, i.e. measured at a specific point in time
  - E.g. 10 W (watts)
  - does not have a time component
- energy is power over time  $(E = \int P)$ 
  - ▶ E.g. 10 Wh (watt-hours) or 36 kJ kiloJoules
  - Could be measured using analogue means
  - Often just power sampling  $(E \cong P_{avg} \times T)$ 
    - Often requires very high temporal resolution for reasonable accuracy




### Power consumption of integrated circuits

- $ightharpoonup P_{total} = P_{short-circuit} + P_{static} + P_{dynamic}$ 
  - $ightharpoonup P_{short-circuit}$ : Power due to short-circuit current during transistor switching
  - $ightharpoonup P_{static}$ : Power due to leakage current, increases with decreasing feature size
  - $P_{dynamic} = C \times F \times V^2 \times \alpha \approx F^3$ (C... capacitance, F... frequency, V... voltage,  $\alpha$ ... switching factor)
  - Frequency and voltage are tightly connected
    - ▶ Hence: Sometimes referred to as "cube rule"

# Power consumption of supercomputers

- Cores are not everything
  - Off-core entities: shared caches, memory controllers, system agents, etc.
  - Off-chip entities: RAM, mainboard, NIC, etc.
- Computing nodes are not everything
  - Network, storage, management, etc.
  - Cooling system
  - Lights, office equipment, etc.
- ▶ Efficiency measured via e.g. PUE Power Usage Effectiveness
  - Ratio of power required by supercomputer vs. power for its entire facility
  - ▶ E.g. SuperMUC-NG @ LRZ: PUE of 1.08
  - ▶ 10-20 years ago: PUEs as high as 2-3
    - Mostly caused by cooling overhead

# Supermuc-NG (Lenovo SD650 nodes, direct water cooling)





# Cooling technologies

#### Air cooling

easy to build and maintain, inefficient

#### Direct water cooling


- warm: "free air cooling", water is not actively chilled, inlet temperature up to 50° C, difficult to build and maintain, very efficient, only for cooler climates
- cold: water is actively chilled, difficult to build and maintain, semi-efficient, for warmer climates

#### Indirect cooling

cool hardware with air, cool air with water


#### Immersion cooling

VSC-3 ("the oil thing")




2020 survey among tier-0 and tier-1 HPC sites in Europe

# ESIF data center, NREL (PUE of 1.06)



NREL Data Center Energy Balance, From: 2020-11-27T06:00 To: 2020-11-29T23:59



Instrumentation, measurement & modeling


#### Measurement methods

#### Hardware instrumentation

- in-bound: data available directly at compute resource (e.g. on- or off-core register)
- out-of-bound: data available externally (e.g. via network interface)
  - Provided by vendor or self-made
  - Alternatively: wall socket measurements

#### Models and simulators

- Wattch, SimpleScalar, Sim-PowerCMP, CACTI, McPAT, GPUWATTCH, etc.
- Additional considerations: scalability & deployment of instrumentation hardware




# Out-of-bound examples



Voltech PM1000+



PowerMon2



PowerSensor 2

### Intel RAPL – Running Average Power Limit

- In-bound hardware method of monitoring and controlling power and energy
  - Available since Sandy Bridge (~2011)
  - Underlying model or measurement method depends on CPU microarchitecture
- Provides low-overhead measurements via model-specific registers (MSRs)
  - Directly provide energy consumption data in "energy units", model-dependent
    - E.g. Sandy Bridge: 15.3 μJ; Haswell: 61 μJ
  - Update once every 976 μs
  - Increase monotonically (similar to TSC register)
    - ▶ But only 32 bit! Overflows after some time, dependent on CPU stress
- Also supports controlling the hardware by power capping
  - ▶ E.g. "never exceed 43 watts"
  - Much more fine-grained than any OS/software mechanism

#### How to read Intel RAPL data

- Often requires root due to security implications
  - Reading MSRs requires raw register access to basically the entire CPU
  - Reading fine-grained energy/power data might enable side channel attacks
- Using the Linux kernel's perf\_event interface
  - Using perf and sudo
    - > sudo perf stat -a -e "power/energy-cores/" <your\_program\_goes\_here>
    - Alternative without root: requires a /proc/sys/kernel/perf\_event\_paranoid setting of less than 1
- Manually reading the MSRs (e.g. <a href="https://github.com/kentcz/rapl-tools">https://github.com/kentcz/rapl-tools</a>)
  - sudo modprobe msr && sudo chmod o+rw /dev/cpu/0/msr
  - > sudo setcap cap\_sys\_rawio+ep <measurement\_program>

#### Additional tools

#### Linux

- likwid: https://github.com/RRZE-HPC/likwid/wiki/Likwid-Powermeter
- powertop: <a href="https://github.com/fenrus75/powertop">https://github.com/fenrus75/powertop</a>
- perf: sudo perf stat -a -e "power/energy-cores/" <your\_program\_goes\_here>
- PAPI: <a href="https://icl.utk.edu/papi/">https://icl.utk.edu/papi/</a>
- nvidia-smi

#### Windows?

- Hwinfo, AIDA64, HWMonitor, PowerStrip, SpeedFan, ...
- Powercfg & windows energy estimation engine (E3), srumutil: <a href="https://devblogs.microsoft.com/sustainable-software/measuring-your-application-power-and-carbon-impact-part-1/?WT.mc\_id=green-8660-cxa">https://devblogs.microsoft.com/sustainable-software/measuring-your-application-power-and-carbon-impact-part-1/?WT.mc\_id=green-8660-cxa</a>
- Intel Power Gadget
- WSL1/2?

#### Mac

Intel Power Gadget, ... ?


#### Other vendors

- ▶ A lot of "RAPL-compatible" systems from other vendors
  - Doesn't really mean "compatible", RAPL is used as a deonym here
  - Just means there is a user-accessible interface for getting power or energy data
- ▶ In-bound: AMD CPUs (RAPL/APM), Apple M (?), etc.
- Out-of-bound: Nvidia (?), AMD GPUs (?), IBM (Amester), Sun (?), etc.
- Third-party: PowerMon, PowerPack, PowerInsight, etc.
  - Always out-of-bound

# DVFS – <u>Dynamic Voltage and Frequency Scaling</u>

- Hardware can operate at multiple clock frequency points
  - Usually requires to scale voltage along with frequency
  - Originally one frequency for all components, these days individual frequencies for cores, last-level cache, etc.
- ▶ Originally controlled in software by selecting next DVFS state ~30 ms latency
  - OS directly requests a so-called P-state by writing into a register
  - ▶ PCU halts CPU e.g. every few milliseconds, reads the requested & current P-state, acts accordingly
- Modern CPUs have much more autonomy in this
  - OS requests a certain range of frequencies, minimum QoS or maximum performance
  - ▶ CPU controls the actual setting in hardware (e.g. Intel SpeedShift, ~1 ms latency)
  - Required by AVX, Turbo and alike to work properly

# AVX Turbo Frequencies (Intel Xeon 8174)



### Green500 measurement methodology

- > 33 pages of definitions: measurement devices, topology, workload requirements, averaging, etc.
  - https://www.top500.org/static/media/uploads/methodology-2.0rc1.pdf
- Level 1 requires to measure
  - The entire "core" phase ≥1 minute, compute-nodes + measure or estimate network interconnect
  - Power and take the average
  - At least std::max({2 kW, 10% of the system, 15 nodes})
- ▶ Level 2
  - ▶ Level 1 + average power of full run, intermediate measurements (at least 10 averages in core phase)
  - Compute-node subsystem + measure or estimate all other subsystems
  - At least std::max({10 kW, 12% of the system, 15 nodes})
- Level 3
  - Level 2 but measure energy and compute average power consumption
  - ▶ Energy measurement resolution: 120 Hz for DC, 5 KHz for AC
  - ▶ Entire system (all components, all nodes, no extrapolations!)

#### Issues

#### Spatial resolution / topology

- E.g. Intel RAPL offers separate readings for entire package, cores and off-core entities (e.g. RAM controller or iGPU)
  - What about RAM? Mainboard? GPUs? Storage? Network?
- ▶ GPUs can draw up to 75 watts via PCIe, rest via ATX power connectors,
  - ▶ If no in-bound measurement available, you need PCIe riser cards

#### Temporal resolution and accuracy

- ▶ High-frequency CPU loads are hardly visible at the wall socket
- Resolution != accuracy
  - E.g. RAPL can have 15.3 μJ resolution but a mJ accuracy or worse


#### External conditions

- Temperature
- Measurement perturbation (often caused by high-frequency in-bound measurements)





# In-bound measurement perturbation on a i7-2600k (RAPL)




# Modeling Example

#### Lots of models available

- Some as simple as linear combination of performance counters
  - $E_{dynamic} = \sum \alpha_i c_i$
- All the way up to Support Vector Machines (SVEs), Deep Learning, etc.

# Energy consumption in nJ for IBM POWER7 FMA operations





# Multi-objective optimization

- We now have at least two objectives which are (partially) in conflict
  - Faster program execution (generally requires more power and energy)
  - Lower power or energy consumption (generally requires longer execution times)
- Two possible optimization approaches
  - Weight function to combine all objectives into a single one
    - ▶ E.g. EDP Energy Delay Product, also: ED²P, ED³P, PDP, ...
  - Alternatively use true multi-objective optimization, keeps flexibility
    - e.g. Pareto optimality


# Multi-objective optimization and Pareto optimality

#### Definition of Pareto set:

- For each point in the set, no other point "dominates" it (=is better in all objectives)
- Entails that it's impossible to improve one objective without worsening another objective

#### Superior to weighted approach

 Provide all configurations in the Pareto set to the user, choose dynamically according to current preferences




### MPI slack time optimization

- ▶ Recognize slack time in parallel applications
  - Wait states
  - Periods of extended memcopy operations or I/O
  - Even computation if not on the critical path
  - etc.


- Use DVFS to reduce energy footprint with minimal impact on wall time
  - ▶ Lots of work on that from 5-15 years ago

# Slack time optimization example



# Slack time optimization results


- Rizvandi et al. "Some Observations on Optimal Frequency Selection in DVFS—based Energy Consumption Minimization"
  - Simulations with 3000 randomly generated task graphs
  - ▶ Energy savings 10-20%



https://arxiv.org/ftp/arxiv/papers/1201/1201.1695.pdf


# Near-Threshold Voltage

- Idea: reduce voltage below safe operating levels
  - Near-threshold voltage computing (NTV/NTC)
  - Can still operate transistors, but at large clock frequency reductions
    - ► Slowdown of 5x-10x
    - Might produce computational errors



### Approximate Computing

- Idea: use NTV and mitigate slowdown with parallelism
  - Single, reliable core at super-threshold voltage
  - Several unreliable ones at near-threshold voltage (under the same power envelope!)
  - Switch cores depending on state of computation
- Investigate effects of bit flips in floating point data for converging algorithms (e.g. jacobi)



# Approximate Computing cont'd

- Idea: reduce voltage below safe operating levels
  - Near-threshold voltage computing (NTV/NTC)
  - Replace single, reliable core with several unreliable ones under the same power envelope
    - Speedup through parallelism results in energy savings
- Investigate effects of bit flips in floating point data for converging algorithms (e.g. jacobi)




Fig. 4: Relative energy and time savings of an unreliable, parallel run of Jacobi on 16 cores compared to a reliable, sequential one. The missing data at bits 55–62 denotes divergence.

### Additional Consequences

- Job Scheduling: Profile applications, compute roofline model, set optimal DVFS setting for consecutive runs
  - ▶ E.g. EAR Energy Aware Runtime (SLURM tool @ SuperMUC, LRZ, Germany)
- Influences load balancing & scheduling decisions
  - Data movement is expensive
  - Move tasks to location of data instead of data to location of tasks
- Stacked memory, processing-in-memory, etc.

### Open issues

- There is more than just energy and power
  - Carbon Usage Effectiveness (CUE)
  - Water Usage Effectiveness (WUE)
  - Space Usage Effectiveness (SpUE)
- There are too many metrics and many are inaccurate
  - Power Usage Effectiveness (PUE)
    - Partial PUE (pPUE)
  - Energy Reuse Effectiveness (ERE)
  - Energy Reuse Factor (ERF)

- The metrics are often flawed
  - e.g. PUE cannot be used to compare
    HPC sites in different climate zones
- There are diverging interests
  - Operator: minimize power/energy, maximize workload throughput
  - User: minimize wall time
  - Taxpayer/politicians: minimize costs

### Future developments and ideas

#### High-bandwidth memory (HBM)

Memory and computational units physically as close together as possible, minimize data transport distance

#### Fabrication size reduction

 Research in new designs and materials (away from silicon) to decrease below
 2 nm threshold

#### Special purpose hardware


- Accelerators (scientific computing, AI, etc.)
- FPGAs
- Custom hardware designs for domainspecific problems

#### Optical computing

- Use photons instead of electrons
- Various approaches in research, not clear yet if viable alternative


# Reversible computing and Landauer principle: the future?

- There's a lower theoretical limit ("Landauer limit") to energy consumption of computation
  - Irreversible computation (e.g. logical AND) erases information, hence must be accompanied by corresponding entropy increase (=heat) in a closed system
    - ▶ because thermodynamics ¯\\_(ツ)\_/¯
  - ▶ Landauer limit is approx. 0.0175 eV or 2.805 \* 10<sup>-21</sup> J at room temperature
  - We're currently still several orders of magnitude away from that...



# Reversible computing and Landauer principle: the future? cont'd

- Koomey's Law: The number of computations per joule doubles every 1.57 years
  - Coupled with Landauer limit: no more energy efficiency increase after 2080...
  - Also applies to quantum computing
- Solution: reversible computing
  - In theory, computing without losing information doesn't need to increase entropy, hence no heat



### Summary

- Energy is a hot topic in HPC
- ▶ Instrumentation and measurements got a lot easier over the past decade
  - Availability not an issue these days
  - Accuracy and granularity however is
- Discussed several research perspectives on the topic
  - Multi-objective optimization, slack time optimization, approximate computing, ...

#### Image Sources

- Voltech PM1000: <a href="https://www.voltech.com/media/8d8595acca6d01f/pm1000-user-manual-v14.pdf">https://www.voltech.com/media/8d8595acca6d01f/pm1000-user-manual-v14.pdf</a>
- ▶ Shunt transistor: <a href="https://articles.saleae.com/oscilloscopes/how-to-measure-current-with-an-oscilloscope">https://articles.saleae.com/oscilloscopes/how-to-measure-current-with-an-oscilloscope</a>
- PowerMon:

https://ieeexplore.ieee.org/abstract/document/5453824?casa\_token=Ax4\_mcUUF0IAAAAA:YFY5X2H6aCU2pMDs5gwvMqbvA28huJePfLkRDveibf6d1TKkKmvqXfgCVtyVz1nZCp\_z8-mIT9U

- PowerSensor 2:
  - https://ieeexplore.ieee.org/stamp/stamp.jsp?arnumber=8366941&casa\_token=T70QZiDS9F4AAAAA:002oYwOTJXaLIRj8as2ZAGQSmYUDeigrjd5 Mt-sAIGfegoz0NIH25rfXL1gsEM8mmM6WYtr6DdE
- ▶ PCle riser: <a href="https://www.igorslab.de/en/power-recording-graphics-card-power-supply-interaction-measurement/3/">https://www.igorslab.de/en/power-recording-graphics-card-power-supply-interaction-measurement/3/</a>
- ► Supermuc-NGn nodes: <a href="https://www.lenovo.com/us/en/p/servers-storage/servers/high-density/thinksystem-sd650-n-v2/77xx7dsd672?orgRef=https%253A%252F%252Fwww.google.com%252F">https://www.lenovo.com/us/en/p/servers-storage/servers/high-density/thinksystem-sd650-n-v2/77xx7dsd672?orgRef=https%253A%252F%252Fwww.google.com%252F</a>
- ▶ Intel Architecture Day Slide: <a href="https://download.intel.com/newsroom/2021/client-computing/intel-architecture-day-2021-presentation.pdf">https://download.intel.com/newsroom/2021/client-computing/intel-architecture-day-2021-presentation.pdf</a>
- ▶ Alder Lake Die Shots: https://www.reddit.com/r/intel/comments/qhbbow/10nm esf intel 7 alder lake die shot/