# **Machine-Level Programming I: Basics**

Lecture 4 September 27<sup>th</sup>, 2017

Jae W. Lee (<a href="mailto:jaewlee@snu.ac.kr">jaewlee@snu.ac.kr</a>)
Computer Science and Engineering
Seoul National University

**Slide credits**: [CS:APP3e] slides from CMU; [COD5e] slides from Elsevier Inc.

# **Today: Machine Programming I: Basics**

**Textbook: [CS:APP3e] 3.1-3.5** 

- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

# **Intel x86 Processors**

## Dominate laptop/desktop/server market

## Evolutionary design

- Backwards compatible up until 8086, introduced in 1978
- Added more features as time goes on

## Complex instruction set computer (CISC)

- Many different instructions with many different formats
  - But, only small subset encountered with Linux programs
- Hard to match performance of Reduced Instruction Set Computers (RISC)
- But, Intel has done just that!
  - In terms of speed. Less so for low power.

# Intel x86 Evolution: Milestones

Name Date Transistors MHz

■ 8086 1978 29K 5-10

First 16-bit Intel processor. Basis for IBM PC & DOS

1MB address space

■ 386 1985 275K 16-33

First 32 bit Intel processor, referred to as IA32

Added "flat addressing", capable of running Unix

■ Pentium 4E 2004 125M 2800-3800

First 64-bit Intel x86 processor, referred to as x86-64

■ Core 2 2006 291M 1060-3500

First multi-core Intel processor


■ Core i7 2008 731M 1700-3900

Four cores

# Intel x86 Processors, cont.

## Machine Evolution

<b>386</b>	1985	0.3M
Pentium	1993	3.1M
Pentium/MMX	1997	4.5M
PentiumPro	1995	6.5M
Pentium III	1999	8.2M
Pentium 4	2001	42M
Core 2 Duo	2006	291M



## Added Features

Core i7

Instructions to support multimedia operations

2008

Instructions to enable more efficient conditional operations

731M

- Transition from 32 bits to 64 bits
- More cores

# x86 Clones: Advanced Micro Devices (AMD)

## Historically

- AMD has followed just behind Intel
- A little bit slower, a lot cheaper

## Then

- Recruited top circuit designers from Digital Equipment Corp. and other downward trending companies
- Built Opteron: tough competitor to Pentium 4
- Developed x86-64, their own extension to 64 bits

## Recent Years

- Intel got its act together
  - Leads the world in semiconductor technology
- AMD had fallen behind, but is coming back!
  - Relies on external semiconductor manufacturer
  - AMD Ryzen (2017) demonstrates competitive performance

# Intel's 64-Bit History

- 2001: Intel Attempts Radical Shift from IA32 to IA64
  - Totally different architecture (Itanium)
  - Executes IA32 code only as legacy
  - Performance disappointing
- 2003: AMD Steps in with Evolutionary Solution
  - x86-64 (now called "AMD64")
- Intel Felt Obligated to Focus on IA64
  - Hard to admit mistake or that AMD is better
- 2004: Intel Announces EM64T extension to IA32
  - Extended Memory 64-bit Technology
  - Almost identical to x86-64!
- All but low-end x86 processors support x86-64
  - But, lots of code still runs in 32-bit mode

# **Today: Machine Programming I: Basics**

- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

# **Definitions**

- Architecture: (also ISA: instruction set architecture) The parts of a processor design that one needs to understand or write assembly/machine code.
  - Examples: instruction set specification, registers.
- Microarchitecture: Implementation of the architecture.
  - Examples: cache sizes and core frequency.


## Code Forms:

- Machine Code: The byte-level programs that a processor executes
- Assembly Code: A text representation of machine code

## Example ISAs:

- Intel: x86, IA32, Itanium, x86-64
- ARM: Used in almost all mobile phones

# **Assembly/Machine Code View**



## **Programmer-Visible State**


- PC: Program counter
  - Address of next instruction
  - Called "RIP" (x86-64)
- Register file
  - Heavily used program data
- Condition codes
  - Store status information about most recent arithmetic or logical operation
  - Used for conditional branching

## Memory

- Byte addressable array
- Code and user data
- Stack to support procedures

# **Turning C into Object Code**

- Code in files p1.c p2.c
- Compile with command: gcc -Og p1.c p2.c -o p
  - Use basic optimizations (-Og) [New to recent versions of GCC]
  - Put resulting binary in file p



# **Compiling Into Assembly**

## C Code (sum.c)

## **Generated x86-64 Assembly**

```
sumstore:
   pushq %rbx
   movq %rdx, %rbx
   call plus
   movq %rax, (%rbx)
   popq %rbx
   ret
```

## **Obtain with command**

```
gcc -Og -S sum.c
```

Produces file sum.s

Warning: Will get very different results due to different versions of gcc and different compiler settings.

# **Assembly Characteristics: Data Types**

- "Integer" data of 1, 2, 4, or 8 bytes
  - Data values
  - Addresses (untyped pointers)
- Floating point data of 4, 8, or 10 bytes
- Code: Byte sequences encoding series of instructions
- No aggregate types such as arrays or structures
  - Just contiguously allocated bytes in memory

# **Assembly Characteristics: Operations**

- Perform arithmetic function on register or memory data
- Transfer data between memory and register
  - Load data from memory into register
  - Store register data into memory
- Transfer control
  - Unconditional jumps to/from procedures
  - Conditional branches

# **Object Code**

## Code for sumstore

Total of 14 bytes

**Each instruction** 

1, 3, or 5 bytes

 $0 \times 0400595$ 

Starts at address

#### 0x0400595:

0x53

0x48

0x89

0xd3

0xe8

0xf2

0xff

0xff

0xff

0x48

0x89

0x03

0x5b

0xc3

## Assembler

- Translates .s into .o
- Binary encoding of each instruction
- Nearly-complete image of executable code
- Missing linkages between code in different files

## Linker

- Resolves references between files
- Combines with static run-time libraries
  - E.g., code for malloc, printf
- Some libraries are dynamically linked
  - Linking occurs when program begins execution

# **Machine Instruction Example**

0x40059e: 48 89 03

## C Code

Store value t where designated by dest

## Assembly

- Move 8-byte value to memory
  - Quad words in x86-64 parlance
- Operands:

t: Register %rax

dest: Register %rbx

\*dest: Memory M[%rbx]

## Object Code

- 3-byte instruction
- Stored at address 0x40059e

# **Disassembling Object Code**

## Disassembled

```
0000000000400595 <sumstore>:
 400595:
          53
                                  %rbx
                           push
 400596: 48 89 d3
                                  %rdx,%rbx
                           mov
 400599: e8 f2 ff ff ff
                           callq 400590 <plus>
 40059e: 48 89 03
                                  %rax, (%rbx)
                           mov
 4005a1:
          5b
                                  %rbx
                           pop
  4005a2: c3
                            reta
```

## Disassembler

```
objdump -d sum
```

- Useful tool for examining object code
- Analyzes bit pattern of series of instructions
- Produces approximate rendition of assembly code
- Can be run on either a .out (complete executable) or .o file

# **Alternate Disassembly**

## **Object**

## Disassembled

```
0 \times 0400595:
    0x53
    0x48
    0x89
    0xd3
    0xe8
    0xf2
    0xff
    0xff
    0xff
    0x48
    0x89
    0 \times 0.3
    0x5b
    0xc3
```

```
Dump of assembler code for function sumstore:

0x00000000000400595 <+0>: push %rbx

0x0000000000400596 <+1>: mov %rdx,%rbx

0x0000000000400599 <+4>: callq 0x400590 <plus>
0x000000000040059e <+9>: mov %rax,(%rbx)

0x000000000004005a1 <+12>:pop %rbx

0x0000000000004005a2 <+13>:retq
```

Within gdb Debugger

```
gdb sum disassemble sumstore
```

Disassemble procedure

```
x/14xb sumstore
```

Examine the 14 bytes starting at sumstore

# What Can be Disassembled?

```
% objdump -d WINWORD.EXE
WINWORD.EXE: file format pei-i386
No symbols in "WINWORD.EXE".
Disassembly of section .text:
30001000 <.text>:
30001000:
30001001:
               Reverse engineering forbidden by
30001003:
             Microsoft End User License Agreement
30001005:
3000100a:
```

- Anything that can be interpreted as executable code
- Disassembler examines bytes and reconstructs assembly source

# **Today: Machine Programming I: Basics**


- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

# x86-64 Integer Registers

%rax	%eax	% <b>r8</b>	%r8d
%rbx	%ebx	%r9	%r9d
%rcx	%ecx	%r10	%r10d
%rdx	%edx	%r11	%r11d
%rsi	%esi	%r12	%r12d
%rdi	%edi	%r13	%r13d
%rsp	%esp	%r14	%r14d
%rbp	%ebp	%r15	%r15d

Can reference low-order 4 bytes (also low-order 1 & 2 bytes)

# Some History: IA32 Registers



# Origin (mostly obsolete)

accumulate

counter

data

base

source index

destination index

stack pointer base pointer

# **Moving Data**

Moving Data

movq Source, Dest:

- Operand Types
  - Immediate: Constant integer data
    - Example: \$0x400, \$-533
    - Like C constant, but prefixed with \\$'
    - Encoded with 1, 2, or 4 bytes
  - Register: One of 16 integer registers
    - Example: %rax, %r13
    - But %rsp reserved for special use
    - Others have special uses for particular instructions
  - Memory: 8 consecutive bytes of memory at address given by register
    - Simplest example: (%rax)
    - Various other "address modes"

```
%rax
%rcx
%rdx
%rbx
%rsi
%rdi
%rsp
```

%rN		

%rbp

# movq Operand Combinations

```
Source Dest Src, Dest C Analog
```

Cannot do memory-memory transfer with a single instruction

# **Simple Memory Addressing Modes**

- Normal (R) Mem[Reg[R]]
  - Register R specifies memory address
  - Aha! Pointer dereferencing in C

```
movq (%rcx),%rax
```


- Displacement D(R) Mem[Reg[R]+D]
  - Register R specifies start of memory region
  - Constant displacement D specifies offset

```
movq 8(%rbp),%rdx
```

# **Example of Simple Addressing Modes**

```
void swap
   (long *xp, long *yp)
{
   long t0 = *xp;
   long t1 = *yp;
   *xp = t1;
   *yp = t0;
}
```

# void swap (long \*xp, long \*yp) { long t0 = \*xp; long t1 = \*yp; \*xp = t1; \*yp = t0; }




```
Register Value
%rdi xp
%rsi yp
%rax t0
%rdx t1
```

## Registers


%rdi	0x120
%rsi	0x100
%rax	
%rdx	

## **Memory**




## swap:

```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```



### swap:

```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```




```
swap:
    movq          (%rdi), %rax # t0 = *xp
    movq          (%rsi), %rdx # t1 = *yp
    movq          %rdx, (%rdi) # *xp = t1
```

%rax, (%rsi) # \*yp = t0


ret

movq



```
swap:
```

```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```



## swap:

```
movq (%rdi), %rax # t0 = *xp
movq (%rsi), %rdx # t1 = *yp
movq %rdx, (%rdi) # *xp = t1
movq %rax, (%rsi) # *yp = t0
ret
```

# **Simple Memory Addressing Modes**

- Normal (R) Mem[Reg[R]]
  - Register R specifies memory address
  - Aha! Pointer dereferencing in C

```
movq (%rcx),%rax
```

- Displacement D(R) Mem[Reg[R]+D]
  - Register R specifies start of memory region
  - Constant displacement D specifies offset

```
movq 8(%rbp),%rdx
```

# **Complete Memory Addressing Modes**

## Most General Form

D(Rb,Ri,S) Mem[Reg[Rb]+S\*Reg[Ri]+D]

D: Constant "displacement" 1, 2, or 4 bytes

Rb: Base register: Any of 16 integer registers

Ri: Index register: Any, except for %rsp

• S: Scale: 1, 2, 4, or 8 (*why these numbers?*)

## Special Cases

(Rb,Ri) Mem[Reg[Rb]+Reg[Ri]]

D(Rb,Ri) Mem[Reg[Rb]+Reg[Ri]+D]

(Rb,Ri,S) Mem[Reg[Rb]+S\*Reg[Ri]]

# **Address Computation Examples**

%rdx	0xf000
%rcx	0x0100

Expression	Address Computation	Address
0x8(%rdx)	0xf000 + 0x8	0xf008
(%rdx,%rcx)	0xf000 + 0x100	0xf100
(%rdx,%rcx,4)	0xf000 + 4*0x100	0xf400
0x80(,%rdx,2)	2*0xf000 + 0x80	0x1e080

# **Today: Machine Programming I: Basics**

- History of Intel processors and architectures
- C, assembly, machine code
- Assembly Basics: Registers, operands, move
- Arithmetic & logical operations

# **Address Computation Instruction**

## leaq Src, Dst

- Src is address mode expression
- Set Dst to address denoted by expression

## Uses

- Computing addresses without a memory reference
  - E.g., translation of p = &x[i];
- Computing arithmetic expressions of the form x + k\*y
  - k = 1, 2, 4, or 8

## Example

```
long m12(long x)
{
   return x*12;
}
```

## Converted to ASM by compiler:

```
leaq (%rdi,%rdi,2), %rax # t <- x+x*2
salq $2, %rax # return t<<2</pre>
```

# **Some Arithmetic Operations**

## **■ Two Operand Instructions:**

Format	Computation		
addq	Src,Dest	Dest = Dest + Src	
subq	Src,Dest	Dest = Dest – Src	
imulq	Src,Dest	Dest = Dest * Src	
salq	Src,Dest	Dest = Dest << Src	Also called shlq
sarq	Src,Dest	Dest = Dest >> Src	Arithmetic
shrq	Src,Dest	Dest = Dest >> Src	Logical
xorq	Src,Dest	Dest = Dest ^ Src	
andq	Src,Dest	Dest = Dest & Src	
orq	Src,Dest	Dest = Dest   Src	

- Watch out for argument order!
- No distinction between signed and unsigned int (why?)

# **Some Arithmetic Operations**

## One Operand Instructions

```
incq Dest Dest = Dest + 1

decq Dest Dest = Dest - 1

negq Dest Dest = - Dest

notq Dest Dest = ^{\sim}Dest
```

See book for more instructions

# **Arithmetic Expression Example**

```
long arith
(long x, long y, long z)
{
  long t1 = x+y;
  long t2 = z+t1;
  long t3 = x+4;
  long t4 = y * 48;
  long t5 = t3 + t4;
  long rval = t2 * t5;
  return rval;
}
```

```
arith:
  leaq (%rdi,%rsi), %rax
  addq %rdx, %rax
  leaq (%rsi,%rsi,2), %rdx
  salq $4, %rdx
  leaq 4(%rdi,%rdx), %rcx
  imulq %rcx, %rax
  ret
```

## **Interesting Instructions**

- leaq: address computation
- salq: shift
- imulq: multiplication
  - But, only used once

# Understanding Arithmetic Expression Example

```
long arith
(long x, long y, long z)
  long t1 = x+y;
  long t2 = z+t1;
  long t3 = x+4;
  long t4 = y * 48;
  long t5 = t3 + t4;
  long rval = t2 * t5;
  return rval;
```

```
arith:
  leaq (%rdi,%rsi), %rax # t1
  addq %rdx, %rax # t2
  leaq (%rsi,%rsi,2), %rdx
  salq $4, %rdx # t4
  leaq 4(%rdi,%rdx), %rcx # t5
  imulq %rcx, %rax # rval
  ret
```

Register	Use(s)
%rdi	Argument x
%rsi	Argument <b>y</b>
%rdx	Argument <b>z</b>
%rax	t1, t2, rval
%rdx	t4
%rcx	t5

# **Machine Programming I: Summary**

## History of Intel processors and architectures

Evolutionary design leads to many quirks and artifacts

## C, assembly, machine code

- New forms of visible state: program counter, registers, ...
- Compiler must transform statements, expressions, procedures into low-level instruction sequences

## Assembly Basics: Registers, operands, move

 The x86-64 move instructions cover wide range of data movement forms

## Arithmetic

 C compiler will figure out different instruction combinations to carry out computation