Project Scheme Documentation

Document information

Association Name, WG	KNX ASSOCIATION
Author(s):	KNX & DEV
Status:	Valid
Version:	1.0.0
Date:	22.03.2019
Document file name:	Project Scheme20 v01.00.00.docx
Number of pages:	61

Acronyms

DEV	KNX Development subcontractors
KNX	KNX Association
MT5	KNX Manufacturer Tool 5

Referenced documents

[XSD]	XML scheme (KNX-Project-Scheme-v20.xsd. part of KNX MT5 → Version 5.7)
[DS]	XML DSIG documentation (xmldsig-core-schemescheme.xsd)

List of Changes

Version	Date	Maturity	Author	Description
1.0.0	22.03.2019	Valid	KNX Association	 Initial public version, derived from KNX internal version 0.93, for XML scheme 2.0 (ETS5) → Version 5.7

Disclaimer

The document is subject to change without prior notice. KNX Association SHALL IN ANY CASE NOT BE LIABLE FOR DIRECT AND INDIRECT DAMAGES ARISING FROM incorrect or missing descriptions in this document, especially when basing software and or hardware developments on the content of this document.

Contents

1	Overview	4
	1.1 Document Purpose	4
	1.2 Extended Import Restrictions	4
	1.3 Extended Import Checks	4
	1.4 Validity	4
	1.5 Namespaces	5
2	XSD Scheme File & KNX Master Data File	5
3	Elements, Types and Attributes	6
	1.1 General	6
	1.1.1 element KNX	6
	1.1.2 Enumerations	6
	1.1.3 Other simpleTypes	25
	1.2 Project Data	31
	1.2.1 element KNX/Project	31
	1.2.2 complexType Project_t	32
	1.2.3 General	33
	1.2.4 Topology	37
	1.2.5 Device Data	40
	1.2.6 Building Structure	51
	1.2.7 Group Addresses	56
	1.2.8 SplitInfos	58
4	Transfer files	59
	4.1 File extensions	60
	4.2 Content	60
	4.2.1 Non-XML files	60
	4.2.2 Distribution to partial XML files	60
	4.2.3 Naming convention	61
	4.2.4 Password protection	61

1 Overview

With introduction of ETS4, the ETS4 and ETS5 ex/- import format for KNX projects and products changed to a standard XML based format (by ETS4/5 exported projects have the file extension *.knxproj).

1.1 Document Purpose

This document describes all necessary elements, types and attributes of the KNX XML Scheme [XSD] for an ETS5 created project. All other –for the project scope not relevant - elements/ attributes might be missing or simply only listed (but not described).

The main use case is to read in (import) ETS5 projects into external tools (e.g. visualizations), but another use case might be to create an ETS5 project from scratch and later import into ETS5 (import is however restricted).

The document does not describe how manufacturers create and define products (parameter and/or Group Object dependencies and their visibility in correlation with download image creation) to compile valid device configurations outside ETS5. The KNX MT5 exclusively handles this task.

1.2 Extended Import Restrictions

ETS will import projects only from a trusted source, which means:

- 1. The project originates (exported) from ETS itself
- 2. The project originates from a KNX member (and only products of this member are contained in the project)

This is done via a dedicated project signature, in case of 2 the KNX manufacturer shall obtain a unique signature. This implies that an 'unreliable' project import from a source not trusted by ETS - is not possible!

Extended import restrictions implemented in the ETS 4.1/4.2 and ETS 5.0/ETS 5.7.

1.3 Extended Import Checks

The ETS5 check on import if a project is valid as regards conformance to the XML conformity (syntax check), i.e. the ETS5 checks if the project format is correct. ETS5 does not check if the saved data inside the file (normally a project/ installation) is a valid project/ installation configuration (semantic check), e.g. if such a project is semantically valid1.

Hence, it is expected that saved projects & configurations are valid as regards ETS project and installation data integrity.

1.4 Validity

This XML documentation refers to XML scheme version 2.0 (as currently implemented in ETS 5.7).

¹ This validity covers things such as KNX project settings used and processed by ETS up to any manufacturer device configuration (with its communication object/ parameter dependencies and visibilities).

1.5 Namespaces

The "targetNamespace" is defined as "http://knx.org/xml/project/20"; the prefix knx is used here. The scheme references the name spaces http://www.w3.org/2001/XMLScheme (prefix xs).

2 XSD Scheme File & KNX Master Data File

The KNX XML scheme is normally defined and described in a file with file extension *.xsd. This file is not part of an ETS5 installation, but of MT5 (the MT5 purpose is to build/compile valid KNX products and therefore it uses the XML scheme as a basis).

The KNX master data contains data definitions, which describe basic KNX system properties as data point types, manufacturer IDs and other things. This data is mandatory for any KNX project and product description. The file normally has the file extension *.xml, the current name is knx master.xml.

For valid owners of the MT (KNX members) it is allowed to use and distribute the KNX XML scheme and the KNX master data file as part of their own tool chain without any legal restrictions. When this KNX XML scheme or the KNX master data is updated, it lies within the responsibility of the tool owner to keep his own tool chain up to date.

The information on any update of KNX XML scheme will be provided by KNX a few months prior to the official availability of the scheme.

The KNX master data will be updated in ETS on demand (online update capability), the corresponding version can be seen in the ETS overview screen.

3 Elements, Types and Attributes

1.1 General

1.1.1 element KNX

Description	Root element	Root element of the XML document.					
Children	Name	De	scription				
	MasterData	<u>.</u> Glo	obal data	created a	and administered by the KNX Association.		
	Manufactur	ManufacturerData Data created and administered by the KNX manufacturers.					
	<u>Project</u>	roject Any number of projects.					
Attributes	Name	Туре	Use	Default	Description		
	CreatedBy	eatedBy xs:string optional The tool that created this XML file may include its name here. ETS will write "ETS4".					
	ToolVersion	xs:string	optiona	Į	The tool that created this XML file may include its version here. ETS4 will write "4.0.xxxx.zzzzz" (xxxx is the build number, zzzzz is the changeset).		

1.1.2 Enumerations

1.1.2.1 simpleType Access_t

restriction of xs:string
This enumeration encodes the rights for the ETS user to view and modify parameters.
enumeration None
enumeration Read
enumeration ReadWrite

${\bf 1.1.2.2} \quad simple Type \ Group Address Style_t$

Type	restriction of xs:string
1 9 00	Total Guille of Asia and San Carlotte of Asia

Description	This enumeration contains the different types of representations of group addresses in ETS4. 2-level and 3-level style are also available in ETS3, the free group address structure is new to ETS4.
Facets	enumeration TwoLevel
	enumeration ThreeLevel
	enumeration Free

1.1.2.3 simpleType SpaceType_t

Туре	restriction of xs:string
Description	This enumeration contains the different types of availablespaces in the ETS5.
Facets	enumeration Building
	enumeration BuildingPart
	enumeration Floor
	enumeration Stairway
	enumeration Room
	enumeration Corridor
	enumeration DistributionBoard
	enumeration Area
	enumeration Ground
	enumeration Segment

1.1.2.4 simpleType ComObjectPriority_t

Туре	restriction of xs:string
Description	This enumeration lists the possible transmission priorities available in the KNX protocol.
Facets	enumeration Low
	enumeration High
	enumeration Alert

1.1.2.5 simpleType ComObjectSize_t

Туре	restriction of xs:string
Description	This enumeration lists the possible data sizes for KNX group communication.
Facets	enumeration 1 Bit
	enumeration 2 Bit
	enumeration 3 Bit
	enumeration 4 Bit
	enumeration 5 Bit
	enumeration 6 Bit
	enumeration 7 Bit
	enumeration 1 Byte
	enumeration 2 Bytes
	enumeration 3 Bytes
	enumeration 4 Bytes
	enumeration 5 Bytes
	enumeration 6 Bytes
	enumeration 7 Bytes
	enumeration 8 Bytes
	enumeration 9 Bytes
	enumeration 10 Bytes
	enumeration 11 Bytes
	enumeration 12 Bytes
	enumeration 14 Bytes
	enumeration LegacyVarData
	enumeration 13 Bytes
	enumeration 15 Bytes
	enumeration 16 Bytes
	enumeration 17 Bytes

enumeration 18 Bytes enumeration 19 Bytes enumeration 20 Bytes enumeration 21 Bytes enumeration 22 Bytes enumeration 23 Bytes enumeration 24 Bytes enumeration 25 Bytes enumeration 26 Bytes enumeration 27 Bytes enumeration 28 Bytes enumeration 29 Bytes enumeration 30 Bytes enumeration 31 Bytes enumeration 32 Bytes enumeration 33 Bytes enumeration 34 Bytes enumeration 35 Bytes enumeration 36 Bytes enumeration 37 Bytes enumeration 38 Bytes enumeration 39 Bytes enumeration 40 Bytes enumeration 41 Bytes enumeration 42 Bytes enumeration 43 Bytes enumeration 44 Bytes enumeration 45 Bytes enumeration 46 Bytes enumeration 47 Bytes enumeration 48 Bytes

enumeration	49 Bytes
enumeration	50 Bytes

1.1.2.6 simpleType CompletionStatus_t

Туре	restriction of xs:string
Description	Several elements contain a completion status attrubute which might have one of the following values:
Facets	enumeration Undefined
	enumeration Editing
	enumeration FinishedDesign
	enumeration FinishedCommissioning
	enumeration Tested
	enumeration Accepted
	enumeration Locked

1.1.2.7 simpleType Enable_t

Туре	restriction of xs:string
Description	This enumeration is used for the group object communication flags.:
Facets	enumeration Enabled enumeration Disabled

${\bf 1.1.2.8} \quad simple Type \ LdCtrlControlVariable_t$

Туре	restriction of xs:string
Description	This enumeration lists the internal variables accessible from the <u>LdCtrlSetControlVariable</u> element

Facets	enumeration EnableSegmentWrite
	enumeration EnableVerifyOnWriteDirect
	enumeration EnableOptimisticWrite
	enumeration EnableMemoryAutoVerify

${\bf 1.1.2.9} \quad simple Type \ LdCtrlMemAddr Space_t$

Туре	restriction of xs:string
Description	This enumeration lists the memory address spaces available in several memory-related LdCtrl* elements
Facets	enumeration Standard
	enumeration User
	enumeration LcSlave
	enumeration LcFilter

1.1.2.10 simpleType LdCtrlProcType_t

Туре	restriction of xs:string
Description	This enumeration contains the possible values for the AppliesTo attribute of the LdCtrl* elements.
Facets	enumeration full
	enumeration par
	enumeration grp
	enumeration full,par
	enumeration full,grp
	enumeration par,grp
	enumeration all
	enumeration auto

1.1.2.11 simpleType LoadProcedureStyle_t

Туре	restriction of xs:string
Description	ETS supports three different mechanism to specify a device load procedure
Facets	enumeration DefaultProcedure
	enumeration ProductProcedure
	enumeration MergedProcedure

1.1.2.12 simpleType LdCtrlErrorCause_t

Туре	restriction of xs:string
Description	Used to provide richer error messages to the ETS user if something fails during download. A plugin is no longer required fot this information.
Facets	enumeration ResourceNotFound enumeration CompareMismatch

1.1.2.13 simpleType MemoryType_t

Туре	restriction of xs:string
Description	List of memory technologies
Facets	enumeration RAM
	enumeration EEPROM
	enumeration FLASH

1.1.2.14 simpleType ProcedureType_t

Туре	restriction of xs:string
Description	List of device configuration procedures

Facets	enumeration Load
	enumeration Unload

1.1.2.15 simpleType PropType_t

Туре	restriction of xs:string
Description	List of interface object property types
Facets	enumeration PDT_CONTROL
	enumeration PDT_CHAR
	enumeration PDT_UNSIGNED_CHAR
	enumeration PDT_INT
	enumeration PDT_UNSIGNED_INT
	enumeration PDT_KNX_FLOAT
	enumeration PDT_DATE
	enumeration PDT_TIME
	enumeration PDT_LONG
	enumeration PDT_UNSIGNED_LONG
	enumeration PDT_FLOAT
	enumeration PDT_DOUBLE
	enumeration PDT_CHAR_BLOCK
	enumeration PDT_POLL_GROUP_SETTINGS
	enumeration PDT_SHORT_CHAR_BLOCK
	enumeration PDT_DATE_TIME
	enumeration PDT_VARIABLE_LENGTH
	enumeration PDT_GENERIC_01
	enumeration PDT_GENERIC_02
	enumeration PDT_GENERIC_03
	enumeration PDT_GENERIC_04
	enumeration PDT_GENERIC_05

```
enumeration PDT_GENERIC_06
enumeration PDT_GENERIC_07
enumeration PDT_GENERIC_08
enumeration PDT_GENERIC_09
enumeration PDT_GENERIC_10
enumeration PDT_GENERIC_11
enumeration PDT_GENERIC_12
enumeration PDT_GENERIC_13
enumeration PDT_GENERIC_14
enumeration PDT_GENERIC_15
enumeration PDT_GENERIC_16
enumeration PDT_GENERIC_17
enumeration PDT_GENERIC_18
enumeration PDT_GENERIC_19
enumeration PDT_GENERIC_20
enumeration PDT_UTF-8
enumeration PDT_VERSION
enumeration PDT_ALARM_INFO
enumeration PDT_BINARY_INFORMATION
enumeration PDT_BITSET8
enumeration PDT_BITSET16
enumeration PDT_ENUM8
enumeration PDT_SCALING
enumeration PDT_NE_VL
enumeration PDT_NE_FL
enumeration PDT_FUNCTION
```

1.1.2.16 simpleType ResourceName t

Type restriction of xs:string

Facets enumeration enumeration cumeration operations and commentation enumeration enumerat	Cription List of management resource names; see also RESOURCEID in the eteC SDK documentation [SDK]	Description
enumeration DeviceBusVoltage cnumeration GroupAddressTableLoadControl enumeration GroupAddressTableLoadStatus enumeration GroupAddressTablePtr enumeration GroupAddressTableLoadControl enumeration GroupAddressTableLoadControl enumeration GroupAssociationTableLoadControl enumeration GroupAssociationTableLoadStatus enumeration GroupAssociationTableDtr enumeration GroupAssociationTablePtr enumeration GroupAssociationTablePtr enumeration GroupObjectTablePtr enumeration GroupObjectTablePtr enumeration GroupObjectTablePtr enumeration GroupFilterTablePtr enumeration ApplicationId enumeration ApplicationId enumeration ApplicationLoadControl enumeration ApplicationLoadControl enumeration ApplicationRunControl enumeration ApplicationRunStatus enumeration PeiprogLoadCoatrol enumeration PeiprogLoadCoatrol enumeration PeiprogLoadStatus	Facets enumeration ManagementStyle	Facets
enumeration cnumeration cnumer	enumeration DeviceManufacturerId	
enumeration cnumeration cnumer	enumeration DeviceBusVoltage	
enumeration enumeration cnumeration cnumer	enumeration DevicePeiType	
enumeration enumer	enumeration GroupAddressTableLoadControl	
enumeration enumer	enumeration GroupAddressTableLoadStatus	
enumeration GroupAssociationTableLoadStatus enumeration GroupAssociationTablePtr enumeration GroupAssociationTable enumeration GroupAssociationTable enumeration GroupObjectTablePtr enumeration GroupObjectTablePtr enumeration GroupFilterTable enumeration GroupFilterTable enumeration ApplicationI.oadControl enumeration ApplicationRunControl enumeration PeiprogLoadControl enumeration PeiprogRunControl enumeration PeiprogRunControl	enumeration GroupAddressTablePtr	
enumeration GroupAssociationTableLoadStatus enumeration GroupAssociationTablePtr enumeration GroupObjectTablePtr enumeration GroupObjectTablePtr enumeration GroupObjectTablePtr enumeration GroupFilterTablePtr enumeration GroupFilterTable enumeration ApplicationLoadControl enumeration ApplicationRunControl enumeration ApplicationRunControl enumeration PeiprogLoadControl enumeration PeiprogLoadStatus enumeration PeiprogLoadStatus enumeration PeiprogLoadStatus enumeration PeiprogLoadStatus enumeration PeiprogLoadStatus	enumeration GroupAddressTable	
enumeration croupAssociationTablePtr enumeration croupObjectTablePtr enumeration croupObjectTablePtr enumeration croupFilterTablePtr enumeration enumeration enumeration croupFilterTable enumeration enumeration enumeration croupFilterTable enumeration enumeration enumeration croupFilterTable enumeration enumeration ApplicationLoadControl enumeration enu	enumeration GroupAssociationTableLoadControl	
enumeration enumer	enumeration GroupAssociationTableLoadStatus	
enumeration GroupObjectTablePtr enumeration GroupFiterTablePtr enumeration GroupFiterTablePtr enumeration GroupFiterTable enumeration ApplicationLoadControl enumeration ApplicationLoadStatus enumeration ApplicationRunControl enumeration ApplicationRunControl enumeration ApplicationRunControl enumeration PeiprogId enumeration PeiprogLoadControl enumeration PeiprogLoadStatus enumeration PeiprogRunControl	enumeration GroupAssociationTablePtr	
enumeration GroupObjectTable enumeration GroupFilterTablePtr enumeration GroupFilterTable enumeration ApplicationId enumeration ApplicationLoadControl enumeration ApplicationLoadStatus enumeration ApplicationRunControl enumeration ApplicationRunControl enumeration ApplicationRunControl enumeration ApplicationRunControl enumeration PeiprogLoadControl enumeration PeiprogLoadControl enumeration PeiprogLoadStatus enumeration PeiprogRunControl	enumeration GroupAssociationTable	
enumeration GroupFilterTablePtr enumeration GroupFilterTable enumeration ApplicationId enumeration ApplicationLoadControl enumeration ApplicationRunControl enumeration enumeration enumeration enumeration Peiprogld enumeration enumeration enumeration PeiprogLoadControl enumeration PeiprogLoadControl enumeration PeiprogRunControl	enumeration GroupObjectTablePtr	
enumeration GroupFilterTable enumeration ApplicationId enumeration ApplicationLoadControl enumeration ApplicationLoadStatus enumeration ApplicationRunControl enumeration ApplicationRunStatus enumeration PeiprogId enumeration PeiprogLoadControl enumeration PeiprogLoadStatus enumeration PeiprogLoadStatus enumeration PeiprogRunControl	enumeration GroupObjectTable	
enumeration ApplicationId enumeration ApplicationLoadControl enumeration ApplicationLoadStatus enumeration ApplicationRunControl enumeration ApplicationRunControl enumeration PeiprogId enumeration PeiprogLoadControl enumeration PeiprogLoadStatus enumeration PeiprogLoadStatus enumeration PeiprogRunControl		
enumeration ApplicationLoadControl enumeration ApplicationLoadStatus enumeration ApplicationRunControl enumeration ApplicationRunStatus enumeration PeiprogId enumeration PeiprogLoadControl enumeration PeiprogLoadStatus enumeration PeiprogRunControl	enumeration GroupFilterTable	
enumeration ApplicationLoadStatus enumeration ApplicationRunControl enumeration ApplicationRunStatus enumeration PeiprogId enumeration PeiprogLoadControl enumeration PeiprogLoadStatus enumeration PeiprogRunControl		
enumeration ApplicationRunControl enumeration ApplicationRunStatus enumeration PeiprogId enumeration PeiprogLoadControl enumeration PeiprogLoadStatus enumeration PeiprogRunControl	enumeration ApplicationLoadControl	
enumeration ApplicationRunStatus enumeration PeiprogId enumeration PeiprogLoadControl enumeration PeiprogLoadStatus enumeration PeiprogRunControl	enumeration ApplicationLoadStatus	
enumeration PeiprogId enumeration PeiprogLoadControl enumeration PeiprogLoadStatus enumeration PeiprogRunControl	enumeration ApplicationRunControl	
enumeration PeiprogLoadControl enumeration PeiprogLoadStatus enumeration PeiprogRunControl	enumeration ApplicationRunStatus	
enumeration PeiprogLoadStatus enumeration PeiprogRunControl		
enumeration PeiprogRunControl		
enumeration PeiprogRunStatus		
	enumeration PeiprogRunStatus	
enumeration ApplicationPeiType		
enumeration ReConfig	enumeration ReConfig	
enumeration IndividualAddress	enumeration IndividualAddress	

enumeration	DomainAddress
enumeration	FrequencyChannel
enumeration	Sensitivity
enumeration	HardwareConfig1
enumeration	HardwareConfig2
enumeration	HardwareConfig3
enumeration	HardwareConfig4
enumeration	DeviceOrderId
enumeration	DeviceSerialNumber
enumeration	ProgrammingMode
enumeration	PollingGroupSettings
enumeration	ManagementDescriptor01
enumeration	RunError
enumeration	LeConfig
enumeration	LeGrpConfig
enumeration	LeError
enumeration	LcMode
enumeration	GroupObjectTableLoadControl
enumeration	GroupObjectTableLoadStatus
enumeration	GroupAcknowledgeTable
enumeration	HardwareType
enumeration	FirmwareVersion
enumeration	ManufacturerData
enumeration	ApplicationDataPtr
enumeration	PeiprogDataPtr
enumeration	GroupAddressTableStamp
enumeration	GroupAssociationTableStamp
enumeration	GroupObjectTableStamp
enumeration	GroupFilterTableStamp
enumeration	ApplicationStamp
enumeration	PeiprogStamp



1.1.2.17 simpleType ResourceAccess_t

Туре	restriction of xs:string
Description	List of access specifiers for Hawk resource descriptions
Facets	enumeration remote
	enumeration local1
	enumeration local2

1.1.2.18 simpleType ResourceAccessRights_t

striction of xs:string
t of access rights for Hawk resource descriptions
umeration None
umeration SystemManufacturer
umeration Manufacturer
umeration Configuration
ume ume

enumeration Runtime

$1.1.2.19\ simple Type\ Resource Addr Space_t$

Туре	restriction of xs:string
Description	List of address spaces for Hawk resource descriptions
Facets	enumeration None
	enumeration StandardMemory
	enumeration UserMemory
	enumeration SystemProperty
	enumeration AppProperty
	enumeration LcSlaveMemory
	enumeration LcFilterMemory
	enumeration ADC
	enumeration Constant
	enumeration Pointer
	enumeration Property
	enumeration RelativeMemory

${\bf 1.1.2.20~simple Type~Resource MgmtStyle_t}$

Туре	restriction of xs:string
Description	List of management styles for Hawk resource descriptions
Facets	enumeration simple enumeration lsm

$1.1.2.21\ simple Type\ Application Program Type_t$

Туре	restriction of xs:string
Description	Type of application program
	enumeration ApplicationProgram enumeration PeiProgram

1.1.2.22 simpleType RegistrationStatus_t

Туре	restriction of xs:string
Description	Registration status enumeration
Facets	enumeration Unregistered
	enumeration Registered
	enumeration Certified
	enumeration FutureUseNotRecommended
	enumeration FutureUseNotAllowed

1.1.2.23 simpleType ProjectTracingLevel_t

Туре	restriction of xs:string
Description	ProjectTracingLevel enumeration
Facets	enumeration None
	enumeration OperationUsed
	enumeration Detailed

1.1.2.24 simpleType ToDoStatus_t

Туре	restriction of xs:string
Description	ToDo status enumeration

Facets	enumeration Open
	enumeration Accomplished

1.1.2.25 simpleType Capability_t

Туре	restriction of xs:string
Description	Enumeration of capabilities of EtsDataHandler
Facets	enumeration AddDeleteDevice
	enumeration GroupCommunicationEvents
	enumerationGroupCommunicationLimits
	enumerationTransferParameters
	enumeration ProjectCheck
	Enumeration Printing

${\bf 1.1.2.26\ simple Type\ Application Program IP Config_t}$

Туре	restriction of xs:string
Description	IPConfig enumeration for the application program
Facets	enumeration Custom enumeration Tool

1.1.2.27 simpleType IPConfigAssign_t

Туре	restriction of xs:string
Description	Enumeration describing whether IP configuration is performed automatically or by fixed configuration
Facets	enumeration Fixed
	enumeration Auto

${\bf 1.1.2.28~simple Type~ComTable Expectation_t}$

Туре	restriction of xs:string
Description	Enumeration describing whether the standard ComTable can be expected. Required for DeviceCompare
Facets	enumeration Yes enumeration No
	enumeration Try

$1.1.2.29\ simple Type\ Horizontal Alignment_t$

Туре	restriction of xs:string
Description	Enumeration describing whether the picture shall be aligned left, centered or right, or stretched or repeated
Facets	enumeration Left
	enumeration Middle
	enumeration Right
	enumeration Stretch
	enumeration Repeat

1.1.2.30 simpleType TextEncoding_t

Туре	restriction of xs:string
Description	This enum may only contain valid codepages!
Facets	enumeration us-ascii
	enumeration iso-8859-1
	enumeration iso-8859-2
	enumeration iso-8859-3
	enumeration iso-8859-4
	enumeration iso-8859-5
	enumeration iso-8859-6



1.1.2.31 simpleType CouplerCapability_t

Туре	restriction of xs:string
Description	This enum represents the different capabilities a coupler can have
Facets	enumeration RfReady enumeration RfMultiFast enumeration RfMultiSlow enumeration SecurityProxy

$1.1.2.32\ simple Type\ Download Behavior_t$

Туре	restriction of xs:string
Description	This enum represents the different download behaviors for invisible parameters
Facets	enumeration None
	enumeration Background
	enumeration DefaultValue

1.1.2.33 simpleType SecurityMode_t

Туре	Restriction of xs:string	
Description	This enum represents the different options for secure communication	

Facets	enumeration Auto
	enumeration On
	enumeration Off

1.1.2.34 simpleType ComObjectSecurityRequirements_t

Туре	Restriction of xs:string
Description	This enum represents the different options for the required security for ComObjects. The ETS5 does not distinguish Auth and AuthAndConf and will treat both enum values equally. Any other value than None means that security is required.
	Manufacturer can already define, which security level their products require, but only future ETS-Versions will distinguish those values. Auth: The ComObject may only communicate with authenticated partners. (Authentication required) AuthAndConf: The ComObject may only communicate with authenticated partners and the communication must be encrypted (Authentication and Confidentiality)
Facets	enumeration None
	enumeration Auth
	enumeration AuthAndConf

1.1.2.35 simpleType CellRef_t

Туре	Restriction of xs:string
Description	Required for non-standard layout of parameters as tabular display. This represents the position in the table, given as "row,col" (both 1-based!). See [PSR] 2.1.1
Facets	pattern \d+,\d+

${\bf 1.1.2.36\ simple Type\ Parameter Block Layout_t}$

	Туре	Restriction of xs:string
De	escription	Possible layout types of a parameter block. See [PSR] 2.1.1
	Facets	enumeration Table

enumeration Grid
enumeration List

1.1.2.37 simpleType DeprecationStatus_t

Туре	Restriction of xs:string
Description	Enum that can be used to disable DatapointRoles, SpaceUsages, FunctionTypes or FunctionsGroups.
Facets	enumeration active
	enumeration deprecated
	enumeration removed

1.1.2.38 simpleType ModuleDefArgType_t

Туре	Restriction of xs:string
Description	Enum that can be used to define the argument in a module definition. Required for modular application programs.
Facets	enumeration Numeric
	enumeration Text
	enumeration AllocatorRef

$1.1.2.39\ simple Type\ Member Status_t$

Туре	Restriction of xs:string
Description	Enum that can be used to declare active and inactive members of the KNX
Facets	enumeration Active enumeration Inactive

${\bf 1.1.2.40~simple Type~RFRx Capabilities_t}$

Туре	restriction of xs:string
Description	This enum represents the different capabilities a

Facets	enumeration Ready
	enumeration ReadyFast
	enumeration Slow

1.1.2.41 simpleType RFTxCapabilities_t

Туре	restriction of xs:string
Description	This enum represents the different capabilities a
Facets	enumeration Ready
	enumeration ReadyFast
	enumeration ReadFastSlow

1.1.3 Other simpleTypes

1.1.3.1 simpleType IDREF

Туре	xs:NCName
Description	This type is used for references to xs:ID. In constrast to the standard XML IDREF type, the referenced element need not be in the same XML file.

1.1.3.2 simpleType IDREFS

Туре	xs:list of knx:IDREF
Description	This type is used for multiple references to xs:ID, separated by space. In constrast to the standard XML IDREFS type, the referenced elements need not be in the same XML file.

1.1.3.3 simpleType RELIDREF

T	NONe
lype xs:	::NCName

Description	This type is used for references to elements below a known application program, e.g. instead of the IDREF "M-0004_A-104E-01-5221-O000A_O-2_R-199", the RELIDREF is shortened to "O-2_R-199".	

1.1.3.4 simpleType RELIDREFS

Туре	xs:list of knx:RELIDREF
Description	This type is used for multiple references to knx:RELIDREF, separated by space.

simpleType LanguageDependentIDREF

Туре	xs:NCName
Description	This type is used for references to language dependent xs:ID. In constrast to the standard XML IDREF type, the referenced element need not be in the same XML file.

1.1.3.5 simpleType Capabilities_t

Туре	xs:list of knx:Capability_t
Description	Used to list the actions, an EtsDataHandler is capable of.

1.1.3.6 simpleType String20_t

Туре	xs:string
Description	Same as xs:string, but restricted to 20 unicode characters.

1.1.3.7 simpleType String50_t

Туре	xs:string
Description	Same as xs:string, but restricted to 50 unicode characters.

1.1.3.8 simpleType String255_t

Туре	xs:string
Description	Same as xs:string, but restricted to 255 unicode characters.

1.1.3.9 simpleType Identifier50_t

	Туре	restriction of xs:string
De	escription	This type is for specifying the name of ModuleDef\Arguments\Argument.
	Facets	pattern [A-Za-z_][A-Za-z0-9_]

1.1.3.10 simpleType LanguageDependentString_t

Туре	xs:string
Description	This type is used for texts in master or product data that may be translated to different languages.

1.1.3.11 simpleType LanguageDependentString20_t

Туре	xs:LanguageDependentString_t
Description	Same as LanguageDependentString_t, but restricted to 20 unicode characters.

1.1.3.12 simpleType LanguageDependentString50_t

Туре	xs:LanguageDependentString_t
Description	Same as LanguageDependentString_t, but restricted to 50 unicode characters.

1.1.3.13 simpleType LanguageDependentString255_t

Туре	xs:LanguageDependentString_t
Description	Same as LanguageDependentString_t, but restricted to 255 unicode characters.

1.1.3.14 simpleType Regex_t

Туре	xs:string
Description	Same as string, but must obey the rules of a .NET Regex.

1.1.3.15 simpleType AccessLevel_t

Туре	restriction of xs:unsignedByte
Description	This type is for specifying the segment access level in <u>LdCtrlDeclarePropDesc</u> .
Facets	minInclusive 0 maxInclusive 15
	maxinclusive 15

1.1.3.16 simpleType FloatFormat_t

Туре	restriction of xs:string
Description	This type is for specifying the DisplayFormat of a Parameter of Type TypeFloat
Facets	[#,]*[0,]+(\.0*)?([eE][+-]?0+)?[#,]*[0,]+(\.0*)?([eE][+-]?0+)?

1.1.3.17 simpleType BitOffset_t

Туре	restriction of xs:unsignedByte
Description	This type is for specifying the bit offset of parameters.

	The bit offset is the distance of the most significant bit of the parameter from the most significant bit of the first octet in memory.
Facets	minInclusive 0
	maxInclusive 7

1.1.3.18 simpleType Condition_t

Туре	xs:string		
Description	This type is for specifying conditions in When t.		
	The following values are	possible (<i>number</i> is an integer valu	e written in decimal notation, ()?+* are the usual EBNF symbols, □ denotes the space character):
	A single number	number	The condition evaluates to true, if the value of the controlling parameter is numerically equal to the given number.
	Space-separated list of numbers	number (number)*	The condition evaluates to true, if the value of the controlling parameter is numerically equal to any one of the given numbers.
	Comparison expressions	op number	Compares the value of the controlling parameter to the given number using one of the comparison operators: = != > < >= <= (note that < > have to be written as < / > in XML attributes)
	The controlling paramete	r must be of type TypeNumber or T	ypeRestriction. In the latter case, the Value attribute is used in the comparison.
			stead of numbers if the parameter is of type TypeRestriction. But at latest when the data is submitted for registration, these have ation signature will get invalid on an XML → DB → XML round trip.

1.1.3.19 simpleType Value_t

Туре	xs:string	
Description	This type is for sto	ring parameter or module argument values. The different parameter types or module argument values are encoded as follows:
	TypeNone	Always the empty string.
	TypeText	The text value, suitably escaped by character references (e.g. for the tab character) or entity references (e.g. &It instead of <). Note that all whitespace characters (newline, tab etc.) must be written as character references, otherwise input normalization would replace them by space characters.
	TypeNumber	The numeric value, formatted as decimal string.
	TypeFloat	The numeric value, formatted in scientific notation, with 16 significant digits and 3 exponent digits (regular expression: "-?\d\.\d{15}E[+-]\d{3}"). This corresponds to the conversion value.ToString("E15", CultureInfo.InvariantCulture) in C#.
		Note: if a Value_t attribute would ever be registration-relevant, care must be taken to ensure that this attribute is reproduced exactly on all data transformations, e.g. when importing the XML into an ETS 4 database and exporting it again.

TypeRestriction	The Value attribute of the selected Enumeration option.
TypeTime	Same as TypeNumber
TypeDate	yyyy-mm-dd
TypelPAddress	IPv4 addresses: decimal dotted notation
	IPv6 addresses: eight groups of four hexadecimal digits, separated by colons, e.g. 2001:0db8:85a3:0000:0000:8a2e:0370:7334
TypeAllocatorRefld	A module allocator refld as string
-	

$1.1.3.20\ simpleType\ Guid_t$

Туре	restriction of xs:string
Description	This type is for specifying GUIDs, e.g. the CLSIDs of Plugins.
Facets	pattern \{[0-9A-F]{8}-[0-9A-F]{4}-[0-9A-F]{4}-[0-9A-F]{4}-[0-9A-F]{12}\}

$1.1.3.21\ simple Type\ Ipv4Address_t$

Туре	restriction of xs:string
Description	This type is for specifying IP v4 addresses, e.g. the IP routing multicast address.
Facets	pattern ((25[0-5] 2[0-4][0-9] 1[0-9][0-9] [1-9][0-9])\.){3}(25[0-5] 2[0-4][0-9] 1[0-9][0-9] [1-9][0-9])

1.1.3.22 simpleType RegistrationNumber_t

Туре	restriction of xs:string
Description	This type is for specifying registration numbers in the format yyyy/n
Facets	pattern \d{4}\/d+

$1.1.3.23\ simple Type\ Hardware Version Number_t$

Туре	restriction of xs:unsignedShort
Description	This type is for specifying the VersionNumber of a hardware. Restricted to ensure compatibility with ETS3
Facets	minInclusive 0
	maxInclusive32767

1.1.3.24 simpleType Aes128Key_t

Туре	xs:string
Description	Same as xs:string, but restricted to 40 characters. Used to represent a base64-encoded string of an AES128 key.

1.1.3.25 simpleType AccessPolicy_t

Туре	restriction of xs:string
Description	This type is for specifying access policies for interface object properties.
Facets	pattern [0-3][0-9A-F]{2}/[0-3][0-9A-F]{2}

1.1.3.26 simpleType RepeatIndex_t

Туре	restriction of xs:string
Description	This type is for specifying the repeat index of a module
Facets	pattern \d+x\d+

1.2 Project Data

1.2.1 element KNX/Project

Description	Contains a project.	
Туре	knx:Project t	

1.2.2 complexType Project_t

Description	Contains	s a projec	i.	
Children	Name		Description	
	Project	Informatio	on Contains gene	ral information about the project.
	Installa	tions_	Contains the li	st of installations within the project Most project will just have one Installation. Count of installations must be in [116].
	AddinDa	<u>ıta</u>	Contains proje	ct related data for Addins
	UserFile	s	Contains the u	ser files that are appended to the project
Attributes	Name	Туре	Use	Default Description
	ld	xs:ID	required	Unique ID of the project in the knxproj container.
				On export or conversion, this will be constructed as P- <i>nnnn</i> , where:
				nnnn Random 16Bit Identifier, formatted as 4 hexadecimal digits . Must be unique in the knxproj container.

1.2.2.1 element Project_t/UserFiles

Description	Contains the Userfiles
Туре	knx:Userfiles t

1.2.2.2 complexType UserFile_t

Attributes Name Type Use Default Description Filename knx:string255_t required The name of the user file Comment xs:string optional A comment for the user file	Description	An elemen	t of the Userfile			
	Attributes	Name	Туре	Use	Default	Description
Comment xs:string optional A comment for the user file		Filename	knx:string255_t	required		The name of the user file
		Comment	xs:string	optional		A comment for the user file

1.2.3 General

1.2.3.1 element Project_t/ProjectInformation

Description	Contains general information abo	ut the project.			
Children	Name Description <u>HistoryEntries</u> Contains hist	ory entries entered by the user.			
	<u>ToDoItems</u> Contains proj	ect related ToDo notes			
	<u>ProjectTraces</u> Contains the	ProjectTraces			
	<u>DeviceCertificates</u> Contains the	DeviceCertificates			
Attributes	Name	Туре	Use D	Default	Description
	Name	knx:String50_t	required		Project Name
	GroupAddressStyle	knx:GroupAddressStyle_t	required		Representation of group addresses in this project
	ProjectNumber	knx:String50_t	optional		Optional project number
	ContractNumber	knx:String50_t	optional		Optional contract number
	LastModified	xs:dateTime	optional		Date and time of last modification (UTC)
	ProjectStart	xs:dateTime	optional		Date of project start (UTC)
	ProjectEnd	xs:dateTime	optional		Date of schedules project end (UTC)
	ProjectId	xs:unsignedShort	optional		KNXnet/IP project ID [0 4095]. Not used for other media.
					See KNX standard, Volume 3, Part 8, Chapter 2.
	ProjectPassword	knx:String20_t	optional		Project password. Note that the password is not encrypted in the XML file as password protected projects are stored in encrypted zip containers (see chapter 4.2.4 Password protection).
	Comment	xs:string	optional		Optional comment
	CompletionStatus	knx:CompletionStatus_t	optional U	Jndefined	Completion status
	ProjectTracingLevel	knx:ProjectTracingLevel_t	optional N	None	The Level for ProjectTraces
	ProjectTracingPassword	knx:String20_t	optional		The password for ProjectTracing. This is stored as the first 20 characters of the Base64 encoded string of the salted hash of the original password. "PT-" is used as salt.
	Hide16BitGroupsFromLegacyl	Pluginsxs:boolean	optional fa		If true, the project will not use 16 bit groups. This will prevent problems with older plugins that only support 15 bit groups.
	CodePage	knx:TextEncoding_t	optional		Optional CodePage for correct encoding of project related texts.
	BusAccessLegacyMode	xs:Boolean	optional fa	alse	Determines the mode of the buss access
	Guid	xs:string	required		The project guid, used to secure the project data

LastUsedPuid	xs:int	required	The highest puid that is so far used in the project
Security	knx:SecurityMode_t	optional Auto	Flag to indicate how project shall handle security:
			On -> each secure enabled device must be used securely
			Off -> no secure enabled device may be used securely
			Auto -> let the user decide

1.2.3.2 element Project_t/ProjectInformation/HistoryEntries

Description	List of histor	y entries entered by the user
Children	Name	Description
	HistoryEntr	Y

1.2.3.3 element Project_t/ProjectInformation/HistoryEntries/HistoryEntry

History	ory entries entered by the user					
Name	Туре	Use	Default	Description		
Date	xs:dateTime	required		Date and time of the history entry (UTC)		
User	knx:String255_t	optional		User name (optional)		
Text	xs:string	required		Text of the history entry		
Detail	xs:string	optional		Detailed text for the entry		
	Name Date User Text	Name Type Date xs:dateTime User knx:String255_t Text xs:string	Name Type Use Date xs:dateTime required User knx:String255_t optional Text xs:string required	Date xs:dateTime required User knx:String255_t optional Text xs:string required		

1.2.3.4 element Project_t/ProjectInformation/ProjectTraces

Description	Contains the ProjectTraces
Туре	knx:ProjectTraces t

1.2.3.5 complexType ProjectTrace_t

Description	An element of the ProjectTrace

Attributes Name Type Use Default Description

Date xs:datetimerequired The date and time of the trace's creation

UserName xs:string required The name of the user

Comment xs:string required The text of the trace

1.2.3.6 element Project t/ProjectInformation/DeviceCertificates

Description	Contains the DeviceCertificates
Туре	knx:DeviceCertificates_t

1.2.3.7 complexType DeviceCertificate_t

Description	An element of	An element of the DeviceCertificate				
Attributes	Name	Туре	Use	Default	Description	
	SerialNumbe	r xs:base64Binary	required		The serial number of the device	
	FDSK knx:Aes128Key_t required				The factory default setup key of the device	
		7-	•			

1.2.3.8 element Project_t/ProjectInformation/ToDoItems

Description	Contains the ToDoltems
Туре	knx:ToDoltems t

1.2.3.9 complexType ToDoItem_t

Description	An element	An element of the ToDoltem				
Attributes	Name	Туре	Use De	efault Description		
	Description	xs:string	required	The description of the item		
	ObjectPath	xs:string	optional	The path to the object		
	Status	knx:ToDoStatus_t	trequired	The status of the ToDoltem, either "Open" or "Accomplished"		

1.2.3.10 element Project_t/AddinData

Description List of AddinData

1.2.3.11 complexType AddinData_t

Description	An element of the AddinData							
Attributes	Name Type Use Default	t Description						
	Name knx:String50_trequired	The name of the Addin						
	AddinId xs:ID required	The identifier of the Addin						
	· ·							

1.2.3.12 complexType BusAccess_t

The information for the bus access				
Name	Туре	Use Default		Description
Name	xs:string	required		The name of the access
			The Guid of the access type. If no Edi specified, the Parameter contains the FalconConnectionString	
			The parameters necessary for the connection	
N E	lame lame	lame Type lame xs:string Edi knx:Guid_t	lame Type Use lame xs:string required di knx:Guid_t optional	lame Type Use Default lame xs:string required Edi knx:Guid_t optional

1.2.3.13 element Project_t/Installations

Description	Contains the list of installations within the project.						
Children	Name Description						
	Installation Up to 16 instrallations						

1.2.3.14 element Project_t/Installations/Installation

Description	Contains data fo	Contains data for one installation						
Children	Name	Description						
	<u>Topology</u>	Contains the topology structure and device data						
	<u>Buildings</u>	Contains the building structure						

	GroupAddresses Conta	ains the group address structure			
	<u>Trades</u> Conta	ains the trades structure			
	<u>SplitInfos</u> Conta	ains the split infos for the installation			
Attributes	Name	Туре	Use	Default	Description
	Name	knx:String50_t	required		Name of the installation. If the project contains just one installation, this can be set to an empty string
	InstallationId	xs:unsignedShort	optional		KNXnet/IP installation ID [015]; not used for other media.
					See KNX standard, Volume 3, Part 8, Chapter 2
	BCUKey	xs:unsignedLong	optional	4294967295	The key used to lock devices supporting authentication.
	IPRoutingMulticastAddre	ess knx:Ipv4Address_t	optional	224.0.23.12	The multicast address for IP communcation.
	MulticastTTL	xs:byte	optional	16	The time to live for multicast telegrams, i.e.the number of routers the telegram may pass before deletion.
	IPRoutingBackboneKey	knx:Aes128Key_t	optional		For symmetric encryption the AES algorithm with a key length of 128 bit is used. For every IP multicast group, a single encryption key is used. This key is stored in every device of the IP multicast group and has an unlimited lifetime.
	IPRoutingLatencyTolera	ance xs:unsingedShort	optional		To prevent replay attacks, the devices shall only accept IP telegrams that were received within a specified time after the telegram was sent. This tolerance can be specified by the user. The latency tolerance is specified in milliseconds.
	IPSyncLatencyFraction	xs:float	optional	0.1	To define the latency for secure IP communication. For futher information, please see KSG 616
	IPRoutingBackboneSec	urity knx:IPRoutingBackboneSecurity_	_toptional	Auto	Specifies if the communication via IP is secure or not. Can be either Auto, On or Off. On means the IP communication is performed securely, Off means the IP communication is performed normally. Auto means: If every IP device in the installation has an ApplicationProgram with IsSecureEnabled == true, the communication is performed securely.
	DefaultLine	xs:string	optional		The Refld of the default line.
	CompletionStatus	knx:CompletionStatus_t	optional	Undefined	Completion status
	SplitType	xs:string	optional		Completion status

1.2.4 Topology

1.2.4.1 element Project_t/Installations/Installation/Topology

Description | Contains the topology structure and device data

1.2.4.2 complexType Topology_t

Description	Contains the to	ontains the topology structure and device data				
Children	Name	Description				
	<u>Area</u>	Up to 16 Areas				
	<u>UnassignedDevices</u> List of devices not assigned to a line					

1.2.4.3 element Topology_t/Area

Description	Description of a Kl	Description of a KNX area					
Children	Name Description <u>Line</u> Up to 16 lines						
Attributes	Name	Туре	Use Default	Description			
	Id	xs:ID	optional	Unique ID.			
				On export or conversion, this will be constructed as parid_A-number, where:			
				parid ID of the parent Project and InstallationID sepearted with '-'			
				<i>number</i> Unique number of the area within the project. This does not reflect the area address! For converted projects, this corresponds to Area.UniqueNumber in the database schema.			
	Name	knx:String255_t	required	Name of the area			
	Address	xs:int	required	Area address [015]			
	Comment	xs:string	optional	User comment			
	CompletionStatus	knx:CompletionStatus_t	optional	Completion status			
	Description	xs:string	optional	Description of the area			
	Puid	xs:int	required	The project wide unique identifier. After deletion of the element, no other element will receive the same Puid.			

1.2.4.4 element Topology_t/Area/Line

Description	Description of a KNX line	

Children	Name	Description							
	DeviceInstance	List of device	es assigned	d to the I	e.				
	AdditionalGroupAddresses List of additional group addresses that should be included in the filter table of this line's line coupler.								
	<u>BusAccess</u>	Contains the	bus acces	s inform	nation for the line				
Attributes	Name	Туре	Use I	Default	Description				
	Id	xs:ID	required		Unique ID.				
					On export or conversion, this will be constructed as parid_L-number, where:				
					parid ID of the parent Project and InstallationID sepearted with '-'				
					<i>number</i> Unique number of the line within the project. This does not reflect the line address! For converted projects, this corresponds to Line.UniqueNumber in the database schema.				
	Name	knx:String255_t	required		Name of the line				
	Address	xs:int	required		Line address [015]				
	MediumTypeRefld	knx:IDREF	required		Medium type of the line, a reference to MediumType.				
	Comment	xs:string	optional		User comment				
	DomainAddress	xs:unsignedLong	optional		For open media (PL, RF), the domain address				
	CompletionStatus	knx:CompletionStatus_t	optional		Completion status				
	Description	xs:string	optional		Description of the line				
	Puid	xs:string	required		The project wide unique identifier. After deletion of the element, no other element will receive the same Puid.				

1.2.4.5 element Topology_t/Area/Line/DeviceInstance

Description	Represents a device in the project.
Туре	knx:DeviceInstance t

1.2.4.6 element Topology_t/Area/Line/AdditionalGroupAddresses

Description	List of additional group addresses that should be included in the filter table of this line's line coupler.				
Children	Name	Description			

GroupAddress GroupAddress that is not necessarily contained in the project

1.2.4.7 element Topology_t/Area/Line/AdditionalGroupAddresses/GroupAddress

Description					
Attributes	Name	Туре	Use	Default	Description
	Address	xs:unsignedShort	required		The address of the GroupAddress

1.2.4.8 element Topology_t/UnassignedDevices

Description	List of devices not assigned to a line
Children	Name Description
	<u>DeviceInstance</u> List of devices assigned to no line.

1.2.4.9 element Topology_t/UnassignedDevices/DeviceInstance

Description	Represents a device in the project.
Туре	knx:DeviceInstance t

1.2.5 Device Data

1.2.5.1 complexType DeviceInstance_t

Description	Represents a device in	the project.
Children	Name	Description
	ParameterInstanceRef	<u>fs</u> List of parameter instances with non-default values
	ComObjectInstanceRe	efs_List of group communication object instances

		List of channel instances.									
	<u>ModuleInstances</u>	List of module instances.									
		The structured content of the contains the channels and active group objects.									
	<u>AdditionalAddresses</u>	Additional individual addres	ses of the device								
	<u>BinaryData</u>	For use by plugins									
	IPConfig	The IP configuration of the device									
	Security	Security The security configuration of the device									
	BusInterfaces	The bus interfaces of the de	evice								
	<u>RfFastAckSlots</u>	The slots for fast RF acks									
Attributes	Name	Туре	Use Default	Description							
	Id	xs:ID	required	Unique ID.							
				On export or conversion, this will be constructed as parid_DI-number, where:							
				parid ID of the parent Project and InstallationID sepearted with '-'							
				<i>number</i> Unique number of the area within the project. This does not reflect the device address! For converted projects, this corresponds to DeviceInstance.UniqueNumber in the database schema.							
	Name	knx:String255_t	optional	Device name							
	ProductRefld	knx:IDREF	required	Reference to a Product; must be a child of the Hardware2Progrem element							
	Hardware2ProgramRefld	knx:IDREF	optional	Reference to a <u>Hardware2Program</u>							
	Address	xs:int	optional	Device address [0255]							
	Comment	xs:string	optional	Device comment							
	LastModified	xs:dateTime	optional	Date/time of last modification (UTC)							
	LastDownload	xs:dateTime	optional	Date/time of last download (UTC)							
	LastUsedAPDULength	xs:unsignedShort	optional								
	ReadMaxAPDULength	xs:unsignedShort	optional								
	ReadMaxRoutingAPDULe	engthxs:unsignedShort	optional								
	InstallationHints	xs:string	optional	Installation hints, may be plain text or RTF text							
	CompletionStatus	knx:CompletionStatus_t	optional Undefine	d Completion status							
	IndividualAddressLoaded	xs:boolean	optional false	true if the IA has been programmed							

ApplicationProgramLoaded	xs:boolean	optional false	true if the application program has been programmed
ParametersLoaded	xs:boolean	optional false	true if the parameters has been programmed
CommunicationPartLoaded	xs:boolean	optional false	true if the group communication part has been programmed
MediumConfigLoaded	xs:boolean	optional false	true if the PL medium configuration has been programmed
LoadedImage	xs:base64Binary	optional	The image loaded into the device the last time (used with differential download)
CheckSums	xs:base64Binary	optional	Check sums read from the device the last time (used with differential download)
Description	xs:string	optional	Device description.
DownloadCounter	xs:unsignedInt	optional	
IsActivityCalculated	xs:boolean	optional	If the IsActivityCalculated flag exists at the DeviceInstance and is "true", the activity for the DeviceInstance is already claculated
Broken	xs:boolean	optional false	true if the OnImport handler failed. A broken application program cannot be used in the ETS4.
SerialNumber	xs:base64Binary	optional	The SerialNumber is used for DownloadIndividualAddressBySerialNumber. This serial number must be provided base64 encoded.
UniqueId	knx:Guid_t	optional	The unique identifier for the device instance. This is set, if an AddIn requests the identifier and the device instance has none set so far. Otherwise, this unique identifier remains null
IsRFRetransmitter	xs:boolean	optional	True if the device instance shall act as a RF retransmitter
Puid	xs:string	required	The project wide unique identifier. After deletion of the element, no other element will receive the same Puid.

1.2.5.2 complexType IPConfig_t

Description	IP configuration for the DeviceInstance					
Attributes	Name	Туре	Use	Default	Description	
	Assign	knx:IPConfigAssign_t	optional	Auto	If the value is 'Auto', the IP configuration is fetched from DHCP, if the value is 'Fixed', the IP configuration is performed manually	
	IPAddress	knx:lpv4Address_t	optional		The IP address of the IP device	
	SubnetMask	knx:lpv4Address_t	optional		The subnet mask of the IP device	
	DefaultGatewa	yknx:lpv4Address_t	optional		The default gateway of the IP device	
	MACAddress	knx:String50_t	optional		The MAC address of theIP device	

1.2.5.3 complexType Security_t

Description	Configuration for security elements
2000р	osing a submit of south y osine its
1	

Children	Name	Description			
	Role	The security role of the device.			
Attributes	Name		Туре	Use Defau	It Description
	LoadedI	PRoutingBackboneKey	knx:Aes128Key_	_toptional	After the download of a device, the encryption key of the IP multicast group is written to the device. The user cannot set the key manually. This encryption key is used for the symmetric encryption within the IP multicast group.
	DeviceA	uthenticationCode	knx:String20_t	optional	The device authentication code is generated when the device is instanciated .
	DeviceA	uthenticationCodeHash	xs:base64Binary	optional	A hash of the device authentication code.
	Loaded[DeviceAuthenticationCodeHash	xs:base64binary	t optional	A hash of the device authentication code that was used with the last device downloaded.
	DeviceM	ManagementPassword	knx:String20_t	optional	The management password is generated when the device is instanciated. The initial password has a length of 8 elements and consists of lower and upper case letters, numbers and the special characters "+", "-", ",", "," "#" and "*". The device management password can be changed by the user anytime.
	DeviceN	ManagementPasswordHash	xs:base64Binary	optional	A hash of the device management password.
	Loaded	DeviceManagementPasswordHasl	hxs:base64Binary	optional	A hash of the device management password that was used with the last device download.
	ToolKey	,	knx:Aes128Key_	_toptional	The tool key for the device.
	Loaded	ГооlКеу	knx:Aes128Key_	_toptional	The tool key used with the last device download.
	Sequenc	ceNumber	xs:unsignedLong	g optional	The value of the last received sender counter. The SequenceNumber is updated during secure online communication.
	Sequend	ceNumberTimestamp	xs:dateTime	optional	The timestamp of the last sequence number. This could be used to check how trustworthy a sequence number is.

1.2.5.4 element Security_t/Role

Group addresses assigned to a ComObjectInstanceRef for sending (and receiving)					
е Туре	Use Defa	ult Description			
d knx:IDREF	required	Reference to the DataSecurity role defined in the application program.			
Addressxs:unsignedByterequired		The individual address used for this role.			
d	knx:IDREF	knx:IDREF required			

1.2.5.5 element DeviceInstance_t/BusInterfaces

Description	Contains bus interfaces for the device
Children	Name Description

BusInterface The bus interface (can be 1...n)

1.2.5.6 complexType BusInterface_t

Description	Bus interface of	Bus interface of the device, only used for devices that have one or more tunnelling server. For more information, please see KSG 616.							
Children	Name De	scription							
	Connectors If t	Connectors of the tunnelling server is used for a visualisation, the addresses that shall be visualized can be added here, so that the filter tables are calculated correctly.							
Attributes	Name	Туре	Use Default	Description					
	Refld	knx:IDREF	required	The Refld to the BusInterface in the ApplicationProgram.					
	Name	xs:string	optional	The name of the additional address used as a bus interface.					
	Description	xs:string	optional	The description for the additional address used as a bus interaface.					
	Comment	xs:string	optional	The comment for the additional address used as a bus interface.					
	Password	knx:String20_t	optional	The optional password for the tunnelling server					
	PasswordHash	xs:base64Binary	optional	A hash of the optional password for the tunnelling server					

1.2.5.7 element BusInterface_t/Connectors

Description	Group a	Group addresses assigned to the bus interface. Needed for correct calculation of filter tables.						
Childre	n Name	Description						
	Conne	Connector to a group address that shall be represented in the calculated filter table.						

1.2.5.8 element BusInterface_t/Connectors/Connector

Description	Group addresses assigned to a ComObjectInstanceRef for sending (and receiving)				
Attributes	Name	Туре	Use	Default Description	
	GroupAddressRefld	knx:IDREF	required	Reference to a GroupAddress	

1.2.5.9 element DeviceInstance_t/ParameterInstanceRefs

Desc	ription	List of parameter instances with non-default values.
		If a parameter has its default value, it needs not be listed here.

Children	Name	Description
	<u>ParameterInstanceRe</u>	<u>of</u>

1.2.5.10 element DeviceInstance_t/ParameterInstanceRefs/ParameterInstanceRef

Description	Parameter instance				
Attributes	Name	Туре	Use [Default	Description
	Id	xs:ID	optional		Might be set and used by Plugins. It is recommended to use one of the following methods for constructing the attribute value:
	Refld	knx:IDREF	required		 a GUID (without enclosing braces) deviceid_paramrefid where deviceid is the ld of the parent Device and paramrefid is the ld of the referenced ParameterRef Reference to a ParameterRef.
	Value	knx:Value_t	optional		The current value
	GrantUseByCustome	rxs:boolean	optional f	false	For ETS Inside: The installer can grant the customer the right to change the value of this parameter.
	CustomizedText	xs:string	optional		For ETS Inside: The installer can specify a customized text for this parameter.

1.2.5.11 element DeviceInstance_t/ComObjectInstanceRefs

Description	List of group communica	ation object instances.
	If a communication obje	ect instance has all default settings and no associations, it needs not be listed here.
Children	Nama	Description
Children		Description
	ComObjectInstanceRe	

$1.2.5.12\ element\ DeviceInstance_t/ComObjectInstanceRefs/ComObjectInstanceRef$

Description	Goup communication object instance
Туре	knx:ComObjectInstanceRef t

1.2.5.13 complexType ComObjectInstanceRef_t

Description	Goup communication	pup communication object instance					
Attributes	Name	Туре	Use Defau	It Description			
	ld	xs:ID	optional	The identifier			
	Refld	knx:RELIDREF	required	Reference to a ComObjectRef RELIDREF means, the ld is stripped of the parent part, e.g. "O-2_R-9"			
	Text	knx:String255_t	optional	Visible communication object name. If missing, the attribute of the underlying ComObjectRef or ComObject is used			
	FunctionText	knx:String255_t	optional	Visible communication object function name. If missing, the attribute of the underlying ComObjectRef or ComObject is used			
	Priority	knx:ComObjectPriority_t	optional	Transmission priority. If missing, the attribute of the underlying ComObjectRef or ComObject is used.			
	ReadFlag	knx:Enable_t	optional	Read flag. If missing, the attribute of the underlying ComObjectRef or ComObject is used.			
	WriteFlag	knx:Enable_t	optional	Write flag. If missing, the attribute of the underlying ComObjectRef or ComObject is used.			
	CommunicationFlag	knx:Enable_t	optional	Communication flag. If missing, the attribute of the underlying ComObjectRef or ComObject is used.			
	TransmitFlag	knx:Enable_t	optional	Transmit flag. If missing, the attribute of the underlying ComObjectRef or ComObject is used.			
	UpdateFlag	knx:Enable_t	optional	Update flag. If missing, the attribute of the underlying ComObjectRef or ComObject is used.			
	ReadOnInitFlag	knx:Enable_t	optional	ReadOnInit flag. If missing, the attribute of the underlying ComObjectRef or ComObject is used.			
	DatapointType	knx:IDREFS	optional	May be a reference to (one or more) <u>DatapointType</u> or <u>DatapointSubtype</u> . If missing, the attribute of the underlying ComObjectRef or ComObject is used.			
	Description	xs:string	optional	Description			
	Channelld	knx:IDREF	optional	The reference to the ApplicationProgramChannel in which the ComObjectInstance is located. If the ComObjectInstance is located in the ChannelIndependentBlock, the ChannelId is null.			
	Links	knx:RELIDREFS	optional	The list of (shortened) group address ids that are linked with this object. The first group address in the list is always the sending one.			
	Acknowledges	knx:RELIDREFS	optional	The list of (shortened) group address ids that have the acknowledge flag set (used in PL).			

1.2.5.14 element DeviceInstance_t/ChannelInstances

Description	List of channel insta	ist of channel instances, can be 0n.							
	ChannelInstances a	annellnstances are only available, if PreEts4Style of the referenced ApplicationProgram is false and the ApplicationProgram does not only contain the ChannelIndependentBlock.							
Children	Name	Description							
	ChannelInstance	List of channel instances.							

1.2.5.15 element DeviceInstance_t/ChannelInstances/ChannelInstance

Description	The chann	el instances are	used to vis	sualize t	he logical structure of the ComObjectInstances of the device.
Attributes	Name	Туре	Use	Default	Description
	ld	xs:ID	required		The unique identifier for the ChannelInstance. Is a combination of Device ID and unique Channel ID.
	Refld	knx:RELIDREF	optional		Reference to a Channel in the dynamic part of the ApplicationProgram. If the channel is user defined, the Refld is null. RELIDREF means, the ld is stripped of the parent part, e.g. "CH-1"
	Name	knx:String255_t	optional		The name of the channel.Can only be edited, if Refld == null (i.e. only names of user defined ChannelInstances can be edited)
	Description	nknx:String255_t	optional		The description of the channel.
	IsActive	xs:boolean	optional		The indicator whether the channel is currently active

${\bf 1.2.5.16\ element\ DeviceInstance_t/ModuleInstances}$

Description	List of module insta	st of module instances, can be 0n.					
Children	Name	Description					
	ModuleInstance	List of module instances.					

${\bf 1.2.5.17\ element\ DeviceInstance_t/ModuleInstances/ModuleInstance}$

Description	The module instances are used to persist the structure of active modules.
Туре	knx:ModuleInstance_t

1.2.5.18 complexType ModuleInstance_t

Description	Description	Description of a module instance					
Children		Name Description Arguments The list of argument with which the module instance was instantiated.					
Attributes	Name Type Use Defauld knx:RELID required			Description The shortened id of the module instance.			

For Modules:

 $\textbf{MD-} \textit{ModuleDefUniqueNumber} \underline{\textbf{M}} \textbf{-} \textit{ModuleUnqiueNumber} \underline{\textbf{M}} \textbf{-} \textit{ModuleInstance} \textcircled{RepeatIndex}$

For SubModules:

 $\textbf{MD-} \textit{ModuleDefUniqueNumber} _ \textbf{M} - \texttt{ModuleInstance} @ \textbf{RepeatIndex} _ \textbf{SM-} \\ \textbf{SubModuleDefUniqueNumber} _ \textbf{M} - \texttt{ModuleInstance} \\ \textbf{M} - \texttt{M$ SubModuleUniqueNumber_MI-SubModuleInstance@RepeatIndex

Examples for the ID are shown here

Refld knx: String255_t required

The shortened Id of the Module

RepeatIndexxs:list of

knx:RepeatIndex t

optional

The repeat index of the module. The index contains a list of order infos, the order info consists of the XmlOrder and the repeat counter, separated by an 'x', (e.g. 37x2, meaning the XmlOrder is 37 and the repeat counter is 2). For nested repeats, each nesting level requires

1.2.5.19 element ModuleInstance_t/Arguments

Description	The list of argument	The list of arguments used for the creation of the module instance							
Children	Name	Description							
	Argument	A specific argument used for creation of the module instance							

1.2.5.20 element ModuleInstance_t/Arguments/Argument

Description	Represe	presents a argument that was used for creation of the module instance					
Attributes	Name	Туре	Use	Default	Description		
	Refld	knx:RELIDREF	required		The shortened ID of the specified argument		
	Value	knx:Value_t	required		The value that was used for instantiation of the module		
					·		

1.2.5.21 element DeviceInstance t/GroupObjectTree

Description		
Children	Name	Description
	<u>Node</u>	List of nodes in the group object tree (Channels and Folder).

Attributes	Name	Туре	Use	Default Description
	GroupObjectInstances	knx:RELIDREFS	optional	The list of group object instances that are active in the ChannelIndependentBlock

1.2.5.22 element DeviceInstance_t/GroupObjectTree/Node

Description	The list of nodes that are in the root level of the group object tree.
Туре	knx:Node_t

1.2.5.23 element Node_t

Description	The node element in t	The node element in the GroupObjectTree					
Children	Name Description	ame Description					
	<u>Nodes</u>						
Attributes	Name	Туре	Use	Default Description			
	Туре	xs:string	required	The type of the node. Can be:			
				Folder (ParameterBlock with "ShowInComObjectTree")Channel			
	Refld	knx:RELIDREF	requried	The shortened Refld to the Channel or ParameterBlock			
	GroupObjectInstances	s knx:RELIDREFS	optional	The list of shortened Reflds			

1.2.5.24 element DeviceInstance_t/RfFastAckSlots

Description		
Children	Name	Description
	<u>Slot</u>	List of fast ACK RF slots.

1.2.5.25 element DeviceInstance_t/ RfFastAckSlots /Slot

Description	
Description	

Attributes	Name	Туре	Use	Default Description
	GroupAddressRefld	knx:IDREF	required	
	Number	xs:unsignedByte	required	

1.2.5.26 element DeviceInstance_t/AdditionalAddresses

Description	Contains	Contains additional device addresses used by the device (maximum 254)							
Children	Name	Description							
	Address	Device address							

${\bf 1.2.5.27\ element\ DeviceInstance_t/AdditionalAddresses/Address}$

Additional device address (individual address) used by the device				
he device.				
:h				

1.2.5.28 element DeviceInstance_t/BinaryData

Description	For use by plugins				
Children	Name Description				
	<u>BinaryData</u>				

1.2.5.29 element DeviceInstance_t/BinaryData/BinaryData

Description	For use by	plugins			
Children	Name Des	scription			
	Data Any	y data (optional)			
Attributes	Name	Туре	Use	Default	Description
	Id	xs:string	optional		Might be set and used by Plugins. It is recommended to use one of the following methods for constructing the attribute value:
					a GUID (without enclosing braces)
					 deviceid_id where deviceid is the ld of the parent Device and id is the ld of the referenced BinaryData or the suitably escaped name.
	Refld	knx:IDREF	optional		Reference to a BinaryData.
	Name	knx:String255_t	optional		
	AutoCopy	xs:boolean	optional	false	Allows DCAs to specify, if on copy, the binary data shall be copied.

1.2.5.30 element DeviceInstance_t/BinaryData/BinaryData/Data

Description	
Туре	xs:base64Binary

1.2.6 Building Structure

1.2.6.1 element Project_t/Installations/Installation/Locations

Description	Contains the building structure
Туре	knx:Locations t
Children	Name Description
	<u>BuildingPart</u>
'	

1.2.6.2 complexType Locations_t

Description	Contains the building structure (locations structure)
Children	Name Description
	Space Any number of spaces

1.2.6.3 element Locations_t/Space

	Description	A space.	
		Space elements directly below Locations_t will nromally have Type "Area" or "Building" or "Ground"	
ļ			
	Туре	knx:Space t	

1.2.6.4 complexType Space_t

Description	An element of the	ment of the building structure							
Children	Name	Description	scription						
	<u>Space</u>	Child space							
	DeviceInstancel	RefList of devices in this	s building part.						
	<u>Function</u>	List of functions in the	is building part.						
Attributes	Name	Туре	Use Defa	ault De	scription				
	Id	xs:ID	required	Un	ique ID.				
					export or conversion, this will be constructed as id_BP-number, where:				
				pai	id ID of the parent Project and InstallationID sepearted with '-'				
				nui	mber Unique number of the building part within the project.				
	Name	knx:String255_t	required	Na	me				
	Туре	knx:Space_t	required		e of: "Building", "BuildingPart", "Floor", "Room", "RoomPart", "DistributionBoard", "Stairway", "Corridor", "Area", "Ground" d "Segment".				
	Usage	knx:IDREF	optional	The	e optional usage for this space.				

Number	knx:String255_t	optional	Optional number
Comment	xs:string	optional	Cptional comment
CompletionStatus	knx:CompletionStatus_t	optional Undefined	Completion status
DefaultLine	xs:string	optional	The Refld of the line, to which devices will be added if added to the BuildingPart
Description	xs:string	optional	Description
Puid	xs:string	required	The project wide unique identifier. After deletion of the element, no other element will receive the same Puid.

1.2.6.5 element Space_t/Space

Description	Child building part.
Туре	knx:BuildingPart t

1.2.6.6 element BuildingPart_t/DeviceInstanceRef

Description	References a device contained in a building part.					
Тур	knx:DeviceInstanceRef t					

1.2.6.7 element BuildingPart_t/Function

Description	References a function contained in a building part.						
Туре	knx:Function t						

1.2.6.8 complexType DeviceInstanceRef_t

Description			
Attributes	Name Type	Use	Default Description
	Refld knx:II	REF required	d Reference to <u>DeviceInstance</u>

1.2.6.9 complexType Function_t

Description	A function containi	function containing group addresses						
Children	Name	Description						
	GroupAddressRe	<u>f</u> List of functions in this	building part.					
Attributes	Name	Туре	Use Default	Description				
	Id	xs:ID	required					
	Name	knx:String255_t	required	Name				
	Туре	knx:String255_t	optional	The optional type of the function				
	Implements	knx:IDREFS	optional	Reflds to the function types this function implements.				
	Number	knx:String255_t	optional	Optional number				
	Comment	xs:string	optional	Cptional comment				
	Description	xs:string	optional	Description				
	CompletionStatus	knx:CompletionStatus_t	optional Undefined	Completion status				
	DefaulGroupRang	exs:IDREF	optional	The Refld of the default GroupRange				
	Puid	xs:string	required	The project wide unique identifier. After deletion of the element, no other element will receive the same Puid.				

1.2.6.10 complexType GroupAddressRef_t

Description	A type	type containing information of the referenced group address					
Attributes	Name	Name Type Use Default Description					
	Id xs:ID required			Unique identifier of the GroupAddressRef			
	Refld knx:IDREF required			Reference to GroupAddress			
	Name knx:String255_t required			Name			
	Role knx:String255_t optional			The optional name of the role of that group address			
	Puid xs:string required The project wide unique identifier. After deletion of the element, no other element will receive the same Puid.						

1.2.6.11 complexType Trades_t

Description	Contains the trades structure
Children	Name Description
	<u>Trade</u> Any number of trades

1.2.6.12 element Trades_t/Trade

Description	A Trade.
Туре	knx:Trade t

1.2.6.13 complexType Trade_t

Description	An element of the	n element of the trades structure					
Children	Name	Description					
	<u>Trade</u>	Child Trades					
	DeviceInstanceR	tefList of devices in this	trade.				
Attributes	Name	Туре	Use Defau	Description			
	Id	xs:ID	optional	Unique ID.			
				On export or conversion, this will be constructed as parid_T-number, where:			
				parid ID of the parent Project and InstallationID sepearted with '-'			
				number Unique number of the Trade within the project.			
	Name	knx:String255_t	required	Name of the trade			
	Number	knx:String255_t	optional	Optional number			
	Comment	xs:string	optional	Cptional comment			
	CompletionStatus	knx:CompletionStatus_t	optional Unde	ned Completion status			
	Description	xs:string	optional	Description of the trade			
	Puid	xs:string	required	The project wide unique identifier. After deletion of the element, no other element will receive the same Puid.			

1.2.6.14 element Trade_t/Trade

Description	
Туре	knx:Trade t

1.2.6.15 element Trade_t/DeviceInstanceRef

Description	References a device contained in a trade.				
Туре	knx:DeviceInstanceRef t				

1.2.7 Group Addresses

1.2.7.1 element Project_t/Installations/Installation/GroupAddresses

Description	Contains the group address structure
Туре	knx:GroupAddresses t

1.2.7.2 complexType GroupAddresses t

Description	Contains the group address structure				
Children	Name Description				
	GroupRangeList of named group address ranges				

1.2.7.3 element GroupRange_t/GroupAddress

Description	Describes a group address
Description	Beschibes a group address

Attributes	Name	Туре	Use	Default	Description
7 tti ibatos	Id	xs:ID	required		Unique ID.
	lu lu	X0.1D	required		On export or conversion, this will be constructed as
					parid_GA-number, where:
					parid ID of the parent Project and InstallationID sepearted with '-'
					<i>number</i> Unique number of the group addess within the project. This does not reflect the address value! For converted projects, this corresponds to GroupAddress.UniqueNumber in the database schema.
	Address	xs:unsignedInt	required		Group address [165535]
	Name	knx:String255_t	required		Name
	Unfiltered	xs:boolean	optional	false	If true, the group addresses in the range will not be filtered by routers.
					Note that if a group address is part of one or more GroupRanges with Unfiltered=true, it will not be filtered irrespective of the setting of Unfiltered in the GroupAddress.
	Central	xs:boolean	optional	false	If true, the group address will be treated as central address during copy operations.
	Global	xs:boolean	optional	false	If true, the group address will be used in all installations of the project. Global groups must have the same address and type in all installations of a project.
	Description	xs:string	optional		Description
	Comment	xs:string	optional		Comment
	DatapointType	knx:IDREF	optional		Optional datapoint type specification. A reference to DatapointSubtype .
					If the group address is linked to any DeviceCommunicationObjects, the sizes must match.
	Puid	xs:string	required		The project wide unique identifier. After deletion of the element, no other element will receive the same Puid.
	Key	knx:Aes128_t	optional		The key used for data security communication. All senders and receivers of this group address use the same key.
	Security	knx:SecurityMod	eoptional	Auto	Defines the security mode for the group address. Can be either Auto, On or Off.

1.2.7.4 element GroupAddresses_t/GroupRanges/GroupRange

Description	Top-level named group range
Туре	extension of knx:GroupRange t

1.2.7.5 complexType GroupRange_t

Description	Element of the group address structure	
Description	Liement of the group address structure	

Children	Name	Description		
	GroupRang	<u>le</u> Child group rar	nges	
	GroupAddr	ess GroupAddres	ses located withir	the GroupRange
Attributes	Name	Туре	Use Default	Description
	ld	xs:ID	required	Unique ID.
				On export or conversion, this will be constructed as parid_ GR -number, where:
				parid ID of the parent Project and InstallationID sepearted with '-'
				number Unique number of the group range within the project.
	Name	knx:String255_t	required	Name
	RangeStart	xs:unsignedShort	required	First possible group address in the range
	RangeEnd	xs:unsignedShort	required	Last possible group address in the range
	Unfiltered	xs:boolean	optional false	If true, all group addresses in the range will not be filtered by routers; irrespective of the individual setting of GroupAddress/@Unfiltered.
	Description	xs:string	optional	Description
	Comment	xs:string	optional	Comment
	Puid	xs:string	required	The project wide unique identifier. After deletion of the element, no other element will receive the same Puid.
	Security	knx:SecurityMode	optional Auto	Defines the security mode for the group addresses within the range or any child range.

1.2.7.6 element GroupRange_t/GroupRange

Description	Child named group address range			
Туре	extension of knx:GroupRange t			

1.2.8 SplitInfos

${\bf 1.2.8.1} \quad element \ Project_t/Installations/Installation/SplitInfos$

Description	The required information about a split installation
Туре	knx:SplitInfos t

1.2.8.2 complextType SplitInfos_t

Description	ection of SplitInfo elements, used for Split & Merge				
Туре	extension of knx:SplitInfo t				
Children	Name Description				
	SplitInfo Any number of split infos				

1.2.8.3 element SplitInfo t/SplitInfo

Description	The required information about a split installation				
Туре	knx:SplitInfo t				

1.2.8.4 complexType SplitInfo_t

Description	An element with information for Split & Merge					
Attributes	Name	Туре	Use	Default Description		
	ObjectPath	ObjectPath xs:string required				
	Cookie	xs:string	required	Pattern for the cookie: [0-9a-fA-F]{8}-[0-9a-fA-F]{4}-[0-9a-fA-F]{4}-[0-9a-fA-F]{4}-[0-9a-fA-F]{12}		

4 Transfer files

For export and import scenarios, the generated XML file(s) will be packed into a ZIP archive. This has the following advantages:

- By compression, the files have a manageable size
- Not everything needs to be in a single XML. This is important since current XML parsers and XPath implementations do not work well or do not work at all on huge XML files.

knx:IDREF need not resolve within each individual XML file within the archive, but within the whole archive.

For import, the individual XML files may also be present unzipped, but in the same file system directory.

4.1 File extensions

As file extension, the following is used:

*.knxprod	If just master and manufacturer product data is included
*.knxproj	If master, product and project data is included.

4.2 Content

4.2.1 Non-XML files

The following data is not stored within the XML files but as external files

- Baggage data
- BinaryData and BinaryDataRef data within device instance data
- UserFile data

The corresponding XML elements omit the Data child element.

4.2.2 Distribution to partial XML files

When distributing the data to different XML files, the following restrictions apply:

- All MasterData is in one XML file.
- Together with an ApplicationProgram element, all child elements must be in the same XML file.
- Together with a Project element, all child elements must be in the same XML file.

Logically, the files can be thought of as a merged XML file.

In principle, starting from the KNX element, the files are merged recursively, with the following rules:

- The following elements will be identified (within a recursion level); they must have identical attributes in each partial XML.
 - o Elements with same tag and same "Id"
 - o Elements with same tag without "Id" (this is for the container-type elements like e.g. "ManufacturerData").
 - o Language elements with same "Identifier"
 - o Language/Translation elements with same "RefId"
 - o Language/Translation/Translation elements with same "AttributeName"
 - o Exception: Project is never merged (two projects even with the same name will stay two distinct projects)
 - o Below ApplicationProgram no merging is required; here everything must be identical.

The converter will produce the partial XML files according to the following rules:

- Each ApplicationProgram element will be written to a separate XML file
- Each Baggage element will be written to a separate XML file
- Each Project element will be written to a separate XML file

4.2.3 Naming convention

To avoid name conflicts between the individual XML files within the archive, the following naming convention should be obeyed:

knx_master.xml	Created by KNX; contains only master data.
M-iiii/Baggages.xml	Created by manufacturer iiii (manufacturer ID, formatted as 4 hex digits); contains baggage data.
M-iiii/Catalog.xml	Created by manufacturer iiii (manufacturer ID, formatted as 4 hex digits); contains catalog data.
M-iiii/Hardware.xml	Created by manufacturer iiii (manufacturer ID, formatted as 4 hex digits); contains hardware data.
M-iiii/M-iiii_A-nnnn-vv- ffff.xml	Created by manufacturer <i>iiii</i> (manufacturer ID, formatted as 4 hex digits); contains the data for the application program <i>nnnn</i> in version <i>vv</i> with fingerprint <i>ffff</i> .
P-iiii/project.xml	Created by user; contains the global data for project <i>iiii</i> (internal project ID, formatted as 4 hex digits).
P-iiii/n.xml	Created by user; contains the data for installation <i>n</i> of project <i>iiii</i> (internal project ID, formatted as 4 hex digits).
.xml	Created by user; contains project data (should not contain – and _ characters).

4.2.4 Password protection

When exporting a password-protected project, the proj_*.xml file may optionally be ZIP encoded with the project password.

Note that there is no way to recover or reset a lost ZIP password!