# F2802x Peripheral Driver Library

# **USER'S GUIDE**



# Copyright

Copyright © 2012 Texas Instruments Incorporated. All rights reserved. ControlSUITE is a registered trademark of Texas Instruments. Other names and brands may be claimed as the property of others.

APlease be aware that an important notice concerning availability, standard warranty, and use in critical applications of Texas Instruments semiconductor products and disclaimers thereto appears at the end of this document.

Texas Instruments 12203 Southwest Freeway Houston, TX 77477 http://www.ti.com/c2000



# **Revision Information**

This is version 200 of this document, last updated on Tue Jul 24 10:01:42 CDT 2012.

# **Table of Contents**

	yright	2
Revi	sion Information	2
1	Introduction	5
2.1 2.2 2.3 2.4	Programming Model Introduction Direct Register Access Model Software Driver Model Combining The Models	<b>7</b> 7 7 8
3 3.1 3.2	Analog to Digital Converter (ADC)	<b>9</b> 9
<b>4</b> 4.1 4.2 <b>5</b>	Capture (CAP) Introduction	33 33 33 49
5.1 5.2	Introduction	49 49
<b>6</b> 6.1 6.2	Comparater (COMP)  Introduction	<b>73</b> 73 73
<b>7</b> 7.1 7.2	3 - 1 - 1	<b>81</b> 81 81
<b>8</b> 8.1 8.2	Flash	103
9 9.1 9.2	General Purpose Input/Output (GPIO)	115
	Oscillator (OSC) Introduction OSC	127 127
	PIE	135 135 135
	Introduction	<b>167</b> 167 167
	Introduction	<b>177</b> 177 177
		229 229 229

15.1	Serial Communications Interface (SCI)  Introduction	235
16.1	Serial Peripheral Interface (SPI) Introduction SPI	261
17.1	Timer	279
18.1 18.2	Watchdog Timer Introduction	287 287
IMPO	ORTANT NOTICE	294

# 1 Introduction

The Texas Instruments® ControlSUITE® Peripheral Driver Library is a set of drivers for accessing the peripherals found on the Piccolo Entryline family of C2000 microcontrollers. While they are not drivers in the pure operating system sense (that is, they do not have a common interface and do not connect into a global device driver infrastructure), they do provide a mechanism that makes it easy to use the device's peripherals.

The capabilities and organization of the drivers are governed by the following design goals:

- They are written entirely in C except where absolutely not possible.
- They demonstrate how to use the peripheral in its common mode of operation.
- They are easy to understand.
- They are reasonably efficient in terms of memory and processor usage.
- They are as self-contained as possible.
- Where possible, computations that can be performed at compile time are done there instead of at run time.

Some consequences of these design goals are:

- The drivers are not necessarily as efficient as they could be (from a code size and/or execution speed point of view). While the most efficient piece of code for operating a peripheral would be written in assembly and custom tailored to the specific requirements of the application, further size optimizations of the drivers would make them more difficult to understand.
- The drivers do not support the full capabilities of the hardware. Some of the peripherals provide complex capabilities which cannot be utilized by the drivers in this library, though the existing code can be used as a reference upon which to add support for the additional capabilities.

For many applications, the drivers can be used as is. But in some cases, the drivers will have to be enhanced or rewritten in order to meet the functionality, memory, or processing requirements of the application. If so, the existing driver can be used as a reference on how to operate the peripheral.

This device support release also contains the traditional peripheral register header files and associated software. Please see chapter 2 of this guide for more information on this software. For future development we recommend the use of this driver infrastructure instead of the traditional header files.

## Source Code Overview

The following is an overview of the organization of the peripheral driver library source code.

 ${\tt f2802x0\_common/src/} \ \ \, \textbf{This directory contains the source code for the drivers.}$ 

f2802x0\_common/inc/ This directory contains the header files for the drivers. These headers define not only values used in the drivers and calls to drivers but also define the register structure of each peripheral.

Tue Jul 24 10:01:42 CDT 2012

f2802x0\_common/proje&his directory contains the CCS project for the driver library. The driver library can be rebuilt if modifications are made by importing and building this project.

# 2 Programming Model

Introduction	7
Direct Register Access Model	7
Software Driver Model	3
Combining The Models	3

# 2.1 Introduction

The peripheral driver library provides support for two programming models: the direct register access model and the software driver model. Each model can be used independently or combined, based on the needs of the application or the programming environment desired by the developer.

Each programming model has advantages and disadvantages. Use of the direct register access model generally results in smaller and more efficient code than using the software driver model. However, the direct register access model requires detailed knowledge of the operation of each register and bit field, as well as their interactions and any sequencing required for proper operation of the peripheral; the developer is insulated from these details by the software driver model, generally requiring less time to develop applications.

# 2.2 Direct Register Access Model

In the direct register access model, the peripherals are programmed by the application by writing values directly into the peripheral's registers. Every register is defined in a peripherals corresponding header file contained in  $f2802 \times 0\_header/include$ . These headers define the locations of each register relative to the other registers in a peripheral as well as the bit fields within each register. All of this is implemented using structures. The header files only define these structure; they do not declare them. To declare the structures a C source file must be included in each project  $f2802 \times 0\_headers/source/F2802 \times 0\_GlobalVariableDefs.c$ . This file declares each structure (and in some cases multiple instances when there are multiple instances of a peripheral) as well as declaring and associating each structure with a code section for the linker. The final piece of the puzzle is a special linker command file that associates each section defined in  $F2802 \times 0\_GlobalVariableDefs.c$  with the physical memory of the device. There are two version of this linker command file, one for use with SYS/BIOS and one for use without, but both can be found in  $f2802 \times 0\_headers/cmd$ . One of this linker command files as well as your normal application linker command file should be used to link your project.

Applications that wish to use the direct register access model should define the root of the f2802x0 version directory to be an include path and include the file  $DSP28x\_Project.h$  in each source file where register accesses are made.

In practice accessing peripheral registers and bitfields is extremely easy. Below are a few examples:

```
GpioCtrlRegs.GPAPUD.bit.GPIO0 = 0;
GpioCtrlRegs.GPAMUX1.bit.GPIO0 = 1;
```

## 2.3 Software Driver Model

In the software driver model, the API provided by the peripheral driver library is used by applications to control the peripherals. Because these drivers provide complete control of the peripherals in their normal mode of operation, it is possible to write an entire application without direct access to the hardware. This method provides for rapid development of the application without requiring detailed knowledge of how to program the peripherals.

Before a driver for a peripheral can be used that peripherals driver header file should be included and a handle to that peripheral initialized:

```
GPIO_Handle myGpio;
myGpio = GPIO_init((void *)GPIO_BASE_ADDR, sizeof(GPIO_Obj));
```

In subsequent calls to that peripheral's driver the initialized handle as well as any parameters are passed to the function:

```
GPIO_setPullUp(myGpio, GPIO_Number_0, GPIO_PullUp_Enable);
GPIO_setMode(myGpio, GPIO_Number_0, GPIO_0_Mode_EPWM1A);
```

As you can see from the above sample, using the driver library makes one's code substantially more readable.

In addition to including the appropriate header files for the drivers you are using, the project should also have driverlib.lib linked into it. A CCS project as well as the lib file can be found in  $f2802x0\_common/project$ . The driver library also contains some basic helper functions that many projects will use as well as the direct register access model source file  $F2802x0\_GlobalVariableDefs.c$  which allows you to use the header files without having to directly compile this source file into your project.

The drivers in the peripheral driver library are described in the remaining chapters in this document. They combine to form the software driver model.

# 2.4 Combining The Models

The direct register access model and software driver model can be used together in a single application, allowing the most appropriate model to be applied as needed to any particular situation within the application. For example, the software driver model can be used to configure the peripherals (because this is not performance critical) and the direct register access model can be used for operation of the peripheral (which may be more performance critical). Or, the software driver model can be used for peripherals that are not performance critical (such as a UART used for data logging) and the direct register access model for performance critical peripherals.

To use both models interchangeably in your application:

- Link driverlib.lib into your application
- Include DSP28x\_Project.h in files you wish to use the direct register access model
- Add /controlsuite/device\_support/f2802x0/version/ to your projects include path (Right click on project, Build Properties, Include Path)
- Include driver header files from f2802x0\_common/include in any source file that makes calls to that driver.

# 3 Analog to Digital Converter (ADC)

Introduction	9
API Functions	9

## 3.1 Introduction

The Analog to Digital Converter (ADC) APIs provide a set of functions for accessing the Piccolo F2802x0 ADC modules.

This driver is contained in f2802x0\_common/source/adc.c, with f2802x0\_common/include/adc.h containing the API definitions for use by applications.

## 3.2 ADC

## **Data Structures**

\_ADC\_Obj\_

## **Defines**

- ADC ADCCTL1 ADCBGPWD BITS
- ADC\_ADCCTL1\_ADCBSY\_BITS
- ADC ADCCTL1 ADCBSYCHAN BITS
- ADC ADCCTL1 ADCENABLE BITS
- ADC ADCCTL1 ADCPWDN BITS
- ADC\_ADCCTL1\_ADCREFPWD\_BITS
- ADC\_ADCCTL1\_ADCREFSEL\_BITS
- ADC ADCCTL1 INTPULSEPOS BITS
- ADC\_ADCCTL1\_RESET\_BITS
- ADC ADCCTL1 TEMPCONV BITS
- ADC\_ADCCTL1\_VREFLOCONV\_BITS
- ADC\_ADCSAMPLEMODE\_SEPARATE\_FLAG
- ADC\_ADCSAMPLEMODE\_SIMULENO\_BITS
- ADC\_ADCSAMPLEMODE\_SIMULEN10\_BITS
- ADC\_ADCSAMPLEMODE\_SIMULEN12\_BITS
- ADC\_ADCSAMPLEMODE\_SIMULEN14\_BITS
- ADC ADCSAMPLEMODE SIMULEN2 BITS
- ADC\_ADCSAMPLEMODE\_SIMULEN4\_BITS
- ADC ADCSAMPLEMODE SIMULEN6 BITS
- ADC\_ADCSAMPLEMODE\_SIMULEN8\_BITS
- ADC\_ADCSOCxCTL\_ACQPS\_BITS

- ADC ADCSOCxCTL CHSEL BITS
- ADC\_ADCSOCxCTL\_TRIGSEL\_BITS
- ADC BASE ADDR
- ADC dataBias
- ADC DELAY usec
- ADC INTSELxNy INTCONT BITS
- ADC INTSELxNy INTE BITS
- ADC\_INTSELxNy\_INTSEL\_BITS
- ADC\_INTSELxNy\_LOG2\_NUMBITS\_PER\_REG
- ADC INTSELxNy NUMBITS PER REG

## **Enumerations**

- ADC\_IntMode\_e
- ADC IntNumber e
- ADC\_IntPulseGenMode\_e
- ADC\_IntSrc\_e
- ADC\_ResultNumber\_e
- ADC\_SampleMode\_e
- ADC SocChanNumber e
- ADC\_SocNumber\_e
- ADC SocSampleWindow e
- ADC\_SocTrigSrc\_e
- ADC VoltageRefSrc e

## **Functions**

- void ADC\_clearIntFlag (ADC\_Handle adcHandle, const ADC\_IntNumber\_e intNumber)
- void ADC disable (ADC Handle adcHandle)
- void ADC\_disableBandGap (ADC\_Handle adcHandle)
- void ADC disableInt (ADC Handle adcHandle, const ADC IntNumber e intNumber)
- void ADC\_disableRefBuffers (ADC\_Handle adcHandle)
- void ADC disableTempSensor (ADC Handle adcHandle)
- void ADC\_enable (ADC\_Handle adcHandle)
- void ADC\_enableBandGap (ADC\_Handle adcHandle)
- void ADC\_enableInt (ADC\_Handle adcHandle, const ADC\_IntNumber\_e intNumber)
- void ADC\_enableRefBuffers (ADC\_Handle adcHandle)
- void ADC\_enableTempSensor (ADC\_Handle adcHandle)
- void ADC forceConversion (ADC Handle adcHandle, const ADC SocNumber e socNumber)
- bool t ADC getIntStatus (ADC Handle adcHandle, const ADC IntNumber e intNumber)
- ADC\_SocSampleWindow\_e ADC\_getSocSampleWindow (ADC\_Handle adcHandle, const ADC\_SocNumber\_e socNumber)
- int16 t ADC getTemperatureC (ADC Handle adcHandle, int16 t sensorSample)
- int16\_t ADC\_getTemperatureK (ADC\_Handle adcHandle, int16\_t sensorSample)
- ADC\_Handle ADC\_init (void \*pMemory, const size\_t numBytes)

- void ADC powerDown (ADC Handle adcHandle)
- void ADC\_powerUp (ADC\_Handle adcHandle)
- uint\_least16\_t ADC\_readResult (ADC\_Handle adcHandle, const ADC\_ResultNumber\_e resultNumber)
- void ADC reset (ADC Handle adcHandle)
- void ADC\_setIntMode (ADC\_Handle adcHandle, const ADC\_IntNumber\_e intNumber, const ADC\_IntMode\_e intMode)
- void ADC\_setIntPulseGenMode (ADC\_Handle adcHandle, const ADC\_IntPulseGenMode\_e pulseMode)
- void ADC\_setIntSrc (ADC\_Handle adcHandle, const ADC\_IntNumber\_e intNumber, const ADC IntSrc e intSrc)
- void ADC\_setSampleMode (ADC\_Handle adcHandle, const ADC\_SampleMode\_e sample-Mode)
- void ADC\_setSocChanNumber (ADC\_Handle adcHandle, const ADC\_SocNumber\_e socNumber, const ADC\_SocChanNumber e chanNumber)
- void ADC\_setSocSampleWindow (ADC\_Handle adcHandle, const ADC\_SocNumber\_e socNumber, const ADC\_SocSampleWindow\_e sampleWindow)
- void ADC\_setSocTrigSrc (ADC\_Handle adcHandle, const ADC\_SocNumber\_e socNumber, const ADC\_SocTrigSrc e trigSrc)
- void ADC setVoltRefSrc (ADC Handle adcHandle, const ADC VoltageRefSrc e voltRef)

## 3.2.1 Data Structure Documentation

## 3.2.1.1 \_ADC\_Obj\_

## **Definition:**

```
typedef struct
    uint16_t ADCRESULT[16];
    uint16_t resvd_1[26096];
    uint16_t ADCCTL1;
    uint16_t rsvd_2[3];
    uint16_t ADCINTFLG;
    uint16 t ADCINTFLGCLR;
    uint16 t ADCINTOVF;
    uint16_t ADCINTOVFCLR;
    uint16_t INTSELxNy[5];
    uint16_t rsvd_3[3];
    uint16_t SOCPRICTRL;
    uint16_t rsvd_4;
    uint16_t ADCSAMPLEMODE;
    uint16_t rsvd_5;
    uint16_t ADCINTSOCSEL1;
    uint16_t ADCINTSOCSEL2;
    uint16_t rsvd_6[2];
    uint16_t ADCSOCFLG1;
    uint16_t rsvd_7;
    uint16_t ADCSOCFRC1;
    uint16_t rsvd_8;
```

```
uint16_t ADCSOCOVF1;
        uint16_t rsvd_9;
        uint16_t ADCSOCOVFCLR1;
        uint16_t rsvd_10;
        uint16 t ADCSOCxCTL[16];
        uint16_t rsvd_11[16];
        uint16_t ADCREFTRIM;
        uint16_t ADCOFFTRIM;
        uint16_t resvd_12[13];
        uint16_t ADCREV;
   _ADC_Obj_
Members:
   ADCRESULT ADC result registers.
   resvd_1 Reserved.
    ADCCTL1 ADC Control Register 1.
    rsvd 2 Reserved.
    ADCINTFLG ADC Interrupt Flag Register.
    ADCINTFLGCLR ADC Interrupt Flag Clear Register.
    ADCINTOVF ADC Interrupt Overflow Register.
    ADCINTOVFCLR ADC Interrupt Overflow Clear Register.
   INTSELxNy ADC Interrupt Select x and y Register.
    rsvd 3 Reserved.
    SOCPRICTRL ADC Start Of Conversion Priority Control Register.
    rsvd 4 Reserved.
    ADCSAMPLEMODE ADC Sample Mode Register.
    rsvd 5 Reserved.
    ADCINTSOCSEL1 ADC Interrupt Trigger SOC Select 1 Register.
    ADCINTSOCSEL2 ADC Interrupt Trigger SOC Select 2 Register.
    rsvd 6 Reserved.
    ADCSOCFLG1 ADC SOC Flag 1 Register.
   rsvd 7 Reserved.
    ADCSOCFRC1 ADC SOC Force 1 Register.
    rsvd 8 Reserved.
    ADCSOCOVF1 ADC SOC Overflow 1 Register.
    rsvd_9 Reserved.
    ADCSOCOVFCLR1 ADC SOC Overflow Clear 1 Register.
    rsvd 10 Reserved.
    ADCSOCxCTL ADC SOCx Control Registers.
   rsvd 11 Reserved.
    ADCREFTRIM ADC Reference/Gain Trim Register.
    ADCOFFTRIM ADC Offset Trim Register.
   resvd_12 Reserved.
    ADCREV ADC Revision Register.
```

### **Description:**

Defines the analog-to-digital converter (ADC) object.

## 3.2.2 Define Documentation

## 3.2.2.1 ADC ADCCTL1 ADCBGPWD BITS

## **Definition:**

#define ADC\_ADCCTL1\_ADCBGPWD\_BITS

## **Description:**

Defines the location of the ADCBGPWD bits in the ADCTL1 register.

## 3.2.2.2 ADC ADCCTL1 ADCBSY BITS

## **Definition:**

#define ADC\_ADCCTL1\_ADCBSY\_BITS

## **Description:**

Defines the location of the ADCBSY bits in the ADCTL1 register.

## 3.2.2.3 ADC ADCCTL1 ADCBSYCHAN BITS

#### **Definition:**

#define ADC\_ADCCTL1\_ADCBSYCHAN\_BITS

## **Description:**

Defines the location of the ADCBSYCHAN bits in the ADCTL1 register.

## 3.2.2.4 ADC\_ADCCTL1\_ADCENABLE\_BITS

#### **Definition:**

#define ADC\_ADCCTL1\_ADCENABLE\_BITS

### **Description:**

Defines the location of the ADCENABLE bits in the ADCTL1 register.

## 3.2.2.5 ADC ADCCTL1 ADCPWDN BITS

### **Definition:**

#define ADC\_ADCCTL1\_ADCPWDN\_BITS

### **Description:**

Defines the location of the ADCPWDN bits in the ADCTL1 register.

## 3.2.2.6 ADC ADCCTL1 ADCREFPWD BITS

#### **Definition:**

#define ADC\_ADCCTL1\_ADCREFPWD\_BITS

#### **Description:**

Defines the location of the ADCREFPWD bits in the ADCTL1 register.

## 3.2.2.7 ADC ADCCTL1 ADCREFSEL BITS

#### **Definition:**

#define ADC\_ADCCTL1\_ADCREFSEL\_BITS

## **Description:**

Defines the location of the ADCREFSEL bits in the ADCTL1 register.

## 3.2.2.8 ADC ADCCTL1 INTPULSEPOS BITS

#### **Definition:**

#define ADC\_ADCCTL1\_INTPULSEPOS\_BITS

#### **Description:**

Defines the location of the INTPULSEPOS bits in the ADCTL1 register.

## 3.2.2.9 ADC\_ADCCTL1\_RESET\_BITS

### **Definition:**

#define ADC\_ADCCTL1\_RESET\_BITS

## **Description:**

Defines the location of the RESET bits in the ADCTL1 register.

## 3.2.2.10 ADC\_ADCCTL1\_TEMPCONV\_BITS

## **Definition:**

#define ADC\_ADCCTL1\_TEMPCONV\_BITS

### **Description:**

Defines the location of the TEMPCONV bits in the ADCTL1 register.

## 3.2.2.11 ADC ADCCTL1 VREFLOCONV BITS

## **Definition:**

#define ADC\_ADCCTL1\_VREFLOCONV\_BITS

## **Description:**

Defines the location of the VREFLOCONV bits in the ADCTL1 register.

## 3.2.2.12 ADC ADCSAMPLEMODE SEPARATE FLAG

#### **Definition:**

#define ADC\_ADCSAMPLEMODE\_SEPARATE\_FLAG

#### **Description:**

Define for the channel separate flag.

## 3.2.2.13 ADC\_ADCSAMPLEMODE\_SIMULENO\_BITS

#### **Definition:**

#define ADC\_ADCSAMPLEMODE\_SIMULENO\_BITS

## **Description:**

Defines the location of the SIMULEN0 bits in the ADCSAMPLEMODE register.

## 3.2.2.14 ADC ADCSAMPLEMODE SIMULEN10 BITS

#### **Definition:**

#define ADC\_ADCSAMPLEMODE\_SIMULEN10\_BITS

## **Description:**

Defines the location of the SIMULEN10 bits in the ADCSAMPLEMODE register.

## 3.2.2.15 ADC\_ADCSAMPLEMODE\_SIMULEN12\_BITS

### **Definition:**

#define ADC\_ADCSAMPLEMODE\_SIMULEN12\_BITS

## **Description:**

Defines the location of the SIMULEN12 bits in the ADCSAMPLEMODE register.

## 3.2.2.16 ADC\_ADCSAMPLEMODE\_SIMULEN14\_BITS

## **Definition:**

#define ADC\_ADCSAMPLEMODE\_SIMULEN14\_BITS

### **Description:**

Defines the location of the SIMULEN14 bits in the ADCSAMPLEMODE register.

## 3.2.2.17 ADC ADCSAMPLEMODE\_SIMULEN2\_BITS

## **Definition:**

#define ADC\_ADCSAMPLEMODE\_SIMULEN2\_BITS

## **Description:**

Defines the location of the SIMULEN2 bits in the ADCSAMPLEMODE register.

Tue Jul 24 10:01:42 CDT 2012

## 3.2.2.18 ADC ADCSAMPLEMODE SIMULEN4 BITS

#### **Definition:**

#define ADC\_ADCSAMPLEMODE\_SIMULEN4\_BITS

#### **Description:**

Defines the location of the SIMULEN4 bits in the ADCSAMPLEMODE register.

## 3.2.2.19 ADC ADCSAMPLEMODE SIMULEN6 BITS

#### **Definition:**

#define ADC\_ADCSAMPLEMODE\_SIMULEN6\_BITS

## **Description:**

Defines the location of the SIMULEN6 bits in the ADCSAMPLEMODE register.

## 3.2.2.20 ADC ADCSAMPLEMODE SIMULEN8 BITS

#### **Definition:**

#define ADC\_ADCSAMPLEMODE\_SIMULEN8\_BITS

#### **Description:**

Defines the location of the SIMULEN8 bits in the ADCSAMPLEMODE register.

## 3.2.2.21 ADC\_ADCSOCxCTL\_ACQPS\_BITS

#### **Definition:**

#define ADC\_ADCSOCxCTL\_ACQPS\_BITS

## **Description:**

Defines the location of the ACQPS bits in the ADCSOCxCTL register.

## 3.2.2.22 ADC\_ADCSOCxCTL\_CHSEL\_BITS

## **Definition:**

#define ADC\_ADCSOCxCTL\_CHSEL\_BITS

### **Description:**

Defines the location of the CHSEL bits in the ADCSOCxCTL register.

## 3.2.2.23 ADC ADCSOCxCTL TRIGSEL BITS

#### **Definition:**

#define ADC\_ADCSOCxCTL\_TRIGSEL\_BITS

## **Description:**

Defines the location of the TRIGSEL bits in the ADCSOCxCTL register.

## 3.2.2.24 ADC BASE ADDR

### **Definition:**

#define ADC\_BASE\_ADDR

## **Description:**

Defines the base address of the analog-to-digital converter (ADC) registers.

## 3.2.2.25 ADC dataBias

#### **Definition:**

#define ADC\_dataBias

### **Description:**

Integer value bias corresponding to voltage 1.65V bias of input data on 3.3V, 12 bit ADC.

## 3.2.2.26 ADC DELAY usec

## **Definition:**

#define ADC\_DELAY\_usec

## **Description:**

Defines the ADC delay for part of the ADC initialization.

## 3.2.2.27 ADC\_INTSELxNy\_INTCONT\_BITS

#### **Definition:**

#define ADC\_INTSELxNy\_INTCONT\_BITS

## **Description:**

Defines the location of the INTCONT bits in the INTSELxNy register.

## 3.2.2.28 ADC\_INTSELxNy\_INTE\_BITS

## **Definition:**

#define ADC\_INTSELxNy\_INTE\_BITS

## **Description:**

Defines the location of the INTE bits in the INTSELxNy register.

## 3.2.2.29 ADC INTSELxNy INTSEL BITS

#### **Definition:**

#define ADC INTSELxNy INTSEL BITS

## **Description:**

Defines the location of the INTSEL bits in the INTSELxNy register.

## 3.2.2.30 ADC INTSELxNy LOG2 NUMBITS PER REG

### **Definition:**

#define ADC\_INTSELxNy\_LOG2\_NUMBITS\_PER\_REG

### **Description:**

Defines the log2() of the number of bits per INTSELxNy register.

## 3.2.2.31 ADC INTSELxNy NUMBITS PER REG

#### **Definition:**

#define ADC\_INTSELxNy\_NUMBITS\_PER\_REG

#### **Description:**

Defines the number of bits per INTSELxNy register.

## 3.2.3 Typedef Documentation

## 3.2.3.1 ADC Handle

#### **Definition:**

```
typedef struct ADC_Obj *ADC_Handle
```

### **Description:**

Defines the analog-to-digital converter (ADC) handle.

## 3.2.3.2 ADC Obj

## **Definition:**

```
typedef struct _ADC_Obj_ ADC_Obj
```

## **Description:**

Defines the analog-to-digital converter (ADC) object.

## 3.2.4 Enumeration Documentation

## 3.2.4.1 ADC\_IntMode\_e

### **Description:**

Enumeration to define the analog-to-digital converter (ADC) interrupt mode.

#### **Enumerators:**

**ADC\_IntMode\_ClearFlag** Denotes that a new interrupt with not be generated until the interrupt flag is cleared.

**ADC\_IntMode\_EOC** Denotes that a new interrupt with be generated on the next end of conversion (EOC).

## 3.2.4.2 ADC IntNumber e

### **Description:**

Enumeration to define the analog-to-digital converter (ADC) interrupt number.

#### **Enumerators:**

```
ADC_IntNumber_1 Denotes ADCINT1.
ADC_IntNumber_2 Denotes ADCINT2.
ADC_IntNumber_3 Denotes ADCINT3.
ADC_IntNumber_4 Denotes ADCINT4.
ADC_IntNumber_5 Denotes ADCINT5.
ADC_IntNumber_6 Denotes ADCINT6.
ADC_IntNumber_7 Denotes ADCINT7.
ADC_IntNumber_8 Denotes ADCINT8.
ADC_IntNumber_9 Denotes ADCINT9.
```

## 3.2.4.3 ADC IntPulseGenMode e

### **Description:**

Enumeration to define the analog-to-digital converter (ADC) interrupt pulse generation mode.

#### **Enumerators:**

**ADC\_IntPulseGenMode\_During** Denotes that interrupt pulse generation occurs when the ADC begins conversion.

**ADC\_IntPulseGenMode\_Prior** Denotes that interrupt pulse generation occurs 1 cycle prior to the ADC result latching.

## 3.2.4.4 ADC IntSrc e

## **Description:**

Enumeration to define the analog-to-digital converter (ADC) interrupt source.

```
ADC_IntSrc_EOC1 Denotes that interrupt source is the end of conversion for SOC1.

ADC_IntSrc_EOC2 Denotes that interrupt source is the end of conversion for SOC2.

ADC_IntSrc_EOC3 Denotes that interrupt source is the end of conversion for SOC3.

ADC_IntSrc_EOC4 Denotes that interrupt source is the end of conversion for SOC4.

ADC_IntSrc_EOC5 Denotes that interrupt source is the end of conversion for SOC5.

ADC_IntSrc_EOC6 Denotes that interrupt source is the end of conversion for SOC6.

ADC_IntSrc_EOC7 Denotes that interrupt source is the end of conversion for SOC7.

ADC_IntSrc_EOC8 Denotes that interrupt source is the end of conversion for SOC8.

ADC_IntSrc_EOC9 Denotes that interrupt source is the end of conversion for SOC9.

ADC_IntSrc_EOC10 Denotes that interrupt source is the end of conversion for SOC10.

ADC_IntSrc_EOC11 Denotes that interrupt source is the end of conversion for SOC11.

ADC_IntSrc_EOC12 Denotes that interrupt source is the end of conversion for SOC11.

ADC_IntSrc_EOC13 Denotes that interrupt source is the end of conversion for SOC13.
```

ADC\_IntSrc\_EOC14 Denotes that interrupt source is the end of conversion for SOC14.ADC\_IntSrc\_EOC15 Denotes that interrupt source is the end of conversion for SOC15.

## 3.2.4.5 ADC ResultNumber e

## Description:

Enumeration to define the analog-to-digital converter (ADC) result number.

#### **Enumerators:**

```
ADC ResultNumber 0 Denotes ADCRESULTO.
ADC_ResultNumber_1 Denotes ADCRESULT1.
ADC ResultNumber 2 Denotes ADCRESULT2.
ADC_ResultNumber_3 Denotes ADCRESULT3.
ADC_ResultNumber_4 Denotes ADCRESULT4.
ADC ResultNumber 5 Denotes ADCRESULT5.
ADC_ResultNumber_6 Denotes ADCRESULT6.
ADC ResultNumber 7 Denotes ADCRESULT7.
ADC_ResultNumber_8 Denotes ADCRESULT8.
ADC_ResultNumber_9 Denotes ADCRESULT9.
ADC_ResultNumber_10 Denotes ADCRESULT10.
ADC_ResultNumber_11 Denotes ADCRESULT11.
ADC ResultNumber 12 Denotes ADCRESULT12.
ADC_ResultNumber_13 Denotes ADCRESULT13.
ADC_ResultNumber_14 Denotes ADCRESULT14.
ADC ResultNumber 15 Denotes ADCRESULT15.
```

## 3.2.4.6 ADC SampleMode e

#### **Description:**

Enumeration to define the analog-to-digital converter (ADC) sample modes.

- **ADC\_SampleMode\_SOC0\_and\_SOC1\_Separate** Denotes SOC0 and SOC1 are sampled separately.
- **ADC\_SampleMode\_SOC2\_and\_SOC3\_Separate** Denotes SOC2 and SOC3 are sampled separately.
- **ADC\_SampleMode\_SOC4\_and\_SOC5\_Separate** Denotes SOC4 and SOC5 are sampled separately.
- **ADC\_SampleMode\_SOC6\_and\_SOC7\_Separate** Denotes SOC6 and SOC7 are sampled separately.
- **ADC\_SampleMode\_SOC8\_and\_SOC9\_Separate** Denotes SOC8 and SOC9 are sampled separately.
- **ADC\_SampleMode\_SOC10\_and\_SOC11\_Separate** Denotes SOC10 and SOC11 are sampled separately.
- **ADC\_SampleMode\_SOC12\_and\_SOC13\_Separate** Denotes SOC12 and SOC13 are sampled separately.

- **ADC\_SampleMode\_SOC14\_and\_SOC15\_Separate** Denotes SOC14 and SOC15 are sampled separately.
- **ADC\_SampleMode\_SOC0\_and\_SOC1\_Together** Denotes SOC0 and SOC1 are sampled together.
- **ADC\_SampleMode\_SOC2\_and\_SOC3\_Together** Denotes SOC2 and SOC3 are sampled together.
- **ADC\_SampleMode\_SOC4\_and\_SOC5\_Together** Denotes SOC4 and SOC5 are sampled together.
- **ADC\_SampleMode\_SOC6\_and\_SOC7\_Together** Denotes SOC6 and SOC7 are sampled together.
- **ADC\_SampleMode\_SOC8\_and\_SOC9\_Together** Denotes SOC8 and SOC9 are sampled together.
- **ADC\_SampleMode\_SOC10\_and\_SOC11\_Together** Denotes SOC10 and SOC11 are sampled together.
- **ADC\_SampleMode\_SOC12\_and\_SOC13\_Together** Denotes SOC12 and SOC13 are sampled together.
- **ADC\_SampleMode\_SOC14\_and\_SOC15\_Together** Denotes SOC14 and SOC15 are sampled together.

## 3.2.4.7 ADC\_SocChanNumber\_e

#### **Description:**

Enumeration to define the start of conversion (SOC) channel numbers.

- ADC\_SocChanNumber\_A0 Denotes SOC channel number A0.
- ADC\_SocChanNumber\_A1 Denotes SOC channel number A1.
- ADC\_SocChanNumber\_A2 Denotes SOC channel number A2.
- ADC\_SocChanNumber\_A3 Denotes SOC channel number A3.
- ADC\_SocChanNumber\_A4 Denotes SOC channel number A4.
- **ADC\_SocChanNumber\_A5** Denotes SOC channel number A5.
- ADC\_SocChanNumber\_A6 Denotes SOC channel number A6.
- ADC\_SocChanNumber\_A7 Denotes SOC channel number A7.
- ADC\_SocChanNumber\_B0 Denotes SOC channel number B0.
- ADC\_SocChanNumber\_B1 Denotes SOC channel number B1.
- ADC SocChanNumber B2 Denotes SOC channel number B2.
- ADC\_SocChanNumber\_B3 Denotes SOC channel number B3.
- ADC\_SocChanNumber\_B4 Denotes SOC channel number B4.
- ADC SocChanNumber B5 Denotes SOC channel number B5.
- ADC SocChanNumber B6 Denotes SOC channel number B6.
- ADC\_SocChanNumber\_B7 Denotes SOC channel number B7.
- **ADC\_SocChanNumber\_A0\_and\_B0\_Together** Denotes SOC channel number A0 and B0 together.
- **ADC\_SocChanNumber\_A1\_and\_B1\_Together** Denotes SOC channel number A0 and B0 together.
- **ADC\_SocChanNumber\_A2\_and\_B2\_Together** Denotes SOC channel number A0 and B0 together.

- **ADC\_SocChanNumber\_A3\_and\_B3\_Together** Denotes SOC channel number A0 and B0 together.
- **ADC\_SocChanNumber\_A4\_and\_B4\_Together** Denotes SOC channel number A0 and B0 together.
- **ADC\_SocChanNumber\_A5\_and\_B5\_Together** Denotes SOC channel number A0 and B0 together.
- **ADC\_SocChanNumber\_A6\_and\_B6\_Together** Denotes SOC channel number A0 and B0 together.
- **ADC\_SocChanNumber\_A7\_and\_B7\_Together** Denotes SOC channel number A0 and B0 together.

## 3.2.4.8 ADC SocNumber e

## **Description:**

Enumeration to define the start of conversion (SOC) numbers.

#### **Enumerators:**

- ADC\_SocNumber\_0 Denotes SOC0.
- ADC\_SocNumber\_1 Denotes SOC1.
- ADC\_SocNumber\_2 Denotes SOC2.
- ADC SocNumber 3 Denotes SOC3.
- ADC\_SocNumber\_4 Denotes SOC4.
- ADC\_SocNumber\_5 Denotes SOC5.
- ADC\_SocNumber\_6 Denotes SOC6.
- ADC\_SocNumber\_7 Denotes SOC7.
- ADC SocNumber 8 Denotes SOC8.
- ADC\_SocNumber\_9 Denotes SOC9.
- ADC SocNumber 10 Denotes SOC10.
- ADC\_SocNumber\_11 Denotes SOC11.
- ADC\_SocNumber\_12 Denotes SOC12.
- ADC\_SocNumber\_13 Denotes SOC13.
- ADC SocNumber 14 Denotes SOC14.
- ADC\_SocNumber\_15 Denotes SOC15.

## 3.2.4.9 ADC SocSampleWindow e

#### **Description:**

Enumeration to define the start of conversion (SOC) sample delays.

- ADC\_SocSampleWindow\_7\_cycles Denotes an SOC sample window of 7 cycles.
- ADC\_SocSampleWindow\_8\_cycles Denotes an SOC sample window of 8 cycles.
- **ADC\_SocSampleWindow\_9\_cycles** Denotes an SOC sample window of 9 cycles.
- ADC SocSampleWindow 10 cycles Denotes an SOC sample window of 10 cycles.
- ADC\_SocSampleWindow\_11\_cycles Denotes an SOC sample window of 11 cycles.
- ADC\_SocSampleWindow\_12\_cycles Denotes an SOC sample window of 12 cycles.

ADC\_SocSampleWindow\_13\_cycles Denotes an SOC sample window of 13 cycles. ADC\_SocSampleWindow\_14\_cycles Denotes an SOC sample window of 14 cycles. ADC\_SocSampleWindow\_15\_cycles Denotes an SOC sample window of 15 cycles. ADC\_SocSampleWindow\_16\_cycles Denotes an SOC sample window of 16 cycles. ADC SocSampleWindow 17 cycles Denotes an SOC sample window of 17 cycles. ADC\_SocSampleWindow\_18\_cycles Denotes an SOC sample window of 18 cycles. ADC SocSampleWindow\_19\_cycles Denotes an SOC sample window of 19 cycles. ADC\_SocSampleWindow\_20\_cycles Denotes an SOC sample window of 20 cycles. ADC\_SocSampleWindow\_21\_cycles Denotes an SOC sample window of 21 cycles. ADC\_SocSampleWindow\_22\_cycles Denotes an SOC sample window of 22 cycles. ADC SocSampleWindow 23 cycles Denotes an SOC sample window of 23 cycles. ADC\_SocSampleWindow\_24\_cycles Denotes an SOC sample window of 24 cycles. ADC\_SocSampleWindow\_25\_cycles Denotes an SOC sample window of 25 cycles. ADC\_SocSampleWindow\_26\_cycles Denotes an SOC sample window of 26 cycles. ADC\_SocSampleWindow\_27\_cycles Denotes an SOC sample window of 27 cycles. ADC SocSampleWindow 28 cycles Denotes an SOC sample window of 28 cycles. ADC\_SocSampleWindow\_29\_cycles Denotes an SOC sample window of 29 cycles. ADC\_SocSampleWindow\_30\_cycles Denotes an SOC sample window of 30 cycles. ADC SocSampleWindow 31 cycles Denotes an SOC sample window of 31 cycles. ADC\_SocSampleWindow\_32\_cycles Denotes an SOC sample window of 32 cycles. ADC\_SocSampleWindow\_33\_cycles Denotes an SOC sample window of 33 cycles. ADC SocSampleWindow 34 cycles Denotes an SOC sample window of 34 cycles. ADC\_SocSampleWindow\_35\_cycles Denotes an SOC sample window of 35 cycles. Denotes an SOC sample window of 36 cycles. ADC SocSampleWindow 36 cycles ADC SocSampleWindow 37 cycles Denotes an SOC sample window of 37 cycles. ADC\_SocSampleWindow\_38\_cycles Denotes an SOC sample window of 38 cycles. ADC\_SocSampleWindow\_39\_cycles Denotes an SOC sample window of 39 cycles. ADC SocSampleWindow 40 cycles Denotes an SOC sample window of 40 cycles. ADC\_SocSampleWindow\_41\_cycles Denotes an SOC sample window of 41 cycles. ADC SocSampleWindow 42 cycles Denotes an SOC sample window of 42 cycles. ADC\_SocSampleWindow\_43\_cycles Denotes an SOC sample window of 43 cycles. ADC SocSampleWindow 44 cycles Denotes an SOC sample window of 44 cycles. ADC\_SocSampleWindow\_45\_cycles Denotes an SOC sample window of 45 cycles. Denotes an SOC sample window of 46 cycles. ADC SocSampleWindow 46 cycles ADC SocSampleWindow 47 cycles Denotes an SOC sample window of 47 cycles. ADC\_SocSampleWindow\_48\_cycles Denotes an SOC sample window of 48 cycles. ADC\_SocSampleWindow\_49\_cycles Denotes an SOC sample window of 49 cycles. ADC SocSampleWindow 50 cycles Denotes an SOC sample window of 50 cycles. ADC\_SocSampleWindow\_51\_cycles Denotes an SOC sample window of 51 cycles. Denotes an SOC sample window of 52 cycles. ADC SocSampleWindow 52 cycles ADC\_SocSampleWindow\_53\_cycles Denotes an SOC sample window of 53 cycles. ADC\_SocSampleWindow\_54\_cycles Denotes an SOC sample window of 54 cycles. ADC SocSampleWindow 55 cycles Denotes an SOC sample window of 55 cycles. ADC\_SocSampleWindow\_56\_cycles Denotes an SOC sample window of 56 cycles. ADC\_SocSampleWindow\_57\_cycles Denotes an SOC sample window of 57 cycles. ADC SocSampleWindow 58 cycles Denotes an SOC sample window of 58 cycles. ADC\_SocSampleWindow\_59\_cycles

ADC\_SocSampleWindow\_60\_cycles

Denotes an SOC sample window of 59 cycles.

Denotes an SOC sample window of 60 cycles.

Denotes an SOC sample window of 61 cycles.

Denotes an SOC sample window of 62 cycles.

Denotes an SOC sample window of 62 cycles.

Denotes an SOC sample window of 63 cycles.

Denotes an SOC sample window of 63 cycles.

Denotes an SOC sample window of 64 cycles.

Denotes an SOC sample window of 64 cycles.

Denotes an SOC sample window of 64 cycles.

## 3.2.4.10 ADC\_SocTrigSrc\_e

## **Description:**

Enumeration to define the start of conversion (SOC) trigger source.

#### **Enumerators:**

**ADC\_SocTrigSrc\_Sw** Denotes a software trigger source for the SOC flag.

ADC\_SocTrigSrc\_CpuTimer\_0 Denotes a CPUTIMER0 trigger source for the SOC flag.

ADC\_SocTrigSrc\_CpuTimer\_1 Denotes a CPUTIMER1 trigger source for the SOC flag.

ADC\_SocTrigSrc\_CpuTimer\_2 Denotes a CPUTIMER2 trigger source for the SOC flag.

**ADC\_SocTrigSrc\_XINT2\_XINT2SOC** Denotes a XINT2, XINT2SOC trigger source for the SOC flag.

ADC\_SocTrigSrc\_EPWM1\_ADCSOCA Denotes a EPWM1, ADCSOCA trigger source for the SOC flag.

**ADC\_SocTrigSrc\_EPWM1\_ADCSOCB** Denotes a EPWM1, ADCSOCB trigger source for the SOC flag.

**ADC\_SocTrigSrc\_EPWM2\_ADCSOCA** Denotes a EPWM2, ADCSOCA trigger source for the SOC flag.

**ADC\_SocTrigSrc\_EPWM2\_ADCSOCB** Denotes a EPWM2, ADCSOCB trigger source for the SOC flag.

**ADC\_SocTrigSrc\_EPWM3\_ADCSOCA** Denotes a EPWM3, ADCSOCA trigger source for the SOC flag.

**ADC\_SocTrigSrc\_EPWM3\_ADCSOCB** Denotes a EPWM3, ADCSOCB trigger source for the SOC flag.

**ADC\_SocTrigSrc\_EPWM4\_ADCSOCA** Denotes a EPWM4, ADCSOCA trigger source for the SOC flag.

**ADC\_SocTrigSrc\_EPWM4\_ADCSOCB** Denotes a EPWM4, ADCSOCB trigger source for the SOC flag.

**ADC\_SocTrigSrc\_EPWM5\_ADCSOCA** Denotes a EPWM5, ADCSOCA trigger source for the SOC flag.

ADC\_SocTrigSrc\_EPWM5\_ADCSOCB Denotes a EPWM5, ADCSOCB trigger source for the SOC flag.

**ADC\_SocTrigSrc\_EPWM6\_ADCSOCA** Denotes a EPWM6, ADCSOCA trigger source for the SOC flag.

**ADC\_SocTrigSrc\_EPWM6\_ADCSOCB** Denotes a EPWM7, ADCSOCB trigger source for the SOC flag.

**ADC\_SocTrigSrc\_EPWM7\_ADCSOCA** Denotes a EPWM7, ADCSOCA trigger source for the SOC flag.

**ADC\_SocTrigSrc\_EPWM7\_ADCSOCB** Denotes a EPWM7, ADCSOCB trigger source for the SOC flag.

## 3.2.4.11 ADC\_VoltageRefSrc\_e

## **Description:**

Enumeration to define the voltage reference source.

### **Enumerators:**

ADC\_VoltageRefSrc\_Int Denotes an internal voltage reference source.ADC\_VoltageRefSrc\_Ext Denotes an internal voltage reference source.

## 3.2.5 Function Documentation

## 3.2.5.1 ADC clearIntFlag

Clears the analog-to-digital converter (ADC) interrupt flag.

## Prototype:

### Parameters:

- ← adcHandle The analog-to-digital converter (ADC) object handle
- ← *intNumber* The ADC interrupt number

## 3.2.5.2 void ADC disable (ADC Handle adcHandle)

Disables the analog-to-digital converter (ADC).

#### Parameters:

← adcHandle The analog-to-digital converter (ADC) object handle

## 3.2.5.3 void ADC\_disableBandGap (ADC\_Handle adcHandle)

Disables the analog-to-digital converter (ADC) band gap circuit.

#### Parameters:

← *adcHandle* The analog-to-digital converter (ADC) object handle

# 3.2.5.4 void ADC\_disableInt (ADC\_Handle adcHandle, const ADC\_IntNumber\_e intNumber)

Disables the analog-to-digital converter (ADC) interrupt.

## Parameters:

- ← adcHandle The analog-to-digital converter (ADC) object handle
- ← *intNumber* The interrupt number

3.2.5.5 void ADC disableRefBuffers (ADC Handle adcHandle)

Disables the analog-to-digital converter (ADC) reference buffers circuit.

### Parameters:

← adcHandle The analog-to-digital converter (ADC) object handle

3.2.5.6 void ADC disableTempSensor (ADC Handle adcHandle)

Disables temperature sensor for conversion on A5.

## Parameters:

← adcHandle The analog-to-digital converter (ADC) object handle

3.2.5.7 void ADC enable (ADC Handle adcHandle)

Enables the analog-to-digital converter (ADC).

#### Parameters:

← adcHandle The analog-to-digital converter (ADC) object handle

3.2.5.8 void ADC enableBandGap (ADC Handle adcHandle)

Enables the analog-to-digital converter (ADC) band gap circuit.

#### Parameters:

← adcHandle The analog-to-digital converter (ADC) object handle

3.2.5.9 void ADC\_enableInt (ADC\_Handle adcHandle, const ADC\_IntNumber\_e intNumber)

Enables the analog-to-digital converter (ADC) interrupt.

#### Parameters:

- ← *adcHandle* The analog-to-digital converter (ADC) object handle
- $\leftarrow$  *intNumber* The interrupt number

3.2.5.10 void ADC enableRefBuffers (ADC Handle adcHandle)

Enables the analog-to-digital converter (ADC) reference buffers circuit.

## Parameters:

← adcHandle The analog-to-digital converter (ADC) object handle

## 3.2.5.11 void ADC enableTempSensor (ADC Handle adcHandle)

Enables temperature sensor for conversion on A5.

### Parameters:

- ← adcHandle The analog-to-digital converter (ADC) object handle
- 3.2.5.12 void ADC\_forceConversion (ADC\_Handle adcHandle, const ADC\_SocNumber\_e socNumber) [inline]

Reads the specified ADC result (i.e. value).

#### Parameters:

- ← *adcHandle* The ADC handle
- ← *resultNumber* The result number for the ADCRESULT registers

#### Returns:

The ADC result

3.2.5.13 bool\_t ADC\_getIntStatus (ADC\_Handle adcHandle, const ADC\_IntNumber\_e intNumber) [inline]

Reads the status for a given ADC interrupt.

#### Parameters:

- ← adcHandle The analog-to-digital converter (ADC) object handle
- ← *intNumber* The ADC interrupt number

### Returns:

Interrupt status for selected ADC interrupt

3.2.5.14 ADC\_SocSampleWindow\_e ADC\_getSocSampleWindow (ADC\_Handle adcHandle, const ADC\_SocNumber e socNumber) [inline]

Gets the analog-to-digital converter (ADC) start-of-conversion (SOC) sample delay value.

## Parameters:

- ← adcHandle The analog-to-digital converter (ADC) object handle
- $\leftarrow$  **socNumber** The SOC number

## Returns:

The ADC sample delay value

# 3.2.5.15 int16\_t ADC\_getTemperatureC (ADC\_Handle adcHandle, int16\_t sensorSample) [inline]

Converts a temperature sensor sample into a temperature in Celcius.

#### Parameters:

← adcHandle The analog-to-digital converter (ADC) object handle

#### Returns:

Temperature in degrees Celcius

# 3.2.5.16 int16\_t ADC\_getTemperatureK (ADC\_Handle adcHandle, int16\_t sensorSample) [inline]

Converts a temperature sensor sample into a temperature in Kelvin.

#### Parameters:

← adcHandle The analog-to-digital converter (ADC) object handle

### Returns:

Temperature in degrees Kelvin

## 3.2.5.17 ADC Handle ADC init (void \* pMemory, const size t numBytes)

Initializes the analog-to-digital converter (ADC) object handle.

## Parameters:

- ← *pMemory* A pointer to the base address of the ADC registers
- ← *numBytes* The number of bytes allocated for the ADC object, bytes

## Returns:

The analog-to-digital converter (ADC) object handle

## 3.2.5.18 void ADC\_powerDown (ADC\_Handle adcHandle)

Powers down the analog-to-digital converter (ADC).

## Parameters:

← adcHandle The analog-to-digital converter (ADC) object handle

## 3.2.5.19 void ADC\_powerUp (ADC\_Handle adcHandle)

Powers up the analog-to-digital converter (ADC).

#### Parameters:

← adcHandle The analog-to-digital converter (ADC) object handle

3.2.5.20 uint\_least16\_t ADC\_readResult (ADC\_Handle adcHandle, const ADC\_ResultNumber\_e resultNumber) [inline]

Reads the specified ADC result (i.e. value).

#### Parameters:

- ← adcHandle The ADC handle
- ← *resultNumber* The result number for the ADCRESULT registers

#### Returns:

The ADC result

3.2.5.21 void ADC reset (ADC Handle adcHandle)

Resets the analog-to-digital converter (ADC).

#### Parameters:

- ← adcHandle The analog-to-digital converter (ADC) object handle
- 3.2.5.22 void ADC\_setIntMode (ADC\_Handle adcHandle, const ADC\_IntNumber\_e intNumber, const ADC\_IntMode\_e intMode)

Sets the interrupt mode.

#### Parameters:

- ← *adcHandle* The analog-to-digital converter (ADC) object handle
- ← *intNumber* The interrupt number
- ← *intMode* The interrupt mode
- 3.2.5.23 void ADC\_setIntPulseGenMode (ADC\_Handle adcHandle, const ADC\_IntPulseGenMode\_e pulseMode)

Sets the interrupt pulse generation mode.

#### Parameters:

- ← adcHandle The analog-to-digital converter (ADC) object handle
- ← *pulseMode* The pulse generation mode
- 3.2.5.24 void ADC\_setIntSrc (ADC\_Handle adcHandle, const ADC\_IntNumber\_e intNumber, const ADC\_IntSrc\_e intSrc)

Sets the interrupt source.

## Parameters:

← adcHandle The analog-to-digital converter (ADC) object handle

- ← *intNumber* The interrupt number
- ← intSrc The interrupt source
- 3.2.5.25 void ADC\_setSampleMode (ADC\_Handle adcHandle, const ADC\_SampleMode\_e sampleMode)

Sets the sample mode.

### Parameters:

- ← adcHandle The analog-to-digital converter (ADC) object handle
- ← *sampleMode* The sample mode
- 3.2.5.26 void ADC\_setSocChanNumber (ADC\_Handle adcHandle, const ADC\_SocNumber\_e socNumber, const ADC\_SocChanNumber\_e chanNumber)

Sets the start-of-conversion (SOC) channel number.

#### Parameters:

- ← adcHandle The analog-to-digital converter (ADC) object handle
- $\leftarrow$  **socNumber** The SOC number
- ← *chanNumber* The channel number
- 3.2.5.27 void ADC\_setSocSampleWindow (ADC\_Handle adcHandle, const ADC\_SocNumber\_e socNumber, const ADC\_SocSampleWindow\_e sampleWindow)

Sets the start-of-conversion (SOC) sample delay.

## Parameters:

- ← adcHandle The analog-to-digital converter (ADC) object handle
- ← **socNumber** The SOC number
- ← sampleDelay The sample delay
- 3.2.5.28 void ADC\_setSocTrigSrc (ADC\_Handle adcHandle, const ADC\_SocNumber\_e socNumber, const ADC\_SocTrigSrc\_e trigSrc)

Sets the start-of-conversion (SOC) trigger source.

## Parameters:

- ← adcHandle The analog-to-digital converter (ADC) object handle
- ← *socNumber* The SOC number
- ← trigSrc The trigger delay

# 3.2.5.29 void ADC\_setVoltRefSrc (ADC\_Handle adcHandle, const ADC\_VoltageRefSrc\_e voltRef)

Sets the voltage reference source.

## Parameters:

- $\leftarrow$  *adcHandle* The analog-to-digital converter (ADC) object handle
- ← *voltRef* The voltage reference source

# 4 Capture (CAP)

Introduction	33
API Functions	33

## 4.1 Introduction

The Enhanced Capture (CAP) API provides a set of functions and data structs for configuring and capturing data as well as generating PWMs with the capture peripheral.

This driver is contained in  $f2802x0\_common/source/cap.c$ , with  $f2802x0\_common/include/cap.h$  containing the API definitions and data structs for use by applications.

## 4.2 CAP

## **Data Structures**

\_CAP\_Obj\_

## **Defines**

- CAP ECCTL1 CAP1POL BITS
- CAP\_ECCTL1\_CAP2POL\_BITS
- CAP\_ECCTL1\_CAP3POL\_BITS
- CAP ECCTL1 CAP4POL BITS
- CAP\_ECCTL1\_CAPLDEN\_BITS
- CAP\_ECCTL1\_CTRRST1\_BITS
- CAP\_ECCTL1\_CTRRST2\_BITS
- CAP ECCTL1 CTRRST3 BITS
- CAP\_ECCTL1\_CTRRST4\_BITS
- CAP ECCTL1 FREESOFT BITS
- CAP\_ECCTL1\_PRESCALE\_BITS
- CAP ECCTL2 APWMPOL BITS
- CAP\_ECCTL2\_CAPAPWM\_BITS
- CAP\_ECCTL2\_CONTONESHOT\_BITS
- CAP ECCTL2 REARM BITS
- CAP\_ECCTL2\_STOP\_WRAP\_BITS
- CAP ECCTL2 SWSYNC BITS
- CAP\_ECCTL2\_SYNCIEN\_BITS
- CAP ECCTL2 SYNCOSEL BITS
- CAP\_ECCTL2\_TSCTRSTOP\_BITS
- CAP\_ECCxxx\_CEVT1\_BITS

Tue Jul 24 10:01:42 CDT 2012

- CAP ECCxxx CEVT2 BITS
- CAP ECCxxx CEVT3 BITS
- CAP\_ECCxxx\_CEVT4\_BITS
- CAP ECCxxx CTRCOMP BITS
- CAP\_ECCxxx\_CTROVF\_BITS
- CAP ECCxxx CTRPRD BITS
- CAP\_ECCxxx\_INT BITS
- CAPA BASE ADDR

## **Enumerations**

- CAP Event e
- CAP Int Type e
- CAP Polarity e
- CAP Prescale e
- CAP\_Reset\_e
- CAP RunMode e
- CAP\_SyncOut\_e

## **Functions**

- void CAP\_clearInt (CAP\_Handle capHandle, const CAP\_Int\_Type\_e intType)
- void CAP disableCaptureLoad (CAP Handle capHandle)
- void CAP\_disableInt (CAP\_Handle capHandle, const CAP\_Int\_Type\_e intType)
- void CAP disableSyncIn (CAP Handle capHandle)
- void CAP\_disableTimestampCounter (CAP\_Handle capHandle)
- void CAP enableCaptureLoad (CAP Handle capHandle)
- void CAP\_enableInt (CAP\_Handle capHandle, const CAP\_Int\_Type\_e intType)
- void CAP enableSyncIn (CAP Handle capHandle)
- void CAP\_enableTimestampCounter (CAP\_Handle capHandle)
- uint32\_t CAP\_getCap1 (CAP\_Handle capHandle)
- uint32 t CAP getCap2 (CAP Handle capHandle)
- uint32\_t CAP\_getCap3 (CAP\_Handle capHandle)
- uint32\_t CAP\_getCap4 (CAP\_Handle capHandle)
- CAP Handle CAP init (void \*pMemory, const size t numBytes)
- void CAP\_rearm (CAP\_Handle capHandle)
- void CAP\_setApwmCompare (CAP\_Handle capHandle, const uint32\_t compare)
- void CAP\_setApwmPeriod (CAP\_Handle capHandle, const uint32\_t period)
- void CAP\_setCapContinuous (CAP\_Handle capHandle)
- void CAP\_setCapEvtPolarity (CAP\_Handle capHandle, const CAP\_Event\_e event, const CAP\_Polarity\_e polarity)
- void CAP\_setCapEvtReset (CAP\_Handle capHandle, const CAP\_Event\_e event, const CAP\_Reset\_e reset)
- void CAP\_setCapOneShot (CAP\_Handle capHandle)
- void CAP\_setModeApwm (CAP\_Handle capHandle)

- void CAP setModeCap (CAP Handle capHandle)
- void CAP\_setStopWrap (CAP\_Handle capHandle, const CAP\_Stop\_Wrap\_e stopWrap)
- void CAP\_setSyncOut (CAP\_Handle capHandle, const CAP\_SyncOut\_e syncOut)

## 4.2.1 Data Structure Documentation

## 4.2.1.1 \_CAP\_Obj\_

### **Definition:**

```
typedef struct
{
    uint32_t TSCTR;
    uint32_t CAPHS;
    uint32_t CAP1;
    uint32_t CAP2;
    uint32_t CAP4;
    uint32_t CAP4;
    uint16_t Rsvd_1[8];
    uint16_t ECCTL1;
    uint16_t ECCTL2;
    uint16_t ECEINT;
    uint16_t ECEFLG;
    uint16_t ECEFLG;
    uint16_t ECEFLG;
    uint16_t ECEFLG;
    uint16_t ECEFLG;
}
_CAP_Obj_
```

#### Members:

TSCTR Time-stamp Counter.

CTRPHS Counter Phase Offset Value Register.

CAP1 Capture 1 Register.

CAP2 Capture 2 Register.

CAP3 Capture 3 Register.

CAP4 Capture 4 Register.

Rsvd\_1 Reserved.

ECCTL1 Capture Control Register 1.

ECCTL2 Capture Control Register 2.

**ECEINT** Capture Interrupt Enable Register.

**ECEFLG** Capture Interrupt Flag Register.

ECECLR Capture Interrupt Clear Register.

ECEFRC Capture Interrupt Force Register.

### **Description:**

Defines the capture (CAP) object.

## 4.2.2 Define Documentation

## 4.2.2.1 CAP\_ECCTL1\_CAP1POL\_BITS

## **Definition:**

#define CAP\_ECCTL1\_CAP1POL\_BITS

## **Description:**

Defines the location of the CAP1POL bits in the ECCTL1 register.

## 4.2.2.2 CAP\_ECCTL1\_CAP2POL\_BITS

## **Definition:**

#define CAP\_ECCTL1\_CAP2POL\_BITS

## **Description:**

Defines the location of the CAP2POL bits in the ECCTL1 register.

## 4.2.2.3 CAP ECCTL1 CAP3POL BITS

#### **Definition:**

#define CAP\_ECCTL1\_CAP3POL\_BITS

## **Description:**

Defines the location of the CAP3POL bits in the ECCTL1 register.

## 4.2.2.4 CAP\_ECCTL1\_CAP4POL\_BITS

#### **Definition:**

#define CAP\_ECCTL1\_CAP4POL\_BITS

### **Description:**

Defines the location of the CAP4POL bits in the ECCTL1 register.

## 4.2.2.5 CAP\_ECCTL1\_CAPLDEN\_BITS

### **Definition:**

#define CAP\_ECCTL1\_CAPLDEN\_BITS

### **Description:**

Defines the location of the CAPLDEN bits in the ECCTL1 register.

## 4.2.2.6 CAP ECCTL1 CTRRST1 BITS

#### **Definition:**

#define CAP\_ECCTL1\_CTRRST1\_BITS

#### **Description:**

Defines the location of the CTRRST1 bits in the ECCTL1 register.

## 4.2.2.7 CAP ECCTL1 CTRRST2 BITS

#### **Definition:**

#define CAP\_ECCTL1\_CTRRST2\_BITS

### **Description:**

Defines the location of the CTRRST2 bits in the ECCTL1 register.

# 4.2.2.8 CAP ECCTL1 CTRRST3 BITS

#### **Definition:**

#define CAP\_ECCTL1\_CTRRST3\_BITS

#### **Description:**

Defines the location of the CTRRST3 bits in the ECCTL1 register.

# 4.2.2.9 CAP\_ECCTL1\_CTRRST4\_BITS

## **Definition:**

#define CAP\_ECCTL1\_CTRRST4\_BITS

#### **Description:**

Defines the location of the CTRRST4 bits in the ECCTL1 register.

## 4.2.2.10 CAP ECCTL1 FREESOFT BITS

## **Definition:**

#define CAP\_ECCTL1\_FREESOFT\_BITS

#### **Description:**

Defines the location of the FREE/SOFT bits in the ECCTL1 register.

# 4.2.2.11 CAP ECCTL1 PRESCALE BITS

#### **Definition:**

#define CAP\_ECCTL1\_PRESCALE\_BITS

#### **Description:**

Defines the location of the PRESCALE bits in the ECCTL1 register.

## 4.2.2.12 CAP ECCTL2 APWMPOL BITS

#### **Definition:**

#define CAP\_ECCTL2\_APWMPOL\_BITS

#### **Description:**

Defines the location of the APWMPOL bits in the ECCTL2 register.

# 4.2.2.13 CAP\_ECCTL2\_CAPAPWM\_BITS

#### **Definition:**

#define CAP\_ECCTL2\_CAPAPWM\_BITS

### **Description:**

Defines the location of the CAP/APWM bits in the ECCTL2 register.

# 4.2.2.14 CAP ECCTL2 CONTONESHOT BITS

#### **Definition:**

#define CAP\_ECCTL2\_CONTONESHOT\_BITS

#### **Description:**

Defines the location of the CONT/ONESHOT bits in the ECCTL2 register.

## 4.2.2.15 CAP ECCTL2 REARM BITS

#### **Definition:**

#define CAP\_ECCTL2\_REARM\_BITS

#### **Description:**

Defines the location of the REARM bits in the ECCTL2 register.

# 4.2.2.16 CAP\_ECCTL2\_STOP\_WRAP\_BITS

## **Definition:**

#define CAP\_ECCTL2\_STOP\_WRAP\_BITS

#### **Description:**

Defines the location of the STOP\_WRAP bits in the ECCTL2 register.

# 4.2.2.17 CAP\_ECCTL2\_SWSYNC\_BITS

#### **Definition:**

#define CAP\_ECCTL2\_SWSYNC\_BITS

#### **Description:**

38

Defines the location of the SWSYNC bits in the ECCTL2 register.

## 4.2.2.18 CAP ECCTL2 SYNCIEN BITS

#### **Definition:**

#define CAP\_ECCTL2\_SYNCIEN\_BITS

#### **Description:**

Defines the location of the SYNCI\_EN bits in the ECCTL2 register.

# 4.2.2.19 CAP\_ECCTL2\_SYNCOSEL\_BITS

#### **Definition:**

#define CAP\_ECCTL2\_SYNCOSEL\_BITS

## **Description:**

Defines the location of the SYNCO\_SEL bits in the ECCTL2 register.

# 4.2.2.20 CAP ECCTL2 TSCTRSTOP BITS

#### **Definition:**

#define CAP\_ECCTL2\_TSCTRSTOP\_BITS

#### **Description:**

Defines the location of the TSCTRSTOP bits in the ECCTL2 register.

# 4.2.2.21 CAP\_ECCxxx\_CEVT1\_BITS

## **Definition:**

#define CAP\_ECCxxx\_CEVT1\_BITS

#### **Description:**

Defines the location of the CEVT4 bits in the ECCxxx register.

## 4.2.2.22 CAP ECCxxx CEVT2 BITS

## **Definition:**

#define CAP\_ECCxxx\_CEVT2\_BITS

#### **Description:**

Defines the location of the CEVT4 bits in the ECCxxx register.

# 4.2.2.23 CAP ECCxxx CEVT3 BITS

#### **Definition:**

#define CAP\_ECCxxx\_CEVT3\_BITS

#### **Description:**

Defines the location of the CEVT4 bits in the ECCxxx register.

- . . .

# 4.2.2.24 CAP\_ECCxxx\_CEVT4\_BITS

## **Definition:**

#define CAP\_ECCxxx\_CEVT4\_BITS

#### **Description:**

Defines the location of the CEVT4 bits in the ECCxxx register.

# 4.2.2.25 CAP\_ECCxxx\_CTRCOMP\_BITS

#### **Definition:**

#define CAP\_ECCxxx\_CTRCOMP\_BITS

## **Description:**

Defines the location of the CTR=COMP bits in the ECCxxx register.

# 4.2.2.26 CAP\_ECCxxx\_CTROVF\_BITS

#### **Definition:**

#define CAP\_ECCxxx\_CTROVF\_BITS

#### **Description:**

Defines the location of the CTROVF bits in the ECCxxx register.

# 4.2.2.27 CAP ECCxxx CTRPRD BITS

#### **Definition:**

#define CAP\_ECCxxx\_CTRPRD\_BITS

#### **Description:**

Defines the location of the CTR=PRD bits in the ECCxxx register.

# 4.2.2.28 CAP\_ECCxxx\_INT\_BITS

#### **Definition:**

#define CAP\_ECCxxx\_INT\_BITS

## **Description:**

Defines the location of the INT bits in the ECCxxx register.

## 4.2.2.29 CAPA BASE ADDR

#### **Definition:**

#define CAPA\_BASE\_ADDR

## **Description:**

Defines the base address of the capture (CAP) A registers.

# 4.2.3 Typedef Documentation

# 4.2.3.1 CAP Handle

#### **Definition:**

```
typedef struct CAP_Obj *CAP_Handle
```

#### **Description:**

Defines the capture (CAP) handle.

## 4.2.3.2 CAP Obj

#### **Definition:**

```
typedef struct _CAP_Obj_ CAP_Obj
```

#### **Description:**

Defines the capture (CAP) object.

# 4.2.4 Enumeration Documentation

# 4.2.4.1 CAP Event e

### **Description:**

Enumeration to define the capture (CAP) events.

#### **Enumerators:**

```
CAP_Event_1 Capture Event 1.
```

CAP\_Event\_2 Capture Event 2.

CAP\_Event\_3 Capture Event 3.

CAP\_Event\_4 Capture Event 4.

# 4.2.4.2 CAP\_Int\_Type\_e

#### **Description:**

Enumeration to define the capture (CAP) interrupts.

#### **Enumerators:**

```
CAP_Int_Type_CTR_CMP Denotes CTR = CMP interrupt.
```

**CAP\_Int\_Type\_CTR\_PRD** Denotes CTR = PRD interrupt.

CAP\_Int\_Type\_CTR\_OVF Denotes CTROVF interrupt.

*CAP\_Int\_Type\_CEVT4* Denotes CEVT4 interrupt.

CAP\_Int\_Type\_CEVT3 Denotes CEVT3 interrupt.

CAP\_Int\_Type\_CEVT2 Denotes CEVT2 interrupt.

CAP\_Int\_Type\_CEVT1 Denotes CEVT1 interrupt.

CAP\_Int\_Type\_Global Denotes Capture global interrupt.

CAP\_Int\_Type\_All Denotes All interrupts.

## 4.2.4.3 CAP Polarity e

## Description:

Enumeration to define the capture (CAP) event polarities.

#### **Enumerators:**

```
CAP_Polarity_Rising Rising Edge Triggered. CAP_Polarity_Falling Falling Edge Triggered.
```

## 4.2.4.4 CAP Prescale e

#### **Description:**

Enumeration to define the capture (CAP) prescaler values.

#### **Enumerators:**

```
CAP_Prescale_By_1 Divide by 1.
CAP_Prescale_By_2 Divide by 2.
CAP_Prescale_By_4 Divide by 4.
CAP_Prescale_By_6 Divide by 6.
CAP_Prescale_By_8 Divide by 8.
CAP_Prescale_By_10 Divide by 10.
CAP_Prescale_By_12 Divide by 12.
CAP_Prescale_By_14 Divide by 14.
CAP_Prescale_By_16 Divide by 16.
CAP_Prescale_By_18 Divide by 18.
CAP_Prescale_By_20 Divide by 20.
CAP_Prescale_By_22 Divide by 22.
CAP_Prescale_By_24 Divide by 24.
CAP_Prescale_By_26 Divide by 26.
CAP Prescale By 28 Divide by 28.
CAP Prescale By 30 Divide by 30.
CAP_Prescale_By_32 Divide by 32.
CAP Prescale By 34 Divide by 34.
CAP_Prescale_By_36 Divide by 36.
CAP_Prescale_By_38 Divide by 38.
CAP_Prescale_By_40 Divide by 40.
CAP_Prescale_By_42 Divide by 42.
CAP_Prescale_By_44 Divide by 44.
CAP Prescale By 46 Divide by 46.
CAP Prescale By 48 Divide by 48.
CAP Prescale By 50 Divide by 50.
CAP_Prescale_By_52 Divide by 52.
CAP_Prescale_By_54 Divide by 54.
CAP_Prescale_By_56 Divide by 56.
CAP_Prescale_By_58 Divide by 58.
CAP_Prescale_By_60 Divide by 60.
```

42

CAP\_Prescale\_By\_62 Divide by 62.

## 4.2.4.5 CAP Reset e

#### **Description:**

Enumeration to define the capture (CAP) event resets.

#### **Enumerators:**

**CAP\_Reset\_Disable** Disable counter reset on capture event. **CAP\_Reset\_Enable** Enable counter reset on capture event.

# 4.2.4.6 CAP RunMode e

#### **Description:**

Enumeration to define the pulse width modulation (PWM) run modes.

# 4.2.4.7 enum CAP\_Stop\_Wrap\_e

Enumeration to define the capture (CAP) Stop/Wrap modes.

#### **Enumerators:**

```
    CAP_Stop_Wrap_CEVT1 Stop/Wrap after Capture Event 1.
    CAP_Stop_Wrap_CEVT2 Stop/Wrap after Capture Event 2.
    CAP_Stop_Wrap_CEVT3 Stop/Wrap after Capture Event 3.
    CAP_Stop_Wrap_CEVT4 Stop/Wrap after Capture Event 4.
```

## 4.2.4.8 CAP SyncOut e

#### **Description:**

Enumeration to define the Sync Out options.

#### **Enumerators:**

```
CAP_SyncOut_SyncInSync In used for Sync Out.CAP_SyncOut_CTRPRDCTR = PRD used for Sync Out.CAP_SyncOut_DisableDisables Sync Out.
```

# 4.2.5 Function Documentation

## 4.2.5.1 CAP clearInt

Clears capture (CAP) interrupt flag.

#### Prototype:

## Parameters:

← *capHandle* The capture (CAP) object handle

← *intType* The capture interrupt to be cleared

## 4.2.5.2 void CAP disableCaptureLoad (CAP Handle capHandle)

Disables loading of CAP1-4 on capture event.

#### Parameters:

← *capHandle* The capture (CAP) object handle

## 4.2.5.3 void CAP disableInt (CAP Handle capHandle, const CAP Int Type e intType)

Disables capture (CAP) interrupt source.

#### Parameters:

- ← *capHandle* The capture (CAP) object handle
- ← *intType* The capture interrupt type to be disabled

# 4.2.5.4 void CAP\_disableSyncIn (CAP\_Handle capHandle)

Disables counter synchronization.

#### Parameters:

← *capHandle* The capture (CAP) object handle

## 4.2.5.5 void CAP disableTimestampCounter (CAP Handle capHandle)

Disables Time Stamp counter from running.

#### Parameters:

← *capHandle* The capture (CAP) object handle

## 4.2.5.6 void CAP enableCaptureLoad (CAP Handle capHandle)

Enables loading of CAP1-4 on capture event.

## Parameters:

← *capHandle* The capture (CAP) object handle

# 4.2.5.7 void CAP\_enableInt (CAP\_Handle capHandle, const CAP\_Int\_Type\_e intType)

Enables capture (CAP) interrupt source.

- ← capHandle The capture (CAP) object handle
- ← *intType* The capture interrupt type to be enabled

4.2.5.8 void CAP\_enableSyncIn (CAP\_Handle capHandle)

Enables counter synchronization.

#### Parameters:

- ← *capHandle* The capture (CAP) object handle
- 4.2.5.9 void CAP enableTimestampCounter (CAP Handle capHandle)

Enables Time Stamp counter to running.

### Parameters:

- ← *capHandle* The capture (CAP) object handle
- 4.2.5.10 uint32\_t CAP\_getCap1 (CAP\_Handle capHandle) [inline]

Gets the CAP1 register value.

- Parameters:
  - ← *capHandle* The capture (CAP) object handle
- 4.2.5.11 uint32\_t CAP\_getCap2 (CAP\_Handle capHandle) [inline]

Gets the CAP2 register value.

#### Parameters:

- ← *capHandle* The capture (CAP) object handle
- 4.2.5.12 uint32\_t CAP\_getCap3 (CAP\_Handle capHandle) [inline]

Gets the CAP3 register value.

#### Parameters:

- $\leftarrow$  *capHandle* The capture (CAP) object handle
- 4.2.5.13 uint32\_t CAP\_getCap4 (CAP\_Handle capHandle) [inline]

Gets the CAP4 register value.

#### Parameters:

← *capHandle* The capture (CAP) object handle

4.2.5.14 CAP Handle CAP init (void \* pMemory, const size t numBytes)

Initializes the capture (CAP) object handle.

#### Parameters:

- ← *pMemory* A pointer to the base address of the CAP registers
- ← *numBytes* The number of bytes allocated for the CAP object, bytes

#### Returns:

The capture (CAP) object handle

4.2.5.15 void CAP\_rearm (CAP\_Handle capHandle) [inline]

(Re-)Arm the capture module

#### Parameters:

- ← *capHandle* The capture (CAP) object handle
- 4.2.5.16 void CAP\_setApwmCompare (CAP\_Handle capHandle, const uint32\_t compare) [inline]

Sets the APWM compare value.

#### Parameters:

- ← *capHandle* The capture (CAP) object handle
- $\leftarrow$  *compare* The APWM compare value
- 4.2.5.17 void CAP\_setApwmPeriod (CAP\_Handle capHandle, const uint32\_t period) [inline]

Sets the APWM period.

#### Parameters:

- ← *capHandle* The capture (CAP) object handle
- ← *period* The APWM period
- 4.2.5.18 void CAP setCapContinuous (CAP Handle capHandle)

Sets up for continuous Capture.

## Parameters:

← *capHandle* The capture (CAP) object handle

4.2.5.19 void CAP\_setCapEvtPolarity (CAP\_Handle capHandle, const CAP\_Event\_e event, const CAP\_Polarity e polarity)

Sets the capture event polarity.

#### Parameters:

- ← *capHandle* The capture (CAP) object handle
- ← *event* The event to configure
- ← *polarity* The polarity to configure the event for
- 4.2.5.20 void CAP\_setCapEvtReset (CAP\_Handle capHandle, const CAP\_Event\_e event, const CAP\_Reset\_e reset)

Sets the capture event counter reset configuration.

#### Parameters:

- ← *capHandle* The capture (CAP) object handle
- ← *event* The event to configure
- ← **reset** Whether the event should reset the counter or not
- 4.2.5.21 void CAP\_setCapOneShot (CAP\_Handle capHandle)

Sets up for one-shot Capture.

#### Parameters:

- ← *capHandle* The capture (CAP) object handle
- 4.2.5.22 void CAP\_setModeApwm (CAP\_Handle capHandle)

Sets capture peripheral up for APWM mode.

#### Parameters:

- ← *capHandle* The capture (CAP) object handle
- 4.2.5.23 void CAP setModeCap (CAP Handle capHandle)

Sets capture peripheral up for capture mode.

#### Parameters:

← *capHandle* The capture (CAP) object handle

4.2.5.24 void CAP\_setStopWrap (CAP\_Handle capHandle, const CAP\_Stop\_Wrap\_e stopWrap)

Set the stop/wrap mode.

#### Parameters:

- ← *capHandle* The capture (CAP) object handle
- $\leftarrow$  **stopWrap** The stop/wrap mode to set
- 4.2.5.25 void CAP\_setSyncOut (CAP\_Handle capHandle, const CAP\_SyncOut\_e syncOut)

Set the sync out mode.

- $\leftarrow$  *capHandle* The capture (CAP) object handle
- $\leftarrow$  **syncOut** The sync out mode to set

# 5 Device Clocking (CLK)

Introduction	49
API Functions	49

# 5.1 Introduction

The CLK API provides functions to control the clocking subsystem of the device. Clock dividers and prescalers as well as peripheral clocks can all be set or enabled via this API.

This driver is contained in f280x0\_common/source/clk.c, with <ttf280x0\_common/include/clk.h containing the API definitions for use by applications.

# 5.2 CLK

## **Data Structures**

CLK Obj

# **Defines**

- CLK BASE ADDR
- CLK CLKCTL INTOSC1HALTI BITS
- CLK CLKCTL INTOSC1OFF BITS
- CLK CLKCTL INTOSC2HALTI BITS
- CLK CLKCTL INTOSC2OFF BITS
- CLK\_CLKCTL\_NMIRESETSEL\_BITS
- CLK\_CLKCTL\_OSCCLKSRC2SEL\_BITS
- CLK CLKCTL OSCCLKSRCSEL BITS
- CLK\_CLKCTL\_TMR2CLKPRESCALE\_BITS
- CLK CLKCTL TMR2CLKSRCSEL BITS
- CLK\_CLKCTL\_WDCLKSRCSEL\_BITS
- CLK\_CLKCTL\_WDHALTI\_BITS
- CLK\_CLKCTL\_XCLKINOFF\_BITS
- CLK\_CLKCTL\_XTALOSCOFF\_BITS
- CLK\_LOSPCP\_LSPCLK\_BITS
- CLK\_PCLKCR0\_ADCENCLK\_BITS
- CLK PCLKCR0 ECANAENCLK BITS
- CLK\_PCLKCR0\_HRPWMENCLK\_BITS
- CLK\_PCLKCR0\_I2CAENCLK\_BITS
- CLK\_PCLKCR0\_LINAENCLK\_BITS
- CLK\_PCLKCR0\_SCIAENCLK\_BITS

- CLK\_PCLKCR0\_SPIAENCLK\_BITS
- CLK\_PCLKCR0\_SPIBENCLK\_BITS
- CLK\_PCLKCR0\_TBCLKSYNC\_BITS
- CLK PCLKCR1 ECAP1ENCLK BITS
- CLK\_PCLKCR1\_EPWM1ENCLK\_BITS
- CLK PCLKCR1 EPWM2ENCLK BITS
- CLK\_PCLKCR1\_EPWM3ENCLK\_BITS
- CLK PCLKCR1 EPWM4ENCLK BITS
- CLK\_PCLKCR1\_EPWM5ENCLK\_BITS
- CLK PCLKCR1 EPWM6ENCLK BITS
- CLK\_PCLKCR1\_EPWM7ENCLK\_BITS
- CLK PCLKCR1 EQEP1ENCLK BITS
- CLK\_PCLKCR3\_CLA1ENCLK\_BITS
- CLK PCLKCR3 COMP1ENCLK BITS
- CLK\_PCLKCR3\_COMP2ENCLK\_BITS
- CLK PCLKCR3 COMP3ENCLK BITS
- CLK\_PCLKCR3\_CPUTIMER0ENCLK\_BITS
- CLK\_PCLKCR3\_CPUTIMER1ENCLK\_BITS
- CLK\_PCLKCR3\_CPUTIMER2ENCLK\_BITS
- CLK PCLKCR3 GPIOINENCLK BITS
- CLK\_XCLK\_XCLKINSEL\_BITS
- CLK XCLK XCLKOUTDIV BITS

# **Enumerations**

- CLK ClkInSrc e
- CLK CompNumber e
- CLK CpuTimerNumber e
- CLK\_LowSpdPreScaler\_e
- CLK\_Osc2Src\_e
- CLK OscSrc e
- CLK Timer2PreScaler e
- CLK\_Timer2Src\_e
- CLK\_WdClkSrc\_e

# **Functions**

- void CLK\_disableAdcClock (CLK\_Handle clkHandle)
- void CLK\_disableClaClock (CLK\_Handle clkHandle)
- void CLK disableClkIn (CLK Handle clkHandle)
- void CLK\_disableCompClock (CLK\_Handle clkHandle, const CLK\_CompNumber\_e comp-Number)
- void CLK\_disableCpuTimerClock (CLK\_Handle clkHandle, const CLK\_CpuTimerNumber\_e cpuTimerNumber)
- void CLK\_disableCrystalOsc (CLK\_Handle clkHandle)

50

- void CLK disableEcanaClock (CLK Handle clkHandle)
- void CLK\_disableEcap1Clock (CLK\_Handle clkHandle)
- void CLK disableEqep1Clock (CLK Handle clkHandle)
- void CLK\_disableGpioInputClock (CLK\_Handle clkHandle)
- void CLK\_disableHrPwmClock (CLK\_Handle clkHandle)
- void CLK\_disableI2cClock (CLK\_Handle clkHandle)
- void CLK\_disableLinAClock (CLK\_Handle clkHandle)
- void CLK disableOsc1 (CLK Handle clkHandle)
- void CLK\_disableOsc1HaltMode (CLK\_Handle clkHandle)
- void CLK\_disableOsc2 (CLK\_Handle clkHandle)
- void CLK\_disableOsc2HaltMode (CLK\_Handle clkHandle)
- void CLK\_disablePwmClock (CLK\_Handle clkHandle, const PWM\_Number\_e pwmNumber)
- void CLK\_disableSciaClock (CLK\_Handle clkHandle)
- void CLK\_disableSpiaClock (CLK\_Handle clkHandle)
- void CLK\_disableSpibClock (CLK\_Handle clkHandle)
- void CLK disableTbClockSync (CLK Handle clkHandle)
- void CLK disableWatchDogHaltMode (CLK Handle clkHandle)
- void CLK\_enableAdcClock (CLK\_Handle clkHandle)
- void CLK\_enableClaClock (CLK\_Handle clkHandle)
- void CLK enableClkIn (CLK Handle clkHandle)
- void CLK\_enableCompClock (CLK\_Handle clkHandle, const CLK\_CompNumber\_e comp-Number)
- void CLK\_enableCpuTimerClock (CLK\_Handle clkHandle, const CLK\_CpuTimerNumber\_e cpuTimerNumber)
- void CLK\_enableCrystalOsc (CLK\_Handle clkHandle)
- void CLK\_enableEcanaClock (CLK\_Handle clkHandle)
- void CLK\_enableEcap1Clock (CLK\_Handle clkHandle)
- void CLK enableEqep1Clock (CLK Handle clkHandle)
- void CLK enableGpioInputClock (CLK Handle clkHandle)
- void CLK enableHrPwmClock (CLK Handle clkHandle)
- void CLK enablel2cClock (CLK Handle clkHandle)
- void CLK\_enableLinAClock (CLK\_Handle clkHandle)
- void CLK enableOsc1 (CLK Handle clkHandle)
- void CLK enableOsc1HaltMode (CLK Handle clkHandle)
- void CLK enableOsc2 (CLK Handle clkHandle)
- void CLK enableOsc2HaltMode (CLK Handle clkHandle)
- void CLK enablePwmClock (CLK Handle clkHandle, const PWM Number e pwmNumber)
- void CLK\_enableSciaClock (CLK\_Handle clkHandle)
- void CLK\_enableSpiaClock (CLK\_Handle clkHandle)
- void CLK enableSpibClock (CLK Handle clkHandle)
- void CLK enableTbClockSync (CLK Handle clkHandle)
- void CLK enableWatchDogHaltMode (CLK Handle clkHandle)
- CLK\_Handle CLK\_init (void \*pMemory, const size\_t numBytes)
- void CLK\_setClkOutPreScaler (CLK\_Handle clkHandle, const CLK\_ClkOutPreScaler\_e preScaler)
- void CLK\_setLowSpdPreScaler (CLK\_Handle clkHandle, const CLK\_LowSpdPreScaler\_e preScaler)

- void CLK setOsc2Src (CLK Handle clkHandle, const CLK Osc2Src e src)
- void CLK\_setOscSrc (CLK\_Handle clkHandle, const CLK\_OscSrc\_e src)
- void CLK\_setTimer2PreScaler (CLK\_Handle clkHandle, const CLK\_Timer2PreScaler\_e preScaler)
- void CLK setTimer2Src (CLK Handle clkHandle, const CLK Timer2Src e src)
- void CLK setWatchDogSrc (CLK Handle clkHandle, const CLK WdClkSrc e src)

## 5.2.1 Data Structure Documentation

## 5.2.1.1 CLK Obj

#### **Definition:**

```
typedef struct
{
    uint16_t XCLK;
    uint16_t rsvd_1;
    uint16_t CLKCTL;
    uint16_t rsvd_2[8];
    uint16_t PCLKCR0;
    uint16_t PCLKCR1;
    uint16_t PCLKCR1;
    uint16_t PCLKCR3;
}
_CLK_Obj_
```

#### Members:

XCLK XCLKOUT/XCLKIN Control.

rsvd 1 Reserved.

CLKCTL Clock Control Register.

rsvd\_2 Reserved.

LOSPCP Low-Speed Peripheral Clock Pre-Scaler Register.

**PCLKCR0** Peripheral Clock Control Register 0.

PCLKCR1 Peripheral Clock Control Register 1.

rsvd 3 Reserved.

PCLKCR3 Peripheral Clock Control Register 3.

## **Description:**

Defines the clock (CLK) object.

## 5.2.2 Define Documentation

## 5.2.2.1 CLK BASE ADDR

#### **Definition:**

```
#define CLK_BASE_ADDR
```

## **Description:**

Defines the base address of the clock (CLK) registers.

53

## 5.2.2.2 CLK CLKCTL INTOSC1HALTI BITS

#### **Definition:**

#define CLK\_CLKCTL\_INTOSC1HALTI\_BITS

#### **Description:**

Defines the location of the INTOSC1HALTI bits in the CLKCTL register.

## 5.2.2.3 CLK CLKCTL INTOSC1OFF BITS

#### **Definition:**

#define CLK\_CLKCTL\_INTOSC1OFF\_BITS

## **Description:**

Defines the location of the INTOSC1OFF bits in the CLKCTL register.

# 5.2.2.4 CLK CLKCTL INTOSC2HALTI BITS

#### **Definition:**

#define CLK\_CLKCTL\_INTOSC2HALTI\_BITS

#### **Description:**

Defines the location of the INTOSC2HALTI bits in the CLKCTL register.

# 5.2.2.5 CLK\_CLKCTL\_INTOSC2OFF\_BITS

#### **Definition:**

#define CLK\_CLKCTL\_INTOSC2OFF\_BITS

#### **Description:**

Defines the location of the INTOSC2OFF bits in the CLKCTL register.

## 5.2.2.6 CLK CLKCTL NMIRESETSEL BITS

## **Definition:**

#define CLK\_CLKCTL\_NMIRESETSEL\_BITS

#### **Description:**

Defines the location of the NMIRESETSEL bits in the CLKCTL register.

# 5.2.2.7 CLK CLKCTL OSCCLKSRC2SEL BITS

## **Definition:**

#define CLK\_CLKCTL\_OSCCLKSRC2SEL\_BITS

#### **Description:**

Defines the location of the OSCCLKSRC2SEL bits in the CLKCTL register.

## 5.2.2.8 CLK CLKCTL OSCCLKSRCSEL BITS

#### **Definition:**

#define CLK\_CLKCTL\_OSCCLKSRCSEL\_BITS

#### **Description:**

Defines the location of the OSCCLKSRCSEL bits in the CLKCTL register.

## 5.2.2.9 CLK CLKCTL TMR2CLKPRESCALE BITS

#### **Definition:**

#define CLK\_CLKCTL\_TMR2CLKPRESCALE\_BITS

### **Description:**

Defines the location of the TMR2CLKPRESCALE bits in the CLKCTL register.

# 5.2.2.10 CLK CLKCTL TMR2CLKSRCSEL BITS

#### **Definition:**

#define CLK\_CLKCTL\_TMR2CLKSRCSEL\_BITS

#### **Description:**

Defines the location of the TMR2CLKSRCSEL bits in the CLKCTL register.

# 5.2.2.11 CLK\_CLKCTL\_WDCLKSRCSEL\_BITS

#### **Definition:**

#define CLK\_CLKCTL\_WDCLKSRCSEL\_BITS

#### **Description:**

Defines the location of the WDCLKSRCSEL bits in the CLKCTL register.

## 5.2.2.12 CLK CLKCTL WDHALTI BITS

## **Definition:**

#define CLK\_CLKCTL\_WDHALTI\_BITS

#### **Description:**

Defines the location of the WDHALTI bits in the CLKCTL register.

# 5.2.2.13 CLK CLKCTL XCLKINOFF BITS

#### **Definition:**

#define CLK\_CLKCTL\_XCLKINOFF\_BITS

## **Description:**

Defines the location of the XCLKINOFF bits in the CLKCTL register.

55

## 5.2.2.14 CLK CLKCTL XTALOSCOFF BITS

#### **Definition:**

#define CLK\_CLKCTL\_XTALOSCOFF\_BITS

#### **Description:**

Defines the location of the XTALOSCOFF bits in the CLKCTL register.

## 5.2.2.15 CLK LOSPCP LSPCLK BITS

#### **Definition:**

#define CLK\_LOSPCP\_LSPCLK\_BITS

## **Description:**

Defines the location of the LSPNCLK bits in the LOSPCP register.

# 5.2.2.16 CLK PCLKCR0 ADCENCLK BITS

#### **Definition:**

#define CLK\_PCLKCRO\_ADCENCLK\_BITS

## **Description:**

Defines the location of the ADCENCLK bits in the PCLKCR0 register.

# 5.2.2.17 CLK\_PCLKCR0\_ECANAENCLK\_BITS

#### **Definition:**

#define CLK\_PCLKCR0\_ECANAENCLK\_BITS

#### **Description:**

Defines the location of the ECANAENCLK bits in the PCLKCR0 register.

# 5.2.2.18 CLK PCLKCR0 HRPWMENCLK\_BITS

## **Definition:**

#define CLK\_PCLKCRO\_HRPWMENCLK\_BITS

#### **Description:**

Defines the location of the HRPWMENCLK bits in the PCLKCR0 register.

# 5.2.2.19 CLK PCLKCR0 I2CAENCLK BITS

#### **Definition:**

#define CLK\_PCLKCR0\_I2CAENCLK\_BITS

#### **Description:**

Defines the location of the I2CAENCLK bits in the PCLKCR0 register.

## 5.2.2.20 CLK PCLKCR0 LINAENCLK BITS

#### **Definition:**

#define CLK\_PCLKCRO\_LINAENCLK\_BITS

#### **Description:**

Defines the location of the LINAENCLK bits in the PCLKCR0 register.

# 5.2.2.21 CLK\_PCLKCR0\_SCIAENCLK\_BITS

#### **Definition:**

#define CLK\_PCLKCRO\_SCIAENCLK\_BITS

## **Description:**

Defines the location of the SCIAENCLK bits in the PCLKCR0 register.

# 5.2.2.22 CLK PCLKCR0 SPIAENCLK BITS

#### **Definition:**

#define CLK\_PCLKCRO\_SPIAENCLK\_BITS

#### **Description:**

Defines the location of the SPIAENCLK bits in the PCLKCR0 register.

# 5.2.2.23 CLK\_PCLKCR0\_SPIBENCLK\_BITS

#### **Definition:**

#define CLK\_PCLKCRO\_SPIBENCLK\_BITS

#### **Description:**

Defines the location of the SPIBENCLK bits in the PCLKCR0 register.

# 5.2.2.24 CLK\_PCLKCR0\_TBCLKSYNC\_BITS

## **Definition:**

#define CLK\_PCLKCRO\_TBCLKSYNC\_BITS

#### **Description:**

Defines the location of the TBCLKSYNC bits in the PCLKCR0 register.

# 5.2.2.25 CLK PCLKCR1 ECAP1ENCLK BITS

#### **Definition:**

#define CLK\_PCLKCR1\_ECAP1ENCLK\_BITS

#### **Description:**

Defines the location of the ECAP1ENCLK bits in the PCLKCR1 register.

57

## 5.2.2.26 CLK PCLKCR1 EPWM1ENCLK BITS

#### **Definition:**

#define CLK\_PCLKCR1\_EPWM1ENCLK\_BITS

#### **Description:**

Defines the location of the EPWM1ENCLK bits in the PCLKCR1 register.

# 5.2.2.27 CLK\_PCLKCR1\_EPWM2ENCLK\_BITS

#### **Definition:**

#define CLK\_PCLKCR1\_EPWM2ENCLK\_BITS

### **Description:**

Defines the location of the EPWM2ENCLK bits in the PCLKCR1 register.

# 5.2.2.28 CLK PCLKCR1 EPWM3ENCLK BITS

#### **Definition:**

#define CLK\_PCLKCR1\_EPWM3ENCLK\_BITS

#### **Description:**

Defines the location of the EPWM3ENCLK bits in the PCLKCR1 register.

## 5.2.2.29 CLK PCLKCR1 EPWM4ENCLK BITS

#### **Definition:**

#define CLK\_PCLKCR1\_EPWM4ENCLK\_BITS

#### **Description:**

Defines the location of the EPWM4ENCLK bits in the PCLKCR1 register.

## 5.2.2.30 CLK PCLKCR1 EPWM5ENCLK BITS

## **Definition:**

#define CLK\_PCLKCR1\_EPWM5ENCLK\_BITS

#### **Description:**

Defines the location of the EPWM5ENCLK bits in the PCLKCR1 register.

# 5.2.2.31 CLK PCLKCR1 EPWM6ENCLK BITS

## **Definition:**

#define CLK\_PCLKCR1\_EPWM6ENCLK\_BITS

#### **Description:**

Defines the location of the EPWM6ENCLK bits in the PCLKCR1 register.

## 5.2.2.32 CLK PCLKCR1 EPWM7ENCLK BITS

#### **Definition:**

#define CLK\_PCLKCR1\_EPWM7ENCLK\_BITS

#### **Description:**

Defines the location of the EPWM7ENCLK bits in the PCLKCR1 register.

## 5.2.2.33 CLK PCLKCR1 EQEP1ENCLK BITS

#### **Definition:**

#define CLK\_PCLKCR1\_EQEP1ENCLK\_BITS

## **Description:**

Defines the location of the EQEP1ENCLK bits in the PCLKCR1 register.

# 5.2.2.34 CLK PCLKCR3 CLA1ENCLK BITS

#### **Definition:**

#define CLK\_PCLKCR3\_CLA1ENCLK\_BITS

#### **Description:**

Defines the location of the CLA1ENCLK bits in the PCLKCR3 register.

## 5.2.2.35 CLK PCLKCR3 COMP1ENCLK BITS

#### **Definition:**

#define CLK\_PCLKCR3\_COMP1ENCLK\_BITS

#### **Description:**

Defines the location of the COMP1ENCLK bits in the PCLKCR3 register.

# 5.2.2.36 CLK\_PCLKCR3\_COMP2ENCLK\_BITS

## **Definition:**

#define CLK\_PCLKCR3\_COMP2ENCLK\_BITS

#### **Description:**

Defines the location of the COMP2ENCLK bits in the PCLKCR3 register.

# 5.2.2.37 CLK\_PCLKCR3\_COMP3ENCLK\_BITS

#### **Definition:**

#define CLK\_PCLKCR3\_COMP3ENCLK\_BITS

#### **Description:**

Defines the location of the COMP3ENCLK bits in the PCLKCR3 register.

59

## 5.2.2.38 CLK PCLKCR3 CPUTIMER0ENCLK BITS

#### **Definition:**

#define CLK\_PCLKCR3\_CPUTIMER0ENCLK\_BITS

## **Description:**

Defines the location of the CPUTIMER0ENCLK bits in the PCLKCR3 register.

# 5.2.2.39 CLK PCLKCR3 CPUTIMER1ENCLK BITS

#### **Definition:**

#define CLK\_PCLKCR3\_CPUTIMER1ENCLK\_BITS

### **Description:**

Defines the location of the CPUTIMER1ENCLK bits in the PCLKCR3 register.

# 5.2.2.40 CLK\_PCLKCR3\_CPUTIMER2ENCLK\_BITS

#### **Definition:**

#define CLK\_PCLKCR3\_CPUTIMER2ENCLK\_BITS

#### **Description:**

Defines the location of the CPUTIMER2ENCLK bits in the PCLKCR3 register.

# 5.2.2.41 CLK PCLKCR3 GPIOINENCLK BITS

#### **Definition:**

#define CLK\_PCLKCR3\_GPIOINENCLK\_BITS

#### **Description:**

Defines the location of the GPIOINENCLK bits in the PCLKCR3 register.

# 5.2.2.42 CLK XCLK XCLKINSEL BITS

#### **Definition:**

#define CLK\_XCLK\_XCLKINSEL\_BITS

## **Description:**

Defines the location of the XCLKINSEL bits in the XCLK register.

# 5.2.2.43 CLK XCLK XCLKOUTDIV BITS

#### **Definition:**

#define CLK\_XCLK\_XCLKOUTDIV\_BITS

#### **Description:**

Defines the location of the XCLKOUTDIV bits in the XCLK register.

# 5.2.3 Typedef Documentation

# 5.2.3.1 CLK Handle

#### **Definition:**

typedef struct CLK\_Obj \*CLK\_Handle

#### Description:

Defines the clock (CLK) handle.

## 5.2.3.2 CLK Obj

#### **Definition:**

typedef struct \_CLK\_Obj\_ CLK\_Obj

#### **Description:**

Defines the clock (CLK) object.

# 5.2.4 Enumeration Documentation

# 5.2.4.1 CLK ClkInSrc e

#### **Description:**

Enumeration to define the clock in source.

# 5.2.4.2 enum CLK ClkOutPreScaler e

Enumeration to define the external clock output frequency.

#### **Enumerators:**

```
CLK_ClkOutPreScaler_SysClkOut_by_4 Denotes XCLKOUT = SYSCLKOUT/4.
CLK_ClkOutPreScaler_SysClkOut_by_2 Denotes XCLKOUT = SYSCLKOUT/2.
CLK_ClkOutPreScaler_SysClkOut_by_1 Denotes XCLKOUT = SYSCLKOUT/1.
CLK_ClkOutPreScaler_Off Denotes XCLKOUT = Off.
```

# 5.2.4.3 CLK\_CompNumber\_e

#### **Description:**

Enumeration to define the comparator numbers.

#### **Enumerators:**

```
CLK_CompNumber_1 Denotes comparator number 1.CLK_CompNumber_2 Denotes comparator number 2.CLK_CompNumber_3 Denotes comparator number 3.
```

## 5.2.4.4 CLK CpuTimerNumber e

## **Description:**

Enumeration to define the CPU timer numbers.

#### **Enumerators:**

CLK\_CpuTimerNumber\_0 Denotes CPU timer number 0.CLK\_CpuTimerNumber\_1 Denotes CPU timer number 1.CLK\_CpuTimerNumber\_2 Denotes CPU timer number 2.

## 5.2.4.5 CLK LowSpdPreScaler e

#### **Description:**

Enumeration to define the low speed clock prescaler, which sets the clock frequency.

#### **Enumerators:**

```
CLK_LowSpdPreScaler_SysClkOut_by_1 Denotes Low Speed Clock = SYSCLKOUT/1.

CLK_LowSpdPreScaler_SysClkOut_by_2 Denotes Low Speed Clock = SYSCLKOUT/2.

CLK_LowSpdPreScaler_SysClkOut_by_4 Denotes Low Speed Clock = SYSCLKOUT/4.

CLK_LowSpdPreScaler_SysClkOut_by_6 Denotes Low Speed Clock = SYSCLKOUT/6.

CLK_LowSpdPreScaler_SysClkOut_by_8 Denotes Low Speed Clock = SYSCLKOUT/8.

CLK_LowSpdPreScaler_SysClkOut_by_10 Denotes Low Speed Clock = SYSCLKOUT/10.
```

**CLK\_LowSpdPreScaler\_SysClkOut\_by\_12** Denotes Low Speed Clock = SYSCLKOUT/12.

CLK\_LowSpdPreScaler\_SysClkOut\_by\_14 Denotes Low Speed Clock = SYSCLKOUT/14.

## 5.2.4.6 CLK Osc2Src e

### **Description:**

Enumeration to define the clock oscillator 2 source.

#### **Enumerators:**

**CLK\_Osc2Src\_Internal** Denotes an internal oscillator 2 source. **CLK Osc2Src External** Denotes an external oscillator 2 source.

## 5.2.4.7 CLK OscSrc e

#### **Description:**

Enumeration to define the clock oscillator source.

#### **Enumerators:**

**CLK\_OscSrc\_Internal** Denotes an internal oscillator source. **CLK\_OscSrc\_External** Denotes an external oscillator source.

# 5.2.4.8 CLK\_Timer2PreScaler\_e

#### **Description:**

Enumeration to define the timer 2 prescaler, which sets the timer 2 frequency.

#### **Enumerators:**

CLK\_Timer2PreScaler\_by\_1 Denotes a CPU timer 2 clock pre-scaler value of divide by 1.
CLK\_Timer2PreScaler\_by\_2 Denotes a CPU timer 2 clock pre-scaler value of divide by 2.
CLK\_Timer2PreScaler\_by\_4 Denotes a CPU timer 2 clock pre-scaler value of divide by 4.
CLK\_Timer2PreScaler\_by\_8 Denotes a CPU timer 2 clock pre-scaler value of divide by 8.
CLK\_Timer2PreScaler\_by\_16 Denotes a CPU timer 2 clock pre-scaler value of divide by 16.

# 5.2.4.9 CLK\_Timer2Src\_e

### **Description:**

Enumeration to define the timer 2 source.

#### **Enumerators:**

CLK\_Timer2Src\_SysClk
 Denotes the CPU timer 2 clock source is SYSCLKOUT.
 CLK\_Timer2Src\_ExtOsc
 Denotes the CPU timer 2 clock source is external oscillator.
 CLK\_Timer2Src\_IntOsc1
 Denotes the CPU timer 2 clock source is internal oscillator 1.
 CLK\_Timer2Src\_IntOsc2
 Denotes the CPU timer 2 clock source is internal oscillator 2.

# 5.2.4.10 CLK\_WdClkSrc\_e

#### **Description:**

Enumeration to define the watchdog clock source.

#### **Enumerators:**

CLK\_WdClkSrc\_IntOsc1 Denotes the watchdog clock source is internal oscillator 1.
CLK\_WdClkSrc\_ExtOscOrIntOsc2 Denotes the watchdog clock source is external oscillator or internal oscillator 2.

# 5.2.5 Function Documentation

## 5.2.5.1 CLK disableAdcClock

Disables the ADC clock.

## Prototype:

void
CLK\_disableAdcClock(CLK\_Handle clkHandle)

#### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.2 void CLK disableClaClock (CLK Handle clkHandle)

Disables the CLA clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.3 void CLK disableClkIn (CLK Handle clkHandle)

Disables the XCLKIN oscillator input.

#### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.4 void CLK\_disableCompClock (CLK\_Handle clkHandle, const CLK CompNumber e compNumber)

Disables the comparator clock.

#### Parameters:

- ← clkHandle The clock (CLK) object handle
- $\leftarrow$  *compNumber* The comparator number
- 5.2.5.5 void CLK\_disableCpuTimerClock (CLK\_Handle clkHandle, const CLK\_CpuTimerNumber\_e cpuTimerNumber)

Disables the CPU timer clock.

#### Parameters:

- ← clkHandle The clock (CLK) object handle
- ← *cpuTimerNumber* The CPU timer number
- 5.2.5.6 void CLK disableCrystalOsc (CLK Handle clkHandle)

Disables the crystal oscillator.

#### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.7 void CLK disableEcanaClock (CLK Handle clkHandle)

Disables the ECANA clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.8 void CLK disableEcap1Clock (CLK Handle clkHandle)

Disables the ECAP1 clock.

#### Parameters:

← *clkHandle* The clock (CLK) object handle

5.2.5.9 void CLK\_disableEqep1Clock (CLK\_Handle clkHandle)

Disables the EQEP1 clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.10 void CLK disableGpioInputClock (CLK Handle clkHandle)

Disables the GPIO input clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.11 void CLK\_disableHrPwmClock (CLK\_Handle clkHandle)

Disables the HRPWM clock.

#### Parameters:

← *clkHandle* The clock (CLK) object handle

5.2.5.12 void CLK disable 2cClock (CLK Handle clkHandle)

Disables the I2C clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.13 void CLK disableLinAClock (CLK Handle clkHandle)

Disables the LIN-A clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

## 5.2.5.14 void CLK disableOsc1 (CLK Handle clkHandle)

Disables internal oscillator 1.

#### Parameters:

← clkHandle The clock (CLK) object handle

# 5.2.5.15 void CLK\_disableOsc1HaltMode (CLK\_Handle clkHandle)

Disables internal oscillator 1 halt mode ignore.

#### Parameters:

← *clkHandle* The clock (CLK) object handle

## 5.2.5.16 void CLK disableOsc2 (CLK Handle clkHandle)

Disables internal oscillator 2.

#### Parameters:

← clkHandle The clock (CLK) object handle

# 5.2.5.17 void CLK\_disableOsc2HaltMode (CLK\_Handle clkHandle)

Disables internal oscillator 2 halt mode ignore.

#### Parameters:

← *clkHandle* The clock (CLK) object handle

# 5.2.5.18 void CLK\_disablePwmClock (CLK\_Handle clkHandle, const PWM\_Number\_e pwmNumber)

Disables the pwm clock.

#### Parameters:

- ← clkHandle The clock (CLK) object handle
- ← *pwmNumber* The PWM number

# 5.2.5.19 void CLK\_disableSciaClock (CLK\_Handle clkHandle)

Disables the SCI-A clock.

## Parameters:

← clkHandle The clock (CLK) object handle

## 5.2.5.20 void CLK disableSpiaClock (CLK Handle clkHandle)

Disables the SPI-A clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

# 5.2.5.21 void CLK\_disableSpibClock (CLK\_Handle clkHandle)

Disables the SPI-B clock.

#### Parameters:

← *clkHandle* The clock (CLK) object handle

# 5.2.5.22 void CLK disableTbClockSync (CLK Handle clkHandle)

Disables the ePWM module time base clock sync signal.

#### Parameters:

← clkHandle The clock (CLK) object handle

# 5.2.5.23 void CLK disableWatchDogHaltMode (CLK Handle clkHandle)

Disables the watchdog halt mode ignore.

#### Parameters:

← clkHandle The clock (CLK) object handle

# 5.2.5.24 void CLK enableAdcClock (CLK Handle clkHandle)

Enables the ADC clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

## 5.2.5.25 void CLK\_enableClaClock (CLK\_Handle clkHandle)

Enables the CLA clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

## 5.2.5.26 void CLK enableClkIn (CLK Handle clkHandle)

Enables the XCLKIN oscillator input.

#### Parameters:

← clkHandle The clock (CLK) object handle

# 5.2.5.27 void CLK\_enableCompClock (CLK\_Handle clkHandle, const CLK CompNumber e compNumber)

Enables the comparator clock.

#### Parameters:

- ← clkHandle The clock (CLK) object handle
- $\leftarrow$  *compNumber* The comparator number

# 5.2.5.28 void CLK\_enableCpuTimerClock (CLK\_Handle clkHandle, const CLK\_CpuTimerNumber\_e cpuTimerNumber)

Enables the CPU timer clock.

#### Parameters:

- ← *clkHandle* The clock (CLK) object handle
- ← *cpuTimerNumber* The CPU timer number

## 5.2.5.29 void CLK enableCrystalOsc (CLK Handle clkHandle)

Enables the crystal oscillator.

#### Parameters:

← clkHandle The clock (CLK) object handle

## 5.2.5.30 void CLK enableEcanaClock (CLK Handle clkHandle)

Enables the ECANA clock.

#### Parameters:

 $\leftarrow$  **clkHandle** The clock (CLK) object handle

# 5.2.5.31 void CLK\_enableEcap1Clock (CLK\_Handle clkHandle)

Enables the ECAP1 clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.32 void CLK enableEqep1Clock (CLK Handle clkHandle)

Enables the EQEP1 clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.33 void CLK enableGpioInputClock (CLK Handle clkHandle)

Enables the GPIO input clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.34 void CLK enableHrPwmClock (CLK Handle clkHandle)

Enables the HRPWM clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.35 void CLK enable 12cClock (CLK Handle clkHandle)

Enables the I2C clock.

#### Parameters:

← *clkHandle* The clock (CLK) object handle

5.2.5.36 void CLK enableLinAClock (CLK Handle clkHandle)

Enables the LIN-A clock.

### Parameters:

← clkHandle The clock (CLK) object handle

5.2.5.37 void CLK\_enableOsc1 (CLK\_Handle clkHandle)

Enables internal oscillator 1.

#### Parameters:

← clkHandle The clock (CLK) object handle

## 5.2.5.38 void CLK enableOsc1HaltMode (CLK Handle clkHandle)

Enables internal oscillator 1 halt mode ignore.

#### Parameters:

← clkHandle The clock (CLK) object handle

## 5.2.5.39 void CLK enableOsc2 (CLK Handle clkHandle)

Enables internal oscillator 2.

#### Parameters:

← *clkHandle* The clock (CLK) object handle

## 5.2.5.40 void CLK enableOsc2HaltMode (CLK Handle clkHandle)

Enables internal oscillator 2 halt mode ignore.

#### Parameters:

← clkHandle The clock (CLK) object handle

# 5.2.5.41 void CLK\_enablePwmClock (CLK\_Handle clkHandle, const PWM\_Number\_e pwmNumber)

Enables the pwm clock.

#### Parameters:

- ← *clkHandle* The clock (CLK) object handle
- $\leftarrow$  *pwmNumber* The PWM number

## 5.2.5.42 void CLK\_enableSciaClock (CLK\_Handle clkHandle)

Enables the SCI-A clock.

#### Parameters:

← *clkHandle* The clock (CLK) object handle

# 5.2.5.43 void CLK enableSpiaClock (CLK Handle clkHandle)

Enables the SPI-A clock.

## Parameters:

← clkHandle The clock (CLK) object handle

## 5.2.5.44 void CLK enableSpibClock (CLK Handle clkHandle)

Enables the SPI-B clock.

#### Parameters:

← clkHandle The clock (CLK) object handle

## 5.2.5.45 void CLK\_enableTbClockSync (CLK\_Handle clkHandle)

Enables the ePWM module time base clock sync signal.

#### Parameters:

← *clkHandle* The clock (CLK) object handle

## 5.2.5.46 void CLK enableWatchDogHaltMode (CLK Handle clkHandle)

Enables the watchdog halt mode ignore.

#### Parameters:

← clkHandle The clock (CLK) object handle

# 5.2.5.47 CLK\_Handle CLK\_init (void \* pMemory, const size\_t numBytes)

Initializes the clock (CLK) object handle.

#### Parameters:

- ← *pMemory* A pointer to the base address of the CLK registers
- ← *numBytes* The number of bytes allocated for the CLK object, bytes

#### Returns:

The clock (CLK) object handle

# 5.2.5.48 void CLK\_setClkOutPreScaler (CLK\_Handle clkHandle, const CLK\_ClkOutPreScaler\_e preScaler)

Sets the external clock out prescaler.

- ← *clkHandle* The clock (CLK) object handle
- ← *preScaler* The prescaler value

# 5.2.5.49 void CLK\_setLowSpdPreScaler (CLK\_Handle clkHandle, const CLK LowSpdPreScaler e preScaler)

Sets the low speed peripheral clock prescaler.

#### Parameters:

- ← clkHandle The clock (CLK) object handle
- ← *preScaler* The prescaler value

# 5.2.5.50 void CLK\_setOsc2Src (CLK\_Handle clkHandle, const CLK\_Osc2Src\_e src)

Sets the oscillator 2 clock source.

#### Parameters:

- ← clkHandle The clock (CLK) object handle
- ← src The oscillator 2 clock source

# 5.2.5.51 void CLK\_setOscSrc (CLK\_Handle clkHandle, const CLK\_OscSrc\_e src)

Sets the oscillator clock source.

#### Parameters:

- ← clkHandle The clock (CLK) object handle
- $\leftarrow$  **src** The oscillator clock source

# 5.2.5.52 void CLK\_setTimer2PreScaler (CLK\_Handle clkHandle, const CLK\_Timer2PreScaler\_e preScaler)

Sets the timer 2 clock prescaler.

#### Parameters:

- ← *clkHandle* The clock (CLK) object handle
- ← *preScaler* The prescaler value

# 5.2.5.53 void CLK\_setTimer2Src (CLK\_Handle clkHandle, const CLK\_Timer2Src\_e src)

Sets the timer 2 clock source.

- ← clkHandle The clock (CLK) object handle
- ← src The timer 2 clock source

5.2.5.54 void CLK\_setWatchDogSrc (CLK\_Handle clkHandle, const CLK\_WdClkSrc\_e src)

Sets the watchdog clock source.

- ← *clkHandle* The clock (CLK) object handle
- $\leftarrow$  **src** The watchdog clock source

# 6 Comparater (COMP)

Introduction	73
API Functions	73

# 6.1 Introduction

The Comparator (COMP) API provides the set of functions to configure the analog comparators present on this device.

This driver is contained in  $f280 \times 0$ \_common/source/comp.c, with  $f280 \times 0$ \_common/include/comp.h containing the API definitions for use by applications.

# 6.2 COMP

# **Data Structures**

\_COMP\_Obj\_

### **Defines**

- COMP1 BASE ADDR
- COMP2 BASE ADDR
- COMP\_COMPCTL\_CMPINV\_BITS
- COMP COMPCTL COMPDACE BITS
- COMP COMPCTL COMPSOURCE BITS
- COMP\_COMPCTL\_QUALSEL\_BITS
- COMP\_COMPCTL\_SYNCSEL\_BITS
- COMP COMPSTS COMPSTS BITS
- COMP\_DACCTL\_DACSOURCE\_BITS
- COMP\_DACCTL\_FREESOFT\_BITS
- COMP\_DACCTL\_RAMPSOURCE\_BITS

### **Enumerations**

- COMP\_QualSel\_e
- COMP\_RampSyncSrc\_e

### **Functions**

■ void COMP\_disable (COMP\_Handle compHandle)

- void COMP\_disableDac (COMP\_Handle compHandle)
- void COMP\_enable (COMP\_Handle compHandle)
- void COMP\_enableDac (COMP\_Handle compHandle)
- COMP Handle COMP init (void \*pMemory, const size t numBytes)
- void COMP\_setDacValue (COMP\_Handle compHandle, uint16\_t dacValue)

### 6.2.1 Data Structure Documentation

### 6.2.1.1 COMP Obj

#### **Definition:**

```
typedef struct
    uint16_t COMPCTL;
    uint16_t rsvd_1;
    uint16_t COMPSTS;
    uint16_t rsvd_2;
    uint16_t DACCTL;
    uint16_t rsvd_3;
    uint16_t DACVAL;
    uint16_t rsvd_4;
    uint16 t RAMPMAXREF ACTIVE;
    uint16_t rsvd_5;
    uint16_t RAMPMAXREF_SHADOW;
    uint16_t rsvd_6;
    uint16 t RAMPDECVAL ACTIVE;
    uint16_t rsvd_7;
    uint16_t RAMPDECVAL_SHADOW;
    uint16_t rsvd_8;
    uint16_t RAMPSTS;
_COMP_Obj_
```

#### Members:

```
COMPCTL COMP Control Register.
```

rsvd\_1 Reserved.

COMPSTS COMP Status Register.

rsvd\_2 Reserved.

DACCTL DAC Control Register.

rsvd\_3 Reserved.

DACVAL DAC Value Register.

rsvd\_4 Reserved.

**RAMPMAXREF ACTIVE** Ramp Generator Maxmimum Reference (Active).

rsvd\_5 Reserved.

RAMPMAXREF\_SHADOW Ramp Generator Maximum Reference (Shadow).

rsvd\_6 Reserved.

RAMPDECVAL\_ACTIVE Ramp Generator Decrement Value (Active).

rsvd 7 Reserved.

RAMPDECVAL\_SHADOW Ramp Generator Decrement Value (Shadow).

rsvd 8 Reserved.

**RAMPSTS** Ramp Generator Status.

#### **Description:**

Defines the comparator (COMP) object.

# 6.2.2 Define Documentation

# 6.2.2.1 COMP1\_BASE\_ADDR

#### **Definition:**

#define COMP1\_BASE\_ADDR

#### **Description:**

Defines the base address of the comparator (COMP) registers.

### 6.2.2.2 COMP2 BASE ADDR

#### **Definition:**

#define COMP2\_BASE\_ADDR

### **Description:**

Defines the base address of the comparator (COMP) registers.

### 6.2.2.3 COMP\_COMPCTL\_CMPINV\_BITS

#### **Definition:**

#define COMP\_COMPCTL\_CMPINV\_BITS

#### **Description:**

Defines the location of the CMPINV bits in the COMPCTL register.

### 6.2.2.4 COMP COMPCTL COMPDACE BITS

#### **Definition:**

#define COMP\_COMPCTL\_COMPDACE\_BITS

#### **Description:**

Defines the location of the COMPDACE bits in the COMPCTL register.

### 6.2.2.5 COMP COMPCTL COMPSOURCE BITS

#### **Definition:**

#define COMP\_COMPCTL\_COMPSOURCE\_BITS

Tue Jul 24 10:01:42 CDT 2012

### **Description:**

Defines the location of the COMPSOURCE bits in the COMPCTL register.

### 6.2.2.6 COMP\_COMPCTL\_QUALSEL\_BITS

#### **Definition:**

#define COMP\_COMPCTL\_QUALSEL\_BITS

#### **Description:**

Defines the location of the QUALSEL bits in the COMPCTL register.

### 6.2.2.7 COMP COMPCTL SYNCSEL BITS

#### **Definition:**

#define COMP\_COMPCTL\_SYNCSEL\_BITS

#### **Description:**

Defines the location of the SYNCSEL bits in the COMPCTL register.

### 6.2.2.8 COMP COMPSTS COMPSTS BITS

#### **Definition:**

#define COMP\_COMPSTS\_COMPSTS\_BITS

### **Description:**

Defines the location of the COMPSTS bits in the COMPSTS register.

### 6.2.2.9 COMP DACCTL DACSOURCE BITS

#### **Definition:**

#define COMP\_DACCTL\_DACSOURCE\_BITS

#### **Description:**

Defines the location of the DACSOURCE bits in the DACCTL register.

# 6.2.2.10 COMP\_DACCTL\_FREESOFT\_BITS

#### **Definition:**

#define COMP\_DACCTL\_FREESOFT\_BITS

#### **Description:**

Defines the location of the FREE:SOFT bits in the DACCTL register.

### 6.2.2.11 COMP DACCTL RAMPSOURCE BITS

#### **Definition:**

#define COMP\_DACCTL\_RAMPSOURCE\_BITS

#### **Description:**

Defines the location of the RAMPSOURCE bits in the DACCTL register.

# 6.2.3 Typedef Documentation

### 6.2.3.1 COMP Handle

#### Definition:

```
typedef struct COMP_Obj *COMP_Handle
```

#### Description

Defines the comparator (COMP) handle.

### 6.2.3.2 COMP Obj

#### **Definition:**

```
typedef struct _COMP_Obj_ COMP_Obj
```

#### **Description:**

Defines the comparator (COMP) object.

### 6.2.4 Enumeration Documentation

### 6.2.4.1 COMP QualSel e

#### **Description:**

Enumeration to define the comparator (COMP) output qualification.

#### **Enumerators:**

Tue Jul 24 10:01:42 CDT 2012

```
COMP QualSel Sync Syncronize comparator output.
```

COMP\_QualSel\_Qual\_2 Qualify comparator output with 2 cycles.

COMP\_QualSel\_Qual\_3 Qualify comparator output with 3 cycles.

COMP\_QualSel\_Qual\_4 Qualify comparator output with 4 cycles.

COMP\_QualSel\_Qual\_5 Qualify comparator output with 5 cycles.

COMP\_QualSel\_Qual\_6 Qualify comparator output with 6 cycles.

COMP\_QualSel\_Qual\_7 Qualify comparator output with 7 cycles.

COMP\_QualSel\_Qual\_8 Qualify comparator output with 8 cycles.

COMP\_QualSel\_Qual\_9 Qualify comparator output with 9 cycles.

COMP\_QualSel\_Qual\_10 Qualify comparator output with 10 cycles.

**COMP\_QualSel\_Qual\_11** Qualify comparator output with 11 cycles. **COMP\_QualSel\_Qual\_12** Qualify comparator output with 12 cycles.

COMP QualSel Qual 13 Qualify comparator output with 13 cycles.

```
COMP_QualSel_Qual_14 Qualify comparator output with 14 cycles.
COMP_QualSel_Qual_15 Qualify comparator output with 15 cycles.
COMP_QualSel_Qual_16 Qualify comparator output with 16 cycles.
COMP QualSel Qual 17 Qualify comparator output with 17 cycles.
COMP_QualSel_Qual_18 Qualify comparator output with 18 cycles.
COMP QualSel Qual 19 Qualify comparator output with 19 cycles.
COMP_QualSel_Qual_20 Qualify comparator output with 20 cycles.
COMP_QualSel_Qual_21 Qualify comparator output with 21 cycles.
COMP_QualSel_Qual_22 Qualify comparator output with 22 cycles.
COMP_QualSel_Qual_23 Qualify comparator output with 23 cycles.
COMP_QualSel_Qual_24 Qualify comparator output with 24 cycles.
COMP QualSel Qual 25 Qualify comparator output with 25 cycles.
COMP_QualSel_Qual_26 Qualify comparator output with 26 cycles.
COMP_QualSel_Qual_27 Qualify comparator output with 27 cycles.
COMP_QualSel_Qual_28 Qualify comparator output with 28 cycles.
COMP QualSel Qual 29 Qualify comparator output with 29 cycles.
COMP QualSel Qual 30 Qualify comparator output with 30 cycles.
COMP_QualSel_Qual_31 Qualify comparator output with 31 cycles.
COMP QualSel Qual 32 Qualify comparator output with 32 cycles.
COMP_QualSel_Qual_33 Qualify comparator output with 33 cycles.
```

# 6.2.4.2 COMP RampSyncSrc e

### **Description:**

Enumeration to define the comparator (COMP) ramp generator sync source.

#### **Enumerators:**

```
    COMP_RampSyncSrc_PWMSYNC1
    COMP_RampSyncSrc_PWMSYNC2
    COMP_RampSyncSrc_PWMSYNC3
    PWMSync3 used as Ramp Sync.
    COMP_RampSyncSrc_PWMSYNC4
    PWMSync4 used as Ramp Sync.
```

### 6.2.5 Function Documentation

### 6.2.5.1 COMP disable

Disables the comparator (COMP).

#### Prototype:

```
void
COMP_disable(COMP_Handle compHandle)
```

#### Parameters:

← *compHandle* The comparator (COMP) object handle

6.2.5.2 void COMP disableDac (COMP Handle compHandle)

Disables the DAC.

#### Parameters:

← *compHandle* The comparator (COMP) object handle

6.2.5.3 void COMP\_enable (COMP\_Handle compHandle)

Enables the comparator (COMP).

#### Parameters:

← *compHandle* The comparator (COMP) object handle

6.2.5.4 void COMP enableDac (COMP Handle compHandle)

Enables the DAC.

#### Parameters:

← *compHandle* The comparator (COMP) object handle

6.2.5.5 COMP Handle COMP init (void \* pMemory, const size t numBytes)

Initializes the comparator (COMP) object handle.

### Parameters:

- ← *pMemory* A pointer to the base address of the COMP registers
- ← *numBytes* The number of bytes allocated for the COMP object, bytes

#### Returns:

The comparator (COMP) object handle

6.2.5.6 void COMP\_setDacValue (COMP\_Handle compHandle, uint16\_t dacValue) [inline]

Sets the DAC's value.

#### Parameters:

- ← *compHandle* The comparator (COMP) object handle
- ← dacValue The DAC's value

# 7 Central Processing Unit (CPU)

Introduction8	
API Functions	1

# 7.1 Introduction

The CPU API provides a set of functions for controlling the central processing unit of this device. This driver is unique in that when initialized NULL should be passed as the peripheral base address.

This driver is contained in  $f2802x0_common/source/cpu.c$ , with  $f2802x0_common/include/cpu.h$  containing the API definitions for use by applications.

# 7.2 CPU

### **Data Structures**

■ CPU Obj

# **Defines**

- CPU DBGIER DLOGINT BITS
- CPU\_DBGIER\_INT10\_BITS
- CPU DBGIER INT11 BITS
- CPU DBGIER INT12 BITS
- CPU\_DBGIER\_INT13\_BITS
- CPU\_DBGIER\_INT14\_BITS
- CPU\_DBGIER\_INT1\_BITS
- CPU DBGIER\_INT2\_BITS
- CPU\_DBGIER\_INT3\_BITS
- CPU\_DBGIER\_INT4\_BITS
- CPU\_DBGIER\_INT5\_BITS
- CPU\_DBGIER\_INT6\_BITS
- CPU\_DBGIER\_INT7\_BITS ■ CPU\_DBGIER\_INT8\_BITS
- CPU DBGIER INT9 BITS
- CPU\_DBGIER\_RTOSINT\_BITS
- CPU IER DLOGINT BITS
- CPU\_IER\_INT10\_BITS
- CPU IER INT11 BITS
- CPU\_IER\_INT12\_BITS
- CPU\_IER\_INT13\_BITS

- CPU IER INT14 BITS
- CPU IER INT1 BITS
- CPU\_IER\_INT2\_BITS
- CPU IER INT3 BITS
- CPU\_IER\_INT4\_BITS
- CPU\_IER\_INT5\_BITS
- CPU IER INT6 BITS
- CPU\_IER\_INT7\_BITS
- CPU IER INT8 BITS
- CPU IER INT9 BITS
- CPU IER RTOSINT BITS
- CPU IFR DLOGINT BITS
- CPU\_IFR\_INT10\_BITS
- CPU\_IFR\_INT11\_BITS
- CPU IFR INT12 BITS
- CPU IFR INT13 BITS
- CPU\_IFR\_INT14\_BITS
- CPU IFR INT1 BITS
- CPU\_IFR\_INT2\_BITS
- CPU IFR INT3 BITS
- CPU IFR INT4 BITS
- CPU\_IFR\_INT5\_BITS
- CPU\_IFR\_INT6\_BITS
- CPU IFR INT7 BITS
- CPU IFR INT8 BITS
- CPU\_IFR\_INT9\_BITS
- CPU\_IFR\_RTOSINT\_BITS
- CPU ST0 C BITS
- CPU ST0 N BITS
- CPU\_ST0\_OVCOVCU\_BITS
- CPU\_ST0\_OVM\_BITS
- CPU ST0 PW BITS
- CPU\_ST0\_SXM\_BITS
- CPU ST0\_TC\_BITS
- CPU\_ST0\_V\_BITS
- CPU ST0 Z BITS
- CPU\_ST1\_AMODE\_BITS
- CPU ST1 ARP BITS
- CPU\_ST1\_DBGM\_BITS
- CPU\_ST1\_EALLOW\_BITS
- CPU\_ST1\_IDLESTAT\_BITS
- CPU ST1 INTM BITS
- CPU\_ST1\_LOOP\_BITS
- CPU\_ST1\_MOM1MAP\_BITS
- CPU\_ST1\_OBJMODE\_BITS
- CPU\_ST1\_PAGE0\_BITS

82

- CPU ST1 SPA BITS
- CPU\_ST1\_VMAP\_BITS
- CPU\_ST1\_XF\_BITS
- DINT
- DISABLE INTERRUPTS
- DISABLE PROTECTED REGISTER WRITE MODE
- DRTM
- **EALLOW**
- EDIS
- **EINT**
- ENABLE INTERRUPTS
- ENABLE PROTECTED REGISTER WRITE MODE
- **■** ERTM
- ESTOP0
- IDLE

### **Enumerations**

- CPU ExtIntNumber e
- CPU\_IntNumber\_e

### **Functions**

- void CPU\_clearIntFlags (CPU\_Handle cpuHandle)
- void CPU\_disableDebugInt (CPU\_Handle cpuHandle)
- void CPU disableGlobalInts (CPU Handle cpuHandle)
- void CPU\_disableInt (CPU\_Handle cpuHandle, const CPU\_IntNumber\_e intNumber)
- void CPU disableInts (CPU Handle cpuHandle)
- void CPU\_disableProtectedRegisterWrite (CPU\_Handle cpuHandle)
- void CPU\_enableDebugInt (CPU\_Handle cpuHandle)
- void CPU enableGlobalInts (CPU Handle cpuHandle)
- void CPU\_enableInt (CPU\_Handle cpuHandle, const CPU\_IntNumber\_e intNumber)
- void CPU enableProtectedRegisterWrite (CPU Handle cpuHandle)
- CPU\_Handle CPU\_init (void \*pMemory, const size\_t numBytes)

### **Variables**

- CPU\_Obj cpu
- cregister volatile unsigned int IER
- cregister volatile unsigned int IFR

# 7.2.1 Data Structure Documentation

# 7.2.1.1 \_CPU\_Obj\_

#### **Definition:**

```
typedef struct
{
    HASH(0x14e3838) argsstring;
}
_CPU_Obj_
```

#### Members:

argsstring

### **Description:**

Defines the central processing unit (CPU) object.

# 7.2.2 Define Documentation

# 7.2.2.1 CPU\_DBGIER\_DLOGINT\_BITS

### **Definition:**

```
#define CPU_DBGIER_DLOGINT_BITS
```

#### **Description:**

Defines the location of the DLOGINT bits in the DBGIER register.

### 7.2.2.2 CPU\_DBGIER\_INT10\_BITS

#### **Definition:**

```
#define CPU_DBGIER_INT10_BITS
```

#### **Description:**

Defines the location of the INT10 bits in the DBGIER register.

# 7.2.2.3 CPU\_DBGIER\_INT11\_BITS

#### **Definition:**

```
#define CPU_DBGIER_INT11_BITS
```

#### **Description:**

Defines the location of the INT11 bits in the DBGIER register.

### 7.2.2.4 CPU DBGIER INT12 BITS

#### **Definition:**

```
#define CPU_DBGIER_INT12_BITS
```

### **Description:**

Defines the location of the INT12 bits in the DBGIER register.

### 7.2.2.5 CPU\_DBGIER\_INT13\_BITS

#### **Definition:**

#define CPU DBGIER INT13 BITS

#### **Description:**

Defines the location of the INT13 bits in the DBGIER register.

### 7.2.2.6 CPU DBGIER INT14 BITS

### **Definition:**

#define CPU\_DBGIER\_INT14\_BITS

#### **Description:**

Defines the location of the INT14 bits in the DBGIER register.

# 7.2.2.7 CPU\_DBGIER\_INT1\_BITS

#### **Definition:**

#define CPU\_DBGIER\_INT1\_BITS

### **Description:**

Defines the location of the INT1 bits in the DBGIER register.

### 7.2.2.8 CPU DBGIER INT2 BITS

#### **Definition:**

#define CPU\_DBGIER\_INT2\_BITS

#### **Description:**

Defines the location of the INT2 bits in the DBGIER register.

# 7.2.2.9 CPU\_DBGIER\_INT3\_BITS

#### **Definition:**

#define CPU\_DBGIER\_INT3\_BITS

#### **Description:**

Defines the location of the INT3 bits in the DBGIER register.

### 7.2.2.10 CPU DBGIER INT4 BITS

#### **Definition:**

#define CPU\_DBGIER\_INT4\_BITS

#### **Description:**

Defines the location of the INT4 bits in the DBGIER register.

### 7.2.2.11 CPU DBGIER INT5 BITS

#### **Definition:**

#define CPU\_DBGIER\_INT5\_BITS

### **Description:**

Defines the location of the INT5 bits in the DBGIER register.

### 7.2.2.12 CPU DBGIER INT6 BITS

#### **Definition:**

#define CPU\_DBGIER\_INT6\_BITS

#### **Description:**

Defines the location of the INT6 bits in the DBGIER register.

### 7.2.2.13 CPU DBGIER INT7 BITS

#### **Definition:**

#define CPU\_DBGIER\_INT7\_BITS

#### **Description:**

Defines the location of the INT7 bits in the DBGIER register.

### 7.2.2.14 CPU DBGIER INT8 BITS

### **Definition:**

#define CPU\_DBGIER\_INT8\_BITS

#### **Description:**

Defines the location of the INT8 bits in the DBGIER register.

### 7.2.2.15 CPU DBGIER INT9 BITS

#### **Definition:**

#define CPU\_DBGIER\_INT9\_BITS

### **Description:**

Defines the location of the INT9 bits in the DBGIER register.

### 7.2.2.16 CPU\_DBGIER\_RTOSINT\_BITS

#### **Definition:**

#define CPU\_DBGIER\_RTOSINT\_BITS

#### **Description:**

Defines the location of the RTOSINT bits in the DBGIER register.

### 7.2.2.17 CPU IER DLOGINT BITS

#### **Definition:**

#define CPU\_IER\_DLOGINT\_BITS

### **Description:**

Defines the location of the DLOGINT bits in the IER register.

### 7.2.2.18 CPU IER INT10 BITS

#### **Definition:**

#define CPU\_IER\_INT10\_BITS

### **Description:**

Defines the location of the INT10 bits in the IER register.

### 7.2.2.19 CPU IER INT11 BITS

### **Definition:**

#define CPU\_IER\_INT11\_BITS

#### **Description:**

Defines the location of the INT11 bits in the IER register.

### 7.2.2.20 CPU IER INT12 BITS

### **Definition:**

#define CPU\_IER\_INT12\_BITS

#### **Description:**

Defines the location of the INT12 bits in the IER register.

### 7.2.2.21 CPU IER INT13 BITS

#### **Definition:**

#define CPU\_IER\_INT13\_BITS

#### **Description:**

Defines the location of the INT13 bits in the IER register.

### 7.2.2.22 CPU IER INT14 BITS

#### **Definition:**

#define CPU\_IER\_INT14\_BITS

#### **Description:**

Defines the location of the INT14 bits in the IER register.

# 7.2.2.23 CPU\_IER\_INT1\_BITS

#### **Definition:**

#define CPU\_IER\_INT1\_BITS

### **Description:**

Defines the location of the INT1 bits in the IER register.

### 7.2.2.24 CPU IER INT2 BITS

#### **Definition:**

#define CPU\_IER\_INT2\_BITS

### **Description:**

Defines the location of the INT2 bits in the IER register.

### 7.2.2.25 CPU\_IER\_INT3\_BITS

#### **Definition:**

#define CPU\_IER\_INT3\_BITS

#### **Description:**

Defines the location of the INT3 bits in the IER register.

### 7.2.2.26 CPU IER INT4 BITS

### **Definition:**

#define CPU\_IER\_INT4\_BITS

#### **Description:**

Defines the location of the INT4 bits in the IER register.

# 7.2.2.27 CPU\_IER\_INT5\_BITS

#### **Definition:**

#define CPU\_IER\_INT5\_BITS

### **Description:**

Defines the location of the INT5 bits in the IER register.

### 7.2.2.28 CPU\_IER\_INT6\_BITS

#### **Definition:**

#define CPU\_IER\_INT6\_BITS

#### **Description:**

Defines the location of the INT6 bits in the IER register.

### 7.2.2.29 CPU\_IER\_INT7\_BITS

#### **Definition:**

#define CPU\_IER\_INT7\_BITS

### **Description:**

Defines the location of the INT7 bits in the IER register.

### 7.2.2.30 CPU IER INT8 BITS

#### **Definition:**

#define CPU\_IER\_INT8\_BITS

### **Description:**

Defines the location of the INT8 bits in the IER register.

### 7.2.2.31 CPU\_IER\_INT9\_BITS

#### **Definition:**

#define CPU\_IER\_INT9\_BITS

#### **Description:**

Defines the location of the INT9 bits in the IER register.

# 7.2.2.32 CPU IER\_RTOSINT\_BITS

### **Definition:**

#define CPU\_IER\_RTOSINT\_BITS

#### **Description:**

Defines the location of the RTOSINT bits in the IER register.

### 7.2.2.33 CPU IFR DLOGINT BITS

#### **Definition:**

#define CPU\_IFR\_DLOGINT\_BITS

### **Description:**

Defines the location of the DLOGINT bits in the IFR register.

### 7.2.2.34 CPU IFR INT10 BITS

#### **Definition:**

#define CPU\_IFR\_INT10\_BITS

#### **Description:**

Defines the location of the INT10 bits in the IER register.

### 7.2.2.35 CPU\_IFR\_INT11\_BITS

#### **Definition:**

#define CPU\_IFR\_INT11\_BITS

### **Description:**

Defines the location of the INT11 bits in the IER register.

### 7.2.2.36 CPU IFR INT12 BITS

#### **Definition:**

#define CPU\_IFR\_INT12\_BITS

#### **Description:**

Defines the location of the INT12 bits in the IER register.

### 7.2.2.37 CPU IFR INT13 BITS

#### **Definition:**

#define CPU\_IFR\_INT13\_BITS

#### **Description:**

Defines the location of the INT13 bits in the IER register.

### 7.2.2.38 CPU IFR INT14 BITS

### **Definition:**

#define CPU\_IFR\_INT14\_BITS

#### **Description:**

Defines the location of the INT14 bits in the IER register.

# 7.2.2.39 CPU\_IFR\_INT1\_BITS

#### **Definition:**

#define CPU\_IFR\_INT1\_BITS

### **Description:**

Defines the location of the INT1 bits in the IER register.

### 7.2.2.40 CPU IFR INT2 BITS

#### **Definition:**

#define CPU\_IFR\_INT2\_BITS

#### **Description:**

Defines the location of the INT2 bits in the IER register.

### 7.2.2.41 CPU IFR INT3 BITS

#### **Definition:**

#define CPU\_IFR\_INT3\_BITS

### **Description:**

Defines the location of the INT3 bits in the IER register.

### 7.2.2.42 CPU IFR INT4 BITS

#### **Definition:**

#define CPU\_IFR\_INT4\_BITS

#### **Description:**

Defines the location of the INT4 bits in the IER register.

### 7.2.2.43 CPU IFR INT5 BITS

#### **Definition:**

#define CPU\_IFR\_INT5\_BITS

#### **Description:**

Defines the location of the INT5 bits in the IER register.

### 7.2.2.44 CPU IFR INT6 BITS

### **Definition:**

#define CPU\_IFR\_INT6\_BITS

#### **Description:**

Defines the location of the INT6 bits in the IER register.

### 7.2.2.45 CPU IFR INT7 BITS

#### **Definition:**

#define CPU\_IFR\_INT7\_BITS

### **Description:**

Defines the location of the INT7 bits in the IER register.

### 7.2.2.46 CPU IFR INT8 BITS

#### **Definition:**

#define CPU\_IFR\_INT8\_BITS

#### **Description:**

Defines the location of the INT8 bits in the IER register.

### 7.2.2.47 CPU\_IFR\_INT9\_BITS

#### **Definition:**

#define CPU\_IFR\_INT9\_BITS

### **Description:**

Defines the location of the INT9 bits in the IER register.

### 7.2.2.48 CPU IFR RTOSINT BITS

#### **Definition:**

#define CPU\_IFR\_RTOSINT\_BITS

#### **Description:**

Defines the location of the RTOSINT bits in the IFR register.

### 7.2.2.49 CPU\_ST0\_C\_BITS

### **Definition:**

#define CPU\_STO\_C\_BITS

#### **Description:**

Defines the location of the C bits in the ST0 register.

### 7.2.2.50 CPU ST0 N BITS

### **Definition:**

#define CPU\_ST0\_N\_BITS

#### **Description:**

Defines the location of the N bits in the ST0 register.

# 7.2.2.51 CPU\_ST0\_OVCOVCU\_BITS

#### **Definition:**

#define CPU\_STO\_OVCOVCU\_BITS

### **Description:**

Defines the location of the OVCOVCU bits in the ST0 register.

### 7.2.2.52 CPU\_ST0\_OVM\_BITS

#### **Definition:**

#define CPU\_ST0\_OVM\_BITS

#### **Description:**

Defines the location of the OVM bits in the ST0 register.

# 7.2.2.53 CPU\_ST0\_PW\_BITS

#### **Definition:**

#define CPU\_ST0\_PW\_BITS

#### **Description:**

Defines the location of the PW bits in the ST0 register.

### 7.2.2.54 CPU ST0 SXM BITS

#### **Definition:**

#define CPU\_ST0\_SXM\_BITS

#### **Description:**

Defines the location of the SXM bits in the ST0 register.

### 7.2.2.55 CPU\_ST0\_TC\_BITS

#### **Definition:**

#define CPU\_ST0\_TC\_BITS

#### **Description:**

Defines the location of the T bits in the ST0 register.

### 7.2.2.56 CPU\_ST0\_V\_BITS

### **Definition:**

#define CPU\_ST0\_V\_BITS

#### **Description:**

Defines the location of the V bits in the ST0 register.

# 7.2.2.57 CPU\_ST0\_Z\_BITS

#### **Definition:**

#define CPU\_STO\_Z\_BITS

### **Description:**

Defines the location of the Z bits in the ST0 register.

### 7.2.2.58 CPU ST1 AMODE BITS

#### **Definition:**

#define CPU\_ST1\_AMODE\_BITS

#### **Description:**

Defines the location of the AMODE bits in the ST1 register.

### 7.2.2.59 CPU\_ST1\_ARP\_BITS

#### **Definition:**

#define CPU\_ST1\_ARP\_BITS

### **Description:**

Defines the location of the ARP bits in the ST1 register.

### 7.2.2.60 CPU ST1 DBGM BITS

#### **Definition:**

#define CPU\_ST1\_DBGM\_BITS

#### **Description:**

Defines the location of the DBGM bits in the ST1 register.

### 7.2.2.61 CPU\_ST1\_EALLOW\_BITS

#### **Definition:**

#define CPU\_ST1\_EALLOW\_BITS

#### **Description:**

Defines the location of the EALLOW bits in the ST1 register.

### 7.2.2.62 CPU\_ST1\_IDLESTAT\_BITS

### **Definition:**

#define CPU\_ST1\_IDLESTAT\_BITS

#### **Description:**

Defines the location of the IDLESTAT bits in the ST1 register.

# 7.2.2.63 CPU\_ST1\_INTM\_BITS

#### **Definition:**

#define CPU\_ST1\_INTM\_BITS

### **Description:**

Defines the location of the INTM bits in the ST1 register.

### 7.2.2.64 CPU\_ST1\_LOOP\_BITS

#### **Definition:**

#define CPU\_ST1\_LOOP\_BITS

#### **Description:**

Defines the location of the LOOP bits in the ST1 register.

# 7.2.2.65 CPU\_ST1\_MOM1MAP\_BITS

#### **Definition:**

#define CPU\_ST1\_MOM1MAP\_BITS

### **Description:**

Defines the location of the MOM1MAP bits in the ST1 register.

### 7.2.2.66 CPU ST1 OBJMODE BITS

#### **Definition:**

#define CPU\_ST1\_OBJMODE\_BITS

#### **Description:**

Defines the location of the OBJMODE bits in the ST1 register.

### 7.2.2.67 CPU\_ST1\_PAGE0\_BITS

#### **Definition:**

#define CPU\_ST1\_PAGE0\_BITS

#### **Description:**

Defines the location of the PAGE0 bits in the ST1 register.

### 7.2.2.68 CPU\_ST1\_SPA\_BITS

### **Definition:**

#define CPU\_ST1\_SPA\_BITS

#### **Description:**

Defines the location of the SPA bits in the ST1 register.

### 7.2.2.69 CPU ST1 VMAP BITS

#### **Definition:**

#define CPU\_ST1\_VMAP\_BITS

#### **Description:**

Defines the location of the VMAP bits in the ST1 register.

Tue Jul 24 10:01:42 CDT 2012

### 7.2.2.70 CPU\_ST1\_XF\_BITS

#### **Definition:**

#define CPU\_ST1\_XF\_BITS

#### **Description:**

Defines the location of the XF bits in the ST1 register.

#### 7.2.2.71 DINT

#### **Definition:**

#define DINT

### **Description:**

Define to disable interrupts (legacy).

# 7.2.2.72 DISABLE\_INTERRUPTS

#### **Definition:**

#define DISABLE\_INTERRUPTS

### **Description:**

Define to disable interrupts.

# 7.2.2.73 DISABLE PROTECTED REGISTER WRITE MODE

#### **Definition:**

#define DISABLE\_PROTECTED\_REGISTER\_WRITE\_MODE

#### **Description:**

Define to disable protected register writes.

### 7.2.2.74 DRTM

#### **Definition:**

#define DRTM

### **Description:**

Define to disable debug events.

#### 7.2.2.75 EALLOW

#### **Definition:**

#define EALLOW

#### **Description:**

Define to allow protected register writes (legacy).

### 7.2.2.76 EDIS

#### **Definition:**

#define EDIS

#### **Description:**

Define to disable protected register writes (legacy).

### 7.2.2.77 EINT

#### **Definition:**

#define EINT

### **Description:**

Define to enable interrupts (legacy).

### 7.2.2.78 ENABLE INTERRUPTS

#### **Definition:**

#define ENABLE\_INTERRUPTS

### **Description:**

Define to enable interrupts.

# 7.2.2.79 ENABLE\_PROTECTED\_REGISTER\_WRITE\_MODE

### **Definition:**

#define ENABLE\_PROTECTED\_REGISTER\_WRITE\_MODE

#### Description:

Define to allow protected register writes.

### 7.2.2.80 ERTM

### **Definition:**

#define ERTM

#### **Description:**

Define to enable debug events.

### 7.2.2.81 ESTOP0

### **Definition:**

#define ESTOP0

#### **Description:**

Define for emulation stop 0.

#### 7.2.2.82 IDLE

#### **Definition:**

#define IDLE

#### **Description:**

Define for entering IDLE mode.

# 7.2.3 Typedef Documentation

### 7.2.3.1 CPU Handle

### **Definition:**

```
typedef struct CPU_Obj *CPU_Handle
```

#### **Description:**

Defines the central processing unit (CPU) handle.

### 7.2.3.2 CPU Obj

#### **Definition:**

```
typedef struct _CPU_Obj_ CPU_Obj
```

#### **Description:**

Defines the central processing unit (CPU) object.

### 7.2.4 Enumeration Documentation

# 7.2.4.1 CPU\_ExtIntNumber\_e

#### **Description:**

Enumeration to define the external interrupt numbers.

#### **Enumerators:**

```
    CPU_ExtIntNumber_1 Denotes external interrupt number 1.
    CPU_ExtIntNumber_2 Denotes external interrupt number 2.
    CPU_ExtIntNumber_3 Denotes external interrupt number 3.
```

# 7.2.4.2 CPU\_IntNumber\_e

#### **Description:**

Enumeration to define the interrupt numbers.

### **Enumerators:**

```
CPU_IntNumber_1 Denotes interrupt number 1.CPU_IntNumber_2 Denotes interrupt number 2.CPU_IntNumber_3 Denotes interrupt number 3.
```

```
    CPU_IntNumber_4 Denotes interrupt number 4.
    CPU_IntNumber_5 Denotes interrupt number 5.
    CPU_IntNumber_6 Denotes interrupt number 6.
    CPU_IntNumber_7 Denotes interrupt number 7.
    CPU_IntNumber_8 Denotes interrupt number 8.
    CPU_IntNumber_9 Denotes interrupt number 9.
    CPU_IntNumber_10 Denotes interrupt number 10.
    CPU_IntNumber_11 Denotes interrupt number 11.
    CPU_IntNumber_12 Denotes interrupt number 12.
    CPU_IntNumber_13 Denotes interrupt number 13.
    CPU_IntNumber_14 Denotes interrupt number 14.
```

# 7.2.5 Function Documentation

### 7.2.5.1 CPU clearIntFlags

Clears all interrupt flags.

#### Prototype:

```
void
CPU_clearIntFlags(CPU_Handle cpuHandle)
```

#### Parameters:

← *cpuHandle* The central processing unit (CPU) object handle

### 7.2.5.2 void CPU disableDebugInt (CPU Handle cpuHandle)

Disables the debug interrupt.

### Parameters:

← *cpuHandle* The central processing unit (CPU) object handle

### 7.2.5.3 void CPU\_disableGlobalInts (CPU\_Handle cpuHandle)

Disables global interrupts.

#### Parameters:

← *cpuHandle* The CPU handle

# 7.2.5.4 void CPU\_disableInt (CPU\_Handle cpuHandle, const CPU\_IntNumber\_e intNumber)

Disables a specified interrupt number.

#### Parameters:

- ← *cpuHandle* The central processing unit (CPU) object handle
- ← *intNumber* The interrupt number
- 7.2.5.5 void CPU disableInts (CPU Handle cpuHandle)

Disables all interrupts.

#### Parameters:

- ← *cpuHandle* The central processing unit (CPU) object handle
- 7.2.5.6 void CPU disableProtectedRegisterWrite (CPU Handle cpuHandle)

Disables protected register writes.

#### Parameters:

- ← *cpuHandle* The central processing unit (CPU) object handle
- 7.2.5.7 void CPU\_enableDebugInt (CPU\_Handle cpuHandle)

Enables the debug interrupt.

#### Parameters:

- ← *cpuHandle* The CPU handle
- 7.2.5.8 void CPU enableGlobalInts (CPU Handle cpuHandle)

Enables global interrupts.

#### Parameters:

- ← *cpuHandle* The CPU handle
- 7.2.5.9 void CPU\_enableInt (CPU\_Handle cpuHandle, const CPU\_IntNumber\_e intNumber)

Enables a specified interrupt number.

#### Parameters:

- ← *cpuHandle* The central processing unit (CPU) object handle
- $\leftarrow$  *intNumber* The interrupt number

### 7.2.5.10 void CPU enableProtectedRegisterWrite (CPU Handle cpuHandle)

Enables protected register writes.

#### Parameters:

← *cpuHandle* The central processing unit (CPU) object handle

### 7.2.5.11 CPU Handle CPU init (void \* pMemory, const size t numBytes)

Initializes the central processing unit (CPU) object handle.

### Parameters:

- ← *pMemory* A pointer to the memory for the CPU object
- ← *numBytes* The number of bytes allocated for the CPU object, bytes

#### Returns:

The central processing unit (CPU) object handle

### 7.2.6 Variable Documentation

### 7.2.6.1 CPU Obj cpu

Defines the CPU object.

# 7.2.6.2 cregister volatile unsigned int IER

External reference to the interrupt enable register (IER) register.

### 7.2.6.3 cregister volatile unsigned int IFR

External reference to the interrupt flag register (IFR) register.

# 8 Flash

Introduction	103
API Functions	103

# 8.1 Introduction

The Flash API contains functions for configuring the wait states as well as run and sleep modes of flash in the device.

**CAUTION:** The flash function(s) should only be run from RAM. Please copy the function to RAM using the memcpy function found in the run time support library before calling any of them.

This driver is contained in f2802x0\_common/source/flash.c, with f2802x0\_common/include/flash.h containing the API definitions for use by applications.

# 8.2 FLASH

### **Data Structures**

■ \_FLASH\_Obj\_

### **Defines**

- FLASH\_ACTIVE\_WAIT\_COUNT\_DEFAULT
- FLASH\_BASE\_ADDR
- FLASH\_FACTIVEWAIT\_ACTIVEWAIT\_BITS
- FLASH FBANKWAIT PAGEWAIT BITS
- FLASH\_FBANKWAIT\_RANDWAIT\_BITS
- FLASH\_FOPT\_ENPIPE\_BITS
- FLASH FOTPWAIT OTPWAIT BITS
- FLASH\_FPWR\_PWR\_BITS
- FLASH\_FSTATUS\_3VSTAT\_BITS
- FLASH\_FSTATUS\_ACTIVEWAITS\_BITS
- FLASH FSTATUS PWRS BITS
- FLASH\_FSTATUS\_STDBYWAITS\_BITS
- FLASH FSTDBYWAIT STDBYWAIT BITS
- FLASH\_STANDBY\_WAIT\_COUNT\_DEFAULT

### **Enumerations**

■ FLASH 3VStatus e

- FLASH\_CounterStatus\_e
- FLASH\_NumOtpWaitStates\_e
- FLASH NumPagedWaitStates e
- FLASH\_NumRandomWaitStates\_e
- FLASH PowerMode e

### **Functions**

- void FLASH\_clear3VStatus (FLASH\_Handle flashHandle)
- void FLASH\_disablePipelineMode (FLASH\_Handle flashHandle)
- void FLASH\_enablePipelineMode (FLASH\_Handle flashHandle)
- FLASH 3VStatus e FLASH get3VStatus (FLASH Handle flashHandle)
- uint16\_t FLASH\_getActiveWaitCount (FLASH\_Handle flashHandle)
- FLASH CounterStatus e FLASH getActiveWaitStatus (FLASH Handle flashHandle)
- FLASH PowerMode e FLASH getPowerMode (FLASH Handle flashHandle)
- uint16 t FLASH getStandbyWaitCount (FLASH Handle flashHandle)
- FLASH\_CounterStatus\_e FLASH\_getStandbyWaitStatus (FLASH\_Handle flashHandle)
- FLASH Handle FLASH init (void \*pMemory, const size t numBytes)
- void FLASH setActiveWaitCount (FLASH Handle flashHandle, const uint16 t count)
- void FLASH\_setNumPagedReadWaitStates (FLASH\_Handle flashHandle, const FLASH\_NumPagedWaitStates\_e numStates)
- void FLASH\_setNumRandomReadWaitStates (FLASH\_Handle flashHandle, const FLASH\_NumRandomWaitStates\_e numStates)
- void FLASH\_setOtpWaitStates (FLASH\_Handle flashHandle, const FLASH NumOtpWaitStates e numStates)
- void FLASH\_setPowerMode (FLASH\_Handle flashHandle, const FLASH\_PowerMode\_e mode)
- void FLASH\_setStandbyWaitCount (FLASH\_Handle flashHandle, const uint16\_t count)
- void FLASH setup (FLASH Handle flashHandle)

### 8.2.1 Data Structure Documentation

### 8.2.1.1 FLASH Obj

#### **Definition:**

```
typedef struct
{
    uint16_t FOPT;
    uint16_t rsvd_1;
    uint16_t FPWR;
    uint16_t FSTATUS;
    uint16_t FSTDBYWAIT;
    uint16_t FACTIVEWAIT;
    uint16_t FBANKWAIT;
    uint16_t FOTPWAIT;
}
_FLASH_Obj_
```

#### Members:

**FOPT** Flash Option Register.

rsvd\_1 Reserved.

FPWR Flash Power Modes Register.

FSTATUS Status Register.

FSTDBYWAIT Flash Sleep To Standby Wait Register.

FACTIVEWAIT Flash Standby to Active Wait Register.

FBANKWAIT Flash Read Access Wait State Register.

FOTPWAIT OTP Read Access Wait State Register.

### **Description:**

Defines the flash (FLASH) object.

### 8.2.2 Define Documentation

### 8.2.2.1 FLASH ACTIVE WAIT COUNT DEFAULT

#### **Definition:**

#define FLASH\_ACTIVE\_WAIT\_COUNT\_DEFAULT

#### **Description:**

Defines the default active wait count in units of SYSCLKOUT cycles.

### 8.2.2.2 FLASH\_BASE\_ADDR

#### **Definition:**

#define FLASH\_BASE\_ADDR

#### **Description:**

Defines the base address of the flash (FLASH) registers.

### 8.2.2.3 FLASH\_FACTIVEWAIT\_ACTIVEWAIT\_BITS

#### **Definition:**

#define FLASH\_FACTIVEWAIT\_ACTIVEWAIT\_BITS

#### **Description:**

Defines the location of the ACTIVEWAIT bits in the FACTIVEWAIT register.

### 8.2.2.4 FLASH FBANKWAIT PAGEWAIT BITS

#### **Definition:**

#define FLASH\_FBANKWAIT\_PAGEWAIT\_BITS

#### **Description:**

Defines the location of the PAGEWAIT bits in the FBANKWAIT register.

Tue Jul 24 10:01:42 CDT 2012

### 8.2.2.5 FLASH FBANKWAIT RANDWAIT BITS

#### **Definition:**

#define FLASH\_FBANKWAIT\_RANDWAIT\_BITS

#### **Description:**

Defines the location of the RANDWAIT bits in the FBANKWAIT register.

### 8.2.2.6 FLASH FOPT ENPIPE BITS

#### **Definition:**

#define FLASH\_FOPT\_ENPIPE\_BITS

### **Description:**

Defines the location of the ENPIPE bits in the FOPT register.

# 8.2.2.7 FLASH\_FOTPWAIT\_OTPWAIT\_BITS

#### **Definition:**

#define FLASH\_FOTPWAIT\_OTPWAIT\_BITS

#### **Description:**

Defines the location of the OTPWAIT bits in the FOTPWAIT register.

### 8.2.2.8 FLASH\_FPWR\_PWR\_BITS

#### **Definition:**

#define FLASH\_FPWR\_PWR\_BITS

#### **Description:**

Defines the location of the PWR bits in the FPWR register.

### 8.2.2.9 FLASH\_FSTATUS\_3VSTAT\_BITS

### **Definition:**

#define FLASH\_FSTATUS\_3VSTAT\_BITS

#### **Description:**

Defines the location of the 3VSTAT bits in the FSTATUS register.

### 8.2.2.10 FLASH FSTATUS ACTIVEWAITS BITS

#### **Definition:**

#define FLASH\_FSTATUS\_ACTIVEWAITS\_BITS

#### **Description:**

Defines the location of the ACTIVEWAITS bits in the FSTATUS register.

# 8.2.2.11 FLASH\_FSTATUS\_PWRS\_BITS

#### **Definition:**

#define FLASH\_FSTATUS\_PWRS\_BITS

#### **Description:**

Defines the location of the PWRS bits in the FSTATUS register.

### 8.2.2.12 FLASH\_FSTATUS\_STDBYWAITS\_BITS

#### **Definition:**

#define FLASH\_FSTATUS\_STDBYWAITS\_BITS

#### **Description:**

Defines the location of the STDBYWAITS bits in the FSTATUS register.

### 8.2.2.13 FLASH\_FSTDBYWAIT\_STDBYWAIT\_BITS

#### **Definition:**

#define FLASH\_FSTDBYWAIT\_STDBYWAIT\_BITS

#### **Description:**

Defines the location of the STDBYWAIT bits in the FSTDBYWAIT register.

### 8.2.2.14 FLASH\_STANDBY\_WAIT\_COUNT\_DEFAULT

#### **Definition:**

#define FLASH\_STANDBY\_WAIT\_COUNT\_DEFAULT

#### **Description:**

Defines the default standby wait count in units of SYSCLKOUT cycles.

# 8.2.3 Typedef Documentation

### 8.2.3.1 FLASH Handle

### **Definition:**

typedef struct FLASH\_Obj \*FLASH\_Handle

### **Description:**

Defines the flash (FLASH) handle.

### 8.2.3.2 FLASH Obj

#### **Definition:**

typedef struct \_FLASH\_Obj\_ FLASH\_Obj

#### **Description:**

Defines the flash (FLASH) object.

### 8.2.4 Enumeration Documentation

### 8.2.4.1 FLASH\_3VStatus\_e

#### **Description:**

Enumeration to define the 3V status.

#### **Enumerators:**

**FLASH\_3VStatus\_InRange** Denotes the 3V flash voltage is in range. **FLASH\_3VStatus\_OutOfRange** Denotes the 3V flash voltage went out of range.

### 8.2.4.2 FLASH\_CounterStatus\_e

#### **Description:**

Enumeration to define the counter status.

#### **Enumerators:**

**FLASH\_CounterStatus\_NotCounting** Denotes the flash counter is not counting. **FLASH\_CounterStatus\_Counting** Denotes the flash counter is counting.

### 8.2.4.3 FLASH NumOtpWaitStates e

#### **Description:**

Enumeration to define the number of one-time programmable wait states.

#### **Enumerators:**

- **FLASH\_NumOtpWaitStates\_1** Denotes the number of one-time programmable (OTP) wait states is 1.
- **FLASH\_NumOtpWaitStates\_2** Denotes the number of one-time programmable (OTP) wait states is 2.
- **FLASH\_NumOtpWaitStates\_3** Denotes the number of one-time programmable (OTP) wait states is 3.
- **FLASH\_NumOtpWaitStates\_4** Denotes the number of one-time programmable (OTP) wait states is 4.
- **FLASH\_NumOtpWaitStates\_5** Denotes the number of one-time programmable (OTP) wait states is 5.
- **FLASH\_NumOtpWaitStates\_6** Denotes the number of one-time programmable (OTP) wait states is 6.
- **FLASH\_NumOtpWaitStates\_7** Denotes the number of one-time programmable (OTP) wait states is 7.

- **FLASH\_NumOtpWaitStates\_8** Denotes the number of one-time programmable (OTP) wait states is 8.
- **FLASH\_NumOtpWaitStates\_9** Denotes the number of one-time programmable (OTP) wait states is 9.
- **FLASH\_NumOtpWaitStates\_10** Denotes the number of one-time programmable (OTP) wait states is 10.
- **FLASH\_NumOtpWaitStates\_11** Denotes the number of one-time programmable (OTP) wait states is 11.
- **FLASH\_NumOtpWaitStates\_12** Denotes the number of one-time programmable (OTP) wait states is 12.
- **FLASH\_NumOtpWaitStates\_13** Denotes the number of one-time programmable (OTP) wait states is 13.
- **FLASH\_NumOtpWaitStates\_14** Denotes the number of one-time programmable (OTP) wait states is 14.
- **FLASH\_NumOtpWaitStates\_15** Denotes the number of one-time programmable (OTP) wait states is 15.

## 8.2.4.4 FLASH NumPagedWaitStates e

### **Description:**

Enumeration to define the number of paged wait states.

#### **Enumerators:**

- **FLASH\_NumPagedWaitStates\_0** Denotes the number of paged read wait states is 0.
- FLASH\_NumPagedWaitStates\_1 Denotes the number of paged read wait states is 1.
- FLASH\_NumPagedWaitStates\_2 Denotes the number of paged read wait states is 2.
- FLASH\_NumPagedWaitStates\_3 Denotes the number of paged read wait states is 3.
- FLASH\_NumPagedWaitStates\_4 Denotes the number of paged read wait states is 4.
- **FLASH\_NumPagedWaitStates\_5** Denotes the number of paged read wait states is 5.
- **FLASH\_NumPagedWaitStates\_6** Denotes the number of paged read wait states is 6.
- FLASH\_NumPagedWaitStates\_7 Denotes the number of paged read wait states is 7.
- FLASH\_NumPagedWaitStates\_8 Denotes the number of paged read wait states is 8.
- **FLASH\_NumPagedWaitStates\_9** Denotes the number of paged read wait states is 9.
- **FLASH\_NumPagedWaitStates\_10** Denotes the number of paged read wait states is 10.
- FLASH\_NumPagedWaitStates\_11 Denotes the number of paged read wait states is 11.
- FLASH\_NumPagedWaitStates\_12 Denotes the number of paged read wait states is 12.
- FLASH\_NumPagedWaitStates\_13 Denotes the number of paged read wait states is 13.
- FLACU Name Para di Mati Otalia and A. Danata alla ana albana di sala and anti alla and anti alla and anti alla
- FLASH\_NumPagedWaitStates\_14 Denotes the number of paged read wait states is 14.
- **FLASH\_NumPagedWaitStates\_15** Denotes the number of paged read wait states is 15.

## 8.2.4.5 FLASH NumRandomWaitStates e

#### Description:

Enumeration to define the number of random wait states.

#### **Enumerators:**

FLASH NumRandomWaitStates 1 Denotes the number of randowm read wait states is 1.

FLASH\_NumRandomWaitStates\_4 Denotes the number of randowm read wait states is 3.

FLASH\_NumRandomWaitStates\_5 Denotes the number of randowm read wait states is 4.

FLASH\_NumRandomWaitStates\_6 Denotes the number of randowm read wait states is 5.

FLASH\_NumRandomWaitStates\_7 Denotes the number of randowm read wait states is 6.

FLASH\_NumRandomWaitStates\_8 Denotes the number of randowm read wait states is 8.

FLASH\_NumRandomWaitStates\_9 Denotes the number of randowm read wait states is 9.

FLASH\_NumRandomWaitStates\_10 Denotes the number of randowm read wait states is 10.

FLASH\_NumRandomWaitStates\_11 Denotes the number of randowm read wait states is 11.

**FLASH NumRandomWaitStates 2** Denotes the number of randowm read wait states is 2.

- 11. FLASH\_NumRandomWaitStates\_12 Denotes the number of randowm read wait states is
- 12. **FLASH\_NumRandomWaitStates\_13** Denotes the number of randowm read wait states is
- 13.
- **FLASH\_NumRandomWaitStates\_14** Denotes the number of randowm read wait states is 14.
- **FLASH\_NumRandomWaitStates\_15** Denotes the number of randowm read wait states is 15.

## 8.2.4.6 FLASH\_PowerMode\_e

#### **Description:**

Enumeration to define the power modes.

#### **Enumerators:**

**FLASH\_PowerMode\_PumpAndBankSleep** Denotes a pump and bank sleep power mode.

**FLASH\_PowerMode\_PumpAndBankStandby** Denotes a pump and bank standby power mode.

**FLASH\_PowerMode\_PumpAndBankActive** Denotes a pump and bank active power mode.

## 8.2.5 Function Documentation

## 8.2.5.1 FLASH clear3VStatus

Clears the 3V status.

#### Prototype:

void

FLASH\_clear3VStatus(FLASH\_Handle flashHandle)

#### Parameters:

110

← *flashHandle* The flash (FLASH) object handle

## 8.2.5.2 void FLASH\_disablePipelineMode (FLASH\_Handle flashHandle)

Disables the pipeline mode.

#### Parameters:

← flashHandle The flash (FLASH) object handle

## 8.2.5.3 void FLASH enablePipelineMode (FLASH Handle flashHandle)

Enables the pipeline mode.

## Parameters:

← flashHandle The flash (FLASH) object handle

## 8.2.5.4 FLASH\_3VStatus\_e FLASH\_get3VStatus (FLASH\_Handle flashHandle)

Gets the 3V status.

#### Parameters:

← flashHandle The flash (FLASH) object handle

#### Returns:

The 3V status

## 8.2.5.5 uint16\_t FLASH\_getActiveWaitCount (FLASH\_Handle flashHandle)

Gets the active wait count.

#### Parameters:

← *flashHandle* The flash (FLASH) object handle

## Returns:

The active wait count

## 8.2.5.6 FLASH\_CounterStatus\_e FLASH\_getActiveWaitStatus (FLASH\_Handle flashHandle)

Gets the active wait counter status.

#### Parameters:

← *flashHandle* The flash (FLASH) object handle

#### Returns:

The active wait counter status

## 8.2.5.7 FLASH PowerMode e FLASH getPowerMode (FLASH Handle flashHandle)

Gets the power mode.

## Parameters:

← flashHandle The flash (FLASH) object handle

#### Returns:

The power mode

## 8.2.5.8 uint16\_t FLASH\_getStandbyWaitCount (FLASH\_Handle flashHandle)

Gets the standby wait count.

#### Parameters:

← flashHandle The flash (FLASH) object handle

#### Returns:

The standby wait count

## 8.2.5.9 FLASH\_CounterStatus\_e FLASH\_getStandbyWaitStatus (FLASH\_Handle flashHandle)

Gets the standby wait counter status.

#### Parameters:

← *flashHandle* The flash (FLASH) object handle

#### Returns:

The standby wait counter status

## 8.2.5.10 FLASH\_Handle FLASH\_init (void \* pMemory, const size\_t numBytes)

Initializes the flash (FLASH) handle.

## Parameters:

- ← *pMemory* A pointer to the base address of the FLASH registers
- ← *numBytes* The number of bytes allocated for the FLASH object, bytes

## Returns:

The flash (FLASH) object handle

## 8.2.5.11 void FLASH\_setActiveWaitCount (FLASH\_Handle flashHandle, const uint16\_t count)

Sets the active wait count.

#### Parameters:

- ← *flashHandle* The flash (FLASH) object handle
- ← *count* The active wait count
- 8.2.5.12 void FLASH\_setNumPagedReadWaitStates (FLASH\_Handle flashHandle, const FLASH\_NumPagedWaitStates e numStates)

Sets the number of paged read wait states.

#### Parameters:

- ← flashHandle The flash (FLASH) object handle
- ← *numStates* The number of paged read wait states
- 8.2.5.13 void FLASH\_setNumRandomReadWaitStates (FLASH\_Handle flashHandle, const FLASH\_NumRandomWaitStates\_e numStates)

Sets the number of random read wait states.

#### Parameters:

- ← flashHandle The flash (FLASH) object handle
- ← *numStates* The number of random read wait states
- 8.2.5.14 void FLASH\_setOtpWaitStates (FLASH\_Handle flashHandle, const FLASH\_NumOtpWaitStates\_e numStates)

Sets the number of one-time programmable (OTP) wait states.

#### Parameters:

- ← *flashHandle* The flash (FLASH) object handle
- ← *numStates* The number of one-time programmable (OTP) wait states
- 8.2.5.15 void FLASH\_setPowerMode (FLASH\_Handle flashHandle, const FLASH\_PowerMode\_e mode)

Sets the power mode.

#### Parameters:

- ← flashHandle The flash (FLASH) object handle
- ← *mode* The power mode

# 8.2.5.16 void FLASH\_setStandbyWaitCount (FLASH\_Handle flashHandle, const uint16\_t count)

Sets the standby wait count.

#### Parameters:

- ← flashHandle The flash (FLASH) object handle
- $\leftarrow$  **count** The standby wait count

## 8.2.5.17 void FLASH\_setup (FLASH\_Handle flashHandle)

Setup flash for optimal performance.

## Parameters:

← flashHandle The flash (FLASH) object handle

## 9 General Purpose Input/Output (GPIO)

Introduction	1	1!	5
API Functions	1	1!	5

## 9.1 Introduction

The GPIO API provides functions to configure and control the GPIO of this device. Pins can be set as inputs, outputs, or a peripheral function and their value set or read via this API.

This driver is contained in f2802x0\_common/source/gpio.c, with f2802x0\_common/include/gpio.h containing the API definitions for use by applications.

## 9.2 **GPIO**

## **Data Structures**

■ GPIO Obj

## **Defines**

- GPIO BASE ADDR
- GPIO\_GPMUX\_CONFIG\_BITS

## **Enumerations**

- GPIO Direction e
- GPIO\_Mode\_e
- GPIO Number e
- GPIO\_Port\_e
- GPIO PullUp e
- GPIO Qual e

## **Functions**

- uint16\_t GPIO\_getData (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber)
- uint16\_t GPIO\_getPortData (GPIO\_Handle gpioHandle, const GPIO\_Port\_e gpioPort)
- GPIO\_Handle GPIO\_init (void \*pMemory, const size\_t numBytes)
- void GPIO\_lpmSelect (GPIO\_Handle gpioHandle, const GPIO\_Number e gpioNumber)
- void GPIO\_setDirection (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber, const GPIO\_Direction\_e direction)

- void GPIO\_setExtInt (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber, const CPU\_ExtIntNumber\_e intNumber)
- void GPIO setHigh (GPIO Handle gpioHandle, const GPIO Number e gpioNumber)
- void GPIO\_setLow (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber)
- void GPIO\_setMode (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber, const GPIO Mode e mode)
- void GPIO\_setPortData (GPIO\_Handle gpioHandle, const GPIO\_Port\_e gpioPort, const uint16\_t data)
- void GPIO\_setPullUp (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber, const GPIO PullUp e pullUp)
- void GPIO\_setQualification (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber, const GPIO\_Qual\_e qualification)
- void GPIO\_setQualificationPeriod (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioN-umber, const uint8\_t period)
- void GPIO toggle (GPIO Handle gpioHandle, const GPIO Number e gpioNumber)

## 9.2.1 Data Structure Documentation

## 9.2.1.1 \_GPIO\_Obj\_

## **Definition:**

```
typedef struct
    uint32_t GPACTRL;
    uint32_t GPAQSEL1;
    uint32_t GPAQSEL2;
    uint32_t GPAMUX1;
    uint32_t GPAMUX2;
    uint32_t GPADIR;
    uint32 t GPAPUD;
    uint16_t rsvd_1[2];
    uint32 t GPBCTRL;
    uint32_t GPBQSEL1;
    uint16_t rsvd_2[2];
    uint32_t GPBMUX1;
    uint16_t rsvd_3[2];
    uint32_t GPBDIR;
    uint32_t GPBPUD;
    uint16_t rsvd_4[24];
    uint32_t AIOMUX1;
    uint16_t rsvd_5[2];
    uint32_t AIODIR;
    uint16_t rsvd_6[4];
    uint32_t GPADAT;
    uint32 t GPASET;
    uint32_t GPACLEAR;
    uint32 t GPATOGGLE;
    uint32_t GPBDAT;
    uint32 t GPBSET;
    uint32 t GPBCLEAR;
```

```
uint32_t GPBTOGGLE;
        uint16_t rsvd_7[8];
        uint32_t AIODAT;
        uint32_t AIOSET;
        uint32 t AIOCLEAR;
        uint32_t AIOTOGGLE;
        uint16_t GPIOXINTnSEL[3];
        uint16_t rsvd_8[5];
        uint32_t GPIOLPMSEL;
   _GPIO_Obj_
Members:
   GPACTRL GPIO A Control Register.
    GPAQSEL1 GPIO A Qualifier Select 1 Register.
    GPAQSEL2 GPIO A Qualifier Select 2 Register.
    GPAMUX1 GPIO A MUX 1 Register.
    GPAMUX2 GPIO A MUX 2 Register.
    GPADIR GPIO A Direction Register.
    GPAPUD GPIO A Pull Up Disable Register.
    rsvd 1 Reserved.
    GPBCTRL GPIO B Control Register.
    GPBQSEL1 GPIO B Qualifier Select 1 Register.
    rsvd 2 Reserved.
    GPBMUX1 GPIO B MUX 1 Register.
    rsvd 3 Reserved.
    GPBDIR GPIO B Direction Register.
    GPBPUD GPIO B Pull Up Disable Register.
    rsvd_4 Reserved.
    AIOMUX1 Analog, I/O Mux 1 Register.
    rsvd_5 Reserved.
    AIODIR Analog, I/O Direction Register.
    rsvd_6 Reserved.
    GPADAT GPIO A Data Register.
    GPASET GPIO A Set Register.
    GPACLEAR GPIO A Clear Register.
    GPATOGGLE GPIO A Toggle Register.
    GPBDAT GPIO B Data Register.
    GPBSET GPIO B Set Register.
    GPBCLEAR GPIO B Clear Register.
    GPBTOGGLE GPIO B Toggle Register.
    rsvd 7 Reserved.
    AIODAT Analog I/O Data Register.
    AIOSET Analog I/O Data Set Register.
    AIOCLEAR Analog I/O Clear Register.
    AIOTOGGLE Analog I/O Toggle Register.
    GPIOXINTnSEL XINT1-3 Source Select Registers.
```

rsvd 8 Reserved.

GPIOLPMSEL GPIO Low Power Mode Wakeup Select Register.

## **Description:**

Defines the General Purpose I/O (GPIO) object.

## 9.2.2 Define Documentation

## 9.2.2.1 GPIO\_BASE\_ADDR

## **Definition:**

#define GPIO BASE ADDR

#### **Description:**

Defines the base address of the general purpose I/O (GPIO) registers.

## 9.2.2.2 GPIO GPMUX CONFIG BITS

#### **Definition:**

#define GPIO\_GPMUX\_CONFIG\_BITS

#### **Description:**

Defines the location of the CONFIG bits in the GPMUX register.

## 9.2.3 Typedef Documentation

## 9.2.3.1 GPIO\_Handle

#### **Definition:**

```
typedef struct GPIO_Obj *GPIO_Handle
```

## **Description:**

Defines the general purpose I/O (GPIO) handle.

## 9.2.3.2 GPIO Obj

#### **Definition:**

```
typedef struct _GPIO_Obj_ GPIO_Obj
```

## **Description:**

Defines the General Purpose I/O (GPIO) object.

## 9.2.4 Enumeration Documentation

## 9.2.4.1 GPIO\_Direction\_e

## **Description:**

Enumeration to define the general purpose I/O (GPIO) directions.

#### **Enumerators:**

GPIO Direction Input Denotes an input direction.

GPIO\_Direction\_Output Denotes an output direction.

## 9.2.4.2 GPIO Mode e

## **Description:**

Enumeration to define the general purpose I/O (GPIO) modes for each pin.

#### **Enumerators:**

- **GPIO\_0\_Mode\_GeneralPurpose** Denotes a general purpose function.
- **GPIO\_0\_Mode\_EPWM1A** Denotes a EPWM1A function.
- GPIO\_0\_Mode\_Rsvd\_2 Denotes a reserved function.
- GPIO\_0\_Mode\_Rsvd\_3 Denotes a reserved function.
- GPIO\_1\_Mode\_GeneralPurpose Denotes a general purpose function.
- GPIO 1 Mode EPWM1B Denotes a EPWM1B function.
- GPIO 1 Mode Rsvd 2 Denotes a reserved function.
- GPIO\_1\_Mode\_COMP1OUT Denotes a COMP1OUT function.
- GPIO\_2\_Mode\_GeneralPurpose Denotes a general purpose function.
- GPIO\_2\_Mode\_EPWM2A Denotes a EPWM2A function.
- GPIO\_2\_Mode\_Rsvd\_2 Denotes a reserved function.
- GPIO\_2\_Mode\_Rsvd\_3 Denotes a reserved function.
- **GPIO\_3\_Mode\_GeneralPurpose** Denotes a general purpose function.
- GPIO\_3\_Mode\_EPWM2B Denotes a EPWM2B function.
- GPIO\_3\_Mode\_Rsvd\_2 Denotes a reserved function.
- GPIO\_3\_Mode\_COMP2OUT Denotes a COMP2OUT function.
- GPIO 4 Mode GeneralPurpose Denotes a general purpose function.
- GPIO 4 Mode EPWM3A Denotes a EPWM3A function.
- GPIO\_4\_Mode\_Rsvd\_2 Denotes a reserved function.
- GPIO\_4\_Mode\_Rsvd\_3 Denotes a reserved function.
- GPIO 5 Mode GeneralPurpose Denotes a general purpose function.
- GPIO\_5\_Mode\_EPWM3B Denotes a EPWM3B function.
- GPIO 5 Mode Rsvd 2 Denotes a reserved function.
- GPIO\_5\_Mode\_ECAP1 Denotes a ECAP1 function.
- **GPIO\_6\_Mode\_GeneralPurpose** Denotes a general purpose function.
- GPIO\_6\_Mode\_EPWM4A Denotes a EPWM4A function.
- **GPIO\_6\_Mode\_EPWMSYNCI** Denotes a EPWMSYNCI function.
- GPIO\_6\_Mode\_EPWMSYNCO Denotes a EPWMSYNCO function.
- **GPIO\_7\_Mode\_GeneralPurpose** Denotes a general purpose function.
- GPIO\_7\_Mode\_EPWM4B Denotes a EPWM4B function.
- GPIO 7 Mode SCIRXDA Denotes a SCIRXDA function.
- GPIO 7 Mode Rsvd 3 Denotes a reserved function.
- **GPIO\_12\_Mode\_GeneralPurpose** Denotes a general purpose function.
- GPIO 12 Mode TZ1 NOT Denotes a TZ1 NOT function.
- GPIO\_12\_Mode\_SCITXDA Denotes a SCITXDA function.
- GPIO 12 Mode Rsvd 3 Denotes a reserved function.

- **GPIO\_16\_Mode\_GeneralPurpose** Denotes a general purpose function.
- **GPIO\_16\_Mode\_SPISIMOA** Denotes a SPISIMOA function.
- GPIO 16 Mode Rsvd 2 Denotes a reserved function.
- GPIO\_16\_Mode\_TZ2\_NOT Denotes a TZ2 NOT function.
- GPIO 17 Mode GeneralPurpose Denotes a general purpose function.
- GPIO\_17\_Mode\_SPISOMIA Denotes a SPISOMIA function.
- GPIO 17 Mode Rsvd 2 Denotes a reserved function.
- GPIO 17 Mode TZ3 NOT Denotes a TZ3 NOT function.
- GPIO\_18\_Mode\_GeneralPurpose Denotes a general purpose function.
- GPIO\_18\_Mode\_SPICLKA Denotes a SPICLKA function.
- GPIO 18 Mode SCITXDA Denotes a SCITXDA function.
- **GPIO\_18\_Mode\_XCLKOUT** Denotes a XCLKOUT function.
- GPIO\_19\_Mode\_GeneralPurpose Denotes a general purpose function.
- GPIO\_19\_Mode\_SPISTEA\_NOT Denotes a SPISTEA\_NOT function.
- GPIO\_19\_Mode\_SCIRXDA Denotes a SCIRXDA function.
- GPIO 19 Mode ECAP1 Denotes a ECAP1 function.
- **GPIO\_28\_Mode\_GeneralPurpose** Denotes a general purpose function.
- GPIO\_28\_Mode\_SCIRXDA Denotes a SCIRXDA function.
- GPIO 28 Mode SDDA Denotes a SDDA function.
- GPIO\_28\_Mode\_TZ2\_NOT Denotes a TZ2 NOT function.
- GPIO\_29\_Mode\_GeneralPurpose Denotes a general purpose function.
- GPIO\_29\_Mode\_SCITXDA Denotes a SCITXDA function.
- GPIO\_29\_Mode\_SCLA Denotes a SCLA function.
- GPIO\_29\_Mode\_TZ3\_NOT Denotes a TZ2\_NOT function.
- GPIO 32 Mode GeneralPurpose Denotes a general purpose function.
- GPIO\_32\_Mode\_SDAA Denotes a SDDA function.
- GPIO 32 Mode EPWMSYNCI Denotes a EPWMSYNCI function.
- GPIO 32 Mode ADCSOCAO NOT Denotes a ADCSOCAO NOT function.
- GPIO\_33\_Mode\_GeneralPurpose Denotes a general purpose function.
- GPIO 33 Mode SCLA Denotes a SCLA function.
- GPIO\_33\_Mode\_EPWMSYNCO Denotes a EPWMSYNCO function.
- GPIO 33 Mode ADCSOCBO NOT Denotes a ADCSOCBO NOT function.
- GPIO 34 Mode GeneralPurpose Denotes a general purpose function.
- GPIO 34 Mode COMP2OUT Denotes a COMP2OUT function.
- *GPIO\_34\_Mode\_Rsvd\_2* Denotes a reserved function.
- GPIO\_34\_Mode\_Rsvd\_3 Denotes a reserved function.
- GPIO\_35\_Mode\_JTAG\_TDI Denotes a JTAG TDI function.
- GPIO 35 Mode Rsvd 1 Denotes a reserved function.
- *GPIO\_35\_Mode\_Rsvd\_2* Denotes a reserved function.
- GPIO 35 Mode Rsvd 3 Denotes a reserved function.
- GPIO\_36\_Mode\_JTAG\_TMS Denotes a JTAG\_TMS function.
- GPIO\_36\_Mode\_Rsvd\_1 Denotes a reserved function.
- GPIO 36 Mode Rsvd 2 Denotes a reserved function.
- GPIO 36 Mode Rsvd 3 Denotes a reserved function.
- GPIO\_37\_Mode\_JTAG\_TDO Denotes a JTAG TDO function.
- GPIO\_37\_Mode\_Rsvd\_1 Denotes a reserved function.

```
GPIO_37_Mode_Rsvd_2 Denotes a reserved function.
GPIO_37_Mode_Rsvd_3 Denotes a reserved function.
GPIO_38_Mode_JTAG_TCK Denotes a JTAG_TCK function.
GPIO_38_Mode_Rsvd_1 Denotes a reserved function.
GPIO_38_Mode_Rsvd_2 Denotes a reserved function.
GPIO_38_Mode_Rsvd_3 Denotes a reserved function.
```

## 9.2.4.3 GPIO\_Number\_e

### **Description:**

Enumeration to define the general purpose I/O (GPIO) numbers.

#### **Enumerators:**

```
GPIO Number 0 Denotes GPIO number 0.
GPIO Number 1 Denotes GPIO number 1.
GPIO_Number_2 Denotes GPIO number 2.
GPIO Number 3 Denotes GPIO number 3.
GPIO_Number_4 Denotes GPIO number 4.
GPIO Number 5 Denotes GPIO number 5.
GPIO_Number_6 Denotes GPIO number 6.
GPIO_Number_7 Denotes GPIO number 7.
GPIO Rsvd 8 This GPIO not present.
GPIO_Rsvd_9 This GPIO not present.
GPIO_Rsvd_10 This GPIO not present.
GPIO Rsvd 11 This GPIO not present.
GPIO_Number_12 Denotes GPIO number 12.
GPIO_Rsvd_13 This GPIO not present.
GPIO_Rsvd_14 This GPIO not present.
GPIO Rsvd 15 This GPIO not present.
GPIO Number 16 Denotes GPIO number 16.
GPIO_Number_17 Denotes GPIO number 17.
GPIO Number 18 Denotes GPIO number 18.
GPIO_Number_19 Denotes GPIO number 19.
GPIO Rsvd 20 This GPIO not present.
GPIO Rsvd 21 This GPIO not present.
GPIO_Rsvd_22 This GPIO not present.
GPIO_Rsvd_23 This GPIO not present.
GPIO_Rsvd_24 This GPIO not present.
GPIO_Rsvd_25 This GPIO not present.
GPIO_Rsvd_26 This GPIO not present.
GPIO_Rsvd_27 This GPIO not present.
GPIO Number 28 Denotes GPIO number 28.
GPIO Number 29 Denotes GPIO number 29.
GPIO_Rsvd_30 This GPIO not present.
```

GPIO\_Rsvd\_31 This GPIO not present.

```
GPIO_Number_32
GPIO_Number_33
GPIO_Number_34
GPIO_Number_35
GPIO_Number_36
GPIO_Number_37
Denotes GPIO number 36.
GPIO_Number_37
Denotes GPIO number 37.
GPIO_Number_38
Denotes GPIO number 38.
```

## 9.2.4.4 GPIO Port e

## **Description:**

Enumeration to define the general purpose I/O (GPIO) ports.

#### **Enumerators:**

```
GPIO_Port_A GPIO Port A.GPIO_Port_B GPIO Port B.
```

## 9.2.4.5 GPIO\_PullUp\_e

## **Description:**

Enumeration to define the general purpose I/O (GPIO) pull ups.

#### **Enumerators:**

```
GPIO_PullUp_Enable Denotes pull up will be enabled. GPIO_PullUp_Disable Denotes pull up will be disabled.
```

## 9.2.4.6 GPIO\_Qual\_e

## **Description:**

Enumeration to define the general purpose I/O (GPIO) qualification.

## **Enumerators:**

```
    GPIO_Qual_Sync Denotes input will be synchronized to SYSCLK.
    GPIO_Qual_Sample_3 Denotes input is qualified with 3 samples.
    GPIO_Qual_Sample_6 Denotes input is qualified with 6 samples.
    GPIO_Qual_ASync Denotes input is asynchronous.
```

## 9.2.5 Function Documentation

## 9.2.5.1 GPIO getData

Returns the data value present on a pin (either input or output).

## Prototype:

#### Parameters:

- ← *gpioHandle* The general purpose I/O (GPIO) object handle
- ← *gpioNumber* The GPIO number

#### Returns:

The boolen state of a pin (high/low)

## 9.2.5.2 uint16\_t GPIO\_getPortData (GPIO\_Handle gpioHandle, const GPIO\_Port\_e gpioPort)

Returns the data value present on a GPIO port.

#### Parameters:

- ← *gpioHandle* The general purpose I/O (GPIO) object handle
- ← *gpioPort* The GPIO port

#### Returns:

The data values for the specified port

## 9.2.5.3 GPIO Handle GPIO init (void \* pMemory, const size t numBytes)

Initializes the general purpose I/O (GPIO) object handle.

## Parameters:

- ← *pMemory* A pointer to the base address of the GPIO registers
- ← *numBytes* The number of bytes allocated for the GPIO object, bytes

#### Returns:

The general purpose I/O (GPIO) object handle

## 9.2.5.4 void GPIO\_lpmSelect (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber)

Selects a gpio pin to wake up device from STANDBY and HALT LPM.

#### Parameters:

- ← *gpioHandle* The general purpose I/O (GPIO) object handle
- ← *apioNumber* The GPIO number

9.2.5.5 void GPIO\_setDirection (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber, const GPIO\_Direction e direction)

Sets the general purpose I/O (GPIO) signal direction.

#### Parameters:

- ← *gpioHandle* The general purpose I/O (GPIO) object handle
- ← *gpioNumber* The GPIO number
- ← direction The signal direction
- 9.2.5.6 void GPIO\_setExtInt (GPIO\_Handle *gpioHandle*, const GPIO\_Number\_e *gpioNumber*, const CPU\_ExtIntNumber\_e *intNumber*)

Sets the general purpose I/O (GPIO) external interrupt number.

#### Parameters:

- ← *gpioHandle* The general purpose I/O (GPIO) object handle
- ← *apioNumber* The GPIO number
- ← *intNumber* The interrupt number
- 9.2.5.7 void GPIO\_setHigh (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber)

Sets the specified general purpose I/O (GPIO) signal high.

## Parameters:

- ← *gpioHandle* The general purpose I/O (GPIO) object handle
- ← *gpioNumber* The GPIO number
- 9.2.5.8 void GPIO\_setLow (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber)

Sets the specified general purpose I/O (GPIO) signal low.

## Parameters:

- ← *gpioHandle* The general purpose I/O (GPIO) object handle
- ← *gpioNumber* The GPIO number
- 9.2.5.9 void GPIO\_setMode (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber, const GPIO\_Mode\_e mode)

Sets the mode for the specified general purpose I/O (GPIO) signal.

## Parameters:

← *gpioHandle* The general purpose I/O (GPIO) object handle

- ← *gpioNumber* The GPIO number
- ← *mode* The mode
- 9.2.5.10 void GPIO\_setPortData (GPIO\_Handle gpioHandle, const GPIO\_Port\_e gpioPort, const uint16 t data)

Sets data output on a given GPIO port.

#### Parameters:

- ← *gpioHandle* The general purpose I/O (GPIO) object handle
- ← *gpioPort* The GPIO number
- ← data The data to write to the port
- 9.2.5.11 void GPIO\_setPullUp (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber, const GPIO\_PullUp\_e pullUp)

Sets the general purpose I/O (GPIO) signal pullups.

#### Parameters:

- ← *gpioHandle* The general purpose I/O (GPIO) object handle
- ← *apioNumber* The GPIO number
- ← *pullUp* The pull up enable or disable
- 9.2.5.12 void GPIO\_setQualification (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber, const GPIO\_Qual\_e qualification)

Sets the qualification for the specified general purpose I/O (GPIO).

## Parameters:

- ← *gpioHandle* The general purpose I/O (GPIO) object handle
- ← *gpioNumber* The GPIO number
- ← *qualification* The desired input qualification
- 9.2.5.13 void GPIO\_setQualificationPeriod (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber, const uint8\_t period)

Sets the qualification period for the specified general purpose I/O block (8 I/O's per block).

## Parameters:

- ← *gpioHandle* The general purpose I/O (GPIO) object handle
- ← *gpioNumber* The GPIO number
- ← *period* The desired input qualification period

# 9.2.5.14 void GPIO\_toggle (GPIO\_Handle gpioHandle, const GPIO\_Number\_e gpioNumber)

Toggles the specified general purpose I/O (GPIO) signal.

## Parameters:

- ← *gpioHandle* The general purpose I/O (GPIO) object handle
- $\leftarrow$  *gpioNumber* The GPIO number

## 10 Oscillator (OSC)

Introduction	. 127
OSC API Drivers	.127

## 10.1 Introduction

The oscillator (OSC) API provides functions for configuring an external or internal oscillator as well as compensating the internal oscillator for temperature drift.

This driver is contained in  $f2802x0\_common/source/osc.c$ , with  $f2802x0\_common/include/osc.h$  containing the API definitions for use by applications.

## 10.2 OSC

## **Data Structures**

OSC\_Obj\_

## **Defines**

- OSC\_BASE\_ADDR
- OSC INTOSCnTRIM COARSE BITS
- OSC INTOSCnTRIM FINE BITS
- OSC\_OTP\_COURSE\_TRIM1
- OSC\_OTP\_COURSE\_TRIM2
- OSC OTP FINE TRIM OFFSET1
- OSC\_OTP\_FINE\_TRIM\_OFFSET2
- OSC\_OTP\_FINE\_TRIM\_SLOPE1
- OSC\_OTP\_FINE\_TRIM\_SLOPE2
- OSC\_OTP\_REF\_TEMP\_OFFSET

## **Enumerations**

- OSC\_Number\_e
- OSC Osc2Src e
- OSC\_Src\_e

## **Functions**

- int16 t OSC getCourseTrim1 (OSC Handle oscHandle)
- int16\_t OSC\_getCourseTrim2 (OSC\_Handle oscHandle)
- int16\_t OSC\_getFineTrimOffset1 (OSC\_Handle oscHandle)
- int16 t OSC getFineTrimOffset2 (OSC Handle oscHandle)
- int16\_t OSC\_getFineTrimSlope1 (OSC\_Handle oscHandle)
- int16\_t OSC\_getFineTrimSlope2 (OSC\_Handle oscHandle)
- int16\_t OSC\_getRefTempOffset (OSC\_Handle oscHandle)
- OSC\_Handle OSC\_init (void \*pMemory, const size\_t numBytes)
- void OSC\_setCoarseTrim (OSC\_Handle oscHandle, const OSC\_Number\_e oscNumber, const uint8\_t trimValue)
- void OSC\_setFineTrim (OSC\_Handle oscHandle, const OSC\_Number\_e oscNumber, const uint8\_t trimValue)

## 10.2.1 Data Structure Documentation

## 10.2.1.1 OSC Obj

## **Definition:**

```
typedef struct
{
    uint16_t INTOSC1TRIM;
    uint16_t rsvd_1;
    uint16_t INTOSC2TRIM;
}
_OSC_Obj_
```

## Members:

INTOSC1TRIM Internal Oscillator 1 Trim Register.

rsvd 1 Reserved.

INTOSC2TRIM Internal Oscillator 2 Trim Register.

#### **Description:**

Defines the oscillator (OSC) object.

## 10.2.2 Define Documentation

## 10.2.2.1 OSC BASE ADDR

#### **Definition:**

```
#define OSC BASE ADDR
```

#### **Description:**

Defines the base address of the oscillator (OSC) registers.

## 10.2.2.2 OSC INTOSCnTRIM COARSE BITS

#### **Definition:**

#define OSC\_INTOSCnTRIM\_COARSE\_BITS

#### **Description:**

Defines the location of the COARSETRIM bits in the INTOSCnTRIM register.

## 10.2.2.3 OSC INTOSCnTRIM FINE BITS

#### **Definition:**

#define OSC\_INTOSCnTRIM\_FINE\_BITS

#### **Description:**

Defines the location of the FINETRIM bits in the INTOSCnTRIM register.

## 10.2.2.4 OSC OTP COURSE TRIM1

### **Definition:**

#define OSC\_OTP\_COURSE\_TRIM1

#### **Description:**

Defines the address of the Course Trim 1 in OTP.

## 10.2.2.5 OSC OTP COURSE TRIM2

## **Definition:**

#define OSC\_OTP\_COURSE\_TRIM2

#### **Description:**

Defines the address of the Course Trim 1 in OTP.

## 10.2.2.6 OSC\_OTP\_FINE\_TRIM\_OFFSET1

#### **Definition:**

#define OSC\_OTP\_FINE\_TRIM\_OFFSET1

## **Description:**

Defines the address of the Fine Trim Offset 1 in OTP.

## 10.2.2.7 OSC\_OTP\_FINE\_TRIM\_OFFSET2

## **Definition:**

#define OSC\_OTP\_FINE\_TRIM\_OFFSET2

#### **Description:**

Defines the address of the Fine Trim Offset 1 in OTP.

Tue Jul 24 10:01:42 CDT 2012

## 10.2.2.8 OSC\_OTP\_FINE\_TRIM\_SLOPE1

#### **Definition:**

#define OSC\_OTP\_FINE\_TRIM\_SLOPE1

## **Description:**

Defines the address of the Fine Trim Slope 1 in OTP.

## 10.2.2.9 OSC\_OTP\_FINE\_TRIM\_SLOPE2

### **Definition:**

#define OSC\_OTP\_FINE\_TRIM\_SLOPE2

#### **Description:**

Defines the address of the Fine Trim Slope 1 in OTP.

## 10.2.2.10 OSC\_OTP\_REF\_TEMP\_OFFSET

#### **Definition:**

#define OSC\_OTP\_REF\_TEMP\_OFFSET

### Description:

Defines the address of the Reference Temp Offset in OTP.

## 10.2.3 Typedef Documentation

## 10.2.3.1 OSC\_Handle

#### **Definition:**

typedef struct OSC\_Obj \*OSC\_Handle

## **Description:**

Defines the oscillator (OSC) handle.

## 10.2.3.2 OSC Obj

#### **Definition:**

typedef struct \_OSC\_Obj\_ OSC\_Obj

## **Description:**

Defines the oscillator (OSC) object.

## 10.2.4 Enumeration Documentation

## 10.2.4.1 OSC\_Number\_e

## **Description:**

Enumeration to define the oscillator (OSC) number.

#### **Enumerators:**

OSC\_Number\_1 Denotes oscillator number 1.OSC\_Number\_2 Denotes oscillator number 2.

## 10.2.4.2 OSC\_Osc2Src\_e

## **Description:**

Enumeration to define the oscillator (OSC) 2 source.

### **Enumerators:**

OSC\_Osc2Src\_Internal Denotes an internal oscillator source for oscillator 2.OSC\_Osc2Src\_External Denotes an external oscillator source for oscillator 2.

## 10.2.4.3 OSC\_Src\_e

## **Description:**

Enumeration to define the oscillator (OSC) source.

#### **Enumerators:**

OSC\_Src\_Internal Denotes an internal oscillator.OSC\_Src\_External Denotes an external oscillator.

## 10.2.5 Function Documentation

## 10.2.5.1 OSC getCourseTrim1

Gets the fine trim offset for oscillator 1.

#### Prototype:

```
int16_t
OSC_getCourseTrim1(OSC_Handle oscHandle) [inline]
```

#### Parameters:

← clkHandle The oscillator (OSC) object handle

### Returns:

The fine trim offset for oscillator 1

10.2.5.2 int16\_t OSC\_getCourseTrim2 (OSC\_Handle oscHandle) [inline]

Gets the fine trim offset for oscillator 2.

#### Parameters:

← *clkHandle* The oscillator (OSC) object handle

#### Returns:

The fine trim offset for oscillator 2

10.2.5.3 int16\_t OSC\_getFineTrimOffset1 (OSC\_Handle oscHandle) [inline]

Gets the fine trim offset for oscillator 1.

#### Parameters:

← *clkHandle* The oscillator (OSC) object handle

#### Returns:

The fine trim offset for oscillator 1

10.2.5.4 int16\_t OSC\_getFineTrimOffset2 (OSC\_Handle oscHandle) [inline]

Gets the fine trim offset for oscillator 2.

#### Parameters:

← *clkHandle* The oscillator (OSC) object handle

#### Returns:

The fine trim offset for oscillator 2

10.2.5.5 int16 t OSC getFineTrimSlope1 (OSC Handle oscHandle) [inline]

Gets the fine trim offset for oscillator 1.

#### **Parameters:**

← *clkHandle* The oscillator (OSC) object handle

## Returns:

The fine trim offset for oscillator 1

10.2.5.6 int16\_t OSC\_getFineTrimSlope2 (OSC\_Handle oscHandle) [inline]

Gets the fine trim offset for oscillator 2.

## Parameters:

 $\leftarrow$  **clkHandle** The oscillator (OSC) object handle

#### Returns:

The fine trim offset for oscillator 2

10.2.5.7 int16 t OSC getRefTempOffset (OSC Handle oscHandle) [inline]

Gets the reference temperature offset.

#### Parameters:

← clkHandle The oscillator (OSC) object handle

#### Returns:

The reference temperature offset

10.2.5.8 OSC\_Handle OSC\_init (void \* pMemory, const size\_t numBytes)

Initializes the oscillator (OSC) handle.

#### Parameters:

- ← *pMemory* A pointer to the base address of the FLASH registers
- ← *numBytes* The number of bytes allocated for the FLASH object, bytes

#### Returns:

The flash (FLASH) object handle

10.2.5.9 void OSC\_setCoarseTrim (OSC\_Handle oscHandle, const OSC\_Number\_e oscNumber, const uint8 t trimValue)

Sets the coarse trim value for a specified oscillator.

#### Parameters:

- ← oscHandle The oscillator (OSC) object handle
- ← *oscNumber* The oscillator number
- $\leftarrow$  *trimValue* The coarse trim value

10.2.5.10 void OSC\_setFineTrim (OSC\_Handle oscHandle, const OSC\_Number\_e oscNumber, const uint8\_t trimValue)

Sets the fine trim value for a specified oscillator.

## Parameters:

- ← *oscHandle* The oscillator (OSC) object handle
- $\leftarrow$  *oscNumber* The oscillator number
- ← *trimValue* The fine trim value

## 11 Peripheral Interrupt Expansion Module (PIE)

Introduction	135
API Functions	135

## 11.1 Introduction

The Peripheral Interrupt Expansion controller (PIE) API provides functions for configuring and using the PIE on Piccolo devices. This API provides functions for enabling and disabling individual interrupt sources as well as acknowledging interrupts that have occurred.

This driver is contained in f2802x0\_common/source/pie.c, with f2802x0\_common/include/pie.h containing the API definitions for use by applications.

## 11.2 PIE

## **Data Structures**

- \_PIE\_IERIFR\_t
- PIE\_Obj\_

## **Defines**

- PIE BASE ADDR
- PIE DBGIER DLOGINT BITS
- PIE\_DBGIER\_INT10\_BITS
- PIE\_DBGIER\_INT11\_BITS
- PIE DBGIER INT12 BITS
- PIE\_DBGIER\_INT13\_BITS
- PIE DBGIER INT14 BITS
- PIE\_DBGIER\_INT1\_BITS
- PIE DBGIER INT2 BITS
- PIE\_DBGIER\_INT3\_BITS
- PIE DBGIER INT4 BITS
- PIE DBGIER INT5 BITS
- PIE\_DBGIER\_INT6\_BITS
- PIE DBGIER INT7 BITS
- PIE\_DBGIER\_INT8\_BITS
- PIE DBGIER INT9 BITS
- PIE\_DBGIER\_RTOSINT\_BITS
- PIE\_IER\_DLOGINT\_BITS
- PIE IER INT10 BITS

- PIE IER INT11 BITS
- PIE\_IER\_INT12\_BITS
- PIE\_IER\_INT13\_BITS
- PIE IER INT14 BITS
- PIE\_IER\_INT1\_BITS
- PIE\_IER\_INT2\_BITS
- PIE IER INT3 BITS
- PIE\_IER\_INT4\_BITS
- PIE IER INT5 BITS
- PIE IER INT6 BITS
- PIE\_IER\_INT7\_BITS
- PIE IER INT8 BITS
- PIE\_IER\_INT9\_BITS
- PIE\_IER\_RTOSINT\_BITS
- PIE IERx INTx1 BITS
- PIE IERx INTx2 BITS
- PIE\_IERx\_INTx3\_BITS
- PIE IERx INTx4 BITS
- PIE\_IERx\_INTx5\_BITS
- PIE IERx INTx6 BITS
- PIE IERx INTx7 BITS
- PIE\_IERx\_INTx8\_BITS
- PIE\_IFR\_DLOGINT\_BITS
- PIE IFR INT10 BITS
- PIE\_IFR\_INT11\_BITS
- PIE\_IFR\_INT12\_BITS
- PIE\_IFR\_INT13\_BITS
- PIE IFR INT14 BITS
- PIE IFR INT1 BITS
- PIE\_IFR\_INT2\_BITS
- PIE\_IFR\_INT3\_BITS
- PIE\_IFR\_INT4\_BITS
- PIE\_IFR\_INT5\_BITS
- PIE\_IFR\_INT6\_BITS
- PIE\_IFR\_INT7\_BITS
- PIE IFR INT8 BITS
- PIE\_IFR\_INT9\_BITS
- PIE IFR RTOSINT BITS
- PIE\_IFRx\_INTx1\_BITS
- PIE\_IFRx\_INTx2\_BITS
- PIE\_IFRx\_INTx3\_BITS
- PIE IFRx INTx4 BITS
- PIE\_IFRx\_INTx5\_BITS
- PIE\_IFRx\_INTx6\_BITS■ PIE\_IFRx\_INTx7\_BITS
- PIE\_IFRx\_INTx8\_BITS

- PIE PIEACK GROUP10 BITS
- PIE PIEACK GROUP11 BITS
- PIE PIEACK GROUP12 BITS
- PIE PIEACK GROUP1 BITS
- PIE PIEACK GROUP2 BITS
- PIE PIEACK GROUP3 BITS
- PIE\_PIEACK\_GROUP4\_BITS
- PIE PIEACK GROUP5 BITS
- PIE PIEACK GROUP6 BITS
- PIE PIEACK GROUP7 BITS
- PIE PIEACK GROUP8 BITS
- PIE PIEACK GROUP9 BITS
- PIE PIECTRL ENPIE BITS
- PIE PIECTRL PIEVECT BITS

## **Enumerations**

- PIE ExtIntPolarity e
- PIE GroupNumber e
- PIE\_InterruptSource\_e
- PIE SubGroupNumber e
- PIE\_SystemInterrupts\_e

## **Functions**

- void PIE clearAllFlags (PIE Handle pieHandle)
- void PIE\_clearAllInts (PIE\_Handle pieHandle)
- void PIE clearInt (PIE Handle pieHandle, const PIE GroupNumber e groupNumber)
- void PIE\_disable (PIE\_Handle pieHandle)
- void PIE disableAllInts (PIE Handle pieHandle)
- void PIE disableCaptureInt (PIE Handle pieHandle)
- void PIE\_disableInt (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e group, const PIE\_InterruptSource\_e intSource)
- void PIE\_enable (PIE\_Handle pieHandle)
- void PIE\_enableAdcInt (PIE\_Handle pieHandle, const ADC\_IntNumber\_e intNumber)
- void PIE\_enableCaptureInt (PIE\_Handle pieHandle)
- void PIE\_enableExtInt (PIE\_Handle pieHandle, const CPU\_ExtIntNumber\_e intNumber)
- void PIE\_enableInt (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e group, const PIE\_InterruptSource\_e intSource)
- void PIE enablePwmInt (PIE Handle pieHandle, const PWM Number e pwmNumber)
- void PIE\_enablePwmTzInt (PIE\_Handle pieHandle, const PWM\_Number\_e pwmNumber)
- void PIE enableTimerOInt (PIE Handle pieHandle)
- void PIE\_forceInt (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e group, const PIE\_InterruptSource\_e intSource)

- uint16\_t PIE\_getExtIntCount (PIE\_Handle pieHandle, const CPU\_ExtIntNumber\_e intNumber)
- uint16 t PIE getIntEnables (PIE Handle pieHandle, const PIE GroupNumber e group)
- uint16 t PIE getIntFlags (PIE Handle pieHandle, const PIE GroupNumber e group)
- interrupt void PIE\_illegallsr (void)
- PIE\_Handle PIE\_init (void \*pMemory, const size\_t numBytes)
- void PIE\_registerPieIntHandler (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e group-Number, const PIE\_SubGroupNumber e subGroupNumber, const intVec\_t vector)
- void PIE\_registerSystemIntHandler (PIE\_Handle pieHandle, const PIE\_SystemInterrupts\_e systemInt, const intVec t vector)
- void PIE\_setDefaultIntVectorTable (PIE\_Handle pieHandle)
- void PIE\_setExtIntPolarity (PIE\_Handle pieHandle, const CPU\_ExtIntNumber\_e intNumber, const PIE\_ExtIntPolarity\_e polarity)
- void PIE\_unregisterPieIntHandler (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e group-Number, const PIE\_SubGroupNumber\_e subGroupNumber)
- void PIE\_unregisterSystemIntHandler (PIE\_Handle pieHandle, const PIE\_SystemInterrupts\_e systemInt)

## 11.2.1 Data Structure Documentation

## 11.2.1.1 PIE IERIFR t

#### **Definition:**

```
typedef struct
{
    uint16_t IER;
    uint16_t IFR;
}
_PIE_IERIFR_t
```

#### Members:

**IER** the Interrupt Enable Register (IER) **IFR** the Interrupt Flag Register (IFR)

#### **Description:**

Defines the PIE\_IERIFR\_t data type.

## 11.2.1.2 PIE Obj

#### **Definition:**

```
typedef struct
{
    uint16_t PIECTRL;
    uint16_t PIEACK;
    PIE_IERIFR_t PIEIER_PIEIFR[12];
    uint16_t rsvd_1[6];
    intVec_t Reset;
    intVec_t INT1;
```

```
intVec_t INT2;
intVec_t INT3;
intVec_t INT4;
intVec_t INT5;
intVec t INT6;
intVec_t INT7;
intVec_t INT8;
intVec_t INT9;
intVec t INT10;
intVec_t INT11;
intVec_t INT12;
intVec_t TINT1;
intVec_t TINT2;
intVec_t DATALOG;
intVec_t RTOSINT;
intVec_t EMUINT;
intVec_t NMI;
intVec_t ILLEGAL;
intVec_t USER1;
intVec_t USER2;
intVec_t USER3;
intVec t USER4;
intVec_t USER5;
intVec t USER6;
intVec_t USER7;
intVec_t USER8;
intVec_t USER9;
intVec t USER10;
intVec_t USER11;
intVec_t USER12;
intVec_t rsvd1_1;
intVec_t rsvd1_2;
intVec_t rsvd1_3;
intVec_t XINT1;
intVec_t XINT2;
intVec_t ADCINT9;
intVec_t TINT0;
intVec_t WAKEINT;
intVec t EPWM1 TZINT;
intVec_t EPWM2_TZINT;
intVec t EPWM3 TZINT;
intVec_t EPWM4_TZINT;
intVec t rsvd2 5;
intVec_t rsvd2_6;
intVec_t rsvd2_7;
intVec_t rsvd2_8;
intVec_t EPWM1_INT;
intVec_t EPWM2_INT;
intVec_t EPWM3_INT;
intVec_t EPWM4_INT;
intVec_t rsvd3_5;
intVec_t rsvd3_6;
```

```
intVec_t rsvd3_7;
intVec_t rsvd3_8;
intVec_t ECAP1_INT;
intVec_t rsvd4_2;
intVec t rsvd4 3;
intVec_t rsvd4_4;
intVec_t rsvd4_5;
intVec_t rsvd4_6;
intVec_t rsvd4_7;
intVec_t rsvd4_8;
intVec_t rsvd5_1;
intVec_t rsvd5_2;
intVec_t rsvd5_3;
intVec_t rsvd5_4;
intVec_t rsvd5_5;
intVec_t rsvd5_6;
intVec_t rsvd5_7;
intVec_t rsvd5_8;
intVec_t SPIRXINTA;
intVec_t SPITXINTA;
intVec_t rsvd6_3;
intVec t rsvd6 4;
intVec_t rsvd6_5;
intVec t rsvd6 6;
intVec_t rsvd6_7;
intVec_t rsvd6_8;
intVec_t rsvd7_1;
intVec_t rsvd7_2;
intVec_t rsvd7_3;
intVec_t rsvd7_4;
intVec_t rsvd7_5;
intVec_t rsvd7_6;
intVec_t rsvd7_7;
intVec_t rsvd7_8;
intVec_t I2CINT1A;
intVec_t I2CINT2A;
intVec_t rsvd8_3;
intVec_t rsvd8_4;
intVec t rsvd8 5;
intVec_t rsvd8_6;
intVec_t rsvd8_7;
intVec_t rsvd8_8;
intVec t SCIRXINTA;
intVec_t SCITXINTA;
intVec_t rsvd9_3;
intVec_t rsvd9_4;
intVec_t rsvd9_5;
intVec_t rsvd9_6;
intVec_t rsvd9_7;
intVec_t rsvd9_8;
intVec_t ADCINT1;
intVec_t ADCINT2;
```

```
intVec_t ADCINT3;
        intVec_t ADCINT4;
        intVec_t ADCINT5;
        intVec_t ADCINT6;
        intVec t ADCINT7;
        intVec_t ADCINT8;
        intVec_t rsvd11_1;
        intVec_t rsvd11_2;
        intVec_t rsvd11_3;
        intVec_t rsvd11_4;
        intVec_t rsvd11_5;
        intVec_t rsvd11_6;
        intVec_t rsvd11_7;
        intVec_t rsvd11_8;
        intVec_t XINT3;
        intVec_t rsvd12_2;
        intVec_t rsvd12_3;
        intVec_t rsvd12_4;
        intVec_t rsvd12_5;
        intVec_t rsvd12_6;
        intVec_t rsvd12_7;
        intVec t rsvd12 8;
        uint16_t rsvd13[25200];
        uint16 t XINTnCR[3];
        uint16_t rsvd14[5];
        uint16_t XINTnCTR[3];
    _PIE_Obj_
Members:
    PIECTRL PIE Control Register.
    PIEACK PIE Acknowledge Register.
    PIEIER PIEIFR PIE Interrupt Enable Register and PIE Interrupt Flag Register.
    rsvd_1 Reserved.
    Reset Reset interrupt vector.
    INT1 INT1 interrupt vector.
    INT2 INT2 interrupt vector.
    INT3 INT3 interrupt vector.
    INT4 INT4 interrupt vector.
    INT5 INT5 interrupt vector.
    INT6 INT6 interrupt vector.
    INT7 INT7 interrupt vector.
    INT8 INT8 interrupt vector.
    INT9 INT9 interrupt vector.
    INT10 INT10 interrupt vector.
    INT11 INT11 interrupt vector.
    INT12 INT12 interrupt vector.
    TINT1 INT13 interrupt vector.
```

TINT2 INT14 interrupt vector.

**DATALOG** DATALOG interrupt vector.

```
RTOSINT RTOSINT interrupt vector.
EMUINT EMUINT interrupt vector.
NMI NMI interrupt vector.
ILLEGAL ILLEGAL interrupt vector.
USER1 USER1 interrupt vector.
USER2 USER2 interrupt vector.
USER3 USER3 interrupt vector.
USER4 USER4 interrupt vector.
USER5 USER5 interrupt vector.
USER6 USER6 interrupt vector.
USER7 USER7 interrupt vector.
USER8 USER8 interrupt vector.
USER9 USER9 interrupt vector.
USER10 USER10 interrupt vector.
USER11 Interrupt vector.
USER12 USER12 interrupt vector.
rsvd1_1 Reserved (Note: using ADCINT_1 in group 10).
rsvd1_2 Reserved (Note: using ADCINT 2 in group 10).
rsvd1_3 Reserved.
XINT1 XINT1 interrupt vector.
XINT2 XINT2 interrupt vector.
ADCINT9 ADCINT9 interrupt vector.
TINTO TINTO interrupt vector.
WAKEINT WAKEINT interrupt vector.
EPWM1_TZINT EPWM1_TZINT interrupt vector.
EPWM2_TZINT EPWM2 TZINT interrupt vector.
EPWM3_TZINT EPWM3_TZINT interrupt vector.
EPWM4_TZINT EPWM4 TZINT interrupt vector.
rsvd2_5 Reserved.
rsvd2 6 Reserved.
rsvd2 7 Reserved.
rsvd2 8 Reserved.
EPWM1_INT EPWM1 interrupt vector.
EPWM2 INT EPWM2 interrupt vector.
EPWM3_INT EPWM3 interrupt vector.
EPWM4_INT EPWM4 interrupt vector.
rsvd3_5 Reserved.
rsvd3 6 Reserved.
rsvd3 7 Reserved.
rsvd3 8 Reserved.
ECAP1_INT ECAP1_INT interrupt vector.
rsvd4 2 Reserved.
rsvd4 3 Reserved.
rsvd4 4 Reserved.
rsvd4_5 Reserved.
```

rsvd4\_6 Reserved.

- rsvd4\_7 Reserved.
- rsvd4\_8 Reserved.
- rsvd5\_1 Reserved.
- rsvd5\_2 Reserved.
- rsvd5 3 Reserved.
- rsvd5\_4 Reserved.
- rsvd5 5 Reserved.
- rsvd5 6 Reserved.
- rsvd5\_7 Reserved.
- rsvd5\_8 Reserved.
- SPIRXINTA SPIRXINTA interrupt vector.
- SPITXINTA SPITXINTA interrupt vector.
- rsvd6\_3 Reserved.
- rsvd6\_4 Reserved.
- rsvd6\_5 Reserved.
- rsvd6 6 Reserved.
- rsvd6\_7 Reserved.
- rsvd6\_8 Reserved.
- rsvd7\_1 Reserved.
- rsvd7\_2 Reserved.
- rsvd7\_3 Reserved.
- rsvd7 4 Reserved.
- rsvd7\_5 Reserved.
- rsvd7 6 Reserved.
- rsvd7 7 Reserved.
- *rsvd7 8* Reserved.
- I2CINT1A I2CINT1A interrupt vector.
- I2CINT2A I2CINT2A interrupt vector.
- rsvd8\_3 Reserved.
- rsvd8 4 Reserved.
- rsvd8\_5 Reserved.
- rsvd8 6 Reserved.
- rsvd8\_7 Reserved.
- rsvd8 8 Reserved.
- **SCIRXINTA** SCIRXINTA interrupt vector.
- **SCITXINTA** SCITXINTA interrupt vector.
- rsvd9\_3 Reserved.
- rsvd9 4 Reserved.
- rsvd9 5 Reserved.
- rsvd9 6 Reserved.
- rsvd9\_7 Reserved.
- rsvd9\_8 Reserved.
- ADCINT1 ADCINT1 interrupt vector.
- ADCINT2 ADCINT2 interrupt vector.
- ADCINT3 ADCINT3 interrupt vector.
- ADCINT4 ADCINT4 interrupt vector.

```
ADCINT5 ADCINT5 interrupt vector.
ADCINT6 ADCINT6 interrupt vector.
ADCINT7 ADCINT7 interrupt vector.
ADCINT8 ADCINT8 interrupt vector.
rsvd11_1 Reserved.
rsvd11 2 Reserved.
rsvd11_3 Reserved.
rsvd11_4 Reserved.
rsvd11 5 Reserved.
rsvd11_6 Reserved.
rsvd11_7 Reserved.
rsvd11 8 Reserved.
XINT3 XINT3 interrupt vector.
rsvd12 2 Reserved.
rsvd12_3 Reserved.
rsvd12 4 Reserved.
rsvd12 5 Reserved.
rsvd12_6 Reserved.
rsvd12 7 Reserved.
rsvd12_8 Reserved.
rsvd13 Reserved.
XINTnCR External Interrupt n Control Register.
rsvd14 Reserved.
XINTnCTR External Interrupt n Counter Register.
```

## **Description:**

Defines the peripheral interrupt expansion (PIE) object.

## 11.2.2 Define Documentation

## 11.2.2.1 PIE\_BASE\_ADDR

## **Definition:**

#define PIE\_BASE\_ADDR

## **Description:**

Defines the base address of the peripheral interrupt expansion (PIE) registers.

## 11.2.2.2 PIE\_DBGIER\_DLOGINT\_BITS

## **Definition:**

#define PIE\_DBGIER\_DLOGINT\_BITS

## **Description:**

Defines the location of the DLOGINT bits in the DBGIER register.

## 11.2.2.3 PIE\_DBGIER\_INT10\_BITS

#### **Definition:**

#define PIE\_DBGIER\_INT10\_BITS

#### **Description:**

Defines the location of the INT10 bits in the DBGIER register.

## 11.2.2.4 PIE DBGIER INT11 BITS

#### **Definition:**

#define PIE\_DBGIER\_INT11\_BITS

## **Description:**

Defines the location of the INT11 bits in the DBGIER register.

## 11.2.2.5 PIE DBGIER INT12 BITS

#### **Definition:**

#define PIE\_DBGIER\_INT12\_BITS

## **Description:**

Defines the location of the INT12 bits in the DBGIER register.

## 11.2.2.6 PIE\_DBGIER\_INT13\_BITS

## **Definition:**

#define PIE\_DBGIER\_INT13\_BITS

#### **Description:**

Defines the location of the INT13 bits in the DBGIER register.

## 11.2.2.7 PIE DBGIER INT14 BITS

## **Definition:**

#define PIE\_DBGIER\_INT14\_BITS

#### **Description:**

Defines the location of the INT14 bits in the DBGIER register.

## 11.2.2.8 PIE DBGIER INT1 BITS

#### **Definition:**

#define PIE\_DBGIER\_INT1\_BITS

#### **Description:**

Defines the location of the INT1 bits in the DBGIER register.

## 11.2.2.9 PIE DBGIER INT2 BITS

#### **Definition:**

#define PIE\_DBGIER\_INT2\_BITS

#### **Description:**

Defines the location of the INT2 bits in the DBGIER register.

## 11.2.2.10 PIE\_DBGIER\_INT3\_BITS

#### **Definition:**

#define PIE\_DBGIER\_INT3\_BITS

## **Description:**

Defines the location of the INT3 bits in the DBGIER register.

## 11.2.2.11 PIE DBGIER INT4 BITS

#### **Definition:**

#define PIE\_DBGIER\_INT4\_BITS

#### **Description:**

Defines the location of the INT4 bits in the DBGIER register.

## 11.2.2.12 PIE DBGIER INT5 BITS

#### **Definition:**

#define PIE\_DBGIER\_INT5\_BITS

#### **Description:**

Defines the location of the INT5 bits in the DBGIER register.

## 11.2.2.13 PIE DBGIER INT6 BITS

## **Definition:**

#define PIE\_DBGIER\_INT6\_BITS

#### **Description:**

Defines the location of the INT6 bits in the DBGIER register.

## 11.2.2.14 PIE DBGIER INT7 BITS

#### **Definition:**

#define PIE\_DBGIER\_INT7\_BITS

## **Description:**

Defines the location of the INT7 bits in the DBGIER register.

## 11.2.2.15 PIE\_DBGIER\_INT8\_BITS

#### **Definition:**

#define PIE\_DBGIER\_INT8\_BITS

#### **Description:**

Defines the location of the INT8 bits in the DBGIER register.

## 11.2.2.16 PIE DBGIER INT9 BITS

#### **Definition:**

#define PIE\_DBGIER\_INT9\_BITS

## **Description:**

Defines the location of the INT9 bits in the DBGIER register.

# 11.2.2.17 PIE\_DBGIER\_RTOSINT\_BITS

#### **Definition:**

#define PIE\_DBGIER\_RTOSINT\_BITS

#### **Description:**

Defines the location of the RTOSINT bits in the DBGIER register.

## 11.2.2.18 PIE\_IER\_DLOGINT\_BITS

## **Definition:**

#define PIE\_IER\_DLOGINT\_BITS

#### **Description:**

Defines the location of the DLOGINT bits in the IER register.

## 11.2.2.19 PIE IER INT10 BITS

## **Definition:**

#define PIE\_IER\_INT10\_BITS

#### **Description:**

Defines the location of the INT10 bits in the IER register.

# 11.2.2.20 PIE\_IER\_INT11\_BITS

#### **Definition:**

#define PIE\_IER\_INT11\_BITS

#### **Description:**

Defines the location of the INT11 bits in the IER register.

## 11.2.2.21 PIE\_IER\_INT12\_BITS

#### **Definition:**

#define PIE\_IER\_INT12\_BITS

#### **Description:**

Defines the location of the INT12 bits in the IER register.

## 11.2.2.22 PIE\_IER\_INT13\_BITS

#### **Definition:**

#define PIE\_IER\_INT13\_BITS

## **Description:**

Defines the location of the INT13 bits in the IER register.

## 11.2.2.23 PIE IER INT14 BITS

#### **Definition:**

#define PIE\_IER\_INT14\_BITS

#### **Description:**

Defines the location of the INT14 bits in the IER register.

## 11.2.2.24 PIE IER INT1 BITS

## **Definition:**

#define PIE\_IER\_INT1\_BITS

#### **Description:**

Defines the location of the INT1 bits in the IER register.

## 11.2.2.25 PIE IER INT2 BITS

## **Definition:**

#define PIE\_IER\_INT2\_BITS

#### **Description:**

Defines the location of the INT2 bits in the IER register.

# 11.2.2.26 PIE\_IER\_INT3\_BITS

#### **Definition:**

#define PIE\_IER\_INT3\_BITS

## **Description:**

Defines the location of the INT3 bits in the IER register.

## 11.2.2.27 PIE\_IER\_INT4\_BITS

#### **Definition:**

#define PIE\_IER\_INT4\_BITS

#### **Description:**

Defines the location of the INT4 bits in the IER register.

## 11.2.2.28 PIE\_IER\_INT5\_BITS

#### **Definition:**

#define PIE\_IER\_INT5\_BITS

## **Description:**

Defines the location of the INT5 bits in the IER register.

## 11.2.2.29 PIE IER INT6 BITS

#### **Definition:**

#define PIE\_IER\_INT6\_BITS

#### **Description:**

Defines the location of the INT6 bits in the IER register.

## 11.2.2.30 PIE\_IER\_INT7\_BITS

## **Definition:**

#define PIE\_IER\_INT7\_BITS

#### **Description:**

Defines the location of the INT7 bits in the IER register.

## 11.2.2.31 PIE IER INT8 BITS

## **Definition:**

#define PIE\_IER\_INT8\_BITS

#### **Description:**

Defines the location of the INT8 bits in the IER register.

# 11.2.2.32 PIE\_IER\_INT9\_BITS

#### **Definition:**

#define PIE\_IER\_INT9\_BITS

## **Description:**

Defines the location of the INT9 bits in the IER register.

## 11.2.2.33 PIE\_IER\_RTOSINT\_BITS

## **Definition:**

#define PIE\_IER\_RTOSINT\_BITS

#### **Description:**

Defines the location of the RTOSINT bits in the IER register.

## 11.2.2.34 PIE\_IERx\_INTx1\_BITS

#### **Definition:**

#define PIE\_IERx\_INTx1\_BITS

## **Description:**

Defines the location of the INTx1 bits in the IERx register.

## 11.2.2.35 PIE IERx INTx2 BITS

#### **Definition:**

#define PIE\_IERx\_INTx2\_BITS

#### **Description:**

Defines the location of the INTx2 bits in the IERx register.

## 11.2.2.36 PIE IERX INTX3 BITS

#### **Definition:**

#define PIE\_IERx\_INTx3\_BITS

#### **Description:**

Defines the location of the INTx3 bits in the IERx register.

## 11.2.2.37 PIE IERX INTX4 BITS

## **Definition:**

#define PIE\_IERx\_INTx4\_BITS

#### **Description:**

Defines the location of the INTx4 bits in the IERx register.

# 11.2.2.38 PIE\_IERx\_INTx5\_BITS

#### **Definition:**

#define PIE\_IERx\_INTx5\_BITS

## **Description:**

Defines the location of the INTx5 bits in the IERx register.

## 11.2.2.39 PIE\_IERx\_INTx6\_BITS

#### **Definition:**

#define PIE\_IERx\_INTx6\_BITS

## **Description:**

Defines the location of the INTx6 bits in the IERx register.

## 11.2.2.40 PIE\_IERx\_INTx7\_BITS

#### **Definition:**

#define PIE\_IERx\_INTx7\_BITS

## **Description:**

Defines the location of the INTx7 bits in the IERx register.

## 11.2.2.41 PIE IERx INTx8 BITS

#### **Definition:**

#define PIE\_IERx\_INTx8\_BITS

#### **Description:**

Defines the location of the INTx8 bits in the IERx register.

## 11.2.2.42 PIE\_IFR\_DLOGINT\_BITS

## **Definition:**

#define PIE\_IFR\_DLOGINT\_BITS

#### **Description:**

Defines the location of the DLOGINT bits in the IFR register.

## 11.2.2.43 PIE IFR INT10 BITS

## **Definition:**

#define PIE\_IFR\_INT10\_BITS

#### **Description:**

Defines the location of the INT10 bits in the IFR register.

# 11.2.2.44 PIE\_IFR\_INT11\_BITS

#### **Definition:**

#define PIE\_IFR\_INT11\_BITS

## **Description:**

Defines the location of the INT11 bits in the IFR register.

## 11.2.2.45 PIE\_IFR\_INT12\_BITS

## **Definition:**

#define PIE\_IFR\_INT12\_BITS

## **Description:**

Defines the location of the INT12 bits in the IFR register.

## 11.2.2.46 PIE\_IFR\_INT13\_BITS

#### **Definition:**

#define PIE\_IFR\_INT13\_BITS

## **Description:**

Defines the location of the INT13 bits in the IFR register.

## 11.2.2.47 PIE IFR INT14 BITS

#### **Definition:**

#define PIE\_IFR\_INT14\_BITS

## **Description:**

Defines the location of the INT14 bits in the IFR register.

## 11.2.2.48 PIE IFR INT1 BITS

#### **Definition:**

#define PIE\_IFR\_INT1\_BITS

#### **Description:**

Defines the location of the INT1 bits in the IFR register.

## 11.2.2.49 PIE IFR INT2 BITS

## **Definition:**

#define PIE\_IFR\_INT2\_BITS

#### **Description:**

Defines the location of the INT2 bits in the IFR register.

# 11.2.2.50 PIE\_IFR\_INT3\_BITS

#### **Definition:**

#define PIE\_IFR\_INT3\_BITS

## **Description:**

Defines the location of the INT3 bits in the IFR register.

## 11.2.2.51 PIE\_IFR\_INT4\_BITS

#### **Definition:**

#define PIE\_IFR\_INT4\_BITS

#### **Description:**

Defines the location of the INT4 bits in the IFR register.

## 11.2.2.52 PIE\_IFR\_INT5\_BITS

#### **Definition:**

#define PIE\_IFR\_INT5\_BITS

## **Description:**

Defines the location of the INT5 bits in the IFR register.

## 11.2.2.53 PIE IFR INT6 BITS

#### **Definition:**

#define PIE\_IFR\_INT6\_BITS

## **Description:**

Defines the location of the INT6 bits in the IFR register.

## 11.2.2.54 PIE\_IFR\_INT7\_BITS

## **Definition:**

#define PIE\_IFR\_INT7\_BITS

#### **Description:**

Defines the location of the INT7 bits in the IFR register.

## 11.2.2.55 PIE IFR INT8 BITS

## **Definition:**

#define PIE\_IFR\_INT8\_BITS

#### **Description:**

Defines the location of the INT8 bits in the IFR register.

# 11.2.2.56 PIE\_IFR\_INT9\_BITS

#### **Definition:**

#define PIE\_IFR\_INT9\_BITS

## **Description:**

Defines the location of the INT9 bits in the IFR register.

## 11.2.2.57 PIE\_IFR\_RTOSINT\_BITS

## **Definition:**

#define PIE\_IFR\_RTOSINT\_BITS

#### **Description:**

Defines the location of the RTOSINT bits in the IFR register.

## 11.2.2.58 PIE\_IFRx\_INTx1\_BITS

#### **Definition:**

#define PIE\_IFRx\_INTx1\_BITS

## **Description:**

Defines the location of the INTx1 bits in the IFRx register.

## 11.2.2.59 PIE IFRx INTx2 BITS

#### **Definition:**

#define PIE\_IFRx\_INTx2\_BITS

#### **Description:**

Defines the location of the INTx2 bits in the IFRx register.

## 11.2.2.60 PIE\_IFRx\_INTx3\_BITS

#### **Definition:**

#define PIE\_IFRx\_INTx3\_BITS

#### **Description:**

Defines the location of the INTx3 bits in the IFRx register.

## 11.2.2.61 PIE IFRx INTx4 BITS

## **Definition:**

#define PIE\_IFRx\_INTx4\_BITS

#### **Description:**

Defines the location of the INTx4 bits in the IFRx register.

# 11.2.2.62 PIE\_IFRx\_INTx5\_BITS

#### **Definition:**

#define PIE\_IFRx\_INTx5\_BITS

## **Description:**

Defines the location of the INTx5 bits in the IFRx register.

## 11.2.2.63 PIE\_IFRx\_INTx6\_BITS

#### **Definition:**

#define PIE\_IFRx\_INTx6\_BITS

#### **Description:**

Defines the location of the INTx6 bits in the IFRx register.

## 11.2.2.64 PIE IFRX INTX7 BITS

#### **Definition:**

#define PIE\_IFRx\_INTx7\_BITS

## **Description:**

Defines the location of the INTx7 bits in the IFRx register.

## 11.2.2.65 PIE\_IFRx\_INTx8\_BITS

#### **Definition:**

#define PIE\_IFRx\_INTx8\_BITS

#### **Description:**

Defines the location of the INTx8 bits in the IFRx register.

# 11.2.2.66 PIE\_PIEACK\_GROUP10\_BITS

#### **Definition:**

#define PIE\_PIEACK\_GROUP10\_BITS

#### **Description:**

Defines the location of the GROUP10 bits in the PIEACK register.

## 11.2.2.67 PIE PIEACK GROUP11 BITS

## **Definition:**

#define PIE\_PIEACK\_GROUP11\_BITS

#### **Description:**

Defines the location of the GROUP11 bits in the PIEACK register.

## 11.2.2.68 PIE PIEACK GROUP12 BITS

#### **Definition:**

#define PIE\_PIEACK\_GROUP12\_BITS

#### **Description:**

Defines the location of the GROUP12 bits in the PIEACK register.

## 11.2.2.69 PIE\_PIEACK\_GROUP1\_BITS

#### **Definition:**

#define PIE\_PIEACK\_GROUP1\_BITS

#### **Description:**

Defines the location of the GROUP1 bits in the PIEACK register.

## 11.2.2.70 PIE\_PIEACK\_GROUP2\_BITS

#### **Definition:**

#define PIE\_PIEACK\_GROUP2\_BITS

## **Description:**

Defines the location of the GROUP2 bits in the PIEACK register.

## 11.2.2.71 PIE PIEACK GROUP3 BITS

#### **Definition:**

#define PIE\_PIEACK\_GROUP3\_BITS

## **Description:**

Defines the location of the GROUP3 bits in the PIEACK register.

## 11.2.2.72 PIE\_PIEACK\_GROUP4\_BITS

#### **Definition:**

#define PIE\_PIEACK\_GROUP4\_BITS

#### **Description:**

Defines the location of the GROUP4 bits in the PIEACK register.

## 11.2.2.73 PIE PIEACK\_GROUP5\_BITS

## **Definition:**

#define PIE\_PIEACK\_GROUP5\_BITS

#### **Description:**

Defines the location of the GROUP5 bits in the PIEACK register.

## 11.2.2.74 PIE PIEACK GROUP6 BITS

#### **Definition:**

#define PIE\_PIEACK\_GROUP6\_BITS

## **Description:**

Defines the location of the GROUP6 bits in the PIEACK register.

## 11.2.2.75 PIE\_PIEACK\_GROUP7\_BITS

#### **Definition:**

#define PIE\_PIEACK\_GROUP7\_BITS

## **Description:**

Defines the location of the GROUP7 bits in the PIEACK register.

## 11.2.2.76 PIE PIEACK GROUP8 BITS

#### **Definition:**

#define PIE\_PIEACK\_GROUP8\_BITS

## **Description:**

Defines the location of the GROUP8 bits in the PIEACK register.

## 11.2.2.77 PIE PIEACK GROUP9 BITS

#### **Definition:**

#define PIE\_PIEACK\_GROUP9\_BITS

#### **Description:**

Defines the location of the GROUP9 bits in the PIEACK register.

## 11.2.2.78 PIE PIECTRL ENPIE BITS

#### **Definition:**

#define PIE\_PIECTRL\_ENPIE\_BITS

#### **Description:**

Defines the location of the ENPIE bits in the PIECTRL register.

## 11.2.2.79 PIE PIECTRL PIEVECT BITS

#### **Definition:**

#define PIE\_PIECTRL\_PIEVECT\_BITS

## **Description:**

Defines the location of the PIEVECT bits in the PIECTRL register.

# 11.2.3 Typedef Documentation

## 11.2.3.1 intVec t

#### **Definition:**

typedef interrupt void(\*) intVec\_t (void)

## **Description:**

Defines the type for an interrupt vector.

## 11.2.3.2 PIE\_Handle

#### **Definition:**

```
typedef struct PIE_Obj *PIE_Handle
```

## **Description:**

Defines the peripheral interrupt expansion (PIE) handle.

# 11.2.3.3 PIE\_IERIFR\_t

#### **Definition:**

```
typedef struct _PIE_IERIFR_t PIE_IERIFR_t
```

#### **Description:**

Defines the PIE\_IERIFR\_t data type.

## 11.2.3.4 PIE\_Obj

#### **Definition:**

```
typedef struct _PIE_Obj_ PIE_Obj
```

#### **Description:**

Defines the peripheral interrupt expansion (PIE) object.

## 11.2.4 Enumeration Documentation

## 11.2.4.1 PIE\_ExtIntPolarity\_e

#### **Description:**

Enumeration to define the external interrupt polarity.

#### **Enumerators:**

**PIE\_ExtIntPolarity\_FallingEdge** Denotes an interrupt is generated on the falling edge.

PIE\_ExtIntPolarity\_RisingEdge Denotes an interrupt is generated on the rising edge.

**PIE\_ExtIntPolarity\_RisingAndFallingEdge** Denotes an interrupt is generated on the falling and rising edges.

## 11.2.4.2 PIE\_GroupNumber\_e

#### **Description:**

Enumeration to define the peripheral interrupt expansion (PIE) group numbers.

## **Enumerators:**

```
PIE_GroupNumber_1 Denotes PIE group number 1.

PIE_GroupNumber_2 Denotes PIE group number 2.

PIE_GroupNumber_3 Denotes PIE group number 3.

PIE_GroupNumber_4 Denotes PIE group number 4.

PIE_GroupNumber_5 Denotes PIE group number 5.

PIE_GroupNumber_6 Denotes PIE group number 6.

PIE_GroupNumber_7 Denotes PIE group number 7.

PIE_GroupNumber_8 Denotes PIE group number 8.

PIE_GroupNumber_1 Denotes PIE group number 9.

PIE_GroupNumber_1 Denotes PIE group number 10.

PIE_GroupNumber_1 Denotes PIE group number 11.

PIE_GroupNumber_1 Denotes PIE group number 11.
```

## 11.2.4.3 PIE InterruptSource e

#### Description:

Enumeration to define the peripheral interrupt expansion (PIE) individual interrupt sources.

#### **Enumerators:**

```
PIE_InterruptSource_ADCINT_1_1 Group 1 ADC Interrupt 1.
PIE_InterruptSource_ADCINT_1_2 Group 1 ADC Interrupt 2.
PIE InterruptSource_XINT_1 External Interrupt 1.
PIE_InterruptSource_XINT_2 External Interrupt 2.
PIE_InterruptSource_ADCINT_9 ADC Interrupt 9.
PIE_InterruptSource_TIMER_0 Timer Interrupt 0.
PIE InterruptSource WAKE Wake Up Interrupt.
PIE InterruptSource TZ1 EPWM TZ1 Interrupt.
PIE_InterruptSource_TZ2 EPWM TZ2 Interrupt.
PIE_InterruptSource_TZ3 EPWM TZ3 Interrupt.
PIE InterruptSource TZ4 EPWM TZ4 Interrupt.
PIE_InterruptSource_EPWM1 EPWM 1 Interrupt.
PIE_InterruptSource_EPWM2 EPWM 2 Interrupt.
PIE_InterruptSource_EPWM3 EPWM 3 Interrupt.
PIE InterruptSource EPWM4 EPWM 4 Interrupt.
PIE_InterruptSource_ECAP1 ECAP 1 Interrupt.
PIE_InterruptSource_SPIATX SPI A TX Interrupt.
PIE InterruptSource I2CA1 I2C A Interrupt 1.
PIE InterruptSource I2CA2 | I2C A Interrupt 2.
PIE_InterruptSource_SCIARX SCI A RX Interrupt.
PIE InterruptSource SCIATX SCI A TX Interrupt.
PIE_InterruptSource_ADCINT_10_1 Group 10 ADC Interrupt 1.
PIE InterruptSource ADCINT 10 2 Group 10 ADC Interrupt 2.
PIE_InterruptSource_ADCINT_3 ADC Interrupt 3.
PIE InterruptSource ADCINT 4 ADC Interrupt 4.
```

```
PIE_InterruptSource_ADCINT_5 ADC Interrupt 5.
PIE_InterruptSource_ADCINT_6 ADC Interrupt 6.
PIE_InterruptSource_ADCINT_7 ADC Interrupt 7.
PIE_InterruptSource_ADCINT_8 ADC Interrupt 8.
PIE_InterruptSource_XINT_3 External Interrupt 3.
```

## 11.2.4.4 PIE SubGroupNumber e

#### **Description:**

Enumeration to define the peripheral interrupt expansion (PIE) sub-group numbers.

#### **Enumerators:**

```
    PIE_SubGroupNumber_1 Denotes PIE group number 1.
    PIE_SubGroupNumber_2 Denotes PIE group number 2.
    PIE_SubGroupNumber_3 Denotes PIE group number 3.
    PIE_SubGroupNumber_4 Denotes PIE group number 4.
    PIE_SubGroupNumber_5 Denotes PIE group number 5.
    PIE_SubGroupNumber_6 Denotes PIE group number 6.
    PIE_SubGroupNumber_7 Denotes PIE group number 7.
    PIE_SubGroupNumber_8 Denotes PIE group number 8.
```

## 11.2.4.5 PIE\_SystemInterrupts\_e

#### Description:

Enumeration to define the system interrupts.

#### **Enumerators:**

```
PIE_SystemInterrupts_Reset Reset interrupt vector.
PIE SystemInterrupts INT1 INT1 interrupt vector.
PIE_SystemInterrupts_INT2 INT2 interrupt vector.
PIE_SystemInterrupts_INT3 INT3 interrupt vector.
PIE SystemInterrupts INT4 INT4 interrupt vector.
PIE_SystemInterrupts_INT5 INT5 interrupt vector.
PIE_SystemInterrupts_INT6 INT6 interrupt vector.
PIE_SystemInterrupts_INT7 INT7 interrupt vector.
PIE_SystemInterrupts_INT8 INT8 interrupt vector.
PIE_SystemInterrupts_INT9 INT9 interrupt vector.
PIE_SystemInterrupts_INT10 INT10 interrupt vector.
PIE SystemInterrupts INT11 INT11 interrupt vector.
PIE_SystemInterrupts_INT12 INT12 interrupt vector.
PIE_SystemInterrupts_TINT1 INT13 interrupt vector.
PIE SystemInterrupts TINT2 INT14 interrupt vector.
PIE_SystemInterrupts_DATALOG DATALOG interrupt vector.
PIE SystemInterrupts RTOSINT RTOSINT interrupt vector.
PIE_SystemInterrupts_EMUINT EMUINT interrupt vector.
```

```
PIE_SystemInterrupts_ILLEGAL ILLEGAL interrupt vector.

PIE_SystemInterrupts_USER1 USER1 interrupt vector.

PIE_SystemInterrupts_USER2 USER2 interrupt vector.

PIE_SystemInterrupts_USER3 USER3 interrupt vector.

PIE_SystemInterrupts_USER4 USER4 interrupt vector.

PIE_SystemInterrupts_USER5 USER5 interrupt vector.

PIE_SystemInterrupts_USER6 USER6 interrupt vector.

PIE_SystemInterrupts_USER7 USER7 interrupt vector.

PIE_SystemInterrupts_USER8 USER8 interrupt vector.

PIE_SystemInterrupts_USER9 USER8 interrupt vector.

PIE_SystemInterrupts_USER10 USER10 interrupt vector.

PIE_SystemInterrupts_USER11 USER11 interrupt vector.

PIE_SystemInterrupts_USER11 USER11 interrupt vector.

PIE_SystemInterrupts_USER12 USER12 interrupt vector.
```

# 11.2.5 Function Documentation

## 11.2.5.1 PIE clearAllFlags

Clears all the interrupt flags.

## Prototype:

```
void
PIE_clearAllFlags(PIE_Handle pieHandle)
```

#### Parameters:

← *pieHandle* The peripheral interrupt expansion (PIE) object handle

## 11.2.5.2 void PIE\_clearAllInts (PIE\_Handle pieHandle)

Clears all the interrupts.

#### Parameters:

← *pieHandle* The peripheral interrupt expansion (PIE) object handle

# 11.2.5.3 void PIE\_clearInt (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e groupNumber) [inline]

Clears an interrupt defined by group number.

- ← *pieHandle* The peripheral interrupt expansion (PIE) object handle
- ← *groupNumber* The group number

## 11.2.5.4 void PIE disable (PIE Handle pieHandle)

Disables the peripheral interrupt expansion (PIE).

#### Parameters:

← *pieHandle* The peripheral interrupt expansion (PIE) object handle

## 11.2.5.5 void PIE disableAllInts (PIE Handle pieHandle)

Disables all of the interrupts.

#### Parameters:

← *pieHandle* The peripheral interrupt expansion (PIE) object handle

## 11.2.5.6 void PIE disableCaptureInt (PIE Handle pieHandle)

Disables the capture interrupt.

#### Parameters:

← *pieHandle* The peripheral interrupt expansion (PIE) object handle

# 11.2.5.7 void PIE\_disableInt (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e group, const PIE\_InterruptSource\_e intSource)

Disable a specific PIE interrupt.

#### Parameters:

- ← *pieHandle* The peripheral interrupt expansion (PIE) object handle
- ← *group* The PIE group an interrupt belongs to
- ← *intSource* The specific interrupt source to disable

## 11.2.5.8 void PIE\_enable (PIE\_Handle pieHandle)

Enables the peripheral interrupt expansion (PIE).

#### Parameters:

← *pieHandle* The peripheral interrupt expansion (PIE) object handle

# 11.2.5.9 void PIE\_enableAdcInt (PIE\_Handle pieHandle, const ADC\_IntNumber\_e intNumber)

Enables the specified ADC interrupt.

- ← pieHandle The peripheral interrupt expansion (PIE) object handle
- ← *intNumber* The interrupt number

11.2.5.10 void PIE enableCaptureInt (PIE Handle pieHandle)

Enables the capture interrupt.

#### **Parameters:**

- ← *pieHandle* The peripheral interrupt expansion (PIE) object handle
- 11.2.5.11 void PIE\_enableExtInt (PIE\_Handle pieHandle, const CPU\_ExtIntNumber\_e intNumber)

Enables the prescribed external interrupt.

#### Parameters:

- ← *pieHandle* The peripheral interrupt expansion (PIE) handle
- ← *intNumber* The interrupt number
- 11.2.5.12 void PIE\_enableInt (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e group, const PIE\_InterruptSource e intSource)

Enable a specific PIE interrupt.

#### Parameters:

- ← *pieHandle* The peripheral interrupt expansion (PIE) object handle
- ← *group* The PIE group an interrupt belongs to
- ← *intSource* The specific interrupt source to enable
- 11.2.5.13 void PIE\_enablePwmInt (PIE\_Handle pieHandle, const PWM\_Number\_e pwmNumber)

Enables the PWM interrupt.

#### Parameters:

- ← *pieHandle* The peripheral interrupt expansion (PIE) handle
- ← *pwmNumber* The PWM number
- 11.2.5.14 void PIE\_enablePwmTzInt (PIE\_Handle *pieHandle*, const PWM\_Number\_e *pwmNumber*)

Enables the PWM Trip Zone interrupt.

- ← *pieHandle* The peripheral interrupt expansion (PIE) handle
- $\leftarrow$  *pwmNumber* The PWM number

11.2.5.15 void PIE enableTimer0Int (PIE Handle pieHandle)

Enables the Cpu Timer 0 interrupt.

#### Parameters:

- ← *pieHandle* The peripheral interrupt expansion (PIE) handle
- 11.2.5.16 void PIE\_forceInt (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e group, const PIE\_InterruptSource\_e intSource)

Force a specific PIE interrupt.

#### Parameters:

- ← *pieHandle* The peripheral interrupt expansion (PIE) object handle
- ← *group* The PIE group an interrupt belongs to
- ← *intSource* The specific interrupt source to force
- 11.2.5.17 uint16\_t PIE\_getExtIntCount (PIE\_Handle pieHandle, const CPU\_ExtIntNumber\_e intNumber)

Gets the external interrupt count value.

#### Parameters:

- ← *pieHandle* The peripheral interrupt expansion (PIE) handle
- $\leftarrow$  *intNumber* The external interrupt number

#### Returns:

The count value

11.2.5.18 uint16\_t PIE\_getIntEnables (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e group)

Gets PIE interrupt enable values.

#### Parameters:

- ← *pieHandle* The peripheral interrupt expansion (PIE) object handle
- $\leftarrow$  *group* The PIE group the flags belong to
- 11.2.5.19 uint16\_t PIE\_getIntFlags (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e group)

Gets PIE interrupt flag values.

- ← *pieHandle* The peripheral interrupt expansion (PIE) object handle
- ← group The PIE group the flags belong to

## 11.2.5.20 interrupt void PIE illegallsr (void)

Defines an illegal interrupt service routine - if the program pointer references this function, there is an incorrect mapping in the PIE interrupt table.

## 11.2.5.21 PIE Handle PIE init (void \* pMemory, const size t numBytes)

Initializes the peripheral interrupt expansion (PIE) object handle.

#### Parameters:

- ← *pMemory* A pointer to the memory for the PIE object
- ← *numBytes* The number of bytes allocated for the PIE object, bytes

#### Returns:

The peripheral interrupt expansion (PIE) object handle

11.2.5.22 void PIE\_registerPieIntHandler (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e groupNumber, const PIE\_SubGroupNumber\_e subGroupNumber, const intVec\_t vector)

Registers a handler for a PIE interrupt.

#### Parameters:

- ← *pieHandle* The peripheral interrupt expansion (PIE) object handle
- ← *groupNumber* The PIE group an interrupt belongs to
- ← *subGroupNumber* The PIE subgroup an interrupt belongs to
- ← *vector* The specific interrupt handler

# 11.2.5.23 void PIE\_registerSystemIntHandler (PIE\_Handle pieHandle, const PIE\_SystemInterrupts\_e systemInt, const intVec\_t vector)

Registers a handler for a PIE interrupt.

## Parameters:

- ← *pieHandle* The peripheral interrupt expansion (PIE) object handle
- ← **systemInt** The system interrupt to register this handler to
- ← *vector* The specific interrupt handler

## 11.2.5.24 void PIE setDefaultIntVectorTable (PIE Handle pieHandle)

Initializes the vector table with illegal ISR handlers.

#### Parameters:

← *pieHandle* The peripheral interrupt expansion (PIE) object handle

11.2.5.25 void PIE\_setExtIntPolarity (PIE\_Handle pieHandle, const CPU\_ExtIntNumber\_e intNumber, const PIE\_ExtIntPolarity\_e polarity)

Sets the external interrupt polarity.

#### Parameters:

- ← *pieHandle* The peripheral interrupt expansion (PIE) handle
- ← *intNumber* The external interrupt number
- ← *polarity* The signal polarity
- 11.2.5.26 void PIE\_unregisterPieIntHandler (PIE\_Handle pieHandle, const PIE\_GroupNumber\_e groupNumber, const PIE\_SubGroupNumber\_e subGroupNumber)

Unregisters a handler for a PIE interrupt.

#### Parameters:

- ← *pieHandle* The peripheral interrupt expansion (PIE) object handle
- ← *groupNumber* The PIE group an interrupt belongs to
- ← *subGroupNumber* The PIE subgroup an interrupt belongs to
- 11.2.5.27 void PIE\_unregisterSystemIntHandler (PIE\_Handle pieHandle, const PIE SystemInterrupts e systemInt)

Unregisters a handler for a PIE interrupt.

- ← *pieHandle* The peripheral interrupt expansion (PIE) object handle
- ← **systemInt** The system interrupt to unregister

# 12 Phase Locked Loop (PLL)

Introduction	1	6	
API Functions	1	6	í

# 12.1 Introduction

The Phase Locked Loop (PLL) API provides functions for configuring the device's PLL as well as other miscellaneous clock functions.

This driver is contained in f2802x0\_common/source/pll.c, with f2802x0\_common/include/pll.h containing the API definitions for use by applications.

# 12.2 PLL

## **Data Structures**

■ PLL Obj

# **Defines**

- PLL BASE ADDR
- PLL\_PLLCR\_DIV\_BITS
- PLL\_PLLSTS\_DIVSEL\_BITS
- PLL PLLSTS MCLKCLR BITS
- PLL PLLSTS MCLKOFF BITS
- PLL\_PLLSTS\_MCLKSTS\_BITS
- PLL\_PLLSTS\_NORMRDYE\_BITS
- PLL PLLSTS OSCOFF BITS
- PLL\_PLLSTS\_PLLLOCKS\_BITS
- PLL PLLSTS PLLOFF BITS

## **Enumerations**

- PLL ClkStatus e
- PLL\_DivideSelect\_e
- PLL LockStatus e
- PLL\_Multiplier\_e

## **Functions**

- void PLL\_disable (PLL\_Handle pllHandle)
- void PLL\_disableClkDetect (PLL\_Handle pllHandle)
- void PLL\_disableNormRdy (PLL\_Handle pllHandle)
- void PLL disableOsc (PLL Handle pllHandle)
- void PLL\_enable (PLL\_Handle pllHandle)
- void PLL\_enableClkDetect (PLL\_Handle pllHandle)
- void PLL\_enableNormRdy (PLL\_Handle pllHandle)
- void PLL\_enableOsc (PLL\_Handle pllHandle)
- PLL\_ClkStatus\_e PLL\_getClkStatus (PLL\_Handle pllHandle)
- PLL DivideSelect e PLL getDivider (PLL Handle pllHandle)
- PLL LockStatus e PLL getLockStatus (PLL Handle pllHandle)
- PLL\_Multiplier\_e PLL\_getMultiplier (PLL\_Handle pllHandle)
- PLL\_Handle PLL\_init (void \*pMemory, const size\_t numBytes)
- void PLL resetClkDetect (PLL Handle pllHandle)
- void PLL\_setDivider (PLL\_Handle pllHandle, const PLL\_DivideSelect\_e divSelect)
- void PLL setLockPeriod (PLL Handle pllHandle, const uint16 t lockPeriod)
- void PLL\_setMultiplier (PLL\_Handle pllHandle, const PLL\_Multiplier\_e freq)
- void PLL\_setup (PLL\_Handle pllHandle, const PLL\_Multiplier\_e clkMult, const PLL\_DivideSelect\_e divSelect)

## 12.2.1 Data Structure Documentation

## 12.2.1.1 PLL Obj

## **Definition:**

```
typedef struct
{
    uint16_t PLLSTS;
    uint16_t rsvd_1;
    uint16_t PLLLOCKPRD;
    uint16_t rsvd_2[13];
    uint16_t PLLCR;
}
_PLL_Obj_
```

## Members:

PLLSTS PLL Status Register.
rsvd\_1 Reserved.
PLLLOCKPRD PLL Lock Period Register.
rsvd\_2 Reserved.
PLLCR PLL Control Register.

#### **Description:**

Defines the phase lock loop (PLL) object.

# 12.2.2 Define Documentation

## 12.2.2.1 PLL BASE ADDR

#### **Definition:**

#define PLL\_BASE\_ADDR

## **Description:**

Defines the base address of the phase lock loop (PLL) registers.

## 12.2.2.2 PLL PLLCR DIV BITS

#### **Definition:**

#define PLL\_PLLCR\_DIV\_BITS

## **Description:**

Defines the location of the DIV bits in the PLLCR register.

## 12.2.2.3 PLL PLLSTS DIVSEL BITS

#### **Definition:**

#define PLL\_PLLSTS\_DIVSEL\_BITS

## **Description:**

Defines the location of the DIVSEL bits in the PLLSTS register.

## 12.2.2.4 PLL\_PLLSTS\_MCLKCLR\_BITS

#### **Definition:**

#define PLL\_PLLSTS\_MCLKCLR\_BITS

#### **Description:**

Defines the location of the MCLKCLR bits in the PLLSTS register.

## 12.2.2.5 PLL PLLSTS MCLKOFF BITS

#### **Definition:**

#define PLL\_PLLSTS\_MCLKOFF\_BITS

#### **Description:**

Defines the location of the MCLKOFF bits in the PLLSTS register.

# 12.2.2.6 PLL\_PLLSTS\_MCLKSTS\_BITS

#### **Definition:**

#define PLL\_PLLSTS\_MCLKSTS\_BITS

## **Description:**

Defines the location of the MCLKSTS bits in the PLLSTS register.

# 12.2.2.7 PLL\_PLLSTS\_NORMRDYE\_BITS

#### **Definition:**

#define PLL\_PLLSTS\_NORMRDYE\_BITS

## **Description:**

Defines the location of the NORMRDYE bits in the PLLSTS register.

# 12.2.2.8 PLL\_PLLSTS\_OSCOFF\_BITS

#### **Definition:**

#define PLL\_PLLSTS\_OSCOFF\_BITS

### **Description:**

Defines the location of the OSCOFF bits in the PLLSTS register.

## 12.2.2.9 PLL PLLSTS PLLLOCKS BITS

#### **Definition:**

#define PLL\_PLLSTS\_PLLLOCKS\_BITS

## **Description:**

Defines the location of the PLLLOCKS bits in the PLLSTS register.

## 12.2.2.10 PLL\_PLLSTS\_PLLOFF\_BITS

#### **Definition:**

#define PLL\_PLLSTS\_PLLOFF\_BITS

## **Description:**

Defines the location of the PLLOFF bits in the PLLSTS register.

# 12.2.3 Typedef Documentation

## 12.2.3.1 PLL Handle

#### **Definition:**

typedef struct PLL\_Obj \*PLL\_Handle

## **Description:**

Defines the phase lock loop (PLL) handle.

## 12.2.3.2 PLL\_Obj

#### **Definition:**

```
typedef struct _PLL_Obj PLL_Obj
```

## **Description:**

Defines the phase lock loop (PLL) object.

## 12.2.4 Enumeration Documentation

## 12.2.4.1 PLL\_ClkStatus\_e

## **Description:**

Enumeration to define the phase lock loop (PLL) clock status.

#### **Enumerators:**

PLL\_ClkStatus\_NormalDenotes a normal clock.PLL\_ClkStatus\_MissingDenotes a missing clock.

# 12.2.4.2 PLL\_DivideSelect\_e

#### **Description:**

Enumeration to define the phase lock loop (PLL) divide select.

#### **Enumerators:**

```
    PLL_DivideSelect_ClkIn_by_4
    Denotes a divide select of CLKIN/4.
    PLL_DivideSelect_ClkIn_by_2
    Denotes a divide select of CLKIN/2.
    PLL_DivideSelect_ClkIn_by_1
    Denotes a divide select of CLKIN/1.
```

## 12.2.4.3 PLL LockStatus e

## **Description:**

Enumeration to define the phase lock loop (PLL) clock lock status.

## **Enumerators:**

**PLL\_LockStatus\_Locking** Denotes that the system is locking to the clock. **PLL\_LockStatus\_Done** Denotes that the system is locked to the clock.

## 12.2.4.4 PLL Multiplier e

## Description:

Enumeration to define the phase lock loop (PLL) clock frequency.

#### **Enumerators:**

```
PLL_Multiplier_1 Denotes a multiplier of 1.
PLL_Multiplier_2 Denotes a multiplier of 2.
PLL_Multiplier_3 Denotes a multiplier of 3.
PLL_Multiplier_4 Denotes a multiplier of 4.
PLL_Multiplier_5 Denotes a multiplier of 5.
PLL_Multiplier_6 Denotes a multiplier of 6.
PLL_Multiplier_7 Denotes a multiplier of 7.
PLL_Multiplier_8 Denotes a multiplier of 8.
PLL_Multiplier_9 Denotes a multiplier of 9.
PLL_Multiplier_10 Denotes a multiplier of 10.
PLL_Multiplier_11 Denotes a multiplier of 11.
```

PLL Multiplier 12 Denotes a multiplier of 12.

## 12.2.5 Function Documentation

## 12.2.5.1 PLL disable

Disables the phase lock loop (PLL).

#### Prototype:

```
void
PLL_disable(PLL_Handle pllHandle)
```

## Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

## 12.2.5.2 void PLL\_disableClkDetect (PLL\_Handle pllHandle)

Disables the clock detect logic.

#### Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

## 12.2.5.3 void PLL disableNormRdy (PLL Handle pllHandle)

Disables the NORMRDY signal.

#### Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

## 12.2.5.4 void PLL disableOsc (PLL Handle pllHandle)

Disables the oscillator.

#### Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

## 12.2.5.5 void PLL enable (PLL Handle pllHandle)

Enables the phase lock loop (PLL).

#### Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

## 12.2.5.6 void PLL enableClkDetect (PLL Handle pllHandle)

Enables the clock detect logic.

#### Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

## 12.2.5.7 void PLL enableNormRdy (PLL Handle pllHandle)

Enables the NORMRDY signal.

#### Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

## 12.2.5.8 void PLL\_enableOsc (PLL\_Handle pllHandle)

Enables the oscillator.

#### Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

## 12.2.5.9 PLL ClkStatus e PLL getClkStatus (PLL Handle pllHandle)

Gets the phase lock loop (PLL) clock status.

#### Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

## Returns:

The clock status

## 12.2.5.10 PLL DivideSelect e PLL getDivider (PLL Handle pllHandle)

Gets the phase lock loop (PLL) divide select value.

### Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

#### Returns:

The divide select value

## 12.2.5.11 PLL LockStatus e PLL getLockStatus (PLL Handle pllHandle)

Gets the phase lock loop (PLL) lock status.

#### Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

#### Returns:

The lock status

## 12.2.5.12 PLL Multiplier e PLL getMultiplier (PLL Handle pllHandle)

Gets the phase lock loop (PLL) clock frequency.

#### Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

#### Returns:

The clock frequency

## 12.2.5.13 PLL Handle PLL init (void \* pMemory, const size t numBytes)

Initializes the phase lock loop (PLL) object handle.

#### Parameters:

- ← *pMemory* A pointer to the base address of the PLL registers
- ← *numBytes* The number of bytes allocated for the PLL object, bytes

## Returns:

The phase lock loop (PLL) object handle

## 12.2.5.14 void PLL\_resetClkDetect (PLL\_Handle)

Resets the phase lock loop (PLL) clock detect logic.

#### Parameters:

← *pllHandle* The phase lock loop (PLL) object handle

# 12.2.5.15 void PLL\_setDivider (PLL\_Handle pllHandle, const PLL\_DivideSelect\_e divSelect)

Sets the phase lock loop (PLL) divide select value.

#### Parameters:

- ← *pllHandle* The phase lock loop (PLL) object handle
- ← *divSelect* The divide select value

## 12.2.5.16 void PLL\_setLockPeriod (PLL\_Handle pllHandle, const uint16\_t lockPeriod)

Sets the phase lock loop (PLL) lock time.

#### Parameters:

- ← *pllHandle* The phase lock loop (PLL) object handle
- ← *lockPeriod* The lock period, cycles

## 12.2.5.17 void PLL\_setMultiplier (PLL\_Handle pllHandle, const PLL\_Multiplier\_e freq)

Sets the phase lock loop (PLL) clock frequency.

#### Parameters:

- ← *pllHandle* The phase lock loop (PLL) object handle
- ← *freq* The clock frequency

# 12.2.5.18 void PLL\_setup (PLL\_Handle *pllHandle*, const PLL\_Multiplier\_e *clkMult*, const PLL\_DivideSelect\_e *divSelect*)

Sets the phase lock loop (PLL) divider and multiplier.

- ← *pllHandle* The phase lock loop (PLL) object handle
- ← *clkMult* The clock multiplier value
- ← *divSelect* The divide select value

176

# 13 Pulse Width Modulator (PWM)

Introduction	177
API Functions	177

# 13.1 Introduction

The pulse width modulation peripheral (PWM) APIs provide functions for configuring and updating the PWM peripherals on this device.

This driver is contained in f2802x0\_common/source/pwm.c, with f2802x0\_common/include/pwm.h containing the API definitions for use by applications.

# 13.2 **PWM**

## **Data Structures**

PWM Obj

## **Defines**

- PWM AQCTL CAD BITS
- PWM AQCTL CAU BITS
- PWM AQCTL CBD BITS
- PWM AQCTL CBU BITS
- PWM AQCTL PRD BITS
- PWM\_AQCTL\_ZRO\_BITS
- PWM\_CMPCTL\_LOADAMODE\_BITS
- PWM CMPCTL LOADBMODE BITS
- PWM\_CMPCTL\_SHDWAFULL\_BITS
- PWM CMPCTL SHDWAMODE BITS
- PWM\_CMPCTL\_SHDWBFULL\_BITS
- PWM CMPCTL SHDWBMODE BITS
- PWM\_DBCTL\_HALFCYCLE\_BITS
- PWM\_DBCTL\_INMODE\_BITS
- PWM DBCTL OUTMODE BITS
- PWM\_DBCTL\_POLSEL\_BITS
- PWM DCFCTL BLANKE BITS
- PWM\_DCFCTL\_BLANKINV\_BITS
- PWM DCFCTL PULSESEL BITS
- PWM\_DCFCTL\_SRCSEL\_BITS
- PWM\_DCTRIPSEL\_DCAHCOMPSEL\_BITS

- PWM DCTRIPSEL DCALCOMPSEL BITS
- PWM DCTRIPSEL DCBHCOMPSEL BITS
- PWM\_DCTRIPSEL\_DCBLCOMPSEL\_BITS
- PWM ePWM1 BASE ADDR
- PWM ePWM2 BASE ADDR
- PWM\_ePWM3\_BASE\_ADDR
- PWM ePWM4 BASE ADDR
- PWM\_ETCLR\_INT\_BITS
- PWM ETCLR SOCA BITS
- PWM ETCLR SOCB BITS
- PWM\_ETPS\_INTCNT\_BITS
- PWM ETPS INTPRD BITS
- PWM\_ETPS\_SOCACNT\_BITS
- PWM\_ETPS\_SOCAPRD\_BITS
- PWM ETPS SOCBCNT BITS
- PWM ETPS SOCBPRD BITS
- PWM\_ETSEL\_INTEN\_BITS
- PWM ETSEL INTSEL BITS
- PWM\_ETSEL\_SOCAEN\_BITS
- PWM ETSEL SOCASEL BITS
- PWM ETSEL SOCBEN BITS
- PWM\_ETSEL\_SOCBSEL\_BITS
- PWM HRCNFG AUTOCONV BITS
- PWM HRCNFG CTLMODE BITS
- PWM HRCNFG EDGMODE BITS
- PWM\_HRCNFG\_HRLOAD\_BITS
- PWM\_HRCNFG\_SELOUTB\_BITS
- PWM HRCNFG SWAPAB BITS
- PWM HRPCTL HRPE BITS
- PWM HRPCTL PWMSYNCSEL BITS
- PWM\_HRPCTL\_TBPHSHRLOADE\_BITS
- PWM PCCTL CHPDUTY BITS
- PWM\_PCCTL\_CHPEN\_BITS
- PWM PCCTL CHPFREQ BITS
- PWM\_PCCTL\_OSHTWTH\_BITS
- PWM TBCTL CLKDIV BITS
- PWM TBCTL CTRMODE BITS
- PWM TBCTL FREESOFT BITS
- PWM TBCTL HSPCLKDIV BITS
- PWM\_TBCTL\_PHSDIR\_BITS
- PWM\_TBCTL\_PHSEN\_BITS
- PWM TBCTL PRDLD BITS
- PWM\_TBCTL\_SWFSYNC\_BITS
- PWM\_TBCTL\_SYNCOSEL\_BITS
- PWM\_TZCLR\_CBC\_BITS
- PWM\_TZCLR\_DCAEVT1\_BITS

- PWM TZCLR DCAEVT2 BITS
- PWM TZCLR DCBEVT1 BITS
- PWM TZCLR DCBEVT2 BITS
- PWM TZCLR INT BITS
- PWM TZCLR OST BITS
- PWM TZCTL DCAEVT1 BITS
- PWM TZCTL DCAEVT2 BITS
- PWM\_TZCTL\_DCBEVT1\_BITS
- PWM TZCTL DCBEVT2 BITS
- PWM TZCTL TZA BITS
- PWM TZCTL TZB BITS
- PWM TZDCSEL DCAEVT1 BITS
- PWM TZDCSEL DCAEVT2 BITS
- PWM TZDCSEL DCBEVT1 BITS
- PWM TZDCSEL DCBEVT2 BITS
- PWM TZFRC CBC BITS
- PWM\_TZFRC\_DCAEVT1\_BITS
- PWM\_TZFRC\_DCAEVT2\_BITS
- PWM TZFRC DCBEVT1 BITS
- PWM TZFRC DCBEVT2 BITS
- PWM\_TZFRC\_OST\_BITS

## **Enumerations**

- PWM ActionQual e
- PWM TripZoneFlag e
- PWM TripZoneSrc e

## **Functions**

- void PWM\_clearIntFlag (PWM\_Handle pwmHandle)
- void PWM\_clearOneShotTrip (PWM\_Handle pwmHandle)
- void PWM clearSocAFlag (PWM Handle pwmHandle)
- void PWM\_clearSocBFlag (PWM\_Handle pwmHandle)
- void PWM\_clearTripZone (PWM\_Handle pwmHandle, const PWM\_TripZoneFlag\_e tripZone-Flag)
- void PWM decrementDeadBandFallingEdgeDelay (PWM Handle pwmHandle)
- void PWM decrementDeadBandRisingEdgeDelay (PWM Handle pwmHandle)
- void PWM disableAutoConvert (PWM Handle pwmHandle)
- void PWM\_disableChopping (PWM\_Handle pwmHandle)
- void PWM disableCounterLoad (PWM Handle pwmHandle)
- void PWM disableDeadBand (PWM Handle pwmHandle)
- void PWM\_disableDeadBandHalfCycle (PWM\_Handle pwmHandle)
- void PWM disableDigitalCompareBlankingWindow (PWM Handle pwmHandle)
- void PWM\_disableDigitalCompareBlankingWindowInversion (PWM\_Handle pwmHandle)

- void PWM disableHrPeriod (PWM Handle pwmHandle)
- void PWM\_disableHrPhaseSync (PWM\_Handle pwmHandle)
- void PWM\_disableInt (PWM\_Handle pwmHandle)
- void PWM\_disableSocAPulse (PWM\_Handle pwmHandle)
- void PWM\_disableSocBPulse (PWM\_Handle pwmHandle)
- void PWM\_disableTripZoneInt (PWM\_Handle pwmHandle, const PWM\_TripZoneFlag\_e interruptSource)
- void PWM\_disableTripZones (PWM\_Handle pwmHandle)
- void PWM\_disableTripZoneSrc (PWM\_Handle pwmHandle, const PWM\_TripZoneSrc\_e src)
- void PWM\_enableAutoConvert (PWM\_Handle pwmHandle)
- void PWM enableChopping (PWM Handle pwmHandle)
- void PWM\_enableCounterLoad (PWM\_Handle pwmHandle)
- void PWM\_enableDeadBandHalfCycle (PWM\_Handle pwmHandle)
- void PWM\_enableDigitalCompareBlankingWindow (PWM\_Handle pwmHandle)
- void PWM enableDigitalCompareBlankingWindowInversion (PWM Handle pwmHandle)
- void PWM enableHrPeriod (PWM Handle pwmHandle)
- void PWM\_enableHrPhaseSync (PWM\_Handle pwmHandle)
- void PWM\_enableInt (PWM\_Handle pwmHandle)
- void PWM enableSocAPulse (PWM Handle pwmHandle)
- void PWM\_enableSocBPulse (PWM\_Handle pwmHandle)
- void PWM\_enableTripZoneInt (PWM\_Handle pwmHandle, const PWM\_TripZoneFlag\_e interruptSource)
- void PWM\_enableTripZoneSrc (PWM\_Handle pwmHandle, const PWM\_TripZoneSrc\_e src)
- void PWM\_forceSync (PWM\_Handle pwmHandle)
- uint16 t PWM getCmpA (PWM Handle pwmHandle)
- uint16 t PWM getCmpAHr (PWM Handle pwmHandle)
- uint16 t PWM getCmpB (PWM Handle pwmHandle)
- uint16 t PWM getDeadBandFallingEdgeDelay (PWM Handle pwmHandle)
- uint16 t PWM getDeadBandRisingEdgeDelay (PWM Handle pwmHandle)
- uint16\_t PWM\_getIntCount (PWM\_Handle pwmHandle)
- uint16\_t PWM\_getPeriod (PWM\_Handle pwmHandle)
- uint16\_t PWM\_getSocACount (PWM\_Handle pwmHandle)
- uint16\_t PWM\_getSocBCount (PWM\_Handle pwmHandle)
- void PWM\_incrementDeadBandFallingEdgeDelay (PWM\_Handle pwmHandle)
- void PWM incrementDeadBandRisingEdgeDelay (PWM Handle pwmHandle)
- PWM\_Handle PWM\_init (void \*pMemory, const size\_t numBytes)
- void PWM\_setActionQual\_CntDown\_CmpA\_PwmA (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)
- void PWM\_setActionQual\_CntDown\_CmpA\_PwmB (PWM\_Handle pwmHandle, const PWM\_ActionQual\_e actionQual)
- void PWM\_setActionQual\_CntDown\_CmpB\_PwmA (PWM\_Handle pwmHandle, const PWM\_ActionQual\_e actionQual)
- void PWM\_setActionQual\_CntDown\_CmpB\_PwmB (PWM\_Handle pwmHandle, const PWM\_ActionQual\_e actionQual)
- void PWM\_setActionQual\_CntUp\_CmpA\_PwmA (PWM\_Handle pwmHandle, const PWM\_ActionQual\_e actionQual)

- void PWM\_setActionQual\_CntUp\_CmpA\_PwmB (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)
- void PWM\_setActionQual\_CntUp\_CmpB\_PwmA (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)
- void PWM\_setActionQual\_CntUp\_CmpB\_PwmB (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)
- void PWM\_setActionQual\_Period\_PwmA (PWM\_Handle pwmHandle, const PWM\_ActionQual\_e actionQual)
- void PWM\_setActionQual\_Period\_PwmB (PWM\_Handle pwmHandle, const PWM\_ActionQual\_e actionQual)
- void PWM\_setActionQual\_Zero\_PwmA (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)
- void PWM\_setActionQual\_Zero\_PwmB (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)
- void PWM\_setChoppingClkFreq (PWM\_Handle pwmHandle, const PWM ChoppingClkFreq e clkFreq)
- void PWM\_setChoppingDutyCycle (PWM\_Handle pwmHandle, const PWM ChoppingDutyCycle e dutyCycle)
- void PWM\_setChoppingPulseWidth (PWM\_Handle pwmHandle, const PWM\_ChoppingPulseWidth\_e pulseWidth)
- void PWM\_setClkDiv (PWM\_Handle pwmHandle, const PWM\_ClkDiv\_e clkDiv)
- void PWM\_setCmpA (PWM\_Handle pwmHandle, const uint16\_t pwmData)
- void PWM\_setCmpAHr (PWM\_Handle pwmHandle, const uint16\_t pwmData)
- void PWM\_setCmpB (PWM\_Handle pwmHandle, const uint16\_t pwmData)
- void PWM setCount (PWM Handle pwmHandle, const uint16 t count)
- void PWM\_setCounterMode (PWM\_Handle pwmHandle, const PWM\_CounterMode\_e counterMode)
- void PWM setDeadBandFallingEdgeDelay (PWM Handle pwmHandle, const uint16 t delay)
- void PWM\_setDeadBandInputMode (PWM\_Handle pwmHandle, const PWM DeadBandInputMode e inputMode)
- void PWM\_setDeadBandOutputMode (PWM\_Handle pwmHandle, const PWM\_DeadBandOutputMode\_e outputMode)
- void PWM\_setDeadBandPolarity (PWM\_Handle pwmHandle, const PWM\_DeadBandPolarity\_e polarity)
- void PWM setDeadBandRisingEdgeDelay (PWM Handle pwmHandle, const uint16 t delay)
- void PWM\_setDigitalCompareAEvent1 (PWM\_Handle pwmHandle, const bool\_t selectFilter, const bool\_t disableSync, const bool\_t enableSoc, const bool\_t generateSync)
- void PWM\_setDigitalCompareAEvent2 (PWM\_Handle pwmHandle, const bool\_t selectFilter, const bool\_t disableSync)
- void PWM\_setDigitalCompareBEvent1 (PWM\_Handle pwmHandle, const bool\_t selectFilter, const bool\_t disableSync, const bool\_t enableSoc, const bool\_t generateSync)
- void PWM\_setDigitalCompareBEvent2 (PWM\_Handle pwmHandle, const bool\_t selectFilter, const bool\_t disableSync)
- void PWM\_setDigitalCompareBlankingPulse (PWM\_Handle pwmHandle, const PWM DigitalCompare PulseSel e pulseSelect)
- void PWM setDigitalCompareFilterOffset (PWM Handle pwmHandle, const uint16 t offset)
- void PWM\_setDigitalCompareFilterSource (PWM\_Handle pwmHandle, const PWM DigitalCompare FilterSrc e input)

- void PWM\_setDigitalCompareFilterWindow (PWM\_Handle pwmHandle, const uint16\_t window)
- void PWM\_setDigitalCompareInput (PWM\_Handle pwmHandle, const PWM\_DigitalCompare\_Input\_e input, const PWM\_DigitalCompare\_InputSel\_e inputSel)
- void PWM\_setHighSpeedClkDiv (PWM\_Handle pwmHandle, const PWM\_HspClkDiv\_e clk-Div)
- void PWM\_setHrControlMode (PWM\_Handle pwmHandle, const PWM\_HrControlMode\_e controlMode)
- void PWM\_setHrEdgeMode (PWM\_Handle pwmHandle, const PWM\_HrEdgeMode\_e edge-Mode)
- void PWM\_setHrShadowMode (PWM\_Handle pwmHandle, const PWM\_HrShadowMode\_e shadowMode)
- void PWM\_setIntMode (PWM\_Handle pwmHandle, const PWM\_IntMode\_e intMode)
- void PWM\_setIntPeriod (PWM\_Handle pwmHandle, const PWM\_IntPeriod\_e intPeriod)
- void PWM\_setLoadMode\_CmpA (PWM\_Handle pwmHandle, const PWM\_LoadMode\_e load-Mode)
- void PWM\_setLoadMode\_CmpB (PWM\_Handle pwmHandle, const PWM\_LoadMode\_e load-Mode)
- void PWM\_setOneShotTrip (PWM\_Handle pwmHandle)
- void PWM setPeriod (PWM Handle pwmHandle, const uint16 t period)
- void PWM setPeriodHr (PWM Handle pwmHandle, const uint16 t period)
- void PWM\_setPeriodLoad (PWM\_Handle pwmHandle, const PWM\_PeriodLoad\_e period-Load)
- void PWM\_setPhase (PWM\_Handle pwmHandle, const uint16\_t phase)
- void PWM setPhaseDir (PWM Handle pwmHandle, const PWM PhaseDir e phaseDir)
- void PWM setRunMode (PWM Handle pwmHandle, const PWM RunMode e runMode)
- void PWM\_setShadowMode\_CmpA (PWM\_Handle pwmHandle, const PWM ShadowMode e shadowMode)
- void PWM\_setShadowMode\_CmpB (PWM\_Handle pwmHandle, const PWM ShadowMode e shadowMode)
- void PWM setSocAPeriod (PWM Handle pwmHandle, const PWM SocPeriod e intPeriod)
- void PWM\_setSocAPulseSrc (PWM\_Handle pwmHandle, const PWM\_SocPulseSrc\_e pulseSrc)
- void PWM setSocBPeriod (PWM Handle pwmHandle, const PWM SocPeriod e intPeriod)
- void PWM\_setSocBPulseSrc (PWM\_Handle pwmHandle, const PWM\_SocPulseSrc\_e pulseSrc)
- void PWM\_setSwSync (PWM\_Handle pwmHandle)
- void PWM\_setSyncMode (PWM\_Handle pwmHandle, const PWM\_SyncMode\_e syncMode)
- void PWM\_setTripZoneDCEventSelect\_DCAEVT1 (PWM\_Handle pwmHandle, const PWM TripZoneDCEventSel e tripZoneEvent)
- void PWM\_setTripZoneDCEventSelect\_DCAEVT2 (PWM\_Handle pwmHandle, const PWM\_TripZoneDCEventSel\_e tripZoneEvent)
- void PWM\_setTripZoneDCEventSelect\_DCBEVT1 (PWM\_Handle pwmHandle, const PWM TripZoneDCEventSel e tripZoneEvent)
- void PWM\_setTripZoneDCEventSelect\_DCBEVT2 (PWM\_Handle pwmHandle, const PWM\_TripZoneDCEventSel\_e tripZoneEvent)
- void PWM\_setTripZoneState\_DCAEVT1 (PWM\_Handle pwmHandle, const PWM TripZoneState e tripZoneState)

- void PWM\_setTripZoneState\_DCAEVT2 (PWM\_Handle pwmHandle, const PWM\_TripZoneState\_e tripZoneState)
- void PWM\_setTripZoneState\_DCBEVT1 (PWM\_Handle pwmHandle, const PWM\_TripZoneState\_e tripZoneState)
- void PWM\_setTripZoneState\_DCBEVT2 (PWM\_Handle pwmHandle, const PWM\_TripZoneState\_e tripZoneState)
- void PWM\_setTripZoneState\_TZA (PWM\_Handle pwmHandle, const PWM\_TripZoneState\_e tripZoneState)
- void PWM\_setTripZoneState\_TZB (PWM\_Handle pwmHandle, const PWM\_TripZoneState\_e tripZoneState)
- void PWM\_write\_CmpA (PWM\_Handle pwmHandle, const int16\_t pwmData)
- void PWM write CmpB (PWM Handle pwmHandle, const int16 t pwmData)

# 13.2.1 Data Structure Documentation

# 13.2.1.1 PWM Obj

#### **Definition:**

```
typedef struct
    uint16_t TBCTL;
    uint16_t TBSTS;
    uint16_t TBPHSHR;
    uint16_t TBPHS;
    uint16_t TBCTR;
    uint16_t TBPRD;
    uint16_t TBPRDHR;
    uint16 t CMPCTL;
    uint16_t CMPAHR;
    uint16_t CMPA;
    uint16_t CMPB;
    uint16_t AQCTLA;
    uint16_t AQCTLB;
    uint16 t AQSFRC;
    uint16_t AQCSFRC;
    uint16_t DBCTL;
    uint16_t DBRED;
    uint16_t DBFED;
    uint16_t TZSEL;
    uint16_t TZDCSEL;
    uint16_t TZCTL;
    uint16_t TZEINT;
    uint16_t TZFLG;
    uint16_t TZCLR;
    uint16_t TZFRC;
    uint16 t ETSEL;
    uint16_t ETPS;
    uint16_t ETFLG;
    uint16_t ETCLR;
    uint16_t ETFRC;
```

```
uint16_t PCCTL;
        uint16_t rsvd_1;
        uint16_t HRCNFG;
        uint16_t HRPWR;
        uint16 t rsvd 2[4];
        uint16_t HRMSTEP;
        uint16_t rsvd_3;
        uint16_t HRPCTL;
        uint16 t rsvd 4;
        uint16_t TBPRDHRM;
        uint16_t TBPRDM;
        uint16_t CMPAHRM;
        uint16_t CMPAM;
        uint16_t rsvd_5[2];
        uint16_t DCTRIPSEL;
        uint16_t DCACTL;
        uint16_t DCBCTL;
        uint16_t DCFCTL;
        uint16_t DCCAPCTL;
        uint16_t DCFOFFSET;
        uint16_t DCFOFFSETCNT;
        uint16 t DCFWINDOW;
        uint16_t DCFWINDOWCNT;
        uint16 t DCCAP;
   _PWM_Obj_
Members:
    TBCTL Time-Base Control Register.
    TBSTS Time-Base Status Register.
    TBPHSHR Extension for the HRPWM Phase Register.
    TBPHS Time-Base Phase Register.
    TBCTR Time-Base Counter.
    TBPRD Time-Base Period register set.
    TBPRDHR Time-Base Period High Resolution Register.
    CMPCTL Counter-Compare Control Register.
    CMPAHR Extension of HRPWM Counter-Compare A Register.
    CMPA Counter-Compare A Register.
    CMPB Counter-Compare B Register.
    AQCTLA Action-Qualifier Control Register for Output A (EPWMxA).
    AQCTLB Action-Qualifier Control Register for Output B (EPWMxB).
    AQSFRC Action qual SW force.
    AQCSFRC Action qualifier continuous SW force.
    DBCTL Dead-band control.
    DBRED Dead-band rising edge delay.
    DBFED Dead-band falling edge delay.
    TZSEL Trip zone select.
    TZDCSEL Trip zone digital comparator select.
```

**TZCTL** Trip zone control.

**TZEINT** Trip zone interrupt enable.

**TZFLG** Trip zone interrupt flags.

TZCLR Trip zone clear.

**TZFRC** Trip zone force interrupt.

ETSEL Event trigger selection.

ETPS Event trigger pre-scaler.

ETFLG Event trigger flags.

ETCLR Event trigger clear.

ETFRC Event trigger force.

PCCTL PWM chopper control.

rsvd\_1 Reserved.

HRCNFG HRPWM Config Reg.

HRPWR HRPWM Power Register.

rsvd\_2 Reserved.

HRMSTEP HRPWM MEP Step Register.

rsvd\_3 Reserved.

HRPCTL High Resolution Period Control.

rsvd\_4 Reserved.

**TBPRDHRM** Time base period High Resolution register mirror.

TBPRDM Time base period register mirror.

**CMPAHRM** Compare A High Resolution register mirror.

**CMPAM** Compare A register mirror.

rsvd\_5 Reserved.

**DCTRIPSEL** Digital Compare Trip Select.

**DCACTL** Digital Compare A Control.

**DCBCTL** Digital Compare B Control.

**DCFCTL** Digital Compare Filter Control.

**DCCAPCTL** Digital Compare Capture Control.

**DCFOFFSET** Digital Compare Filter Offset.

**DCFOFFSETCNT** Digital Compare Filter Offset Counter.

**DCFWINDOW** Digital Compare Filter Window.

**DCFWINDOWCNT** Digital Compare Filter Window Counter.

**DCCAP** Digital Compare Filter Counter Capture.

#### **Description:**

Defines the pulse width modulation (PWM) object.

# 13.2.2 Define Documentation

## 13.2.2.1 PWM AQCTL CAD BITS

## **Definition:**

#define PWM\_AQCTL\_CAD\_BITS

## **Description:**

Defines the location of the CAD bits in the AQCTL register.

# 13.2.2.2 PWM AQCTL CAU BITS

## **Definition:**

#define PWM\_AQCTL\_CAU\_BITS

#### **Description:**

Defines the location of the CAU bits in the AQCTL register.

# 13.2.2.3 PWM AQCTL CBD BITS

#### **Definition:**

#define PWM\_AQCTL\_CBD\_BITS

## **Description:**

Defines the location of the CBD bits in the AQCTL register.

# 13.2.2.4 PWM\_AQCTL\_CBU\_BITS

#### **Definition:**

#define PWM\_AQCTL\_CBU\_BITS

#### **Description:**

Defines the location of the CBU bits in the AQCTL register.

# 13.2.2.5 PWM\_AQCTL\_PRD\_BITS

## **Definition:**

#define PWM\_AQCTL\_PRD\_BITS

## **Description:**

Defines the location of the PRD bits in the AQCTL register.

# 13.2.2.6 PWM AQCTL ZRO BITS

## **Definition:**

#define PWM\_AQCTL\_ZRO\_BITS

## **Description:**

Defines the location of the ZRO bits in the AQCTL register.

# 13.2.2.7 PWM CMPCTL LOADAMODE BITS

## **Definition:**

#define PWM\_CMPCTL\_LOADAMODE\_BITS

## **Description:**

Defines the location of the LOADAMODE bits in the CMPCTL register.

# 13.2.2.8 PWM CMPCTL LOADBMODE BITS

#### **Definition:**

#define PWM\_CMPCTL\_LOADBMODE\_BITS

## **Description:**

Defines the location of the LOADBMODE bits in the CMPCTL register.

# 13.2.2.9 PWM CMPCTL SHDWAFULL BITS

#### **Definition:**

#define PWM\_CMPCTL\_SHDWAFULL\_BITS

## **Description:**

Defines the location of the SHDWAFULL bits in the CMPCTL register.

# 13.2.2.10 PWM CMPCTL SHDWAMODE BITS

#### **Definition:**

#define PWM\_CMPCTL\_SHDWAMODE\_BITS

## **Description:**

Defines the location of the SHDWAMODE bits in the CMPCTL register.

# 13.2.2.11 PWM\_CMPCTL\_SHDWBFULL\_BITS

## **Definition:**

#define PWM\_CMPCTL\_SHDWBFULL\_BITS

## **Description:**

Defines the location of the SHDWBFULL bits in the CMPCTL register.

# 13.2.2.12 PWM CMPCTL SHDWBMODE BITS

## **Definition:**

#define PWM\_CMPCTL\_SHDWBMODE\_BITS

## **Description:**

Defines the location of the SHDWBMODE bits in the CMPCTL register.

# 13.2.2.13 PWM DBCTL HALFCYCLE BITS

## **Definition:**

#define PWM\_DBCTL\_HALFCYCLE\_BITS

## **Description:**

Defines the location of the HALFCYCLE bits in the DBCTL register.

# 13.2.2.14 PWM DBCTL INMODE BITS

#### **Definition:**

#define PWM\_DBCTL\_INMODE\_BITS

#### **Description:**

Defines the location of the INMODE bits in the DBCTL register.

# 13.2.2.15 PWM DBCTL OUTMODE BITS

#### **Definition:**

#define PWM\_DBCTL\_OUTMODE\_BITS

## **Description:**

Defines the location of the OUTMODE bits in the DBCTL register.

# 13.2.2.16 PWM DBCTL POLSEL BITS

#### **Definition:**

#define PWM\_DBCTL\_POLSEL\_BITS

## **Description:**

Defines the location of the POLSEL bits in the DBCTL register.

# 13.2.2.17 PWM DCFCTL BLANKE BITS

## **Definition:**

#define PWM\_DCFCTL\_BLANKE\_BITS

## **Description:**

Defines the location of the BLANKE bits in the DCFCTL register.

# 13.2.2.18 PWM DCFCTL BLANKINV BITS

## **Definition:**

#define PWM\_DCFCTL\_BLANKINV\_BITS

## **Description:**

Defines the location of the BLANKINV bits in the DCFCTL register.

# 13.2.2.19 PWM DCFCTL PULSESEL BITS

#### **Definition:**

#define PWM\_DCFCTL\_PULSESEL\_BITS

# **Description:**

Defines the location of the PULSESEL bits in the DCFCTL register.

# 13.2.2.20 PWM DCFCTL SRCSEL BITS

#### **Definition:**

#define PWM\_DCFCTL\_SRCSEL\_BITS

#### **Description:**

Defines the location of the SRCSEL bits in the DCFCTL register.

# 13.2.2.21 PWM DCTRIPSEL DCAHCOMPSEL BITS

#### **Definition:**

#define PWM\_DCTRIPSEL\_DCAHCOMPSEL\_BITS

## **Description:**

Defines the location of the DCAHCOMPSEL bits in the DCTRIPSEL register.

# 13.2.2.22 PWM DCTRIPSEL DCALCOMPSEL BITS

#### **Definition:**

#define PWM\_DCTRIPSEL\_DCALCOMPSEL\_BITS

## **Description:**

Defines the location of the DCALCOMPSEL bits in the DCTRIPSEL register.

# 13.2.2.23 PWM DCTRIPSEL DCBHCOMPSEL BITS

## **Definition:**

#define PWM\_DCTRIPSEL\_DCBHCOMPSEL\_BITS

## **Description:**

Defines the location of the DCBHCOMPSEL bits in the DCTRIPSEL register.

# 13.2.2.24 PWM DCTRIPSEL DCBLCOMPSEL BITS

## **Definition:**

#define PWM\_DCTRIPSEL\_DCBLCOMPSEL\_BITS

## **Description:**

Defines the location of the DCBLCOMPSEL bits in the DCTRIPSEL register.

# 13.2.2.25 PWM ePWM1 BASE ADDR

#### **Definition:**

#define PWM\_ePWM1\_BASE\_ADDR

## **Description:**

Defines the base address of the pulse width modulation (PWM) 1 registers.

Tue Jul 24 10:01:42 CDT 2012

# 13.2.2.26 PWM ePWM2 BASE ADDR

## **Definition:**

#define PWM\_ePWM2\_BASE\_ADDR

#### **Description:**

Defines the base address of the pulse width modulation (PWM) 2 registers.

# 13.2.2.27 PWM ePWM3 BASE ADDR

#### **Definition:**

#define PWM\_ePWM3\_BASE\_ADDR

## **Description:**

Defines the base address of the pulse width modulation (PWM) 3 registers.

# 13.2.2.28 PWM ePWM4 BASE ADDR

#### **Definition:**

#define PWM\_ePWM4\_BASE\_ADDR

## **Description:**

Defines the base address of the pulse width modulation (PWM) 4 registers.

# 13.2.2.29 PWM\_ETCLR\_INT\_BITS

## **Definition:**

#define PWM\_ETCLR\_INT\_BITS

## **Description:**

Defines the location of the ETCR bits in the ETCLR register.

# 13.2.2.30 PWM\_ETCLR\_SOCA\_BITS

## **Definition:**

#define PWM\_ETCLR\_SOCA\_BITS

## **Description:**

Defines the location of the SOCA bits in the ETCLR register.

# 13.2.2.31 PWM ETCLR SOCB BITS

#### **Definition:**

#define PWM\_ETCLR\_SOCB\_BITS

# **Description:**

Defines the location of the SOCB bits in the ETCLR register.

# 13.2.2.32 PWM\_ETPS\_INTCNT\_BITS

## **Definition:**

#define PWM\_ETPS\_INTCNT\_BITS

## **Description:**

Defines the location of the INTCNT bits in the ETPS register.

# 13.2.2.33 PWM ETPS INTPRD BITS

#### **Definition:**

#define PWM\_ETPS\_INTPRD\_BITS

## **Description:**

Defines the location of the INTPRD bits in the ETPS register.

# 13.2.2.34 PWM ETPS SOCACNT BITS

#### **Definition:**

#define PWM\_ETPS\_SOCACNT\_BITS

#### **Description:**

Defines the location of the SOCACNT bits in the ETPS register.

# 13.2.2.35 PWM ETPS SOCAPRD BITS

## **Definition:**

#define PWM\_ETPS\_SOCAPRD\_BITS

## **Description:**

Defines the location of the SOCAPRD bits in the ETPS register.

# 13.2.2.36 PWM ETPS SOCBCNT BITS

# **Definition:**

#define PWM\_ETPS\_SOCBCNT\_BITS

## **Description:**

Defines the location of the SOCBCNT bits in the ETPS register.

# 13.2.2.37 PWM ETPS SOCBPRD BITS

## **Definition:**

#define PWM\_ETPS\_SOCBPRD\_BITS

## **Description:**

Defines the location of the SOCBPRD bits in the ETPS register.

# 13.2.2.38 PWM\_ETSEL\_INTEN\_BITS

#### **Definition:**

#define PWM\_ETSEL\_INTEN\_BITS

#### **Description:**

Defines the location of the INTEN bits in the ETSEL register.

# 13.2.2.39 PWM ETSEL INTSEL BITS

#### **Definition:**

#define PWM\_ETSEL\_INTSEL\_BITS

## **Description:**

Defines the location of the INTSEL bits in the ETSEL register.

# 13.2.2.40 PWM ETSEL SOCAEN BITS

#### **Definition:**

#define PWM\_ETSEL\_SOCAEN\_BITS

## **Description:**

Defines the location of the SOCAEN bits in the ETSEL register.

# 13.2.2.41 PWM\_ETSEL\_SOCASEL\_BITS

## **Definition:**

#define PWM\_ETSEL\_SOCASEL\_BITS

## **Description:**

Defines the location of the SOCASEL bits in the ETSEL register.

# 13.2.2.42 PWM ETSEL SOCBEN\_BITS

## **Definition:**

#define PWM\_ETSEL\_SOCBEN\_BITS

## **Description:**

Defines the location of the SOCBEN bits in the ETSEL register.

# 13.2.2.43 PWM ETSEL SOCBSEL BITS

#### **Definition:**

#define PWM\_ETSEL\_SOCBSEL\_BITS

## **Description:**

Defines the location of the SOCBSEL bits in the ETSEL register.

# 13.2.2.44 PWM HRCNFG AUTOCONV BITS

#### **Definition:**

#define PWM\_HRCNFG\_AUTOCONV\_BITS

#### **Description:**

Defines the location of the AUTOCONV bits in the HRCNFG register.

# 13.2.2.45 PWM HRCNFG CTLMODE BITS

#### **Definition:**

#define PWM\_HRCNFG\_CTLMODE\_BITS

## **Description:**

Defines the location of the CTLMODE bits in the HRCNFG register.

# 13.2.2.46 PWM\_HRCNFG\_EDGMODE\_BITS

#### **Definition:**

#define PWM\_HRCNFG\_EDGMODE\_BITS

#### **Description:**

Defines the location of the EDGMODE bits in the HRCNFG register.

# 13.2.2.47 PWM\_HRCNFG\_HRLOAD\_BITS

## **Definition:**

#define PWM\_HRCNFG\_HRLOAD\_BITS

## **Description:**

Defines the location of the HRLOAD bits in the HRCNFG register.

# 13.2.2.48 PWM\_HRCNFG\_SELOUTB\_BITS

## **Definition:**

#define PWM\_HRCNFG\_SELOUTB\_BITS

## **Description:**

Defines the location of the SELOUTB bits in the HRCNFG register.

# 13.2.2.49 PWM HRCNFG SWAPAB BITS

#### **Definition:**

#define PWM\_HRCNFG\_SWAPAB\_BITS

## **Description:**

Defines the location of the SWAPAB bits in the HRCNFG register.

Tue Jul 24 10:01:42 CDT 2012

# 13.2.2.50 PWM HRPCTL HRPE BITS

#### **Definition:**

#define PWM\_HRPCTL\_HRPE\_BITS

#### **Description:**

Defines the location of the HRPE bits in the HRPCTL register.

# 13.2.2.51 PWM HRPCTL PWMSYNCSEL BITS

#### **Definition:**

#define PWM\_HRPCTL\_PWMSYNCSEL\_BITS

## **Description:**

Defines the location of the PWMSYNCSEL bits in the HRPCTL register.

# 13.2.2.52 PWM HRPCTL TBPHSHRLOADE BITS

#### **Definition:**

#define PWM\_HRPCTL\_TBPHSHRLOADE\_BITS

## **Description:**

Defines the location of the TBPHSHRLOADE bits in the HRPCTL register.

# 13.2.2.53 PWM\_PCCTL\_CHPDUTY\_BITS

## **Definition:**

#define PWM\_PCCTL\_CHPDUTY\_BITS

## **Description:**

Defines the location of the CHPDUTY bits in the PCCTL register.

# 13.2.2.54 PWM PCCTL CHPEN BITS

# **Definition:**

#define PWM\_PCCTL\_CHPEN\_BITS

## **Description:**

Defines the location of the CHPEN bits in the PCCTL register.

# 13.2.2.55 PWM PCCTL CHPFREQ BITS

#### **Definition:**

#define PWM\_PCCTL\_CHPFREQ\_BITS

## **Description:**

Defines the location of the CHPFREQ bits in the PCCTL register.

# 13.2.2.56 PWM PCCTL OSHTWTH BITS

## **Definition:**

#define PWM\_PCCTL\_OSHTWTH\_BITS

## **Description:**

Defines the location of the OSHTWTH bits in the PCCTL register.

# 13.2.2.57 PWM TBCTL CLKDIV BITS

#### **Definition:**

#define PWM\_TBCTL\_CLKDIV\_BITS

## **Description:**

Defines the location of the CLKDIV bits in the TBCTL register.

# 13.2.2.58 PWM TBCTL CTRMODE BITS

#### **Definition:**

#define PWM\_TBCTL\_CTRMODE\_BITS

## **Description:**

Defines the location of the CTRMODE bits in the TBCTL register.

# 13.2.2.59 PWM TBCTL FREESOFT BITS

## **Definition:**

#define PWM\_TBCTL\_FREESOFT\_BITS

## **Description:**

Defines the location of the FREESOFT bits in the TBCTL register.

# 13.2.2.60 PWM TBCTL HSPCLKDIV BITS

## **Definition:**

#define PWM\_TBCTL\_HSPCLKDIV\_BITS

## **Description:**

Defines the location of the HSPCLKDIV bits in the TBCTL register.

# 13.2.2.61 PWM TBCTL PHSDIR BITS

## **Definition:**

#define PWM\_TBCTL\_PHSDIR\_BITS

## **Description:**

Defines the location of the PHSDIR bits in the TBCTL register.

Tue Jul 24 10:01:42 CDT 2012

# 13.2.2.62 PWM\_TBCTL\_PHSEN\_BITS

## **Definition:**

#define PWM\_TBCTL\_PHSEN\_BITS

#### **Description:**

Defines the location of the PHSEN bits in the TBCTL register.

# 13.2.2.63 PWM TBCTL PRDLD BITS

#### **Definition:**

#define PWM\_TBCTL\_PRDLD\_BITS

## **Description:**

Defines the location of the PRDLD bits in the TBCTL register.

# 13.2.2.64 PWM TBCTL SWFSYNC BITS

#### **Definition:**

#define PWM\_TBCTL\_SWFSYNC\_BITS

## **Description:**

Defines the location of the SWFSYNC bits in the TBCTL register.

# 13.2.2.65 PWM\_TBCTL\_SYNCOSEL\_BITS

## **Definition:**

#define PWM\_TBCTL\_SYNCOSEL\_BITS

## **Description:**

Defines the location of the SYNCOSEL bits in the TBCTL register.

# 13.2.2.66 PWM TZCLR CBC BITS

## **Definition:**

#define PWM\_TZCLR\_CBC\_BITS

## **Description:**

Defines the location of the CBC bits in the TXCLR register.

# 13.2.2.67 PWM TZCLR DCAEVT1 BITS

#### **Definition:**

#define PWM\_TZCLR\_DCAEVT1\_BITS

## **Description:**

Defines the location of the DCAEVT1 bits in the TXCLR register.

# 13.2.2.68 PWM\_TZCLR\_DCAEVT2\_BITS

## **Definition:**

#define PWM\_TZCLR\_DCAEVT2\_BITS

## **Description:**

Defines the location of the DCAEVT2 bits in the TXCLR register.

# 13.2.2.69 PWM TZCLR DCBEVT1 BITS

#### **Definition:**

#define PWM\_TZCLR\_DCBEVT1\_BITS

## **Description:**

Defines the location of the DCBEVT1 bits in the TXCLR register.

# 13.2.2.70 PWM TZCLR DCBEVT2 BITS

#### **Definition:**

#define PWM\_TZCLR\_DCBEVT2\_BITS

# **Description:**

Defines the location of the DCBEVT2 bits in the TXCLR register.

# 13.2.2.71 PWM\_TZCLR\_INT\_BITS

## **Definition:**

#define PWM\_TZCLR\_INT\_BITS

## **Description:**

Defines the location of the INT bits in the TXCLR register.

# 13.2.2.72 PWM TZCLR OST BITS

# **Definition:**

#define PWM\_TZCLR\_OST\_BITS

## **Description:**

Defines the location of the OST bits in the TXCLR register.

# 13.2.2.73 PWM TZCTL DCAEVT1 BITS

## **Definition:**

#define PWM\_TZCTL\_DCAEVT1\_BITS

## **Description:**

Defines the location of the DCAEVT1 bits in the TZCTL register.

# 13.2.2.74 PWM TZCTL DCAEVT2 BITS

## **Definition:**

#define PWM\_TZCTL\_DCAEVT2\_BITS

#### **Description:**

Defines the location of the DCAEVT2 bits in the TZCTL register.

# 13.2.2.75 PWM TZCTL DCBEVT1 BITS

#### **Definition:**

#define PWM\_TZCTL\_DCBEVT1\_BITS

## **Description:**

Defines the location of the DCBEVT1 bits in the TZCTL register.

# 13.2.2.76 PWM\_TZCTL\_DCBEVT2\_BITS

#### **Definition:**

#define PWM\_TZCTL\_DCBEVT2\_BITS

## **Description:**

Defines the location of the DCBEVT2 bits in the TZCTL register.

# 13.2.2.77 PWM\_TZCTL\_TZA\_BITS

## **Definition:**

#define PWM\_TZCTL\_TZA\_BITS

## **Description:**

Defines the location of the TZA bits in the TZCTL register.

# 13.2.2.78 PWM TZCTL TZB BITS

## **Definition:**

#define PWM\_TZCTL\_TZB\_BITS

## **Description:**

Defines the location of the TZB bits in the TZCTL register.

# 13.2.2.79 PWM TZDCSEL DCAEVT1 BITS

#### **Definition:**

#define PWM\_TZDCSEL\_DCAEVT1\_BITS

# **Description:**

Defines the location of the DCAEVT1 bits in the TZDCSEL register.

# 13.2.2.80 PWM\_TZDCSEL\_DCAEVT2 BITS

#### **Definition:**

#define PWM\_TZDCSEL\_DCAEVT2\_BITS

#### **Description:**

Defines the location of the DCAEVT2 bits in the TZDCSEL register.

# 13.2.2.81 PWM TZDCSEL DCBEVT1 BITS

#### **Definition:**

#define PWM\_TZDCSEL\_DCBEVT1\_BITS

## **Description:**

Defines the location of the DCBEVT1 bits in the TZDCSEL register.

# 13.2.2.82 PWM TZDCSEL DCBEVT2 BITS

#### **Definition:**

#define PWM\_TZDCSEL\_DCBEVT2\_BITS

## **Description:**

Defines the location of the DCBEVT2 bits in the TZDCSEL register.

# 13.2.2.83 PWM\_TZFRC\_CBC\_BITS

# **Definition:**

#define PWM\_TZFRC\_CBC\_BITS

## **Description:**

Defines the location of the CBC bits in the TZFRC register.

# 13.2.2.84 PWM\_TZFRC\_DCAEVT1\_BITS

# **Definition:**

#define PWM\_TZFRC\_DCAEVT1\_BITS

## **Description:**

Defines the location of the DCAEVT1 bits in the TZFRC register.

# 13.2.2.85 PWM TZFRC DCAEVT2 BITS

#### **Definition:**

#define PWM\_TZFRC\_DCAEVT2\_BITS

## **Description:**

Defines the location of the DCAEVT2 bits in the TZFRC register.

# 13.2.2.86 PWM\_TZFRC\_DCBEVT1\_BITS

## **Definition:**

#define PWM\_TZFRC\_DCBEVT1\_BITS

# **Description:**

Defines the location of the DCBEVT1 bits in the TZFRC register.

# 13.2.2.87 PWM\_TZFRC\_DCBEVT2\_BITS

#### **Definition:**

#define PWM\_TZFRC\_DCBEVT2\_BITS

## **Description:**

Defines the location of the DCBEVT2 bits in the TZFRC register.

# 13.2.2.88 PWM\_TZFRC\_OST\_BITS

#### **Definition:**

#define PWM\_TZFRC\_OST\_BITS

## **Description:**

Defines the location of the OST bits in the TZFRC register.

# 13.2.3 Typedef Documentation

# 13.2.3.1 PWM Handle

#### **Definition:**

```
typedef struct PWM_Obj *PWM_Handle
```

# **Description:**

Defines the pulse width modulation (PWM) handle.

# 13.2.3.2 PWM Obj

#### **Definition:**

typedef struct \_PWM\_Obj\_ PWM\_Obj

## **Description:**

Defines the pulse width modulation (PWM) object.

# 13.2.4 Enumeration Documentation

# 13.2.4.1 PWM\_ActionQual\_e

## **Description:**

Enumeration to define the pulse width modulation (PWM) action qualifiers.

13.2.4.2 enum PWM ChoppingClkFreq e

Enumeration to define the pulse width modulation (PWM) chopping clock frequencies.

13.2.4.3 enum PWM ChoppingDutyCycle e

Enumeration to define the pulse width modulation (PWM) chopping clock duty cycles.

13.2.4.4 enum PWM ChoppingPulseWidth e

Enumeration to define the pulse width modulation (PWM) chopping clock pulse widths.

13.2.4.5 enum PWM ClkDiv e

Enumeration to define the pulse width modulation (PWM) clock dividers.

13.2.4.6 enum PWM CounterMode e

Enumeration to define the pulse width modulation (PWM) counter modes.

13.2.4.7 enum PWM DeadBandInputMode e

Enumeration to define the pulse width modulation (PWM) deadband options.

13.2.4.8 enum PWM\_DeadBandOutputMode\_e

Enumeration to define the pulse width modulation (PWM) deadband output modes.

13.2.4.9 enum PWM DeadBandPolarity e

Enumeration to define the pulse width modulation (PWM) deadband polarity.

13.2.4.10 enum PWM DigitalCompare FilterSrc e

Enumeration to define the pulse width modulation (PWM) digital compare filter sources.

# 13.2.4.11 enum PWM DigitalCompare Input e

Enumeration to define the pulse width modulation (PWM) digital compare inputs.

# 13.2.4.12 enum PWM DigitalCompare InputSel e

Enumeration to define the pulse width modulation (PWM) digital compare input choices.

# 13.2.4.13 enum PWM\_DigitalCompare\_PulseSel\_e

Enumeration to define the pulse width modulation (PWM) digital compare blanking pulse select.

# 13.2.4.14 enum PWM HrControlMode e

Enumeration to define the pulse width modulation (PWM) high resolution control mode options.

# 13.2.4.15 enum PWM\_HrEdgeMode\_e

Enumeration to define the pulse width modulation (PWM) high resolution edge mode options.

# 13.2.4.16 enum PWM HrShadowMode e

Enumeration to define the pulse width modulation (PWM) high resolution shadow load mode options.

# 13.2.4.17 enum PWM HspClkDiv e

Enumeration to define the pulse width modulation (PWM) high speed clock divide options.

## 13.2.4.18 enum PWM IntMode e

Enumeration to define the pulse width modulation (PWM) interrupt generation modes.

# 13.2.4.19 enum PWM IntPeriod e

Enumeration to define the pulse width modulation (PWM) interrupt period options.

# 13.2.4.20 enum PWM LoadMode e

Enumeration to define the pulse width modulation (PWM) load modes.

# 13.2.4.21 enum PWM Number e

Enumeration to define the pulse width modulation (PWM) numbers.

# 13.2.4.22 enum PWM PeriodLoad e

Enumeration to define the pulse width modulation (PWM) period load options.

# 13.2.4.23 enum PWM PhaseDir e

Enumeration to define the pulse width modulation (PWM) phase direction modes.

# 13.2.4.24 enum PWM RunMode e

Enumeration to define the pulse width modulation (PWM) run modes.

# 13.2.4.25 enum PWM ShadowMode e

Enumeration to define the pulse width modulation (PWM) shadow modes.

## 13.2.4.26 enum PWM ShadowStatus e

Enumeration to define the pulse width modulation (PWM) shadow status options.

# 13.2.4.27 enum PWM SocPeriod e

Enumeration to define the pulse width modulation (PWM) start of conversion (SOC) period options.

## 13.2.4.28 enum PWM SocPulseSrc e

Enumeration to define the pulse width modulation (PWM) start of conversion (SOC) sources.

# 13.2.4.29 enum PWM SyncMode e

Enumeration to define the pulse width modulation (PWM) sync modes.

# 13.2.4.30 enum PWM TripZoneDCEventSel e

Enumeration to define the pulse width modulation (PWM) trip zone event selections.

#### **Enumerators:**

PWM TripZoneDCEventSel Disabled Event Disabled.

**PWM\_TripZoneDCEventSel\_DCxHL\_DCxLX** Compare H = Low, Compare L = Don't Care.

PWM\_TripZoneDCEventSel\_DCxHH\_DCxLX Compare H = High, Compare L = Don't Care.

**PWM\_TripZoneDCEventSel\_DCxHx\_DCxLL** Compare H = Don't Care, Compare L = Low. **PWM\_TripZoneDCEventSel\_DCxHx\_DCxLH** Compare H = Don't Care, Compare L = High.

**PWM\_TripZoneDCEventSel\_DCxHL\_DCxLH** Compare H = Low, Compare L = High.

# 13.2.4.31 PWM TripZoneFlag e

## **Description:**

Enumeration to define the pulse width modulation (PWM) trip zone states.

#### **Enumerators:**

**PWM\_TripZoneFlag\_Global** Global Trip Zone flag.

**PWM\_TripZoneFlag\_CBC** Cycle by cycle Trip Zone flag.

PWM\_TripZoneFlag\_OST One Shot Trip Zone flag.

**PWM\_TripZoneFlag\_DCAEVT1** Digital Compare A Event 1 Trip Zone flag.

PWM\_TripZoneFlag\_DCAEVT2 Digital Compare A Event 2 Trip Zone flag.

**PWM\_TripZoneFlag\_DCBEVT1** Digital Compare B Event 1 Trip Zone flag.

PWM TripZoneFlag DCBEVT2 Digital Compare B Event 2 Trip Zone flag.

# 13.2.4.32 PWM TripZoneSrc e

## **Description:**

Enumeration to define the pulse width modulation (PWM) trip zone sources.

## 13.2.4.33 enum PWM TripZoneState e

Enumeration to define the pulse width modulation (PWM) trip zone states.

# 13.2.5 Function Documentation

# 13.2.5.1 void PWM clearIntFlag (PWM Handle pwmHandle) [inline]

Clears the pulse width modulation (PWM) interrupt flag.

## Parameters:

13.2.5.2 void PWM clearOneShotTrip (PWM Handle pwmHandle) [inline]

Clears the pulse width modulation (PWM) one shot trip.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- 13.2.5.3 void PWM clearSocAFlag (PWM Handle pwmHandle) [inline]

Clears the pulse width modulation (PWM) start of conversion (SOC) A flag.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- 13.2.5.4 void PWM clearSocBFlag (PWM Handle pwmHandle) [inline]

Clears the pulse width modulation (PWM) start of conversion (SOC) B flag.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- 13.2.5.5 void PWM\_clearTripZone (PWM\_Handle pwmHandle, const PWM\_TripZoneFlag\_e tripZoneFlag)

Clears the trip zone (TZ) flag specified.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← tripZoneFlag The trip zone flag to clear
- 13.2.5.6 void PWM\_decrementDeadBandFallingEdgeDelay (PWM\_Handle pwmHandle)

Decrement the dead band falling edge delay.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- 13.2.5.7 void PWM\_decrementDeadBandRisingEdgeDelay (PWM\_Handle pwmHandle)

Decrement the dead band rising edge delay.

## Parameters:

# 13.2.5.8 void PWM disableAutoConvert (PWM Handle pwmHandle)

Disables auto conversion of delay line value.

#### **Parameters:**

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.9 void PWM disableChopping (PWM Handle pwmHandle)

Disables the pulse width modulation (PWM) chopping.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.10 void PWM disableCounterLoad (PWM Handle pwmHandle)

Disables the pulse width modulation (PWM) counter loading from the phase register.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.11 void PWM disableDeadBand (PWM Handle pwmHandle)

Disables the pulse width modulation (PWM) deadband.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.12 void PWM\_disableDeadBandHalfCycle (PWM\_Handle pwmHandle)

Disables the pulse width modulation (PWM) deadband half cycle clocking.

#### Parameters:

 $\leftarrow$  *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.13 void PWM disableDigitalCompareBlankingWindow (PWM Handle pwmHandle)

Disables the pulse width modulation (PWM) digital compare blanking window.

## Parameters:

# 13.2.5.14 void PWM\_disableDigitalCompareBlankingWindowInversion (PWM\_Handle pwmHandle)

Disables the pulse width modulation (PWM) digital compare blanking window inversion.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.15 void PWM\_disableHrPeriod (PWM\_Handle pwmHandle)

Disables high resolution period control.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.16 void PWM disableHrPhaseSync (PWM Handle pwmHandle)

Disables high resolution phase synchronization.

## Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.17 void PWM disableInt (PWM Handle pwmHandle)

Disables the pulse width modulation (PWM) interrupt.

## Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.18 void PWM disableSocAPulse (PWM Handle pwmHandle)

Disables the pulse width modulation (PWM) start of conversion (SOC) B pulse generation.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.19 void PWM disableSocBPulse (PWM Handle pwmHandle)

Disables the pulse width modulation (PWM) start of conversion (SOC) B pulse generation.

#### Parameters:

# 13.2.5.20 void PWM\_disableTripZoneInt (PWM\_Handle pwmHandle, const PWM TripZoneFlag e interruptSource)

Disables the pulse width modulation (PWM) trip zones interrupts.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *interrupt* The interrupt source to disable

# 13.2.5.21 void PWM disableTripZones (PWM Handle pwmHandle)

Disables the pulse width modulation (PWM) trip zones.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.22 void PWM\_disableTripZoneSrc (PWM\_Handle pwmHandle, const PWM TripZoneSrc e src)

Disable the pulse width modulation (PWM) trip zone source.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  **src** The pulse width modulation (PWM) trip zone source

## 13.2.5.23 void PWM enableAutoConvert (PWM Handle pwmHandle)

Enables auto conversion of delay line value.

## Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

## 13.2.5.24 void PWM enableChopping (PWM Handle pwmHandle)

Enables the pulse width modulation (PWM) chopping.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.25 void PWM enableCounterLoad (PWM Handle pwmHandle)

Enables the pulse width modulation (PWM) counter loading from the phase register.

#### Parameters:

# 13.2.5.26 void PWM enableDeadBandHalfCycle (PWM Handle pwmHandle)

Enables the pulse width modulation (PWM) deadband half cycle clocking.

## Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.27 void PWM enableDigitalCompareBlankingWindow (PWM Handle pwmHandle)

Enables the pulse width modulation (PWM) digital compare blanking window.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.28 void PWM\_enableDigitalCompareBlankingWindowInversion (PWM\_Handle pwmHandle)

Enables the pulse width modulation (PWM) digital compare blanking window inversion.

## Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

## 13.2.5.29 void PWM enableHrPeriod (PWM Handle pwmHandle)

Enables high resolution period control.

## Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.30 void PWM enableHrPhaseSync (PWM Handle pwmHandle)

Enables high resolution phase synchronization.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

# 13.2.5.31 void PWM enableInt (PWM Handle pwmHandle)

Enables the pulse width modulation (PWM) interrupt.

#### Parameters:

13.2.5.32 void PWM enableSocAPulse (PWM Handle pwmHandle)

Enables the pulse width modulation (PWM) start of conversion (SOC) A pulse generation.

## Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

13.2.5.33 void PWM enableSocBPulse (PWM Handle pwmHandle)

Enables the pulse width modulation (PWM) start of conversion (SOC) B pulse generation.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

13.2.5.34 void PWM\_enableTripZoneInt (PWM\_Handle pwmHandle, const PWM\_TripZoneFlag\_e interruptSource)

Enables the pulse width modulation (PWM) trip zones interrupts.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *interrupt* The interrupt source to enable

13.2.5.35 void PWM\_enableTripZoneSrc (PWM\_Handle pwmHandle, const PWM TripZoneSrc e src)

Enable the pulse width modulation (PWM) trip zone source.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow \textit{\textit{src}}$  The pulse width modulation (PWM) trip zone source

13.2.5.36 void PWM forceSync (PWM Handle pwmHandle) [inline]

Force Synchronization.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

13.2.5.37 uint16 t PWM getCmpA (PWM Handle pwmHandle) [inline]

Gets the pulse width modulation (PWM) data value from the Counter Compare A hardware.

## Parameters:

## Returns:

The PWM compare data value

# 13.2.5.38 uint16\_t PWM\_getCmpAHr (PWM\_Handle pwmHandle) [inline]

Gets the pulse width modulation (PWM) data value from the Counter Compare A Hr hardware.

## Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

#### Returns:

The PWM compare high resolution data value

# 13.2.5.39 uint16\_t PWM\_getCmpB (PWM\_Handle pwmHandle) [inline]

Gets the pulse width modulation (PWM) data value from the Counter Compare B hardware.

## Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

#### Returns:

The PWM compare data value

# 13.2.5.40 uint16 t PWM getDeadBandFallingEdgeDelay (PWM Handle pwmHandle)

Gets the pulse width modulation (PWM) deadband falling edge delay.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

## Returns:

The delay

# 13.2.5.41 uint16 t PWM getDeadBandRisingEdgeDelay (PWM Handle pwmHandle)

Gets the pulse width modulation (PWM) deadband rising edge delay.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

#### Returns:

The delay

# 13.2.5.42 uint16 t PWM getIntCount (PWM Handle pwmHandle)

Gets the pulse width modulation (PWM) interrupt event count.

#### **Parameters:**

← *pwmHandle* The pulse width modulation (PWM) object handle

#### Returns:

The interrupt event count

# 13.2.5.43 uint16\_t PWM\_getPeriod (PWM\_Handle pwmHandle) [inline]

Gets the pulse width modulation (PWM) period value.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

#### Returns:

The pwm period value

# 13.2.5.44 uint16\_t PWM\_getSocACount (PWM\_Handle pwmHandle)

Gets the pulse width modulation (PWM) start of conversion (SOC) A count.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

## Returns:

The SOC A count

# 13.2.5.45 uint16\_t PWM\_getSocBCount (PWM\_Handle pwmHandle)

Gets the pulse width modulation (PWM) start of conversion (SOC) B count.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

#### Returns:

The SOC B count

# 13.2.5.46 void PWM incrementDeadBandFallingEdgeDelay (PWM\_Handle pwmHandle)

Increment the dead band falling edge delay.

#### Parameters:

# 13.2.5.47 void PWM incrementDeadBandRisingEdgeDelay (PWM Handle pwmHandle)

Increment the dead band rising edge delay.

#### Parameters:

← *pwmHandle* The pulse width modulation (PWM) object handle

## 13.2.5.48 PWM Handle PWM init (void \* pMemory, const size t numBytes)

Initializes the pulse width modulation (PWM) object handle.

#### Parameters:

- ← *pMemory* A pointer to the base address of the PWM registers
- ← *numBytes* The number of bytes allocated for the PWM object, bytes

## Returns:

The pulse width modulation (PWM) object handle

# 13.2.5.49 void PWM\_setActionQual\_CntDown\_CmpA\_PwmA (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)

Sets the pulse width modulation (PWM) object action for PWM A when the counter equals CMPA and the counter is decrementing.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← actionQual The action qualifier

# 13.2.5.50 void PWM\_setActionQual\_CntDown\_CmpA\_PwmB (PWM\_Handle pwmHandle, const PWM\_ActionQual\_e actionQual)

Sets the pulse width modulation (PWM) object action for PWM B when the counter equals CMPA and the counter is decrementing.

#### **Parameters:**

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← actionQual The action qualifier

# 13.2.5.51 void PWM\_setActionQual\_CntDown\_CmpB\_PwmA (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)

Sets the pulse width modulation (PWM) object action for PWM A when the counter equals CMPB and the counter is decrementing.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← actionQual The action qualifier

13.2.5.52 void PWM\_setActionQual\_CntDown\_CmpB\_PwmB (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)

Sets the pulse width modulation (PWM) object action for PWM B when the counter equals CMPB and the counter is decrementing.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← actionQual The action qualifier
- 13.2.5.53 void PWM\_setActionQual\_CntUp\_CmpA\_PwmA (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)

Sets the pulse width modulation (PWM) object action for PWM A when the counter equals CMPA and the counter is incrementing.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  actionQual The action qualifier
- 13.2.5.54 void PWM\_setActionQual\_CntUp\_CmpA\_PwmB (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)

Sets the pulse width modulation (PWM) object action for PWM B when the counter equals CMPA and the counter is incrementing.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← actionQual The action qualifier
- 13.2.5.55 void PWM\_setActionQual\_CntUp\_CmpB\_PwmA (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)

Sets the pulse width modulation (PWM) object action for PWM A when the counter equals CMPB and the counter is incrementing.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← actionQual The action qualifier
- 13.2.5.56 void PWM\_setActionQual\_CntUp\_CmpB\_PwmB (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)

Sets the pulse width modulation (PWM) object action for PWM B when the counter equals CMPB and the counter is incrementing.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← actionQual The action qualifier

# 13.2.5.57 void PWM\_setActionQual\_Period\_PwmA (PWM\_Handle pwmHandle, const PWM ActionQual e actionQual)

Sets the pulse width modulation (PWM) object action for PWM A when the counter equals the period.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← actionQual The action qualifier

# 13.2.5.58 void PWM\_setActionQual\_Period\_PwmB (PWM\_Handle pwmHandle, const PWM\_ActionQual\_e actionQual)

Sets the pulse width modulation (PWM) object action for PWM B when the counter equals the period.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← actionQual The action qualifier

# 13.2.5.59 void PWM\_setActionQual\_Zero\_PwmA (PWM\_Handle pwmHandle, const PWM\_ActionQual\_e actionQual)

Sets the pulse width modulation (PWM) object action for PWM A when the counter equals the zero.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← actionQual The action qualifier

# 13.2.5.60 void PWM\_setActionQual\_Zero\_PwmB (PWM\_Handle pwmHandle, const PWM\_ActionQual\_e actionQual)

Sets the pulse width modulation (PWM) object action for PWM B when the counter equals the zero.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  actionQual The action qualifier

# 13.2.5.61 void PWM\_setChoppingClkFreq (PWM\_Handle pwmHandle, const PWM ChoppingClkFreq e clkFreq)

Sets the pulse width modulation (PWM) chopping clock frequency.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *clkFreq* The clock frequency

# 13.2.5.62 void PWM\_setChoppingDutyCycle (PWM\_Handle pwmHandle, const PWM ChoppingDutyCycle e dutyCycle)

Sets the pulse width modulation (PWM) chopping clock duty cycle.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *dutyCycle* The duty cycle

# 13.2.5.63 void PWM\_setChoppingPulseWidth (PWM\_Handle pwmHandle, const PWM\_ChoppingPulseWidth\_e pulseWidth)

Sets the pulse width modulation (PWM) chopping clock pulse width.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *pulseWidth* The pulse width

# 13.2.5.64 void PWM setClkDiv (PWM Handle pwmHandle, const PWM ClkDiv e clkDiv)

Sets the pulse width modulation (PWM) clock divisor.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *clkDiv* The clock divisor

# 13.2.5.65 void PWM\_setCmpA (PWM\_Handle pwmHandle, const uint16\_t pwmData) [inline]

Writes the pulse width modulation (PWM) data value to the Counter Compare A hardware.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← pwmData The PWM data value

# 13.2.5.66 void PWM\_setCmpAHr (PWM\_Handle pwmHandle, const uint16\_t pwmData) [inline]

Writes the pulse width modulation (PWM) data value to the Counter Compare A Hr hardware.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *pwmData* The PWM high resolution data value

# 13.2.5.67 void PWM\_setCmpB (PWM\_Handle pwmHandle, const uint16\_t pwmData) [inline]

Writes the pulse width modulation (PWM) data value to the Counter Compare B hardware.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← pwmData The PWM data value

## 13.2.5.68 void PWM\_setCount (PWM\_Handle pwmHandle, const uint16\_t count)

Sets the pulse width modulation (PWM) count.

#### **Parameters:**

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *count* The count

# 13.2.5.69 void PWM\_setCounterMode (PWM\_Handle pwmHandle, const PWM CounterMode e counterMode)

Sets the pulse width modulation (PWM) counter mode.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *counterMode* The count mode

# 13.2.5.70 void PWM\_setDeadBandFallingEdgeDelay (PWM\_Handle pwmHandle, const uint16\_t delay)

Sets the pulse width modulation (PWM) deadband falling edge delay.

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  **delay** The delay

13.2.5.71 void PWM\_setDeadBandInputMode (PWM\_Handle pwmHandle, const PWM\_DeadBandInputMode e inputMode)

Sets the pulse width modulation (PWM) deadband input mode.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *inputMode* The input mode
- 13.2.5.72 void PWM\_setDeadBandOutputMode (PWM\_Handle pwmHandle, const PWM\_DeadBandOutputMode\_e outputMode)

Sets the pulse width modulation (PWM) deadband output mode.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  *outputMode* The output mode
- 13.2.5.73 void PWM\_setDeadBandPolarity (PWM\_Handle pwmHandle, const PWM\_DeadBandPolarity\_e polarity)

Sets the pulse width modulation (PWM) deadband polarity.

#### Parameters.

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *polarity* The polarity
- 13.2.5.74 void PWM\_setDeadBandRisingEdgeDelay (PWM\_Handle pwmHandle, const uint16\_t delay)

Sets the pulse width modulation (PWM) deadband rising edge delay.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *delay* The delay
- 13.2.5.75 void PWM\_setDigitalCompareAEvent1 (PWM\_Handle pwmHandle, const bool\_t selectFilter, const bool\_t disableSync, const bool\_t enableSoc, const bool\_t generateSync)

Sets the pulse width modulation (PWM) digital compare A event 1 source parameters.

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← selectFilter Select filter output if true

- ← *disableSync* Asynchronous if true
- ← enableSoc Enable SOC generation if true
- ← *generateSync* Generate SYNC if true
- 13.2.5.76 void PWM\_setDigitalCompareAEvent2 (PWM\_Handle pwmHandle, const bool\_t selectFilter, const bool\_t disableSync)

Sets the pulse width modulation (PWM) digital compare A event 2 source parameters.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *selectFilter* Select filter output if true
- ← *disableSync* Asynchronous if true
- 13.2.5.77 void PWM\_setDigitalCompareBEvent1 (PWM\_Handle pwmHandle, const bool\_t selectFilter, const bool\_t disableSync, const bool\_t enableSoc, const bool\_t generateSync)

Sets the pulse width modulation (PWM) digital compare B event 1 source parameters.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *selectFilter* Select filter output if true
- ← *disableSync* Asynchronous if true
- ← enableSoc Enable SOC generation if true
- ← *generateSync* Generate SYNC if true
- 13.2.5.78 void PWM\_setDigitalCompareBEvent2 (PWM\_Handle pwmHandle, const bool\_t selectFilter, const bool\_t disableSync)

Sets the pulse width modulation (PWM) digital compare B event 2 source parameters.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← **selectFilter** Select filter output if true
- ← disableSync Asynchronous if true
- 13.2.5.79 void PWM\_setDigitalCompareBlankingPulse (PWM\_Handle pwmHandle, const PWM\_DigitalCompare\_PulseSel\_e pulseSelect)

Sets the pulse width modulation (PWM) digital compare blanking pulse.

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *input* The pulse selection

13.2.5.80 void PWM\_setDigitalCompareFilterOffset (PWM\_Handle pwmHandle, const uint16 t offset)

Sets the pulse width modulation (PWM) digital compare filter offset.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  **offset** The offset
- 13.2.5.81 void PWM\_setDigitalCompareFilterSource (PWM\_Handle pwmHandle, const PWM\_DigitalCompare\_FilterSrc\_e input)

Sets the pulse width modulation (PWM) digital compare filter source.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  *input* The filter's source
- 13.2.5.82 void PWM\_setDigitalCompareFilterWindow (PWM\_Handle pwmHandle, const uint16 t window)

Sets the pulse width modulation (PWM) digital compare filter offset.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *window* The window
- 13.2.5.83 void PWM\_setDigitalCompareInput (PWM\_Handle pwmHandle, const PWM\_DigitalCompare\_Input\_e input, const PWM\_DigitalCompare\_InputSel\_e inputSel)

Sets the pulse width modulation (PWM) digital compare input.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *input* Comparator input to change
- ← inputSel Input selection for designated input
- 13.2.5.84 void PWM\_setHighSpeedClkDiv (PWM\_Handle pwmHandle, const PWM\_HspClkDiv\_e clkDiv)

Sets the pulse width modulation (PWM) high speed clock divisor.

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← clkDiv The clock divisor

# 13.2.5.85 void PWM\_setHrControlMode (PWM\_Handle pwmHandle, const PWM HrControlMode e controlMode)

Set the High Resolution Control Mode.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← edgeMode The control mode HRPWM should use

# 13.2.5.86 void PWM\_setHrEdgeMode (PWM\_Handle pwmHandle, const PWM HrEdgeMode e edgeMode)

Set the High Resolution Edge Mode.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  *edgeMode* The edge mode HRPWM should use

# 13.2.5.87 void PWM\_setHrShadowMode (PWM\_Handle pwmHandle, const PWM\_HrShadowMode\_e shadowMode)

Set the High Resolution Shadow Load Mode.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *edgeMode* The shadow load mode HRPWM should use

# 13.2.5.88 void PWM\_setIntMode (PWM\_Handle pwmHandle, const PWM\_IntMode\_e intMode)

Sets the pulse width modulation (PWM) interrupt mode.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow \textit{intMode} \ \ \text{The interrupt mode}$

# 13.2.5.89 void PWM\_setIntPeriod (PWM\_Handle pwmHandle, const PWM\_IntPeriod\_e intPeriod)

Sets the pulse width modulation (PWM) interrupt period.

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *intPeriod* The interrupt period

13.2.5.90 void PWM\_setLoadMode\_CmpA (PWM\_Handle pwmHandle, const PWM\_LoadMode e loadMode)

Sets the pulse width modulation (PWM) load mode for CMPA.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *loadMode* The load mode
- 13.2.5.91 void PWM\_setLoadMode\_CmpB (PWM\_Handle pwmHandle, const PWM\_LoadMode e loadMode)

Sets the pulse width modulation (PWM) load mode for CMPB.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  *loadMode* The load mode
- 13.2.5.92 void PWM\_setOneShotTrip (PWM\_Handle pwmHandle) [inline]

Sets the pulse width modulation (PWM) one shot trip.

#### **Parameters:**

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- 13.2.5.93 void PWM setPeriod (PWM Handle pwmHandle, const uint16 t period)

Sets the pulse width modulation (PWM) period.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  *period* The period
- 13.2.5.94 void PWM\_setPeriodHr (PWM\_Handle pwmHandle, const uint16\_t period)

Sets the pulse width modulation (PWM) high resolution period.

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *period* The period

13.2.5.95 void PWM\_setPeriodLoad (PWM\_Handle pwmHandle, const PWM\_PeriodLoad\_e periodLoad)

Sets the pulse width modulation (PWM) period load mode.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *periodLoad* The period load mode
- 13.2.5.96 void PWM\_setPhase (PWM\_Handle pwmHandle, const uint16\_t phase)

Sets the pulse width modulation (PWM) phase.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  *phase* The phase
- 13.2.5.97 void PWM\_setPhaseDir (PWM\_Handle pwmHandle, const PWM\_PhaseDir\_e phaseDir)

Sets the pulse width modulation (PWM) phase direction.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *phaseDir* The phase direction
- 13.2.5.98 void PWM\_setRunMode (PWM\_Handle pwmHandle, const PWM\_RunMode\_e runMode)

Sets the pulse width modulation (PWM) run mode.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  *runMode* The run mode
- 13.2.5.99 void PWM\_setShadowMode\_CmpA (PWM\_Handle pwmHandle, const PWM\_ShadowMode\_e shadowMode)

Sets the pulse width modulation (PWM) shadow mode for CMPA.

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *shadowMode* The shadow mode

13.2.5.100void PWM\_setShadowMode\_CmpB (PWM\_Handle pwmHandle, const PWM\_ShadowMode e shadowMode)

Sets the pulse width modulation (PWM) shadow mode for CMPB.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *shadowMode* The shadow mode
- 13.2.5.101void PWM\_setSocAPeriod (PWM\_Handle pwmHandle, const PWM\_SocPeriod\_e intPeriod)

Sets the pulse width modulation (PWM) start of conversion (SOC) A interrupt period.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *intPeriod* The interrupt period
- 13.2.5.102void PWM\_setSocAPulseSrc (PWM\_Handle pwmHandle, const PWM\_SocPulseSrc e pulseSrc)

Sets the pulse width modulation (PWM) start of conversion (SOC) A interrupt pulse source.

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *pulseSrc* The interrupt pulse source
- 13.2.5.103void PWM\_setSocBPeriod (PWM\_Handle pwmHandle, const PWM\_SocPeriod\_e intPeriod)

Sets the pulse width modulation (PWM) start of conversion (SOC) B interrupt period.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  *intPeriod* The interrupt period
- 13.2.5.104void PWM\_setSocBPulseSrc (PWM\_Handle pwmHandle, const PWM\_SocPulseSrc e pulseSrc)

Sets the pulse width modulation (PWM) start of conversion (SOC) B interrupt pulse source.

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *pulseSrc* The interrupt pulse source

## 13.2.5.105void PWM setSwSync (PWM Handle pwmHandle)

Sets the pulse width modulation (PWM) software sync.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- 13.2.5.106void PWM\_setSyncMode (PWM\_Handle pwmHandle, const PWM\_SyncMode\_e syncMode)

Sets the pulse width modulation (PWM) sync mode.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← **syncMode** The sync mode
- 13.2.5.107void PWM\_setTripZoneDCEventSelect\_DCAEVT1 (PWM\_Handle pwmHandle, const PWM\_TripZoneDCEventSel\_e tripZoneEvent)

Sets the pulse width modulation (PWM) trip zone digital compare event select for Digital Compare Output A Event 1 (DCAEVT1).

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *tripZoneEvent* The trip zone digital compare event
- 13.2.5.108/oid PWM\_setTripZoneDCEventSelect\_DCAEVT2 (PWM\_Handle pwmHandle, const PWM TripZoneDCEventSel e tripZoneEvent)

Sets the pulse width modulation (PWM) trip zone digital compare event select for Digital Compare Output A Event 2 (DCAEVT2).

#### **Parameters:**

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *tripZoneEvent* The trip zone digital compare event
- 13.2.5.109void PWM\_setTripZoneDCEventSelect\_DCBEVT1 (PWM\_Handle pwmHandle, const PWM TripZoneDCEventSel e tripZoneEvent)

Sets the pulse width modulation (PWM) trip zone digital compare event select for Digital Compare Output B Event 1 (DCBEVT1).

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← tripZoneEvent The trip zone digital compare event

13.2.5.110void PWM\_setTripZoneDCEventSelect\_DCBEVT2 (PWM\_Handle pwmHandle, const PWM\_TripZoneDCEventSel\_e tripZoneEvent)

Sets the pulse width modulation (PWM) trip zone digital compare event select for Digital Compare Output B Event 2 (DCBEVT2).

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *tripZoneEvent* The trip zone digital compare event
- 13.2.5.111void PWM\_setTripZoneState\_DCAEVT1 (PWM\_Handle pwmHandle, const PWM TripZoneState e tripZoneState)

Sets the pulse width modulation (PWM) trip zone state for Digital Compare Output A Event 1 (DCAEVT1).

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *tripZoneState* The trip zone state
- 13.2.5.112void PWM\_setTripZoneState\_DCAEVT2 (PWM\_Handle pwmHandle, const PWM TripZoneState e tripZoneState)

Sets the pulse width modulation (PWM) trip zone state for Digital Compare Output A Event 2 (DCAEVT1).

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *tripZoneState* The trip zone state
- 13.2.5.113void PWM\_setTripZoneState\_DCBEVT1 (PWM\_Handle pwmHandle, const PWM TripZoneState e tripZoneState)

Sets the pulse width modulation (PWM) trip zone state for Digital Compare Output B Event 1 (DCBEVT1).

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- $\leftarrow$  *tripZoneState* The trip zone state
- 13.2.5.114void PWM\_setTripZoneState\_DCBEVT2 (PWM\_Handle pwmHandle, const PWM TripZoneState e tripZoneState)

Sets the pulse width modulation (PWM) trip zone state for Digital Compare Output B Event 2 (DCBEVT1).

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *tripZoneState* The trip zone state
- 13.2.5.115void PWM\_setTripZoneState\_TZA (PWM\_Handle pwmHandle, const PWM\_TripZoneState e tripZoneState)

Sets the pulse width modulation (PWM) trip zone state for Output A (TZA).

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *tripZoneState* The trip zone state
- 13.2.5.116void PWM\_setTripZoneState\_TZB (PWM\_Handle pwmHandle, const PWM\_TripZoneState\_e tripZoneState)

Sets the pulse width modulation (PWM) trip zone state for Output B (TZB).

#### Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← *tripZoneState* The trip zone state
- 13.2.5.117void PWM\_write\_CmpA (PWM\_Handle pwmHandle, const int16\_t pwmData) [inline]

Writes the pulse width modulation (PWM) data value to the Counter Compare A hardware.

## Parameters:

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← pwmData The PWM data value
- 13.2.5.118void PWM\_write\_CmpB (PWM\_Handle pwmHandle, const int16\_t pwmData) [inline]

Writes the pulse width modulation (PWM) data value to the Counter Compare B hardware.

- ← *pwmHandle* The pulse width modulation (PWM) object handle
- ← pwmData The PWM data value

228

# 14 Power Control (PWR)

Introduction	229
API Functions	. 229

# 14.1 Introduction

The power API is a set of functions for configuring low power modes as well as other power related functions such as brown out.

This driver is contained in f2802x0\_common/source/pwr.c, with f2802x0\_common/include/pwr.h containing the API definitions for use by applications.

# 14.2 PWR

## **Data Structures**

■ PWR Obj

## **Defines**

- PWR BASE ADDR
- PWR\_BORCFG\_BORENZ\_BITS
- PWR LPMCR0 LPM BITS
- PWR LPMCR0 QUALSTDBY BITS
- PWR LPMCR0 WDINTE BITS

## **Enumerations**

- PWR\_LowPowerMode\_e
- PWR NumStandByClocks e

## **Functions**

- void PWR\_disableBrownOutReset (PWR\_Handle pwrHandle)
- void PWR disableWatchDogInt (PWR Handle pwrHandle)
- void PWR\_enableBrownOutReset (PWR\_Handle pwrHandle)
- void PWR\_enableWatchDogInt (PWR\_Handle pwrHandle)
- PWR\_Handle PWR\_init (void \*pMemory, const size\_t numBytes)
- void PWR\_setLowPowerMode (PWR\_Handle pwrHandle, const PWR\_LowPowerMode\_e low-PowerMode)

■ void PWR\_setNumStandByClocks (PWR\_Handle pwrHandle, const PWR\_NumStandByClocks\_e numClkCycles)

## 14.2.1 Data Structure Documentation

## 14.2.1.1 \_PWR\_Obj\_

## **Definition:**

```
typedef struct
{
    uint16_t BORCFG;
    uint16_t rsvd_1[26264];
    uint16_t LPMCR0;
}
_PWR_Obj_
```

#### Members:

**BORCFG** BOR (Brown Out Reset) Configuration Register.

rsvd\_1 LPMCR0

## **Description:**

Defines the power (PWR) object.

## 14.2.2 Define Documentation

## 14.2.2.1 PWR BASE ADDR

## **Definition:**

#define PWR\_BASE\_ADDR

## **Description:**

Defines the base address of the power (PWR) registers.

## 14.2.2.2 PWR\_BORCFG\_BORENZ\_BITS

#### **Definition:**

```
#define PWR_BORCFG_BORENZ_BITS
```

## **Description:**

Defines the location of the BORENZ bits in the BORCFG register.

# 14.2.2.3 PWR\_LPMCR0\_LPM\_BITS

#### **Definition:**

#define PWR\_LPMCRO\_LPM\_BITS

## **Description:**

Defines the location of the LPM bits in the LPMCR0 register.

## 14.2.2.4 PWR\_LPMCR0\_QUALSTDBY\_BITS

#### **Definition:**

#define PWR\_LPMCR0\_QUALSTDBY\_BITS

#### **Description:**

Defines the location of the QUALSTDBY bits in the LPMCR0 register.

## 14.2.2.5 PWR LPMCR0 WDINTE BITS

## **Definition:**

#define PWR\_LPMCR0\_WDINTE\_BITS

## **Description:**

Defines the location of the WDINTE bits in the LPMCR0 register.

# 14.2.3 Typedef Documentation

## 14.2.3.1 PWR Handle

#### **Definition:**

typedef struct PWR\_Obj \*PWR\_Handle

## **Description:**

Defines the power (PWR) handle.

## 14.2.3.2 PWR Obj

## **Definition:**

typedef struct \_PWR\_Obj\_ PWR\_Obj

## **Description:**

Defines the power (PWR) object.

# 14.2.4 Enumeration Documentation

## 14.2.4.1 PWR\_LowPowerMode\_e

#### Description

Enumeration to define the power (PWR) low power modes.

## **Enumerators:**

PWR\_LowPowerMode\_Idle Denotes the idle mode.

PWR\_LowPowerMode\_Standby Denotes the standby mode.
PWR LowPowerMode Halt Denotes the halt mode.

## 14.2.4.2 PWR\_NumStandByClocks\_e

## **Description:**

Enumeration to define the power (PWR) number of standby clock cycles.

#### **Enumerators:**

```
PWR NumStandByClocks 2 Denotes 2 standby clock cycles.
PWR_NumStandByClocks_3 Denotes 3 standby clock cycles.
PWR_NumStandByClocks_4 Denotes 4 standby clock cycles.
PWR NumStandByClocks 5 Denotes 5 standby clock cycles.
PWR_NumStandByClocks_6 Denotes 6 standby clock cycles.
PWR NumStandByClocks 7 Denotes 7 standby clock cycles.
PWR_NumStandByClocks_8 Denotes 8 standby clock cycles.
PWR_NumStandByClocks_9 Denotes 9 standby clock cycles.
PWR_NumStandByClocks_10 Denotes 10 standby clock cycles.
PWR_NumStandByClocks_11 Denotes 11 standby clock cycles.
PWR_NumStandByClocks_12 Denotes 12 standby clock cycles.
PWR_NumStandByClocks_13 Denotes 13 standby clock cycles.
PWR_NumStandByClocks_14 Denotes 14 standby clock cycles.
PWR NumStandByClocks 15 Denotes 15 standby clock cycles.
PWR NumStandByClocks 16 Denotes 16 standby clock cycles.
PWR_NumStandByClocks_17 Denotes 17 standby clock cycles.
PWR_NumStandByClocks_18 Denotes 18 standby clock cycles.
PWR_NumStandByClocks_19 Denotes 19 standby clock cycles.
PWR NumStandByClocks 20 Denotes 20 standby clock cycles.
PWR_NumStandByClocks_21 Denotes 21 standby clock cycles.
PWR NumStandByClocks 22 Denotes 22 standby clock cycles.
PWR_NumStandByClocks_23 Denotes 23 standby clock cycles.
PWR NumStandByClocks 24 Denotes 24 standby clock cycles.
PWR_NumStandByClocks_25 Denotes 25 standby clock cycles.
PWR_NumStandByClocks_26 Denotes 26 standby clock cycles.
PWR_NumStandByClocks_27 Denotes 27 standby clock cycles.
PWR_NumStandByClocks_28 Denotes 28 standby clock cycles.
PWR NumStandByClocks 29 Denotes 29 standby clock cycles.
PWR NumStandByClocks 30 Denotes 30 standby clock cycles.
PWR NumStandByClocks 31 Denotes 31 standby clock cycles.
PWR_NumStandByClocks_32 Denotes 32 standby clock cycles.
PWR_NumStandByClocks_33 Denotes 33 standby clock cycles.
PWR NumStandByClocks 34 Denotes 34 standby clock cycles.
PWR NumStandByClocks 35 Denotes 35 standby clock cycles.
PWR_NumStandByClocks_36 Denotes 36 standby clock cycles.
PWR_NumStandByClocks_37 Denotes 37 standby clock cycles.
```

```
PWR_NumStandByClocks_38 Denotes 38 standby clock cycles.
PWR_NumStandByClocks_39 Denotes 39 standby clock cycles.
PWR_NumStandByClocks_40 Denotes 40 standby clock cycles.
PWR NumStandByClocks 41 Denotes 41 standby clock cycles.
PWR_NumStandByClocks_42 Denotes 42 standby clock cycles.
PWR NumStandByClocks 43 Denotes 43 standby clock cycles.
PWR_NumStandByClocks_44 Denotes 44 standby clock cycles.
PWR_NumStandByClocks_45 Denotes 45 standby clock cycles.
PWR_NumStandByClocks_46 Denotes 46 standby clock cycles.
PWR_NumStandByClocks_47 Denotes 47 standby clock cycles.
PWR_NumStandByClocks_48 Denotes 48 standby clock cycles.
PWR NumStandByClocks 49 Denotes 49 standby clock cycles.
PWR_NumStandByClocks_50 Denotes 50 standby clock cycles.
PWR_NumStandByClocks_51 Denotes 51 standby clock cycles.
PWR_NumStandByClocks_52 Denotes 52 standby clock cycles.
PWR NumStandByClocks 53 Denotes 53 standby clock cycles.
PWR NumStandByClocks 54 Denotes 54 standby clock cycles.
PWR_NumStandByClocks_55 Denotes 55 standby clock cycles.
PWR NumStandByClocks 56 Denotes 56 standby clock cycles.
PWR_NumStandByClocks_57 Denotes 57 standby clock cycles.
PWR_NumStandByClocks_58 Denotes 58 standby clock cycles.
PWR NumStandByClocks 59 Denotes 59 standby clock cycles.
PWR NumStandByClocks 60 Denotes 60 standby clock cycles.
PWR_NumStandByClocks_61 Denotes 61 standby clock cycles.
PWR_NumStandByClocks_62 Denotes 62 standby clock cycles.
PWR_NumStandByClocks_63 Denotes 63 standby clock cycles.
PWR NumStandByClocks 64 Denotes 64 standby clock cycles.
PWR_NumStandByClocks_65 Denotes 65 standby clock cycles.
```

## 14.2.5 Function Documentation

## 14.2.5.1 PWR disableBrownOutReset

Disables the brownout reset functions.

## Prototype:

void

PWR\_disableBrownOutReset (PWR\_Handle pwrHandle)

## Parameters:

← *pwrHandle* The power (PWR) object handle

## 14.2.5.2 void PWR disableWatchDogInt (PWR Handle pwrHandle)

Disables the watchdog interrupt.

#### Parameters:

← *pwrHandle* The power (PWR) object handle

14.2.5.3 void PWR enableBrownOutReset (PWR Handle pwrHandle)

Enables the brownout reset functions.

#### Parameters:

← *pwrHandle* The power (PWR) object handle

14.2.5.4 void PWR enableWatchDogInt (PWR Handle pwrHandle)

Enables the watchdog interrupt.

#### Parameters:

← *pwrHandle* The power (PWR) object handle

14.2.5.5 PWR\_Handle PWR\_init (void \* pMemory, const size\_t numBytes)

Initializes the power (PWR) object handle.

#### Parameters:

- ← *pMemory* A pointer to the base address of the PWR registers
- ← *numBytes* The number of bytes allocated for the PWR object, bytes

## Returns:

The power (PWR) object handle

14.2.5.6 void PWR\_setLowPowerMode (PWR\_Handle pwrHandle, const PWR LowPowerMode e lowPowerMode)

Sets the low power mode.

## Parameters:

- ← *pwrHandle* The power (PWR) object handle
- ← *lowPowerMode* The low power mode
- 14.2.5.7 void PWR\_setNumStandByClocks (PWR\_Handle pwrHandle, const PWR\_NumStandByClocks\_e numClkCycles)

Sets the number of standby clock cycles.

- ← *pwrHandle* The power (PWR) object handle
- ← *numClkCycles* The number of standby clock cycles

# 15 Serial Communications Interface (SCI)

Introduction	235
API Functions	235

# 15.1 Introduction

The Serial Communication Interface (SCI) API provides a set of functions for configuring and using the SCI peripheral(s) on this device.

This driver is contained in f2802x0\_common/source/sci.c, with f2802x0\_common/include/sci.h containing the API definitions for use by applications.

# 15.2 SCI

## **Data Structures**

■ SCI Obj

## **Defines**

- SCI SCICCR CHAR LENGTH BITS
- SCI\_SCICCR\_LB\_ENA\_BITS
- SCI SCICCR MODE BITS
- SCI SCICCR PARITY BITS
- SCI SCICCR PARITY ENA BITS
- SCI\_SCICCR\_STOP\_BITS
- SCI\_SCICTL1\_RESET\_BITS
- SCI SCICTL1 RX ERR INT ENA BITS
- SCI\_SCICTL1\_RXENA\_BITS
- SCI SCICTL1 SLEEP BITS
- SCI\_SCICTL1\_TXENA\_BITS
- SCI SCICTL1 TXWAKE BITS
- SCI\_SCICTL2\_RX\_INT\_ENA\_BITS
- SCI\_SCICTL2\_TX\_INT\_ENA\_BITS
- SCI SCICTL2 TXEMPTY BITS
- SCI\_SCICTL2\_TXRDY\_BITS
- SCI SCIFFCT ABD BITS
- SCI\_SCIFFCT\_ABDCLR\_BITS
- SCI SCIFFCT CDC BITS
- SCI\_SCIFFCT\_DELAY\_BITS
- SCI\_SCIFFRX\_FIFO\_OVF\_BITS

- SCI SCIFFRX FIFO OVFCLR BITS
- SCI\_SCIFFRX\_FIFO\_RESET\_BITS
- SCI\_SCIFFRX\_FIFO\_ST\_BITS
- SCI SCIFFRX IENA BITS
- SCI SCIFFRX IL BITS
- SCI SCIFFRX INT BITS
- SCI\_SCIFFRX\_INTCLR\_BITS
- SCI SCIFFTX CHAN RESET BITS
- SCI\_SCIFFTX\_FIFO\_ENA\_BITS
- SCI\_SCIFFTX\_FIFO\_RESET\_BITS
- SCI\_SCIFFTX\_FIFO\_ST\_BITS
- SCI SCIFFTX IENA BITS
- SCI SCIFFTX IL BITS
- SCI\_SCIFFTX\_INT\_BITS
- SCI\_SCIFFTX\_INTCLR\_BITS
- SCI\_SCIRXST\_BRKDT\_BITS
- SCI\_SCIRXST\_FE\_BITS
- SCI\_SCIRXST\_OE\_BITS
- SCI SCIRXST PE BITS
- SCI SCIRXST RXERROR BITS
- SCI\_SCIRXST\_RXRDY\_BITS
- SCI\_SCIRXST\_RXWAKE\_BITS
- SCIA BASE\_ADDR

## **Enumerations**

- SCI\_BaudRate\_e
- SCI CharLength e
- SCI\_FifoLevel\_e
- SCI FifoStatus e
- SCI Mode e
- SCI NumStopBits e
- SCI\_Parity\_e
- SCI\_Priority\_e

## **Functions**

- void SCI\_clearAutoBaudDetect (SCI\_Handle sciHandle)
- void SCI\_clearRxFifoInt (SCI\_Handle sciHandle)
- void SCI clearRxFifoOvf (SCI Handle sciHandle)
- void SCI clearTxFifoInt (SCI Handle sciHandle)
- void SCI\_disable (SCI\_Handle sciHandle)
- void SCI disableAutoBaudAlign (SCI Handle sciHandle)
- void SCI\_disableFifoEnh (SCI\_Handle sciHandle)

- void SCI\_disableLoopBack (SCI\_Handle sciHandle)
- void SCI\_disableParity (SCI\_Handle sciHandle)
- void SCI\_disableRx (SCI\_Handle sciHandle)
- void SCI\_disableRxErrorInt (SCI\_Handle sciHandle)
- void SCI\_disableRxFifoInt (SCI\_Handle sciHandle)
- void SCI\_disableRxInt (SCI\_Handle sciHandle)
- void SCI\_disableSleep (SCI\_Handle sciHandle)
- void SCI\_disableTx (SCI\_Handle sciHandle)
- void SCI\_disableTxFifoInt (SCI\_Handle sciHandle)
- void SCI\_disableTxInt (SCI\_Handle sciHandle)
- void SCI disableTxWake (SCI Handle sciHandle)
- void SCI enable (SCI Handle sciHandle)
- void SCI\_enableAutoBaudAlign (SCI\_Handle sciHandle)
- void SCI\_enableFifoEnh (SCI\_Handle sciHandle)
- void SCI enableLoopBack (SCI Handle sciHandle)
- void SCI enableParity (SCI Handle sciHandle)
- void SCI\_enableRx (SCI\_Handle sciHandle)
- void SCI\_enableRxErrorInt (SCI\_Handle sciHandle)
- void SCI\_enableRxFifoInt (SCI\_Handle sciHandle)
- void SCI\_enableRxInt (SCI\_Handle sciHandle)
- void SCI\_enableSleep (SCI\_Handle sciHandle)
- void SCI enableTx (SCI Handle sciHandle)
- void SCI enableTxFifoInt (SCI Handle sciHandle)
- void SCI\_enableTxInt (SCI\_Handle sciHandle)
- void SCI enableTxWake (SCI Handle sciHandle)
- uint16 t SCI getData (SCI Handle sciHandle)
- uint16\_t SCI\_getDataBlocking (SCI\_Handle sciHandle)
- uint16 t SCI getDataNonBlocking (SCI Handle sciHandle, uint16 t \*success)
- SCI FifoStatus e SCI getRxFifoStatus (SCI Handle sciHandle)
- SCI FifoStatus e SCI getTxFifoStatus (SCI Handle sciHandle)
- SCI Handle SCI init (void \*pMemory, const size t numBytes)
- bool t SCI isRxDataReady (SCI Handle sciHandle)
- bool\_t SCI\_isTxReady (SCI\_Handle sciHandle)
- void SCI putData (SCI Handle sciHandle, const uint16 t data)
- void SCI\_putDataBlocking (SCI\_Handle sciHandle, uint16\_t data)
- uint16 t SCI putDataNonBlocking (SCI Handle sciHandle, uint16 t data)
- void SCI reset (SCI Handle sciHandle)
- void SCI resetChannels (SCI Handle sciHandle)
- void SCI resetRxFifo (SCI Handle sciHandle)
- void SCI resetTxFifo (SCI Handle sciHandle)
- void SCI\_setBaudRate (SCI\_Handle sciHandle, const SCI\_BaudRate\_e baudRate)
- void SCI setCharLength (SCI Handle sciHandle, const SCI CharLength e charLength)
- void SCI\_setMode (SCI\_Handle sciHandle, const SCI\_Mode\_e mode)
- void SCI\_setNumStopBits (SCI\_Handle sciHandle, const SCI\_NumStopBits\_e numBits)
- void SCI setParity (SCI Handle sciHandle, const SCI Parity e parity)
- void SCI\_setPriority (SCI\_Handle sciHandle, const SCI\_Priority\_e priority)

- void SCI setRxFifoIntLevel (SCI Handle sciHandle, const SCI FifoLevel e fifoLevel)
- void SCI\_setTxDelay (SCI\_Handle sciHandle, const uint8\_t delay)
- void SCI\_setTxFifoIntLevel (SCI\_Handle sciHandle, const SCI\_FifoLevel\_e fifoLevel)

## 15.2.1 Data Structure Documentation

## 15.2.1.1 \_SCI\_Obj\_

#### **Definition:**

```
typedef struct
    uint16_t SCICCR;
    uint16_t SCICTL1;
    uint16_t SCIHBAUD;
    uint16_t SCILBAUD;
    uint16_t SCICTL2;
    uint16_t SCIRXST;
    uint16_t SCIRXEMU;
    uint16 t SCIRXBUF;
    uint16_t rsvd_1;
    uint16 t SCITXBUF;
    uint16_t SCIFFTX;
    uint16_t SCIFFRX;
    uint16_t SCIFFCT;
    uint16_t rsvd_2[2];
    uint16_t SCIPRI;
_SCI_Obj_
```

## Members:

SCICCR SCI Configuration Control Register.

SCICTL1 SCI Control Register 1.

SCIHBAUD SCI Baud Register, High Bits.

**SCILBAUD** SCI Baud Register, Low Bits.

SCICTL2 SCI Control Register 2.

**SCIRXST** SCI Receive Status Register.

**SCIRXEMU** SCI Receive Emulation Data Buffer Register.

**SCIRXBUF** SCI Receive Data Buffer Register.

rsvd\_1 Reserved.

SCITXBUF SCI Transmit Data Buffer Register.

**SCIFFTX** SCI FIFO Transmit Register.

SCIFFRX SCI FIFO Receive Register.

SCIFFCT SCI FIFO Control Register.

rsvd 2 Reserved.

SCIPRI SCI Priority Register.

#### **Description:**

Defines the serial communications interface (SCI) object.

## 15.2.2 Define Documentation

## 15.2.2.1 SCI\_SCICCR\_CHAR\_LENGTH\_BITS

## **Definition:**

#define SCI\_SCICCR\_CHAR\_LENGTH\_BITS

## **Description:**

Defines the location of the SCICHAR2-0 bits in the SCICCR register.

## 15.2.2.2 SCI\_SCICCR\_LB\_ENA\_BITS

## **Definition:**

#define SCI\_SCICCR\_LB\_ENA\_BITS

## **Description:**

Defines the location of the LOOP BACK ENA bits in the SCICCR register.

## 15.2.2.3 SCI SCICCR MODE BITS

#### **Definition:**

#define SCI\_SCICCR\_MODE\_BITS

## **Description:**

Defines the location of the ADDR/IDLE MODE bits in the SCICCR register.

# 15.2.2.4 SCI\_SCICCR\_PARITY\_BITS

#### **Definition:**

#define SCI\_SCICCR\_PARITY\_BITS

## **Description:**

Defines the location of the EVEN/ODD PARITY bits in the SCICCR register.

## 15.2.2.5 SCI SCICCR PARITY ENA BITS

## **Definition:**

#define SCI\_SCICCR\_PARITY\_ENA\_BITS

## **Description:**

Defines the location of the PARITY ENABLE bits in the SCICCR register.

## 15.2.2.6 SCI\_SCICCR\_STOP\_BITS

#### **Definition:**

#define SCI\_SCICCR\_STOP\_BITS

#### **Description:**

Defines the location of the STOP bits in the SCICCR register.

## 15.2.2.7 SCI SCICTL1 RESET BITS

#### **Definition:**

#define SCI\_SCICTL1\_RESET\_BITS

## **Description:**

Defines the location of the SW RESET bits in the SCICTL1 register.

## 15.2.2.8 SCI\_SCICTL1\_RX\_ERR\_INT\_ENA\_BITS

#### **Definition:**

#define SCI\_SCICTL1\_RX\_ERR\_INT\_ENA\_BITS

#### **Description:**

Defines the location of the RX ERR INT ENA bits in the SCICTL1 register.

## 15.2.2.9 SCI SCICTL1 RXENA BITS

## **Definition:**

#define SCI\_SCICTL1\_RXENA\_BITS

## **Description:**

Defines the location of the RXENA bits in the SCICTL1 register.

## 15.2.2.10 SCI\_SCICTL1\_SLEEP\_BITS

## **Definition:**

#define SCI\_SCICTL1\_SLEEP\_BITS

## **Description:**

Defines the location of the SLEEP bits in the SCICTL1 register.

# 15.2.2.11 SCI\_SCICTL1\_TXENA\_BITS

#### **Definition:**

#define SCI\_SCICTL1\_TXENA\_BITS

## **Description:**

Defines the location of the TXENA bits in the SCICTL1 register.

## 15.2.2.12 SCI\_SCICTL1\_TXWAKE\_BITS

#### **Definition:**

#define SCI\_SCICTL1\_TXWAKE\_BITS

#### **Description:**

Defines the location of the TXWAKE bits in the SCICTL1 register.

## 15.2.2.13 SCI\_SCICTL2\_RX\_INT\_ENA\_BITS

#### **Definition:**

#define SCI\_SCICTL2\_RX\_INT\_ENA\_BITS

## **Description:**

Defines the location of the RX/BK INT ENA bits in the SCICTL2 register.

## 15.2.2.14 SCI SCICTL2 TX INT ENA BITS

#### **Definition:**

#define SCI\_SCICTL2\_TX\_INT\_ENA\_BITS

## **Description:**

Defines the location of the TX INT ENA bits in the SCICTL2 register.

## 15.2.2.15 SCI\_SCICTL2\_TXEMPTY\_BITS

## **Definition:**

#define SCI\_SCICTL2\_TXEMPTY\_BITS

## **Description:**

Defines the location of the TX EMPTY bits in the SCICTL2 register.

## 15.2.2.16 SCI\_SCICTL2\_TXRDY\_BITS

## **Definition:**

#define SCI\_SCICTL2\_TXRDY\_BITS

## **Description:**

Defines the location of the RX EMPTY bits in the SCICTL2 register.

## 15.2.2.17 SCI SCIFFCT ABD BITS

## **Definition:**

#define SCI\_SCIFFCT\_ABD\_BITS

## **Description:**

Defines the location of the ABD bits in the SCIFFCT register.

# 15.2.2.18 SCI\_SCIFFCT\_ABDCLR\_BITS

#### **Definition:**

#define SCI\_SCIFFCT\_ABDCLR\_BITS

#### **Description:**

Defines the location of the ABD CLR bits in the SCIFFCT register.

## 15.2.2.19 SCI\_SCIFFCT\_CDC\_BITS

#### **Definition:**

#define SCI\_SCIFFCT\_CDC\_BITS

## **Description:**

Defines the location of the CDC bits in the SCIFFCT register.

## 15.2.2.20 SCI SCIFFCT DELAY BITS

#### **Definition:**

#define SCI\_SCIFFCT\_DELAY\_BITS

## **Description:**

Defines the location of the FFTXDLY7-0 bits in the SCIFFCT register.

## 15.2.2.21 SCI\_SCIFFRX\_FIFO\_OVF\_BITS

#### **Definition:**

#define SCI\_SCIFFRX\_FIFO\_OVF\_BITS

## **Description:**

Defines the location of the RXFFOVF bits in the SCIFFRX register.

## 15.2.2.22 SCI\_SCIFFRX\_FIFO\_OVFCLR\_BITS

## **Definition:**

#define SCI\_SCIFFRX\_FIFO\_OVFCLR\_BITS

## **Description:**

Defines the location of the RXFFOVF CLR bits in the SCIFFRX register.

# 15.2.2.23 SCI SCIFFRX\_FIFO\_RESET\_BITS

#### **Definition:**

#define SCI\_SCIFFRX\_FIFO\_RESET\_BITS

## **Description:**

Defines the location of the RXFIFO Reset bits in the SCIFFRX register.

## 15.2.2.24 SCI\_SCIFFRX\_FIFO\_ST\_BITS

#### **Definition:**

#define SCI\_SCIFFRX\_FIFO\_ST\_BITS

## **Description:**

Defines the location of the RXFFST4-0 bits in the SCIFFRX register.

## 15.2.2.25 SCI SCIFFRX IENA BITS

#### **Definition:**

#define SCI\_SCIFFRX\_IENA\_BITS

## **Description:**

Defines the location of the RXFFIENA bits in the SCIFFRX register.

## 15.2.2.26 SCI SCIFFRX IL BITS

#### **Definition:**

#define SCI\_SCIFFRX\_IL\_BITS

## **Description:**

Defines the location of the RXFFIL4-0 bits in the SCIFFRX register.

## 15.2.2.27 SCI\_SCIFFRX\_INT\_BITS

## **Definition:**

#define SCI\_SCIFFRX\_INT\_BITS

## **Description:**

Defines the location of the RXFFINT flag bits in the SCIFFRX register.

## 15.2.2.28 SCI SCIFFRX INTCLR BITS

## **Definition:**

#define SCI\_SCIFFRX\_INTCLR\_BITS

## **Description:**

Defines the location of the RXFFINT CLR bits in the SCIFFRX register.

## 15.2.2.29 SCI SCIFFTX CHAN RESET BITS

## **Definition:**

#define SCI\_SCIFFTX\_CHAN\_RESET\_BITS

## **Description:**

Defines the location of the SCIRST bits in the SCIFFTX register.

## 15.2.2.30 SCI SCIFFTX FIFO ENA BITS

#### **Definition:**

#define SCI\_SCIFFTX\_FIFO\_ENA\_BITS

#### **Description:**

Defines the location of the SCIFFENA bits in the SCIFFTX register.

## 15.2.2.31 SCI SCIFFTX FIFO RESET BITS

#### **Definition:**

#define SCI\_SCIFFTX\_FIFO\_RESET\_BITS

## **Description:**

Defines the location of the TXFIFO Reset bits in the SCIFFTX register.

## 15.2.2.32 SCI\_SCIFFTX\_FIFO\_ST\_BITS

#### **Definition:**

#define SCI\_SCIFFTX\_FIFO\_ST\_BITS

#### **Description:**

Defines the location of the TXFFST4-0 bits in the SCIFFTX register.

## 15.2.2.33 SCI SCIFFTX IENA BITS

## **Definition:**

#define SCI\_SCIFFTX\_IENA\_BITS

## **Description:**

Defines the location of the TXFFIENA bits in the SCIFFTX register.

## 15.2.2.34 SCI SCIFFTX IL BITS

## **Definition:**

#define SCI\_SCIFFTX\_IL\_BITS

## **Description:**

Defines the location of the TXFFIL4-0 bits in the SCIFFTX register.

# 15.2.2.35 SCI\_SCIFFTX\_INT\_BITS

#### **Definition:**

#define SCI\_SCIFFTX\_INT\_BITS

## **Description:**

Defines the location of the TXFFINT flag bits in the SCIFFTX register.

## 15.2.2.36 SCI\_SCIFFTX\_INTCLR\_BITS

## **Definition:**

#define SCI\_SCIFFTX\_INTCLR\_BITS

## **Description:**

Defines the location of the TXFFINT CLR bits in the SCIFFTX register.

## 15.2.2.37 SCI SCIRXST BRKDT BITS

#### **Definition:**

#define SCI\_SCIRXST\_BRKDT\_BITS

## **Description:**

Defines the location of the BRKDT bits in the SCIRXST register.

## 15.2.2.38 SCI SCIRXST FE BITS

#### **Definition:**

#define SCI\_SCIRXST\_FE\_BITS

## **Description:**

Defines the location of the FE bits in the SCIRXST register.

## 15.2.2.39 SCI SCIRXST OE BITS

## **Definition:**

#define SCI\_SCIRXST\_OE\_BITS

## **Description:**

Defines the location of the OE bits in the SCIRXST register.

## 15.2.2.40 SCI\_SCIRXST\_PE\_BITS

## **Definition:**

#define SCI\_SCIRXST\_PE\_BITS

## **Description:**

Defines the location of the PE bits in the SCIRXST register.

## 15.2.2.41 SCI SCIRXST RXERROR BITS

## **Definition:**

#define SCI\_SCIRXST\_RXERROR\_BITS

## **Description:**

Defines the location of the RX ERROR bits in the SCIRXST register.

## 15.2.2.42 SCI\_SCIRXST\_RXRDY\_BITS

## **Definition:**

#define SCI\_SCIRXST\_RXRDY\_BITS

## **Description:**

Defines the location of the RXRDY bits in the SCIRXST register.

## 15.2.2.43 SCI\_SCIRXST\_RXWAKE\_BITS

## **Definition:**

#define SCI\_SCIRXST\_RXWAKE\_BITS

## **Description:**

Defines the location of the RXWAKE bits in the SCIRXST register.

## 15.2.2.44 SCIA BASE ADDR

#### **Definition:**

#define SCIA\_BASE\_ADDR

## **Description:**

Defines the base address of the serial communications interface (SCI) A registers.

# 15.2.3 Typedef Documentation

## 15.2.3.1 SCI Handle

#### **Definition:**

typedef struct SCI\_Obj \*SCI\_Handle

## **Description:**

Defines the serial communications interface (SCI) handle.

## 15.2.3.2 SCI Obj

#### **Definition:**

typedef struct \_SCI\_Obj\_ SCI\_Obj

## **Description:**

Defines the serial communications interface (SCI) object.

## 15.2.4 Enumeration Documentation

## 15.2.4.1 SCI BaudRate e

## **Description:**

Enumeration to define the serial communications interface (SCI) baud rates. This enumeration assume a device clock of 60Mhz and a LSPCLK of 15MHz.

#### **Enumerators:**

```
SCI_BaudRate_9_6_kBaud Denotes 9.6 kBaud.

SCI_BaudRate_19_2_kBaud Denotes 19.2 kBaud.

SCI_BaudRate_57_6_kBaud Denotes 57.6 kBaud.

SCI_BaudRate_115_2_kBaud Denotes 115.2 kBaud.
```

## 15.2.4.2 SCI CharLength e

## **Description:**

Enumeration to define the serial communications interface (SCI) character lengths.

#### **Enumerators:**

```
    SCI_CharLength_1_Bit
    Denotes a character length of 1 bit.
    SCI_CharLength_2_Bits
    Denotes a character length of 2 bits.
    SCI_CharLength_3_Bits
    Denotes a character length of 3 bits.
    SCI_CharLength_4_Bits
    Denotes a character length of 4 bits.
    SCI_CharLength_5_Bits
    Denotes a character length of 5 bits.
    SCI_CharLength_6_Bits
    Denotes a character length of 6 bits.
    SCI_CharLength_7_Bits
    Denotes a character length of 7 bits.
    SCI_CharLength_8_Bits
    Denotes a character length of 8 bits.
```

## 15.2.4.3 SCI\_FifoLevel\_e

## **Description:**

Enumeration to define the serial communications interface (SCI) FIFO level.

#### **Enumerators:**

```
    SCI_FifoLevel_Empty Denotes the fifo is empty.
    SCI_FifoLevel_1_Word Denotes the fifo contains 1 word.
    SCI_FifoLevel_2_Words Denotes the fifo contains 2 words.
    SCI_FifoLevel_3_Words Denotes the fifo contains 3 words.
    SCI_FifoLevel_4_Words Denotes the fifo contains 4 words.
```

## 15.2.4.4 SCI\_FifoStatus\_e

## **Description:**

Enumeration to define the serial communications interface (SCI) FIFO status.

## **Enumerators:**

SCI\_FifoStatus\_Empty Denotes the fifo is empty.

SCI\_FifoStatus\_1\_Word Denotes the fifo contains 1 word.

SCI\_FifoStatus\_2\_Words Denotes the fifo contains 2 words.

SCI\_FifoStatus\_3\_Words Denotes the fifo contains 3 words.

**SCI\_FifoStatus\_4\_Words** Denotes the fifo contains 4 words.

## 15.2.4.5 SCI Mode e

## **Description:**

Enumeration to define the serial communications interface (SCI) multiprocessor protocol mode.

#### **Enumerators:**

**SCI\_Mode\_IdleLine** Denotes idle-line mode protocol.

SCI\_Mode\_AddressBit Denotes address-bit mode protocol.

## 15.2.4.6 SCI NumStopBits e

## **Description:**

Enumeration to define the serial communications interface (SCI) number of stop bits.

#### **Enumerators:**

SCI\_NumStopBits\_One Denotes 1 stop bit.

SCI\_NumStopBits\_Two Denotes 2 stop bits.

## 15.2.4.7 SCI Parity e

#### **Description:**

Enumeration to define the serial communications interface (SCI) parity.

## **Enumerators:**

SCI\_Parity\_Odd Denotes odd parity.

SCI\_Parity\_Even Denotes even parity.

## 15.2.4.8 SCI Priority e

#### Description:

Enumeration to define the serial communications interface (SCI) emulation suspend priority.

#### **Enumerators:**

SCI\_Priority\_Immediate Denotes an immediate stop.

**SCI\_Priority\_FreeRun** Denotes free running.

**SCI\_Priority\_AfterRxRxSeq** Denotes that a stop after the current receive/transmit sequence.

## 15.2.5 Function Documentation

## 15.2.5.1 SCI clearAutoBaudDetect

Clears the auto baud detect mode.

## Prototype:

void

SCI clearAutoBaudDetect (SCI Handle sciHandle)

## Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.2 void SCI clearRxFifoInt (SCI Handle sciHandle)

Clears the Rx FIFO interrupt flag.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.3 void SCI\_clearRxFifoOvf (SCI\_Handle sciHandle)

Clears the Rx FIFO overflow flag.

#### **Parameters:**

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.4 void SCI\_clearTxFifoInt (SCI\_Handle sciHandle)

Clears the Tx FIFO interrupt flag.

## Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.5 void SCI disable (SCI Handle sciHandle)

Disables the serial communications interface (SCI) interrupt.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.6 void SCI disableAutoBaudAlign (SCI Handle sciHandle)

Disable the serial communications interface (SCI) auto baud alignment.

#### **Parameters:**

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.7 void SCI disableFifoEnh (SCI Handle sciHandle)

Disables the serial communications interface (SCI) FIFO enhancements.

## Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.8 void SCI disableLoopBack (SCI Handle sciHandle)

Disables the serial peripheral interface (SCI) loop back mode.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.9 void SCI\_disableParity (SCI\_Handle sciHandle)

Disable the parity.

#### Parameters:

← **sciHandle** The serial communications interface (SCI) object handle

## 15.2.5.10 void SCI disableRx (SCI Handle sciHandle)

Disables the serial communications interface (SCI) master/slave receive mode.

## Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.11 void SCI disableRxErrorInt (SCI Handle sciHandle)

Disables the serial communications interface (SCI) receive error interrupt.

#### Parameters:

 $\leftarrow$  *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.12 void SCI disableRxFifoInt (SCI Handle sciHandle)

Disables the serial communications interface (SCI) receive FIFO interrupt.

#### **Parameters:**

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.13 void SCI disableRxInt (SCI Handle sciHandle)

Disables the serial communications interface (SCI) receive interrupt.

## Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.14 void SCI disableSleep (SCI Handle sciHandle)

Disables the serial communications interface (SCI) sleep mode.

## Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.15 void SCI\_disableTx (SCI\_Handle sciHandle)

Disables the serial communications interface (SCI) master/slave transmit mode.

## Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.16 void SCI\_disableTxFifoInt (SCI\_Handle sciHandle)

Disables the serial communications interface (SCI) transmit FIFO interrupt.

## Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.17 void SCI disableTxInt (SCI Handle sciHandle)

Disables the serial communications interface (SCI) transmit interrupt.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.18 void SCI disableTxWake (SCI Handle sciHandle)

Disables the serial communications interface (SCI) wakeup method.

## Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.19 void SCI enable (SCI Handle sciHandle)

Enables the serial communications interface (SCI).

## Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.20 void SCI enableAutoBaudAlign (SCI Handle sciHandle)

Enable the serial communications interface (SCI) auto baud alignment.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.21 void SCI enableFifoEnh (SCI Handle sciHandle)

Enables the serial communications interface (SCI) FIFO enhancements.

#### Parameters:

← **sciHandle** The serial communications interface (SCI) object handle

## 15.2.5.22 void SCI enableLoopBack (SCI Handle sciHandle)

Enables the serial peripheral interface (SCI) loop back mode.

## Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.23 void SCI enableParity (SCI Handle sciHandle)

Enables the serial peripheral interface (SCI) parity.

#### Parameters:

 $\leftarrow$  *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.24 void SCI enableRx (SCI Handle sciHandle)

Enables the serial peripheral interface (SCI) receiver.

#### **Parameters:**

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.25 void SCI enableRxErrorInt (SCI Handle sciHandle)

Enables the serial communications interface (SCI) receive error interrupt.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.26 void SCI enableRxFifoInt (SCI Handle sciHandle)

Enables the serial communications interface (SCI) receive FIFO interrupt.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.27 void SCI\_enableRxInt (SCI\_Handle sciHandle)

Enables the serial communications interface (SCI) receive interrupt.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.28 void SCI enableSleep (SCI Handle sciHandle)

Enables the serial communications interface (SCI) sleep mode.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

#### 15.2.5.29 void SCI enableTx (SCI Handle sciHandle)

Enables the serial communications interface (SCI) masater/slave transmit mode.

#### Parameters:

 $\leftarrow$  *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.30 void SCI enableTxFifoInt (SCI Handle sciHandle)

Enables the serial communications interface (SCI) transmit FIFO interrupt.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.31 void SCI enableTxInt (SCI Handle sciHandle)

Enables the serial communications interface (SCI) transmit interrupt.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.32 void SCI enableTxWake (SCI Handle sciHandle)

Enables the serial communications interface (SCI) wakeup method.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.33 uint16 t SCI getData (SCI Handle sciHandle) [inline]

Reads data from the serial communications interface (SCI).

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

#### Returns:

The received data value

## 15.2.5.34 uint16 t SCI getDataBlocking (SCI Handle sciHandle)

Gets data from the serial communications interface (Blocking).

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

#### Returns:

Data from the serial peripheral

## 15.2.5.35 uint16 t SCI getDataNonBlocking (SCI Handle sciHandle, uint16 t \* success)

Read data from the serial communications interface (Non-Blocking).

#### Parameters:

- ← *sciHandle* The serial communications interface (SCI) object handle
- ightarrow **success** Pointer to a variable which will house whether the read was successful or not (true on success)

#### Returns:

Data if successful, or NULL if no characters

## 15.2.5.36 SCI FifoStatus e SCI getRxFifoStatus (SCI Handle sciHandle)

Gets the serial communications interface (SCI) receive FIFO status.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

#### Returns:

The receive FIFO status

## 15.2.5.37 SCI\_FifoStatus\_e SCI\_getTxFifoStatus (SCI\_Handle sciHandle)

Gets the serial communications interface (SCI) transmit FIFO status.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

#### Returns:

The transmit FIFO status

## 15.2.5.38 SCI Handle SCI init (void \* pMemory, const size t numBytes)

Initializes the serial communications interface (SCI) object handle.

#### Parameters:

- ← *pMemory* A pointer to the base address of the SCI registers
- ← *numBytes* The number of bytes allocated for the SCI object, bytes

#### Returns:

The serial communications interface (SCI) object handle

15.2.5.39 bool t SCI isRxDataReady (SCI Handle sciHandle) [inline]

Determines if the serial communications interface (SCI) has receive data ready.

#### **Parameters:**

← *sciHandle* The serial communications interface (SCI) object handle

#### Returns:

The receive data status

15.2.5.40 bool\_t SCI\_isTxReady (SCI\_Handle sciHandle) [inline]

Determines if the serial communications interface (SCI) is ready to transmit.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

#### Returns:

The transmit status

15.2.5.41 void SCI\_putData (SCI\_Handle sciHandle, const uint16\_t data) [inline]

Writes data to the serial communications interface (SCI).

#### Parameters.

- ← *sciHandle* The serial communications interface (SCI) object handle
- ← data The data value

15.2.5.42 void SCI putDataBlocking (SCI Handle sciHandle, uint16 t data)

Writes data to the serial communications interface (Blocking).

#### Parameters:

- ← *sciHandle* The serial communications interface (SCI) object handle
- ← data The data value

15.2.5.43 uint16 t SCI putDataNonBlocking (SCI Handle sciHandle, uint16 t data)

Writes data to the serial communications interface (Non-Blocking).

#### Parameters:

- ← **sciHandle** The serial communications interface (SCI) object handle
- $\leftarrow$  data The data value

#### Returns:

True on successful write, false if no space is available in the transmit buffer

## 15.2.5.44 void SCI reset (SCI Handle sciHandle)

Resets the serial communications interface (SCI).

#### Parameters:

← **sciHandle** The serial communication interface (SCI) object handle

## 15.2.5.45 void SCI resetChannels (SCI Handle sciHandle)

Resets the serial communications interface (SCI) transmit and receive channels.

#### Parameters:

← *sciHandle* The serial communication interface (SCI) object handle

## 15.2.5.46 void SCI\_resetRxFifo (SCI\_Handle sciHandle)

Resets the serial communications interface (SCI) receive FIFO.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

## 15.2.5.47 void SCI\_resetTxFifo (SCI\_Handle sciHandle)

Resets the serial communications interface (SCI) transmit FIFO.

#### Parameters:

← *sciHandle* The serial communications interface (SCI) object handle

# 15.2.5.48 void SCI\_setBaudRate (SCI\_Handle sciHandle, const SCI\_BaudRate\_e baudRate)

Sets the serial communications interface (SCI) baud rate.

#### Parameters:

- ← *sciHandle* The serial communications interface (SCI) object handle
- ← *baudRate* The baud rate

# 15.2.5.49 void SCI\_setCharLength (SCI\_Handle sciHandle, const SCI\_CharLength\_e charLength)

Sets the serial communications interface (SCI) character length.

- ← *sciHandle* The serial communications interface (SCI) object handle
- ← *charLength* The character length

15.2.5.50 void SCI setMode (SCI Handle sciHandle, const SCI Mode e mode)

Sets the serial communications interface (SCI) miltprocessor mode.

#### **Parameters:**

- ← *sciHandle* The serial communications interface (SCI) object handle
- ← *mode* The multiprocessor mode

# 15.2.5.51 void SCI\_setNumStopBits (SCI\_Handle sciHandle, const SCI\_NumStopBits\_e numBits)

Sets the serial communications interface (SCI) number of stop bits.

#### Parameters:

- ← *sciHandle* The serial communications interface (SCI) object handle
- ← *numBits* The number of bits

## 15.2.5.52 void SCI\_setParity (SCI\_Handle sciHandle, const SCI\_Parity\_e parity)

Sets the serial communications interface (SCI) parity.

#### Parameters:

- ← *sciHandle* The serial communications interface (SCI) object handle
- ← *parity* The parity

## 15.2.5.53 void SCI\_setPriority (SCI\_Handle sciHandle, const SCI\_Priority\_e priority)

Sets the serial communications interface (SCI) priority.

#### Parameters:

- ← **sciHandle** The serial communications interface (SCI) object handle
- ← *priority* The priority

# 15.2.5.54 void SCI\_setRxFifoIntLevel (SCI\_Handle sciHandle, const SCI\_FifoLevel\_e fifoLevel)

Sets the serial communications interface (SCI) receive FIFO level for generating an interrupt.

- ← *sciHandle* The serial communications interface (SCI) object handle
- ← *fifoLevel* The FIFO level

## 15.2.5.55 void SCI\_setTxDelay (SCI\_Handle sciHandle, const uint8\_t delay)

Sets the serial communications interface (SCI) transmit delay.

#### Parameters:

- ← *sciHandle* The serial communications interface (SCI) object handle
- ← *delay* The transmit delay

# 15.2.5.56 void SCI\_setTxFifoIntLevel (SCI\_Handle sciHandle, const SCI\_FifoLevel\_e fifoLevel)

Sets the serial communications interface (SCI) transmit FIFO level for generating an interrupt.

- ← *sciHandle* The serial communications interface (SCI) object handle
- $\leftarrow$  *fifoLevel* The FIFO level

# 16 Serial Peripheral Interface (SPI)

Introduction	. 26
API Functions	26

## 16.1 Introduction

The Serial Peripheral Interface (SPI) API provides a set of functions for configuring and using the device's SPI peripheral(s).

This driver is contained in  $f2802x0\_common/source/spi.c$ , with  $f2802x0\_common/include/spi.h$  containing the API definitions for use by applications.

## 16.2 SPI

## **Defines**

- SPI SPICCR CHAR LENGTH BITS
- SPI SPICCR CLKPOL BITS
- SPI\_SPICCR\_RESET\_BITS
- SPI\_SPICCR\_SPILBK\_BITS
- SPI\_SPICTL\_CLK\_PHASE\_BITS
- SPI SPICTL INT ENA BITS
- SPI SPICTL MODE BITS
- SPI SPICTL OVRRUN INT ENA BITS
- SPI\_SPICTL\_TALK\_BITS
- SPI SPIFFRX FIFO OVF BITS
- SPI\_SPIFFRX\_FIFO\_OVFCLR\_BITS
- SPI SPIFFRX FIFO RESET BITS
- SPI SPIFFRX FIFO ST BITS
- SPI SPIFFRX IENA BITS
- SPI\_SPIFFRX\_IL\_BITS
- SPI SPIFFRX INT BITS
- SPI\_SPIFFRX\_INTCLR\_BITS
- SPI SPIFFTX CHAN RESET BITS
- SPI SPIFFTX FIFO ENA BITS
- SPI\_SPIFFTX\_FIFO\_RESET\_BITS
- SPI\_SPIFFTX\_FIFO\_ST\_BITS
- SPI SPIFFTX IENA BITS
- SPI\_SPIFFTX\_IL\_BITS
- SPI\_SPIFFTX\_INT\_BITS
- SPI\_SPIFFTX\_INTCLR\_BITS
- SPIA BASE ADDR

## **Enumerations**

- SPI BaudRate e
- SPI\_CharLength\_e
- SPI ClkPhase e
- SPI ClkPolarity e
- SPI FifoLevel e
- SPI FifoStatus e
- SPI\_Mode\_e
- SPI\_Priority\_e
- SPI\_SteInv\_e
- SPI\_TriWire\_e

## **Functions**

- void SPI clearRxFifoInt (SPI Handle spiHandle)
- void SPI clearRxFifoOvf (SPI Handle spiHandle)
- void SPI clearTxFifoInt (SPI Handle spiHandle)
- void SPI disable (SPI Handle spiHandle)
- void SPI\_disableChannels (SPI\_Handle spiHandle)
- void SPI disableInt (SPI Handle spiHandle)
- void SPI disableLoopBack (SPI Handle spiHandle)
- void SPI disableOverRunInt (SPI Handle spiHandle)
- void SPI disableRxFifo (SPI Handle spiHandle)
- void SPI disableRxFifoInt (SPI Handle spiHandle)
- void SPI disableTx (SPI Handle spiHandle)
- void SPI\_disableTxFifo (SPI\_Handle spiHandle)
- void SPI disableTxFifoEnh (SPI Handle spiHandle)
- void SPI disableTxFifoInt (SPI Handle spiHandle)
- void SPI enable (SPI Handle spiHandle)
- void SPI\_enableChannels (SPI\_Handle spiHandle)
- void SPI enableFifoEnh (SPI Handle spiHandle)
- void SPI\_enableInt (SPI\_Handle spiHandle)
- void SPI\_enableLoopBack (SPI\_Handle spiHandle)
- void SPI\_enableOverRunInt (SPI\_Handle spiHandle)
- void SPI enableRxFifo (SPI Handle spiHandle)
- void SPI\_enableRxFifoInt (SPI\_Handle spiHandle)
- void SPI enableTx (SPI Handle spiHandle)
- void SPI\_enableTxFifo (SPI\_Handle spiHandle)
- void SPI enableTxFifoInt (SPI Handle spiHandle)
- SPI\_FifoStatus\_e SPI\_getRxFifoStatus (SPI\_Handle spiHandle)
- SPI\_FifoStatus\_e SPI\_getTxFifoStatus (SPI\_Handle spiHandle)
- SPI Handle SPI init (void \*pMemory, const size t numBytes)
- uint16\_t SPI\_read (SPI\_Handle spiHandle)
- void SPI reset (SPI Handle spiHandle)

- void SPI resetChannels (SPI Handle spiHandle)
- void SPI\_resetRxFifo (SPI\_Handle spiHandle)
- void SPI\_resetTxFifo (SPI\_Handle spiHandle)
- void SPI\_setBaudRate (SPI\_Handle spiHandle, const SPI\_BaudRate\_e baudRate)
- void SPI\_setCharLength (SPI\_Handle spiHandle, const SPI\_CharLength\_e length)
- void SPI setClkPhase (SPI Handle spiHandle, const SPI ClkPhase e clkPhase)
- void SPI\_setClkPolarity (SPI\_Handle spiHandle, const SPI\_ClkPolarity\_e polarity)
- void SPI\_setMode (SPI\_Handle spiHandle, const SPI\_Mode\_e mode)
- void SPI\_setPriority (SPI\_Handle spiHandle, const SPI\_Priority\_e priority)
- void SPI\_setRxFifoIntLevel (SPI\_Handle spiHandle, const SPI\_FifoLevel\_e fifoLevel)
- void SPI setSteInv (SPI Handle spiHandle, const SPI SteInv e steinv)
- void SPI setTriWire (SPI Handle spiHandle, const SPI TriWire e triwire)
- void SPI setTxDelay (SPI Handle spiHandle, const uint8 t delay)
- void SPI\_setTxFifoIntLevel (SPI\_Handle spiHandle, const SPI\_FifoLevel\_e fifoLevel)
- void SPI\_write (SPI\_Handle spiHandle, const uint16\_t data)

## 16.2.1 Define Documentation

## 16.2.1.1 SPI SPICCR\_CHAR\_LENGTH\_BITS

#### **Definition:**

#define SPI\_SPICCR\_CHAR\_LENGTH\_BITS

#### Description:

Defines the location of the SPICHAR3-0 bits in the SPICCR register.

## 16.2.1.2 SPI SPICCR CLKPOL BITS

#### **Definition:**

#define SPI\_SPICCR\_CLKPOL\_BITS

#### **Description:**

Defines the location of the CLOCK POLARITY bits in the SPICCR register.

## 16.2.1.3 SPI SPICCR RESET BITS

#### **Definition:**

#define SPI\_SPICCR\_RESET\_BITS

#### **Description:**

Defines the location of the SPI SW Reset bits in the SPICCR register.

## 16.2.1.4 SPI SPICCR SPILBK BITS

#### **Definition:**

#define SPI\_SPICCR\_SPILBK\_BITS

#### **Description:**

Defines the location of the SPILBK bits in the SPICCR register.

## 16.2.1.5 SPI SPICTL CLK PHASE BITS

#### **Definition:**

#define SPI\_SPICTL\_CLK\_PHASE\_BITS

#### **Description:**

Defines the location of the CLOCK PHASE bits in the SPICTL register.

## 16.2.1.6 SPI SPICTL INT ENA BITS

#### **Definition:**

#define SPI\_SPICTL\_INT\_ENA\_BITS

#### **Description:**

Defines the location of the SPI INT ENA bits in the SPICTL register.

## 16.2.1.7 SPI\_SPICTL\_MODE\_BITS

#### **Definition:**

#define SPI\_SPICTL\_MODE\_BITS

#### **Description:**

Defines the location of the MASTER/SLAVE bits in the SPICTL register.

## 16.2.1.8 SPI SPICTL\_OVRRUN\_INT\_ENA\_BITS

### **Definition:**

#define SPI\_SPICTL\_OVRRUN\_INT\_ENA\_BITS

#### **Description:**

Defines the location of the OVERRUN INT ENA bits in the SPICTL register.

## 16.2.1.9 SPI SPICTL TALK BITS

#### **Definition:**

#define SPI\_SPICTL\_TALK\_BITS

#### **Description:**

Defines the location of the TALK bits in the SPICTL register.

## 16.2.1.10 SPI SPIFFRX FIFO OVF BITS

#### **Definition:**

#define SPI\_SPIFFRX\_FIFO\_OVF\_BITS

#### **Description:**

Defines the location of the RXFFOVF bits in the SPIFFRX register.

## 16.2.1.11 SPI SPIFFRX FIFO OVFCLR BITS

#### **Definition:**

#define SPI\_SPIFFRX\_FIFO\_OVFCLR\_BITS

#### **Description:**

Defines the location of the RXFFOVF CLR bits in the SPIFFRX register.

## 16.2.1.12 SPI SPIFFRX FIFO RESET BITS

#### **Definition:**

#define SPI\_SPIFFRX\_FIFO\_RESET\_BITS

#### **Description:**

Defines the location of the RXFIFO Reset bits in the SPIFFRX register.

## 16.2.1.13 SPI\_SPIFFRX\_FIFO\_ST\_BITS

## **Definition:**

#define SPI\_SPIFFRX\_FIFO\_ST\_BITS

#### **Description:**

Defines the location of the RXFFST4-0 bits in the SPIFFRX register.

## 16.2.1.14 SPI SPIFFRX IENA BITS

## **Definition:**

#define SPI\_SPIFFRX\_IENA\_BITS

#### **Description:**

Defines the location of the RXFFIENA bits in the SPIFFRX register.

## 16.2.1.15 SPI SPIFFRX IL BITS

#### **Definition:**

#define SPI\_SPIFFRX\_IL\_BITS

#### **Description:**

Defines the location of the RXFFIL4-0 bits in the SPIFFRX register.

## 16.2.1.16 SPI SPIFFRX INT BITS

#### **Definition:**

#define SPI\_SPIFFRX\_INT\_BITS

#### **Description:**

Defines the location of the RXFFINT CLR bits in the SPIFFRX register.

## 16.2.1.17 SPI SPIFFRX INTCLR BITS

#### **Definition:**

#define SPI\_SPIFFRX\_INTCLR\_BITS

#### **Description:**

Defines the location of the RXFFINT CLR bits in the SPIFFRX register.

## 16.2.1.18 SPI\_SPIFFTX\_CHAN\_RESET\_BITS

#### **Definition:**

#define SPI\_SPIFFTX\_CHAN\_RESET\_BITS

#### **Description:**

Defines the location of the SPIRST bits in the SPIFFTX register.

## 16.2.1.19 SPI\_SPIFFTX\_FIFO\_ENA\_BITS

#### **Definition:**

#define SPI\_SPIFFTX\_FIFO\_ENA\_BITS

#### **Description:**

Defines the location of the SPIFFENA bits in the SPIFFTX register.

## 16.2.1.20 SPI SPIFFTX\_FIFO\_RESET\_BITS

### **Definition:**

#define SPI\_SPIFFTX\_FIFO\_RESET\_BITS

#### **Description:**

Defines the location of the TXFIFO Reset bits in the SPIFFTX register.

## 16.2.1.21 SPI\_SPIFFTX\_FIFO\_ST\_BITS

#### **Definition:**

#define SPI\_SPIFFTX\_FIFO\_ST\_BITS

#### **Description:**

Defines the location of the TXFFST4-0 bits in the SPIFFTX register.

## 16.2.1.22 SPI SPIFFTX IENA BITS

#### **Definition:**

#define SPI\_SPIFFTX\_IENA\_BITS

## **Description:**

Defines the location of the TXFFIENA bits in the SPIFFTX register.

## 16.2.1.23 SPI SPIFFTX IL BITS

#### **Definition:**

#define SPI\_SPIFFTX\_IL\_BITS

#### **Description:**

Defines the location of the TXFFIL4-0 bits in the SPIFFTX register.

## 16.2.1.24 SPI SPIFFTX INT BITS

#### **Definition:**

#define SPI\_SPIFFTX\_INT\_BITS

#### **Description:**

Defines the location of the TXFFINT bits in the SPIFFTX register.

## 16.2.1.25 SPI SPIFFTX INTCLR BITS

#### **Definition:**

#define SPI\_SPIFFTX\_INTCLR\_BITS

### **Description:**

Defines the location of the TXFFINT CLR bits in the SPIFFTX register.

## 16.2.1.26 SPIA BASE ADDR

#### **Definition:**

#define SPIA\_BASE\_ADDR

## **Description:**

Defines the base address of the serial peripheral interface (SPI) A registers.

## 16.2.2 Typedef Documentation

## 16.2.2.1 SPI Handle

#### **Definition:**

typedef struct SPI\_Obj \*SPI\_Handle

### **Description:**

Defines the serial peripheral interface (SPI) handle.

## 16.2.3 Enumeration Documentation

## 16.2.3.1 SPI\_BaudRate\_e

#### **Description:**

Enumeration to define the serial peripheral interface (SPI) baud rates. These assume a LSCLK of 12.5MHz.

#### **Enumerators:**

```
SPI_BaudRate_500_KBaud Denotes 500 KBaud. SPI_BaudRate_1_MBaud Denotes 1 MBaud.
```

## 16.2.3.2 SPI CharLength e

#### **Description:**

Enumeration to define the serial peripheral interface (SPI) character lengths.

#### **Enumerators:**

```
SPI_CharLength_1_Bit Denotes a character length of 1 bit.
SPI CharLength 2 Bits Denotes a character length of 2 bits.
SPI_CharLength_3_Bits Denotes a character length of 3 bits.
SPI CharLength 4 Bits Denotes a character length of 4 bits.
SPI_CharLength_5_Bits Denotes a character length of 5 bits.
SPI CharLength 6 Bits Denotes a character length of 6 bits.
SPI_CharLength_7_Bits Denotes a character length of 7 bits.
SPI_CharLength_8_Bits Denotes a character length of 8 bits.
SPI_CharLength_9_Bits Denotes a character length of 9 bits.
SPI_CharLength_10_Bits Denotes a character length of 10 bits.
SPI_CharLength_11_Bits Denotes a character length of 11 bits.
SPI_CharLength_12_Bits Denotes a character length of 12 bits.
SPI CharLength 13 Bits Denotes a character length of 13 bits.
SPI CharLength 14 Bits Denotes a character length of 14 bits.
SPI_CharLength_15_Bits Denotes a character length of 15 bits.
SPI_CharLength_16_Bits Denotes a character length of 16 bits.
```

## 16.2.3.3 SPI\_ClkPhase\_e

#### **Description:**

Enumeration to define the serial peripheral interface (SPI) clock phase.

#### **Enumerators:**

```
SPI_CIkPhase_Normal Denotes a normal clock scheme. SPI_CIkPhase_Delayed Denotes that the SPICLK signal is delayed by one half-cycle.
```

## 16.2.3.4 SPI ClkPolarity e

## **Description:**

Enumeration to define the serial peripheral interface (SPI) clock polarity for the input and output data.

#### **Enumerators:**

**SPI\_CIkPolarity\_OutputRisingEdge\_InputFallingEdge** Denotes that the tx data is output on the rising edge, the rx data is latched on the falling edge.

**SPI\_CIkPolarity\_OutputFallingEdge\_InputRisingEdge** Denotes that the tx data is output on the falling edge, the rx data is latched on the rising edge.

## 16.2.3.5 SPI FifoLevel e

#### **Description:**

Enumeration to define the serial peripheral interface (SPI) FIFO level.

#### **Enumerators:**

```
SPI_FifoLevel_Empty Denotes the fifo is empty.
SPI_FifoLevel_1_Word Denotes the fifo contains 1 word.
SPI_FifoLevel_2_Words Denotes the fifo contains 2 words.
SPI_FifoLevel_3_Words Denotes the fifo contains 3 words.
SPI_FifoLevel_4_Words Denotes the fifo contains 4 words.
```

## 16.2.3.6 SPI FifoStatus e

#### **Description:**

Enumeration to define the serial peripheral interface (SPI) FIFO status.

#### **Enumerators:**

```
SPI_FifoStatus_Empty Denotes the fifo is empty.
SPI_FifoStatus_1_Word Denotes the fifo contains 1 word.
SPI_FifoStatus_2_Words Denotes the fifo contains 2 words.
SPI_FifoStatus_3_Words Denotes the fifo contains 3 words.
SPI_FifoStatus_4_Words Denotes the fifo contains 4 words.
```

## 16.2.3.7 SPI Mode e

## **Description:**

Enumeration to define the serial peripheral interface (SPI) network mode control.

#### **Enumerators:**

```
SPI_Mode_Slave Denotes slave mode.SPI Mode Master Denotes master mode.
```

## 16.2.3.8 SPI\_Priority\_e

#### **Description:**

#### **Enumerators:**

SPI\_Priority\_Immediate Stops immediately after EMU halt.

SPI\_Priority\_FreeRun Doesn't stop after EMU halt.

**SPI\_Priority\_AfterRxRxSeq** Stops after EMU halt and next rx/rx sequence.

## 16.2.3.9 SPI Stelnv e

#### **Description:**

#### **Enumerators:**

**SPI\_SteInv\_ActiveLow** Denotes active low STE pin. **SPI\_SteInv\_ActiveHigh** Denotes active high STE pin.

## 16.2.3.10 SPI\_TriWire\_e

## **Description:**

#### **Enumerators:**

**SPI\_TriWire\_NormalFourWire** Denotes 4 wire SPI mode. **SPI\_TriWire\_ThreeWire** Denotes 3 wire SPI mode.

## 16.2.4 Function Documentation

## 16.2.4.1 SPI clearRxFifoInt

Clears the Rx FIFO interrupt flag.

#### Prototype:

```
void
SPI_clearRxFifoInt(SPI_Handle spiHandle)
```

#### Parameters:

← *spiHandle* The serial peripheral interface (SPI) object handle

## 16.2.4.2 void SPI clearRxFifoOvf (SPI Handle spiHandle)

Clears the Rx FIFO overflow flag.

#### Parameters:

## 16.2.4.3 void SPI clearTxFifoInt (SPI Handle spiHandle)

Clears the Tx FIFO interrupt flag.

#### **Parameters:**

← **spiHandle** The serial peripheral interface (SPI) object handle

## 16.2.4.4 void SPI disable (SPI Handle spiHandle)

Disables the serial peripheral interface (SPI).

#### Parameters:

← *spiHandle* The serial peripheral interface (SPI) object handle

## 16.2.4.5 void SPI disableChannels (SPI Handle spiHandle)

Disables the serial peripheral interface (SPI) transmit and receive channels.

#### Parameters:

← *spiHandle* The serial peripheral interface (SPI) object handle

## 16.2.4.6 void SPI\_disableInt (SPI\_Handle spiHandle)

Disables the serial peripheral interface (SPI) interrupt.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

## 16.2.4.7 void SPI disableLoopBack (SPI Handle spiHandle)

Disables the serial peripheral interface (SPI) loop back mode.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

#### 16.2.4.8 void SPI disableOverRunInt (SPI Handle spiHandle)

Disables the serial peripheral interface (SPI) over-run interrupt.

#### Parameters:

## 16.2.4.9 void SPI disableRxFifo (SPI Handle spiHandle)

Disables the serial peripheral interface (SPI) receive FIFO.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

## 16.2.4.10 void SPI disableRxFifoInt (SPI Handle spiHandle)

Disables the serial peripheral interface (SPI) receive FIFO interrupt.

#### Parameters:

← *spiHandle* The serial peripheral interface (SPI) object handle

## 16.2.4.11 void SPI disableTx (SPI Handle spiHandle)

Disables the serial peripheral interface (SPI) master/slave transmit mode.

#### Parameters:

← *spiHandle* The serial peripheral interface (SPI) object handle

## 16.2.4.12 void SPI\_disableTxFifo (SPI\_Handle spiHandle)

Disables the serial peripheral interface (SPI) transmit FIFO.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

## 16.2.4.13 void SPI disableTxFifoEnh (SPI Handle spiHandle)

Disables the serial peripheral interface (SPI) transmit FIFO enhancements.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

#### 16.2.4.14 void SPI disableTxFifoInt (SPI Handle spiHandle)

Disables the serial peripheral interface (SPI) transmit FIFO interrupt.

#### Parameters:

## 16.2.4.15 void SPI enable (SPI Handle spiHandle)

Enables the serial peripheral interface (SPI).

#### **Parameters:**

← *spiHandle* The serial peripheral interface (SPI) object handle

## 16.2.4.16 void SPI enableChannels (SPI Handle spiHandle)

Enables the serial peripheral interface (SPI) transmit and receive channels.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

## 16.2.4.17 void SPI enableFifoEnh (SPI Handle spiHandle)

Enables the serial peripheral interface (SPI) transmit FIFO enhancements.

#### Parameters:

← *spiHandle* The serial peripheral interface (SPI) object handle

## 16.2.4.18 void SPI\_enableInt (SPI\_Handle spiHandle)

Enables the serial peripheral interface (SPI) interrupt.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

## 16.2.4.19 void SPI\_enableLoopBack (SPI\_Handle spiHandle)

Enables the serial peripheral interface (SPI) loop back mode.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

#### 16.2.4.20 void SPI enableOverRunInt (SPI Handle spiHandle)

Enables the serial peripheral interface (SPI) over-run interrupt.

#### Parameters:

### 16.2.4.21 void SPI enableRxFifo (SPI Handle spiHandle)

Enables the serial peripheral interface (SPI) receive FIFO.

#### Parameters:

← *spiHandle* The serial peripheral interface (SPI) object handle

### 16.2.4.22 void SPI enableRxFifoInt (SPI Handle spiHandle)

Enables the serial peripheral interface (SPI) receive FIFO interrupt.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

## 16.2.4.23 void SPI enableTx (SPI Handle spiHandle)

Enables the serial peripheral interface (SPI) masater/slave transmit mode.

#### Parameters:

← *spiHandle* The serial peripheral interface (SPI) object handle

## 16.2.4.24 void SPI enableTxFifo (SPI Handle spiHandle)

Enables the serial peripheral interface (SPI) transmit FIFO.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

## 16.2.4.25 void SPI enableTxFifoInt (SPI Handle spiHandle)

Enables the serial peripheral interface (SPI) transmit FIFO interrupt.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

### 16.2.4.26 SPI FifoStatus e SPI getRxFifoStatus (SPI Handle spiHandle)

Gets the serial peripheral interface (SPI) receive FIFO status.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

#### Returns:

The recieve FIFO status

## 16.2.4.27 SPI FifoStatus e SPI getTxFifoStatus (SPI Handle spiHandle)

Gets the serial peripheral interface (SPI) transmit FIFO status.

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

#### Returns:

The transmit FIFO status

## 16.2.4.28 SPI\_Handle SPI\_init (void \* pMemory, const size\_t numBytes)

Initializes the serial peripheral interface (SPI) object handle.

#### Parameters:

- ← *pMemory* A pointer to the base address of the SPI registers
- ← *numBytes* The number of bytes allocated for the SPI object, bytes

#### Returns:

The serial peripheral interface (SPI) object handle

## 16.2.4.29 uint16\_t SPI\_read (SPI\_Handle spiHandle) [inline]

Reads data from the serial peripheral interface (SPI).

#### Parameters:

← **spiHandle** The serial peripheral interface (SPI) object handle

#### Returns:

The received data value

#### 16.2.4.30 void SPI reset (SPI Handle spiHandle)

Resets the serial peripheral interface (SPI).

#### Parameters:

← *spiHandle* The serial peripheral interface (SPI) object handle

## 16.2.4.31 void SPI resetChannels (SPI Handle spiHandle)

Resets the serial peripheral interface (SPI) transmit and receive channels.

#### Parameters:

16.2.4.32 void SPI resetRxFifo (SPI Handle spiHandle)

Resets the serial peripheral interface (SPI) receive FIFO.

#### Parameters:

- ← *spiHandle* The serial peripheral interface (SPI) object handle
- 16.2.4.33 void SPI resetTxFifo (SPI Handle spiHandle)

Resets the serial peripheral interface (SPI) transmit FIFO.

#### Parameters:

- ← *spiHandle* The serial peripheral interface (SPI) object handle
- 16.2.4.34 void SPI\_setBaudRate (SPI\_Handle spiHandle, const SPI\_BaudRate\_e baudRate)

Sets the serial peripheral interface (SPI) baud rate.

#### Parameters:

- ← **spiHandle** The serial peripheral interface (SPI) object handle
- ← *baudRate* The baud rate
- 16.2.4.35 void SPI\_setCharLength (SPI\_Handle spiHandle, const SPI\_CharLength\_e length)

Sets the serial peripheral interface (SPI) character length.

#### Parameters:

- ← *spiHandle* The serial peripheral interface (SPI) object handle
- ← *length* The character length
- 16.2.4.36 void SPI setClkPhase (SPI Handle spiHandle, const SPI ClkPhase e clkPhase)

Sets the serial peripheral interface (SPI) clock phase.

- ← **spiHandle** The serial peripheral interface (SPI) object handle
- ← *clkPhase* The clock phase

16.2.4.37 void SPI setClkPolarity (SPI Handle spiHandle, const SPI ClkPolarity e polarity)

Sets the serial peripheral interface (SPI) clock polarity.

#### Parameters:

- ← *spiHandle* The serial peripheral interface (SPI) object handle
- ← *polarity* The clock polarity
- 16.2.4.38 void SPI setMode (SPI Handle spiHandle, const SPI Mode e mode)

Sets the serial peripheral interface (SPI) network mode.

#### Parameters:

- ← **spiHandle** The serial peripheral interface (SPI) object handle
- $\leftarrow$  *mode* The network mode
- 16.2.4.39 void SPI\_setPriority (SPI\_Handle spiHandle, const SPI\_Priority\_e priority)

Sets the priority of the SPI port vis-a-vis the EMU.

#### Parameters:

- ← *spiHandle* The serial peripheral interface (SPI) object handle
- ← *priority* The priority of the SPI port vis-a-vis the EMU
- 16.2.4.40 void SPI\_setRxFifoIntLevel (SPI\_Handle spiHandle, const SPI\_FifoLevel\_e fifoLevel)

Sets the serial peripheral interface (SPI) receive FIFO level for generating an interrupt.

#### Parameters:

- ← **spiHandle** The serial peripheral interface (SPI) object handle
- $\leftarrow$  *fifoLevel* The FIFO level
- 16.2.4.41 void SPI setSteInv (SPI Handle spiHandle, const SPI SteInv e steinv)

Controls pin inversion of STE pin.

- ← **spiHandle** The serial peripheral interface (SPI) object handle
- ← *steinv* Polarity of STE pin

16.2.4.42 void SPI setTriWire (SPI Handle spiHandle, const SPI TriWire e triwire)

Sets SPI port operating mode.

#### Parameters:

- ← *spiHandle* The serial peripheral interface (SPI) object handle
- ← *triwire* 3 or 4 wire mode

## 16.2.4.43 void SPI\_setTxDelay (SPI\_Handle spiHandle, const uint8\_t delay)

Sets the serial peripheral interface (SPI) transmit delay.

#### Parameters:

- ← **spiHandle** The serial peripheral interface (SPI) object handle
- ← *delay* The delay value

# 16.2.4.44 void SPI\_setTxFifoIntLevel (SPI\_Handle spiHandle, const SPI\_FifoLevel\_e fifoLevel)

Sets the serial peripheral interface (SPI) transmit FIFO level for generating an interrupt.

#### Parameters:

- ← **spiHandle** The serial peripheral interface (SPI) object handle
- $\leftarrow$  *fifoLevel* The FIFO level

## 16.2.4.45 void SPI\_write (SPI\_Handle spiHandle, const uint16\_t data) [inline]

Writes data to the serial peripheral interface (SPI).

- ← **spiHandle** The serial peripheral interface (SPI) object handle
- $\leftarrow$  **data** The data value

# 17 Timer

Introduction	279
API Functions	279

## 17.1 Introduction

The timer API provides a set of functions for configuring, starting, stopping, and reading the CPU timers.

This driver is contained in f2802x0\_common/source/timer.c, with f2802x0\_common/include/timer.h containing the API definitions for use by applications.

## **17.2 TIMER**

## **Data Structures**

■ \_TIMER\_Obj\_

## **Defines**

- TIMERO BASE ADDR
- TIMER1\_BASE\_ADDR
- TIMER2 BASE ADDR
- TIMER\_TCR\_FREESOFT\_BITS
- TIMER\_TCR\_TIE\_BITS
- TIMER\_TCR\_TIF\_BITS
- TIMER TCR TRB BITS
- TIMER\_TCR\_TSS\_BITS

## **Enumerations**

- TIMER EmulationMode e
- TIMER\_Status\_e

## **Functions**

- void TIMER\_clearFlag (TIMER\_Handle timerHandle)
- void TIMER disableInt (TIMER Handle timerHandle)
- void TIMER\_enableInt (TIMER\_Handle timerHandle)
- uint32\_t TIMER\_getCount (TIMER\_Handle timerHandle)
- TIMER\_Status\_e TIMER\_getStatus (TIMER\_Handle timerHandle)

- TIMER Handle TIMER init (void \*pMemory, const size t numBytes)
- void TIMER reload (TIMER Handle timerHandle)
- void TIMER\_setDecimationFactor (TIMER\_Handle timerHandle, const uint16\_t decFactor)
- void TIMER\_setEmulationMode (TIMER\_Handle timerHandle, const TIMER\_EmulationMode\_e mode)
- void TIMER\_setPeriod (TIMER\_Handle timerHandle, const uint32\_t period)
- void TIMER setPreScaler (TIMER Handle timerHandle, const uint16 t preScaler)
- void TIMER\_start (TIMER\_Handle timerHandle)
- void TIMER\_stop (TIMER\_Handle timerHandle)

## 17.2.1 Data Structure Documentation

## 17.2.1.1 \_TIMER\_Obj\_

#### **Definition:**

```
typedef struct
{
    uint32_t TIM;
    uint32_t PRD;
    uint32_t TCR;
    uint32_t TPR;
}
_TIMER_Obj_
```

#### Members:

**TIM** Timer Counter Register.

PRD Period Register.

TCR Timer Control Register.

TPR Timer Prescaler Register.

#### **Description:**

Defines the timer (TIMER) object.

## 17.2.2 Define Documentation

## 17.2.2.1 TIMERO BASE ADDR

#### **Definition:**

```
#define TIMERO_BASE_ADDR
```

#### **Description:**

Defines the base address of the timer (TIMER) 0 registers.

## 17.2.2.2 TIMER1 BASE ADDR

#### **Definition:**

```
#define TIMER1_BASE_ADDR
```

## **Description:**

Defines the base address of the timer (TIMER) 1 registers.

## 17.2.2.3 TIMER2\_BASE\_ADDR

#### **Definition:**

#define TIMER2\_BASE\_ADDR

#### **Description:**

Defines the base address of the timer (TIMER) 2 registers.

## 17.2.2.4 TIMER TCR FREESOFT BITS

#### **Definition:**

#define TIMER\_TCR\_FREESOFT\_BITS

#### **Description:**

Defines the location of the FREESOFT bits in the TCR register.

## 17.2.2.5 TIMER\_TCR\_TIE\_BITS

#### **Definition:**

#define TIMER\_TCR\_TIE\_BITS

## **Description:**

Defines the location of the TIE bits in the TCR register.

## 17.2.2.6 TIMER TCR TIF BITS

#### **Definition:**

#define TIMER\_TCR\_TIF\_BITS

#### **Description:**

Defines the location of the TIF bits in the TCR register.

## 17.2.2.7 TIMER TCR TRB BITS

#### **Definition:**

#define TIMER\_TCR\_TRB\_BITS

#### **Description:**

Defines the location of the TRB bits in the TCR register.

## 17.2.2.8 TIMER\_TCR\_TSS\_BITS

#### **Definition:**

#define TIMER\_TCR\_TSS\_BITS

## **Description:**

Defines the location of the TSS bits in the TCR register.

## 17.2.3 Typedef Documentation

## 17.2.3.1 TIMER Handle

### **Definition:**

```
typedef struct TIMER_Obj *TIMER_Handle
```

#### **Description:**

Defines the timer (TIMER) handle.

## 17.2.3.2 TIMER Obj

#### **Definition:**

```
typedef struct _TIMER_Obj_ TIMER_Obj
```

#### **Description:**

Defines the timer (TIMER) object.

## 17.2.4 Enumeration Documentation

## 17.2.4.1 TIMER EmulationMode e

#### **Description:**

Enumeration to define the timer (TIMER) emulation mode.

### **Enumerators:**

**TIMER\_EmulationMode\_StopAfterNextDecrement** Denotes that the timer will stop after the next decrement.

**TIMER\_EmulationMode\_StopAtZero** Denotes that the timer will stop when it reaches zero.

**TIMER\_EmulationMode\_RunFree** Denotes that the timer will run free.

## 17.2.4.2 TIMER\_Status\_e

#### **Description:**

Enumeration to define the timer (TIMER) status.

#### **Enumerators:**

**TIMER\_Status\_CntIsNotZero** Denotes that the counter is non-zero.

**TIMER\_Status\_CntlsZero** Denotes that the counter is zero.

## 17.2.5 Function Documentation

## 17.2.5.1 TIMER\_clearFlag

Clears the timer (TIMER) flag.

#### Prototype:

void

TIMER\_clearFlag(TIMER\_Handle timerHandle)

#### Parameters:

← *timerHandle* The timer (TIMER) object handle

## 17.2.5.2 void TIMER\_disableInt (TIMER\_Handle timerHandle)

Disables the timer (TIMER) interrupt.

#### Parameters:

← *timerHandle* The timer (TIMER) object handle

## 17.2.5.3 void TIMER enableInt (TIMER Handle timerHandle)

Enables the timer (TIMER) interrupt.

#### Parameters:

← *timerHandle* The timer (TIMER) object handle

## 17.2.5.4 uint32 t TIMER getCount (TIMER Handle timerHandle) [inline]

Gets the timer (TIMER) count.

#### Parameters:

← *timerHandle* The timer (TIMER) object handle

#### Returns:

The timer (TIMER) count

## 17.2.5.5 TIMER\_Status\_e TIMER\_getStatus (TIMER\_Handle timerHandle)

Gets the timer (TIMER) status.

#### Parameters:

← *timerHandle* The timer (TIMER) object handle

#### Returns:

The timer (TIMER) status

17.2.5.6 TIMER Handle TIMER init (void \* pMemory, const size t numBytes)

Initializes the timer (TIMER) object handle.

#### Parameters:

- ← *pMemory* A pointer to the base address of the TIMER registers
- ← *numBytes* The number of bytes allocated for the TIMER object, bytes

## Returns:

The timer (CLK) object handle

17.2.5.7 void TIMER reload (TIMER Handle timerHandle)

Reloads the timer (TIMER) value.

#### Parameters:

← *timerHandle* The timer (TIMER) object handle

17.2.5.8 void TIMER\_setDecimationFactor (TIMER\_Handle timerHandle, const uint16\_t decFactor)

Sets the timer (TIMER) decimation factor.

#### Parameters:

- ← *timerHandle* The timer (TIMER) object handle
- ← *decFactor* The timer decimation factor

17.2.5.9 void TIMER\_setEmulationMode (TIMER\_Handle timerHandle, const TIMER EmulationMode e mode)

Sets the timer (TIMER) emulation mode.

#### Parameters:

- ← *timerHandle* The timer (TIMER) object handle
- ← *mode* The emulation mode

17.2.5.10 void TIMER\_setPeriod (TIMER\_Handle timerHandle, const uint32\_t period)

Sets the timer (TIMER) period.

- ← *timerHandle* The timer (TIMER) object handle
- ← *period* The period

## 17.2.5.11 void TIMER\_setPreScaler (TIMER\_Handle timerHandle, const uint16\_t preScaler)

Sets the timer (TIMER) prescaler.

## Parameters:

- ← *timerHandle* The timer (TIMER) object handle
- ← *preScaler* The preScaler value

## 17.2.5.12 void TIMER\_start (TIMER\_Handle timerHandle)

Starts the timer (TIMER).

#### Parameters:

← *timerHandle* The timer (TIMER) object handle

## 17.2.5.13 void TIMER\_stop (TIMER\_Handle timerHandle)

Stops the timer (TIMER).

## Parameters:

← *timerHandle* The timer (TIMER) object handle

# 18 Watchdog Timer

Introduction	287
API Functions 2	287

## 18.1 Introduction

The Watchdog Timer API provides a set of functions for using the watchdog module.

This driver is contained in  $f2802x0\_common/source/watchdog.c$ , with  $f2802x0\_common/include/watchdog.h$  containing the API definitions for use by applications.

# 18.2 WDOG

## **Data Structures**

■ \_WDOG\_Obj\_

## **Defines**

- WDOG BASE ADDR
- WDOG\_SCSR\_WDENINT\_BITS
- WDOG SCSR WDINTS BITS
- WDOG\_SCSR\_WDOVERRIDE\_BITS
- WDOG WDCNTR BITS
- WDOG\_WDCR\_WDCHK\_BITS
- WDOG WDCR WDDIS BITS
- WDOG\_WDCR\_WDFLAG\_BITS
- WDOG\_WDCR\_WDPS\_BITS
- WDOG\_WDCR\_WRITE\_ENABLE
- WDOG WDKEY BITS

## **Enumerations**

■ WDOG\_IntStatus\_e

## **Functions**

- void WDOG\_clearCounter (WDOG\_Handle wdogHandle)
- void WDOG\_disable (WDOG\_Handle wdogHandle)
- void WDOG\_disableInt (WDOG\_Handle wdogHandle)

- void WDOG disableOverRide (WDOG Handle wdogHandle)
- void WDOG enable (WDOG Handle wdogHandle)
- void WDOG\_enableInt (WDOG\_Handle wdogHandle)
- void WDOG\_enableOverRide (WDOG\_Handle wdogHandle)
- WDOG\_IntStatus\_e WDOG\_getIntStatus (WDOG\_Handle wdogHandle)
- WDOG Handle WDOG init (void \*pMemory, const size t numBytes)
- void WDOG\_setCount (WDOG\_Handle wdogHandle, const uint8\_t count)
- void WDOG\_setPreScaler (WDOG\_Handle wdogHandle, const WDOG\_PreScaler\_e preScaler)

## 18.2.1 Data Structure Documentation

## 18.2.1.1 \_WDOG\_Obj\_

#### **Definition:**

```
typedef struct
{
    uint16_t SCSR;
    uint16_t WDCNTR;
    uint16_t rsvd_1;
    uint16_t WDKEY;
    uint16_t wDCR;
}
uint16_t WDCR;
}
_WDOG_Obj_
```

#### Members:

SCSR System Control Status Register.

WDCNTR Watchdog Counter Register.

rsvd 1 Reserved.

WDKEY Watchdog Reset Key Register.

rsvd 2 Reserved.

WDCR Watchdog Control Register.

#### **Description:**

Defines the watchdog (WDOG) object.

## 18.2.2 Define Documentation

## 18.2.2.1 WDOG BASE ADDR

#### **Definition:**

```
#define WDOG_BASE_ADDR
```

## **Description:**

Defines the base address of the watchdog (WDOG) registers.

## 18.2.2.2 WDOG\_SCSR\_WDENINT\_BITS

#### **Definition:**

#define WDOG\_SCSR\_WDENINT\_BITS

#### **Description:**

Defines the location of the WDENINT bits in the SCSR register.

## 18.2.2.3 WDOG\_SCSR\_WDINTS\_BITS

#### **Definition:**

#define WDOG\_SCSR\_WDINTS\_BITS

#### **Description:**

Defines the location of the WDINTS bits in the SCSR register.

## 18.2.2.4 WDOG\_SCSR\_WDOVERRIDE\_BITS

#### **Definition:**

#define WDOG\_SCSR\_WDOVERRIDE\_BITS

#### **Description:**

Defines the location of the WDOVERRIDE bits in the SCSR register.

## 18.2.2.5 WDOG\_WDCNTR\_BITS

#### **Definition:**

#define WDOG\_WDCNTR\_BITS

#### **Description:**

Defines the location of the WDCNTR bits in the WDCNTR register.

## 18.2.2.6 WDOG WDCR\_WDCHK\_BITS

### **Definition:**

#define WDOG\_WDCR\_WDCHK\_BITS

#### **Description:**

Defines the location of the WDCHK bits in the WDCR register.

## 18.2.2.7 WDOG WDCR WDDIS BITS

#### **Definition:**

#define WDOG\_WDCR\_WDDIS\_BITS

#### **Description:**

Defines the location of the WDDIS bits in the WDCR register.

Tue Jul 24 10:01:42 CDT 2012

## 18.2.2.8 WDOG\_WDCR\_WDFLAG\_BITS

#### **Definition:**

#define WDOG\_WDCR\_WDFLAG\_BITS

## **Description:**

Defines the location of the WDFLAG bits in the WDCR register.

## 18.2.2.9 WDOG\_WDCR\_WDPS\_BITS

#### **Definition:**

#define WDOG\_WDCR\_WDPS\_BITS

#### **Description:**

Defines the location of the WDPS bits in the WDCR register.

## 18.2.2.10 WDOG\_WDCR\_WRITE\_ENABLE

#### **Definition:**

#define WDOG\_WDCR\_WRITE\_ENABLE

#### **Description:**

Defines the watchdog write enable mode.

## 18.2.2.11 WDOG\_WDKEY\_BITS

#### **Definition:**

#define WDOG\_WDKEY\_BITS

## **Description:**

Defines the location of the WDKEY bits in the WDKEY register.

# 18.2.3 Typedef Documentation

## 18.2.3.1 WDOG Handle

## **Definition:**

typedef struct WDOG\_Obj \*WDOG\_Handle

## **Description:**

Defines the watchdog (WDOG) handle.

## 18.2.3.2 WDOG\_Obj

#### **Definition:**

```
typedef struct _WDOG_Obj_ WDOG_Obj
```

#### **Description:**

Defines the watchdog (WDOG) object.

## 18.2.4 Enumeration Documentation

## 18.2.4.1 WDOG\_IntStatus\_e

#### **Description:**

Enumeration to define the watchdog (WDOG) interrupt status.

## 18.2.4.2 enum WDOG PreScaler e

Enumeration to define the watchdog (WDOG) timer clock prescaler, which sets the clock frequency.

#### **Enumerators:**

```
WDOG_PreScaler_OscClk_by_512_by_1 Denotes WDCLK = OSCCLK/512/1.

WDOG_PreScaler_OscClk_by_512_by_2 Denotes WDCLK = OSCCLK/512/2.

WDOG_PreScaler_OscClk_by_512_by_4 Denotes WDCLK = OSCCLK/512/4.

WDOG_PreScaler_OscClk_by_512_by_8 Denotes WDCLK = OSCCLK/512/8.

WDOG_PreScaler_OscClk_by_512_by_16 Denotes WDCLK = OSCCLK/512/16.

WDOG_PreScaler_OscClk_by_512_by_32 Denotes WDCLK = OSCCLK/512/32.

WDOG_PreScaler_OscClk_by_512_by_64 Denotes WDCLK = OSCCLK/512/64.
```

## 18.2.5 Function Documentation

## 18.2.5.1 WDOG clearCounter

Clears the watchdog (WDOG) counter.

#### Prototype:

```
void
WDOG_clearCounter(WDOG_Handle wdogHandle)
```

#### **Parameters:**

← wdogHandle The watchdog (WDOG) timer object handle

## 18.2.5.2 void WDOG\_disable (WDOG\_Handle wdogHandle)

Disables the watchdog (WDOG) timer.

#### Parameters:

← wdogHandle The watchdog (WDOG) timer object handle

## 18.2.5.3 void WDOG\_disableInt (WDOG\_Handle wdogHandle)

Disables the watchdog (WDOG) timer interrupt.

#### Parameters:

← *wdogHandle* The watchdog (WDOG) timer object handle

### 18.2.5.4 void WDOG disableOverRide (WDOG Handle wdogHandle)

Disables the timer override.

#### Parameters:

← wdogHandle The watchdog (WDOG) timer object handle

## 18.2.5.5 void WDOG enable (WDOG Handle wdogHandle)

Enables the watchdog (WDOG) timer.

#### Parameters:

← wdogHandle The watchdog (WDOG) timer object handle

## 18.2.5.6 void WDOG enableInt (WDOG Handle wdogHandle)

Enables the watchdog (WDOG) timer interrupt.

#### Parameters:

← wdogHandle The watchdog (WDOG) timer object handle

#### 18.2.5.7 void WDOG enableOverRide (WDOG Handle wdogHandle)

Enables the watchdog (WDOG) timer override.

#### Parameters:

← wdogHandle The watchdog (WDOG) timer object handle

## 18.2.5.8 WDOG IntStatus e WDOG getIntStatus (WDOG Handle wdogHandle)

Gets the watchdog (WDOG) interrupt status.

#### Parameters:

← wdogHandle The watchdog (WDOG) timer object handle

#### Returns:

The interrupt status

18.2.5.9 WDOG\_Handle WDOG\_init (void \* pMemory, const size\_t numBytes)

Initializes the watchdog (WDOG) object handle.

#### Parameters:

- ← *pMemory* A pointer to the base address of the WDOG registers
- ← *numBytes* The number of bytes allocated for the WDOG object, bytes

#### Returns:

The watchdog (WDOG) object handle

18.2.5.10 void WDOG\_setCount (WDOG\_Handle wdogHandle, const uint8\_t count)

Sets the watchdog (WDOG) counter.

#### Parameters:

- ← wdogHandle The watchdog (WDOG) timer object handle
- ← *count* The count

18.2.5.11 void WDOG\_setPreScaler (WDOG\_Handle wdogHandle, const WDOG PreScaler e preScaler)

Sets the watchdog (WDOG) timer clock prescaler.

- ← wdogHandle The watchdog (WDOG) timer object handle
- ← *preScaler* The prescaler

## IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

#### **Products**

Amplifiers
Data Converters
DLP® Products
DSP
Clocks and Timers
Interface
Logic
Power Mgmt
Microcontrollers

RF/IF and ZigBee® Solutions

amplifier.ti.com
dataconverter.ti.com
www.dlp.com
dsp.ti.com
www.ti.com/clocks
interface.ti.com
logic.ti.com
power.ti.com
microcontroller.ti.com
www.ti-rfid.com
www.ti.com/lprf

Applications
Audio
Automotive
Broadband
Digital Control
Medical
Military

Military
Optical Networking
Security
Telephony
Video & Imaging
Wireless

www.ti.com/audio www.ti.com/automotive

www.ti.com/broadband www.ti.com/digitalcontrol

www.ti.com/medical www.ti.com/military

www.ti.com/opticalnetwork

www.ti.com/security www.ti.com/telephony www.ti.com/video

www.ti.com/wireless

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2012, Texas Instruments Incorporated