







Note:

- 1. J1 can be omitted if the debug UART is not needed.
- 2. J4 can be omitted if power on BIST is not needed.
- 3. D1, D2, and/or D3 and R3, R4, and/or R5 can be omitted if the corresponding indicator is not needed.

