MIPS Architecture and Assembly Language Overview

Adapted from: http://edge.mcs.dre.g.el.edu/GICL/people/sevy/architecture/MIPSRef(SPIM).html

[Register Description] [I/O Description]

Data Types and Literals

Data types:

- Instructions are all 32 bits
- byte(8 bits), halfword (2 bytes), word (4 bytes)
- a character requires 1 byte of storage
- an integer requires 1 word (4 bytes) of storage

Literals:

- numbers entered as is. <u>e.g.</u> 4
- characters enclosed in single quotes. <u>e.g.</u> 'b'
- strings enclosed in double quotes. <u>e.g.</u> "A string"

Registers

- 32 general-purpose registers
- register preceded by \$ in assembly language instruction two formats for addressing:
 - using register number <u>e.g.</u> \$0 through \$31
 - using equivalent names <u>e.g.</u> \$t1, \$sp
- special registers Lo and Hi used to store result of multiplication and division
 - o not directly addressable; contents accessed with special instruction mfhi ("move from Hi") and mflo ("move from Lo")
- stack grows from high memory to low memory

This is from Figure 9.9 in the Goodman&Miller text

Register Number	Alternative Name	Description	
0	zero	the value 0	
1	\$at	(assembler temporary) reserved by the assembler	
2-3	\$v0 - \$v1	(values) from expression evaluation and function results	
4-7	\$a0 - \$a3	(arguments) First four parameters for subroutine. Not preserved across procedure calls	
8-15	\$t0 - \$t7	(temporaries) Caller saved if needed. Subroutines can use w/out saving. Not preserved across procedure calls	
16-23	\$s0 - \$s7	(saved values) - Callee saved. A subroutine using one of these must save original and restore it before exiting. Preserved across procedure calls	
24-25	\$t8 - \$t9	(temporaries) Caller saved if needed. Subroutines can use w/out saving. These are in addition to \$t0 - \$t7 above. Not preserved across procedure calls.	
26-27	\$k0 - \$k1	reserved for use by the interrupt/trap handler	
28	\$gp	global p ointer. Points to the middle of the 64K block of memory in the static data segment.	
29	\$sp	stack pointer Points to last location on the stack.	
30	\$s8/\$fp	saved value / frame pointer Preserved across procedure calls	
31	\$ra	return address	

See also Britton section 1.9, Sweetman section 2.21, Larus Appendix section A.6

Program Structure

- just plain text file with data declarations, program code (name of file should end in suffix .s to be used with SPIM simulator)
- data declaration section followed by program code section

Data Declarations

- placed in section of program identified with assembler directive .data
- declares variable names used in program; storage allocated in main memory (RAM)

Code

- placed in section of text identified with assembler directive .text
- contains program code (instructions)
- starting point for code e.g.ecution given label main:

• ending point of main code should use exit system call (see below under System Calls)

Comments

- anything following # on a line # This stuff would be considered a comment
- Template for a MIPS assembly language program:

```
# Comment giving name of program and description of function
# Template.s
# Bare-bones outline of MIPS assembly language program
                       # variable declarations follow this line
                       # instructions follow this line
           .text
                       # indicates start of code (first instruction to execute)
main:
# End of program, leave a blank line afterwards to make SPIM happy
```

Data Declarations

```
format for declarations:
```

```
name:
        storage_type
                         value(s)
```

- create storage for variable of specified type with given name and specified value
- value(s) usually gives initial value(s); for storage type .space, gives number of spaces to be allocated

Note: labels always followed by colon (:)

```
example
                                # create a single integer variable with initial value 3
var1:
                .word
                        'a', 'b' # create a 2-element character array with elements initialized
array1:
                .byte
                                    to a and b
                                # allocate 40 consecutive bytes, with storage uninitialized
array2:
                .space 40
                                    could be used as a 40-element character array, or a
                                    10-element integer array; a comment should indicate which!
```

Load / Store Instructions

- RAM access only allowed with load and store instructions
- all other instructions use register operands

<u>load:</u>

```
register destination, RAM_source
               lw
                 #copy word (4 bytes) at source RAM location to destination register.
               lb
                        register_destination, RAM_source
                 #copy byte at source RAM location to low-order byte of destination register,
                 # and sign-e.g.tend to higher-order bytes
store word:
                        register_source, RAM_destination
               SW
                 #store word in source register into RAM destination
               sb
                        register_source, RAM_destination
                 #store byte (low-order) in source register into RAM destination
```

<u>load immediate:</u>

```
li
         register_destination, value
  #load immediate value into destination register
```

```
example:
        .data
               23
                                # declare storage for var1; initial value is 23
var1:
        .word
        .text
_start:
               $t0, var1
                                        # load contents of RAM location into register $t0: $t0 = var1
       lw
               $t1, 5
                                # $t1 = 5 ("load immediate")
       li
                                        # store contents of register $t1 into RAM: var1 = $t1
               $t1, var1
        SW
        done
```

• Used only with load and store instructions

load address:

```
la $t0, var1
```

• copy RAM address of var1 (presumably a label defined in the program) into register \$t0

indirect addressing:

```
lw $t2, ($t0)
```

• load word at RAM address contained in \$t0 into \$t2

```
sw $t2, ($t0)
```

• store word in register \$t2 into RAM at address contained in \$t0

based or indexed addressing:

```
lw $t2, 4($t0)
```

- load word at RAM address (\$t0+4) into register \$t2
- "4" gives offset from address in register \$t0

```
sw $t2, -12($t0)
```

- store word in register \$t2 into RAM at address (\$t0 12)
- negative offsets are fine

Note: based addressing is especially useful for:

- arrays; access elements as offset from base address
- stacks; easy to access elements at offset from stack pointer or frame pointer

example

```
.data
                .space 12
                                        # declare 12 bytes of storage to hold array of 3 integers
array1:
                .text
                                                # load base address of array into register $t0
               la
                        $t0, array1
_start:
                                           $t1 = 5 ("load immediate")
               li
                        $t1, 5
                                          first array element set to 5; indirect addressing
               sw $t1, ($t0)
               li $t1, 13
                                            $t1 = 13
                                          second array element set to 13
               sw $t1, 4($t0)
               li $t1, -7
                                            $t1 = -7
                                        # third array element set to -7
               sw $t1, 8($t0)
                done
```

Arithmetic Instructions

- most use 3 operands
- all operands are registers; no RAM or indirect addressing
- operand size is word (4 bytes)

```
add
        $t0,$t1,$t2
                        # $t0 = $t1 + $t2;
                                              add as signed (2's complement) integers
                        # $t2 = $t3 Đ $t4
sub
        $t2,$t3,$t4
                        # $t2 = $t3 + 5;
addi
        $t2,$t3, 5
                                            "add immediate" (no sub immediate)
                                             add as unsigned integers
addu
        $t1,$t6,$t7
                        # $t1 = $t6 + $t7;
                                             subtract as unsigned integers
subu
        $t1,$t6,$t7
                        # $t1 = $t6 + $t7;
mult
        $t3,$t4
                          multiply 32-bit quantities in $t3 and $t4, and store 64-bit
                          result in special registers Lo and Hi: (Hi,Lo) = $t3 * $t4
                          Lo = $t5 / $t6
div
        $t5,$t6
                                           (integer quotient)
                        # Hi = $t5 mod $t6
                                            (remainder)
                          move quantity in special register Hi to $t0:
mfhi
        $t0
                                                                          $t0 = Hi
mflo
        $t1
                          move quantity in special register Lo to $t1:
                                                                         $t1 = Lo
                          used to get at result of product or quotient
        $t2,$t3 # $t2 = $t3
move
```

Control Structures

Branches

• comparison for conditional branches is built into instruction

```
b target # unconditional branch to program label target beq $t0,$t1,target # branch to target if $t0 = $t1 blt $t0,$t1,target # branch to target if $t0 < $t1 ble $t0,$t1,target # branch to target if $t0 <= $t1 bgt $t0,$t1,target # branch to target if $t0 >= $t1 bge $t0,$t1,target # branch to target if $t0 > $t1 bge $t0,$t1,target # branch to target if $t0 >= $t1 branch to target if $t0 >> $t1 branch
```

<u>Jumps</u>

```
j target # unconditional jump to program label target
jr $t3  # jump to address contained in $t3 ("jump register")
```

Subroutine Calls

subroutine call: "jump and link" instruction

```
jal sub_label # "jump and link"
```

- copy program counter (return address) to register \$ra (return address register)
- jump to program statement at sub_label

subroutine return: "jump register" instruction

```
jr $ra # "jump register"
```

• jump to return address in \$ra (stored by jal instruction)

Note: return address stored in register \$ra; if subroutine will call other subroutines, or is recursive, return address should be copied from \$ra onto stack to preserve it, since jal always places return address in this register and hence will overwrite previous value

System Calls and I/O (SPIM Simulator)

- used to read or print values or strings from input/output window, and indicate program end
- use syscall operating system routine call
- first supply appropriate values in registers \$v0 and \$a0-\$a1
- result value (if any) returned in register \$v0

The following table lists the possible **syscall** services.

Service	Code in \$v0	Arguments	Results
print_int	1	\$a0 = integer to be printed	
print_float	2	\$f12 = float to be printed	
print_double	3	\$f12 = double to be printed	
print_string	4	\$a0 = address of string in memory	
read_int	5		integer returned in \$v0
read_float	6		float returned in \$v0
read_double	7		double returned in \$v0
read_string	8	\$a0 = memory address of string input buffer \$a1 = length of string buffer (n)	
sbrk	9	\$a0 = amount	address in \$v0
exit	10		

- The print_string service expects the address to start a null-terminated character string. The directive .asciiz creates a null-terminated character string.
- The read_int, read_float and read_double services read an entire line of input up to and including the newline character.
- The read_string service has the same semantices as the UNIX library routine fgets.
 - It reads up to n-1 characters into a buffer and terminates the string with a null character.
 - If fewer than n-1 characters are in the current line, it reads up to and including the newline and terminates the string with a null character.
- The sbrk service returns the address to a block of memory containing n additional bytes. This would be used for dynamic memory allocation.
- The exit service stops a program from running.

```
Print out integer value contained in register $t2
e.g.
                li
                        $v0, 1
                                                # load appropriate system call code into register $v0;
                                                # code for printing integer is 1
                                                # move integer to be printed into $a0: $a0 = $t2
                        $a0, $t2
                move
                                                # call operating system to perform operation
                syscall
       Read integer value, store in RAM location with label int_value (presumably declared in data section)
e.g.
                                                # load appropriate system call code into register $v0;
                li
                        $v0, 5
                                                # code for reading integer is 5
                                                # call operating system to perform operation
                syscall
                                                # value read from keyboard returned in register $v0;
                        $v0, int_value
                sw
                                                # store this in desired location
       Print out string (useful for prompts)
                .data
                                                # declaration for string variable,
string1
                .asciiz "Print this.\n"
                                                # .asciiz directive makes string null terminated
                .text
                                                # load appropriate system call code into register $v0;
                        $v0, 4
main:
                li
                                                # code for printing string is 4
                                                # load address of string to be printed into $a0
                la
                        $a0, string1
                syscall
                                                # call operating system to perform print operation
e.g. To indicate end of program, use exit system call; thus last lines of program should be:
                        $v0, 10
                                        # system call code for exit = 10
                li
                                                # call operating sys
                syscall
```