Raspberry Pi Installation



These instructions are for Arch Linux ARM on a Rapberry Pi 2

SD card creation

Partitions:

- 1. Find out the device name of your cardreader (ex. /dev/sdd will be used here)
- 2. Type **fdisk /dev/sdd** and press enter to start fdisk.
- 3. Type **o** and press enter to clear out any old partitions.
- 4. Type **p** and press enter to see partitions, there should be none left.
- 5. Type \mathbf{n} and press enter to start creating a new partition.
- Type **p** and press enter to select primary.
- Type 1 and press enter to select first partition.
- Press enter to accept default first sector.
- Type +100M and press enter to select last sector.
- 6. Type **t** and press enter to change type
- Type **c** and press enter to change type to FAT32.
- 7. Type \mathbf{n} and press enter to start creating a new partition.
- Type **p** and press enter to select primary.
- Type 2 and press enter to select second partition.
- Press enter to accept default first sector.
- Press enter to accept default last sector.
- 8. Type w and press enter to save partition table and exit fdisk.

Filesystems:

- 9. Type **mkfs.vfat** /dev/sdd1 and press enter to create a filesystem on the first partition.
- 10. Type **mkdir boot** and press enter to create a directory to use for boot partition.
- 11. Type **mount /dev/sdd1 boot** and press enter to mount boot partition in boot directory.
- 12. Type **mkfs.ext4** /**dev/sdd2** and press enter to create a filesystem on the second partition.
- 13. Type **mkdir root** and press enter to create a directory to use for root partition.
- 14. Type **mount /dev/sdd2 root** and press enter to mount root partition in root directory.

Raspberry Pi Installation



Base system:

- 15. Type wget http://archlinuxarm.org/os/ArchLinuxARM-rpi-2-latest.tar.gz and press enter to download latest build.
- 16. Type **bsdtar -xpf ArchLinuxARM-rpi-2-latest.tar.gz -C root** and press enter to extract files.
- 17. Type **sync** and press enter to write any data buffered in memory out to disk.
- 18. Type **mv root/boot/* boot** and press enter to move boot files to boot partition.

Initial configuration:

- 19. Edit the file boot/cmdline.txt.
 - Remove entries with ttyAMA0 (ex. console=ttyAMA0,115200).
- 20. Edit the file boot/config.txt.
 - Uncomment the line device tree param=i2c arm=on.
 - Uncomment the line device tree param=i2s=on.
- 21. Edit the file root/etc/modules-load.d/raspberrypi.conf.
 - Add line i2c-bcm2708.
 - Add line i2c-dev.
- 22. Edit the file root/etc/hostname.
 - Change text to sailbot.
- 23. Type **umount boot root** and press enter to unmount boot and root filesystems.
- 24. Remove card from reader, put it in the Raspberry and power on.
- 25. Log in with username: root and password: root

Raspberry Pi Installation



Dependency installation:

- 26. Type **pacman -Syu** and press enter to synchronize database then look for and install updates.
- If you get timeouts, edit the file /etc/resolv.conf and add options timeout:1 to it.
- 27. Type **pacman -S gcc make git sudo wget** and press enter to install tools needed to construct software.
- 28. Type **pacman -S i2c-tools** and press enter to install i2c toolkit.
- 29. Type **pacman -S gpsd** and press enter to install GPS daemon and library.
- 30. Goto http://sqlite.org/download.html and copy the link to the latest sqlite-autoconf archive (ex. sqlite-autoconf-3080900.tar.gz).
- 31. Type **wget "filename"** (ex. wget http://sqlite.org/2015/sqlite-autoconf-3080900.tar.gz) and press enter to download archive.
- Type **tar xvf** "**filename**" (ex. tar xvf sqlite-autoconf-3080900.tar.gz) to unpack archive.
 - Enter the folder it got unpacked to.
- Type **./configure** and press enter to run configuration script.
- Type **make** and press enter to create sqlite software.
- Type **make install** and press enter to install sqlite software.
- Type **cd** .. to exit the directory
- Type **rm -r sqlite*** and press enter to remove old files.
- 32. Type **git clone git://git.drogon.net/wiringPi** and press enter to get wiringPi repository.
- Type **cd wiringPi** and press enter to enter folder.
- Type ./build and press enter to create software.
- Exit directory with cd ..

Main software installation:

- 33. Type **git clone https://github.com/pophaax/raspi** and press enter to download repositories.
- 34. Enter enter raspi directory and type sh /PiShell/pishell.sh ti start PiShell then select install.