2015-2016 Test beam Run Control

Generated by Doxygen 1.8.10

Contents

1	Mod	odule Index						
	1.1	Modules	1					
2	Nam	nespace Index	3					
	2.1	Namespace List	3					
3	Hier	rarchical Index	5					
	3.1	Class Hierarchy	5					
4	Data	a Structure Index	7					
	4.1	Data Structures	7					
5	Mod	dule Documentation	9					
	5.1	Socket communication objects	9					
		5.1.1 Detailed Description	9					
	5.2	FPGA board control	10					
		5.2.1 Detailed Description	10					
	5.3	HPTDC chip control	11					
		5.3.1 Detailed Description	11					
		5.3.2 Enumeration Type Documentation	11					
		5.3.2.1 AcquisitionMode	11					
		5.3.2.2 AcquisitionMode	11					
6	Nam	nespace Documentation	13					
	6.1	DAQ Namespace Reference	13					
	6.2	DQM Namespace Reference	13					
7	Data	a Structure Documentation	15					
	7.1	OnlineDBHandler::BurstInfo Struct Reference	15					
		7.1.1 Field Documentation	15					
		7.1.1.1 burst_id	15					
		7.1.1.2 time_start	15					
	7.2	Client Class Reference	15					
		7.2.1 Detailed Description	17					

iv CONTENTS

	7.2.2	Construc	ctor & Destructor Documentation	17
		7.2.2.1	Client()	17
		7.2.2.2	Client(int port)	17
		7.2.2.3	~Client()	18
	7.2.3	Member	Function Documentation	18
		7.2.3.1	Announce()	18
		7.2.3.2	Connect(const SocketType &type=CLIENT)	18
		7.2.3.3	Disconnect()	19
		7.2.3.4	GetType() const	19
		7.2.3.5	ParseMessage(const SocketMessage &m)	19
		7.2.3.6	Receive()	19
		7.2.3.7	Receive(const MessageKey &key)	20
		7.2.3.8	Send(const Message &m) const	20
		7.2.3.9	Send(const Exception &e) const	21
		7.2.3.10	SendAndReceive(const SocketMessage &m, const MessageKey &a) const	21
	7.2.4	Field Doo	cumentation	21
		7.2.4.1	fClientId	21
		7.2.4.2	flsConnected	21
		7.2.4.3	fType	21
7.3	DQM::	GastofCan	nvas::Coord Struct Reference	21
	7.3.1	Field Doo	cumentation	21
		7.3.1.1	x	22
		7.3.1.2	y	22
7.4	DQM::	QuarticCa	nvas::Coord Struct Reference	22
	7.4.1	Field Doo	cumentation	22
		7.4.1.1	\mathbf{x}	22
		7.4.1.2	y	22
7.5	DQM::	DQMProce	ess Class Reference	22
	7.5.1	Detailed	Description	23
	7.5.2	Member	Enumeration Documentation	24
		7.5.2.1	Action	24
	7.5.3	Construc	stor & Destructor Documentation	24
		7.5.3.1	DQMProcess(int port, unsigned short order=0, const char *det_type="""")	24
		7.5.3.2	\sim DQMProcess()	24
	7.5.4	Member	Function Documentation	24
		7.5.4.1	IsInRun()	25
		7.5.4.2	ParseMessage(uint32_t *board_address, std::string *filename)	25
		7.5.4.3	Run(bool(*fcn)(unsigned int addr, std::string filename, std::vector< std::string > *outputs), const Action &act=NewPlot)	25
		7.5.4.4	Run(bool(*fcn)(std::vector< std::string > *outputs), const Action &act=NewPlot)	26

CONTENTS

	7.5.5	Field Doo	cumentation	26
		7.5.5.1	fAddressesCanProcess	26
		7.5.5.2	fDetectorType	26
		7.5.5.3	fOrder	26
		7.5.5.4	fRunNumber	26
7.6	file_he	ader_t Stru	uct Reference	26
	7.6.1	Detailed	Description	26
	7.6.2	Field Doo	cumentation	27
		7.6.2.1	acq_mode	27
		7.6.2.2	det_mode	27
		7.6.2.3	magic	27
		7.6.2.4	num_hptdc	27
		7.6.2.5	run_id	27
		7.6.2.6	spill_id	27
7.7	FileRe	ader Class	Reference	27
	7.7.1	Detailed	Description	28
	7.7.2	Construc	tor & Destructor Documentation	28
		7.7.2.1	FileReader()	28
		7.7.2.2	FileReader(std::string name)	28
		7.7.2.3	\sim FileReader()	29
	7.7.3	Member	Function Documentation	29
		7.7.3.1	Clear()	29
		7.7.3.2	Dump() const	29
		7.7.3.3	GetAcquisitionMode() const	29
		7.7.3.4	GetBurstId() const	29
		7.7.3.5	GetDetectionMode() const	29
		7.7.3.6	GetNextEvent(TDCEvent *)	29
		7.7.3.7	${\sf GetNextMeasurement}({\sf unsigned\ int\ channel_id}, {\sf TDCMeasurement\ *mc})\ .\ .\ .\ .$	29
		7.7.3.8	GetNumEvents() const	30
		7.7.3.9	GetNumTDCs() const	30
		7.7.3.10	GetRunld() const	30
		7.7.3.11	IsOpen() const	30
		7.7.3.12	Open(std::string name)	30
	7.7.4	Field Doo	cumentation	30
		7.7.4.1	fFile	30
		7.7.4.2	fHeader	30
		7.7.4.3	fNumEvents	30
		7.7.4.4	fReadoutMode	30
		7.7.4.5	fWriteTime	30
7.8	DAQ::F	PGAHand	dler Class Reference	30

vi

	7.8.1	7.8.1 Detailed Description				
	7.8.2	Construc	tor & Destructor Documentation	32		
		7.8.2.1	FPGAHandler(int port, const char *dev)	32		
		7.8.2.2	~FPGAHandler()	32		
	7.8.3	Member	Function Documentation	33		
		7.8.3.1	CloseFile()	33		
		7.8.3.2	ErrorState()	33		
		7.8.3.3	GetFilename() const	33		
		7.8.3.4	GetTDC(unsigned int i=0)	33		
		7.8.3.5	GetTDCControl() const	33		
		7.8.3.6	GetTDCStatus() const	33		
		7.8.3.7	GetType() const	33		
		7.8.3.8	OpenFile()	34		
		7.8.3.9	RegisterTest() const	34		
		7.8.3.10	RetrieveSetupWord() const	34		
		7.8.3.11	SendSetupWord() const	35		
		7.8.3.12	SetTDCSetup(const TDCSetup &s)	35		
		7.8.3.13	StartAcquisition()	35		
		7.8.3.14	Stop()	35		
		7.8.3.15	StopAcquisition()	36		
	7.8.4	Field Doo	cumentation	36		
		7.8.4.1	fFilename	36		
		7.8.4.2	flsFileOpen	36		
		7.8.4.3	flsTDCInReadout	36		
		7.8.4.4	fOutput	36		
		7.8.4.5	fTDC	36		
7.9	DQM::0	GastofCan	vas Class Reference	36		
	7.9.1	Detailed	Description	38		
	7.9.2	Construc	tor & Destructor Documentation	38		
		7.9.2.1	GastofCanvas()	38		
		7.9.2.2	GastofCanvas(TString name, unsigned int width=500, unsigned int height=500, TString upper_label="""")	38		
		7.9.2.3	GastofCanvas(TString name, TString upper_label)	38		
		7.9.2.4	~GastofCanvas()	39		
	7.9.3	Member	Function Documentation	39		
		7.9.3.1	Build()	39		
		7.9.3.2	DrawGrid()	39		
		7.9.3.3	FillChannel(unsigned short nino_id, unsigned short channel_id, double content) .	39		
		7.9.3.4	GetCoordinates(unsigned short nino_id, unsigned short channel_id) const	39		
		7.9.3.5	Grid()	39		

CONTENTS vii

		7.9.3.6	Save(IString ext=""png"", IString path=""."")	39
			SetRunInfo(unsigned int board_id, unsigned int run_id, unsigned int spill_id, T⇔ String date)	39
		7.9.3.8	SetUpperLabel(TString text)	39
	7.9.4	Field Docu	mentation	39
		7.9.4.1	c1	40
		7.9.4.2	c2	40
		7.9.4.3	fBoardId	40
		7.9.4.4	fHeight	40
		7.9.4.5	fHist	40
		7.9.4.6	fLabel1	40
		7.9.4.7	fLabel2	40
		7.9.4.8	fLabel3	40
		7.9.4.9	fLabel4	40
		7.9.4.10	fLabelsDrawn	40
		7.9.4.11	fLegend	40
		7.9.4.12	fLegendNumEntries	40
		7.9.4.13	fLegendX	40
		7.9.4.14	fLegendY	40
		7.9.4.15	fRunDate	40
		7.9.4.16	fRunld	40
		7.9.4.17	fSpillId	40
		7.9.4.18	fUpperLabel	40
		7.9.4.19	fUpperLabelText	40
		7.9.4.20	fWidth	40
7.10 I	Logger	Class Refe	rence	40
-	7.10.1	Detailed D	escription	41
-	7.10.2	Constructo	or & Destructor Documentation	41
		7.10.2.1	Logger(std::ostream &lhs, std::ostream &rhs=std::cout)	41
		7.10.2.2	~Logger()	41
	7.10.3	Field Docu	mentation	41
		7.10.3.1	fBuffer	41
		7.10.3.2	fStream	41
7.11 I	LogRed	director Clas	ss Reference	41
-	7.11.1	Detailed D	escription	42
-	7.11.2	Constructo	or & Destructor Documentation	42
		7.11.2.1	LogRedirector(std::ostream &stm=std::cout)	42
-	7.11.3	Member F	unction Documentation	42
		7.11.3.1	contents() const	42
	7.11.4	Field Docu	mentation	42

viii CONTENTS

	7.11.4.1 fRedirect	42
	7.11.4.2 fSS	42
7.12 Messa	age Class Reference	42
7.12.1	Detailed Description	43
7.12.2	Constructor & Destructor Documentation	43
	7.12.2.1 Message()	43
	7.12.2.2 Message(const char *msg)	43
	7.12.2.3 Message(std::string msg)	43
	7.12.2.4 ~Message()	44
7.12.3	Member Function Documentation	44
	7.12.3.1 Dump(std::ostream &os=std::cout) const	44
	7.12.3.2 GetKey() const	44
	7.12.3.3 GetString() const	44
	7.12.3.4 IsFromWeb() const	44
7.12.4	Field Documentation	44
	7.12.4.1 fString	44
7.13 Messe	enger Class Reference	44
7.13.1	Detailed Description	46
7.13.2	Constructor & Destructor Documentation	46
	7.13.2.1 Messenger()	46
	7.13.2.2 Messenger(int port)	46
	7.13.2.3 ~Messenger()	46
7.13.3	Member Function Documentation	47
	7.13.3.1 AddClient()	47
	7.13.3.2 Broadcast(const Message &m) const	47
	7.13.3.3 Connect()	47
	7.13.3.4 Disconnect()	48
	7.13.3.5 DisconnectClient(int sid, MessageKey key, bool force=false)	48
	7.13.3.6 GetType() const	49
	7.13.3.7 ProcessMessage(SocketMessage m, int sid)	49
	7.13.3.8 Receive()	49
	7.13.3.9 Send(const Message &m, int sid) const	50
	7.13.3.10 SendAll(const Socket::SocketType &type, const Message &m) const	50
	7.13.3.11 SendAll(const Socket::SocketType &type, const Exception &e) const	50
	7.13.3.12 StartAcquisition()	50
	7.13.3.13 StopAcquisition()	51
	7.13.3.14 SwitchClientType(int sid, Socket::SocketType type)	51
7.13.4	Field Documentation	51
	7.13.4.1 fNumAttempts	51
	7.13.4.2 fPID	51

CONTENTS

		7.13.4.3	fStderrPipe	51
		7.13.4.4	fStdoutPipe	51
7.14	Online	DBHandler	Class Reference	51
	7.14.1	Detailed I	Description	52
	7.14.2	Member	Typedef Documentation	53
		7.14.2.1	BurstInfos	53
		7.14.2.2	RunCollection	53
		7.14.2.3	TDCConditionsCollection	53
	7.14.3	Construc	tor & Destructor Documentation	53
		7.14.3.1	OnlineDBHandler(std::string path=std::string(std::getenv(""PPS_PATH""))+""/run← _infos.db"")	53
		7.14.3.2	~OnlineDBHandler()	53
	7.14.4	Member I	Function Documentation	53
		7.14.4.1	BuildTables()	53
		7.14.4.2	GetLastBurst(unsigned int run) const	53
		7.14.4.3	GetLastRun() const	53
		7.14.4.4	GetRunInfo(unsigned int run) const	53
		7.14.4.5	GetRuns() const	53
		7.14.4.6	GetTDCConditions(unsigned int run_id) const	53
		7.14.4.7	NewBurst()	54
		7.14.4.8	NewRun()	54
		7.14.4.9	Select(std::string req, int num_fields=-1) const	54
		7.14.4.10	SetHVConditions(unsigned short channel_id, unsigned int vmax, unsigned imax)	54
		7.14.4.11	SetTDCConditions(unsigned short tdc_id, unsigned long tdc_address, unsigned short tdc_acq_mode, unsigned short tdc_det_mode, std::string detector)	54
	7.14.5	Field Doo	eumentation	54
		7.14.5.1	fDB	54
7.15	DQM::F	PSCanva	s Class Reference	55
	7.15.1	Detailed I	Description	56
	7.15.2	Construc	tor & Destructor Documentation	56
		7.15.2.1	PPSCanvas()	56
		7.15.2.2	PPSCanvas(TString name, unsigned int width=500, unsigned int height=500, T⇔ String upper_label="""")	56
		7.15.2.3	PPSCanvas(TString name, TString upper_label)	56
		7.15.2.4	\sim PPSCanvas()	57
	7.15.3	Member I	Function Documentation	57
		7.15.3.1	Build()	57
		7.15.3.2	DrawGrid()	57
		7.15.3.3	Grid()	57
		7.15.3.4	Save(TString ext=""png"", TString path=""."")	57
		7.15.3.5	SetRunInfo(unsigned int run_id, TString date)	57

CONTENTS

		7.15.3.6	SetUpperLabel(TString text)	57
7.	15.4	Field Doc	umentation	57
		7.15.4.1	c1	57
		7.15.4.2	c2	57
		7.15.4.3	fHeight	57
		7.15.4.4	fLabel1	57
		7.15.4.5	fLabel2	57
		7.15.4.6	fLabel3	57
		7.15.4.7	fLabelsDrawn	58
		7.15.4.8	fLegend	58
		7.15.4.9	fLegendNumEntries	58
		7.15.4.10	fLegendX	58
		7.15.4.11	fLegendY	58
		7.15.4.12	fRunDate	58
		7.15.4.13	fRunld	58
		7.15.4.14	fUpperLabel	58
		7.15.4.15	fUpperLabelText	58
		7.15.4.16	fWidth	58
7.16 D	QM::Q	uarticCar	was Class Reference	58
7.	16.1	Detailed [Description	60
7.	16.2	Construct	or & Destructor Documentation	60
		7.16.2.1	QuarticCanvas()	60
		7.16.2.2	QuarticCanvas(TString name, unsigned int width=500, unsigned int height=500, TString upper_label="""")	60
		7.16.2.3	QuarticCanvas(TString name, TString upper_label)	60
		7.16.2.4	~QuarticCanvas()	61
7.	16.3	Member F	Function Documentation	61
		7.16.3.1	Build()	61
		7.16.3.2	DrawGrid()	61
		7.16.3.3	FillChannel(unsigned short channel_id, double content)	61
		7.16.3.4	GetCoordinates(unsigned short channel_id) const	61
		7.16.3.5	Grid()	61
		7.16.3.6	Save(TString ext=""png"", TString path=""."")	61
		7.16.3.7	SetRunInfo(unsigned int board_id, unsigned int run_id, unsigned int spill_id, T⇔ String date)	61
		7.16.3.8	SetUpperLabel(TString text)	61
7.	16.4	Field Doc	umentation	61
		7.16.4.1	c1	62
		7.16.4.2	c2	62
		7.16.4.3	fBoardId	62

CONTENTS xi

		7.16.4.4	fHeight	62
		7.16.4.5	fHist	62
		7.16.4.6	fLabel1	62
		7.16.4.7	fLabel2	62
		7.16.4.8	fLabel3	62
		7.16.4.9	fLabel4	62
		7.16.4.10	fLabelsDrawn	62
		7.16.4.11	fLegend	62
		7.16.4.12	! fLegendNumEntries	62
		7.16.4.13	fLegendX	62
		7.16.4.14	fLegendY	62
		7.16.4.15	fRunDate	62
		7.16.4.16	fRunld	62
		7.16.4.17	'fSpillld	62
		7.16.4.18	fUpperLabel	62
		7.16.4.19	fUpperLabelText	62
		7.16.4.20	fWidth	62
			Handler Class Reference	
	7.17.1	Detailed I	Description	64
	7.17.2	Construc	tor & Destructor Documentation	64
		7.17.2.1	QuickUSBHandler()	64
		7.17.2.2	~QuickUSBHandler()	64
	7.17.3	Member I	Function Documentation	64
		7.17.3.1	Fetch(uint16_t addr, uint16_t size) const	64
		7.17.3.2	GetDLLVersion() const	64
		7.17.3.3	GetDriverVersion() const	64
		7.17.3.4	GetFWVersion() const	64
		7.17.3.5	Init()	64
		7.17.3.6	Reset() const	65
		7.17.3.7	StartBulkTransfer(QVOIDRETURN callback(PQBULKSTREAM))	65
		7.17.3.8	StopBulkTransfer()	65
		7.17.3.9	Write(uint16_t addr, uint8_t word) const	65
		7.17.3.10	$\label{eq:words} \mbox{Write(uint16_t addr, std::vector< uint8_t> \&words, uint16_t size) const} . \ . \ . \ .$	65
	7.17.4	Field Doo	cumentation	65
		7.17.4.1	fDevice	65
		7.17.4.2	fHandle	65
		7.17.4.3	flsStopping	65
		7.17.4.4	fStreamld	65
7.18	Socket	Class Ref	erence	65
	7.18.1	Detailed I	Description	67

xii CONTENTS

	7.18.2	Member 7	Typedef Documentation	67
		7.18.2.1	SocketCollection	67
	7.18.3	Member I	Enumeration Documentation	67
		7.18.3.1	SocketType	67
	7.18.4	Construct	tor & Destructor Documentation	67
		7.18.4.1	Socket()	67
		7.18.4.2	Socket(int port)	67
		7.18.4.3	~Socket()	67
	7.18.5	Member I	Function Documentation	68
		7.18.5.1	AcceptConnections(Socket &socket)	68
		7.18.5.2	Bind()	68
		7.18.5.3	Configure()	68
		7.18.5.4	Create()	68
		7.18.5.5	DumpConnected() const	69
		7.18.5.6	FetchMessage(int id=-1) const	69
		7.18.5.7	GetPort() const	69
		7.18.5.8	GetSocketId() const	69
		7.18.5.9	GetSocketType(int sid) const	69
		7.18.5.10	IsWebSocket(int sid) const	69
		7.18.5.11	Listen(int maxconn)	69
		7.18.5.12	PrepareConnection()	70
		7.18.5.13	SelectConnections()	70
		7.18.5.14	SendMessage(Message message, int id=-1) const	70
		7.18.5.15	SetPort(int port)	70
		7.18.5.16	SetSocketId(int sid)	70
		7.18.5.17	Start()	70
		7.18.5.18	Stop()	71
	7.18.6	Field Doo	sumentation	71
		7.18.6.1	fAddress	71
		7.18.6.2	fBuffer	71
		7.18.6.3	fMaster	71
		7.18.6.4	fPort	71
		7.18.6.5	fReadFds	71
		7.18.6.6	fSocketId	71
		7.18.6.7	fSocketsConnected	71
7.19	Socket	Message (Class Reference	72
	7.19.1	Detailed I	Description	74
	7.19.2	Construct		74
		7.19.2.1		74
		7.19.2.2	SocketMessage(const Message &msg)	74

CONTENTS xiii

		7.19.2.3	SocketMessage(const char *msg_s)	74
		7.19.2.4	SocketMessage(std::string msg_s)	75
		7.19.2.5	SocketMessage(const MessageKey &key)	75
		7.19.2.6	SocketMessage(const MessageKey &key, const char *value)	75
		7.19.2.7	SocketMessage(const MessageKey &key, std::string value)	75
		7.19.2.8	SocketMessage(const MessageKey &key, const short value)	76
		7.19.2.9	SocketMessage(const MessageKey &key, const int value)	76
		7.19.2.10	SocketMessage(const MessageKey &key, const long value)	76
		7.19.2.11	SocketMessage(const MessageKey &key, const float value)	76
		7.19.2.12	SocketMessage(const MessageKey &key, const double value)	77
		7.19.2.13	SocketMessage(MessageMap msg_m)	77
		7.19.2.14	\sim SocketMessage()	77
	7.19.3	Member F	Function Documentation	77
		7.19.3.1	Dump(std::ostream &os=std::cout) const	77
		7.19.3.2	GetCleanedValue() const	77
		7.19.3.3	GetIntValue() const	77
		7.19.3.4	GetKey() const	77
		7.19.3.5	GetString() const	77
		7.19.3.6	GetValue() const	78
		7.19.3.7	GetVectorValue() const	78
		7.19.3.8	Object() const	78
		7.19.3.9	SetKeyValue(const MessageKey &key, const char *value)	78
		7.19.3.10	SetKeyValue(const MessageKey &key, short int_value)	78
		7.19.3.11	SetKeyValue(const MessageKey &key, int int_value)	78
		7.19.3.12	SetKeyValue(const MessageKey &key, long int_value)	79
		7.19.3.13	SetKeyValue(const MessageKey &key, float float_value)	79
		7.19.3.14	SetKeyValue(const MessageKey &key, double double_value)	79
		7.19.3.15	String() const	79
	7.19.4	Field Doc	umentation	79
		7.19.4.1	fMessage	80
7.20	DAQ::T	DC Class	Reference	80
	7.20.1	Detailed D	Description	81
	7.20.2	Member E	Enumeration Documentation	81
		7.20.2.1	DetectionMode	81
	7.20.3	Construct	or & Destructor Documentation	81
		7.20.3.1	TDC(unsigned int id, QuickUSBHandler *h)	81
		7.20.3.2	~TDC()	82
	7.20.4	Member F	Function Documentation	82
		7.20.4.1	CheckFirmwareVersion() const	82
		7.20.4.2	FetchEvents()	82

xiv CONTENTS

		7.20.4.3	GetSetupRegister()	82
		7.20.4.4	ReadConfiguration()	82
		7.20.4.5	ReadRegister(unsigned int r)	82
		7.20.4.6	ReadStatus()	82
		7.20.4.7	SendConfiguration()	82
		7.20.4.8	SetSetupRegister(const TDCSetup &c)	82
		7.20.4.9	SoftReset()	82
		7.20.4.10	WriteRegister(unsigned int r, const T &v)	82
	7.20.5	Field Doo	cumentation	82
		7.20.5.1	fBS	82
		7.20.5.2	fControl	82
		7.20.5.3	fld	82
		7.20.5.4	fSetup	82
		7.20.5.5	fStatus	82
		7.20.5.6	fUSB	82
7.21	TDCBo	oundarySc	an Class Reference	83
	7.21.1	Detailed I	Description	84
	7.21.2	Construc	tor & Destructor Documentation	84
		7.21.2.1	TDCBoundaryScan()	84
		7.21.2.2	TDCBoundaryScan(const TDCBoundaryScan &bs)	84
	7.21.3	Member I	Function Documentation	85
		7.21.3.1	SetConstantValues()	85
	7.21.4	Field Doo	cumentation	85
		7.21.4.1	kAuxClock	85
		7.21.4.2	kBunchReset	85
		7.21.4.3	kClk	85
		7.21.4.4	kDataReady	85
		7.21.4.5	kEncodedControl	85
		7.21.4.6	kError	85
		7.21.4.7	kEventReset	85
		7.21.4.8	kGetData	85
		7.21.4.9	kHit	85
		7.21.4.10	kParallelDataOut	85
		7.21.4.11	kParallelEnable	85
		7.21.4.12	RReset	85
		7.21.4.13	B kSerialBypassIn	85
		7.21.4.14	kSerialIn	85
		7.21.4.15	kSerialOut	85
		7.21.4.16	S kStrobeOut	85
		7.21.4.17	'kTest	85

CONTENTS xv

		7.21.4.18	kTokenBypassIn	85
		7.21.4.19	kTokenIn	85
		7.21.4.20	kTokenOut	85
		7.21.4.21	kTrigger	85
7.22	Online	OBHandler	:::TDCConditions Struct Reference	86
	7.22.1	Member I	Function Documentation	86
		7.22.1.1	operator=(const TDCConditions &rhs)	86
		7.22.1.2	operator==(const TDCConditions &rhs) const	86
	7.22.2	Field Doo	eumentation	86
		7.22.2.1	detector	86
		7.22.2.2	run_id	86
		7.22.2.3	tdc_acq_mode	86
		7.22.2.4	tdc_address	86
		7.22.2.5	tdc_det_mode	86
		7.22.2.6	tdc_id	86
7.23	TDCCc	ontrol Class	s Reference	86
	7.23.1	Detailed I	Description	88
	7.23.2	Member I	Enumeration Documentation	88
		7.23.2.1	EnablePattern	88
		7.23.2.2	RegisterName	88
	7.23.3	Construct	tor & Destructor Documentation	88
		7.23.3.1	TDCControl()	88
		7.23.3.2	TDCControl(const TDCControl &c)	89
		7.23.3.3	$\label{eq:total_const} \mbox{TDCControl(const std::vector< uint8_t > \&words)} $	89
	7.23.4	Member I	Function Documentation	89
		7.23.4.1	DisableAllChannels()	89
		7.23.4.2	DisableChannel(unsigned int id)	89
		7.23.4.3	Dump(int verb=1, std::ostream &os=std::cout) const	90
		7.23.4.4	EnableAllChannels()	90
		7.23.4.5	EnableChannel(unsigned int id)	90
		7.23.4.6	GetDLLReset() const	91
		7.23.4.7	GetEnablePattern() const	91
		7.23.4.8	GetGlobalReset() const	91
		7.23.4.9	GetPLLReset() const	92
		7.23.4.10	SetConstantValues()	92
		7.23.4.11	SetControlParity(const bool cp=true)	92
		7.23.4.12	SetDLLReset(const bool dr=true)	92
		7.23.4.13	SetEnablePattern(const EnablePattern &ep)	93
		7.23.4.14	SetGlobalReset(const bool gr=true)	93
		7.23.4.15	SetPLLReset(const bool pr=true)	93

xvi CONTENTS

	7.23.5	Field Documentation	93
		7.23.5.1 kControlParity	93
		7.23.5.2 kDLLReset	93
		7.23.5.3 kEnableChannel	93
		7.23.5.4 kEnablePattern	93
		7.23.5.5 kGlobalReset	93
		7.23.5.6 kPLLReset	94
7.24	TDCEr	rorFlag Class Reference	94
	7.24.1	Detailed Description	94
	7.24.2	Constructor & Destructor Documentation	95
		7.24.2.1 TDCErrorFlag(uint16_t ef)	95
		7.24.2.2 ~TDCErrorFlag()	95
	7.24.3	Member Function Documentation	95
		7.24.3.1 Dump() const	95
		7.24.3.2 GetWord() const	95
		7.24.3.3 HasGroupError(unsigned int group_id) const	95
		7.24.3.4 HasInternalChipError() const	95
		7.24.3.5 HasL1BufferOverflow(unsigned int group_id) const	95
		7.24.3.6 HasReachedEventSizeLimit() const	95
		7.24.3.7 HasReadoutFIFOOverflow(unsigned int group_id) const	95
		7.24.3.8 HasTriggerFIFOOverflow() const	95
	7.24.4	Friends And Related Function Documentation	95
		7.24.4.1 operator<< 9	95
	7.24.5	Field Documentation	95
		7.24.5.1 fWord	95
7.25	TDCEv	ent Class Reference	95
	7.25.1	Detailed Description	97
	7.25.2	Member Enumeration Documentation	97
		7.25.2.1 EventType	97
	7.25.3	Constructor & Destructor Documentation	97
		7.25.3.1 TDCEvent()	97
		7.25.3.2 TDCEvent(const TDCEvent &ev)	97
		7.25.3.3 TDCEvent(const uint32_t &word)	97
		7.25.3.4 TDCEvent(const EventType &ev)	97
		7.25.3.5 ~TDCEvent()	97
	7.25.4	Member Function Documentation	97
		7.25.4.1 Dump() const	98
		7.25.4.2 GetBunchld() const	98
		7.25.4.3 GetChannelId() const	98
		7.25.4.4 GetErrorFlags() const	98

CONTENTS xvii

		7.25.4.5 GetETTT() const	99
		7.25.4.6 GetEventCount() const	99
		7.25.4.7 GetEventId() const	99
		7.25.4.8 GetGeo() const	00
		7.25.4.9 GetStatus() const	00
		7.25.4.10 GetTDCld() const	00
		7.25.4.11 GetTime(bool pair=false) const)1
		7.25.4.12 GetType() const)1
		7.25.4.13 GetWidth() const)1
		7.25.4.14 GetWord() const	ງ2
		7.25.4.15 GetWordCount() const	ງ2
		7.25.4.16 IsTrailing() const	ງ2
		7.25.4.17 SetWord(const uint32_t &word)	ງ2
	7.25.5	Field Documentation	ງ2
		7.25.5.1 fWord	ງ2
7.26	TDCMe	asurement Class Reference	ງ2
	7.26.1	Detailed Description)3
	7.26.2	Constructor & Destructor Documentation)3
		7.26.2.1 TDCMeasurement())3
		7.26.2.2 TDCMeasurement(const std::vector< TDCEvent > &v))3
		7.26.2.3 ~TDCMeasurement())3
	7.26.3	Member Function Documentation)3
		7.26.3.1 Dump())4
		7.26.3.2 GetBunchId())4
		7.26.3.3 GetChannelld(unsigned short event_id=0))4
		7.26.3.4 GetETTT())4
		7.26.3.5 GetEventId())4
		7.26.3.6 GetLeadingTime(unsigned short event_id=0))4
		7.26.3.7 GetTDCld())4
		7.26.3.8 GetToT(unsigned short event_id=0))5
		7.26.3.9 GetTrailingTime(unsigned short event_id=0))5
		7.26.3.10 NumErrors() const)5
		7.26.3.11 NumEvents() const)5
		7.26.3.12 SetEventsCollection(const std::vector $<$ TDCEvent $>$ &v))5
	7.26.4	Field Documentation)5
		7.26.4.1 fEvents)5
		7.26.4.2 fMap)5
7.27	TDCRe	gister Class Reference)5
	7.27.1	Detailed Description)6
	7.27.2	Member Typedef Documentation	ე7

xviii CONTENTS

		7.27.2.1	bit	107
		7.27.2.2	$word_t \ \ldots \ldots \ldots \ldots \ldots \ldots \ldots$	107
	7.27.3	Construc	tor & Destructor Documentation	107
		7.27.3.1	TDCRegister(const unsigned int size)	107
		7.27.3.2	TDCRegister(const unsigned int size, const TDCRegister &r)	107
		7.27.3.3	TDCRegister(const unsigned int size, const std::vector< uint8_t > words)	107
		7.27.3.4	~TDCRegister()	108
	7.27.4	Member	Function Documentation	108
		7.27.4.1	Clear()	108
		7.27.4.2	DumpRegister(std::ostream &os=std::cout, const bit max_bits=-1) const	108
		7.27.4.3	GetBits(uint16_t lsb, uint8_t size) const	108
		7.27.4.4	GetNumWords() const	108
		7.27.4.5	GetWord(const unsigned int i) const	108
		7.27.4.6	GetWords() const	108
		7.27.4.7	operator=(const TDCRegister &r)	108
		7.27.4.8	SetBits(uint16_t lsb, uint16_t word, uint8_t size)	108
		7.27.4.9	SetConstantValues()=0	108
		7.27.4.10	SetWord(const unsigned int i, const word_t word)	109
	7.27.5	Field Doo	cumentation	109
		7.27.5.1	fNumWords	109
		7.27.5.2	fWord	109
		7.27.5.3	fWordSize	109
7.28	TDCSe	tup Class	Reference	109
	7.28.1	Detailed	Description	116
	7.28.2	Member	Enumeration Documentation	116
		7.28.2.1	CoreClockSource	116
		7.28.2.2	DeadTime	117
		7.28.2.3	DLLClockSource	117
		7.28.2.4	DLLSpeedMode	117
		7.28.2.5	EdgeResolution	117
		7.28.2.6	EnabledError	117
		7.28.2.7	IOClockSource	118
		7.28.2.8	ReadoutSingleCycleSpeed	118
		7.28.2.9	ReadoutSpeed	118
		7.28.2.10	SerialClockSource	118
		7.28.2.11	SerialStrobeType	119
		7.28.2.12	WidthResolution	119
	7.28.3	Construc	tor & Destructor Documentation	119
		7.28.3.1	TDCSetup()	120
		7.28.3.2	TDCSetup(const TDCSetup &c)	121

CONTENTS xix

7.28.4	Member F	Function Documentation	121
	7.28.4.1	Dump(int verb=1, std::ostream &os=std::cout) const	122
	7.28.4.2	GetChannelOffset(int channel) const	122
	7.28.4.3	GetCoarseCountOffset() const	122
	7.28.4.4	GetDeadTime() const	123
	7.28.4.5	GetDLLAdjustment(int tap) const	123
	7.28.4.6	GetEdgeResolution() const	124
	7.28.4.7	GetEdgesPairing() const	124
	7.28.4.8	GetEnableError() const	124
	7.28.4.9	GetEnableErrorBypass() const	125
	7.28.4.10	GetEnableErrorMark() const	125
	7.28.4.11	GetEnableJTAGReadout() const	125
	7.28.4.12	GetEnableReadoutOccupancy() const	126
	7.28.4.13	GetEnableReadoutSeparator() const	126
	7.28.4.14	GetEnableSerial() const	126
	7.28.4.15	GetLeadingMode() const	126
	7.28.4.16	GetMatchWindow() const	127
	7.28.4.17	GetMaxEventSize() const	127
	7.28.4.18	GetRCAdjustment(int tap)	127
	7.28.4.19	GetReadoutFIFOSize() const	128
	7.28.4.20	GetRejectCountOffset() const	128
	7.28.4.21	GetRejectFIFOFull() const	128
	7.28.4.22	GetSearchWindow() const	129
	7.28.4.23	GetSetupParity() const	129
	7.28.4.24	GetTDCId() const	130
	7.28.4.25	GetTestInvert() const	130
	7.28.4.26	GetTestMode() const	130
	7.28.4.27	GetTrailingMode() const	130
	7.28.4.28	GetTriggerCountOffset() const	131
	7.28.4.29	GetTriggerLatency() const	131
	7.28.4.30	GetTriggerMatchingMode() const	131
	7.28.4.31	GetVernierOffset() const	132
	7.28.4.32	GetWidthResolution() const	132
	7.28.4.33	SetAllChannelsOffset(uint16_t offset)	132
	7.28.4.34	SetAllTapsDLLAdjustment(uint8_t adj)	133
	7.28.4.35	SetBypassInputs(const bool sbi=true)	133
		SetChannelOffset(int channel, uint16_t offset)	
		SetCoarseCountOffset(uint16_t cco)	
		SetConstantValues()	
	7.28.4.39	SetCoreClockDelay(const bool delay_clock, const uint8_t delay)	134

CONTENTS

7.28.4.40 SetCoreClockSource(const CoreClockSource ccs)
7.28.4.41 SetDeadTime(const DeadTime dt)
7.28.4.42 SetDLLAdjustment(int tap, uint8_t adj)
7.28.4.43 SetDLLClockDelay(const bool delay_clock, const uint8_t delay) 135
7.28.4.44 SetDLLClockSource(const DLLClockSource dcs)
7.28.4.45 SetDLLControl(const uint8_t dc)
7.28.4.46 SetDLLMode(const DLLSpeedMode dsm)
7.28.4.47 SetEdgeResolution(const EdgeResolution r)
7.28.4.48 SetEdgesPairing(const bool pair=true)
7.28.4.49 SetEnableAutomaticReject(const bool ear=true) 137
7.28.4.50 SetEnableBytewise(const bool seb=true)
7.28.4.51 SetEnableDirectBunchReset(const bool edbr=true)
7.28.4.52 SetEnableDirectEventReset(const bool eder=true)
7.28.4.53 SetEnableDirectTrigger(const bool edt=true)
7.28.4.54 SetEnableError(const uint16_t &err)
7.28.4.55 SetEnableErrorBypass(const bool eb)
7.28.4.56 SetEnableErrorMark(const bool em)
7.28.4.57 SetEnableGlobalHeader(const bool egh=true)
7.28.4.58 SetEnableGlobalTrailer(const bool egt=true)
7.28.4.59 SetEnableJTAGReadout(const bool jr)
7.28.4.60 SetEnableLocalHeader(const bool elh=true)
7.28.4.61 SetEnableLocalTrailer(const bool elt=true)
7.28.4.62 SetEnableMasterResetCode(const bool emrc=true)
7.28.4.63 SetEnableMasterResetOnEventReset(const bool emroer=true) 142
7.28.4.64 SetEnableOverflowDetect(const bool eod=true)
7.28.4.65 SetEnableReadoutOccupancy(const bool ro=true)
7.28.4.66 SetEnableReadoutSeparator(const bool ro=true)
7.28.4.67 SetEnableRelative(const bool er=true)
7.28.4.68 SetEnableResetChannelBufferWhenSeparator(const bool ercbws=true) 143
7.28.4.69 SetEnableSeparatorOnBunchReset(const bool esobr=true)
7.28.4.70 SetEnableSeparatorOnEventReset(const bool esoer=true)
7.28.4.71 SetEnableSerial(const bool es)
7.28.4.72 SetEnableSetCountersOnBunchReset(const bool escobr=true)
7.28.4.73 SetEnableTTLClock(const bool tc=true)
7.28.4.74 SetEnableTTLControl(const bool tc=true)
7.28.4.75 SetEnableTTLHit(const bool th=true)
7.28.4.76 SetEnableTTLReset(const bool tr=true)
7.28.4.77 SetEnableTTLSerial(const bool ts=true)
7.28.4.78 SetEventCountOffset(uint16_t eco)
7.28.4.79 SetIOClockDelay(const bool delay_clock, const uint8_t delay)

CONTENTS xxi

	7.28.4.80 SetIOClockSource(const IOClockSource ics)	148
	7.28.4.81 SetKeepToken(const bool kt=true)	148
	7.28.4.82 SetLeadingMode(const bool lead=true)	148
	7.28.4.83 SetLowPowerMode(const bool lpm=true)	148
	7.28.4.84 SetMaster(const bool m=true)	149
	7.28.4.85 SetMatchWindow(uint16_t mw)	149
	7.28.4.86 SetMaxEventSize(int sz=-1)	149
	7.28.4.87 SetModeRC(const bool mr=true)	150
	7.28.4.88 SetModeRCCompression(const bool mrc=true)	150
	7.28.4.89 SetPLLControl(const uint8_t charge_pump_current=0x4, const bool power_ down_mode=false, const bool enable_test_outputs=false, const bool invert_ connection_to_status=false)	150
	7.28.4.90 SetRCAdjustment(int tap, uint8_t adj)	151
	7.28.4.91 SetReadoutFIFOSize(int rfs)	151
	$7.28.4.92 \ SetReadoutSingleCycleSpeed (const. ReadoutSingleCycleSpeed$	151
	7.28.4.93 SetReadoutSpeedSelect(const ReadoutSpeed rss=RO_Fixed)	152
	7.28.4.94 SetRejectCountOffset(uint16_t rco)	152
	7.28.4.95 SetRejectFIFOFull(const bool rej=true)	153
	7.28.4.96 SetRollOver(const uint16_t ro=0xFFF)	153
	7.28.4.97 SetSearchWindow(uint16_t sw)	153
	7.28.4.98 SetSerialClockDelay(const bool delay_clock, const uint8_t delay)	153
	7.28.4.99 SetSerialClockSource(const SerialClockSource scs)	154
	7.28.4.100SetSerialDelay(const uint8_t sd=0x0)	154
	7.28.4.101SetSetupParity(const bool sp=true)	154
	7.28.4.102SetStrobeSelect(const SerialStrobeType ss=SS_NoStrobe)	155
	7.28.4.103SetTDCId(const uint8_t id=0x0)	155
	7.28.4.104SetTest(const bool test=true)	156
	7.28.4.105SetTestInvert(const bool ti=true)	156
	7.28.4.10&etTestMode(const bool tm=true)	156
	7.28.4.107SetTokenDelay(const uint8_t td=0x0)	156
	7.28.4.10&etTrailingMode(const bool trail=true)	157
	7.28.4.109SetTriggerCountOffset(uint16_t tco)	157
	7.28.4.11©setTriggerMatchingMode(const bool trig=true)	157
	7.28.4.111SetVernierOffset(const uint8_t vo)	158
	7.28.4.11 SetWidthResolution(const WidthResolution r)	158
7.28.5	Field Documentation	158
	7.28.5.1 kCoarseCountOffset	158
	7.28.5.2 kCoreClockDelay	158
	7.28.5.3 kCoreClockSource	158
	7.28.5.4 kDeadTime	158

xxii CONTENTS

7.28.5.5 kDLLClockDelay
7.28.5.6 kDLLClockSource
7.28.5.7 kDLLControl
7.28.5.8 kDLLMode
7.28.5.9 kDLLTapAdjust0
7.28.5.10 kEnableAutomaticReject
7.28.5.11 kEnableBytewise
7.28.5.12 kEnableDirectBunchReset
7.28.5.13 kEnableDirectEventReset
7.28.5.14 kEnableDirectTrigger
7.28.5.15 kEnableError
7.28.5.16 kEnableErrorBypass
7.28.5.17 kEnableErrorMark
7.28.5.18 kEnableGlobalHeader
7.28.5.19 kEnableGlobalTrailer
7.28.5.20 kEnableJTAGReadout
7.28.5.21 kEnableLocalHeader
7.28.5.22 kEnableLocalTrailer
7.28.5.23 kEnableMasterResetCode
7.28.5.24 kEnableMasterResetOnEventReset
7.28.5.25 kEnableMatching
7.28.5.26 kEnableOverflowDetect
7.28.5.27 kEnablePair
7.28.5.28 kEnableReadoutOccupancy
7.28.5.29 kEnableReadoutSeparator
7.28.5.30 kEnableRelative
7.28.5.31 kEnableResetChannelBufferWhenSeparator
7.28.5.32 kEnableSeparatorOnBunchReset
7.28.5.33 kEnableSeparatorOnEventReset
7.28.5.34 kEnableSerial
7.28.5.35 kEnableSetCountersOnBunchReset
7.28.5.36 kEnableTTLClock
7.28.5.37 kEnableTTLControl
7.28.5.38 kEnableTTLHit
7.28.5.39 kEnableTTLReset
7.28.5.40 kEnableTTLSerial
7.28.5.41 kEventCountOffset
7.28.5.42 kIOClockDelay
7.28.5.43 kIOClockSource
7.28.5.44 kKeepToken

CONTENTS xxiii

	7.28.5.45 kLeading	160
	7.28.5.46 kLeadingResolution	160
	7.28.5.47 kLowPowerMode	160
	7.28.5.48 kMaster	160
	7.28.5.49 kMatchWindow	160
	7.28.5.50 kMaxEventSize	160
	7.28.5.51 kModeRC	160
	7.28.5.52 kModeRCCompression	160
	7.28.5.53 kOffset0	160
	7.28.5.54 kPLLControl	160
	7.28.5.55 kRCAdjust0	160
	7.28.5.56 kReadoutFIFOSize	160
	7.28.5.57 kReadoutSingleCycleSpeed	160
	7.28.5.58 kReadoutSpeedSelect	160
	7.28.5.59 kRejectCountOffset	160
	7.28.5.60 kRejectFIFOFull	160
	7.28.5.61 kRollOver	160
	7.28.5.62 kSearchWindow	161
	7.28.5.63 kSelectBypassInputs	161
	7.28.5.64 kSerialClockDelay	161
	7.28.5.65 kSerialClockSource	161
	7.28.5.66 kSerialDelay	161
	7.28.5.67 kSetupParity	161
	7.28.5.68 kStrobeSelect	161
	7.28.5.69 kTDCld	161
	7.28.5.70 kTestInvert	161
	7.28.5.71 kTestMode	161
	7.28.5.72 kTestSelect	161
	7.28.5.73 kTokenDelay	
	7.28.5.74 kTrailing	
	7.28.5.75 kTriggerCountOffset	161
	7.28.5.76 kVernierOffset	161
	7.28.5.77 kWidthSelect	161
7.29 TDCS	atus Class Reference	161
7.29.1	Detailed Description	163
7.29.2	Constructor & Destructor Documentation	163
	7.29.2.1 TDCStatus()	163
	7.29.2.2 TDCStatus(const TDCStatus &s)	
	7.29.2.3 TDCStatus(const std::vector< uint8_t > &words)	
7.29.3	Member Function Documentation	164

xxiv CONTENTS

		7.29.3.1	DLLLock() const
		7.29.3.2	Dump(int verb=1, std::ostream &os=std::cout) const
		7.29.3.3	Error() const
		7.29.3.4	FIFOEmpty() const
		7.29.3.5	FIFOFull() const
		7.29.3.6	FIFOOccupancy() const
		7.29.3.7	HaveToken() const
		7.29.3.8	L1Occupancy() const
		7.29.3.9	SetConstantValues()
		7.29.3.10	TriggerFIFOEmpty() const
		7.29.3.11	TriggerFIFOFull() const
		7.29.3.12	TriggerFIFOOccupancy() const
	7.29.4	Field Doo	numentation
		7.29.4.1	kDLLLock
		7.29.4.2	kError
		7.29.4.3	kHaveToken
		7.29.4.4	kL1Occupancy
		7.29.4.5	kReadoutFIFOEmpty
		7.29.4.6	kReadoutFIFOFull
		7.29.4.7	kReadoutFIFOOccupancy
		7.29.4.8	kTriggerFIFOEmpty
		7.29.4.9	kTriggerFIFOFull
		7.29.4.10	kTriggerFIFOOccupancy
7.30	DAQ::C	QuickUSBF	Handler::Version Struct Reference
	7.30.1	Field Doo	umentation
		7.30.1.1	BuildVersion
		7.30.1.2	MajorVersion
		7.30.1.3	MinorVersion

Index

169

Chapter 1

Module Index

1	1	Module	26

Here	ie	2	liet	Λf	all	modi	عمار

Socket communication objects	9
FPGA board control	10
HPTDC chip control	11

2 Module Index

Chapter 2

Namespace Index

2.1	Names	pace	List
	11411100	1000	

Here is	a li	st c	of a	all r	nar	ne	sp	ac	es	w	ith	b	rie	f d	les	cr	ip	tio	ns	: :													
DA	Q.																												 				13
DQ	M																												 				13

4 Namespace Index

Chapter 3

Hierarchical Index

3.1 Class Hierarchy

This inheritance list is sorted roughly, but not completely, alphabetically:

OnlineDBHandler::BurstInfo
DQM::GastofCanvas::Coord
DQM::QuarticCanvas::Coord
file_header_t
FileReader
Logger
LogRedirector
Message
SocketMessage
OnlineDBHandler
DAQ::QuickUSBHandler
DAQ::FPGAHandler
Socket
Client
DAQ::FPGAHandler
DQM::DQMProcess
Messenger
TCanvas
DQM::GastofCanvas
DQM::PPSCanvas
DQM::QuarticCanvas
DAQ::TDC
OnlineDBHandler::TDCConditions
TDCErrorFlag
TDCEvent
TDCMeasurement
TDCRegister
TDCBoundaryScan
TDCControl
TDCSetup
TDCStatus
DAQ::QuickUSBHandler::Version

6 Hierarchical Index

Chapter 4

Data Structure Index

4.1 Data Structures

	Here	are	the	data	structures	with	brief	descri	ptions:
--	------	-----	-----	------	------------	------	-------	--------	---------

OnlineDBHandler::BurstInfo	15
Base client object for the socket	15
DQM::GastofCanvas::Coord	21
DQM::QuarticCanvas::Coord	22
DQM::DQMProcess	
Handler for a common DQM process to run on the socket	22
file header t	
Header to the output files	26
FileReader	
Handler for a TDC output file readout	27
DAQ::FPGAHandler	
Driver for timing detectors' FPGA readout	30
DQM::GastofCanvas	36
Logger	
Redirect outputs to another output stream	40
LogRedirector	
Redirect output stream to a string	41
Message	
Base socket message type	42
Messenger	
Base master object for the socket	44
OnlineDBHandler	
Handler for the run information online database	51
DQM::PPSCanvas	55
DQM::QuarticCanvas	58
DAQ::QuickUSBHandler	
Generic QuickUSB communication handler	62
Socket	
Base socket object from which clients/master from a socket inherit	65
SocketMessage	
Socket-passed message type	72
DAQ::TDC	. –
HPTDC object	80
TDCBoundaryScan	83
OnlineDBHandler::TDCConditions	86
TDCControl	55
Control word to be sent to the HPTDC chip	86

8 Data Structure Index

OCErrorFlag	
Error flags handler	94
OCEvent	
HPTDC event parser	95
OCMeasurement	ງ2
OCRegister	
General register object to interact with a HPTDC chip)5
OCSetup Control of the Control of th	
Setup word to be sent to the HPTDC chip)9
OCStatus	31
AO::OuickUSBHandler::Version	86

Chapter 5

Module Documentation

5.1 Socket communication objects

Data Structures

· class Client

Base client object for the socket.

class Messenger

Base master object for the socket.

class Socket

Base socket object from which clients/master from a socket inherit.

• class SocketMessage

Socket-passed message type.

5.1.1 Detailed Description

10 Module Documentation

5.2 FPGA board control

Data Structures

• class DAQ::FPGAHandler

Driver for timing detectors' FPGA readout.

- struct DAQ::QuickUSBHandler::Version
- class DAQ::QuickUSBHandler

Generic QuickUSB communication handler.

5.2.1 Detailed Description

5.3 HPTDC chip control 11

5.3 HPTDC chip control

Data Structures

class TDCErrorFlag

Error flags handler.

class TDCEvent

HPTDC event parser.

• class DAQ::TDC

HPTDC object.

- class TDCBoundaryScan
- class TDCControl

Control word to be sent to the HPTDC chip.

class TDCRegister

General register object to interact with a HPTDC chip.

class TDCSetup

Setup word to be sent to the HPTDC chip.

· class TDCStatus

Enumerations

enum AcquisitionMode { CONT_STORAGE, TRIG_MATCH }

TDC acquisition mode.

enum DAQ::TDC::AcquisitionMode { DAQ::TDC::CONT_STORAGE, DAQ::TDC::TRIG_MATCH }

TDC acquisition mode.

- 5.3.1 Detailed Description
- 5.3.2 Enumeration Type Documentation
- 5.3.2.1 enum AcquisitionMode

TDC acquisition mode.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Enumerator

CONT_STORAGE
TRIG_MATCH

5.3.2.2 enum DAQ::TDC::AcquisitionMode

TDC acquisition mode.

Enumerator

CONT_STORAGE
TRIG_MATCH

12 Module Documentation

Chapter 6

Namespace Documentation

6.1 DAQ Namespace Reference

Data Structures

· class FPGAHandler

Driver for timing detectors' FPGA readout.

• class QuickUSBHandler

Generic QuickUSB communication handler.

class TDC

HPTDC object.

6.2 DQM Namespace Reference

Data Structures

• class DQMProcess

Handler for a common DQM process to run on the socket.

- class GastofCanvas
- class PPSCanvas
- class QuarticCanvas

Chapter 7

Data Structure Documentation

7.1 OnlineDBHandler::BurstInfo Struct Reference

#include <OnlineDBHandler.h>

Data Fields

- · unsigned int burst_id
- unsigned int time_start

7.1.1 Field Documentation

7.1.1.1 unsigned int OnlineDBHandler::BurstInfo::burst_id

7.1.1.2 unsigned int OnlineDBHandler::BurstInfo::time_start

The documentation for this struct was generated from the following file:


• include/OnlineDBHandler.h

7.2 Client Class Reference


Base client object for the socket.

#include <Client.h>

Inheritance diagram for Client:



Collaboration diagram for Client:



Public Member Functions

• Client ()

General void client constructor.

• Client (int port)

Bind a socket client to a given port.

- virtual ∼Client ()
- bool Connect (const SocketType &type=CLIENT)

Bind this client to the socket.

• void Disconnect ()

Unbind this client from the socket.

• void Send (const Message &m) const

Send a message to the master through the socket.

- · void Send (const Exception &e) const
- SocketMessage SendAndReceive (const SocketMessage &m, const MessageKey &a) const
- void Receive ()

7.2 Client Class Reference 17

Receive a socket message from the master.

- SocketMessage Receive (const MessageKey &key)
- virtual void ParseMessage (const SocketMessage &m)

Parse a SocketMessage received from the master.

virtual SocketType GetType () const

Socket actor type retrieval method.

Private Member Functions

• void Announce ()

Announce our entry on the socket to its master.

Private Attributes

- · int fClientId
- · bool flsConnected
- SocketType fType

Additional Inherited Members

7.2.1 Detailed Description

Base client object for the socket.

Client object used by the server to send/receive commands from the messenger/broadcaster.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

24 Mar 2015

7.2.2 Constructor & Destructor Documentation

```
7.2.2.1 Client::Client() [inline]
```


General void client constructor.

7.2.2.2 Client::Client (int port)

Bind a socket client to a given port.

7.2.2.3 Client::~Client() [virtual]

Here is the call graph for this function:




7.2.3 Member Function Documentation

7.2.3.1 void Client::Announce() [private]

Announce our entry on the socket to its master.

Here is the call graph for this function:




7.2.3.2 bool Client::Connect (const SocketType & type = CLIENT)

Bind this client to the socket.

7.2 Client Class Reference 19


Here is the call graph for this function:



7.2.3.3 void Client::Disconnect ()

Unbind this client from the socket.

Here is the call graph for this function:



7.2.3.4 virtual SocketType Client::GetType () const [inline], [virtual]

Socket actor type retrieval method.

Reimplemented in DAQ::FPGAHandler.


7.2.3.5 virtual void Client::ParseMessage (const SocketMessage & m) [inline], [virtual]

Parse a SocketMessage received from the master.

7.2.3.6 void Client::Receive ()


Receive a socket message from the master.

Here is the call graph for this function:




7.2.3.7 SocketMessage Client::Receive (const MessageKey & key)

Here is the call graph for this function:




7.2.3.8 void Client::Send (const Message & m) const [inline]

Send a message to the master through the socket.




7.2.3.9 void Client::Send (const Exception & e) const [inline]

Here is the call graph for this function:



7.2.3.10 SocketMessage Client::SendAndReceive (const SocketMessage & m, const MessageKey & a) const [inline]

Here is the call graph for this function:



7.2.4 Field Documentation

7.2.4.1 int Client::fClientId [private]

7.2.4.2 bool Client::flsConnected [private]

7.2.4.3 SocketType Client::fType [private]

The documentation for this class was generated from the following files:

- include/Client.h
- · src/Client.cpp

7.3 DQM::GastofCanvas::Coord Struct Reference

Data Fields

- · unsigned int x
- · unsigned int y

7.3.1 Field Documentation

- 7.3.1.1 unsigned int DQM::GastofCanvas::Coord::x
- 7.3.1.2 unsigned int DQM::GastofCanvas::Coord::y

The documentation for this struct was generated from the following file:

· include/GastofCanvas.h

7.4 DQM::QuarticCanvas::Coord Struct Reference

Data Fields

- unsigned int x
- · unsigned int y

7.4.1 Field Documentation

- 7.4.1.1 unsigned int DQM::QuarticCanvas::Coord::x
- 7.4.1.2 unsigned int DQM::QuarticCanvas::Coord::y

The documentation for this struct was generated from the following file:


• include/QuarticCanvas.h

7.5 DQM::DQMProcess Class Reference


Handler for a common DQM process to run on the socket.

#include <DQMProcess.h>

Inheritance diagram for DQM::DQMProcess:



Collaboration diagram for DQM::DQMProcess:



Public Types

• enum Action { NewPlot = 0x0, UpdatedPlot = 0x1 }

Public Member Functions

- DQMProcess (int port, unsigned short order=0, const char *det_type="")
- ∼DQMProcess ()
- void Run (bool(*fcn)(unsigned int addr, std::string filename, std::vector< std::string > *outputs), const Action
 &act=NewPlot)

Run a DQM plotter making use of the board/output filename information.

void Run (bool(*fcn)(std::vector< std::string > *outputs), const Action &act=NewPlot)

Run a DQM plotter without any information on the board/output filename.

Private Member Functions

- int ParseMessage (uint32_t *board_address, std::string *filename)
- bool IsInRun ()

Private Attributes

- unsigned short fOrder
- unsigned int fRunNumber
- std::string fDetectorType
- std::map< unsigned long, std::string > fAddressesCanProcess

Additional Inherited Members

7.5.1 Detailed Description

Handler for a common DQM process to run on the socket.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

3 Aug 2015

7.5.2 Member Enumeration Documentation

7.5.2.1 enum DQM::DQMProcess::Action

Enumerator


NewPlot

UpdatedPlot

7.5.3 Constructor & Destructor Documentation


7.5.3.1 DQM::DQMProcess::DQMProcess (int port, unsigned short order = 0, const char * $det_type = ""$) [inline]

Here is the call graph for this function:



7.5.3.2 DQM::DQMProcess::~DQMProcess() [inline]

Here is the call graph for this function:



7.5.4 Member Function Documentation


7.5.4.1 bool DQM::DQMProcess::IsInRun() [inline], [private]

Here is the call graph for this function:




7.5.4.2 int DQM::DQMProcess::ParseMessage (uint32_t * board_address, std::string * filename) [inline], [private]

Here is the call graph for this function:



7.5.4.3 void DQM::DQMProcess::Run (bool(*)(unsigned int addr, std::string filename, std::vector< std::string > *outputs) fcn, const Action & act = NewPlot) [inline]


Run a DQM plotter making use of the board/output filename information.



7.5.4.4 void DQM::DQMProcess::Run (bool(*)(std::vector< std::string > *outputs) fcn, const Action & act = NewPlot)
[inline]

Run a DQM plotter without any information on the board/output filename.

Here is the call graph for this function:



7.5.5 Field Documentation

- 7.5.5.1 std::map<unsigned long, std::string> DQM::DQMProcess::fAddressesCanProcess [private]
- **7.5.5.2 std::string DQM::DQMProcess::fDetectorType** [private]
- **7.5.5.3 unsigned short DQM::DQMProcess::fOrder** [private]
- **7.5.5.4 unsigned int DQM::DQMProcess::fRunNumber** [private]

The documentation for this class was generated from the following file:

• include/DQMProcess.h

7.6 file_header_t Struct Reference

Header to the output files.

#include <FileConstants.h>

Data Fields

- · uint32_t magic
- · uint32_t run_id
- uint32_t spill_id
- uint8_t num_hptdc
- · AcquisitionMode acq_mode
- DetectionMode det_mode

7.6.1 Detailed Description

Header to the output files.

General header to store in each collected data file for offline readout. It enable any reader to retrieve the run/spill number, as well as the HPTDC configuration during data collection.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

14 Apr 2015

- 7.6.2 Field Documentation
- 7.6.2.1 AcquisitionMode file_header_t::acq_mode
- 7.6.2.2 DetectionMode file_header_t::det_mode
- 7.6.2.3 uint32_t file_header_t::magic
- 7.6.2.4 uint8_t file_header_t::num_hptdc
- 7.6.2.5 uint32_t file_header_t::run_id
- 7.6.2.6 uint32_t file_header_t::spill_id

The documentation for this struct was generated from the following file:


• include/FileConstants.h

7.7 FileReader Class Reference

Handler for a TDC output file readout.

#include <FileReader.h>

Collaboration diagram for FileReader:



Public Member Functions

- FileReader ()
- FileReader (std::string name)

Class constructor.

∼FileReader ()

- void Open (std::string name)
- bool IsOpen () const
- void Clear ()
- void Dump () const
- unsigned int GetNumTDCs () const
- unsigned int GetRunId () const
- unsigned int GetBurstld () const
- unsigned int GetAcquisitionMode () const
- unsigned int GetDetectionMode () const
- unsigned long GetNumEvents () const
- bool GetNextEvent (TDCEvent *)
- bool GetNextMeasurement (unsigned int channel_id, TDCMeasurement *mc)

Fetch the next full measurement on a given channel.

Private Attributes

- std::ifstream fFile
- file_header_t fHeader
- · AcquisitionMode fReadoutMode
- time t fWriteTime
- unsigned long fNumEvents

7.7.1 Detailed Description

Handler for a TDC output file readout.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

Jun 2015

7.7.2 Constructor & Destructor Documentation

```
7.7.2.1 FileReader::FileReader( ) [inline]
```

7.7.2.2 FileReader::FileReader (std::string name)

Class constructor.


Parameters

in	name	Path to the file to read
in	ro	Data readout mode (continuous storage or trigger matching)



- 7.7.2.3 FileReader::~FileReader()
- 7.7.3 Member Function Documentation
- 7.7.3.1 void FileReader::Clear () [inline]
- 7.7.3.2 void FileReader::Dump () const
- $\textbf{7.7.3.3} \quad \textbf{unsigned int FileReader::} \textbf{GetAcquisitionMode() const} \quad \texttt{[inline]}$
- 7.7.3.4 unsigned int FileReader::GetBurstld () const [inline]
- 7.7.3.5 unsigned int FileReader::GetDetectionMode () const [inline]
- 7.7.3.6 bool FileReader::GetNextEvent (TDCEvent * ev)

Here is the call graph for this function:



7.7.3.7 bool FileReader::GetNextMeasurement (unsigned int channel_id, TDCMeasurement * mc)


Fetch the next full measurement on a given channel.

Parameters

in	channel_id	Unique identifier of the channel number to retrieve
out	m	A full measurement with leading, trailing times,

Returns

A boolean stating the success of retrieval operation



7.7.3.8 unsigned long FileReader::GetNumEvents() const [inline]
7.7.3.9 unsigned int FileReader::GetNumTDCs() const [inline]
7.7.3.10 unsigned int FileReader::GetRunId() const [inline]
7.7.3.11 bool FileReader::IsOpen() const [inline]
7.7.3.12 void FileReader::Open(std::string name)
7.7.4 Field Documentation
7.7.4.1 std::ifstream FileReader::fFile [private]
7.7.4.2 file_header_t FileReader::fHeader [private]
7.7.4.3 unsigned long FileReader::fNumEvents [private]
7.7.4.4 AcquisitionMode FileReader::fReadoutMode [private]
7.7.4.5 time_t FileReader::fWriteTime [private]

The documentation for this class was generated from the following files:


- · include/FileReader.h
- src/FileReader.cpp

7.8 DAQ::FPGAHandler Class Reference


Driver for timing detectors' FPGA readout.

#include <FPGAHandler.h>

Inheritance diagram for DAQ::FPGAHandler:



Collaboration diagram for DAQ::FPGAHandler:



Public Member Functions

- FPGAHandler (int port, const char *dev)

 Bind to a FPGA through the USB protocol, and to the socket.
- ∼FPGAHandler ()
- void Stop ()
- · void OpenFile ()

Open an output file to store header/HPTDC events.

• void CloseFile ()

Close a previously opened output file used to store header/HPTDC events.

• std::string GetFilename () const

Retrieve the file name used to store data collected from the FPGA.

- TDC * GetTDC (unsigned int i=0)
- void SetTDCSetup (const TDCSetup &s)
- bool ErrorState ()
- void StartAcquisition ()
- void StopAcquisition ()
- SocketType GetType () const

Socket actor type retrieval method.

- TDCControl GetTDCControl () const
- TDCStatus GetTDCStatus () const

Private Member Functions

- · void RegisterTest () const
- void SendSetupWord () const
- · void RetrieveSetupWord () const

Private Attributes

- std::string fFilename
- std::ofstream fOutput
- bool flsFileOpen
- TDC * fTDC [NUM HPTDC]
- bool flsTDCInReadout

Additional Inherited Members

7.8.1 Detailed Description

Driver for timing detectors' FPGA readout.

Main driver for a homebrew FPGA designed for the timing detectors' HPTDC chip readout.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date


14 Apr 2015

7.8.2 Constructor & Destructor Documentation

7.8.2.1 DAQ::FPGAHandler::FPGAHandler (int port, const char * dev)

Bind to a FPGA through the USB protocol, and to the socket.

Here is the call graph for this function:



7.8.2.2 DAQ::FPGAHandler::~FPGAHandler()



7.8.3 Member Function Documentation

7.8.3.1 void DAQ::FPGAHandler::CloseFile ()

Close a previously opened output file used to store header/HPTDC events.

7.8.3.2 bool DAQ::FPGAHandler::ErrorState ()


7.8.3.3 std::string DAQ::FPGAHandler::GetFilename() const [inline]

Retrieve the file name used to store data collected from the FPGA.

7.8.3.4 TDC* DAQ::FPGAHandler::GetTDC (unsigned int *i* = 0) [inline]


7.8.3.5 TDCControl DAQ::FPGAHandler::GetTDCControl () const

Here is the call graph for this function:



7.8.3.6 TDCStatus DAQ::FPGAHandler::GetTDCStatus () const

Here is the call graph for this function:



7.8.3.7 SocketType DAQ::FPGAHandler::GetType() const [inline], [virtual]

Socket actor type retrieval method.

Reimplemented from Client.

7.8.3.8 void DAQ::FPGAHandler::OpenFile ()


Open an output file to store header/HPTDC events.

7.8.3.9 void DAQ::FPGAHandler::RegisterTest() const [private]

Here is the call graph for this function:




7.8.3.10 void DAQ::FPGAHandler::RetrieveSetupWord() const [private]



7.8.3.11 void DAQ::FPGAHandler::SendSetupWord() const [private]

Here is the call graph for this function:



7.8.3.12 void DAQ::FPGAHandler::SetTDCSetup (const TDCSetup & s) [inline]

Here is the call graph for this function:



7.8.3.13 void DAQ::FPGAHandler::StartAcquisition ()

Here is the call graph for this function:



7.8.3.14 void DAQ::FPGAHandler::Stop() [inline]

7.8.3.15 void DAQ::FPGAHandler::StopAcquisition ()

Here is the call graph for this function:



7.8.4 Field Documentation

- **7.8.4.1 std::string DAQ::FPGAHandler::fFilename** [private]
- **7.8.4.2** bool DAQ::FPGAHandler::flsFileOpen [private]
- **7.8.4.3 bool DAQ::FPGAHandler::flsTDClnReadout** [private]
- **7.8.4.4** std::ofstream DAQ::FPGAHandler::fOutput [private]
- **7.8.4.5 TDC* DAQ::FPGAHandler::fTDC[NUM_HPTDC]** [private]


The documentation for this class was generated from the following files:

- · daq/include/FPGAHandler.h
- · daq/src/FPGAHandler.cpp


7.9 DQM::GastofCanvas Class Reference

#include <GastofCanvas.h>

Inheritance diagram for DQM::GastofCanvas:



Collaboration diagram for DQM::GastofCanvas:



Data Structures

struct Coord

Public Member Functions

- GastofCanvas ()
- GastofCanvas (TString name, unsigned int width=500, unsigned int height=500, TString upper_label="")
- GastofCanvas (TString name, TString upper label)
- virtual ∼GastofCanvas ()
- void SetRunInfo (unsigned int board_id, unsigned int run_id, unsigned int spill_id, TString date)
- void SetUpperLabel (TString text)
- · void FillChannel (unsigned short nino_id, unsigned short channel_id, double content)
- TH2D * Grid ()
- void Save (TString ext="png", TString path=".")

Private Member Functions

- · void Build ()
- void DrawGrid ()
- Coord GetCoordinates (unsigned short nino_id, unsigned short channel_id) const

Private Attributes

- TPad * c1
- TPad * c2
- TH2D * fHist
- double fWidth
- double fHeight
- TLegend * fLegend
- double fLegendX
- double fLegendY
- unsigned int fLegendNumEntries
- TPaveText * fLabel1
- TPaveText * fLabel2
- TPaveText * fLabel3

- TPaveText * fLabel4
- TString fUpperLabelText
- TPaveText * fUpperLabel
- bool fLabelsDrawn
- · unsigned int fBoardId
- · unsigned int fRunId
- · unsigned int fSpillId
- TString fRunDate

7.9.1 Detailed Description

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

25 Jul 2015

7.9.2 Constructor & Destructor Documentation


7.9.2.1 DQM::GastofCanvas::GastofCanvas() [inline]

7.9.2.2 DQM::GastofCanvas::GastofCanvas (TString *name*, unsigned int *width* = 500, unsigned int *height* = 500, TString *upper_label* = "") [inline]

Here is the call graph for this function:




7.9.2.3 DQM::GastofCanvas::GastofCanvas (TString name, TString upper_label) [inline]




- 7.9.2.4 virtual DQM::GastofCanvas::∼GastofCanvas() [inline], [virtual]
- 7.9.3 Member Function Documentation
- 7.9.3.1 void DQM::GastofCanvas::Build() [inline], [private]
- 7.9.3.2 void DQM::GastofCanvas::DrawGrid() [inline], [private]
- 7.9.3.3 void DQM::GastofCanvas::FillChannel (unsigned short *nino_id*, unsigned short *channel_id*, double *content*) [inline]

Here is the call graph for this function:



- **7.9.3.4 Coord DQM::**GastofCanvas::GetCoordinates (unsigned short *nino_id*, unsigned short *channel_id*) const [inline], [private]
- 7.9.3.5 TH2D* DQM::GastofCanvas::Grid() [inline]
- 7.9.3.6 void DQM::GastofCanvas::Save (TString ext = "png", TString path = ".") [inline]



- 7.9.3.7 void DQM::GastofCanvas::SetRunInfo (unsigned int *board_id*, unsigned int *run_id*, unsigned int *spill_id*, TString *date*) [inline]
- 7.9.3.8 void DQM::GastofCanvas::SetUpperLabel(TString text) [inline]
- 7.9.4 Field Documentation

```
7.9.4.1 TPad* DQM::GastofCanvas::c1 [private]
7.9.4.2 TPad * DQM::GastofCanvas::c2 [private]
7.9.4.3 unsigned int DQM::GastofCanvas::fBoardId [private]
7.9.4.4 double DQM::GastofCanvas::fHeight [private]
7.9.4.5 TH2D* DQM::GastofCanvas::fHist [private]
7.9.4.6 TPaveText* DQM::GastofCanvas::fLabel1 [private]
7.9.4.7 TPaveText * DQM::GastofCanvas::fLabel2 [private]
7.9.4.8 TPaveText * DQM::GastofCanvas::fLabel3 [private]
7.9.4.9 TPaveText * DQM::GastofCanvas::fLabel4 [private]
7.9.4.10 bool DQM::GastofCanvas::fLabelsDrawn [private]
7.9.4.11 TLegend* DQM::GastofCanvas::fLegend [private]
7.9.4.12 unsigned int DQM::GastofCanvas::fLegendNumEntries [private]
7.9.4.13 double DQM::GastofCanvas::fLegendX [private]
7.9.4.14 double DQM::GastofCanvas::fLegendY [private]
7.9.4.15 TString DQM::GastofCanvas::fRunDate [private]
7.9.4.16 unsigned int DQM::GastofCanvas::fRunId [private]
7.9.4.17 unsigned int DQM::GastofCanvas::fSpillId [private]
7.9.4.18 TPaveText* DQM::GastofCanvas::fUpperLabel [private]
7.9.4.19 TString DQM::GastofCanvas::fUpperLabelText [private]
7.9.4.20 double DQM::GastofCanvas::fWidth [private]
```

The documentation for this class was generated from the following file:

• include/GastofCanvas.h

7.10 Logger Class Reference

Redirect outputs to another output stream.

```
#include <FileConstants.h>
```

Public Member Functions

- Logger (std::ostream &lhs, std::ostream &rhs=std::cout)
- ∼Logger ()

Private Attributes

- std::ostream & fStream
- std::streambuf *const fBuffer

7.10.1 Detailed Description

Redirect outputs to another output stream.

7.10.2 Constructor & Destructor Documentation

```
7.10.2.1 Logger::Logger ( std::ostream & lhs, std::ostream & rhs = std::cout ) [inline]
```

```
7.10.2.2 Logger::~Logger( ) [inline]
```

7.10.3 Field Documentation

```
7.10.3.1 std::streambuf* const Logger::fBuffer [private]
```

```
7.10.3.2 std::ostream& Logger::fStream [private]
```

The documentation for this class was generated from the following file:


• include/FileConstants.h

7.11 LogRedirector Class Reference

Redirect output stream to a string.

```
#include <FileConstants.h>
```

Collaboration diagram for LogRedirector:



Public Member Functions

- LogRedirector (std::ostream &stm=std::cout)
- std::string contents () const

Private Attributes

- std::ostringstream fSS
- · const Logger fRedirect

7.11.1 Detailed Description

Redirect output stream to a string.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

3 Aug 2015

7.11.2 Constructor & Destructor Documentation

7.11.2.1 LogRedirector::LogRedirector (std::ostream & stm = std::cout) [inline]

7.11.3 Member Function Documentation

7.11.3.1 std::string LogRedirector::contents () const [inline]

7.11.4 Field Documentation

7.11.4.1 const Logger LogRedirector::fRedirect [private]

7.11.4.2 std::ostringstream LogRedirector::fSS [private]

The documentation for this class was generated from the following file:


• include/FileConstants.h

7.12 Message Class Reference

Base socket message type.

#include <Message.h>

Inheritance diagram for Message:



Public Member Functions

• Message ()

Void message constructor.

Message (const char *msg)

Construct a message from a string.

Message (std::string msg)

Construct a message from a string.

- virtual ∼Message ()
- MessageKey GetKey () const

Placeholder for the MessageKey retrieval method.

• std::string GetString () const

Retrieve the string carried by this message as a whole.

• bool IsFromWeb () const

Extract from any message its potential arrival from a WebSocket protocol.

void Dump (std::ostream &os=std::cout) const

Protected Attributes

· std::string fString

7.12.1 Detailed Description

Base socket message type.

Base handler for messages to be transmitted through the socket

Author

```
Laurent Forthomme laurent.forthomme@cern.ch
```

Date

6 Apr 2015

7.12.2 Constructor & Destructor Documentation

```
7.12.2.1 Message::Message() [inline]
```

Void message constructor.

```
7.12.2.2 Message::Message(const char * msg) [inline]
```

Construct a message from a string.

```
7.12.2.3 Message::Message(std::string msg) [inline]
```

Construct a message from a string.

7.12.2.4 virtual Message::~Message() [inline], [virtual]

7.12.3 Member Function Documentation

7.12.3.1 void Message::Dump (std::ostream & os = std::cout) const [inline]

7.12.3.2 MessageKey Message::GetKey () const [inline]

Placeholder for the MessageKey retrieval method.

7.12.3.3 std::string Message::GetString () const [inline]

Retrieve the string carried by this message as a whole.

7.12.3.4 bool Message::IsFromWeb() const [inline]

Extract from any message its potential arrival from a WebSocket protocol.

7.12.4 Field Documentation

7.12.4.1 std::string Message::fString [protected]

The documentation for this class was generated from the following file:


· include/Message.h

7.13 Messenger Class Reference


Base master object for the socket.

#include <Messenger.h>

Inheritance diagram for Messenger:



Collaboration diagram for Messenger:



Public Member Functions

· Messenger ()

Build a void master object or socket actor.

Messenger (int port)

Build a master object to control the socket.

- ∼Messenger ()
- bool Connect ()

Connect the master to the socket.

· void Disconnect ()

Remove the master and destroy the socket.

• void Send (const Message &m, int sid) const

Send any type of message to any client.

void SendAll (const Socket::SocketType &type, const Message &m) const

Send any type of message to all clients of one type.

- void SendAll (const Socket::SocketType &type, const Exception &e) const
- void Receive ()

Handle a message reception from a client.

• void Broadcast (const Message &m) const

Emit a message to all clients connected through the socket.

• void StartAcquisition ()

Start the data acquisition.

- void StopAcquisition ()
- SocketType GetType () const

Socket actor type retrieval method.

Private Member Functions

• void AddClient ()

Add a client to listen to.

• void DisconnectClient (int sid, MessageKey key, bool force=false)

Disconnect a client.

- void SwitchClientType (int sid, Socket::SocketType type)
- void ProcessMessage (SocketMessage m, int sid)

Process a message received from the socket.

Private Attributes

- · int fNumAttempts
- pid_t fPID
- int fStdoutPipe [2]
- int fStderrPipe [2]

Additional Inherited Members

7.13.1 Detailed Description

Base master object for the socket.

Messenger/broadcaster object used by the server to send/receive commands from the clients/listeners.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

23 Mar 2015

7.13.2 Constructor & Destructor Documentation

7.13.2.1 Messenger::Messenger()

Build a void master object or socket actor.

7.13.2.2 Messenger::Messenger (int port)

Build a master object to control the socket.

Here is the call graph for this function:



7.13.2.3 Messenger:: \sim Messenger ()




7.13.3 Member Function Documentation

7.13.3.1 void Messenger::AddClient() [private]

Add a client to listen to.

Add one client to the list of socket actors to monitor for message retrieval/submission.

Here is the call graph for this function:




7.13.3.2 void Messenger::Broadcast (const Message & m) const

Emit a message to all clients connected through the socket.

Parameters

in	m	Message to transmit

Here is the call graph for this function:




7.13.3.3 bool Messenger::Connect ()

Connect the master to the socket.

Connect this master to the socket for clients to be able to bind.

Here is the call graph for this function:



7.13.3.4 void Messenger::Disconnect ()

Remove the master and destroy the socket.

Remove this master from the socket, thus disconnecting automatically the clients connected.

Here is the call graph for this function:




7.13.3.5 void Messenger::DisconnectClient (int sid, MessageKey key, bool force = false) [private]

Disconnect a client.

Ask to a client to disconnect from this socket.

Parameters

ſ	in	sid	Unique identifier of the client to disconnect
	in	key	Key to the message to transmit for disconnection
Ī	in	force	Do we need to force the client out of this socket ?



7.13.3.6 SocketType Messenger::GetType () const [inline]

Socket actor type retrieval method.


7.13.3.7 void Messenger::ProcessMessage (SocketMessage m, int sid) [private]

Process a message received from the socket.

Parameters


in	Unique	identifier of the client sending the message

Here is the call graph for this function:



7.13.3.8 void Messenger::Receive ()

Handle a message reception from a client.




7.13.3.9 void Messenger::Send (const Message & m, int sid) const

Send any type of message to any client.

Parameters

in	т	Message to transmit
in	sid	Unique identifier of the client on this socket

Here is the call graph for this function:



7.13.3.10 void Messenger::SendAll (const Socket::SocketType & type, const Message & m) const [inline]

Send any type of message to all clients of one type.

Parameters


in	type	Client type
in	т	Message to transmit

Here is the call graph for this function:



7.13.3.11 void Messenger::SendAll (const Socket::SocketType & type, const Exception & e) const [inline]

Here is the call graph for this function:



7.13.3.12 void Messenger::StartAcquisition ()

Start the data acquisition.

Here is the call graph for this function:




7.13.3.13 void Messenger::StopAcquisition ()

Here is the call graph for this function:



7.13.3.14 void Messenger::SwitchClientType (int sid, Socket::SocketType type) [private]

Here is the call graph for this function:



7.13.4 Field Documentation

7.13.4.1 int Messenger::fNumAttempts [private]

7.13.4.2 pid_t Messenger::fPID [private]

7.13.4.3 int Messenger::fStderrPipe[2] [private]

7.13.4.4 int Messenger::fStdoutPipe[2] [private]

The documentation for this class was generated from the following files:

- · include/Messenger.h
- src/Messenger.cpp

7.14 Online DBH andler Class Reference

Handler for the run information online database.

#include <OnlineDBHandler.h>

Data Structures

- struct BurstInfo
- struct TDCConditions

Public Types

- typedef std::map< unsigned int, unsigned int > RunCollection
- typedef std::vector< BurstInfo > BurstInfos
- typedef std::vector< TDCConditions > TDCConditionsCollection

Public Member Functions

- OnlineDBHandler (std::string path=std::string(std::getenv("PPS PATH"))+"/run infos.db")
- ∼OnlineDBHandler ()
- void NewRun ()
- void NewBurst ()
- · RunCollection GetRuns () const
- unsigned int GetLastRun () const

Retrieve the last run acquired.

- int GetLastBurst (unsigned int run) const
- BurstInfos GetRunInfo (unsigned int run) const

Retrieve information on a given run (spill IDs / timestamp)

- void SetTDCConditions (unsigned short tdc_id, unsigned long tdc_address, unsigned short tdc_acq_mode, unsigned short tdc_det_mode, std::string detector)
- TDCConditionsCollection GetTDCConditions (unsigned int run_id) const
- void SetHVConditions (unsigned short channel_id, unsigned int vmax, unsigned imax)

Private Member Functions

- void BuildTables ()
- template < class T >
 std::vector < std::vector < T > > Select (std::string req, int num_fields=-1) const

Private Attributes

sqlite3 * fDB

7.14.1 Detailed Description

Handler for the run information online database.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

3 Aug 2015

- 7.14.2 Member Typedef Documentation
- 7.14.2.1 typedef std::vector<BurstInfo> OnlineDBHandler::BurstInfos
- 7.14.2.2 typedef std::map<unsigned int, unsigned int> OnlineDBHandler::RunCollection
- 7.14.2.3 typedef std::vector<TDCConditions> OnlineDBHandler::TDCConditionsCollection
- 7.14.3 Constructor & Destructor Documentation
- 7.14.3.1 OnlineDBHandler::OnlineDBHandler (std::string path = std::string (std::getenv("PPS_← PATH"))+"/run_infos.db") [inline]

Here is the call graph for this function:

OnlineDBHandler::OnlineDBHandler OnlineDBHandler::BuildTables

- **7.14.3.2 OnlineDBHandler::** \sim **OnlineDBHandler()** [inline]
- 7.14.4 Member Function Documentation
- 7.14.4.1 void OnlineDBHandler::BuildTables() [inline], [private]
- 7.14.4.2 int OnlineDBHandler::GetLastBurst (unsigned int run) const [inline]
- 7.14.4.3 unsigned int OnlineDBHandler::GetLastRun () const [inline]

Retrieve the last run acquired.


7.14.4.4 BurstInfos OnlineDBHandler::GetRunInfo (unsigned int *run* **) const** [inline]

Retrieve information on a given run (spill IDs / timestamp)

- 7.14.4.5 RunCollection OnlineDBHandler::GetRuns () const [inline]
- 7.14.4.6 TDCConditionsCollection OnlineDBHandler::GetTDCConditions (unsigned int run_id) const [inline]

7.14.4.7 void OnlineDBHandler::NewBurst() [inline]

Here is the call graph for this function:



- 7.14.4.8 void OnlineDBHandler::NewRun() [inline]
- 7.14.4.9 template < class T > std::vector < std::vector < T > > OnlineDBHandler::Select (std::string req, int num_fields = -1) const [inline], [private]
- 7.14.4.10 void OnlineDBHandler::SetHVConditions (unsigned short *channel_id*, unsigned int *vmax*, unsigned *imax*) [inline]

Here is the call graph for this function:



7.14.4.11 void OnlineDBHandler::SetTDCConditions (unsigned short tdc_id, unsigned long tdc_address, unsigned short tdc_acq_mode, unsigned short tdc_det_mode, std::string detector) [inline]

Here is the call graph for this function:



7.14.5 Field Documentation

7.14.5.1 sqlite3* OnlineDBHandler::fDB [private]


The documentation for this class was generated from the following file:

• include/OnlineDBHandler.h


7.15 DQM::PPSCanvas Class Reference

#include <PPSCanvas.h>

Inheritance diagram for DQM::PPSCanvas:



Collaboration diagram for DQM::PPSCanvas:



Public Member Functions

- PPSCanvas ()
- PPSCanvas (TString name, unsigned int width=500, unsigned int height=500, TString upper_label="")
- PPSCanvas (TString name, TString upper_label)
- virtual ∼PPSCanvas ()
- void SetRunInfo (unsigned int run_id, TString date)
- void SetUpperLabel (TString text)
- TPad * Grid ()
- void Save (TString ext="png", TString path=".")

Private Member Functions

- void Build ()
- void DrawGrid ()

Private Attributes

- TPad * c1
- TPad * c2
- · double fWidth
- double fHeight
- TLegend * fLegend
- double fLegendX
- · double fLegendY
- unsigned int fLegendNumEntries
- TPaveText * fLabel1
- TPaveText * fLabel2
- TPaveText * fLabel3
- TString fUpperLabelText
- TPaveText * fUpperLabel
- bool fLabelsDrawn
- · unsigned int fRunId
- TString fRunDate

7.15.1 Detailed Description

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

3 Aug 2015

7.15.2 Constructor & Destructor Documentation

7.15.2.1 DQM::PPSCanvas::PPSCanvas() [inline]

7.15.2.2 DQM::PPSCanvas::PPSCanvas (TString *name*, unsigned int *width* = 500, unsigned int *height* = 500, TString *upper_label* = " ") [inline]

Here is the call graph for this function:



7.15.2.3 DQM::PPSCanvas::PPSCanvas (TString name, TString upper_label) [inline]



```
7.15.2.4 virtual DQM::PPSCanvas::~PPSCanvas() [inline], [virtual]
```

7.15.3 Member Function Documentation

7.15.3.1 void DQM::PPSCanvas::Build() [inline], [private]

Here is the call graph for this function:




```
7.15.3.2 void DQM::PPSCanvas::DrawGrid() [inline], [private]
```

7.15.3.3 TPad* DQM::PPSCanvas::Grid() [inline]

7.15.3.4 void DQM::PPSCanvas::Save (TString ext = "png", TString path = ".") [inline]

Here is the call graph for this function:



```
7.15.3.5 void DQM::PPSCanvas::SetRunInfo ( unsigned int run_id, TString date ) [inline]
```

 $\textbf{7.15.3.6} \quad \textbf{void DQM::PPSCanvas::SetUpperLabel (TString \textit{text})} \quad \texttt{[inline]}$

7.15.4 Field Documentation

7.15.4.1 TPad* DQM::PPSCanvas::c1 [private]

7.15.4.2 TPad * DQM::PPSCanvas::c2 [private]

 $\textbf{7.15.4.3} \quad \textbf{double DQM::PPSCanvas::fHeight} \quad \texttt{[private]}$

7.15.4.4 TPaveText* DQM::PPSCanvas::fLabel1 [private]

7.15.4.5 TPaveText * DQM::PPSCanvas::fLabel2 [private]

7.15.4.6 TPaveText * **DQM::PPSCanvas::fLabel3** [private]

```
7.15.4.7 bool DQM::PPSCanvas::fLabelsDrawn [private]
7.15.4.8 TLegend* DQM::PPSCanvas::fLegend [private]
7.15.4.9 unsigned int DQM::PPSCanvas::fLegendNumEntries [private]
7.15.4.10 double DQM::PPSCanvas::fLegendX [private]
7.15.4.11 double DQM::PPSCanvas::fLegendY [private]
7.15.4.12 TString DQM::PPSCanvas::fRunDate [private]
7.15.4.13 unsigned int DQM::PPSCanvas::fRunId [private]
7.15.4.14 TPaveText* DQM::PPSCanvas::fUpperLabel [private]
7.15.4.15 TString DQM::PPSCanvas::fUpperLabelText [private]
7.15.4.16 double DQM::PPSCanvas::fWidth [private]
```


The documentation for this class was generated from the following file:

· include/PPSCanvas.h


7.16 DQM::QuarticCanvas Class Reference

#include <QuarticCanvas.h>

Inheritance diagram for DQM::QuarticCanvas:



Collaboration diagram for DQM::QuarticCanvas:



Data Structures

struct Coord

Public Member Functions

- QuarticCanvas ()
- QuarticCanvas (TString name, unsigned int width=500, unsigned int height=500, TString upper_label="")
- QuarticCanvas (TString name, TString upper label)
- virtual ~QuarticCanvas ()
- void SetRunInfo (unsigned int board_id, unsigned int run_id, unsigned int spill_id, TString date)
- void SetUpperLabel (TString text)
- void FillChannel (unsigned short channel_id, double content)
- TH2D * Grid ()
- void Save (TString ext="png", TString path=".")

Private Member Functions

- void Build ()
- · void DrawGrid ()
- Coord GetCoordinates (unsigned short channel_id) const

Private Attributes

- TPad * c1
- TPad * c2
- TH2D * fHist
- double fWidth
- double fHeight
- TLegend * fLegend
- double fLegendX
- double fLegendY
- unsigned int fLegendNumEntries
- TPaveText * fLabel1
- TPaveText * fLabel2
- TPaveText * fLabel3

- TPaveText * fLabel4
- TString fUpperLabelText
- TPaveText * fUpperLabel
- bool fLabelsDrawn
- · unsigned int fBoardId
- · unsigned int fRunId
- · unsigned int fSpillId
- TString fRunDate

7.16.1 Detailed Description

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

3 Aug 2015

7.16.2 Constructor & Destructor Documentation


7.16.2.1 DQM::QuarticCanvas::QuarticCanvas() [inline]

7.16.2.2 DQM::QuarticCanvas::QuarticCanvas (TString *name*, unsigned int *width* = 500, unsigned int *height* = 500, TString *upper_label* = " ") [inline]

Here is the call graph for this function:



7.16.2.3 DQM::QuarticCanvas::QuarticCanvas (TString name, TString upper_label) [inline]



```
7.16.2.4 virtual DQM::QuarticCanvas::~QuarticCanvas() [inline], [virtual]
```

7.16.3 Member Function Documentation

```
7.16.3.1 void DQM::QuarticCanvas::Build( ) [inline],[private]
```

7.16.3.2 void DQM::QuarticCanvas::DrawGrid() [inline], [private]

7.16.3.3 void DQM::QuarticCanvas::FillChannel (unsigned short channel_id, double content) [inline]

Here is the call graph for this function:




7.16.3.4 Coord DQM::QuarticCanvas::GetCoordinates (unsigned short channel_id) const [inline], [private]

7.16.3.5 TH2D* DQM::QuarticCanvas::Grid() [inline]

7.16.3.6 void DQM::QuarticCanvas::Save (TString ext = "png", TString path = ".") [inline]

Here is the call graph for this function:



- 7.16.3.7 void DQM::QuarticCanvas::SetRunInfo (unsigned int *board_id*, unsigned int *run_id*, unsigned int *spill_id*, TString *date*) [inline]
- 7.16.3.8 void DQM::QuarticCanvas::SetUpperLabel(TString text) [inline]

7.16.4 Field Documentation

```
7.16.4.1 TPad* DQM::QuarticCanvas::c1 [private]
7.16.4.2 TPad * DQM::QuarticCanvas::c2 [private]
7.16.4.3 unsigned int DQM::QuarticCanvas::fBoardId [private]
7.16.4.4 double DQM::QuarticCanvas::fHeight [private]
7.16.4.5 TH2D* DQM::QuarticCanvas::fHist [private]
7.16.4.6 TPaveText* DQM::QuarticCanvas::fLabel1 [private]
7.16.4.7 TPaveText * DQM::QuarticCanvas::fLabel2 [private]
7.16.4.8 TPaveText * DQM::QuarticCanvas::fLabel3 [private]
7.16.4.9 TPaveText * DQM::QuarticCanvas::fLabel4 [private]
7.16.4.10 bool DQM::QuarticCanvas::fLabelsDrawn [private]
7.16.4.11 TLegend* DQM::QuarticCanvas::fLegend [private]
7.16.4.12 unsigned int DQM::QuarticCanvas::fLegendNumEntries [private]
7.16.4.13 double DQM::QuarticCanvas::fLegendX [private]
7.16.4.14 double DQM::QuarticCanvas::fLegendY [private]
7.16.4.15 TString DQM::QuarticCanvas::fRunDate [private]
7.16.4.16 unsigned int DQM::QuarticCanvas::fRunId [private]
7.16.4.17 unsigned int DQM::QuarticCanvas::fSpillId [private]
7.16.4.18 TPaveText* DQM::QuarticCanvas::fUpperLabel [private]
7.16.4.19 TString DQM::QuarticCanvas::fUpperLabelText [private]
7.16.4.20 double DQM::QuarticCanvas::fWidth [private]
```

The documentation for this class was generated from the following file:


• include/QuarticCanvas.h

7.17 DAQ::QuickUSBHandler Class Reference

Generic QuickUSB communication handler.

#include <QuickUSBHandler.h>

Inheritance diagram for DAQ::QuickUSBHandler:



Data Structures

struct Version

Public Member Functions

- · QuickUSBHandler ()
- virtual ~QuickUSBHandler ()
- void Init ()
- void Reset () const
- · Version GetFWVersion () const
- Version GetDriverVersion () const
- Version GetDLLVersion () const
- void Write (uint16_t addr, uint8_t word) const

Write a single word to the QuickUSB device.

void Write (uint16_t addr, std::vector< uint8_t > &words, uint16_t size) const

Write a set of words to the QuickUSB device.

• std::vector< uint8_t > Fetch (uint16_t addr, uint16_t size) const

Receive a set of words from the QuickUSB device.

- void StartBulkTransfer (QVOIDRETURN callback(PQBULKSTREAM))
- void StopBulkTransfer ()

Protected Attributes

bool flsStopping

Private Attributes

- std::string fDevice
- QHANDLE fHandle
- uint8_t fStreamId

7.17.1 Detailed Description

Generic QuickUSB communication handler.

Date

17 May 2016

Author

Laurent Forthomme laurent.forthomme@cern.ch

7.17.2 Constructor & Destructor Documentation


- 7.17.2.1 DAQ::QuickUSBHandler::QuickUSBHandler ()
- 7.17.2.2 DAQ::QuickUSBHandler::~QuickUSBHandler() [virtual]

7.17.3 Member Function Documentation

7.17.3.1 $std::vector < uint8_t > DAQ::QuickUSBHandler::Fetch (uint16_t addr, uint16_t size) const$

Receive a set of words from the QuickUSB device.

- 7.17.3.2 QuickUSBHandler::Version DAQ::QuickUSBHandler::GetDLLVersion () const
- $7.17.3.3 \quad \textbf{QuickUSBH} \textbf{andler::} \textbf{Version DAQ::} \textbf{QuickUSBH} \textbf{andler::} \textbf{GetDriverVersion (} \quad \textbf{) const}$
- 7.17.3.4 QuickUSBHandler::Version DAQ::QuickUSBHandler::GetFWVersion () const
- 7.17.3.5 void DAQ::QuickUSBHandler::Init ()



- 7.17.3.6 void DAQ::QuickUSBHandler::Reset () const
- 7.17.3.7 void DAQ::QuickUSBHandler::StartBulkTransfer (QVOIDRETURN callbackPQBULKSTREAM)
- 7.17.3.8 void DAQ::QuickUSBHandler::StopBulkTransfer ()
- 7.17.3.9 void DAQ::QuickUSBHandler::Write (uint16_t addr, uint8_t word) const [inline]

Write a single word to the QuickUSB device.

7.17.3.10 void DAQ::QuickUSBHandler::Write (uint16_t addr, std::vector < uint8_t > & words, uint16_t size) const

Write a set of words to the QuickUSB device.

7.17.4 Field Documentation

- **7.17.4.1 std::string DAQ::QuickUSBHandler::fDevice** [private]
- **7.17.4.2 QHANDLE DAQ::QuickUSBHandler::fHandle** [private]
- 7.17.4.3 bool DAQ::QuickUSBHandler::flsStopping [protected]
- 7.17.4.4 uint8_t DAQ::QuickUSBHandler::fStreamId [private]

The documentation for this class was generated from the following files:


- · daq/include/QuickUSBHandler.h
- dag/src/QuickUSBHandler.cpp

7.18 Socket Class Reference

Base socket object from which clients/master from a socket inherit.

#include <Socket.h>

Inheritance diagram for Socket:



Public Types

```
    enum SocketType {
        INVALID =-1, MASTER =0, WEBSOCKET_CLIENT, CLIENT,
        DETECTOR, DQM, DAQ }
```

Type of actor playing a role on the socket.

typedef std::set< std::pair< int, SocketType > > SocketCollection

Public Member Functions

- Socket ()
- · Socket (int port)
- virtual ∼Socket ()
- void Stop ()

Terminates the socket and all attached communications.

- void SetPort (int port)
- · int GetPort () const

Retrieve the port used for this socket.

void AcceptConnections (Socket &socket)

Accept connection from a client.

- void SelectConnections ()
- void SetSocketId (int sid)
- int GetSocketId () const
- SocketType GetSocketType (int sid) const
- · bool IsWebSocket (int sid) const
- void DumpConnected () const

Protected Member Functions

· bool Start ()

Start the socket.

• void Bind ()

Bind a name to a socket.

- void PrepareConnection ()
- void Listen (int maxconn)

Listen to incoming messages.

void SendMessage (Message message, int id=-1) const

Send a message on a socket.

Message FetchMessage (int id=-1) const

Receive a message from a socket.

Protected Attributes

- int fPort
- char fBuffer [MAX_WORD_LENGTH]
- · SocketCollection fSocketsConnected
- · fd set fMaster

Master file descriptor list.

• fd_set fReadFds

Temp file descriptor list for select()

Private Member Functions

```
• void Create ()
```

Create an endpoint for communication.

• void Configure ()

Configure the socket object for communication.

Private Attributes

- · int fSocketId
- · struct sockaddr_in fAddress

7.18.1 Detailed Description

Base socket object from which clients/master from a socket inherit.

General object providing all useful method to connect/bind/send/receive information through system sockets.

Author

```
Laurent Forthomme laurent.forthomme@cern.ch
```

Date

23 Mar 2015

7.18.2 Member Typedef Documentation

```
7.18.2.1 typedef std::set< std::pair<int,SocketType> > Socket::SocketCollection
```

7.18.3 Member Enumeration Documentation

7.18.3.1 enum Socket::SocketType

Type of actor playing a role on the socket.

Enumerator

```
INVALID
MASTER
WEBSOCKET_CLIENT
CLIENT
DETECTOR
DQM
DAQ
```

7.18.4 Constructor & Destructor Documentation

```
7.18.4.1 Socket::Socket( ) [inline]
7.18.4.2 Socket::Socket( int port )
7.18.4.3 Socket::~Socket( ) [virtual]
```

7.18.5 Member Function Documentation

7.18.5.1 void Socket::AcceptConnections (Socket & socket)


Accept connection from a client.

Set the socket to accept connections any client transmitting through the socket

Parameters

-			
	in,out	socket	Master/client object to enable on the socket

Here is the call graph for this function:



7.18.5.2 void Socket::Bind() [protected]

Bind a name to a socket.

Returns

Success of the operation

Here is the call graph for this function:



7.18.5.3 void Socket::Configure() [private]

Configure the socket object for communication.

7.18.5.4 void Socket::Create() [private]

Create an endpoint for communication.

7.18.5.5 void Socket::DumpConnected () const

7.18.5.6 Message Socket::FetchMessage (int id = -1) const [protected]

Receive a message from a socket.

Returns

Received message as a std::string

7.18.5.7 int Socket::GetPort() const [inline]

Retrieve the port used for this socket.

7.18.5.8 int Socket::GetSocketId () const [inline]

7.18.5.9 SocketType Socket::GetSocketType (int sid) const [inline]

7.18.5.10 bool Socket::IsWebSocket (int sid) const [inline]

Here is the call graph for this function:



7.18.5.11 void Socket::Listen (int maxconn) [protected]

Listen to incoming messages.

Set the socket to listen to any message coming from outside



7.18.5.12 void Socket::PrepareConnection() [protected]

Here is the call graph for this function:



7.18.5.13 void Socket::SelectConnections ()

Register all open file descriptors to read their communication through the socket

7.18.5.14 void Socket::SendMessage (Message message, int id = -1) const [protected]

Send a message on a socket.

Here is the call graph for this function:



7.18.5.15 void Socket::SetPort(int port) [inline]

7.18.5.16 void Socket::SetSocketId (int sid) [inline]

7.18.5.17 bool Socket::Start() [protected]


Start the socket.

Launch all mandatory operations to set the socket to be used

Returns

Success of the operation

Here is the call graph for this function:



7.18.5.18 void Socket::Stop ()

Terminates the socket and all attached communications.

7.18.6 Field Documentation

```
7.18.6.1 struct sockaddr_in Socket::fAddress [private]
```

7.18.6.2 char Socket::fBuffer[MAX_WORD_LENGTH] [protected]

7.18.6.3 fd_set Socket::fMaster [protected]

Master file descriptor list.

```
7.18.6.4 int Socket::fPort [protected]
```

7.18.6.5 fd_set Socket::fReadFds [protected]

Temp file descriptor list for select()

7.18.6.6 int Socket::fSocketId [private]

A file descriptor for this socket, if Create was performed beforehand.

7.18.6.7 SocketCollection Socket::fSocketsConnected [protected]

The documentation for this class was generated from the following files:


- · include/Socket.h
- src/Socket.cpp

7.19 SocketMessage Class Reference


Socket-passed message type.

#include <SocketMessage.h>

Inheritance diagram for SocketMessage:



Collaboration diagram for SocketMessage:



Public Member Functions

- SocketMessage ()
- SocketMessage (const Message &msg)
- SocketMessage (const char *msg_s)
- SocketMessage (std::string msg_s)
- SocketMessage (const MessageKey &key)

Construct a socket message out of a key.

• SocketMessage (const MessageKey &key, const char *value)

Construct a socket message out of a key and a string-type value.

• SocketMessage (const MessageKey &key, std::string value)

Construct a socket message out of a key and a string-type value.

SocketMessage (const MessageKey &key, const short value)

Construct a socket message out of a key and a short integer-type value.

• SocketMessage (const MessageKey &key, const int value)

Construct a socket message out of a key and an integer-type value.

• SocketMessage (const MessageKey &key, const long value)

Construct a socket message out of a key and a long integer-type value.

SocketMessage (const MessageKey &key, const float value)

Construct a socket message out of a key and a float-type value.

• SocketMessage (const MessageKey &key, const double value)

Construct a socket message out of a key and a double precision-type value.

SocketMessage (MessageMap msg_m)

Construct a socket message out of a map of key/string-type value.

- ∼SocketMessage ()
- void SetKeyValue (const MessageKey &key, const char *value)

String-valued message.

void SetKeyValue (const MessageKey &key, short int_value)

Send a short integer-valued message.

void SetKeyValue (const MessageKey &key, int int_value)

Send an integer-valued message.

void SetKeyValue (const MessageKey &key, long int_value)

Send a long integer-valued message.

void SetKeyValue (const MessageKey &key, float float_value)

Float-valued message.

• void SetKeyValue (const MessageKey &key, double double_value)

Double-valued message.

• std::string GetString () const

Extract the whole key:value message.

· MessageKey GetKey () const

Extract the message's key.

• std::string GetValue () const

Extract the message's string value.

• std::string GetCleanedValue () const

Extract the message's string value (without the trailing endlines)

• int GetIntValue () const

Extract the message's integer value.

· VectorValue GetVectorValue () const

Extract the message's vector of string value.

void Dump (std::ostream &os=std::cout) const

Private Member Functions

- MessageMap Object () const
- std::string String () const

Private Attributes

MessageMap fMessage

Additional Inherited Members

7.19.1 Detailed Description

Socket-passed message type.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

26 Mar 2015

7.19.2 Constructor & Destructor Documentation

7.19.2.1 SocketMessage::SocketMessage() [inline]

7.19.2.2 SocketMessage::SocketMessage (const Message & msg) [inline]

Here is the call graph for this function:




7.19.2.3 SocketMessage::SocketMessage (const char * msg_s) [inline]



7.19.2.4 SocketMessage::SocketMessage (std::string msg_s) [inline]

Here is the call graph for this function:



7.19.2.5 SocketMessage::SocketMessage(const MessageKey & key) [inline]

Construct a socket message out of a key.

Here is the call graph for this function:



7.19.2.6 SocketMessage::SocketMessage (const MessageKey & key, const char * value) [inline]

Construct a socket message out of a key and a string-type value.

Here is the call graph for this function:



7.19.2.7 SocketMessage::SocketMessage(const MessageKey & key, std::string value) [inline]


Construct a socket message out of a key and a string-type value.



7.19.2.8 SocketMessage::SocketMessage (const MessageKey & key, const short value) [inline]

Construct a socket message out of a key and a short integer-type value.

Here is the call graph for this function:



7.19.2.9 SocketMessage::SocketMessage (const MessageKey & key, const int value) [inline]

Construct a socket message out of a key and an integer-type value.


Here is the call graph for this function:



7.19.2.10 SocketMessage::SocketMessage (const MessageKey & key, const long value) [inline]

Construct a socket message out of a key and a long integer-type value.

Here is the call graph for this function:



7.19.2.11 SocketMessage::SocketMessage (const MessageKey & key, const float value) [inline]

Construct a socket message out of a key and a float-type value.



7.19.2.12 SocketMessage::SocketMessage (const MessageKey & key, const double value) [inline]

Construct a socket message out of a key and a double precision-type value.

Here is the call graph for this function:



7.19.2.13 SocketMessage::SocketMessage (MessageMap msg_m) [inline]


Construct a socket message out of a map of key/string-type value.

7.19.2.14 SocketMessage::~SocketMessage() [inline]

7.19.3 Member Function Documentation

7.19.3.1 void SocketMessage::Dump (std::ostream & os = std::cout) const [inline]

Here is the call graph for this function:



7.19.3.2 std::string SocketMessage::GetCleanedValue()const [inline]

Extract the message's string value (without the trailing endlines)

7.19.3.3 int SocketMessage::GetIntValue () const [inline]

Extract the message's integer value.

7.19.3.4 MessageKey SocketMessage::GetKey()const [inline]

Extract the message's key.

7.19.3.5 std::string SocketMessage::GetString () const [inline]

Extract the whole key:value message.


7.19.3.6 std::string SocketMessage::GetValue()const [inline]

Extract the message's string value.

7.19.3.7 VectorValue SocketMessage::GetVectorValue () const [inline]

Extract the message's vector of string value.

Here is the call graph for this function:




7.19.3.8 MessageMap SocketMessage::Object() const [inline], [private]

7.19.3.9 void SocketMessage::SetKeyValue (const MessageKey & key, const char * value) [inline]

String-valued message.

Here is the call graph for this function:



7.19.3.10 void SocketMessage::SetKeyValue (const MessageKey & key, short int_value) [inline]

Send a short integer-valued message.


Here is the call graph for this function:



7.19.3.11 void SocketMessage::SetKeyValue (const MessageKey & key, int int_value) [inline]

Send an integer-valued message.

Here is the call graph for this function:



7.19.3.12 void SocketMessage::SetKeyValue (const MessageKey & key, long int_value) [inline]

Send a long integer-valued message.

Here is the call graph for this function:



7.19.3.13 void SocketMessage::SetKeyValue (const MessageKey & key, float float_value) [inline]

Float-valued message.

Here is the call graph for this function:



7.19.3.14 void SocketMessage::SetKeyValue (const MessageKey & key, double double_value) [inline]

Double-valued message.

Here is the call graph for this function:



7.19.3.15 std::string SocketMessage::String() const [inline], [private]

7.19.4 Field Documentation

7.19.4.1 MessageMap SocketMessage::fMessage [private]

The documentation for this class was generated from the following file:


· include/SocketMessage.h

7.20 DAQ::TDC Class Reference

HPTDC object.

#include <TDC.h>

Collaboration diagram for DAQ::TDC:



Public Types

- enum AcquisitionMode { CONT_STORAGE, TRIG_MATCH }
 TDC acquisition mode.
- enum DetectionMode { PAIR = 0x0, OTRAILING = 0x1, OLEADING = 0x2, TRAILEAD = 0x3 }

Public Member Functions

- TDC (unsigned int id, QuickUSBHandler *h)
- ∼TDC ()
- void SetSetupRegister (const TDCSetup &c)

Submit the HPTDC setup word as a TDCSetup object.

• TDCSetup GetSetupRegister ()

Retrieve the HPTDC setup word as a TDCSetup object.

- bool CheckFirmwareVersion () const
- void SoftReset ()
- TDCEventCollection FetchEvents ()
- void ReadStatus ()

Private Member Functions

• void SendConfiguration ()

Set the setup word to the HPTDC internal setup register.

void ReadConfiguration ()

Read the setup word from the HPTDC internal setup register.

template < class T >
 void WriteRegister (unsigned int r, const T &v)
 Write one register content on the HPTDC inner memory.
 template < class T >
 T ReadRegister (unsigned int r)

Retrieve one register content from the HPTDC inner memory.

Private Attributes

- · unsigned int fld
- QuickUSBHandler * fUSB
- TDCSetup fSetup
- TDCControl fControl
- TDCBoundaryScan fBS
- · TDCStatus fStatus

7.20.1 Detailed Description

HPTDC object.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

27 Apr 2015

7.20.2 Member Enumeration Documentation

7.20.2.1 enum DAQ::TDC::DetectionMode

Enumerator

PAIR OTRAILING OLEADING TRAILEAD

7.20.3 Constructor & Destructor Documentation

7.20.3.1 DAQ::TDC::TDC (unsigned int id, QuickUSBHandler *h)

Here is the call graph for this function:

DAQ::TDC::ReadConfiguration

```
7.20.3.2 DAQ::TDC::~TDC() [inline]
7.20.4 Member Function Documentation
7.20.4.1 bool DAQ::TDC::CheckFirmwareVersion ( ) const
7.20.4.2 TDCEventCollection DAQ::TDC::FetchEvents ( )
7.20.4.3 TDCSetup DAQ::TDC::GetSetupRegister( ) [inline]
Retrieve the HPTDC setup word as a TDCSetup object.
7.20.4.4 void DAQ::TDC::ReadConfiguration() [private]
Read the setup word from the HPTDC internal setup register.
7.20.4.5 template < class T > T DAQ::TDC::ReadRegister (unsigned int r) [private]
Retrieve one register content from the HPTDC inner memory.
7.20.4.6 void DAQ::TDC::ReadStatus() [inline]
7.20.4.7 void DAQ::TDC::SendConfiguration() [private]
Set the setup word to the HPTDC internal setup register.
7.20.4.8 void DAQ::TDC::SetSetupRegister ( const TDCSetup & c ) [inline]
Submit the HPTDC setup word as a TDCSetup object.
7.20.4.9 void DAQ::TDC::SoftReset ( )
7.20.4.10 template < class T > void DAQ::TDC::WriteRegister ( unsigned int r, const T & v ) [private]
Write one register content on the HPTDC inner memory.
7.20.5 Field Documentation
7.20.5.1 TDCBoundaryScan DAQ::TDC::fBS [private]
7.20.5.2 TDCControl DAQ::TDC::fControl [private]
7.20.5.3 unsigned int DAQ::TDC::fld [private]
7.20.5.4 TDCSetup DAQ::TDC::fSetup [private]
7.20.5.5 TDCStatus DAQ::TDC::fStatus [private]
7.20.5.6 QuickUSBHandler* DAQ::TDC::fUSB [private]
```


The documentation for this class was generated from the following files:

- · daq/include/TDC.h
- daq/src/TDC.cpp


7.21 TDCBoundaryScan Class Reference

#include <TDCBoundaryScan.h>

Inheritance diagram for TDCBoundaryScan:



Collaboration diagram for TDCBoundaryScan:



Public Member Functions

- TDCBoundaryScan ()
- TDCBoundaryScan (const TDCBoundaryScan &bs)
- void SetConstantValues ()

Static Private Attributes

- static const bit kTokenOut = 0
- static const bit kStrobeOut = 1
- static const bit kSerialOut = 2
- static const bit kTest = 3
- static const bit kError = 4

- static const bit kDataReady = 5
- static const bit kParallelEnable = 6
- static const bit kParallelDataOut = 7
- static const bit kEncodedControl = 39
- static const bit kTrigger = 40
- static const bit kEventReset = 41
- static const bit kBunchReset = 42
- static const bit kGetData = 43
- static const bit kSerialBypassIn = 44
- static const bit kSerialIn = 45
- static const bit kTokenBypassIn = 46
- static const bit kTokenIn = 47
- static const bit kReset = 48
- static const bit kAuxClock = 49
- static const bit kClk = 50
- static const bit kHit = 51

Additional Inherited Members

7.21.1 Detailed Description

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

24 Apr 2015

7.21.2 Constructor & Destructor Documentation

7.21.2.1 TDCBoundaryScan::TDCBoundaryScan() [inline]

Here is the call graph for this function:



7.21.2.2 TDCBoundaryScan::TDCBoundaryScan (const TDCBoundaryScan & bs) [inline]



7.21.3 Member Function Documentation

```
7.21.3.1 void TDCBoundaryScan::SetConstantValues() [inline], [virtual]
```

Ensure that the critical constant values are properly set in the register word Implements TDCRegister.

7.21.4 Field Documentation

```
7.21.4.1 const bit TDCBoundaryScan::kAuxClock = 49 [static], [private]
7.21.4.2 const bit TDCBoundaryScan::kBunchReset = 42 [static], [private]
7.21.4.3 const bit TDCBoundaryScan::kClk = 50 [static], [private]
7.21.4.4 const bit TDCBoundaryScan::kDataReady = 5 [static], [private]
7.21.4.5 const bit TDCBoundaryScan::kEncodedControl = 39 [static], [private]
7.21.4.6 const bit TDCBoundaryScan::kError = 4 [static], [private]
7.21.4.7 const bit TDCBoundaryScan::kEventReset = 41 [static], [private]
7.21.4.8 const bit TDCBoundaryScan::kGetData = 43 [static], [private]
7.21.4.9 const bit TDCBoundaryScan::kHit = 51 [static], [private]
7.21.4.10 const bit TDCBoundaryScan::kParallelDataOut = 7 [static], [private]
7.21.4.11 const bit TDCBoundaryScan::kParallelEnable = 6 [static], [private]
7.21.4.12 const bit TDCBoundaryScan::kReset = 48 [static], [private]
7.21.4.13 const bit TDCBoundaryScan::kSerialBypassIn = 44 [static], [private]
7.21.4.14 const bit TDCBoundaryScan::kSerialln = 45 [static], [private]
7.21.4.15 const bit TDCBoundaryScan::kSerialOut = 2 [static], [private]
7.21.4.16 const bit TDCBoundaryScan::kStrobeOut = 1 [static], [private]
7.21.4.17 const bit TDCBoundaryScan::kTest = 3 [static], [private]
7.21.4.18 const bit TDCBoundaryScan::kTokenBypassIn = 46 [static], [private]
7.21.4.19 const bit TDCBoundaryScan::kTokenIn = 47 [static], [private]
7.21.4.20 const bit TDCBoundaryScan::kTokenOut = 0 [static], [private]
7.21.4.21 const bit TDCBoundaryScan::kTrigger = 40 [static], [private]
```

The documentation for this class was generated from the following file:

daq/include/TDCBoundaryScan.h

7.22 OnlineDBHandler::TDCConditions Struct Reference

#include <OnlineDBHandler.h>

Public Member Functions

- bool operator== (const TDCConditions &rhs) const
- TDCConditions & operator= (const TDCConditions &rhs)

Data Fields

- · unsigned int run_id
- · unsigned short tdc_id
- unsigned long tdc_address
- unsigned short tdc_acq_mode
- unsigned short tdc_det_mode
- std::string detector

7.22.1 Member Function Documentation

- 7.22.1.1 TDCConditions& OnlineDBHandler::TDCConditions::operator=(const TDCConditions & rhs) [inline]
- 7.22.1.2 bool OnlineDBHandler::TDCConditions::operator== (const TDCConditions & rhs) const [inline]

7.22.2 Field Documentation

- 7.22.2.1 std::string OnlineDBHandler::TDCConditions::detector
- 7.22.2.2 unsigned int OnlineDBHandler::TDCConditions::run_id
- $7.22.2.3 \quad unsigned \ short \ Online DB Handler:: TDC Conditions:: tdc_acq_mode$
- $7.22.2.4 \quad unsigned \ long \ Online DB Handler:: TDC Conditions:: tdc_address$
- 7.22.2.5 unsigned short OnlineDBHandler::TDCConditions::tdc_det_mode
- 7.22.2.6 unsigned short OnlineDBHandler::TDCConditions::tdc_id

The documentation for this struct was generated from the following file:


• include/OnlineDBHandler.h

7.23 TDCControl Class Reference


Control word to be sent to the HPTDC chip.

#include <TDCControl.h>

Inheritance diagram for TDCControl:



Collaboration diagram for TDCControl:



Public Types

- enum EnablePattern
- enum RegisterName { R_EnablePattern, R_GlobalReset, R_DLLReset, R_PLLReset }

Public Member Functions

- TDCControl ()
- TDCControl (const TDCControl &c)
- TDCControl (const std::vector< uint8_t > &words)
- void SetEnablePattern (const EnablePattern &ep)
- EnablePattern GetEnablePattern () const
- void SetGlobalReset (const bool gr=true)
- bool GetGlobalReset () const
- void SetDLLReset (const bool dr=true)
- bool GetDLLReset () const
- void SetPLLReset (const bool pr=true)
- bool GetPLLReset () const
- void EnableChannel (unsigned int id)
- void EnableAllChannels ()
- void DisableChannel (unsigned int id)

- void DisableAllChannels ()
- void Dump (int verb=1, std::ostream &os=std::cout) const
- void SetConstantValues ()

Private Member Functions

• void SetControlParity (const bool cp=true)

Static Private Attributes

- static const bit kEnablePattern = 0
- static const bit kGlobalReset = 4
- static const bit kEnableChannel = 5
- static const bit kDLLReset = 37
- static const bit kPLLReset = 38
- static const bit kControlParity = 39

Additional Inherited Members

7.23.1 Detailed Description

Control word to be sent to the HPTDC chip.

Object handling the control word provided by/to the HPTDC chip

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

24 Apr 2015

7.23.2 Member Enumeration Documentation

7.23.2.1 enum TDCControl::EnablePattern

7.23.2.2 enum TDCControl::RegisterName

Enumerator

R_EnablePattern

R_GlobalReset

R_DLLReset

R_PLLReset

7.23.3 Constructor & Destructor Documentation

```
7.23.3.1 TDCControl::TDCControl( ) [inline]
```

```
TDCControl::TDCControl::EnableChannel


TDCControl::EnableChannel

TDCControl::EnableChannel

TDCControl::EnableChannel
```

7.23.3.2 TDCControl::TDCControl (const TDCControl & c) [inline]

Here is the call graph for this function:



7.23.3.3 TDCControl::TDCControl (const std::vector < uint8_t > & words) [inline]

7.23.4 Member Function Documentation

7.23.4.1 void TDCControl::DisableAllChannels () [inline]

Here is the call graph for this function:




7.23.4.2 void TDCControl::DisableChannel (unsigned int id) [inline]



7.23.4.3 void TDCControl::Dump (int verb = 1, std::ostream & os = std::cout) const [inline]

Here is the call graph for this function:




7.23.4.4 void TDCControl::EnableAllChannels () [inline]

Here is the call graph for this function:



 $\textbf{7.23.4.5} \quad \textbf{void TDCControl} :: \textbf{EnableChannel (unsigned int } \textit{id)} \quad \texttt{[inline]}$




7.23.4.6 bool TDCControl::GetDLLReset () const [inline]

Here is the call graph for this function:



7.23.4.7 EnablePattern TDCControl::GetEnablePattern () const [inline]

Here is the call graph for this function:



7.23.4.8 bool TDCControl::GetGlobalReset() const [inline]



7.23.4.9 bool TDCControl::GetPLLReset() const [inline]

Here is the call graph for this function:



7.23.4.10 void TDCControl::SetConstantValues() [inline], [virtual]

Ensure that the critical constant values are properly set in the register word Implements TDCRegister.

Here is the call graph for this function:



7.23.4.11 void TDCControl::SetControlParity (const bool cp = true) [inline], [private]

Here is the call graph for this function:



7.23.4.12 void TDCControl::SetDLLReset (const bool dr = true) [inline]



7.23.4.13 void TDCControl::SetEnablePattern (const EnablePattern & ep) [inline]

Here is the call graph for this function:



7.23.4.14 void TDCControl::SetGlobalReset (const bool gr = true) [inline]

Here is the call graph for this function:



7.23.4.15 void TDCControl::SetPLLReset (const bool pr = true) [inline]

Here is the call graph for this function:



7.23.5 Field Documentation

7.23.5.1 const bit TDCControl::kControlParity = 39 [static], [private]

7.23.5.2 const bit TDCControl::kDLLReset = 37 [static], [private]

7.23.5.3 const bit TDCControl::kEnableChannel = 5 [static], [private]

7.23.5.4 const bit TDCControl::kEnablePattern = 0 [static], [private]

7.23.5.5 const bit TDCControl::kGlobalReset = 4 [static], [private]

7.23.5.6 const bit TDCControl::kPLLReset = 38 [static], [private]

The documentation for this class was generated from the following file:

· daq/include/TDCControl.h

7.24 TDCErrorFlag Class Reference

Error flags handler.

#include <TDCEvent.h>

Public Member Functions

- TDCErrorFlag (uint16_t ef)
- virtual ∼TDCErrorFlag ()
- · uint16 t GetWord () const
- void Dump () const
- bool HasReadoutFIFOOverflow (unsigned int group_id) const

Check whether hits have been lost from read-out FIFO overflow in a given group.

bool HasL1BufferOverflow (unsigned int group_id) const

Check whether hits have been lost from L1 buffer overflow in a given group.

• bool HasGroupError (unsigned int group_id) const

Check whether hits have been lost due to error in a given group.

bool HasReachedEventSizeLimit () const

Hits rejected because of programmed event size limit.

• bool HasTriggerFIFOOverflow () const

Event lost (trigger FIFO overflow)

• bool HasInternalChipError () const

Internal fatal chip error has been detected.

Private Attributes

• uint16_t fWord

Friends

• std::ostream & operator<< (std::ostream &os, const TDCErrorFlag &ef)

7.24.1 Detailed Description

Error flags handler.

Author

 $\textbf{Laurent Forthomme} \ \texttt{laurent.forthomme} \\ \texttt{@cern.ch}$

Date

22 Jun 2015

7.24.2 Constructor & Destructor Documentation

```
7.24.2.1 TDCErrorFlag::TDCErrorFlag ( uint16_t ef ) [inline]
```

7.24.2.2 virtual TDCErrorFlag::~TDCErrorFlag() [inline], [virtual]

7.24.3 Member Function Documentation

```
7.24.3.1 void TDCErrorFlag::Dump() const [inline]
```

7.24.3.2 uint16_t TDCErrorFlag::GetWord() const [inline]

7.24.3.3 bool TDCErrorFlag::HasGroupError (unsigned int group_id) const [inline]

Check whether hits have been lost due to error in a given group.

```
7.24.3.4 bool TDCErrorFlag::HasInternalChipError() const [inline]
```

Internal fatal chip error has been detected.

7.24.3.5 bool TDCErrorFlag::HasL1BufferOverflow (unsigned int group_id) const [inline]

Check whether hits have been lost from L1 buffer overflow in a given group.

```
7.24.3.6 bool TDCErrorFlag::HasReachedEventSizeLimit() const [inline]
```

Hits rejected because of programmed event size limit.

7.24.3.7 bool TDCErrorFlag::HasReadoutFIFOOverflow (unsigned int group_id) const [inline]

Check whether hits have been lost from read-out FIFO overflow in a given group.

```
7.24.3.8 bool TDCErrorFlag::HasTriggerFlFOOverflow( )const [inline]
```

Event lost (trigger FIFO overflow)

7.24.4 Friends And Related Function Documentation

```
7.24.4.1 std::ostream& operator<<( std::ostream & os, const TDCErrorFlag & ef ) [friend]
```

7.24.5 Field Documentation

```
7.24.5.1 uint16_t TDCErrorFlag::fWord [private]
```

The documentation for this class was generated from the following file:

• include/TDCEvent.h

7.25 TDCEvent Class Reference

HPTDC event parser.

```
#include <TDCEvent.h>
```

Public Types

```
    enum EventType {
        TDCMeasurement = 0x0, TDCHeader = 0x1, TDCTrailer = 0x3, TDCError = 0x4,
        GlobalHeader = 0x8, GlobalTrailer = 0x10, ETTT = 0x11, Filler = 0x18,
        Trigger = 0x1f }
```

Public Member Functions

- TDCEvent ()
- TDCEvent (const TDCEvent &ev)
- TDCEvent (const uint32_t &word)
- TDCEvent (const EventType &ev)
- virtual ∼TDCEvent ()
- · void Dump () const
- void SetWord (const uint32_t &word)
- uint32_t GetWord () const
- EventType GetType () const

Type of packet read out from the TDC.

• unsigned int GetTDCld () const

Programmed identifier of master TDC providing the event.

• uint16_t GetEventId () const

Event identifier from event counter.

• uint16_t GetWordCount () const

Total number of words in event (including headers and trailers)

- unsigned int GetGeo () const
- · unsigned int GetChannelld () const

Channel number for.

• uint32_t GetEventCount () const

Total number of events.

• uint16_t GetBunchld () const

Bunch identifier of trigger (or trigger time tag)

• bool IsTrailing () const

Are we dealing with a trailing or a leading measurement?

uint32_t GetETTT () const

Extended trigger time tag.

• uint32_t GetTime (bool pair=false) const

Edge measurement in programmed time resolution.

• unsigned int GetWidth () const

Width of pulse in programmed time resolution.

- · unsigned int GetStatus () const
- TDCErrorFlag GetErrorFlags () const

Return error flags if an error condition has been detected.

Private Attributes

uint32_t fWord

7.25.1 Detailed Description

```
HPTDC event parser.
```

Object enabling to decipher any measurement/error/debug event returned by the HPTDC chip

Author

```
Laurent Forthomme laurent.forthomme@cern.ch
```

Date

4 May 2015

7.25.2 Member Enumeration Documentation

7.25.2.1 enum TDCEvent::EventType

Enumerator

TDCMeasurement

TDCHeader

TDCTrailer

TDCError

GlobalHeader

GlobalTrailer

ETTT

Filler

Trigger

7.25.3 Constructor & Destructor Documentation

```
7.25.3.1 TDCEvent::TDCEvent() [inline]
```

7.25.3.2 TDCEvent::TDCEvent (const TDCEvent & ev) [inline]

7.25.3.3 TDCEvent::TDCEvent (const uint32_t & word) [inline]

7.25.3.4 TDCEvent::TDCEvent(const EventType & ev) [inline]

7.25.3.5 virtual TDCEvent::~TDCEvent() [inline], [virtual]

7.25.4 Member Function Documentation

7.25.4.1 void TDCEvent::Dump() const [inline]

Here is the call graph for this function:



7.25.4.2 uint16_t TDCEvent::GetBunchld() const [inline]

Bunch identifier of trigger (or trigger time tag)

Here is the call graph for this function:



7.25.4.3 unsigned int TDCEvent::GetChannelld () const [inline]

Channel number for.

Here is the call graph for this function:



7.25.4.4 TDCErrorFlag TDCEvent::GetErrorFlags () const [inline]

Return error flags if an error condition has been detected.

Here is the call graph for this function:



7.25.4.5 uint32_t TDCEvent::GetETTT() const [inline]

Extended trigger time tag.

Here is the call graph for this function:



7.25.4.6 uint32_t TDCEvent::GetEventCount () const [inline]

Total number of events.

Here is the call graph for this function:



7.25.4.7 uint16_t TDCEvent::GetEventId() const [inline]

Event identifier from event counter.

Here is the call graph for this function:



7.25.4.8 unsigned int TDCEvent::GetGeo () const [inline]

Here is the call graph for this function:



7.25.4.9 unsigned int TDCEvent::GetStatus () const [inline]

Here is the call graph for this function:



7.25.4.10 unsigned int TDCEvent::GetTDCld() const [inline]

Programmed identifier of master TDC providing the event.

Here is the call graph for this function:



7.25.4.11 uint32_t TDCEvent::GetTime (bool pair = false) const [inline]

Edge measurement in programmed time resolution.

Parameters

in	pair	Are we dealing with a pair measurement? (only for leading time word)

Here is the call graph for this function:



7.25.4.12 EventType TDCEvent::GetType () const [inline]

Type of packet read out from the TDC.

7.25.4.13 unsigned int TDCEvent::GetWidth() const [inline]

Width of pulse in programmed time resolution.



```
7.25.4.14 uint32_t TDCEvent::GetWord() const [inline]
```

7.25.4.15 uint16_t TDCEvent::GetWordCount() const [inline]

Total number of words in event (including headers and trailers)

Here is the call graph for this function:



7.25.4.16 bool TDCEvent::IsTrailing() const [inline]

Are we dealing with a trailing or a leading measurement?

Here is the call graph for this function:



7.25.4.17 void TDCEvent::SetWord (const uint32_t & word) [inline]

7.25.5 Field Documentation

7.25.5.1 uint32_t TDCEvent::fWord [private]

The documentation for this class was generated from the following file:

• include/TDCEvent.h

7.26 TDCMeasurement Class Reference

#include <TDCMeasurement.h>

Public Member Functions

- TDCMeasurement ()
- TDCMeasurement (const std::vector< TDCEvent > &v)

- ∼TDCMeasurement ()
- void Dump ()
- void SetEventsCollection (const std::vector< TDCEvent > &v)
- uint32 t GetLeadingTime (unsigned short event id=0)
- uint32_t GetTrailingTime (unsigned short event_id=0)
- uint16_t GetToT (unsigned short event_id=0)
- uint16_t GetChannelld (unsigned short event_id=0)
- uint16_t GetTDCld ()
- uint16_t GetEventId ()
- uint16_t GetBunchld ()
- uint32_t GetETTT ()
- size_t NumEvents () const
- size_t NumErrors () const

Private Attributes

- std::map< TDCEvent::EventType, TDCEvent > fMap
- std::vector< std::pair< TDCEvent, TDCEvent > > fEvents

7.26.1 Detailed Description

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

Jun 2015

7.26.2 Constructor & Destructor Documentation

7.26.2.1 TDCMeasurement::TDCMeasurement() [inline]

7.26.2.2 TDCMeasurement::TDCMeasurement (const std::vector < TDCEvent > & v) [inline]

Here is the call graph for this function:




7.26.2.3 TDCMeasurement::~TDCMeasurement() [inline]

7.26.3 Member Function Documentation

7.26.3.1 void TDCMeasurement::Dump() [inline]


Here is the call graph for this function:



7.26.3.2 uint16_t TDCMeasurement::GetChannelld (unsigned short event_id = 0) [inline]
7.26.3.3 uint16_t TDCMeasurement::GetETTT() [inline]
7.26.3.4 uint32_t TDCMeasurement::GetETTT() [inline]
7.26.3.5 uint16_t TDCMeasurement::GetEventId() [inline]
7.26.3.6 uint32_t TDCMeasurement::GetLeadingTime(unsigned short event_id = 0) [inline]
7.26.3.7 uint16_t TDCMeasurement::GetTDCId() [inline]

7.26.3.8 uint16_t TDCMeasurement::GetToT (unsigned short event_id = 0) [inline]

Here is the call graph for this function:



```
7.26.3.9 uint32_t TDCMeasurement::GetTrailingTime ( unsigned short event_id = 0 ) [inline]
7.26.3.10 size_t TDCMeasurement::NumErrors ( ) const [inline]
7.26.3.11 size_t TDCMeasurement::NumEvents ( ) const [inline]
7.26.3.12 void TDCMeasurement::SetEventsCollection ( const std::vector < TDCEvent > & v ) [inline]
7.26.4 Field Documentation
7.26.4.1 std::vector < std::pair < TDCEvent, TDCEvent > > TDCMeasurement::fEvents [private]
```

7.26.4.2 std::map<TDCEvent::EventType,TDCEvent>TDCMeasurement::fMap [private]

The documentation for this class was generated from the following file:


• include/TDCMeasurement.h

7.27 TDCRegister Class Reference

General register object to interact with a HPTDC chip.

```
#include <TDCRegister.h>
```

Inheritance diagram for TDCRegister:



Public Types

typedef uint16 t bit

LSB index.

typedef uint32 t word t

Unit of the TDC register word to be successfully contained on any machine.

Public Member Functions

- TDCRegister (const unsigned int size)
- TDCRegister (const unsigned int size, const TDCRegister &r)
- TDCRegister (const unsigned int size, const std::vector< uint8_t > words)
- virtual ∼TDCRegister ()
- TDCRegister & operator= (const TDCRegister &r)
- void SetWord (const unsigned int i, const word_t word)

Set one bit(s) subset in the register word.

· word_t GetWord (const unsigned int i) const

Retrieve one subset from the register word.

- word_t * GetWords () const
- uint8_t GetNumWords () const

Number of words in the register.

- void DumpRegister (std::ostream &os=std::cout, const bit max_bits=-1) const
- virtual void SetConstantValues ()=0

Protected Member Functions

• void SetBits (uint16_t lsb, uint16_t word, uint8_t size)

Set bits in the register word.

uint16_t GetBits (uint16_t lsb, uint8_t size) const

Extract bits from the register word.

• void Clear ()

Set all bits in this register to '0'.

Protected Attributes

• word_t * fWord

Pointer to this register's word.

- unsigned int fNumWords
- unsigned int fWordSize

Number of bits in this register.

7.27.1 Detailed Description

General register object to interact with a HPTDC chip.

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

24 Apr 2015

7.27.2 Member Typedef Documentation

7.27.2.1 typedef uint16_t TDCRegister::bit

LSB index.

7.27.2.2 typedef uint32_t TDCRegister::word_t

Unit of the TDC register word to be successfully contained on any machine.

7.27.3 Constructor & Destructor Documentation

7.27.3.1 TDCRegister::TDCRegister (const unsigned int *size* **)** [inline]

Here is the call graph for this function:



7.27.3.2 TDCRegister::TDCRegister (const unsigned int size, const TDCRegister & r) [inline]

Here is the call graph for this function:



7.27.3.3 TDCRegister::TDCRegister (const unsigned int size, const std::vector < uint8_t > words) [inline]



7.27.3.4 virtual TDCRegister::~TDCRegister() [inline], [virtual]

7.27.4 Member Function Documentation

7.27.4.1 void TDCRegister::Clear() [inline], [protected]

Set all bits in this register to '0'.

7.27.4.2 void TDCRegister::DumpRegister (std::ostream & os = std::cout, const bit max_bits = -1) const [inline]

7.27.4.3 uint16_t TDCRegister::GetBits (uint16_t *lsb*, uint8_t *size*) const [inline], [protected]

Extract bits from the register word.

Extract a fixed amount of bits from the full register word

Parameters

in	Isb	Least significant bit of the word to retrieve
in	size	Size of the word to retrieve

7.27.4.4 uint8_t TDCRegister::GetNumWords() const [inline]

Number of words in the register.

Return the number of words making up the full register word.

7.27.4.5 word_t TDCRegister::GetWord (const unsigned int *i*) const [inline]

Retrieve one subset from the register word.

7.27.4.6 word t* TDCRegister::GetWords() const [inline]

7.27.4.7 TDCRegister& TDCRegister::operator=(const TDCRegister & r) [inline]

7.27.4.8 void TDCRegister::SetBits (uint16_t lsb, uint16_t word, uint8_t size) [inline], [protected]

Set bits in the register word.

Set a fixed amount of bits in the full register word

Parameters

in	lsb	Least significant bit of the word to set
in	word	Word to set
in	size	Size of the word to set

7.27.4.9 virtual void TDCRegister::SetConstantValues () [pure virtual]

Ensure that the critical constant values are properly set in the register word

Implemented in TDCSetup, TDCControl, TDCBoundaryScan, and TDCStatus.

7.27.4.10 void TDCRegister::SetWord (const unsigned int i, const word_t word) [inline]

Set one bit(s) subset in the register word.

7.27.5 Field Documentation

7.27.5.1 unsigned int TDCRegister::fNumWords [protected]

Number of words to fit the fWordSize bits of this register to this object

7.27.5.2 word_t* TDCRegister::fWord [protected]

Pointer to this register's word.

7.27.5.3 unsigned int TDCRegister::fWordSize [protected]

Number of bits in this register.

The documentation for this class was generated from the following file:


• daq/include/TDCRegister.h

7.28 TDCSetup Class Reference


Setup word to be sent to the HPTDC chip.

#include <TDCSetup.h>

Inheritance diagram for TDCSetup:



Collaboration diagram for TDCSetup:



Public Types

```
    enum EdgeResolution {

 E 100ps = 0, E 200ps, E 400ps, E 800ps,
 E 1p6ns, E 3p12ns, E 6p25ns, E 12p5ns }

    enum DeadTime { DT_5ns =0, DT_10ns, DT_30ns, DT_100ns }

enum WidthResolution {
 W_100ps =0, W_200ps, W_400ps, W_800ps,
 W_1p6ns, W_3p2ns, W_6p25ns, W_12p5ns,
 W 25ns, W 50ns, W 100ns, W 200ns,
 W 400ns, W 800ns }
enum EnabledError {
 VernierError =0x1, CoarseError =0x2, ChannelSelectError =0x4, L1BufferParityError =0x8,
 TriggerFIFOParityError =0x10, TriggerMatchingError =0x20, ReadoutFIFOParityError =0x40, ReadoutState ←
 Error =0x80.
 SetupParityError =0x100, ControlParityError =0x200, JTAGInstructionParityError =0x400 }
enum DLLSpeedMode { DLL 40MHz =0x0, DLL 160MHz =0x1, DLL 320MHz =0x2, DLL Illegal =0x3 }
• enum SerialClockSource { Serial pll clock 80 =0x0, Serial pll clock 160 =0x1, Serial pll clock 40 =0x2,
 Serial aux clock =0x3 }
• enum IOClockSource { IO clock 40 =0x0, IO pll clock 80 =0x1, IO pll clock 160 =0x2, IO aux clock =0x3
 }
• enum CoreClockSource { Core_clock_40 =0x0, Core_pll_clock_80 =0x1, Core_pll_clock_160 =0x2, Core_
 aux_clock =0x3 }

    enum DLLClockSource {

 DLL_clock_40 =0x0, DLL_pll_clock_40 =0x1, DLL_pll_clock_160 =0x2, DLL_pll_clock_320 =0x3,
 DLL_aux_clock =0x4 }

    enum ReadoutSpeed { RO Fixed =0x0, RO pll 80Mbits s =0x1 }

• enum SerialStrobeType { SS NoStrobe =0x0, SS DSStrobe =0x1, SS LeadingTrailingStrobe =0x2, SS ←
 LeadingEdge =0x3 }
• enum ReadoutSingleCycleSpeed {
 RSC_40Mbits_s =0x0, RSC_20Mbits_s =0x1, RSC_10Mbits_s =0x2, RSC_5Mbits_s =0x3,
 RSC 2p5Mbits s = 0x4, RSC 1p25Mbits s = 0x5, RSC 625kbits s = 0x6, RSC 312p5kbits s = 0x7
```

Public Member Functions

- TDCSetup ()
- TDCSetup (const TDCSetup &c)
- void SetEnableErrorMark (const bool em)

Mark events with error if global error signal is set.

- · bool GetEnableErrorMark () const
- void SetEnableErrorBypass (const bool eb)

Bypass TDC chip if global error signal is set.

- · bool GetEnableErrorBypass () const
- void SetEnableError (const uint16 t &err)

Enable internal error types for generation of global error signals.

- uint16 t GetEnableError () const
- void SetEnableSerial (const bool es)

Enable of serial read-out (otherwise parallel read-out)

- bool GetEnableSerial () const
- void SetEnableJTAGReadout (const bool jr)

Enable of read-out via JTAG.

- bool GetEnableJTAGReadout () const
- void SetReadoutFIFOSize (int rfs)

Effective size of readout FIFO.

- int GetReadoutFIFOSize () const
- void SetRejectCountOffset (uint16_t rco)

Set the offset in reject counter (defines reject latency together with coarse count offset)

• uint16_t GetRejectCountOffset () const

Extract the offset in reject counter.

void SetSearchWindow (uint16_t sw)

Set the search window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

• uint16_t GetSearchWindow () const

Extract the search window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

void SetMatchWindow (uint16_t mw)

Set the matching window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

• uint16_t GetMatchWindow () const

Extract the matching window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

- void SetEdgeResolution (const EdgeResolution r)
- · EdgeResolution GetEdgeResolution () const
- void SetMaxEventSize (int sz=-1)

Set the maximum number of hits per event.

• uint8_t GetMaxEventSize () const

Extract the maximum number of hits per event.

void SetRejectFIFOFull (const bool rej=true)

Reject hits when readout FIFO full.

• bool GetRejectFIFOFull () const

Are hits rejected when readout FIFO is full?

void SetEnableReadoutOccupancy (const bool ro=true)

Enable the readout of buffer occupancies for each event (for debugging purposes)

- bool GetEnableReadoutOccupancy () const
- void SetEnableReadoutSeparator (const bool ro=true)

Enable the readout of separators for each event (for debugging purposes, valid if readout of occupancies is enabled)

- bool GetEnableReadoutSeparator () const
- void SetEventCountOffset (uint16 t eco)

Set offset for the event counter.

void SetTriggerCountOffset (uint16_t tco)

Set offset for the trigger time tag counter to set effective trigger latency.

uint16_t GetTriggerCountOffset () const

Extract trigger time tag count offset.

void SetChannelOffset (int channel, uint16_t offset)

Set the time offset for one single channel.

uint16_t GetChannelOffset (int channel) const

Return the offset for one single channel.

void SetAllChannelsOffset (uint16 t offset)

Set the time offset for all channels.

void SetCoarseCountOffset (uint16 t cco)

Set offset for the coarse time counter.

• uint16 t GetCoarseCountOffset () const

Extract offset for the coarse time counter.

void SetDLLAdjustment (int tap, uint8_t adj)

Set the DLL taps adjustments with a resolution of \sim 10 ps.

• uint8_t GetDLLAdjustment (int tap) const

Set the adjustment of DLL taps.

· void SetAllTapsDLLAdjustment (uint8_t adj)

Extract the adjustment of DLL taps.

void SetRCAdjustment (int tap, uint8_t adj)

Set the adjustment of the RC delay line.

uint8 t GetRCAdjustment (int tap)

Extract the adjustment of the RC delay line.

void SetWidthResolution (const WidthResolution r)

Set the pulse width resolution when paired measurements are performed.

· WidthResolution GetWidthResolution () const

Extract the pulse width resolution when paired measurements are performed.

• void SetVernierOffset (const uint8 t vo)

Set the offset in vernier decoding.

uint8_t GetVernierOffset () const

Extract the offset in vernier decoding.

void SetDeadTime (const DeadTime dt)

Channel dead time between hits.

- DeadTime GetDeadTime () const
- void SetTestInvert (const bool ti=true)

Automatic inversion of test pattern. Only used during production testing.

- · bool GetTestInvert () const
- void SetTestMode (const bool tm=true)

Test mode where hit data are taken from coretest. Only used during production testing.

- bool GetTestMode () const
- void SetTrailingMode (const bool trail=true)

Enable/disable the detection of trailing edges.

• bool GetTrailingMode () const

Extract the status for the detection of trailing edges.

void SetLeadingMode (const bool lead=true)

Enable the detection of leading edges.

bool GetLeadingMode () const

Extract the status for the detection of leading edges.

void SetTriggerMatchingMode (const bool trig=true)

Set the enable status of trigger matching mode.

bool GetTriggerMatchingMode () const

Extract the enable status of trigger matching mode.

void SetEdgesPairing (const bool pair=true)

Enable the pairing of leading and trailing edges (overrides individual enable of leading/trailing edges)

• bool GetEdgesPairing () const

void SetSetupParity (const bool sp=true)

Set the parity of setup data (should be an even parity)

bool GetSetupParity () const

Extract the parity of setup data (should be an even parity)

void SetConstantValues ()

Ensure that the critical constant values are properly set in the setup word.

uint16 t GetTriggerLatency () const

Effective trigger latency in number of clock cycles (when no counter roll-over is used)

- void SetTDCId (const uint8 t id=0x0)
- uint16_t GetTDCld () const
- void Dump (int verb=1, std::ostream &os=std::cout) const

Private Member Functions

void SetReadoutSingleCycleSpeed (const ReadoutSingleCycleSpeed rscs=RSC 40Mbits s)

Serial transmission speed in single cycle mode.

void SetSerialDelay (const uint8_t sd=0x0)

Programmable delay of serial input, in time unit \sim 1 ns.

- void SetStrobeSelect (const SerialStrobeType ss=SS NoStrobe)
- void SetReadoutSpeedSelect (const ReadoutSpeed rss=RO Fixed)

Selection of serial read-out speed.

void SetTokenDelay (const uint8 t td=0x0)

Programmable delay of token input, in time unit \sim 1 ns.

void SetEnableLocalTrailer (const bool elt=true)

Enable of local trailers in read-out.

void SetEnableLocalHeader (const bool elh=true)

Enable of local headers in read-out.

void SetEnableGlobalTrailer (const bool egt=true)

Enable of global trailers in read-out (only valid for master TDC)

void SetEnableGlobalHeader (const bool egh=true)

Enable of global headers in read-out (only valid for master TDC)

- void SetKeepToken (const bool kt=true)
- void SetMaster (const bool m=true)
- void SetEnableBytewise (const bool seb=true)
- void SetBypassInputs (const bool sbi=true)

Select serial in and token in from bypass inputs.

void SetEnableOverflowDetect (const bool eod=true)

Enable overflow detection of L1 buffers (should always be enabled!)

- void SetEnableRelative (const bool er=true)
- void SetEnableAutomaticReject (const bool ear=true)

Enable of automatic rejection (should always be enabled if trigger matching mode!)

void SetEnableSetCountersOnBunchReset (const bool escobr=true)

Enable all counters to be set on bunch count reset.

void SetEnableMasterResetCode (const bool emrc=true)

Enable master reset code on encoded_control.

void SetEnableMasterResetOnEventReset (const bool emroer=true)

Enable master reset of whole TDC on event reset.

void SetEnableResetChannelBufferWhenSeparator (const bool ercbws=true)

Enable reset channel buffers when separator.

void SetEnableSeparatorOnEventReset (const bool esoer=true)

Enable generation of separator on event reset.

• void SetEnableSeparatorOnBunchReset (const bool esobr=true)

Enable generation of separator on bunch reset.

void SetEnableDirectEventReset (const bool eder=true)

Enable of direct event reset input pin (1), otherwise taken from encoded control.

void SetEnableDirectBunchReset (const bool edbr=true)

Enable of direct bunch reset input pin (1), otherwise taken from encoded control.

void SetEnableDirectTrigger (const bool edt=true)

Enable of direct trigger input pin.

void SetLowPowerMode (const bool lpm=true)

Low power mode of channel buffers.

void SetDLLControl (const uint8_t dc)

Control of DLL (DLL charge pump levels)

void SetModeRCCompression (const bool mrc=true)

Perform RC interpolation on-chip (only valid in very high resolution mode)

void SetModeRC (const bool mr=true)

Enable of RR delay lines mode (in very high resolution mode); only for channels 0-4-8-12-16-20-24-28 active.

void SetDLLMode (const DLLSpeedMode dsm)

Selection of DLL speed mode.

• void SetPLLControl (const uint8_t charge_pump_current=0x4, const bool power_down_mode=false, const bool enable_test_outputs=false, const bool invert_connection_to_status=false)

Control of PLL.

void SetSerialClockDelay (const bool delay clock, const uint8 t delay)

Delay of internal serial clock.

void SetIOClockDelay (const bool delay_clock, const uint8_t delay)

Delay of internal I/O clock.

void SetCoreClockDelay (const bool delay_clock, const uint8_t delay)

Delay of internal core clock.

void SetDLLClockDelay (const bool delay clock, const uint8 t delay)

Delay of internal DLL clock.

void SetSerialClockSource (const SerialClockSource scs)

Selection of source for serial clock.

void SetIOClockSource (const IOClockSource ics)

Selection of clock source for I/O signals.

void SetCoreClockSource (const CoreClockSource ccs)

Selection of clock source for internal logic.

void SetDLLClockSource (const DLLClockSource dcs)

Selection of clock source for DLL.

void SetRollOver (const uint16_t ro=0xFFF)

Counter roll over value, defining maximal count value from where counters will be reset to 0.

void SetEnableTTLSerial (const bool ts=true)

Enable LV TTL inputs on serial registers, and disable their drivers.

void SetEnableTTLControl (const bool tc=true)

Enable LV TTL inputs on control registers.

void SetEnableTTLReset (const bool tr=true)

Enable LV TTL input on reset, otherwise uses LVDS input levels.

void SetEnableTTLClock (const bool tc=true)

Enable LV TTL inputs on: clk, aux_clock, otherwise uses LVDS input levels.

void SetEnableTTLHit (const bool th=true)

Enable LV TTL input on hit[31:0], otherwise uses LVDS input levels.

void SetTest (const bool test=true)

Static Private Attributes

- static const bit kTestSelect = 0
- static const bit kEnableErrorMark = 4
- static const bit kEnableErrorBypass = 5
- static const bit kEnableError = 6
- static const bit kReadoutSingleCycleSpeed = 17
- static const bit kSerialDelay = 20
- static const bit kStrobeSelect = 24
- static const bit kReadoutSpeedSelect = 26
- static const bit kTokenDelay = 27
- static const bit kEnableLocalTrailer = 31
- static const bit kEnableLocalHeader = 32
- static const bit kEnableGlobalTrailer = 33
- static const bit kEnableGlobalHeader = 34
- static const bit kKeepToken = 35
- static const bit kMaster = 36
- static const bit kEnableBytewise = 37
- static const bit kEnableSerial = 38
- static const bit kEnableJTAGReadout = 39
- static const bit kTDCld = 40
- static const bit kSelectBypassInputs = 44
- static const bit kReadoutFIFOSize = 45
- static const bit kRejectCountOffset = 48
- static const bit kSearchWindow = 60
- static const bit kMatchWindow = 72
- static const bit kLeadingResolution = 84
- static const bit kMaxEventSize = 116
- static const bit kRejectFIFOFull = 120
- static const bit kEnableReadoutOccupancy = 121
- static const bit kEnableReadoutSeparator = 122
- static const bit kEnableOverflowDetect = 123
- static const bit kEnableRelative = 124
- static const bit kEnableAutomaticReject = 125
- static const bit kEventCountOffset = 126
- static const bit kTriggerCountOffset = 138
- static const bit kEnableSetCountersOnBunchReset = 150
- static const bit kEnableMasterResetCode = 151
- static const bit kEnableMasterResetOnEventReset = 152
- static const bit kEnableResetChannelBufferWhenSeparator = 153
- static const bit kEnableSeparatorOnEventReset = 154
- static const bit kEnableSeparatorOnBunchReset = 155
- static const bit kEnableDirectEventReset = 156
- static const bit kEnableDirectBunchReset = 157
- static const bit kEnableDirectTrigger = 158
- static const bit kOffset0 = 438
- static const bit kCoarseCountOffset = 447
- static const bit kDLLTapAdjust0 = 459
- static const bit kRCAdjust0 = 555
- static const bit kLowPowerMode = 570
- static const bit kWidthSelect = 571
- static const bit kVernierOffset = 575
- static const bit kDLLControl = 580
- static const bit kDeadTime = 584
- static const bit kTestInvert = 586

- static const bit kTestMode = 587
- static const bit kTrailing = 588
- static const bit kLeading = 589
- static const bit kModeRCCompression = 590
- static const bit kModeRC = 591
- static const bit kDLLMode = 592
- static const bit kPLLControl = 594
- static const bit kSerialClockDelay = 602
- static const bit kIOClockDelay = 606
- static const bit kCoreClockDelay = 610
- static const bit kDLLClockDelay = 614
- static const bit kSerialClockSource = 618
- static const bit kIOClockSource = 620
- static const bit kCoreClockSource = 622
- static const bit kDLLClockSource = 624
- static const bit kRollOver = 627
- static const bit kEnableMatching = 639
- static const bit kEnablePair = 640
- static const bit kEnableTTLSerial = 641
- static const bit kEnableTTLControl = 642
- static const bit kEnableTTLReset = 643
- static const bit kEnableTTLClock = 644
- static const bit kEnableTTLHit = 645
- static const bit kSetupParity = 646

Additional Inherited Members

7.28.1 Detailed Description

Setup word to be sent to the HPTDC chip.

Object handling the setup word provided by/to the HPTDC chip

Author

Laurent Forthomme laurent.forthomme@cern.ch

Date

16 Apr 2015

7.28.2 Member Enumeration Documentation

7.28.2.1 enum TDCSetup::CoreClockSource

Enumerator

Core_clock_40
Core_pll_clock_80
Core_pll_clock_160
Core_aux_clock

7.28.2.2 enum TDCSetup::DeadTime

Enumerator

DT_5ns

DT_10ns

DT_30ns

DT_100ns

7.28.2.3 enum TDCSetup::DLLClockSource

Enumerator

DLL_clock_40

DLL_pll_clock_40

DLL_pll_clock_160

DLL_pll_clock_320

DLL_aux_clock

7.28.2.4 enum TDCSetup::DLLSpeedMode

Enumerator

DLL_40MHz

DLL_160MHz

DLL_320MHz

DLL_Illegal

7.28.2.5 enum TDCSetup::EdgeResolution

Enumerator

E_100ps

E_200ps

E_400ps

E_800ps

E_1p6ns

E_3p12ns

E_6p25ns

E_12p5ns

7.28.2.6 enum TDCSetup::EnabledError

Enumerator

VernierError

CoarseError

ChannelSelectError

L1BufferParityError

```
TriggerFIFOParityError
     TriggerMatchingError
    ReadoutFIFOParityError
    ReadoutStateError
    SetupParityError
    ControlParityError
    JTAGInstructionParityError
7.28.2.7 enum TDCSetup::IOClockSource
Enumerator
    IO_clock_40
    IO_pll_clock_80
    IO_pll_clock_160
    IO aux clock
7.28.2.8 enum TDCSetup::ReadoutSingleCycleSpeed
Enumerator
    RSC_40Mbits_s
    RSC_20Mbits_s
    RSC_10Mbits_s
    RSC_5Mbits_s
    RSC_2p5Mbits_s
    RSC_1p25Mbits_s
    RSC_625kbits_s
    RSC_312p5kbits_s
7.28.2.9 enum TDCSetup::ReadoutSpeed
Enumerator
    RO_Fixed
    RO_pll_80Mbits_s
7.28.2.10 enum TDCSetup::SerialClockSource
Enumerator
    Serial_pll_clock_80
    Serial_pll_clock_160
    Serial_pll_clock_40
```

Serial_aux_clock

7.28.2.11 enum TDCSetup::SerialStrobeType

Enumerator

- SS_NoStrobe
- SS_DSStrobe
- SS_LeadingTrailingStrobe
- SS_LeadingEdge


7.28.2.12 enum TDCSetup::WidthResolution

Enumerator

- W_100ps
- W_200ps
- W_400ps
- W_800ps
- W_1p6ns
- W_3p2ns
- W_6p25ns
- W_12p5ns
- W_25ns
- W_50ns
- W_100ns
- W_200ns
- W_400ns
- W_800ns


7.28.3 Constructor & Destructor Documentation

7.28.3.1 TDCSetup::TDCSetup() [inline]



7.28.3.2 TDCSetup::TDCSetup (const TDCSetup & c) [inline]


Here is the call graph for this function:



7.28.4 Member Function Documentation

7.28.4.1 void TDCSetup::Dump (int verb = 1, std::ostream & os = std::cout) const

Here is the call graph for this function:



7.28.4.2 uint16_t TDCSetup::GetChannelOffset(int channel) const [inline]

Return the offset for one single channel.

Here is the call graph for this function:




7.28.4.3 uint16_t TDCSetup::GetCoarseCountOffset() const [inline]

Extract offset for the coarse time counter.



7.28.4.4 DeadTime TDCSetup::GetDeadTime () const [inline]

Here is the call graph for this function:



7.28.4.5 uint8_t TDCSetup::GetDLLAdjustment (int tap) const [inline]

Set the adjustment of DLL taps.



$\textbf{7.28.4.6} \quad \textbf{EdgeResolution TDCSetup::GetEdgeResolution () const} \quad \texttt{[inline]}$

Here is the call graph for this function:



7.28.4.7 bool TDCSetup::GetEdgesPairing () const [inline]

Here is the call graph for this function:




7.28.4.8 uint16_t TDCSetup::GetEnableError () const [inline]



7.28.4.9 bool TDCSetup::GetEnableErrorBypass () const [inline]

Here is the call graph for this function:



7.28.4.10 bool TDCSetup::GetEnableErrorMark() const [inline]

Here is the call graph for this function:



7.28.4.11 bool TDCSetup::GetEnableJTAGReadout () const [inline]



7.28.4.12 bool TDCSetup::GetEnableReadoutOccupancy() const [inline]

Here is the call graph for this function:




7.28.4.13 bool TDCSetup::GetEnableReadoutSeparator() const [inline]

Here is the call graph for this function:



7.28.4.14 bool TDCSetup::GetEnableSerial () const [inline]

Here is the call graph for this function:



7.28.4.15 bool TDCSetup::GetLeadingMode() const [inline]


Extract the status for the detection of leading edges.



7.28.4.16 uint16_t TDCSetup::GetMatchWindow() const [inline]

Extract the matching window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

Here is the call graph for this function:



7.28.4.17 uint8_t TDCSetup::GetMaxEventSize() const [inline]


Extract the maximum number of hits per event.

Here is the call graph for this function:



7.28.4.18 uint8_t TDCSetup::GetRCAdjustment(int tap) [inline]

Extract the adjustment of the RC delay line.



7.28.4.19 int TDCSetup::GetReadoutFIFOSize () const [inline]

Here is the call graph for this function:



7.28.4.20 uint16_t TDCSetup::GetRejectCountOffset() const [inline]

Extract the offset in reject counter.

Here is the call graph for this function:



7.28.4.21 bool TDCSetup::GetRejectFIFOFull () const [inline]

Are hits rejected when readout FIFO is full?

Extract whether or not hits are rejected once FIFO is full.



7.28.4.22 uint16_t TDCSetup::GetSearchWindow() const [inline]

Extract the search window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

Here is the call graph for this function:



7.28.4.23 bool TDCSetup::GetSetupParity () const [inline]

Extract the parity of setup data (should be an even parity)



7.28.4.24 uint16_t TDCSetup::GetTDCld() const [inline]

Here is the call graph for this function:



7.28.4.25 bool TDCSetup::GetTestInvert () const [inline]

Here is the call graph for this function:



7.28.4.26 bool TDCSetup::GetTestMode () const [inline]

Here is the call graph for this function:



7.28.4.27 bool TDCSetup::GetTrailingMode() const [inline]

Extract the status for the detection of trailing edges.



7.28.4.28 uint16_t TDCSetup::GetTriggerCountOffset()const [inline]


Extract trigger time tag count offset.

Here is the call graph for this function:




7.28.4.29 uint16_t TDCSetup::GetTriggerLatency () const [inline]

Effective trigger latency in number of clock cycles (when no counter roll-over is used) Here is the call graph for this function:



7.28.4.30 bool TDCSetup::GetTriggerMatchingMode() const [inline]

Extract the enable status of trigger matching mode.



7.28.4.31 uint8_t TDCSetup::GetVernierOffset() const [inline]

Extract the offset in vernier decoding.

Here is the call graph for this function:



$\textbf{7.28.4.32} \quad \textbf{WidthResolution TDCSetup::} \textbf{GetWidthResolution () const} \quad \texttt{[inline]}$

Extract the pulse width resolution when paired measurements are performed.

Here is the call graph for this function:



7.28.4.33 void TDCSetup::SetAllChannelsOffset (uint16_t offset) [inline]

Set the time offset for all channels.



7.28.4.34 void TDCSetup::SetAllTapsDLLAdjustment (uint8_t adj) [inline]

Extract the adjustment of DLL taps.

Here is the call graph for this function:



7.28.4.35 void TDCSetup::SetBypassInputs (const bool sbi = true) [inline], [private]

Select serial in and token in from bypass inputs.

Here is the call graph for this function:



7.28.4.36 void TDCSetup::SetChannelOffset (int channel, uint16_t offset) [inline]

Set the time offset for one single channel.

Here is the call graph for this function:



7.28.4.37 void TDCSetup::SetCoarseCountOffset(uint16_t cco) [inline]

Set offset for the coarse time counter.



7.28.4.38 void TDCSetup::SetConstantValues() [virtual]

Ensure that the critical constant values are properly set in the setup word.

Implements TDCRegister.

7.28.4.39 void TDCSetup::SetCoreClockDelay (const bool delay_clock, const uint8_t delay) [inline], [private]

Delay of internal core clock.

Parameters


in	delay_clock	Use of direct clock (0) or delayed clock (1)
in	delay	Delay in steps of (typically) 0.13 ns

Here is the call graph for this function:



 $\textbf{7.28.4.40} \quad \textbf{void TDCSetup::SetCoreClockSource (const CoreClockSource \textit{ccs})} \quad \texttt{[inline], [private]}$

Selection of clock source for internal logic.



7.28.4.41 void TDCSetup::SetDeadTime (const DeadTime dt) [inline]

Channel dead time between hits.

Here is the call graph for this function:



7.28.4.42 void TDCSetup::SetDLLAdjustment (int tap, uint8_t adj) [inline]

Set the DLL taps adjustments with a resolution of \sim 10 ps.

Here is the call graph for this function:




7.28.4.43 void TDCSetup::SetDLLClockDelay (const bool delay_clock, const uint8_t delay) [inline], [private]

Delay of internal DLL clock.

Parameters


in	delay_clock	Use of direct clock (0) or delayed clock (1)
in	delay	Delay in steps of (typically) 0.13 ns

Here is the call graph for this function:



7.28.4.44 void TDCSetup::SetDLLClockSource (const DLLClockSource dcs) [inline], [private]

Selection of clock source for DLL.



7.28.4.45 void TDCSetup::SetDLLControl(const uint8_t dc) [inline], [private]

Control of DLL (DLL charge pump levels)

Here is the call graph for this function:



7.28.4.46 void TDCSetup::SetDLLMode(const DLLSpeedMode dsm) [inline], [private]

Selection of DLL speed mode.



7.28.4.47 void TDCSetup::SetEdgeResolution (const EdgeResolution r) [inline]

Here is the call graph for this function:



7.28.4.48 void TDCSetup::SetEdgesPairing (const bool pair = true) [inline]

Enable the pairing of leading and trailing edges (overrides individual enable of leading/trailing edges) Here is the call graph for this function:




7.28.4.49 void TDCSetup::SetEnableAutomaticReject (const bool ear = true) [inline], [private]

Enable of automatic rejection (should always be enabled if trigger matching mode!) Here is the call graph for this function:



7.28.4.50 void TDCSetup::SetEnableBytewise (const bool seb = true) [inline], [private]


Here is the call graph for this function:



7.28.4.51 void TDCSetup::SetEnableDirectBunchReset (const bool edbr = true) [inline], [private]

Enable of direct bunch reset input pin (1), otherwise taken from encoded control.

Here is the call graph for this function:



7.28.4.52 void TDCSetup::SetEnableDirectEventReset (const bool eder = true) [inline], [private]

Enable of direct event reset input pin (1), otherwise taken from encoded control.

Here is the call graph for this function:



7.28.4.53 void TDCSetup::SetEnableDirectTrigger(const bool edt = true) [inline], [private]

Enable of direct trigger input pin.



7.28.4.54 void TDCSetup::SetEnableError (const uint16_t & err) [inline]

Enable internal error types for generation of global error signals.


Here is the call graph for this function:



7.28.4.55 void TDCSetup::SetEnableErrorBypass (const bool *eb*) [inline]

Bypass TDC chip if global error signal is set.

Here is the call graph for this function:



7.28.4.56 void TDCSetup::SetEnableErrorMark (const bool em) [inline]

Mark events with error if global error signal is set.



7.28.4.57 void TDCSetup::SetEnableGlobalHeader(const bool egh = true) [inline], [private]

Enable of global headers in read-out (only valid for master TDC)


Here is the call graph for this function:



7.28.4.58 void TDCSetup::SetEnableGlobalTrailer (const bool egt = true) [inline], [private]

Enable of global trailers in read-out (only valid for master TDC)

Here is the call graph for this function:



7.28.4.59 void TDCSetup::SetEnableJTAGReadout (const bool jr) [inline]

Enable of read-out via JTAG.



7.28.4.60 void TDCSetup::SetEnableLocalHeader(const bool elh = true) [inline], [private]

Enable of local headers in read-out.

Here is the call graph for this function:



7.28.4.61 void TDCSetup::SetEnableLocalTrailer(const bool elt = true) [inline], [private]

Enable of local trailers in read-out.

Here is the call graph for this function:



7.28.4.62 void TDCSetup::SetEnableMasterResetCode (const bool emrc = true) [inline], [private]

Enable master reset code on encoded_control.



7.28.4.63 void TDCSetup::SetEnableMasterResetOnEventReset(const bool emroer = true) [inline], [private]

Enable master reset of whole TDC on event reset.

Here is the call graph for this function:



7.28.4.64 void TDCSetup::SetEnableOverflowDetect (const bool eod = true) [inline], [private]

Enable overflow detection of L1 buffers (should always be enabled!)

Here is the call graph for this function:



7.28.4.65 void TDCSetup::SetEnableReadoutOccupancy (const bool ro = true) [inline]


Enable the readout of buffer occupancies for each event (for debugging purposes)



7.28.4.66 void TDCSetup::SetEnableReadoutSeparator (const bool ro = true) [inline]

Enable the readout of separators for each event (for debugging purposes, valid if readout of occupancies is enabled)

Here is the call graph for this function:




7.28.4.67 void TDCSetup::SetEnableRelative (const bool er = true) [inline], [private]

Enable read-out of relative time to trigger time tag. Only valid when using trigger matching mode. Here is the call graph for this function:



7.28.4.68 void TDCSetup::SetEnableResetChannelBufferWhenSeparator (const bool *ercbws =* true) [inline], [private]

Enable reset channel buffers when separator.



7.28.4.69 void TDCSetup::SetEnableSeparatorOnBunchReset (const bool esobr = true) [inline], [private]

Enable generation of separator on bunch reset.

Here is the call graph for this function:



7.28.4.70 void TDCSetup::SetEnableSeparatorOnEventReset (const bool esoer = true) [inline], [private]

Enable generation of separator on event reset.

Here is the call graph for this function:



7.28.4.71 void TDCSetup::SetEnableSerial (const bool es) [inline]

Enable of serial read-out (otherwise parallel read-out)



7.28.4.72 void TDCSetup::SetEnableSetCountersOnBunchReset (const bool escobr = true) [inline], [private]

Enable all counters to be set on bunch count reset.

Here is the call graph for this function:



7.28.4.73 void TDCSetup::SetEnableTTLClock (const bool tc = true) [inline], [private]

Enable LV TTL inputs on: clk, aux_clock, otherwise uses LVDS input levels.

Here is the call graph for this function:



7.28.4.74 void TDCSetup::SetEnableTTLControl(const bool tc = true) [inline], [private]

Enable LV TTL inputs on control registers.

Enable LV TTL input on:

- · trigger,
- bunch_reset,
- event_reset,

· encoded_control, otherwise uses LVDS input levels.

Here is the call graph for this function:



7.28.4.75 void TDCSetup::SetEnableTTLHit (const bool th = true) [inline], [private]

Enable LV TTL input on hit[31:0], otherwise uses LVDS input levels.

Here is the call graph for this function:



7.28.4.76 void TDCSetup::SetEnableTTLReset (const bool tr = true) [inline], [private]

Enable LV TTL input on reset, otherwise uses LVDS input levels.

Here is the call graph for this function:




7.28.4.77 void TDCSetup::SetEnableTTLSerial (const bool ts = true) [inline], [private]

Enable LV TTL inputs on serial registers, and disable their drivers.

Enable LV TTL input on:

- · serial_in,
- · serial_bypass_in,

- · token_in,
- token_bypass_in, otherwise uses LVDS input levels. Disable LVDS drivers on:
- · serial_out,
- · strobe_out,
- token_out.



7.28.4.78 void TDCSetup::SetEventCountOffset (uint16_t eco) [inline]

Set offset for the event counter.

Here is the call graph for this function:



7.28.4.79 void TDCSetup::SetIOClockDelay (const bool delay_clock, const uint8_t delay) [inline], [private]

Delay of internal I/O clock.

Parameters

in	delay_clock	Use of direct clock (0) or delayed clock (1)
in	delay	Delay in steps of (typically) 0.13 ns



7.28.4.80 void TDCSetup::SetIOClockSource (const IOClockSource ics) [inline], [private]

Selection of clock source for I/O signals.

Here is the call graph for this function:



7.28.4.81 void TDCSetup::SetKeepToken (const bool kt = true) [inline], [private]

Keep token until end of event or no more data, otherwise pass token after each word read. Must be enabled when using trigger matching.


Here is the call graph for this function:



7.28.4.82 void TDCSetup::SetLeadingMode (const bool lead = true) [inline]

Enable the detection of leading edges.

Here is the call graph for this function:



7.28.4.83 void TDCSetup::SetLowPowerMode (const bool *lpm* = true) [inline], [private]

Low power mode of channel buffers.



7.28.4.84 void TDCSetup::SetMaster (const bool m = true) [inline], [private]

Here is the call graph for this function:



7.28.4.85 void TDCSetup::SetMatchWindow (uint16_t mw) [inline]

Set the matching window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

Here is the call graph for this function:



7.28.4.86 void TDCSetup::SetMaxEventSize (int sz = -1) [inline]

Set the maximum number of hits per event.

Set the maximum number of hits that can be recorded for each event. It is always rounded to the next power of 2 (in the range 0-128), and if lower than 0 or bigger than 128 then set to unimited.




7.28.4.87 void TDCSetup::SetModeRC (const bool mr = true) [inline], [private]

Enable of RR delay lines mode (in very high resolution mode); only for channels 0-4-8-12-16-20-24-28 active. Here is the call graph for this function:



7.28.4.88 void TDCSetup::SetModeRCCompression (const bool mrc = true) [inline], [private]

Perform RC interpolation on-chip (only valid in very high resolution mode) Here is the call graph for this function:



7.28.4.89 void TDCSetup::SetPLLControl (const uint8_t charge_pump_current = 0×4 , const bool power_down_mode = false, const bool enable_test_outputs = false, const bool invert_connection_to_status = false) [inline], [private]

Control of PLL.



7.28.4.90 void TDCSetup::SetRCAdjustment(int tap, uint8_t adj) [inline]

Set the adjustment of the RC delay line.

Here is the call graph for this function:



7.28.4.91 void TDCSetup::SetReadoutFIFOSize (int rfs) [inline]

Effective size of readout FIFO.

Here is the call graph for this function:



7.28.4.92 void TDCSetup::SetReadoutSingleCycleSpeed (const ReadoutSingleCycleSpeed rscs = RSC_40Mbits_s)
[inline], [private]

Serial transmission speed in single cycle mode.



7.28.4.93 void TDCSetup::SetReadoutSpeedSelect (const ReadoutSpeed rss = RO_Fixed) [inline], [private]

Selection of serial read-out speed.

Parameters

in	rss	
		 0: Selection of serial read-out speed (as defined by setup[19:17], Set — ReadoutSingleCycleSpeed)
		• 1: 80 Mbits/s (PLL lock required)

Here is the call graph for this function:



7.28.4.94 void TDCSetup::SetRejectCountOffset (uint16_t rco) [inline]

Set the offset in reject counter (defines reject latency together with coarse count offset) Here is the call graph for this function:



7.28.4.95 void TDCSetup::SetRejectFIFOFull (const bool rej = true) [inline]

Reject hits when readout FIFO full.

Set whether or not hits are rejected once FIFO is full.

Here is the call graph for this function:



7.28.4.96 void TDCSetup::SetRollOver(const uint16_t ro = 0xFFF) [inline], [private]

Counter roll over value, defining maximal count value from where counters will be reset to 0. Here is the call graph for this function:



7.28.4.97 void TDCSetup::SetSearchWindow (uint16_t sw) [inline]

Set the search window (in multiples of clock cycles: 0=25 ns, 1=50 ns, ...)

Here is the call graph for this function:




7.28.4.98 void TDCSetup::SetSerialClockDelay (const bool delay_clock, const uint8_t delay) [inline], [private]

Delay of internal serial clock.

Parameters

in	delay_clock	Use of direct clock (0) or delayed clock (1)
in	delay	Delay in steps of (typically) 0.13 ns


Here is the call graph for this function:



7.28.4.99 void TDCSetup::SetSerialClockSource (const SerialClockSource scs) [inline], [private]

Selection of source for serial clock.


Here is the call graph for this function:



7.28.4.100 void TDCSetup::SetSerialDelay (const uint8_t sd = 0x0) [inline], [private]

Programmable delay of serial input, in time unit \sim 1 ns.

Here is the call graph for this function:



7.28.4.101 void TDCSetup::SetSetupParity (const bool sp = true) [inline]

Set the parity of setup data (should be an even parity)



7.28.4.102 void TDCSetup::SetStrobeSelect (const SerialStrobeType *ss* = **SS_NoStrobe)** [inline], [private]

Here is the call graph for this function:



7.28.4.103 void TDCSetup::SetTDCld (const uint8_t $id = 0 \times 0$) [inline]



7.28.4.104 void TDCSetup::SetTest (const bool test = true) [inline], [private]

Here is the call graph for this function:




7.28.4.105 void TDCSetup::SetTestInvert (const bool ti = true) [inline]

Automatic inversion of test pattern. Only used during production testing. Here is the call graph for this function:



7.28.4.106 void TDCSetup::SetTestMode (const bool tm = true) [inline]

Test mode where hit data are taken from coretest. Only used during production testing. Here is the call graph for this function:



7.28.4.107 void TDCSetup::SetTokenDelay (const uint8_t td = 0x0) [inline], [private]

Programmable delay of token input, in time unit \sim 1 ns.

Here is the call graph for this function:



7.28.4.108 void TDCSetup::SetTrailingMode (const bool trail = true) [inline]

Enable/disable the detection of trailing edges.


Here is the call graph for this function:



7.28.4.109 void TDCSetup::SetTriggerCountOffset (uint16_t tco) [inline]

Set offset for the trigger time tag counter to set effective trigger latency.

Here is the call graph for this function:



7.28.4.110 void TDCSetup::SetTriggerMatchingMode (const bool trig = true) [inline]

Set the enable status of trigger matching mode.

Here is the call graph for this function:



7.28.4.111 void TDCSetup::SetVernierOffset (const uint8_t vo) [inline]

Set the offset in vernier decoding.

Here is the call graph for this function:



7.28.4.112 void TDCSetup::SetWidthResolution (const WidthResolution r) [inline]

Set the pulse width resolution when paired measurements are performed.

Here is the call graph for this function:



7.28.5 Field Documentation

7.28.5.1 const bit TDCSetup::kCoarseCountOffset = 447 [static], [private]

7.28.5.2 const bit TDCSetup::kCoreClockDelay = 610 [static], [private]

7.28.5.3 const bit TDCSetup::kCoreClockSource = 622 [static], [private]

7.28.5.4 const bit TDCSetup::kDeadTime = 584 [static], [private]

7.28.5.5 const bit TDCSetup::kDLLClockDelay = 614 [static], [private]

```
7.28.5.6 const bit TDCSetup::kDLLClockSource = 624 [static], [private]
7.28.5.7 const bit TDCSetup::kDLLControl = 580 [static], [private]
7.28.5.8 const bit TDCSetup::kDLLMode = 592 [static], [private]
7.28.5.9 const bit TDCSetup::kDLLTapAdjust0 = 459 [static], [private]
7.28.5.10 const bit TDCSetup::kEnableAutomaticReject = 125 [static], [private]
7.28.5.11 const bit TDCSetup::kEnableBytewise = 37 [static], [private]
7.28.5.12 const bit TDCSetup::kEnableDirectBunchReset = 157 [static], [private]
7.28.5.13 const bit TDCSetup::kEnableDirectEventReset = 156 [static], [private]
7.28.5.14 const bit TDCSetup::kEnableDirectTrigger = 158 [static], [private]
7.28.5.15 const bit TDCSetup::kEnableError = 6 [static], [private]
7.28.5.16 const bit TDCSetup::kEnableErrorBypass = 5 [static], [private]
7.28.5.17 const bit TDCSetup::kEnableErrorMark = 4 [static], [private]
7.28.5.18 const bit TDCSetup::kEnableGlobalHeader = 34 [static], [private]
7.28.5.19 const bit TDCSetup::kEnableGlobalTrailer = 33 [static], [private]
7.28.5.20 const bit TDCSetup::kEnableJTAGReadout = 39 [static], [private]
7.28.5.21 const bit TDCSetup::kEnableLocalHeader = 32 [static], [private]
7.28.5.22 const bit TDCSetup::kEnableLocalTrailer = 31 [static], [private]
7.28.5.23 const bit TDCSetup::kEnableMasterResetCode = 151 [static], [private]
7.28.5.24 const bit TDCSetup::kEnableMasterResetOnEventReset = 152 [static], [private]
7.28.5.25 const bit TDCSetup::kEnableMatching = 639 [static], [private]
7.28.5.26 const bit TDCSetup::kEnableOverflowDetect = 123 [static], [private]
7.28.5.27 const bit TDCSetup::kEnablePair = 640 [static], [private]
7.28.5.28 const bit TDCSetup::kEnableReadoutOccupancy = 121 [static], [private]
7.28.5.29 const bit TDCSetup::kEnableReadoutSeparator = 122 [static], [private]
7.28.5.30 const bit TDCSetup::kEnableRelative = 124 [static], [private]
7.28.5.31 const bit TDCSetup::kEnableResetChannelBufferWhenSeparator = 153 [static], [private]
7.28.5.32 const bit TDCSetup::kEnableSeparatorOnBunchReset = 155 [static], [private]
7.28.5.33 const bit TDCSetup::kEnableSeparatorOnEventReset = 154 [static], [private]
```

```
7.28.5.34 const bit TDCSetup::kEnableSerial = 38 [static], [private]
7.28.5.35 const bit TDCSetup::kEnableSetCountersOnBunchReset = 150 [static], [private]
7.28.5.36 const bit TDCSetup::kEnableTTLClock = 644 [static], [private]
7.28.5.37 const bit TDCSetup::kEnableTTLControl = 642 [static], [private]
7.28.5.38 const bit TDCSetup::kEnableTTLHit = 645 [static], [private]
7.28.5.39 const bit TDCSetup::kEnableTTLReset = 643 [static], [private]
7.28.5.40 const bit TDCSetup::kEnableTTLSerial = 641 [static], [private]
7.28.5.41 const bit TDCSetup::kEventCountOffset = 126 [static], [private]
7.28.5.42 const bit TDCSetup::klOClockDelay = 606 [static], [private]
7.28.5.43 const bit TDCSetup::klOClockSource = 620 [static], [private]
7.28.5.44 const bit TDCSetup::kKeepToken = 35 [static], [private]
7.28.5.45 const bit TDCSetup::kLeading = 589 [static], [private]
7.28.5.46 const bit TDCSetup::kLeadingResolution = 84 [static], [private]
7.28.5.47 const bit TDCSetup::kLowPowerMode = 570 [static], [private]
7.28.5.48 const bit TDCSetup::kMaster = 36 [static], [private]
7.28.5.49 const bit TDCSetup::kMatchWindow = 72 [static], [private]
7.28.5.50 const bit TDCSetup::kMaxEventSize = 116 [static], [private]
7.28.5.51 const bit TDCSetup::kModeRC = 591 [static], [private]
7.28.5.52 const bit TDCSetup::kModeRCCompression = 590 [static], [private]
7.28.5.53 const bit TDCSetup::kOffset0 = 438 [static], [private]
7.28.5.54 const bit TDCSetup::kPLLControl = 594 [static], [private]
7.28.5.55 const bit TDCSetup::kRCAdjust0 = 555 [static], [private]
7.28.5.56 const bit TDCSetup::kReadoutFIFOSize = 45 [static], [private]
7.28.5.57 const bit TDCSetup::kReadoutSingleCycleSpeed = 17 [static], [private]
7.28.5.58 const bit TDCSetup::kReadoutSpeedSelect = 26 [static], [private]
7.28.5.59 const bit TDCSetup::kRejectCountOffset = 48 [static], [private]
7.28.5.60 const bit TDCSetup::kRejectFlFOFull = 120 [static], [private]
7.28.5.61 const bit TDCSetup::kRollOver = 627 [static], [private]
```

```
7.28.5.62 const bit TDCSetup::kSearchWindow = 60 [static], [private]
7.28.5.63 const bit TDCSetup::kSelectBypassInputs = 44 [static], [private]
7.28.5.64 const bit TDCSetup::kSerialClockDelay = 602 [static], [private]
7.28.5.65 const bit TDCSetup::kSerialClockSource = 618 [static], [private]
7.28.5.66 const bit TDCSetup::kSerialDelay = 20 [static], [private]
7.28.5.67 const bit TDCSetup::kSetupParity = 646 [static], [private]
7.28.5.68 const bit TDCSetup::kStrobeSelect = 24 [static], [private]
7.28.5.69 const bit TDCSetup::kTDCld = 40 [static], [private]
7.28.5.70 const bit TDCSetup::kTestInvert = 586 [static], [private]
7.28.5.71 const bit TDCSetup::kTestMode = 587 [static], [private]
7.28.5.72 const bit TDCSetup::kTestSelect = 0 [static], [private]
7.28.5.73 const bit TDCSetup::kTokenDelay = 27 [static], [private]
7.28.5.74 const bit TDCSetup::kTrailing = 588 [static], [private]
7.28.5.75 const bit TDCSetup::kTriggerCountOffset = 138 [static], [private]
7.28.5.76 const bit TDCSetup::kVernierOffset = 575 [static], [private]
7.28.5.77 const bit TDCSetup::kWidthSelect = 571 [static], [private]
```


The documentation for this class was generated from the following files:

- · daq/include/TDCSetup.h
- daq/src/TDCSetup.cpp


7.29 TDCStatus Class Reference

#include <TDCStatus.h>

Inheritance diagram for TDCStatus:



Collaboration diagram for TDCStatus:



Public Member Functions

- TDCStatus ()
- TDCStatus (const TDCStatus &s)
- TDCStatus (const std::vector< uint8 t > &words)
- void SetConstantValues ()
- uint16_t Error () const
- bool HaveToken () const
- uint8_t FIFOOccupancy () const
- bool FIFOFull () const
- bool FIFOEmpty () const
- uint32_t L1Occupancy () const
- uint8_t TriggerFIFOOccupancy () const
- bool TriggerFIFOFull () const
- bool TriggerFIFOEmpty () const
- bool DLLLock () const
- void Dump (int verb=1, std::ostream &os=std::cout) const

Static Private Attributes

• static const bit kError = 0

- static const bit kHaveToken = 11
- static const bit kReadoutFIFOOccupancy = 12
- static const bit kReadoutFIFOFull = 20
- static const bit kReadoutFIFOEmpty = 21
- static const bit kL1Occupancy = 22
- static const bit kTriggerFIFOOccupancy = 54
- static const bit kTriggerFIFOFull = 58
- static const bit kTriggerFIFOEmpty = 59
- static const bit kDLLLock = 60

Additional Inherited Members

7.29.1 Detailed Description

Author

Laurent Forthomme laurent.forthomme@cern.ch


Date

27 Apr 2015

7.29.2 Constructor & Destructor Documentation

7.29.2.1 TDCStatus::TDCStatus() [inline]

Here is the call graph for this function:



7.29.2.2 TDCStatus::TDCStatus (const TDCStatus & s) [inline]

Here is the call graph for this function:



7.29.2.3 TDCStatus::TDCStatus (const std::vector < uint8_t > & words) [inline]

7.29.3 Member Function Documentation


7.29.3.1 bool TDCStatus::DLLLock() const [inline]

Here is the call graph for this function:




7.29.3.2 void TDCStatus::Dump (int verb = 1, std::ostream & os = std::cout) const [inline]

Here is the call graph for this function:



7.29.3.3 uint16_t TDCStatus::Error() const [inline]

Here is the call graph for this function:



7.29.3.4 bool TDCStatus::FIFOEmpty () const [inline]

Here is the call graph for this function:



7.29.3.5 bool TDCStatus::FIFOFull () const [inline]

Here is the call graph for this function:



7.29.3.6 uint8_t TDCStatus::FIFOOccupancy() const [inline]

Here is the call graph for this function:



7.29.3.7 bool TDCStatus::HaveToken () const [inline]

Here is the call graph for this function:



7.29.3.8 uint32_t TDCStatus::L1Occupancy () const [inline]

Here is the call graph for this function:



7.29.3.9 void TDCStatus::SetConstantValues() [inline], [virtual]

Ensure that the critical constant values are properly set in the register word Implements TDCRegister.

7.29.3.10 bool TDCStatus::TriggerFIFOEmpty() const [inline]

Here is the call graph for this function:



7.29.3.11 bool TDCStatus::TriggerFIFOFull () const [inline]

Here is the call graph for this function:



7.29.3.12 uint8_t TDCStatus::TriggerFIFOOccupancy() const [inline]

Here is the call graph for this function:



7.29.4 Field Documentation

7.29.4.1 const bit TDCStatus::kDLLLock = 60 [static], [private]

7.29.4.2 const bit TDCStatus::kError = 0 [static], [private]

7.29.4.3 const bit TDCStatus::kHaveToken = 11 [static], [private]

7.29.4.4 const bit TDCStatus::kL1Occupancy = 22 [static], [private]

7.29.4.5 const bit TDCStatus::kReadoutFIFOEmpty = 21 [static], [private]

```
7.29.4.6 const bit TDCStatus::kReadoutFIFOFull = 20 [static], [private]
7.29.4.7 const bit TDCStatus::kReadoutFIFOOccupancy = 12 [static], [private]
7.29.4.8 const bit TDCStatus::kTriggerFIFOEmpty = 59 [static], [private]
7.29.4.9 const bit TDCStatus::kTriggerFIFOFull = 58 [static], [private]
7.29.4.10 const bit TDCStatus::kTriggerFIFOOccupancy = 54 [static], [private]
```

The documentation for this class was generated from the following file:

· daq/include/TDCStatus.h

7.30 DAQ::QuickUSBHandler::Version Struct Reference

```
#include <QuickUSBHandler.h>
```

Data Fields

- QWORD MajorVersion
- QWORD MinorVersion
- QWORD BuildVersion

7.30.1 Field Documentation

- 7.30.1.1 QWORD DAQ::QuickUSBHandler::Version::BuildVersion
- 7.30.1.2 QWORD DAQ::QuickUSBHandler::Version::MajorVersion
- 7.30.1.3 QWORD DAQ::QuickUSBHandler::Version::MinorVersion

The documentation for this struct was generated from the following file:

• daq/include/QuickUSBHandler.h

Index

\sim Client	Client, 18
Client, 17	
\sim DQMProcess	Bind
DQM::DQMProcess, 24	Socket, 68
\sim FPGAHandler	bit
DAQ::FPGAHandler, 32	TDCRegister, 107
~FileReader	Broadcast
FileReader, 29	Messenger, 47
~GastofCanvas	Build
DQM::GastofCanvas, 38	DQM::GastofCanvas, 39
~Logger	DQM::PPSCanvas, 57
Logger, 41	DQM::QuarticCanvas, 61
~Message	BuildTables
Message, 43	OnlineDBHandler, 53
~Messenger	BuildVersion
Messenger, 46	DAQ::QuickUSBHandler::Version, 168
~OnlineDBHandler	burst id
OnlineDBHandler, 53	OnlineDBHandler::BurstInfo, 15
~PPSCanvas	BurstInfos
	OnlineDBHandler, 53
DQM::PPSCanvas, 56 ~QuarticCanvas	Chime Beriandici, 30
	c1
DQM::QuarticCanvas, 60	DQM::GastofCanvas, 39
~QuickUSBHandler	DQM::PPSCanvas, 57
DAQ::QuickUSBHandler, 64	DQM::QuarticCanvas, 61
~Socket	c2
Socket, 67	DQM::GastofCanvas, 40
~SocketMessage	
SocketMessage, 77	DQM::PPSCanvas, 57
~TDC	DQM::QuarticCanvas, 62
DAQ::TDC, 81	CLIENT
~TDCErrorFlag	Socket, 67
TDCErrorFlag, 95	CONT_STORAGE
~TDCEvent	HPTDC chip control, 11
TDCEvent, 97	ChannelSelectError
~TDCMeasurement	TDCSetup, 117
TDCMeasurement, 103	CheckFirmwareVersion
\sim TDCRegister	DAQ::TDC, 82
TDCRegister, 107	Clear
	FileReader, 29
AcceptConnections	TDCRegister, 108
Socket, 68	Client, 15
acq_mode	\sim Client, 17
file_header_t, 27	Announce, 18
AcquisitionMode	Client, 17
HPTDC chip control, 11	Connect, 18
Action	Disconnect, 19
DQM::DQMProcess, 24	fClientId, 21
AddClient	flsConnected, 21
Messenger, 47	fType, 21
Announce	GetType, 19

ParseMessage, 19	flsStopping, 65
Receive, 19, 20	fStreamId, 65
Send, 20	Fetch, 64
SendAndReceive, 21	GetDLLVersion, 64
CloseFile	GetDriverVersion, 64
DAQ::FPGAHandler, 33	GetFWVersion, 64
CoarseError	Init, 64
TDCSetup, 117	QuickUSBHandler, 64
Configure	Reset, 64
Socket, 68	
Connect	StartBulkTransfer, 65
	StopBulkTransfer, 65
Client, 18	Write, 65
Messenger, 47	DAQ::QuickUSBHandler::Version, 168
contents	BuildVersion, 168
LogRedirector, 42	MajorVersion, 168
ControlParityError	MinorVersion, 168
TDCSetup, 118	DAQ::TDC, 80
Core_aux_clock	\sim TDC, 81
TDCSetup, 116	CheckFirmwareVersion, 82
Core_clock_40	DetectionMode, 81
TDCSetup, 116	fBS, 82
Core_pll_clock_160	fControl, 82
TDCSetup, 116	
Core_pll_clock_80	fld, 82
TDCSetup, 116	fSetup, 82
CoreClockSource	fStatus, 82
TDCSetup, 116	fUSB, 82
Create	FetchEvents, 82
	GetSetupRegister, 82
Socket, 68	OLEADING, 81
DAQ, 13	OTRAILING, 81
Socket, 67	PAIR, 81
DAQ::FPGAHandler, 30	ReadConfiguration, 82
~FPGAHandler, 32	ReadRegister, 82
· · · · · · · · · · · · · · · · · · ·	ReadStatus, 82
CloseFile, 33	SendConfiguration, 82
ErrorState, 33	SetSetupRegister, 82
fFilename, 36	SoftReset, 82
flsFileOpen, 36	TDC, 81
flsTDCInReadout, 36	TRAILEAD, 81
fOutput, 36	•
FPGAHandler, 32	WriteRegister, 82
fTDC, 36	DETECTOR
GetFilename, 33	Socket, 67
GetTDC, 33	DLL_160MHz
GetTDCControl, 33	TDCSetup, 117
GetTDCStatus, 33	DLL_320MHz
GetType, 33	TDCSetup, 117
OpenFile, 33	DLL_40MHz
RegisterTest, 34	TDCSetup, 117
RetrieveSetupWord, 34	DLL_Illegal
SendSetupWord, 34	TDCSetup, 117
SetTDCSetup, 35	DLL_aux_clock
StartAcquisition, 35	TDCSetup, 117
Stop, 35	DLL_clock_40
•	TDCSetup, 117
StopAcquisition, 35	•
DAQ::QuickUSBHandler, 62	DLL_pll_clock_160
~QuickUSBHandler, 64	TDCSetup, 117
fDevice, 65	DLL_pll_clock_320
fHandle, 65	TDCSetup, 117

DLL_pll_clock_40	\sim PPSCanvas, 56
TDCSetup, 117	Build, 57
DLLClockSource	c1, 57
TDCSetup, 117	c2, 57
DLLLock	DrawGrid, 57
TDCStatus, 164	fHeight, 57
DLLSpeedMode	fLabel1, 57
TDCSetup, 117	fLabel2, 57
DQM, 13	fLabel3, 57
Socket, 67	fLabelsDrawn, 57
DQM::DQMProcess, 22	fLegend, 58
\sim DQMProcess, 24	fLegendNumEntries, 58
Action, 24	fLegendX, 58
DQMProcess, 24	fLegendY, 58
fAddressesCanProcess, 26	fRunDate, 58
fDetectorType, 26	fRunId, 58
fOrder, 26	fUpperLabel, 58
fRunNumber, 26	fUpperLabelText, 58
IsInRun, 24	fWidth, 58
NewPlot, 24 ParseMessage, 25	Grid, 57 PPSCanvas, 56
Run, 25	Save, 57
UpdatedPlot, 24	SetRunInfo, 57
DQM::GastofCanvas, 36	SetUpperLabel, 57
~GastofCanvas, 38	DQM::QuarticCanvas, 58
Build, 39	~QuarticCanvas, 60
c1, 39	Build, 61
c2, 40	c1, 61
DrawGrid, 39	c2, 62
fBoardId, 40	DrawGrid, 61
fHeight, 40	fBoardId, 62
fHist, 40	fHeight, 62
fLabel1, 40	fHist, 62
fLabel2, 40	fLabel1, 62
fLabel3, 40	fLabel2, 62
fLabel4, 40	fLabel3, 62
fLabelsDrawn, 40	fLabel4, 62
fLegend, 40	fLabelsDrawn, 62
fLegendNumEntries, 40	fLegend, 62
fLegendX, 40	fLegendNumEntries, 62
fLegendY, 40	fLegendX, 62
fRunDate, 40	fLegendY, 62
fRunld, 40	fRunDate, 62
fSpillId, 40	fRunld, 62
fUpperLabel, 40	fSpillId, 62
fUpperLabelText, 40	fUpperLabel, 62
fWidth, 40	fUpperLabelText, 62
FillChannel, 39	fWidth, 62
GastofCanvas, 38	FillChannel, 61
GetCoordinates, 39 Grid, 39	GetCoordinates, 61 Grid, 61
Save, 39	QuarticCanvas, 60
SetRunInfo, 39	Save, 61
SetUpperLabel, 39	SetRunInfo, 61
DQM::GastofCanvas::Coord, 21	SetUpperLabel, 61
x, 21	DQM::QuarticCanvas::Coord, 22
y, 22	x, 22
DQM::PPSCanvas, 55	y, 22

DQMProcess	TDCSetup, 117
DQM::DQMProcess, 24	E_800ps
DT_100ns	TDCSetup, 117
TDCSetup, 117	ETTT
DT_10ns	TDCEvent, 97
TDCSetup, 117	EdgeResolution
DT_30ns	TDCSetup, 117
TDCSetup, 117	EnableAllChannels
DT_5ns	TDCControl, 90
TDCSetup, 117	EnableChannel
DeadTime	TDCControl, 90
TDCSetup, 116	EnablePattern
det mode	TDCControl, 88
file_header_t, 27	EnabledError
DetectionMode	TDCSetup, 117
DAQ::TDC, 81	Error
detector	TDCStatus, 164
OnlineDBHandler::TDCConditions, 86	ErrorState
DisableAllChannels	DAQ::FPGAHandler, 33
TDCControl, 89	EventType
DisableChannel	TDCEvent, 97
TDCControl, 89	. = 0 = 10.11, 0.1
Disconnect	fAddress
Client, 19	Socket, 71
Messenger, 48	fAddressesCanProcess
DisconnectClient	DQM::DQMProcess, 26
Messenger, 48	fBS
DrawGrid	DAQ::TDC, 82
DQM::GastofCanvas, 39	fBoardId
	DQM::GastofCanvas, 40
DQM::PPSCanvas, 57	DQM::QuarticCanvas, 62
DQM::QuarticCanvas, 61	fBuffer
Dump File Reader, 20	Logger, 41
FileReader, 29	Socket, 71
Message, 44	fClientId
SocketMessage, 77	Client, 21
TDCControl, 89	fControl
TDCErrorFlag, 95	DAQ::TDC, 82
TDCEvent, 97	fDB
TDCMeasurement, 103	OnlineDBHandler, 54
TDCSetup, 121	fDetectorType
TDCStatus, 164	DQM::DQMProcess, 26
DumpConnected	fDevice
Socket, 68	DAQ::QuickUSBHandler, 65
DumpRegister	fEvents
TDCRegister, 108	TDCMeasurement, 105
E_100ps	fFile
	FileReader, 30
TDCSetup, 117 E_12p5ns	fFilename
TDCSetup, 117	DAQ::FPGAHandler, 36
E_1p6ns	fHandle
_ ·	
TDCSetup, 117	DAQ::QuickUSBHandler, 65
E_200ps	fHeader
TDCSetup, 117	FileReader, 30
E_3p12ns	fHeight
TDCSetup, 117	DQM::GastofCanvas, 40
E_400ps	DQM::PPSCanvas, 57
TDCSetup, 117	DQM::QuarticCanvas, 62
E_6p25ns	fHist

DQM::GastofCanvas, 40	SocketMessage, 79
DQM::QuarticCanvas, 62	fNumAttempts
FIFOEmpty	Messenger, 51
TDCStatus, 165	fNumEvents
FIFOFull	FileReader, 30
TDCStatus, 165	fNumWords
FIFOOccupancy	TDCRegister, 109
TDCStatus, 165	fOrder
fld	DQM::DQMProcess, 26
DAQ::TDC, 82	
	fOutput
flsConnected	DAQ::FPGAHandler, 36
Client, 21	FPGA board control, 10
flsFileOpen	FPGAHandler
DAQ::FPGAHandler, 36	DAQ::FPGAHandler, 32
flsStopping	fPID
DAQ::QuickUSBHandler, 65	Messenger, 51
flsTDCInReadout	fPort
DAQ::FPGAHandler, 36	Socket, 71
fLabel1	fReadFds
DQM::GastofCanvas, 40	Socket, 71
DQM::PPSCanvas, 57	fReadoutMode
DQM::QuarticCanvas, 62	FileReader, 30
fLabel2	fRedirect
DQM::GastofCanvas, 40	LogRedirector, 42
	fRunDate
DQM::PPSCanvas, 57	
DQM::QuarticCanvas, 62	DQM::GastofCanvas, 40
fLabel3	DQM::PPSCanvas, 58
DQM::GastofCanvas, 40	DQM::QuarticCanvas, 62
DQM::PPSCanvas, 57	fRunId
DQM::QuarticCanvas, 62	DQM::GastofCanvas, 40
fLabel4	DQM::PPSCanvas, 58
DQM::GastofCanvas, 40	DQM::QuarticCanvas, 62
DQM::QuarticCanvas, 62	fRunNumber
fLabelsDrawn	DQM::DQMProcess, 26
DQM::GastofCanvas, 40	fSS
DQM::PPSCanvas, 57	LogRedirector, 42
DQM::QuarticCanvas, 62	fSetup
fLegend	DAQ::TDC, 82
DQM::GastofCanvas, 40	fSocketId
DQM::PPSCanvas, 58	Socket, 71
	fSocketsConnected
DQM::QuarticCanvas, 62	
fLegendNumEntries	Socket, 71
DQM::GastofCanvas, 40	fSpillId
DQM::PPSCanvas, 58	DQM::GastofCanvas, 40
DQM::QuarticCanvas, 62	DQM::QuarticCanvas, 62
fLegendX	fStatus
DQM::GastofCanvas, 40	DAQ::TDC, 82
DQM::PPSCanvas, 58	fStderrPipe
DQM::QuarticCanvas, 62	Messenger, 51
fLegendY	fStdoutPipe
DQM::GastofCanvas, 40	Messenger, 51
DQM::PPSCanvas, 58	fStream
DQM::QuarticCanvas, 62	Logger, 41
fMap	fStreamId
TDCMeasurement, 105	DAQ::QuickUSBHandler, 65
fMaster	fString
	_
Socket, 71	Message, 44
fMessage	fTDC

DAQ::FPGAHandler, 36	FillChannel
fType	DQM::GastofCanvas, 39
Client, 21	DQM::QuarticCanvas, 61
fUSB	Filler
DAQ::TDC, 82	TDCEvent, 97
fUpperLabel	0
DQM::GastofCanvas, 40	GastofCanvas
DQM::PPSCanvas, 58	DQM::GastofCanvas, 38
DQM::QuarticCanvas, 62	GetAcquisitionMode
fUpperLabelText	FileReader, 29
DQM::GastofCanvas, 40	GetBits
DQM::PPSCanvas, 58	TDCRegister, 108
DQM::QuarticCanvas, 62	GetBunchld
fWidth	TDCEvent, 98
DQM::GastofCanvas, 40	TDCMeasurement, 104
DQM::PPSCanvas, 58	GetBurstld
DQM::QuarticCanvas, 62	FileReader, 29
fWord	GetChannelld
TDCErrorFlag, 95	TDCEvent, 98
TDCEvent, 102	TDCMeasurement, 104
•	GetChannelOffset
TDCRegister, 109 fWordSize	TDCSetup, 122
	GetCleanedValue
TDCRegister, 109	SocketMessage, 77
fWriteTime	GetCoarseCountOffset
FileReader, 30	TDCSetup, 122
Fetch	GetCoordinates
DAQ::QuickUSBHandler, 64	DQM::GastofCanvas, 39
FetchEvents	DQM::QuarticCanvas, 61
DAQ::TDC, 82	GetDLLAdjustment
FetchMessage	TDCSetup, 123
Socket, 69	GetDLLReset
file_header_t, 26	TDCControl, 90
acq_mode, 27	GetDLLVersion
det_mode, 27	DAQ::QuickUSBHandler, 64
magic, 27	GetDeadTime
num_hptdc, 27	TDCSetup, 123
run_id, 27	GetDetectionMode
spill_id, 27	FileReader, 29
FileReader, 27	GetDriverVersion
\sim FileReader, 29	DAQ::QuickUSBHandler, 64
Clear, 29	GetETTT
Dump, 29	TDCEvent, 99
fFile, 30	TDCMeasurement, 104
fHeader, 30	GetEdgeResolution
fNumEvents, 30	TDCSetup, 123
fReadoutMode, 30	GetEdgesPairing
fWriteTime, 30	TDCSetup, 124
FileReader, 28	GetEnableError
GetAcquisitionMode, 29	TDCSetup, 124
GetBurstId, 29	GetEnableErrorBypass
GetDetectionMode, 29	TDCSetup, 124
GetNextEvent, 29	GetEnableErrorMark
GetNextMeasurement, 29	TDCSetup, 125
GetNumEvents, 30	GetEnableJTAGReadout
GetNumTDCs, 30	TDCSetup, 125
GetRunld, 30	GetEnablePattern
IsOpen, 30	TDCControl, 91
Open, 30	GetEnableReadoutOccupancy
	GOLE Habiot to adout Coouparioy

TDCSature 125	TDCSature 120
TDCSetup, 125 GetEnableReadoutSeparator	TDCSetup, 128 GetRunId
TDCSetup, 126	FileReader, 30
GetEnableSerial	GetRunInfo
TDCSetup, 126	OnlineDBHandler, 53
GetErrorFlags	GetRuns
TDCEvent, 98	OnlineDBHandler, 53
GetEventCount	GetSearchWindow
TDCEvent, 99	TDCSetup, 129
GetEventId	GetSetupParity
TDCEvent, 99	TDCSetup, 129
TDCMeasurement, 104	GetSetupRegister
GetFWVersion	DAQ::TDC, 82
DAQ::QuickUSBHandler, 64	GetSocketId
GetFilename	Socket, 69
DAQ::FPGAHandler, 33	GetSocketType
GetGeo	Socket, 69
TDCEvent, 100	GetStatus
GetGlobalReset	TDCEvent, 100
TDCControl, 91	GetString
GetIntValue	Message, 44
SocketMessage, 77	SocketMessage, 77
GetKey	GetTDC
Message, 44	DAQ::FPGAHandler, 33
SocketMessage, 77	GetTDCConditions
GetLastBurst	OnlineDBHandler, 53
OnlineDBHandler, 53	GetTDCControl
GetLastRun	DAQ::FPGAHandler, 33
OnlineDBHandler, 53	GetTDCld
GetLeadingMode	TDCEvent, 100
TDCSetup, 126	TDCMeasurement, 104
GetLeadingTime	TDCSetup, 129
TDCMeasurement, 104	GetTDCStatus
GetMatchWindow	DAQ::FPGAHandler, 33
TDCSetup, 127	GetTestInvert
GetMaxEventSize	TDCSetup, 130
TDCSetup, 127	GetTestMode
GetNextEvent	TDCSetup, 130
FileReader, 29	GetTime
GetNextMeasurement	TDCEvent, 101
FileReader, 29	GetToT
GetNumEvents	TDCMeasurement, 104
FileReader, 30	GetTrailingMode
GetNumTDCs	TDCSetup, 130
FileReader, 30	GetTrailingTime
GetNumWords	TDCMeasurement, 105
TDCRegister, 108	GetTriggerCountOffset
GetPLLReset	TDCSetup, 131
TDCControl, 91	GetTriggerLatency
GetPort	TDCSetup, 131
Socket, 69	GetTriggerMatchingMode
GetRCAdjustment	TDCSetup, 131
TDCSetup, 127	GetType
GetReadoutFIFOSize	Client, 19
TDCSetup, 128	DAQ::FPGAHandler, 33
GetRejectCountOffset	Messenger, 49
TDCSetup, 128 GetRejectFIFOFull	TDCEvent, 101 GetValue
Gott to jour in O1 uii	GGI Value

SocketMessage, 77	IsFromWeb
GetVectorValue	Message, 44
SocketMessage, 78	IsInRun
GetVernierOffset	DQM::DQMProcess, 24
TDCSetup, 132	IsOpen
GetWidth	FileReader, 30
TDCEvent, 101	IsTrailing
GetWidthResolution	TDCEvent, 102
TDCSetup, 132	IsWebSocket
GetWord	Socket, 69
TDCErrorFlag, 95	Cooker, Co
TDCEvent, 101	JTAGInstructionParityError
TDCRegister, 108	TDCSetup, 118
GetWordCount	120001445, 110
	kAuxClock
TDCEvent, 102	TDCBoundaryScan, 85
GetWords	kBunchReset
TDCRegister, 108	TDCBoundaryScan, 85
GlobalHeader	kClk
TDCEvent, 97	TDCBoundaryScan, 85
GlobalTrailer	kCoarseCountOffset
TDCEvent, 97	
Grid	TDCSetup, 158
DQM::GastofCanvas, 39	kControlParity
DQM::PPSCanvas, 57	TDCControl, 93
DQM::QuarticCanvas, 61	kCoreClockDelay
	TDCSetup, 158
HPTDC chip control, 11	kCoreClockSource
AcquisitionMode, 11	TDCSetup, 158
CONT_STORAGE, 11	kDLLClockDelay
TRIG MATCH, 11	TDCSetup, 158
HasGroupError	kDLLClockSource
TDCErrorFlag, 95	TDCSetup, 158
HasInternalChipError	kDLLControl
TDCErrorFlag, 95	TDCSetup, 159
HasL1BufferOverflow	kDLLLock
	TDCStatus, 167
TDCErrorFlag, 95	kDLLMode
HasReachedEventSizeLimit	TDCSetup, 159
TDCErrorFlag, 95	kDLLReset
HasReadoutFIFOOverflow	TDCControl, 93
TDCErrorFlag, 95	•
HasTriggerFIFOOverflow	kDLLTapAdjust0
TDCErrorFlag, 95	TDCSetup, 159
HaveToken	kDataReady
TDCStatus, 166	TDCBoundaryScan, 85
	kDeadTime
INVALID	TDCSetup, 158
Socket, 67	kEnableAutomaticReject
IO_aux_clock	TDCSetup, 159
TDCSetup, 118	kEnableBytewise
IO_clock_40	TDCSetup, 159
TDCSetup, 118	kEnableChannel
IO_pll_clock_160	TDCControl, 93
TDCSetup, 118	kEnableDirectBunchReset
IO_pll_clock_80	TDCSetup, 159
TDCSetup, 118	kEnableDirectEventReset
IOClockSource	TDCSetup, 159
TDCSetup, 118	kEnableDirectTrigger
Init	TDCSetup, 159
DAQ::QuickUSBHandler, 64	kEnableError

TDCSetup, 159	kEventCountOffset
kEnableErrorBypass	TDCSetup, 160
TDCSetup, 159	kEventReset
kEnableErrorMark	TDCBoundaryScan, 85
TDCSetup, 159	kGetData
kEnableGlobalHeader	TDCBoundaryScan, 85
TDCSetup, 159	kGlobalReset
kEnableGlobalTrailer	TDCControl, 93
TDCSetup, 159	kHaveToken
kEnableJTAGReadout	TDCStatus, 167
TDCSetup, 159	kHit
kEnableLocalHeader	TDCBoundaryScan, 85
TDCSetup, 159	kIOClockDelay
kEnableLocalTrailer	TDCSetup, 160
TDCSetup, 159	kIOClockSource
kEnableMasterResetCode	TDCSetup, 160
TDCSetup, 159	kKeepToken
kEnableMasterResetOnEventReset	TDCSetup, 160
TDCSetup, 159	
• •	kL1Occupancy
kEnableMatching	TDCStatus, 167
TDCSetup, 159	kLeading
kEnableOverflowDetect	TDCSetup, 160
TDCSetup, 159	kLeadingResolution
kEnablePair	TDCSetup, 160
TDCSetup, 159	kLowPowerMode
kEnablePattern	TDCSetup, 160
TDCControl, 93	kMaster
kEnableReadoutOccupancy	TDCSetup, 160
TDCSetup, 159	kMatchWindow
kEnableReadoutSeparator	TDCSetup, 160
TDCSetup, 159	kMaxEventSize
kEnableRelative	TDCSetup, 160
TDCSetup, 159	kModeRC
kEnableResetChannelBufferWhenSeparator	TDCSetup, 160
TDCSetup, 159	kModeRCCompression
kEnableSeparatorOnBunchReset	TDCSetup, 160
TDCSetup, 159	kOffset0
kEnableSeparatorOnEventReset	TDCSetup, 160
TDCSetup, 159	kPLLControl
kEnableSerial	TDCSetup, 160
TDCSetup, 159	kPLLReset
kEnableSetCountersOnBunchReset	TDCControl, 93
TDCSetup, 160	kParallelDataOut
kEnableTTLClock	TDCBoundaryScan, 85
TDCSetup, 160	kParallelEnable
kEnableTTLControl	TDCBoundaryScan, 85
TDCSetup, 160	kRCAdjust0
kEnableTTLHit	TDCSetup, 160
TDCSetup, 160	kReadoutFIFOEmpty
• •	
kEnableTTLReset	TDCStatus, 167
TDCSetup, 160	kReadoutFIFOFull
kEnableTTLSerial	TDCStatus, 167
TDCSetup, 160	kReadoutFIFOOccupancy
kEncodedControl	TDCStatus, 168
TDCBoundaryScan, 85	kReadoutFIFOSize
kError	TDCSetup, 160
TDCBoundaryScan, 85	kReadoutSingleCycleSpeed
TDCStatus, 167	TDCSetup, 160

kReadoutSpeedSelect	kTriggerFIFOFull
TDCSetup, 160	TDCStatus, 168
kRejectCountOffset	kTriggerFIFOOccupancy
TDCSetup, 160	TDCStatus, 168
kRejectFIFOFull	kVernierOffset
TDCSetup, 160	TDCSetup, 161
kReset	kWidthSelect
TDCBoundaryScan, 85	TDCSetup, 161
kRollOver	·
TDCSetup, 160	L1BufferParityError
kSearchWindow	TDCSetup, 117
TDCSetup, 160	L1Occupancy
kSelectBypassInputs	TDCStatus, 166
TDCSetup, 161	Listen
kSerialBypassIn	Socket, 69
TDCBoundaryScan, 85	LogRedirector, 41
kSerialClockDelay	contents, 42
TDCSetup, 161	fRedirect, 42
kSerialClockSource	fSS, 42
TDCSetup, 161	LogRedirector, 42
kSerialDelay	Logger, 40
TDCSetup, 161	∼Logger, 41
kSerialIn	fBuffer, 41
	fStream, 41
TDCBoundaryScan, 85 kSerialOut	Logger, 41
TDCBoundaryScan, 85	MASTER
kSetupParity	Socket, 67
TDCSetup, 161	magic
kStrobeOut	file_header_t, 27
TDCBoundaryScan, 85	MajorVersion
kStrobeSelect	DAQ::QuickUSBHandler::Version, 168
TDCSetup, 161	Message, 42
kTDCld	\sim Message, 43
TDCSetup, 161	Dump, 44
kTest	fString, 44
TDCBoundaryScan, 85	GetKey, 44
kTestInvert	GetString, 44
TDCSetup, 161	IsFromWeb, 44
kTestMode	Message, 43
TDCSetup, 161	Messenger, 44
kTestSelect	\sim Messenger, 46
TDCSetup, 161	AddClient, 47
kTokenBypassIn	Broadcast, 47
TDCBoundaryScan, 85	Connect, 47
kTokenDelay	Disconnect, 48
TDCSetup, 161	DisconnectClient, 48
kTokenIn	fNumAttempts, 51
TDCBoundaryScan, 85	fPID, 51
kTokenOut	fStderrPipe, 51
TDCBoundaryScan, 85	fStdoutPipe, 51
kTrailing	GetType, 49
TDCSetup, 161	Messenger, 46
kTrigger	ProcessMessage, 49
TDCBoundaryScan, 85	Receive, 49
kTriggerCountOffset	Send, 49
TDCSetup, 161	SendAll, 50
kTriggerFIFOEmpty	StartAcquisition, 50
TDCStatus, 168	StopAcquisition, 51
. = 0 0 tatas, . 0 0	

SwitchClientType, 51	operator=
MinorVersion	OnlineDBHandler::TDCConditions, 86
DAQ::QuickUSBHandler::Version, 168	TDCRegister, 108
	operator==
NewBurst	OnlineDBHandler::TDCConditions, 86
OnlineDBHandler, 53	
NewPlot	PAIR
DQM::DQMProcess, 24	DAQ::TDC, 81
NewRun	PPSCanvas
OnlineDBHandler, 54	DQM::PPSCanvas, 56
num_hptdc	ParseMessage
file_header_t, 27	Client, 19
NumErrors	DQM::DQMProcess, 25
TDCMeasurement, 105	PrepareConnection
NumEvents	Socket, 69
TDCMeasurement, 105	ProcessMessage
OLEADING	Messenger, 49
DAQ::TDC, 81	OverticConve
OTRAILING	QuarticCanvas
DAQ::TDC, 81	DQM::QuarticCanvas, 60
,	QuickUSBHandler
Object SpeketManager 70	DAQ::QuickUSBHandler, 64
SocketMessage, 78	R DLLReset
Online DBH andler, 51	TDCControl, 88
~OnlineDBHandler, 53	R EnablePattern
BuildTables, 53	TDCControl, 88
BurstInfos, 53	R GlobalReset
fDB, 54	TDCControl, 88
GetLastBurst, 53	R PLLReset
GetLastRun, 53	TDCControl, 88
GetRunInfo, 53	RO Fixed
GetRuns, 53	TDCSetup, 118
GetTDCConditions, 53	RO_pll_80Mbits_s
NewBurst, 53 NewRun, 54	TDCSetup, 118
	RSC 10Mbits s
OnlineDBHandler, 53	TDCSetup, 118
RunCollection, 53	•
Select, 54	RSC_1p25Mbits_s TDCSetup, 118
SetHVConditions, 54	RSC_20Mbits_s
SetTDCConditions, 54 TDCConditionsCollection, 53	TDCSetup, 118
OnlineDBHandler::BurstInfo, 15	RSC_2p5Mbits_s
burst id, 15	TDCSetup, 118
— :	RSC_312p5kbits_s
time_start, 15 OnlineDBHandler::TDCConditions, 86	TDCSetup, 118
	RSC_40Mbits_s
detector, 86 operator=, 86	TDCSetup, 118
operator==, 86	RSC_5Mbits_s
•	TDCSetup, 118
run_id, 86	RSC_625kbits_s
tdc_acq_mode, 86	TDCSetup, 118
tdc_address, 86	
tdc_det_mode, 86	ReadConfiguration
tdc_id, 86	DAQ::TDC, 82
Open FiloRoader 30	ReadRegister
FileReader, 30	DAQ::TDC, 82
OpenFile DAO::EBGAHandlor 22	ReadStatus
DAQ::FPGAHandler, 33	DAQ::TDC, 82
operator<<	ReadoutFIFOParityError
TDCErrorFlag, 95	TDCSetup, 118

ReadoutSingleCycleSpeed	TDCSetup, 118
TDCSetup, 118	Serial_pll_clock_80
ReadoutSpeed	TDCSetup, 118
TDCSetup, 118	SerialClockSource
ReadoutStateError	TDCSetup, 118
TDCSetup, 118	SerialStrobeType
Receive	TDCSetup, 118
Client, 19, 20	SetAllChannelsOffset
Messenger, 49	TDCSetup, 132
RegisterName	SetAllTapsDLLAdjustment
TDCControl, 88	TDCSetup, 133
RegisterTest	SetBits
DAQ::FPGAHandler, 34	TDCRegister, 108
Reset	SetBypassInputs
DAQ::QuickUSBHandler, 64	TDCSetup, 133
RetrieveSetupWord	SetChannelOffset
DAQ::FPGAHandler, 34	TDCSetup, 133
Run	SetCoarseCountOffset
DQM::DQMProcess, 25	TDCSetup, 133
run_id	SetConstantValues
file_header_t, 27	TDCBoundaryScan, 85
OnlineDBHandler::TDCConditions, 86	TDCControl, 92
RunCollection	TDCRegister, 108
OnlineDBHandler, 53	TDCSetup, 134
SS DSStrobe	TDCStatus, 166
TDCSetup, 119	SetControlParity
SS_LeadingEdge	TDCControl, 92
TDCSetup, 119	SetCoreClockDelay
SS_LeadingTrailingStrobe	TDCSetup, 134
TDCSetup, 119	SetCoreClockSource
SS_NoStrobe	TDCSetup, 134
TDCSetup, 119	SetDLLAdjustment
Save	TDCSetup, 135
DQM::GastofCanvas, 39	SetDLLClockDelay
DQM::PPSCanvas, 57	TDCSetup, 135
DQM::QuarticCanvas, 61	SetDLLClockSource
Select	TDCSetup, 135
OnlineDBHandler, 54	SetDLLControl
SelectConnections	TDCSetup, 136
Socket, 70	SetDLLMode
Send	TDCSetup, 136
Client, 20	SetDLLReset
Messenger, 49	TDCControl, 92
SendAll	SetDeadTime
Messenger, 50	TDCSetup, 134
SendAndReceive	SetEdgeResolution
Client, 21	TDCSetup, 136
SendConfiguration	SetEdgesPairing
DAQ::TDC, 82	TDCSetup, 137
SendMessage	SetEnableAutomaticReject
Socket, 70	TDCSetup, 137
SendSetupWord	SetEnableBytewise
DAQ::FPGAHandler, 34	TDCSetup, 137
Serial_aux_clock	SetEnableDirectBunchReset
TDCSetup, 118	TDCSetup, 138
Serial_pll_clock_160	SetEnableDirectEventReset
TDCSetup, 118	TDCSetup, 138
Serial_pll_clock_40	SetEnableDirectTrigger

TD00 : 400	0 "
TDCSetup, 138	OnlineDBHandler, 54
SetEnableError	SetIOClockDelay TDCSetup, 147
TDCSetup, 139	•
SetEnableErrorBypass TDCSetup, 139	SetIOClockSource
• *	TDCSetup, 147
SetEnableErrorMark	SetKeepToken
TDCSetup, 139	TDCSetup, 148
SetEnableGlobalHeader	SetKeyValue
TDCSetup, 140	SocketMessage, 78, 79
SetEnableGlobalTrailer	SetLeadingMode
TDCSetup, 140	TDCSetup, 148 SetLowPowerMode
SetEnableJTAGReadout	
TDCSetup, 140 SetEnableLocalHeader	TDCSetup, 148 SetMaster
TDCSetup, 141 SetEnableLocalTrailer	TDCSetup, 149 SetMatchWindow
TDCSetup, 141	TDCSetup, 149
SetEnableMasterResetCode	SetMaxEventSize
TDCSetup, 141 SetEnableMasterResetOnEventReset	TDCSetup, 149 SetModeRC
TDCSetup, 142 SetEnableOverflowDetect	TDCSetup, 150
	SetModeRCCompression
TDCSetup, 142	TDCSetup, 150
SetEnablePattern	SetPLLControl
TDCControl, 93	TDCSetup, 150
SetEnableReadoutOccupancy	SetPLLReset
TDCSetup, 142	TDCControl, 93 SetPort
SetEnableReadoutSeparator	
TDCSetup, 143 SetEnableRelative	Socket, 70
	SetRCAdjustment
TDCSetup, 143	TDCSetup, 151
SetEnableResetChannelBufferWhenSeparator TDCSetup, 143	SetReadoutFIFOSize
•	TDCSetup, 151
SetEnableSeparatorOnBunchReset	SetReadoutSingleCycleSpeed
TDCSetup, 144	TDCSetup, 151
SetEnableSeparatorOnEventReset	SetReadoutSpeedSelect
TDCSetup, 144	TDCSetup, 152
SetEnableSerial	SetRejectCountOffset
TDCSetup, 144 SetEnableSetCountersOnBunchReset	TDCSetup, 152
	SetRejectFIFOFull
TDCSetup, 145 SetEnableTTLClock	TDCSetup, 152
	SetRollOver
TDCSetup, 145 SetEnableTTLControl	TDCSetup, 153
	SetRunInfo
TDCSetup, 145 SetEnableTTLHit	DQM::GastofCanvas, 39
	DQM::PPSCanvas, 57
TDCSetup, 146	DQM::QuarticCanvas, 61 SetSearchWindow
SetEnableTTLReset	
TDCSetup, 146	TDCSetup, 153
SetEnableTTLSerial	SetSerialClockDelay
TDCSetup, 146	TDCSetup, 153
SetEventCountOffset	SetSerialClockSource
TDCSetup, 147	TDCSetup, 154
SetEventsCollection	SetSerialDelay
TDCMeasurement, 105	TDCSetup, 154
SetGlobalReset	SetSetupParity
TDCControl, 93	TDCSetup, 154
SetHVConditions	SetSetupRegister

DAG TDG 00	0.10.1.11.00
DAQ::TDC, 82	GetSocketId, 69
SetSocketId	GetSocketType, 69
Socket, 70	INVALID, 67
SetStrobeSelect	IsWebSocket, 69
TDCSetup, 155	Listen, 69
SetTDCConditions	MASTER, 67
OnlineDBHandler, 54	PrepareConnection, 69
SetTDCld	SelectConnections, 70
TDCSetup, 155	SendMessage, 70
SetTDCSetup	SetPort, 70
DAQ::FPGAHandler, 35	SetSocketId, 70
SetTest	Socket, 67
TDCSetup, 155	SocketCollection, 67
SetTestInvert	SocketType, 67
TDCSetup, 156	Start, 70
SetTestMode	Stop, 71
TDCSetup, 156	WEBSOCKET_CLIENT, 67
SetTokenDelay	Socket communication objects, 9
TDCSetup, 156	SocketCollection
SetTrailingMode	Socket, 67
TDCSetup, 157	SocketMessage, 72
SetTriggerCountOffset	\sim SocketMessage, 77
TDCSetup, 157	Dump, 77
SetTriggerMatchingMode	fMessage, 79
TDCSetup, 157	GetCleanedValue, 77
SetUpperLabel	GetIntValue, 77
DQM::GastofCanvas, 39	GetKey, 77
DQM::PPSCanvas, 57	GetString, 77
DQM::QuarticCanvas, 61	GetValue, 77
SetVernierOffset	GetVectorValue, 78
TDCSetup, 158	Object, 78
SetWidthResolution	SetKeyValue, 78, 79
TDCSetup, 158	SocketMessage, 74–77
SetWord	String, 79
TDCEvent, 102	SocketType
TDCRegister, 108	Socket, 67
SetupParityError	SoftReset
TDCSetup, 118	DAQ::TDC, 82
Socket, 65	spill_id
\sim Socket, 67	file_header_t, 27
AcceptConnections, 68	Start
Bind, 68	Socket, 70
CLIENT, 67	StartAcquisition
Configure, 68	DAQ::FPGAHandler, 35
Create, 68	Messenger, 50
DAQ, 67	StartBulkTransfer
DETECTOR, 67	DAQ::QuickUSBHandler, 65
DQM, 67	Stop
DumpConnected, 68	DAQ::FPGAHandler, 35
fAddress, 71	Socket, 71
fBuffer, 71	StopAcquisition
fMaster, 71	DAQ::FPGAHandler, 35
fPort, 71	Messenger, 51
fReadFds, 71	StopBulkTransfer
fSocketId, 71	DAQ::QuickUSBHandler, 65
fSocketsConnected, 71	String
FetchMessage, 69	SocketMessage, 79
GetPort, 69	SwitchClientType
	71 -

Messenger, 51	TDCError
moccongol, or	TDCEvent, 97
TDC	TDCErrorFlag, 94
DAQ::TDC, 81	\sim TDCErrorFlag, 95
TDCBoundaryScan, 83	Dump, 95
kAuxClock, 85	fWord, 95
kBunchReset, 85	GetWord, 95
kClk, 85	HasGroupError, 95
kDataReady, 85	HasInternalChipError, 95
kEncodedControl, 85	HasL1BufferOverflow, 95
kError, 85 kEventReset. 85	HasReachedEventSizeLimit, 95
•	HasReadoutFIFOOverflow, 95
kGetData, 85 kHit, 85	HasTriggerFIFOOverflow, 95
kParallelDataOut, 85	operator<<, 95
kParallelEnable, 85	TDCErrorFlag, 95
kReset, 85	TDCEvent, 95
kSerialBypassIn, 85	\sim TDCEvent, 97
kSerialIn, 85	Dump, 97
kSerialOut, 85	ETTT, 97
kStrobeOut, 85	EventType, 97
kTest, 85	fWord, 102
kTokenBypassIn, 85	Filler, 97
kTokenIn, 85	GetBunchld, 98
kTokenOut, 85	GetChannelld, 98
kTrigger, 85	GetETTT, 99
SetConstantValues, 85	GetErrorFlags, 98
TDCBoundaryScan, 84	GetEventCount, 99
TDCConditionsCollection	GetEventId, 99
OnlineDBHandler, 53	GetGeo, 100
TDCControl, 86	GetStatus, 100
DisableAllChannels, 89	GetTDCld, 100
DisableChannel, 89	GetTime, 101
Dump, 89	GetType, 101
EnableAllChannels, 90	GetWidth, 101
EnableChannel, 90	GetWord, 101
EnablePattern, 88	GetWordCount, 102
GetDLLReset, 90	GlobalHeader, 97
GetEnablePattern, 91	GlobalTrailer, 97
GetGlobalReset, 91	IsTrailing, 102
GetPLLReset, 91	SetWord, 102 TDCError, 97
kControlParity, 93	TDCError, 97
kDLLReset, 93	TDCEvent, 97 TDCHeader, 97
kEnableChannel, 93	TDCMeasurement, 97
kEnablePattern, 93	TDCMeastreffield, 97
kGlobalReset, 93	Trigger, 97
kPLLReset, 93	TDCHeader
R_DLLReset, 88	TDCEvent, 97
R_EnablePattern, 88	TDCMeasurement, 102
R_GlobalReset, 88	~TDCMeasurement, 103
R_PLLReset, 88 RegisterName, 88	Dump, 103
SetConstantValues, 92	fEvents, 105
SetControlParity, 92	fMap, 105
SetDLLReset, 92	GetBunchld, 104
SetEnablePattern, 93	GetChannelld, 104
SetGlobalReset, 93	GetETTT, 104
SetPLLReset, 93	GetEventId, 104
TDCControl, 88, 89	GetLeadingTime, 104
	- 3 -,

GetTDCId, 104	E_6p25ns, 117
GetToT, 104	E_800ps, 117
GetTrailingTime, 105	EdgeResolution, 117
NumErrors, 105	EnabledError, 117
NumEvents, 105	GetChannelOffset, 122
SetEventsCollection, 105	GetCoarseCountOffset, 122
TDCEvent, 97	GetDLLAdjustment, 123
TDCMeasurement, 103	GetDeadTime, 123
TDCRegister, 105	GetEdgeResolution, 123
~TDCRegister, 107	GetEdgesPairing, 124
	G
bit, 107	GetEnableError, 124
Clear, 108	GetEnableErrorBypass, 124
DumpRegister, 108	GetEnableErrorMark, 125
fNumWords, 109	GetEnableJTAGReadout, 125
fWord, 109	GetEnableReadoutOccupancy, 125
fWordSize, 109	GetEnableReadoutSeparator, 126
GetBits, 108	GetEnableSerial, 126
GetNumWords, 108	GetLeadingMode, 126
GetWord, 108	GetMatchWindow, 127
GetWords, 108	GetMaxEventSize, 127
operator=, 108	GetRCAdjustment, 127
SetBits, 108	GetReadoutFIFOSize, 128
SetConstantValues, 108	GetRejectCountOffset, 128
SetWord, 108	GetRejectFIFOFull, 128
TDCRegister, 107	GetSearchWindow, 129
word_t, 107	GetSetupParity, 129
TDCSetup, 109	GetTDCld, 129
ChannelSelectError, 117	GetTestInvert, 130
CoarseError, 117	GetTestMode, 130
ControlParityError, 118	GetTrailingMode, 130
•	-
Core_aux_clock, 116	GetTriggerCountOffset, 131
Core_clock_40, 116	GetTriggerLatency, 131
Core_pll_clock_160, 116	GetTriggerMatchingMode, 131
Core_pll_clock_80, 116	GetVernierOffset, 132
CoreClockSource, 116	GetWidthResolution, 132
DLL_160MHz, 117	IO_aux_clock, 118
DLL_320MHz, 117	IO_clock_40, 118
DLL_40MHz, 117	IO_pll_clock_160, 118
DLL_Illegal, 117	IO_pll_clock_80, 118
DLL_aux_clock, 117	IOClockSource, 118
DLL_clock_40, 117	JTAGInstructionParityError, 118
DLL_pll_clock_160, 117	kCoarseCountOffset, 158
DLL_pll_clock_320, 117	kCoreClockDelay, 158
DLL_pll_clock_40, 117	kCoreClockSource, 158
DLLClockSource, 117	kDLLClockDelay, 158
DLLSpeedMode, 117	kDLLClockSource, 158
DT 100ns, 117	kDLLControl, 159
DT_10ns, 117	kDLLMode, 159
DT_30ns, 117	kDLLTapAdjust0, 159
	kDeadTime, 158
DT_5ns, 117 DeadTime, 116	kEnableAutomaticReject, 159
Dump, 121	kEnableDirectPunchPaget 150
E_100ps, 117	kEnableDirectBunchReset, 159
E_12p5ns, 117	kEnableDirectEventReset, 159
E_1p6ns, 117	kEnableDirectTrigger, 159
E_200ps, 117	kEnableError, 159
E_3p12ns, 117	kEnableErrorBypass, 159
E_400ps, 117	kEnableErrorMark, 159

kEnableGlobalHeader, 159	kVernierOffset, 161
kEnableGlobalTrailer, 159	kWidthSelect, 161
kEnableJTAGReadout, 159	L1BufferParityError, 117
kEnableLocalHeader, 159	RO_Fixed, 118
kEnableLocalTrailer, 159	RO_pll_80Mbits_s, 118
kEnableMasterResetCode, 159	RSC_10Mbits_s, 118
kEnableMasterResetOnEventReset, 159	RSC_1p25Mbits_s, 118
kEnableMatching, 159	RSC 20Mbits s, 118
kEnableOverflowDetect, 159	RSC_2p5Mbits_s, 118
kEnablePair, 159	RSC_312p5kbits_s, 118
kEnableReadoutOccupancy, 159	RSC_40Mbits_s, 118
kEnableReadoutSeparator, 159	RSC_5Mbits_s, 118
kEnableRelative, 159	RSC_625kbits_s, 118
kEnableResetChannelBufferWhenSeparator, 159	ReadoutFIFOParityError, 118
kEnableSeparatorOnBunchReset, 159	ReadoutSingleCycleSpeed, 118
kEnableSeparatorOnEventReset, 159	ReadoutSpeed, 118
kEnableSerial, 159	ReadoutStateError, 118
kEnableSetCountersOnBunchReset, 160	SS_DSStrobe, 119
kEnableTTLClock, 160	SS LeadingEdge, 119
kEnableTTLControl, 160	SS_LeadingTrailingStrobe, 119
kEnableTTLHit, 160	SS_NoStrobe, 119
kEnableTTLReset, 160	Serial_aux_clock, 118
kEnableTTLSerial, 160	Serial_pll_clock_160, 118
kEventCountOffset, 160	Serial_pll_clock_40, 118
kIOClockDelay, 160	Serial_pll_clock_80, 118
kIOClockSource, 160	SerialClockSource, 118
kKeepToken, 160	SerialStrobeType, 118
kLeading, 160	SetAllChannelsOffset, 132
kLeadingResolution, 160	SetAllTapsDLLAdjustment, 133
kLowPowerMode, 160	SetBypassInputs, 133
kMaster, 160	SetChannelOffset, 133
kMatchWindow, 160	SetCoarseCountOffset, 133
kMaxEventSize, 160	SetConstantValues, 134
kModeRC, 160	SetCoreClockDelay, 134
kModeRCCompression, 160	SetCoreClockSource, 134
kOffset0, 160	SetDLLAdjustment, 135
kPLLControl, 160	SetDLLClockDelay, 135
kRCAdjust0, 160	SetDLLClockSource, 135
kReadoutFIFOSize, 160	SetDLLControl, 136
kReadoutSingleCycleSpeed, 160	SetDLLMode, 136
kReadoutSpeedSelect, 160	SetDeadTime, 134
kRejectCountOffset, 160	SetEdgeResolution, 136
kRejectFIFOFull, 160	SetEdgesPairing, 137
kRollOver, 160	SetEnableAutomaticReject, 137
kSearchWindow, 160	SetEnableBytewise, 137
kSelectBypassInputs, 161	SetEnableDirectBunchReset, 138
kSerialClockDelay, 161	SetEnableDirectEventReset, 138
kSerialClockSource, 161	SetEnableDirectTrigger, 138
kSerialDelay, 161	SetEnableError, 139
kSetupParity, 161	
• •	SetEnableErrorBypass, 139
kStrobeSelect, 161	SetEnableErrorMark, 139
kTDCld, 161	SetEnableGlobalHeader, 140
kTestInvert, 161	SetEnableGlobalTrailer, 140
kTestMode, 161	SetEnableJTAGReadout, 140
kTestSelect, 161	SetEnableLocalHeader, 141
kTokenDelay, 161	SetEnableLocalTrailer, 141
kTrailing, 161	SetEnableMasterResetCode, 141
kTriggerCountOffset, 161	SetEnableMasterResetOnEventReset, 142

SetEnableOverflowDetect, 142	W_1p6ns, 119
SetEnableReadoutOccupancy, 142	W_200ns, 119
SetEnableReadoutSeparator, 143	W_200ps, 119
SetEnableRelative, 143	W_25ns, 119
SetEnableResetChannelBufferWhenSeparator,	W 3p2ns, 119
143	W_400ns, 119
SetEnableSeparatorOnBunchReset, 144	W_400ps, 119
SetEnableSeparatorOnEventReset, 144	W 50ns, 119
SetEnableSerial, 144	W 6p25ns, 119
SetEnableSetCountersOnBunchReset, 145	W_800ns, 119
SetEnableTTLClock, 145	W_800ps, 119
SetEnableTTLControl, 145	WidthResolution, 119
SetEnableTTLHit, 146	TDCStatus, 161
SetEnableTTLReset, 146	DLLLock, 164
SetEnableTTLSerial, 146	Dump, 164
SetEventCountOffset, 147	Error, 164
SetIOClockDelay, 147	FIFOEmpty, 165
SetIOClockSource, 147	FIFOFull, 165
SetKeepToken, 148	FIFOOccupancy, 165
SetLeadingMode, 148	HaveToken, 166
SetLowPowerMode, 148	kDLLLock, 167
SetMaster, 149	kError, 167
SetMatchWindow, 149	kHaveToken, 167
SetMaxEventSize, 149	kL1Occupancy, 167
SetModeRC, 150	kReadoutFIFOEmpty, 167
SetModeRCCompression, 150	kReadoutFIFOFull, 167
SetPLLControl, 150	kReadoutFIFOOccupancy, 168
SetRCAdjustment, 151	kTriggerFIFOEmpty, 168
SetReadoutFIFOSize, 151	kTriggerFIFOFull, 168
SetReadoutSingleCycleSpeed, 151	kTriggerFIFOOccupancy, 168
SetReadoutSpeedSelect, 152	L1Occupancy, 166
SetRejectCountOffset, 152	SetConstantValues, 166
SetRejectFIFOFull, 152	TDCStatus, 163
SetRollOver, 153	TriggerFIFOEmpty, 166
SetSearchWindow, 153	Trigger II OLINPIY, 100
	TriggerFIFOOccupancy, 167
SetSerialClockDelay, 153	
SetSerialClockSource, 154	TDCTrailer
SetSerialDelay, 154	TDCEvent, 97
SetSetupParity, 154	TRAILEAD
SetStrobeSelect, 155	DAQ::TDC, 81
SetTDCld, 155	TRIG_MATCH
SetTest, 155	HPTDC chip control, 11
SetTestInvert, 156	tdc_acq_mode
SetTestMode, 156	OnlineDBHandler::TDCConditions, 86
SetTokenDelay, 156	tdc_address
SetTrailingMode, 157	OnlineDBHandler::TDCConditions, 86
SetTriggerCountOffset, 157	tdc_det_mode
SetTriggerMatchingMode, 157	OnlineDBHandler::TDCConditions, 86
SetVernierOffset, 158	tdc_id
SetWidthResolution, 158	OnlineDBHandler::TDCConditions, 86
SetupParityError, 118	time_start
TDCSetup, 119, 120	OnlineDBHandler::BurstInfo, 15
TriggerFIFOParityError, 117	Trigger
TriggerMatchingError, 118	TDCEvent, 97
VernierError, 117	TriggerFIFOEmpty
W_100ns, 119	TDCStatus, 166
W_100ps, 119	TriggerFIFOFull
W_12p5ns, 119	TDCStatus, 167
_ ′	· - / -

```
TriggerFIFOOccupancy
    TDCStatus, 167
TriggerFIFOParityError
    TDCSetup, 117
TriggerMatchingError
    TDCSetup, 118
UpdatedPlot
    DQM::DQMProcess, 24
VernierError
    TDCSetup, 117
W 100ns
    TDCSetup, 119
W_100ps
    TDCSetup, 119
W_12p5ns
    TDCSetup, 119
W_1p6ns
    TDCSetup, 119
W_200ns
    TDCSetup, 119
W_200ps
    TDCSetup, 119
W 25ns
    TDCSetup, 119
W_3p2ns
    TDCSetup, 119
W 400ns
    TDCSetup, 119
W_400ps
    TDCSetup, 119
W 50ns
    TDCSetup, 119
W_6p25ns
    TDCSetup, 119
W_800ns
    TDCSetup, 119
W_800ps
    TDCSetup, 119
WEBSOCKET_CLIENT
    Socket, 67
WidthResolution
    TDCSetup, 119
word t
    TDCRegister, 107
Write
    DAQ::QuickUSBHandler, 65
WriteRegister
    DAQ::TDC, 82
Х
    DQM::GastofCanvas::Coord, 21
    DQM::QuarticCanvas::Coord, 22
У
    DQM::GastofCanvas::Coord, 22
    DQM::QuarticCanvas::Coord, 22
```