



Version 3 ▼

Sep 22, 2020

Cas9 Enrichment for Nanopore Sequencing V.3

Timothy Gilpatrick¹, Isac Lee¹, James E. Graham², Etienne Raimondeau², Rebecca Bowen², Andrew Heron², Fritz J. Sedlazeck³, Winston Timp¹

¹Johns Hopkins University; ²Oxford Nanopore Technologies; ³Baylor College of Medicine

1 Works for me

This protocol is published without a DOI.

TimpLab

Tech. support email: wtimp@jhu.edu



ABSTRACT

This protocol is designed to help users achieve targeted enrichment for regions of interest using nanopore sequencing, providing higher coverage for myriad future analysis applications. GuideRNA components (crRNA and tracrRNA) were designed using online tools provided by IDT.

EXTERNAL LINK

https://doi.org/10.1038/s41587-020-0407-5

PROTOCOL CITATION

Timothy Gilpatrick, Isac Lee, James E. Graham, Etienne Raimondeau, Rebecca Bowen, Andrew Heron, Fritz J. Sedlazeck, Winston Timp 2020. Cas9 Enrichment for Nanopore Sequencing. **protocols.io** https://protocols.io/view/cas9-enrichment-for-nanopore-sequencing-bmi5k4g6

MANUSCRIPT CITATION please remember to cite the following publication along with this protocol

EXTERNAL LINK

https://doi.org/10.1038/s41587-020-0407-5

LICENSE

This is an open access protocol distributed under the terms of the Creative Commons Attribution License, which permits unrestricted use, distribution, and reproduction in any medium, provided the original author and source are credited

CREATED

Sep 20, 2020

LAST MODIFIED

Sep 22, 2020

PROTOCOL INTEGER ID

42301

MATERIALS

NAME	CATALOG #	VENDOR
CutSmart Buffer - 5.0 ml	B7204S	New England Biolabs
Taq DNA Polymerase with Standard Taq Buffer - 2,000 units	M0273L	New England Biolabs
Quick Ligation Kit - 150 rxns	M2200L	New England Biolabs

NAME	CATALOG #	VENDOR
Quick Dephosphorylation Kit - 500 rxns	M0508L	New England Biolabs
TE buffer		Thermo Fisher Scientific
Alt-R® S.p. HiFi Cas9 Nuclease V3	1081060	IDT
Duplex Buffer	11-01-03-01	IDT
1D Ligation Sequencing Kit	SQK-LSK109	
AmpureXP beads	A63880	Beckman Coulter
dATP	D1005	Zymo Research

BEFORE STARTING

Users should design and order their own custom crRNAs. Note that there is a strong preference for reads to start on the side of the Cas9 cut containing the PAM site. The selection of guideRNAs makes a big difference in the performance of the assay, we therefore encourage using available tools to predict guideRNA on-target performance and (if applicable) off-target performance. We used the tool provided by 'Integrated DNA Technologies' to design and estimate performance of guideRNAs

Making Ribonucleoprotein Complex

- Resuspend crRNA(s) and tracrRNA to final concentration of 100uM in TE, pH7.5 (2nmol crRNA in 20uL; 5nmol tracrRNA in 50uL)
- 2 Make equimolar mix of all crRNAs to be used by adding 0.75uL of each to new tube
- 3 Assemble guideRNA duplex: 8uL Nuclease Free Water (NFW) 1uL 100uM tracrRNA 1uL crRNA mix
- 4 Heat guideRNA duplex at +95C for 5min, allowing to cool on bench after incubation (perform steps 5 and 6 during incubation)
- 5 Dilute the 10X CutSmart buffer 1:8 with Nuclease Free Water (NFW) to make 1.25X CutSmart Buffer (14uL NFW + 2uL 10X CutSmart Buffer)
- 6 Dilute the HiFi Cas9 1:5 using the 1.25X CutSmart made in step 5 (1uL HiFi Cas9 + 4uL 1.25X CutSmart)
 - * Cas9 comes in stock of 10ug/uL or 61pM, we dilute 1:5 to prevent pipetting of very small volumes of the Cas9 enzyme in next step
- 7 Assemble Ribonucleoprotein Complex :

23uL NFW
2.8uL 10X CutSmart Buffer
3uL guideRNA duplex (from step 4) [30pmol]
1.2uL 1:5 dilution of Cas9 (from step 6) [15pmol]

Mix by gentle flicking, then keep on benchtop (room temperature) for 20min After incubation, keep the RNP on ice. Can be stored at +4C a few days before use

Dephosphorylation of Free DNA Ends

8 *note: this assumes starting DNA is sufficiently concentrated that 3ug is less than 24uL.
If DNA concentration is too low, adjust volumes of the buffers accordingly. For volume increases up to 3X, the enzyme

and RNP amounts can be kept consistent Dephosphorylation Reaction: 3uL 10X CutSmart Buffer 3ug of DNA (often in TE) NFW up to volume of 27uL *Mix gently by flicking before adding enzyme* Add 3uL QuickCIP enzyme (from NEB Quick dephosphorylation kit) [total volume = 30uL] *Mix by gentle flicking* Incubate at: +37C for 10min (dephosphorylation) +80C for 2min (enzyme inactivation) hold at +20C during incubation: >> get out AmpureXP to allow to come to room temperature, >> thaw 100mM ATP, vortex to mix, keep on ice after thawing, Cleavage and A-tailing of DNA Make 1:10 dilution of 100mM dATP

[5uL 100mM dATP + 45uL NFW]

After allowing dephosphorylated DNA (from step 8) to cool, Add the following components: 10uL Assembled RNP complex (from step 7) 1uL 1:10 (10mM) dATP 1uL Taq polymerase [total volume = 42uL]

Mix by gentle flicking

Incubate at:

+37C for 15min (Cas9 cleavage) +72C for 5min (Mono adenylation of 3' ends by Taq/dATP)

hold at +12C

> During this incubation, get out the following components from SQK-LSK109 reagents to thaw: Ligation Buffer (LNB) - (keep at room temp) Adaptor Mix (AMX) (keeping on ice after thaw)

Adaptor Ligation

Make "Ligation mix": 10

> 20uL LNB (ligation buffer from LSK109 kit) 4.5uL NFW 10uL T4 Ligase (from NEB quick ligation kit) 3.5uL AMX* (sequencing adaptor from LSK109 kit)

- * NOTE: AMX will be consumed in solution with ligase -- add right before use
- 11 Using pipette, mix ligation mix gently until homogenous (LNB is very viscous)

Add 20uL of "ligation mix" to DNA*, mix by gentle flicking

```
Add remaining (~18uL) "ligation mix" to DNA mix by gentle flicking [total volume = 80uL]

* A DNA precipitate may from at this step, as Formation of DNA precipitate does not app
```

* A DNA precipitate may from at this step, adding "ligation mix" in 2-steps helps to reduce this. Formation of DNA precipitate does not appear to interfere with protocol efficiency

12 Rotate ligation for 10min at Room Temperature

>During incubation, get out Long-Fragment Buffer (LFB) and Elution Buffer (EB) from LSK109 kit, keeping both at room temp

[or the Short Fragment Buffer (SFB), if the target region is less than 3kb]

13 After ligation, add equivolume (80uL) amount of TE (pH 8.0) [new volume = 160uL]

- 14 Add 0.3X Ampure (48uL if DNA is currently in 160uL) and mix by gentle flicking until homogeneous
- 15 Rotate for 5 minutes, then keep on benchtop for 5 minutes to allow Ampure beads to bind DNA
- 16 Place on magnetic tube rack, allow 2.5 minutes for beads to collect on back of tube
- 17 Remove supernatant with a pipette, taking care not to disturb the beads

Add 200uL of LFB to beads

[Or use the Short Fragment Buffer (SFB), if the target region is less than 3kb]

Remove tube from magnetic stand and resuspend Ampure beads by gentle flicking until homogeneous

- 18 Return sample to magnetic tube rack, allowing 2.5 minutes for beads to collect
- 19 Repeat steps 17 and 18 for a second bead wash w/ 200uL LFB
- 20 Remove supernatant, briefly spin tube to collect any excess LFB and carefully remove remaining solution from above the beads
- Add 15uL of elution buffer (EB), and keep at room temperature for 10 minutes to elute

 [for longer DNA fragments, it can be helpful to increase the elution time to 30minutes, or to elute with gentle agitation
]

>During this elution, get out the following components from LSK-109 kit to thaw: Flush Buffer (FLB or FB), Loading Beads (LB), Sequencing Buffer (SQB) - (all at room temp) and Sequencing Tether (SQT) - (on ice after thaw)

Library Prep and Sequencing

Return tube with sample to magnetic rack, and allow 2min for beads to collect, 22

Transfer (and keep!) ~15uL supernatant with DNA to a new tube

- 23 Perform initial priming of flow cell by loading 800uL FLB into MinION priming port
- Finish library prep by adding the following components to the 15uL DNA eluate: 24

25uL SQB

14.5uL Loading beads (LB) *

0.5uL SQT

[Total volume of prepped Library: ~55uL]

- *Loading Beads are in suspension -- vortex or flick prior to use
- 25 Perform second flow cell priming with 200uL of second priming solution: (70uL SQB + 70uL NFW + 70uL FLB)
 - ..then immediately afterwards load sample dropwise into MinION sample loading port
- 26 Start sequencing run using MinKNOW software

(We commonly get low pore occupancy with 20-30 pores performing active sequencing by this method. and runs often stop producing data after 24h)