I N S T E 心 N°

INSTEON Developer Notes Leak Sensor (2852-xxx)



Table of Contents

Revision History	ii
Device Description	4
Details	4
Additional Details	4
Example Standard Length Message	5
Example Extended Length Message	6
Messages Sent From – Leak Sensor	
Assign to ALL-Link Group	
Command Example: Docklight Example:	
Success Report	
Command Example: Docklight Example:	
Dry Status	
Command Example:	
Docklight Example:	
Wet Detected/Status	
Command Example:	
Docklight Example:	
Heartbeat	
Docklight Example:	
Messages Sent To – Leak Sensor	
INSTEON Engine Version	12
Command Example:	
Docklight Example:	
Ping	
Command Example:	
ID Request	
Command Example:	
Docklight Example:	
Read Configuration Byte	
Command Example: Docklight Example:	
Database Delta Command Example:	
Docklight Example:	
Remote Enter Linking Mode	
Command Example:	
Docklight Example:	
Remote Exit Linking Mode Command Example:	
Docklight Example:	



Get for Group/Button	21
Command Example:	
Docklight Example:	
Set LED Brightness	
Command Example:	
Docklight Example:	24
Stay Awake	25
Command Example:	
Docklight Example:	26
Set Configuration Byte	27
Command Example:	
Docklight Example:	
Appendix	29
Checksum Information	29
Example of Checksum:	29
Memory Map	30
All-Link Database (AL /L) Overview	30
EEPROM Structure Overview	
AL /L Record Format	
Overwriting an Empty AL /L Record	
Creating a New AL /L Record	
-	
Get Database	
Command Example:	
Docklight Example:	35
Set Database	36
Command Example:	
Docklight Example:	37



Revision History

Release Date	Author	Description
10/04/2013	jtalmich	V0.1 for Leak Sensor



Device Description

Details

Device Name	Leak Sensor
Product SKU	2852-XXX
Product Website	http://www.smarthome.com/2852-222/INSTEON-Leak-Sensor/p.aspx
Category	0x10 – Security, Health, and Safety
Subcategory	0x08 (Leak Sensor – US 915 MHz) 0x0D (Leak Sensor – EU 869.85 MHz) 0x0E (Leak Sensor – AUS/NZ 921 MHz)
Tested Firmware Version	89
Supports SD Messaging	YES
Supports ED Messaging	YES
I2CS enabled (CS)	YES

Additional Details

The Leak Sensor is a battery-powered device, therefore it goes to sleep quickly to preserve battery-life. The Leak Sensor must be awake for it to transmit or receive messages.

All direct commands will be ignored if the sender's ID is not in the I2CS device's database with the exceptions below. The Leak Sensor will reply with a NAK and 0xFF in cmd2 to indicate that the ID is not in the database.



Example Standard Length Message

A Standard Length Message (SD) is comprised of exactly nine (9) bytes.

Byte(s)	Description	Example
1-3	Transmitting INSTEON Device ID	AA BB CC
4-6	Receiving INSTEON Device ID (Target Device)	11 22 33
7	Flag Byte (Message Type)	0F
8	Command 1	11
9	Command 2	FF

andard Message Formatted

The above example will send an ON(11) at Full(FF) command to device 11 22 33.*

^{*}For a detailed explaination of INSTEON Messaging, please see the INSTEON Manual



Example Extended Length Message

An Extended Length Message (ED) is comprised of exactly nine (23) bytes.

Byte(s)	Description	Example
1-3	Transmitting INSTEON Device ID	AA BB CC
4-6	Receiving INSTEON Device ID (Target Device)	11 22 33
7	Flag Byte (Message Type)	1F
8	Command 1	20
9	Command 2	01
10-22	Data1 – Data13	00 00 00 00 00 00 00 00 00 00 00 00 00
23	Data14 (Checksum)	DF

Extended	AA	ВВ	CC	11	22	33	1F	20	01	00	00	00	00	00	00	00	00	00	00	00	00	00	DF
Message																							
Formatted																							

The above example will send an Set Operating Flags (20) of Programming Lock Off(01) command to device 11 22 33.*

^{*}For a detailed explaination of INSTEON Messaging, please see the INSTEON Manual



Messages Sent From - Leak Sensor

When an INSTEON device is active to trigger a group message the messages are sent in the following order *depending on flag options for some devices

Message Sent (Type)	Example
Group Broadcast Message on Activation	AA BB CC 00 00 01 CF 11 01
Direct Message for CleanUp	AA BB CC 11 22 33 40 11 01
Group Broadcast Message Success Report	AA BB CC 11 01 01 CF 06 00

All INSTEON Devices will send a group message for a particular activation. For Multi Group devices, the Group number will change depending on the group that was activated. The CleanUp messages and Success Reports will be the same with exception to the Group Number.

Assign to ALL-Link Group

This command is sent after holding down the SET Button for 3 seconds on the device.

Command Name	Assign to ALL-Link Group
Message Length	Standard Message (SD)
Message Type	Broadcast
To Address (Hi Byte)	0x10
To Address (Mid Byte)	Device Subcategory
To Address (Low Byte)	Firmware Revision
Command 1	0x02
Command 2	Hardware Revision

Command Example:

Assign to ALL-Link Group	AA BB CC 10 08 89 87 02 00
--------------------------	----------------------------

The above example is the command a Leak Sensor sends when it goes into Linking Mode after its SET Button has been pressed and held for about 3 seconds. The To Address contains the Device Category (0x10), Device Subcategory (0x08), and Firmware Revision (0x89). Command 2 conatins the Hardware Revision (0x00).

Docklight Example:

9/24/2013 13:35:04.138 [RX] - 02 50 21 7D B9 10 08 89 87 02 00 INSTEON STD RX Assign to ALL-Link Group/ID Request Response (Leak Sensor)



Success Report

This command is sent at the end of a group broadcast.

Command Name	Success Report
Message Length	Standard Message (SD)
Message Type	Broadcast
To Address (Hi Byte)	Cmd1 being cleaned up
To Address (Mid Byte)	Number of devices to be cleaned up
To Address (Low Byte)	Group number
Command 1	0x06
Command 2	Number of failed cleanups

Command Example:

Success Report	AA BB CC 11 02 01 CB 06 01
----------------	----------------------------

The above example is the message a Leak Sensor sends out after a group broadcast. The To Address contains the Cmd1 being cleaned up (0x11), number of devices to be cleaned up (0x02), and the group number (0x01). Command 2 contains the number of failed cleanups (0x01)

```
02 50 21 7D B9 11 02 01 CB 06 00 INSTEON STD RX
Cleanup Report Zero Error Example (Cmd1=0x11, 2 Devices in Group, Group 1)
02 50 21 7D B9 11 02 01 CB 06 00 INSTEON STD RX
Cleanup Report Zero Error Example (Cmd1=0x11, 2 Devices in Group, Group 1)
02 50 21 7D B9 11 02 01 CB 06 01 INSTEON STD RX
Cleanup Report One Error Example (Cmd1=0x11, 2 Devices in Group, Group 1)
02 50 21 7D B9 11 02 01 CB 06 01 INSTEON STD RX
Cleanup Report One Error Example (Cmd1=0x11, 2 Devices in Group, Group 1)
02 50 21 7D B9 11 02 01 CB 06 01 INSTEON STD RX
Cleanup Report One Error Example (Cmd1=0x11, 2 Devices in Group, Group 1)
```



Dry Status

This command is sent out when the SET Button is pressed and the current status is Dry.

Command Name	Dry Status
Message Length	Standard Message (SD)
Message Type	Broadcast
To Address	0x00 0x00 0x01
Command 1	0x11
Command 2	0x01

Command Example:

Dry Status	AA BB CC 00 00 01 CB 11 01
------------	----------------------------

The above example is the command a Leak Sensor sends out after the SET Button has been pressed and the current status is Dry. The To Address Low Byte contains the group (0x01), and Cmd1 is the On command (0x11).

```
02 50 21 7D B9 00 00 01 CB 11 01 INSTEON STD RX Dry Status
02 50 21 7D B9 00 00 01 CB 11 01 INSTEON STD RX Dry Status
02 50 21 7D B9 1A 77 7B 41 11 01 INSTEON STD RX
```



Wet Detected/Status

This command is sent when either the Leak Sensor senses a leak or if the SET Button is pressed and the current status is Wet.

Command Name	Wet Detected/Status
Message Length	Standard Message (SD)
Message Type	Broadcast
To Address (Hi Byte)	0x00 0x00 0x02
Command 1	0x11
Command 2	0x02

Command Example:

Wet Detected/Status	AA BB CC 00 00 02 CB 11 02

The above example is the command a Leak Sensor sends out after the SET Button has been pressed and the current status is Wet or if a Leak is detected. The To Address Low Byte contains the group (0x02), and Cmd1 is the On command (0x11).

```
02 50 21 7D B9 00 00 02 CB 11 02 INSTEON STD RX Wet Detected/Status
02 50 21 7D B9 00 00 02 CB 11 02 INSTEON STD RX Wet Detected/Status
02 50 21 7D B9 1A 77 7B 41 11 02 INSTEON STD RX
```



Heartbeat

This command is sent about once every 24 hours as a check that the device still has power.

Command Name	Heartbeat
Message Length	Standard Message (SD)
Message Type	Broadcast
To Address (Hi Byte)	0x00 0x00 0x04
Command 1	0x11 = dry; 0x13 = wet
Command 2	0x04

Command Example:

Heartbeat	AA BB CC 00 00 04 CB 11 04

The above example is the command a Leak Sensor sends out once about every 24 hours. The To Address Low Byte contains the group (0x04), and Cmd1 indicates the Leak Sensor is detecting dry status (0x11).

```
02 50 21 77 FC 00 00 04 CB 11 04 INSTEON STD RX
Heartbeat - Dry
02 50 21 77 FC 00 00 04 CB 11 04 INSTEON STD RX
Heartbeat - Dry
02 50 21 77 FC 11 00 04 CB 06 00 INSTEON STD RX
02 50 21 77 FC 11 00 04 CB 06 00 INSTEON STD RX
```



Messages Sent To – Leak Sensor

INSTEON Engine Version

This command requests the INSTEON Engine version of the device.

Command Name	INSTEON Engine Version
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x0D
Command 2	0x00

Command Name	INSTEON Engine Version Response	
Message Length	Standard Message (SD)	
Message Type	Ack	
Transmitting Device ID	Leak Sensor	
Receiving Device ID	Controller	
Flags Byte	Message Type	
Command 1	0x0D	
Command 2	0x02 (Indicates i2CS engine version)	

Command Example:

INSTEON Engine Version	AA	BB	CC	11	22	33	0F	0D	00
INSTEON Engine Version Response	11	22	33	AA	BB	CC	2B	0D	02

The above example device 11 22 33 is asked what it's Engine Version is(0x0D 0x00). Device 11 22 33 then responds back that it has an i2CS engine version(0x02).

```
9/24/2013 13:35:39.123 [RX] - 02 62 21 7D B9 0F 0D 00 06 INSTEON STD TX 02 50 21 7D B9 1A 77 7B 2B 0D 02 INSTEON STD RX i2CS Engine Version
```



Ping

This command checks that the device is able to respond over INSTEON.

Command Name	Ping
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x0F
Command 2	Ignored Value

Command Name	Ping Response	
Message Length	Standard Message (SD)	
Message Type	Ack	
Transmitting Device ID	Leak Sensor	
Receiving Device ID	Controller	
Flags Byte	Message Type	
Command 1	0x0F	
Command 2	Same as what was received in Command 2	

Command Example:

Ping	AA	вв	CC	11	22	33	0F	0F	00
Ping Response	11	22	33	AA	BB	CC	2B	0F	00

The above example is the communication that goes on between a Controller and the Leak Sensor when it is sent a Ping command. The device 11 22 33 is sent a Ping Command (0x0F). The device 11 22 33 then responds back to device AA BB CC with a Ping Response of the exact same thing it received in Command 1 and Command 2.

```
9/24/2013 13:35:40.329 [TX] - 02 62 21 7D B9 0F 0F 00 9/24/2013 13:35:40.355 [RX] - 02 62 21 7D B9 0F 0F 00 06 INSTEON STD TX 02 50 21 7D B9 1A 77 7B 2B 0F 00 INSTEON STD RX Ping Response
```



ID Request

This command asks for the device's Device category, Device Subcategory, Firmware Revision, and Hardware Revision. It is the same info the device sends when it goes into Linking Mode.

Command Name	ID Request
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x10
Command 2	Ignored Value

Command Name	ID Request Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x10
Command 2	Same as what was received in Command 2

Command Name	ID Request Data
Message Length	Standard Message (SD)
Message Type	Broadcast
Transmitting Device ID	Leak Sensor
To Address (Hi Byte)	Device Category
To Address (Mid Byte)	Device Subcategory
To Address (Low Byte)	Firmware Revision
Flags Byte	Message Type
Command 1	0x02
Command 2	Hardware Revision



Command Example:

ID Request	AA	вв	CC	11	22	33	0F	10	00
ID Request Response	11								
ID Request Data	11	22	33	10	80	89	8B	02	00

The above example is the communication that goes on between a Controller and the Leak Sensor when it is sent an ID Request command. The device 11 22 33 is sent an ID Request Command (0x10). The device 11 22 33 then responds back to device AA BB CC with a ID Request Response of the exact same thing it received in Command 1 and Command 2. The device 11 22 33 then responds back with the ID Request Data of Device category (0x10), Device subcategory (0x08), Firmware Revision (0x89), and the Hardware Revision (0x00). Essentially the devices sends out the exact same thing it sends out when it goes into Linking Mode without going into Linking Mode.

Docklight Example:

```
9/24/2013 13:35:42.539 [TX] - 02 62 21 7D B9 0F 10 00 9/24/2013 13:35:42.561 [RX] - 02 62 21 7D B9 0F 10 00 06 INSTEON STD TX 02 50 21 7D B9 1A 77 7B 2B 10 00 INSTEON STD RX ID Request 02 50 21 7D B9 10 08 89 8B 02 00 INSTEON STD RX Assign to ALL-Link Group/ID Request Response (Leak Sensor) 02 50 21 7D B9 10 08 89 8B 02 00 INSTEON STD RX Assign to ALL-Link Group/ID Request Response (Leak Sensor)
```

Read Configuration Byte

This command asks the device for its Configuration Byte.

Command Name	Read Configuration Byte
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x1F
Command 2	0x00

Command Name	Read Configuration Byte Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller



Flags Byte	Message Type
Command 1	0x1F
Command 2	Configuration Byte: bit 0 = Cleanup Report bit 1 = Don't Read the Jumper bit 2 = 2 Groups bit 3 = Repeat Open bit 4 = Repeat Closed bit 5 = LED On/Off bit 6 = Link to FF Group bit 7 = Programming Lock (0x4F is the default Config Byte)

Command Example:

Read Configuration Byte	AA	вв	CC	11	22	33	0F	1F	00
Read Configuration Byte Response	11	22	33	AA	BB	CC	2B	1F	4F

The above example device 11 22 33 is sent a command that asks it for its Configuration Byte (Command 1 = 0x1F, Command 2 = 0x00). Device 11 22 33 then responds back with its Configuration Byte (0x4F). This means that device 11 22 33 has Programming Lock Off, Link to FF Group On, LED On, Repeat Closed Off, Repeat Open On, 2 Groups On, Don't Read the Jumper On, and Cleanup Report On.

```
9/25/2013 10:32:33.354 [TX] - 02 62 21 7D B9 0F 1F 00 9/25/2013 10:32:33.367 [RX] - 02 62 21 7D B9 0F 1F 00 06 INSTEON STD TX Read Config Byte 02 50 21 7D B9 1A 77 7B 2B 1F 4F INSTEON STD RX
```



Database Delta

This command asks the device for its current Database Delta Number. The Database Delta increments with any database write. The Database Delta is cleared on power cycle.

Command Name	Database Delta
Message Length	Standard Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x1F
Command 2	0x01

Command Name	Database Delta Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x1F
Command 2	Database Delta

Command Example:

Database Delta	AA	BB	CC	11	22	33	0F	1F	01
Database Delta Response	11	22	33	AA	ВВ	CC	2B	1F	02

The above example device 11 22 33 is sent a command that asks it for its Database Delta (Command 1 = 0x1F, Command 2 = 0x01). Device 11 22 33 then responds back with its Database Delta (0x02). This means that device 11 22 33 has had two Database writes since its last power cycle.

```
9/13/2013 10:21:54.135 [TX] - 02 62 29 70 02 0F 1F 01
9/13/2013 10:21:54.161 [RX] - 02 62 29 70 02 0F 1F 01 06 INSTEON STD TX
02 50 29 70 02 1A 77 7B 2B 1F 01 INSTEON STD RX Database Delta
```



Remote Enter Linking Mode

This command puts the device into Linking Mode

Command Name	Remote Enter Linking Mode
Message Length	Extended Message (SD)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x09
Command 2	Group Number
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Remote Enter Linking Mode Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x09
Command 2	Same as what was received in Command 2



Command Name	Assign to ALL-Link Group
Message Length	Standard Message (SD)
Message Type	Broadcast
Transmitting Device ID	Leak Sensor
To Address (Hi Byte)	Device Category
To Address (Mid Byte)	Device Subcategory
To Address (Low Byte)	Firmware Revision
Flags Byte	Message Type
Command 1	0x02
Command 2	Hardware Revision

Command Example:

	AA 00	00	00	00	00	00	00	00	00	00	00	00
Remote Enter Linking Mode Response	11	22 22										
Assign to ALL-Link Group	11	22	33	01	3B	C/	88	02	00			

The the above example, device 11 22 33 is sent a command that tells it to go into Linking Mode (0x09) and to link to Group 1(0x01). Device 11 22 33 will ACK the command and then goes into Linking Mode.



Remote Exit Linking Mode

This command tells the device to exit linking mode.

Command Name	Remote Exit Linking Mode
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x08
Command 2	Ignored Value
Data 1 – Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Remote Exit Linking Mode Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x08
Command 2	Same as what was received in Command 2

Command Example:

Remote Exit Linking Mode	AA	ВВ	CC	11	22	33	1F	08	00	00	00	00	00
	00	00	00	00	00	00	00	00	00	F8			
Remote Exit Linking Mode Response	11	22	33	AA	BB	CC	2B	80	00				

The above example device 11 22 33 is sent a command that tells it to exit Linking Mode (0x08).



Get for Group/Button

This command asks the device for its Group/Button Data

Command Name	Get for Group/Button
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00
Data 1	0x00 -> 0xFF (Group/Button)
Data 2 – Data 14	0x00

Command Name	Get for Group/Button Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00



Command Name	Get for Group/Button Data
Message Length	Extended Message (ED)
Message Type	Broadcast
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00
Data 1	Same as what was received in Data 1
Data 2	0x01
Data 3	LED Intensity (Default is 0x64)
Data 4	0x01
Data 5	0x23
Data 6	Configuration Byte
Data 7 – Data 14	Ignored Values

Command Example:

Get for Group/Button					22							00	00
	00 11	00	00	00	00 DD	00	00	00 2E	00	00			
Get for Group/Button Response	11										01	64	01
Get for Group/Button Data	23	4F	00	00	00	00	00	00	00	00			

The above example, device 11 22 33 is sent a command that asks for its Get for Group/Button Data for Group 1(0x2E 0x00 0x01). Device 11 22 33 responds back with an LED brightness at default(0x64) and a Configuration Byte also at default(0x4F).

Docklight Example:

Return of Data



Set LED Brightness

This command sets the device's LED Brightness.

Command Name	Set LED Brightness
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00
Data 1	0x00 -> 0xFF (Group/Button)
Data 2	0x02
Data 3	0x00 -> 0xFF (Brightest)
Data 4 – Data 13	0x00
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Set LED Brightness Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00

Command Example:

Set LED Brightness	AA	BB	CC	11	22	33	1F	2E	00	01	02	FF	00
	00	00	00	00	00	00	00	00	00	D0			
Set LED Brightness Response	11	22	33	AA	вв	CC	2B	2E	00				

The above example, device 11 22 33 is sent a command that sets its LED Brightness to its max brightness (0x2E 0x00 0x01 0x02 0xFF).



Docklight Example:

02 50 21 7D B9 1A 77 7B 2B 2E 00 INSTEON STD RX



Stay Awake

This command tells the device to stay awake for the specified amount of time.

Command Name	Stay Awake
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00
Data 1	0x00 -> 0xFF (Group/Button)
Data 2	0x04
Data 3	0x00 -> 0xFF (Amount of seconds to stay awake)
Data 4 – Data 13	0x00
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Stay Awake Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00

Command Example:

Stay Awake	AA	BB	CC	11	22	33	1F	2E	00	01	04	F0	00
	00	00	00	00	00	00	00	00	00	DD			
Stay Awake Response	11	22	33	AA	BB	CC	2B	2E	00				

The above example, device 11 22 33 is sent a command that tells it to stay awake for about 4 minutes(0x2E 0x00 0x01 0x04 0xF0).



Docklight Example:

9/24/2013 16:03:57.50 [TX] - 02 62 21 7D B9 1F 2E 00 01 04 F0 00 00 00 00 00 00 00 00 00 00 DD 9/24/2013 16:03:57.51 [RX] - 02 62 21 7D B9 1F 2E 00 01 04 F0 00 00 00 00 00 00 00 00 00 00 DD 06 INSTEON EXT TX
Stay Awake - 4 Minutes
02 50 21 7D B9 1A 77 7B 2B 2E 00 INSTEON STD RX



Set Configuration Byte

This command sets the Configuration Byte to the specified settings.

Command Name	Set Configuration Byte
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00
Data 1	0x00 -> 0xFF (Group/Button)
Data 2	0x05
Data 3	Configuration Byte: bit 0 = Cleanup Report bit 1 = Don't Read the Jumper bit 2 = 2 Groups bit 3 = Repeat Open bit 4 = Repeat Closed bit 5 = LED On/Off bit 6 = Link to FF Group bit 7 = Programming Lock (0x4F is the default Config Byte)
Data 4 – Data 13	0x00
Data 14	Calculated Checksum (See below in Checksum Information)

Command Name	Set Configuration Byte Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2E
Command 2	0x00



Command Example:

Set Configuration Byte	AA	BB	CC	11	22	33	1F	2E	00	01	05	4F	00
	00	00	00	00	00	00	00	00	00	DD			
Set Configuration Byte Response	11	22	33	AA	BB	CC	2B	2E	00				

The above example, device 11 22 33 is sent a command that tells it to set its configuration to its default settings(0x2E 0x00 0x01 0x05 0x4F).

Docklight Example:

9/25/2013 11:05:49.52 [TX] - 02 62 21 7D B9 1F 2E 00 01 05 4F 00 00 00 00 00 00 00 00 00 00 7D 9/25/2013 11:05:49.54 [RX] - 02 62 21 7D B9 1F 2E 00 01 05 4F 00 00 00 00 00 00 00 00 00 7D 06 INSTEON EXT TX

02 50 21 7D B9 1A 77 7B 2B 2E 00 INSTEON STD RX



Appendix

Checksum Information

For Set Database, Set Properties and 0x20, Data14 will contain a 2s compliment of cmd1 through 2nd to last data record in the last data record.

Example of Checksum:

Message for Checksum Example	AA	BB	CC	11	22	33	1F	2E	00	01	05	FF	00
	00	00	00	00	00	00	00	00	00	DD			

The above example, device 11 22 33 is sent a command that requires a checksum in Data 14. The checksum is calculated by summing all the values from Command 1 to Data 13(0x2E + 0x01 + 0x05 + 0xFF = 0x133). We then calculate the compliment of the last byte(0x33 compliment = 0xCC). Then we add 1(0x01) to find the checksum for Data 14(0xCC + 0x01 = checksum = 0xCD).



Memory Map

All-Link Database (AL /L) Overview

The AL /L starts at the top of external (serial) EEPROM and grows downward. In the INSTEON LED Bulb, top of memory is 0x0FFF. Each AL /L Record is 8 bytes long, so the first record starts at 0x0FF8, the second record starts at 0x0FF0, and so on down to 0x0300 for a total of 416 links. In what follows, the 3-byte INSTEON Address contained in a record is called the *Device ID* or sometimes just the *ID*. The high byte (MSB) of the Device ID is *ID2*, the middle byte is *ID1*, and the low byte (LSB) is *ID0*.

EEPROM Structure Overview

Location	Comments
0x0FF8	All-Link Database Record
0x0FF0	Ack
0x0FD8	Leak Sensor
	Controller
0x0300	Last Record, 416 total links allowed
0x02xx	Addressing below 0x0300 is ignored by the database

AL/L Record Format

INSTEON Leak Sensor AL Record Format

Database entries with Record Control Bit 6: 0 = Responder and Group 1 will control the local load.

Field	Description
Record Control	Record Control Flag Bits:
	Bit7: 1 = Record is in use, 0 = Record is available
	Bit 6: 0 = Responder to (Slave of) Device ID
	Bit 5: Not Used
	Bit 4 & Bit 3: SmartHops (Keeps track of what the start hop should be)
	Bit 2: Not Used
	Bit 1: 1 = Record has been used before, 0 = High Water Mark
	Bit 0: Not Used
Group	All-Link Group Number this Device ID belongs to
ID	Device ID
Data 1	On Level
Data 2	Ramp Rate
Data 3	Not Used



To add a record to an AL /L, you search for an existing record that is marked available. (Available means the same as empty, unused or deleted.) If none is available, you create a new record at the end of the AL /L.

An unused record will have bit 7 of the *Record Control* byte set to zero. The last record in an AL /L will have bit 1 of the *Record Control* byte set to zero.

Overwriting an Empty AL /L Record

If you found an empty record, you simply overwrite it with your new record data.

Change bit 7 of the Record Control byte from zero to one to show that the record is now in use.

Set bit 6 of the *Record Control* byte to one if the device containing the AL /L is an INSTEON Controller of the INSTEON Responder Device whose *ID* is in the record. If instead the device containing the AL /L is an INSTEON Responder to the INSTEON Controller Device whose *ID* is in the record, then clear bit 6 of the *Record Control* byte to zero. In other words, within an AL /L, setting bit 6 means "I'm a Controller," and clearing bit 6 means "I'm a Responder."

Put the ALL-Link Group number in the *Group* field, and put the *Device ID* in the *ID* field. Finally, set the *Data 1*, *Data 2*, and *Data 3* fields appropriately for the *Record Class* you are storing.

Creating a New AL/L Record

To create a new record at the end of the AL /T, find the record with bit 1 of the *Record Control* byte set to zero, indicating that it is the last record in the AL /L. Flip that bit to one.



Get Database

This command asks the device for a record in its database or the entire database.

Command Name	Get Database
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x2F
Command 2	0x00
Data 1	Ignored Value
Data 2	0x00
Data 3	0x00 -> 0xFF (Hi Byte Address)
Data 4	0x00 -> 0xFF (Lo Byte Address)
Data 5	0x00 -> 0xFF (# of Records, 0x00 dumps all records)
Data 6 – Data 14	Ignored Value

Command Name	Get Database Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2F
Command 2	0x00



Command Name	Get Database Data
Message Length	Extended Message (ED)
Message Type	Broadcast
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2F
Command 2	0x00
Data 1	0x00
Data 2	0x01
Data 3	0x00 -> 0xFF (Hi Byte Address)
Data 4	0x00 -> 0xFF (Lo Byte Address)
Data 5	0x00
Data 6	Link Type Byte: Bit 0 = 0 Bit 1 = High Water (Marks the highest record used in the database) Bit 2 = 0 Bit 3 & Bit 4 = SmartHop (Keeps track of what the start hop should be) Bit 5 = 1 Bit 6 = Controls Me=0; I Control=1 Bit 7 = Inactive=0; Active=1
Data 7	Group Number of Link
Data 8	Linked Device ID (Hi Byte)
Data 9	Linked Device ID (Mid Byte)
Data 10	Linked Device ID (Lo Byte)
Data 11	On-Level of Link
Data 12	Ramp Rate of Link
Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)



Command Name	Empty Record
Message Length	Extended Message (ED)
Message Type	Broadcast
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2F
Command 2	0x00
Data 1	0x00
Data 2	0x01
Data 3	0x00 -> 0xFF (Hi Byte Address)
Data 4	0x00 -> 0xFF (Lo Byte Address)
Data 5	0x00
Data 6	0x00
Data 7	0x00
Data 8	0x00
Data 9	0x00
Data 10	0x00
Data 11	0x00
Data 12	0x00
Data 13	0x00
Data 14	Calculated Checksum (See below in Checksum Information)

Command Example:

·																
Get Database	AA	вв	CC	11	22	33	1F	2F	00	00	00	00	00	00	00	00
	00	00	00	00	00	00	00									
Get Database Response	11	22	33	AA	BB	CC	2B	2F	00							
Get Database Data	11	22	33	AA	BB	CC	11	2F	00	00	01	0F	FF	00	A2	00
Get Database Data	11	CC	AB	FF	1F	01	79									
	11	22	33	AA	BB	CC	11	2F	00	00	01	0F	F7	00	00	00
Empty Record	00	00	00	00	00	00	CA									



The above example, device 11 22 33 is sent a command that asks it for its entire database (0x2F 0x00 0x00 0x00 0x00 0x00 0x00). Device 11 22 33 Acks the command then sends out its first database record (0x0F 0xFF). The next spot is an empty record so the device stops sending out its database (0x0F 0xF7).



Set Database

This command writes a record to the device's database.

Command Name	Set Database
Message Length	Extended Message (ED)
Message Type	Direct
Transmitting Device ID	Controller
Receiving Device ID	Leak Sensor
Flags Byte	Message Type
Command 1	0x2F
Command 2	0x00
Data 1	Ignored Value
Data 2	0x02
Data 3	0x00 -> 0xFF (Hi Byte Address)
Data 4	0x00 -> 0xFF (Lo Byte Address)
Data 5	0x01 -> 0x08 (# of bytes to write, over 0x08 is an error and ignored)
Data 6	
Data 7	Group Number of Link
Data 8	Linked Device ID (Hi Byte)
Data 9	Linked Device ID (Mid Byte)
Data 10	Linked Device ID (Lo Byte)
Data 11	On-Level of Link
Data 12	Ramp Rate of Link
Data 13	Ignored Value
Data 14	Calculated Checksum (See below in Checksum Information)



Command Name	Set Database Response
Message Length	Standard Message (SD)
Message Type	Ack
Transmitting Device ID	Leak Sensor
Receiving Device ID	Controller
Flags Byte	Message Type
Command 1	0x2F
Command 2	0x00

Command Example:

Set Database	AA	BB	CC	11	22	33	1F	2F	00	00	02	0F	F7
	80	AA	00	18	A1	C5	00	1C	00	7D			
Set Database Response	11	22	33	AA	BB	CC	2B	2F	00				

The above example, device 11 22 33 is sent a command that writes a record to its database at location 0x0F 0xF7 (0x2F 0x00 0x00 0x02 0x0F 0xF7)

```
9/24/2013 09:41:43.127 [TX] - 02 62 29 70 02 1F 2F 00 00 02 0F F7 08 AA 00 18 A1 C5 00 1C 00 7D 9/24/2013 09:41:43.146 [RX] - 02 62 29 70 02 1F 2F 00 00 02 0F F7 08 AA 00 18 A1 C5 00 1C 00 7D 06 INSTEON EXT TX Set Database 02 50 29 70 02 1A 77 7B 2B 2F 00 INSTEON STD RX
```