#### Kernel Probes for ARM

Quentin Barnes q.barnes@motorola.com Motorola - Mobile Devices April 17, 2007

#### Overview

- Introduction to kernel probes
- How kernel probes work
- The classic kprobe model and 'boosting'
- Difficulties with the classic model and ARM
- New approach used for ARM
  - Details of implementation
  - Cost and Performance
- Wrap-up

#### Kernel Probes Introduction

- New with 2.6.9-rc2 kernels
  - Currently: avr32, i386, x86\_64, ia64, powerpc, sparc64, s390
- Allows dynamic breakpoints (registered at runtime) to be placed most anywhere in kernel
- Breakpoint transfers control to user specified handlers, executes the instruction, and returns
- User handlers often used to aid debugging or collect performance data
- Can be relatively low overhead

#### Types of Kernel Probes

- Kprobes "Kernel Probes"
  - Places breakpoint at symbol plus offset or address
- Jprobes "Jumper Probes"
  - Insert function call ahead of probed function
- Kretprobes "Return Probes"
  - Probe function's return
- Djprobes "Dynamic Jump Probes"
  - Future direction: Kprobe-like, uses a jump instruction rather than a breakpoint

### How Do Kprobes Work?


- Places a breakpoint instruction most anywhere
  - On ARM, uses an undefined instruction
- May register optional user pre-, post-, break, and fault handlers
  - User handlers can do most things except block
- More than one Kprobe allowed at one address
  - Not so for Jprobes and Kretprobes

# 'Classic' Kprobes Model

### Kprobes Registration & Prep

- Do symbol lookup, if necessary
- Validate address
- Record probe and address for hash lookup
- Save instruction at address and replace it with a breakpoint instruction
- Allocate and initialize instruction slot
- Do additional architecture specific initialization

# Executing a Kprobe




#### Issues with Classic Model

- High execution overhead two exceptions and four full context switches
- Holds interrupts disabled through entire length
  - Some re-enable though resulting in possible unbounded recursion, unpredictable behavior, and skipped user handlers

### Performance Gain - 'Boosting'

- Take one exception instead of two
- Boosting short-circuits the second exception for pre-determined instructions by jumping directly back after execution



#### **Boosting Limitations**

- Limited to only 'boostable' instructions
  - No conditional jumps and no reserved or special instructions
- Non-boostable instructions still run classic way (using two exceptions)
- Use of post-handlers disable boosting still running classic way
- Garbage collector

### Boosting's Garbage Collector

- Boosting holds lock on instruction slot even after execution completes
- Garbage collector needed to clean up unused locks
- When kernel preemption is enabled, garbage collector disables all interrupts and freezes all kernel threads across all CPUs simultaneously to run its O(n) time algorithm

#### Difficulties with Kprobes & ARM

- No single-stepping supported in the processor
  - Single-stepping causes the processor to trigger an exception after completing the current instruction
- No Next-PC register
  - The Next-PC register steps the processor to the "next" address after completing the current instruction

### ARM Difficulties (cont.)

- So no way to regain control of the ARM processor after executing instructions that alter the PC without decoding, detecting, and handling all instructions that can write the PC
- No way to give correct results for instructions that read the PC without decoding, detecting, and handling
- Once you've gone that far already, it's not that much further to a new approach

# New Kprobes Approach

### New Kprobes Goals


- Do as much prep work as possible during registration of a kprobe to reduce its execution overhead
- Complete the kprobe'd instruction and all its side-effects before returning from first (and only) exception
- Provide consistent execution and behavior
- Don't hold any locks longer than necessary

### New Kprobes Advantages

- Fully self-contained within arch, no changes to generic Kprobes code needed
- Can work for all instructions, not just some
- Always works, regardless of post-handlers
- No second exception ever, so all that support code and additional logic goes away
- No locks left dangling so no headaches and no garbage collector

### Advantages (cont.)

- Interrupts disabled throughout single exception
  - No unbounded recursion
  - User handlers guaranteed to be called unless a handler itself triggers recursion by having a kprobe
- Very light-weight
  - Small code size
  - Low execution overhead
- MP and Preemptive (CONFIG\_PREEMPT) clean



### How Does \*insn\_handler() Work?

- At registration time:
  - Depending on the form of the kprobe'd instruction, an instruction execution handler is assigned
  - Registers used by the instruction are recoded to use the registers the instruction handler expects
  - Modified instruction or condition code test instruction saved to instruction slot
- Two groups of instruction handlers ones that execute a modified form and ones that resolve the instruction in straight C code
  - C-only ones are for instructions that write the PC

#### Instruction Handler: Example 1

- Kprobe'd instruction "blne addr"
- Modified instruction in slot "movne r0, #1"
- Handler assigned simulate\_bbl()
  - 25 total instructions

#### simulate\_bbl()

```
static void __kprobes simulate_bbl(struct kprobe *p, struct pt_regs *regs)
{
    insn_1arg_fn_t *i_fn = (insn_1arg_fn_t *)&p->ainsn.insn[0];
    kprobe_opcode_t insn = p->opcode;
    long    iaddr = (long)p->addr;
    int     disp = branch_displacement(insn);

    if (!insnslot_1arg_rflags(0, regs->ARM_cpsr, i_fn)) return;

    if (insn & (1 << 24)) regs->ARM_lr = iaddr + 4;

    regs->ARM_pc = iaddr + 8 + disp;
}
```

- All in C since "bl" writes to the PC
- Handles both "b" (branch) & "bl" (branch & link)
- Could have been two handlers

# insnslot\_1arg\_rflags()

```
static inline long <u>__kprobes insnslot_1arg_rflags(long r0, long cpsr</u>,
                                     insn 1arq fn t *fn)
      register long rr0 asm("r0") = r0;
      register long ret asm("r0");
        _asm___ volatile(
            "msr cpsr_fs, %[cpsr]
                                          \n\t"
            "mov lr, pc
                                           \n\t"
            "mov pc, %[fn]
                                           \n\t"
            : "=r" (ret)
            : "0" (rr0), [cpsr] "r" (cpsr), [fn] "r" (fn)
            : "Ir", "cc"
      return ret;
```

## insnslot\_1arg\_rwflags()

```
static inline long __kprobes insnslot_1arg_rwflags(long r0, long *cpsr,
                                         insn_1arg_fn_t *fn)
{
      register long rr0 asm("r0") = r0;
      register long ret asm("r0");
      long oldcpsr = *cpsr;
      long newcpsr;
        _asm___ volatile(
           "msr cpsr_fs, %[oldcpsr] \n\t"
            "mov lr, pc
                                          \n\t"
           "mov pc, %[fn]
                                          \n\t"
           "mrs %[newcpsr], cpsr
                                          \n\t"
           : "=r" (ret), [newcpsr] "=r" (newcpsr)
           : "0" (rr0), [oldcpsr] "r" (oldcpsr), [fn] "r" (fn)
           : "Ir", "cc"
      ^{\circ}cpsr = (oldcpsr & ~PSR_fs) | (newcpsr & PSR_fs);
     return ret;
```

#### Instruction Handler: Example 2

- Kprobe'd instruction "add r3,r6, #7"
- Modified instruction "add r0, r0, #7"
- Handler assigned emulate\_alu\_imm\_rflags()
  - 19 total instructions

### emulate\_alu\_imm\_rflags()

```
static void <u>__kprobes emulate_alu_imm_rflags(struct kprobe *p</u>,
                                  struct pt_regs *regs)
     insn_1arg_fn_t *i_fn = (insn_1arg_fn_t *)&p->ainsn.insn[0];
     kprobe_opcode_t insn = p->opcode;
     int rd = (insn >> 12) & 0xf;
     int rn = (insn >> 16) & 0xf;
     long rnv = (rn == 15) ? (long)p->addr + 8 : regs->uregs[rn];
     regs->uregs[rd] = insnslot_1arg_rflags(rnv, regs->ARM_cpsr, i_fn);;
```

### Isn't It Expensive?

- Twenty-seven instruction handlers (5 sim + 22 emul) cover virtually all ARM instructions
- Most instruction handlers compile down to just 10-40 instructions
- The ARM Kprobes is 6.6KB of code
- With no second exception ever and no boosting, all that support code is tossed away

#### Overhead Performance

- Overhead results on PXA270@364.00MHz
  - Kprobe: 1.21us
  - Jprobe: 3.11us
  - Kretprobe: 3.40us
  - Kprobe + Kretprobe: 3.81us
  - Jprobe + Kretprobe: 5.86us

 Measured with Jim Keniston's kprobe overhead testing software with defaults (iter=5000000, handler=1)

#### So What's the Catch?

- Uses a lot of decode decision paths and some handlers infrequently used, so needs extensive testing and chance of latent bugs
- Technique is easiest for RISC and orthogonal instruction sets, but could be harder for others

#### State of the Port

- Kprobes, Kretprobes, and Jprobes complete and all working
- Some bugs still running around
- Some rare and unusual instructions not supported – ones that change CPSR state
- Patches for 2.6.20.4 kernel released to Systemtap/Kprobes mailing list on 4/11/07

#### What's Left

- Shakeout of approach and code
- Test suite to test all decode paths and instruction execution handlers
- Integrate into ARM Linux and kernel.org trees
- Finish port of Systemtap's runtime and test suite to ARM and modify Systemtap to support cross-compiles
- Djprobe version

## What's Left? (cont.)

- Remember for the new Kprobes I said one of the goals was to do as much prep work as possible? I'm not quite doing that yet...
- Use larger instruction slots, do more at registration and less at runtime:

Original Inst	add	r3, r6, #7
Instruction slot	ldr add str mov	r1, [r0, #24] r1, r1, #7 r1, [r0, #12] pc, Ir

### Systemtap

- User space front end to Kprobes
- Simple command line interface and scripting language
- Does it all compiles script to C code, builds, loads, and runs the kernel module

#### **URLs**

- Systemtap:
  - Home: http://sourceware.org/systemtap/
  - Mailing list: http://sourceware.org/ml/systemtap/
- Motorola Open Source
  - http://opensource.motorola.com/

#### Questions?