

Neon Programmer Guide for Armv8-A

4.0

Coding for Neon

Non-Confidential

Issue 02

Copyright © 2020, 2022 Arm Limited (or its affiliates). 102159_0400_02_en All rights reserved.



Neon Programmer Guide for Armv8-A

Coding for Neon

Copyright © 2020, 2022 Arm Limited (or its affiliates). All rights reserved.

Release information

Document history

Issue	Date	Confidentiality	Change
0100- 01	5 July 2020	Non- Confidential	First release
0200- 01	17 August 2020	Non- Confidential	Second release. Added sections on load and store leftovers, and permutation instructions.
0300- 01	17 September 2020	Non- Confidential	Third release. Added section on matrix multiplication.
0400- 01	15 December 2020	Non- Confidential	Fourth release. Added section on shifts.
0400- 02	17 July 2022	Non- Confidential	Fix minor issues in Permutation - Neon instructions section

Proprietary Notice

This document is protected by copyright and other related rights and the practice or implementation of the information contained in this document may be protected by one or more patents or pending patent applications. No part of this document may be reproduced in any form by any means without the express prior written permission of Arm. No license, express or implied, by estoppel or otherwise to any intellectual property rights is granted by this document unless specifically stated.

Your access to the information in this document is conditional upon your acceptance that you will not use or permit others to use the information for the purposes of determining whether implementations infringe any third party patents.

THIS DOCUMENT IS PROVIDED "AS IS". ARM PROVIDES NO REPRESENTATIONS AND NO WARRANTIES, EXPRESS, IMPLIED OR STATUTORY, INCLUDING, WITHOUT LIMITATION, THE IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTORY QUALITY, NON-INFRINGEMENT OR FITNESS FOR A PARTICULAR PURPOSE WITH RESPECT TO THE DOCUMENT. For the avoidance of doubt, Arm makes no representation with respect to, has

undertaken no analysis to identify or understand the scope and content of, third party patents, copyrights, trade secrets, or other rights.

This document may include technical inaccuracies or typographical errors.

TO THE EXTENT NOT PROHIBITED BY LAW, IN NO EVENT WILL ARM BE LIABLE FOR ANY DAMAGES, INCLUDING WITHOUT LIMITATION ANY DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, OR CONSEQUENTIAL DAMAGES, HOWEVER CAUSED AND REGARDLESS OF THE THEORY OF LIABILITY, ARISING OUT OF ANY USE OF THIS DOCUMENT, EVEN IF ARM HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

This document consists solely of commercial items. You shall be responsible for ensuring that any use, duplication or disclosure of this document complies fully with any relevant export laws and regulations to assure that this document or any portion thereof is not exported, directly or indirectly, in violation of such export laws. Use of the word "partner" in reference to Arm's customers is not intended to create or refer to any partnership relationship with any other company. Arm may make changes to this document at any time and without notice.

This document may be translated into other languages for convenience, and you agree that if there is any conflict between the English version of this document and any translation, the terms of the English version of the Agreement shall prevail.

The Arm corporate logo and words marked with ® or ™ are registered trademarks or trademarks of Arm Limited (or its subsidiaries) in the US and/or elsewhere. All rights reserved. Other brands and names mentioned in this document may be the trademarks of their respective owners. Please follow Arm's trademark usage guidelines at https://www.arm.com/company/policies/trademarks.

Copyright © 2020, 2022 Arm Limited (or its affiliates). All rights reserved.

Arm Limited. Company 02557590 registered in England.

110 Fulbourn Road, Cambridge, England CB1 9NJ.

(LES-PRE-20349)

Confidentiality Status

This document is Non-Confidential. The right to use, copy and disclose this document may be subject to license restrictions in accordance with the terms of the agreement entered into by Arm and the party that Arm delivered this document to.

Unrestricted Access is an Arm internal classification.

Product Status

The information in this document is Final, that is for a developed product.

Feedback

Arm® welcomes feedback on this product and its documentation. To provide feedback on the product, create a ticket on https://support.developer.arm.com

To provide feedback on the document, fill the following survey: https://developer.arm.com/documentation-feedback-survey.

Inclusive language commitment

Arm values inclusive communities. Arm recognizes that we and our industry have used language that can be offensive. Arm strives to lead the industry and create change.

We believe that this document contains no offensive language. To report offensive language in this document, email terms@arm.com.

Contents

1. Overview	6
2. Load and store - example RGB conversion	7
3. Load and store - data structures	9
4. Load and store - leftovers	15
5. Permutation - rearranging vectors	23
6. Permutation - Neon instructions	25
7. Matrix multiplication	36
8. Shifting left and right	43
9. Related information	49

Overview

1. Overview

Arm Neon technology is a 64-bit or 128-bit hybrid Single Instruction Multiple Data (SIMD) architecture that is designed to accelerate the performance of multimedia and signal processing applications. These applications include the following:

- Video encoding and decoding
- Audio encoding and decoding
- 3D graphics processing
- Speech processing
- Image processing

This guide provides information about how to write SIMD code for Neon using assembly language. This guide is written for anyone wanting to learn more about the Armv8-A instruction set architecture. The following readers should find the information particularly useful:

- Tools developers
- Low-level SoC programmers, such as firmware, device driver, or android kernel developers
- Programmers who want to optimize libraries or applications for an Arm-based target device
- Very keen Raspberry Pi enthusiasts

This guide covers getting started with Neon, using it efficiently, and hints and tips for more experienced coders. Specifically, this guide deals with the following subject areas:

- Memory operations, and how to use the flexible load and store instructions.
- Using the permutation instructions to deal with load and store leftovers.
- Using Neon to perform an example data processing task, matrix multiplication.
- Shifting operations, using the example of converting image data formats.

Load and store - example RGB conversion

2. Load and store - example RGB conversion

This section considers an example task of converting RGB data to BGR color data.

In a 24-bit RGB image, the pixels are arranged in memory as R, G, B, R, G, B, and so on. You want to perform a simple image-processing operation, like switching the red and blue channels. How can you do this efficiently using Neon?

Using a load that pulls RGB data items sequentially from memory into registers makes swapping the red and blue channels awkward.

Consider the following instruction, which loads RGB data one byte at a time from memory into consecutive lanes of three Neon registers:

```
LD1 { V0.16B, V1.16B, V2.16B }, [x0]
```

The following diagram shows the operation of this instruction:

Figure 2-1: Loading data one byte at a time with LD1



Code to swap channels based on this input would be complicated. We would need to mask different lanes to obtain the different color components, then shift those components and recombine. The resulting code is unlikely to be efficient.

Neon provides structure load and store instructions to help in these situations. These instructions pull in data from memory and simultaneously separate the loaded values into different registers. For this example, you can use the LD3 instruction to separate the red, green, and blue data values into different Neon registers as they are loaded:

```
LD3 { V0.16B, V1.16B, V2.16B }, [x0]
```

Load and store - example RGB conversion

The following diagram shows how the above instruction separates the different data channels:

Figure 2-2: Loading RGB data simultaneously with LD1



The red and blue values can now be switched easily using the Mov instruction to copy the entire vector. Finally, we write the data back to memory, with reinterleaving, using the sts store instruction.

A single iteration of this RGB to BGR switch can be coded as follows:

```
LD3
     { V0.16B, V1.16B, V2.16B }, [x0], #48
                                             // 3-way interleaved load from
                                             // address in XO, post-incremented
                                             // by 48
                                                Swap V0 -> V3
VOM
       V3.16B, V0.16B
       V0.16B, V2.16B
                                             // Swap V2 -> V0
MOV
       V2.16B, V3.16B
                                             // Swap V3 -> V2
MOV
                                                (net effect is to swap V0 and V2)
     { V0.16B, V1.16B, V2.16B }, [x1], #48
                                                3-way interleaved store to address
ST3
                                             // in X1, post-incremented by 48
```

Each iteration of this code does the following:

- Loads from memory 16 red bytes into V0, 16 green bytes into V1, and 16 blue bytes into V2.
- Increments the source pointer in XO by 48 bytes ready for the next iteration. The increment of 48 bytes is the total number of bytes that we read into all three registers, so 3 x 16 bytes in total.
- Swaps the vector of red values in V0 with the vector of blue values in V2, using V3 as an intermediary.
- Stores the data in V0, V1, and V2 to memory, starting at the address that is specified by the destination pointer in X1, and increments the pointer.


Load and store - data structures

3. Load and store - data structures

Neon structure load instructions read data from memory into 64-bit Neon registers, with optional deinterleaving.

Structure store instructions work similarly, reinterleaving data from registers before writing it to memory, as shown in the following diagram:

Figure 3-1: Interleaving store with ST3




Syntax

The structure load and store instructions follow a consistent syntax.

The following diagram shows the general syntax of the structure load and store instructions:

Figure 3-2: Syntax of Neon structure load and store instructions



This instruction syntax has the following format:

• An instruction mnemonic, with two parts:

- The operation, either LD for loads or ST for stores.
- A numeric interleave pattern specifying the number of elements in each structure.
- A set of 64-bit Neon registers to be read or written. A maximum of four registers can be listed, depending on the interleave pattern. Each entry in the set of Neon registers has two parts:
 - The Neon register name, for example vo.
 - An arrangement specifier. This indicates the number of bits in each element and the number of elements that can fit in the Neon vector register. For example, 16β indicates that each element is one byte (β), and each vector is a 128-bit vector containing 16 elements.
- A general-purpose register containing the location to access in memory. The address can be updated after the access.

Interleave pattern

Neon provides instructions to load and store interleaved structures containing from one to four equally sized elements. Elements are the standard Neon-supported widths of 8 (B), 16 (H), 32 (S), or 64 (D) bits.

- LD1 is the simplest form. It loads one to four registers of data from memory, with no deinterleaving. You can use LD1 to process an array of non-interleaved data.
- LD2 loads two or four registers of data, deinterleaving even and odd elements into those registers. You can use LD2 to separate stereo audio data into left and right channels.
- LD3 loads three registers and deinterleaves. You can use LD3 to split RGB pixel data into separate color channels.
- LD4 loads four registers and deinterleaves. You can use LD4 to process ARGB image data.

The store instructions st1, st2, st3, and st4 support the same options, but interleave the data from registers before writing them to memory.

Element types

Loads and stores interleave elements based on the size that is specified to the instruction.


For example, consider the following instruction:

LD2 {V0.8H, V1.8H}, [X0]

This instruction loads two Neon registers with deinterleaved data starting from the memory address in XO. The 8H in the arrangement specifier indicates that each element is a 16-bit halfword (H), and each Neon register is loaded with eight elements. This instruction therefore results in eight 16-bit elements in the first register VO, and eight 16-bit elements in the second register V1. Adjacent pairs (even and odd) are separated to each register, as shown in the following diagram:

Load and store - data structures

Figure 3-3: Neon 16-bit 2-way interleaved load




The following instruction uses the arrangement specifier 4s, changing the element size to 32-bits:

```
LD2 {V0.4S, V1.4S}, [X0]
```

Changing the element size to 32-bits loads the same amount of data, but now only four elements make up each vector, as shown in the following diagram:

Figure 3-4: Neon 32-bit 2-way interleaved load



4.0 Load and store - data structures

Element size also affects endianness handling. In general, if you specify the correct element size to the load and store instructions, bytes are read from memory in the appropriate order. This means that the same code works on little-endian systems and big-endian systems.

Finally, element size has an impact on pointer alignment. Alignment to the element size generally gives better performance, and it might be a requirement of your target operating system. For example, when loading 32-bit elements, align the address of the first element to at least 32-bits.

Single or multiple elements


In addition to loading multiple elements, structure loads can also read single elements from memory with deinterleaving. Data can either be replicated to all lanes of a Neon register, or inserted into a single lane, leaving the other lanes intact.

For example, the following instruction loads a single three-element data structure from the memory address pointed to by XO, then replicates that data into all lanes of three Neon registers:

```
LD3R { V0.16B, V1.16B, V2.16B } , [x0]
```

The following diagram shows the operation of this instruction:

Figure 3-5: Load single 3-element structure and replicate



By contrast, the following instruction loads a single three-element data structure into a single lane of three Neon registers, leaving the other lanes intact:

```
LD3 { V0.B, V1.B, V2.B }[4] , [x0]
```

The following diagram shows the operation of this instruction. This form of the load instruction is useful when you need to construct a vector from data scattered in memory.

Load and store - data structures

Memory LD3 { V0.B, V1.B, V2.B }[4] , [x0] 0x0RO 0x1 G0 0x2 ВО 0x30x4G1 V0 0x5**B1** 0x6 0x7 G2 G0 V1 0x8 B2 772

Figure 3-6: Load single 3-element structure to one lane

Stores are similar, providing support for writing single or multiple elements with interleaving.

Addressing

Structure load and store instructions support three formats for specifying addresses:

- Register (no offset): $\[x_n\]$ This is the simplest form. Data is loaded addition stored to the address that is specified by Xn.
- Register with post-index, immediate offset: \[xn\], #imm Use this form to update the pointer in Xn after loading or storing, ready to load or store the next elements. The immediate increment value #imm must be equal to the number of bytes that is read or written by the instruction. For example, the following instruction loads 48 bytes of data, using three registers, each containing 16 x 1 byte data elements. This means that the immediate increment is 48:

```
LD3 { V0.16B, V1.16B, V2.16B }, [x0], #48
```

However, the next example loads 32 bytes of data, using two registers, each containing 2 x 8 byte data elements. This means that the immediate increment is 32:

```
LD2 { V0.2D, V1.2D}, [x0], #32
```

• Register with post-index, register offset: \[xn\], xm After the memory access, increment the pointer by the value in register Xm. This form is useful when reading or writing groups of elements that are separated by fixed widths, for example when reading a vertical line of data from an image.

Other types of loads and stores

This guide only deals with structure loads and stores. However, Neon also provides other types of load and store instruction, including:

- LDR and STR to load and store single Neon registers.
- LDP and STP to load or store pairs of Neon registers.

For more details on supported load and store operations, see the Arm Architecture Reference Manual.

Detailed cycle timing information for the instructions can be found in the Technical Reference Manual for each core.

4. Load and store - leftovers

A common situation when coding for Neon is dealing with input data that is not an exact multiple of the number of lanes in the vector register.

For example, consider an input array that contains 21 data elements, each of which is a 16-bit integer. You want to use Neon to process the data in this array. Neon registers are 128 bits wide, so can process eight lanes of 16-bit data at a time. In two iterations, your Neon code can process 16 (2 x 8) data elements. However, this leaves five leftover data elements to process in the final iteration. These five leftover data elements are not enough to completely fill a Neon register.

There are three approaches that you can take to handle these leftovers. Which method to choose depends on your requirements. The three approaches are as follows, with the fastest approach listed first:

- Extend arrays with padding
- Overlap data elements
- Process leftovers as single elements

Extend arrays with padding

If you can change the size of the arrays, you can increase the length of the array to the next multiple of the vector size using padding elements. This allows you to read and write beyond the end of your data without corrupting adjacent storage.

In our example with 21 data elements, increasing the array size to 24 elements allows the third iteration to complete without potential data corruption.

The following diagram shows how the three iterations load eight data elements into the Neon register. The final iteration loads the three padding elements along with the final five array values:

Load and store - leftovers




Figure 4-1: Handling leftover elements by extending with padding

The gray data elements in the diagram represent padding values, and the green data elements are the original 21 array values.

Be careful to choose padding values that do not affect the result of your calculation. For example:

- If you are summing array values, use a padding value of zero.
- If you are finding the minimum value in an array, use a padding value of the maximum value that the data element can contain.

It might not be possible to choose a padding value that does not affect the result of your calculation. For example, when calculating the range of an array of numbers any padding value you choose could affect the result. In these cases, do not use this method.



LD1 {V0.8H}, [X0], #16

Allocating larger arrays consumes more memory. The increase could be significant if many short arrays are involved.

The following code shows how you could implement a solution that extends arrays with padding:

Load and store - leftovers

```
// by X0 into V0, and update X0 to point to the // next vector

//...

//...

Process the data for this iteration

ST1 { V0.8H } , [X1], #16 // Write eight elements to the output array, and // update X1 to point to next vector

SUBS X2, X2, #1 // Decrement the loop counter and set flags B.NE loop // Branch back if count is not yet zero...

RET // ... otherwise return
```

Overlap data elements

If the operation is suitable, leftover elements can be handled by overlapping those elements. Overlapping means processing some of the elements in the array twice.


In the example case, the iterations that use overlap would follow these steps:

- 1. The first iteration processes elements zero to seven.
- 2. The second iteration processes elements five to 12.
- 3. The third and final iteration processes elements 13-20.

Note that elements five to seven, which are the overlap between the first vector and the second vector, are processed twice.

The following diagram shows how all three iterations load eight data elements into the Neon register, with the first and second iterations operating on overlapping vectors:

Figure 4-2: Handling leftover elements by overlapping



Load and store - leftovers

The blue data elements represent the overlapping elements that are processed twice. The green data elements are the original 21 array values.

You can only use overlaps when the operation applied to the input data does not vary with the number of times that the operation is applied. The technical term is to say that the operation must be idempotent. For example, if you are trying to find the maximum element in an array, you can use overlaps. This is because it does not matter if the maximum value appears more than once. However, if you are summing an array, you cannot use overlaps. This is because the overlapping elements would be counted twice.



The number of elements in the array must fill at least one complete vector.

The following code shows how you could implement a solution that extends arrays with padding:

```
// Function entry point
     X0 = input array pointer
      X1 = output array pointer
      X2 = number of elements in array
process array:
  ANDS \overline{X}3, X^2, #7 // Calculate number of elements left over after
                   // processing complete vectors using // array length & (vector register lanes - 1).
  LSL X3, X3, #1
                   // Multiply leftover elements by 2 to get the required
                    // address increment because we are dealing with doubleword
 data.
  BEQ loopsetup
                    // If the result of the ANDS is zero, the length
                       of the data is an exact multiple of the number
                        of lanes in the vector register, so there is
                       no overlap. Processing can begin.
                    // Otherwise, handle the first vector separately...
  LD1 {V0.8H}, [X0], X3 // Load the first eight elements from the array,
                         \ensuremath{//} and update the pointer by the required address
 increment.
  //...
  //...
                            Process the data for this iteration.
  //...
  ST1 {V0.8H}, [X1], X3 // Write eight elements to the output array, and
                          // update the pointer.
                   // Now set up the vector processing loop
loopsetup:
   LSR X2, X2, #3
                         // Divide the length of the array by the number of lanes
                              in the vector register (8) to find the number of
                              iterations required.
                           // This loop can now operate on exact multiples
                              of the lane number. The first few elements of
                               the first vector overlap with some of those
                              processed earlier.
loop:
   LD1 { V0.8H }, [X0], #16
                                // Load eight elements from the array pointed to
                                    // by X0 into V0, and update X0 to point to the
                                       next vector.
```

```
//...
//...
Process the data for this iteration.

ST1 { V0.8H }, [X1], #16

// Write eight elements to the output array, and // update X1 to point to next vector.

SUBS X2, X2, #1

B.NE loop

RET

// Decrement the loop counter and set flags
// Branch back if count is not yet zero...
// ... otherwise return
```

Process leftovers as single elements

Neon provides load and store instructions that can operate on single elements in a vector. You can use these instructions to load a partial vector that contains one element, operate on that partial vector, and then write the element back to memory.

In the example case, the iterations using single elements would follow these steps:

- 1. The first two iterations execute as normal, processing elements zero to seven, and eight to 15.
- 2. The third iteration needs only to process five elements. A separate loop handles these elements, which loads, processes, and stores single elements.

The following diagram shows how the first two iterations operate on full vectors, while the leftover elements are handled individually:




Figure 4-3: Handling leftover elements individually

This approach is slower than the previous two methods. This is because each leftover element must be loaded, processed, and stored individually.

This approach increases code size. Handling leftovers individually requires two loops, one for the full vectors, and a second loop for the single elements.



Neon single element loads only change the value of the specified lane in the destination element, leaving the rest of the vector intact. If the calculation that you are performing involves instructions that work across a vector, the register must be initialized before loading the first single element. For example, if you were using ADDV to sum across the entire vector, initialize the unused lanes to zero.

The following code shows how you could implement a solution that processes leftovers as single elements:

```
// Function entry point
// X0 = input array pointer
// X1 = output array pointer
// X2 = number of elements in array
process_array:
```

Load and store - leftovers

```
LSR X3, X2, #3
                       // Calculate the number of complete vectors to be
                       // processed.
  CMP X3, #0
  BEQ singlesetup
                       // If there are zero complete vectors, branch to
                        // the single element handling code.
                       // Process vector loop.
vectors:
  LD1 {V0.8H}, [X0], #16 // Load eight elements from the array and update
                                the pointer by eight doublewords.
                          Process the data for this iteration.
  //...
  ST1 \{V0.8H\}, [X1], \#16 // Write eight elements to the output array, and
                           // update the pointer by eight doublewords.
// Decrement the loop counter, and set flags.
  SUBS X3, X3, #1
  BNE vectors
                          // If X3 is not equal to zero, loop.
singlesetup:
  ANDS X3, X2, #7
                          // Calculate the number of single elements to process.
                           // If the number of single elements is zero, branch to
  BEQ exit
 exit.
                             // Process single element loop.
singles:
  \bar{\text{LD1}} {V0.H}[0], [X0], #2 // Load single element into lane 0, and update the
                                pointer by one doubleword.
  //...
                            Process the data for this iteration.
  ST1 \{V0.H\}[0], [X1], \#2 // Write the single element in lane zero to the
                                output array, and update the pointer.
  SUBS X3, X3, #1
                             // Decrement the loop counter, and set flags.
                            // If X3 is not equal to zero, loop.
 BNE singles
exit:
```

Other considerations for leftovers

The three approaches can be refined or adapted to suit your own particular needs as follows:

Choose when to process leftover elements

You can choose to apply the overlapping and single element techniques at either the start, or the end, of processing an array. The examples in this guide can be adapted to process leftover elements at either end of processing, depending on which is more suitable for your application.

Address alignment

The Armv8-A architecture allows many types of load and store accesses to be arbitrarily aligned. However, there are exceptions to this rule. For example, load and store addresses should be aligned to cache lines to allow more efficient memory accesses. Check the documentation for your target processor for more information.

Use A64 base instructions instead of Neon instructions

In the single elements approach, you could use Arm A64 base instructions and the general-purpose registers to operate on each of the single elements, instead of using Neon. However, using both the base A64 instructions and Neon SIMD instructions to write to the same area of memory can reduce performance. The writes from the Arm pipeline are delayed until

Load and store - leftovers

writes from the Neon pipeline are completed. Generally, you should avoid writing to the same area of memory, specifically the same cache line, from both Arm and Neon code.

Permutation - rearranging vectors

5. Permutation - rearranging vectors

When writing programs for SIMD architectures like Neon, performance is often directly related to data ordering. The ordering of data in memory might be inappropriate or suboptimal for the operation that you want to perform.

One solution to these issues might be to rearrange the entire data set in memory before data processing begins. However, this approach is likely to have a high cost to performance. This solution might not even be possible, if your input is a continuous stream of data.

A better solution might be to reorder data values as they are processed. Reordering operations is called permutation. Neon provides a range of permute instructions that typically do the following:

- Take input data from one or more source registers
- Rearrange the data
- Write the result of the permutation to a destination register

Permutation guidelines

Permutations can help to optimize data processing, but you must remember the following guidelines:

- Permuting data is only useful if it leads to an overall increase in performance for your application. Do you really need to permute your data?
- Permute instructions always have a time cost because they only prepare data. Permute instructions do not process data.
- Different instructions might use different hardware pipelines. An optimal solution maximizes the use of idle pipelines. When rearranging data, you have the following goals:
- Minimize the number of permute instructions used.
- Choose instructions that are likely to use idle pipelines when they are executed.

Alternatives to permutation

How can you avoid wasting unnecessary processor cycles on data permutation? Here are some options to consider:

Change the input data structure.

If the input data is well-ordered to begin with, there is no need to rearrange data during loading. However, consider the effects of data locality on cache performance before changing your data structures.

Changing the structure of input data is often not possible, for example when you do not have control over the format.

Redesign your algorithm.

Another algorithm might be available that better suits the input data.

Modify previous processing stages.

4.0 Permutation - rearranging vectors

It might be possible to rearrange data more efficiently earlier in the program, especially if the application has a long or complex data pipeline.

• Use interleaving loads and stores.

Some Neon load and store instructions can interleave and deinterleave data. These interleaving instructions are often used with explicit data permutations, which reduces the total number of instructions required.

You can use any of these approaches, or a combination, to optimize code for Neon.

Permutation - Neon instructions

6. Permutation - Neon instructions

Neon provides several different kinds of permute instruction to perform different operations:

- Move instructions
- Reverse instructions
- Extraction instructions
- Transpose instructions
- Interleave instructions
- Lookup table instructions

Move instructions

The move instructions copy a sequence of bits into a register. This bit sequence can come either from another register or from a compile-time constant.

The Mov instruction has several variants, as shown in the following table:

Instruction	Description
MOV X0, #2	Set X0 to 2.
MOV X0, X1	Set X0 to the value of X1.
MOV X0, V3.S[1]	Set X0 to the value of the second single word (bits 32-63) in V3. This instruction is an alias of UMOV.
MOV V0, V2.H[2]	Set every halfword (16 bit) lane in V0, to the value in the third halfword lane of V2. This instruction is an alias of DUP.
MOV V2.S[2], S0	Set the third single-word lane in V2, to the value of S0. This instruction is an alias of INS.
MOV s0, v2.S[2]	Set S0 to the value in the third single-word lane of V2. This instruction is an alias of INS.

The following move instructions specify a sign extension:

Instruction	Description
UMOV X0, V3.S[1]	Set X0 to the zero-extended value of the second single in V3.
SMOV X0, V3.S[1]	Set X0 to the sign-extended value of the second single in V3.

The following move instructions operate on floating-point values:

Instruction Description	
FMOV S0, #1.0	Set S0, the lowest 32 bits of V0, to the floating-point value 1.0.
FMOV V0.8H, #2.0	Set all eight halfword (16-bit) lanes in V0 to the floating-point value 2.0.
FMOV D1, D4	Set D1 to the value of D4.

All these move instructions have the following in common:

- The instructions copy a single fixed sequence of bits into one or more lanes in a destination register.
- The instructions do not perform any floating-point type conversion.

If you need to move more than one value, see the other instructions below. Floating point conversions are beyond the scope of this guide.

Reverse instructions

The reverse instructions break a vector into ordered containers. The ordering of these containers is preserved. These containers are then split into ordered subcontainers. Within each container, the ordering of subcontainers is reversed. The newly ordered elements are then copied into the destination register.


For example, consider the following instruction:

REV16 v0.16B, v1.16B

This instruction splits the 128-bit V1 register into eight 16-bit halfword containers. Each of these halfword containers is then split into a pair of one-byte subcontainers. Each pair of subcontainers is then reversed, as shown in the following diagram:

Figure 6-1: Reverse instruction


REV16 V0.16B, V1.16B



There are several reverse instructions to handle different sizes of containers and subcontainers, as shown in the following tables and diagrams:

Instruction	Number of containers	Size of containers	Number of subcontainers in each container	Size of subcontainers
REV16 v0.16B, v1.16B	8	16-bit	2	8-bit

Figure 6-2: REV16 8x8-bit reverse




Instruction	Number of containers	Size of containers	Number of subcontainers in each container	Size of subcontainers
REV32 v0.16B, v1.16B	4	32-bit	4	8-bit

Figure 6-3: REV32 4x8-bit reverse



Instruction	Number of containers	Size of containers	Number of subcontainers in each container	Size of subcontainers
REV32 v0.8H, v1.8H	4	32-bit	2	16-bit

Figure 6-4: REV32 4x16-bit reverse




Instruction	Number of containers	Size of containers	Number of subcontainers in each container	Size of subcontainers
REV64 v0.16B, v1.16B	2	64-bit	8	8-bit

Figure 6-5: REV64 2x8-bit reverse




Instruction	Number of containers	Size of containers	Number of subcontainers in each container	Size of subcontainers
REV64 v0.8H, v1.8H	2	64-bit	4	16-bit

Figure 6-6: REV64 2x16-bit reverse



Instruction	Number of containers	Size of containers	Number of subcontainers in each container	Size of subcontainers
REV64 v0.4S, v1.4S	2	64-bit	2	32-bit

Figure 6-7: REV64 2x32-bit reverse



Extraction instructions

The extract instruction, EXT, creates a new vector by extracting consecutive lanes from two different source vectors. An index number, n, specifies the lowest lane from the first source vector to include in the destination vector. This instruction lets you create a new vector that contains elements that straddle a pair of existing vectors.

The EXT instruction constructs the new vector by doing the following:

- 1. From the first source vector, copy the lower ${\tt n}$ lanes to the highest lanes in the destination vector.
- 2. From the second source vector, ignore the lower $\tt n$ lanes and copy the remaining lanes to the lowermost lanes in the destination vector.


For example, the following instruction uses an index with value 3:

This instruction extracts lanes as follows:

- 1. Copy the lowest 3 bytes from V1 into the highest 3 bytes of V0.
- 2. Copy the highest 13 bytes of V2 into the lowest 13 bytes of V1.

The following diagram illustrates the extraction process:

Figure 6-8: EXT instruction




EXT v0.16B, v1.16B, v2.16B, #3

The other extraction instructions are less general. They copy all the values from a source register, then place them into smaller lanes in the destination, as follows:


• XTN Extract and narrow Reads each vector element from the source register, narrows each value to half the original width, and writes the resulting vector to the lower half of the destination register. The upper half of the destination register is cleared. The following diagram shows the operation of the XTN instruction:

Figure 6-9: XTN instruction



• XTN2 Extract and narrow into upper halves Reads each vector element from the source register, narrows each value to half the original width, and writes the resulting vector to the upper half of the destination register. The other bits of the destination register are not affected. The following diagram shows the operation of the XTN2 instruction:

Figure 6-10: XTN2 instruction



With both the XTN and XTN2 instructions, the destination vector elements are half as long as the source vector elements.

Neon provides several variants of the extraction instructions for different combinations of sign and overflow behavior. The following table shows these extraction instruction variants:


Instruction	Description
SQXTN	Signed saturating extract and narrow. All values are signed integer values.
	Large values saturate to the maximum positive or negative integer value.
SQXTN2	Signed saturating extract and narrow into upper halves. All values are signed integer values.
	Large values saturate to the maximum positive or negative integer value.
SQXTUN	Signed saturating extract and unsigned narrow. Source values are signed, destination values are unsigned.
	Large values saturate to the maximum positive integer value or zero. Other values are zero extended.
SQXTUN2	Signed saturating extract and unsigned narrow into upper halves. Source values are signed, destination values are unsigned.
	Large values saturate to the maximum positive integer value or zero. Other values are zero extended.
UQXTN	Unsigned saturating extract and narrow. All values are unsigned integer values.
	Large values saturate to the maximum positive integer value or zero. Other values are zero extended.
UQXTN2	Unsigned saturating extract and narrow into upper halves. All values are unsigned integer values.
	Large values saturate to the maximum positive integer value or zero. Other values are zero extended.

Transpose instructions

The transpose instructions interleave elements from two source vectors. Neon provides two transpose instructions: TRN1 and TRN2.


TRN1 interleaves the odd-numbered lanes from the two source vectors, while TRN2 extracts the even-numbered lanes. The following diagram shows this process:

Figure 6-11: TRN1 and TRN2 transpose instructions



In mathematics, the transpose of a matrix is an operation that switches the rows and columns. For example, the following diagram shows the transpose of a 2x2 matrix:


Figure 6-12: 2x2 matrix transpose operation



We can use the Neon transpose instructions to transpose matrices.

For example, consider the following two matrices:

Figure 6-13: Example matrices



We can store these matrices across two Neon registers, with the top row in V0 and the bottom row in V1, as shown in the following diagram:

Figure 6-14: Example matrices stored in Neon registers




The following instructions transpose this matrix into the destination registers V2 and V3:

```
TRN1 v2.4s, v0.4s, v1.4s
TRN2 v3.4s, v0.4s, v1.4s
```

The following diagram illustrates this process:


Figure 6-15: Transposition instructions



The following diagram shows the transposed matrices:

Permutation - Neon instructions

Figure 6-16: Example matrices transposed



Interleave instructions


Like the transpose instructions, the zip instructions use interleaving to form vectors. zip1 takes the lower halves of two source vectors, and fills a destination vector by interleaving the elements in those two lower halves. zip2 does the same thing with the upper halves of the source vectors.

For example, the following instructions create an interleaved vector that is stored across two registers, V1 and V2:

```
ZIP1 V2.16B, V4.16B, V3.16B
ZIP2 V1.16B, V4.16B, V3.16B
```

This result vector is formed by alternating elements from the two source registers, V1 and V2. The zipi instruction creates the lower half of the result vector in V2, and the zipi instruction creates the upper half in V1. The following diagram shows this process:

Figure 6-17: Interleaving with ZIP1 and ZIP2



ZIP2 V1.16B, V3.16B, V4.16B

ZIP1 V2.16B, V3.16B, V4.16B

The uzip1 and uzip2 instructions perform the reverse operation, deinterleaving alternate elements into two separate vectors.

Lookup table instructions

All the permute instructions that we have described have one thing in common: the pattern of the permutation is fixed. To perform arbitrary permutations, Neon provides the table lookup instructions TBL and TBX.

The TBL and TBX instructions take two inputs:

- An index input, consisting of one vector register containing a series of lookup values
- A lookup table, consisting of a group of up to four vector registers containing data


The instruction reads each lookup value from the index, and uses that lookup value to retrieve the corresponding value from the lookup table.

For example, the following instruction provides a vector of lookup values in VO, and a lookup table consisting of two registers: V1 and V2:

```
TBL V4.16B, {v1.16B, v2.16B}, v0.16B
```

The value in lane 0 of V0 is 6, so the value from lane 6 of V1 is copied into the first lane of the destination register V4. The process continues for all the other lookup values in V0, as shown in the following diagram:

Figure 6-18: Table lookup example



The TBL and TBX instructions only differ in how they handle out of range indices. TBL writes a zero if an index is out-of-range, while TBX leaves the original value unchanged in the destination register. In the above example, lane 14 in VO contains the lookup value, 40. Because the lookup table only contains two registers, the range of indices is 0-31. Lane 14 in the destination vector is therefore set to zero.

The TBL and TBX instructions are very powerful, so only use these instructions when necessary. On most systems a short sequence of fixed pattern permutations is faster.

Matrix multiplication

7. Matrix multiplication

In this section of the guide, we look at how you can use Neon to perform an example data processing task.

Specifically, we show you how to efficiently multiply four-by-four matrices together, an operation frequently used in the world of D graphics. We assume that the matrices are stored in column-major order because OpenGL ES uses this format.



Download the code for the functions that are described in this section here: matrix asm a64.s.zip

The algorithm

First, we will look at the algorithm that multiplies two matrices together. We expand the calculation to examine the matrix multiplication operation in detail, then identify operations that we can implement using Neon instructions.

The following diagram shows how to calculate the first column of results when multiplying two matrices together:


Figure 7-1: Calculating the first column of results for matrix multiplication

```
x0y0 + x4y1 + x8y2 + xCy3 ...
x0
                                               yC
x1
     х5
            х9
                 xD
                            y1
                                              уD
                                                              x1y0 + x5y1 + x9y2 + xDy3 ...
                            y2
x2
                 хE
                                        yΑ
                                               yЕ
                                                              x2y0 + x6y1 + xAy2 + xEy3
      х6
           xΑ
                                  у6
                                              уF
                                                              x3y0 + x7y1 + xBy2 + xFy3
хЗ
```

Look at the first element in the result matrix. Every element in the first row of the first matrix (blue) is multiplied by the corresponding element in the first column of the second matrix (orange). We accumulate the results to give the first result value. This process is repeated for all the remaining elements in the result matrix.

The following diagram shows how we can use the Neon FMUL vector-by-scalar multiplication instruction to calculate these results:

Figure 7-2: Using the FMUL instruction for matrix multiplication



FMUL V3.4S, V1.4S, V2.S[0]

The FMUL instruction in the preceding diagram multiplies every element of the vector in the V1 register by the scalar value in lane 0 of the V2 register. The instruction then stores the resulting vector in the V3 register.

The following diagram shows how this single instruction calculates the first term for each of the values in the first column of the result matrix:

Figure 7-3: Calculating the first term for matrix multiplication

We can use the same method to calculate the remaining terms. However, this time we will use the FMLA multiply and accumulate instruction to sum the terms.

Because we are operating on the columns of the first matrix and producing a column of results, reading and writing elements is a linear operation. Interleaving load or store instructions are not required.


Neon registers and data size

The Neon register file is a collection of registers that can be accessed as either 64-bit or 128-bit registers.

The number of lanes in a Neon vector depends on the size of the vector and the data elements in the vector. The following diagram shows the different ways that you can arrange and access data in Neon registers:

Matrix multiplication

Figure 7-4: Neon registers and lanes



This guide examines two different implementations of the matrix multiplication algorithm. Each implementation performs multiplication in a different way:

- The floating-point implementation operates on values using the 32-bit floating-point format. Multiplying two 32-bit floating-point numbers gives a result that is another 32-bit number. This means that the floating-point implementation uses the 4S vector lane format throughout.
- The fixed-point implementation operates on values using the 16-bit Q1.14 fixed-point format. Multiplying two 16-bit Q1.14 fixed-point format numbers together gives a 32-bit result that must be narrowed to 16 bits. This means that we can use the 4H vector lane format for the 16-bit input and result values, but the 4S vector lane format for the intermediate multiplication result.

Floating-point implementation

The floating-point implementation multiplies two matrices that contain 32-bit floating-point numbers.

The implementation has three stages:

- 1. Load the matrix data from memory to Neon registers.
- 2. Perform the matrix multiplication operation.
- 3. Store the result matrix back to memory.

The following code shows how we load the data into the Neon registers:

```
LD1 {V0.4S, V1.4S, V2.4S, V3.4S}, [X1]
LD1 {V4.4S, V5.4S, V6.4S, V7.4S}, [X2]
```

Our matrices are stored in column-major order. This means that the column data is stored linearly in memory. We use the LD1 instruction to load data from memory into the Neon registers VO - V7.

Matrix multiplication

Neon provides 32 registers. Each register is 128 bits wide. We can load all the elements from both input matrices into registers, and still have registers left over to use as accumulators. In this implementation, registers V0-V3 hold the 16 elements from the first matrix, and registers V4-V7 hold the 16 elements from the second matrix. Each 128-bit register holds four 32-bit values, representing an entire matrix column.

Similarly, the following code shows how we use the sti instruction to store the result back to memory:

```
ST1 {V8.4S, V9.4S, V10.4S, V11.4S}, [X0]
```

The following code shows how we calculate a column of results using just four Neon multiply instructions:

The first FMUL instruction implements the operation that is highlighted in the previous diagram. Matrix elements x0, x1, x2, and x3 (in the four lanes of register V0) are each multiplied by y0 (element 0 in register V4), and the result stored in V8.

Subsequent FMLA instructions operate on the other columns of the first matrix, multiplying by corresponding elements of the first column of the second matrix. Results are accumulated into V8 to give the first column of values for the result matrix.

If we only need to calculate a matrix-by-vector multiplication, the operation is now complete. However, to complete the matrix-by-matrix multiplication, we must execute three more iterations. These iterations use values y4 to yF in registers V5 toV7.

The following code shows the full implementation of a four-by-four floating-point matrix multiply:

```
matrix mul float:
    LD\overline{l} \{\overline{V}0.4S, V1.4S, V2.4S, V3.4S\}, [X1] // load all 16 elements of matrix 0 into
                                                          VO-V3, four elements per register
     LD1 {V4.4S, V5.4S, V6.4S, V7.4S}, [X2] // load all 16 elements of matrix 1 into
                                                           V4-V7, four elements per register
     FMUL V8.4S, V0.4S, V4.S[0]
FMUL V9.4S, V0.4S, V5.S[0]
                                          // rslt col0 = (mat0 col0) * (mat1 col0 elt0)
// rslt col1 = (mat0 col0) * (mat1 col1 elt0)
                                           // rslt col2 = (mat0 col0) * (mat1 col2 elt0)
     FMUL V10.4S, V0.4S, V6.S[0]
     FMUL V11.4S, V0.4S, V7.S[0]
                                           // \text{ rslt col3} = (\text{mat0 col0}) * (\text{mat1 col3 elt0})
     FMLA V8.4S, V1.4S, V4.S[1]
                                           // rslt col0 += (mat0 col1) * (mat1 col0 elt1)
     FMLA V9.4S, V1.4S, V5.S[1]
                                           // rslt col1 += (mat0 col1) * (mat1 col1 elt1)
                                           // rslt col2 += (mat0 col1) * (mat1 col2 elt1)
// rslt col3 += (mat0 col1) * (mat1 col3 elt1)
     FMLA V10.4S, V1.4S, V6.S[1]
FMLA V11.4S, V1.4S, V7.S[1]
    FMLA V8.4S, V2.4S, V4.S[2]
FMLA V9.4S, V2.4S, V5.S[2]
FMLA V10.4S, V2.4S, V6.S[2]
                                           // rslt col0 += (mat0 col2) * (mat1 col0 elt2)
                             V4.S[2]
                                              rslt col1 += (mat0 col2) *
                                                                                 (mat1 col1 elt2)
                                           // rslt col2 += (mat0 col2) * (mat1 col2 elt2)
                                           // rslt col3 += (mat0 col2) * (mat1 col2 elt2)
     FMLA V11.4S, V2.4S, V7.S[2]
     FMLA V8.4S, V3.4S, V4.S[3]
                                          // rslt col0 += (mat0 col3) * (mat1 col0 elt3)
```

Matrix multiplication

```
FMLA V9.4S, V3.4S, V5.S[3] // rslt col1 += (mat0 col3) * (mat1 col1 elt3)
FMLA V10.4S, V3.4S, V6.S[3] // rslt col2 += (mat0 col3) * (mat1 col2 elt3)
FMLA V11.4S, V3.4S, V7.S[3] // rslt col3 += (mat0 col3) * (mat1 col3 elt3)

ST1 {V8.4S, V9.4S, V10.4S, V11.4S}, [X0] // store all 16 elements of result
RET // return to caller
```

Fixed-point implementation

Using fixed-point arithmetic for calculations is often faster than using floating-point arithmetic. Fixed-point arithmetic requires less memory bandwidth than floating-point arithmetic to read and write values that use fewer bits. Because fixed-point arithmetic uses integer data types, multiplication of fixed-point values is usually quicker than the same operations applied to floating point numbers.

However, when using fixed-point arithmetic, you must choose the representation carefully, so that you can avoid overflow or saturation. At the same time, you must preserve the degree of precision in the results that your application requires.

Implementing a matrix multiply using fixed-point values is very similar to floating-point. This example uses fixed-point format, but the operations are similar for other formats. Adapting this example to another fixed-point format might only require a change to the final shift that is applied to the accumulator.

Our fixed-point implementation uses a macro to perform the matrix multiplication, as shown in the following code:

```
.macro mul_col_s16 res_d, col_d
SMULL V12.4S, V0.4H, \col_d\().H[0] // multiply col element 0 by matrix col 0
SMLAL V12.4S, V1.4H, \col_d\().H[1] // multiply col element 0 by matrix col 1
SMLAL V12.4S, V2.4H, \col_d\().H[2] // multiply col element 0 by matrix col 2
SMLAL V12.4S, V3.4H, \col_d\().H[3] // multiply col element 0 by matrix col 3
SQSHRN \res_d\().4H, V12.4S, #14 // shift right and narrow accumulator into
// Q1.14 fixed-point format with saturation
.endm
```

Comparing the fixed-point implementation to the floating-point implementation, the major differences are:

- Matrix values are now 16-bit instead of 32-bit. Because of this difference, we use the 4H configuration to store four 16-bit values in the lower 64 bits of the 128-bit Neon register.
- The result of multiplying two 16-bit numbers is a 32-bit number. We use the signed multiply long smull and signed multiply-add long smlal instructions to store the results in the 32-bit 4S lane configuration of the Neon register.
- The final result matrix must contain 16-bit values, but the accumulators contain 32-bit values. We obtain a 16-bit result using the SQSHRN signed saturating shift right narrow instruction. This instruction adds the correct rounding value to each element, shifts it right, and saturates the result to the new, narrower element size.

The following code shows the full implementation of a four-by-four fixed-point matrix multiply:

```
.macro mul_col_s16 res_d, col_d SMULL V12.4S, \overline{V0.4H}, \overline{Col_d().H[0]} // multiply col_element 0 by matrix col_0
```

```
SMLAL V12.4S, V1.4H, \col d\().H[1] // multiply col element 0 by matrix col 1
  SMLAL V12.4S, V2.4H, \col_d\().H[2] // multiply col element 0 by matrix col 2 SMLAL V12.4S, V3.4H, \col_d\().H[3] // multiply col element 0 by matrix col 3 SQSHRN \res_d\().4H, V12.\overline{4}S, #14 // shift right and narrow accumulator into
                                                  // Q1.14 fixed-point format, with saturation
   .endm
   .global matrix mul fixed
matrix_mul_fixed:
  LD1 {V0.4H, V1.4H, V2.4H, V3.4H}, [X1] // load all 16 elements of matrix 0 // into V0-V3, four elements per register
  LD1 {V4.4H, V5.4H, V6.4H, V7.4H}, [X2] // load all 16 elements of matrix 1
                                                        // into V4-V7, four elements per register
                                                          // matrix 0 * matrix 1 col 0
  mul col s16 v8, v4
  mul_col_s16 v9, v5
                                                          // matrix 0 * matrix 1 col 1
  mul_col_s16 v10, v6 mul_col_s16 v11, v7
                                                          // matrix 0 * matrix 1 col
                                                          // matrix 0 * matrix 1 col 3
         {V8.4H, V9.4H, V10.4H, V11.4H}, [X0] // store all 16 elements of result
  ST1
                                                          // return to caller
```

Optimized instruction scheduling

The fixed-point implementation uses a macro to perform the main multiplication operation on each matrix column. In the macro, adjacent multiply instructions write to the same register: V12. This means that each Neon pipeline must wait for each multiply to complete before it can start the next instruction. The following code repeats the macro from the fixed-point implementation:

```
.macro mul_col_s16 res_d, col_d 

SMULL V12.\overline{4}S, \overline{V}0.4H, \overline{C}0.d\overline{C}0.H[0] // multiply col_element 0 by matrix col_0 

SMLAL V12.4S, V1.4H, \overline{C}0.d\overline{C}0.H[1] // multiply col_element 0 by matrix col_1 

SMLAL V12.4S, V2.4H, \overline{C}0.d\overline{C}0.H[2] // multiply col_element 0 by matrix col_2 

SMLAL V12.4S, V3.4H, \overline{C}0.H[3] // multiply col_element 0 by matrix col_3 

SQSHRN \overline{C}0.4H, V12.\overline{C}5, #14 // shift right and narrow accumulator into 

.endm
```

If we take the instructions out of the macro and rearrange them, we can separate instructions that write to the same register. This reduces the risk of register contention and allows instructions to make efficient use of the Neon pipeline.

The following code shows how to rearrange and optimize accesses to the accumulator registers:

```
SMULL V12.4S, V0.4H, V4.H[0]
SMULL V13.4S, V0.4H, V5.H[0]
SMULL V15.4S, V0.4H, V7.H[0]
SMULL V15.4S, V0.4H, V7.H[0]
SMLAL V12.4S, V1.4H, V4.H[1]
SMLAL V13.4S, V1.4H, V5.H[1]
SMLAL V14.4S, V1.4H, V6.H[1]
SMLAL V15.4S, V1.4H, V7.H[1]

SMLAL V15.4S, V2.4H, V7.H[1]

SMLAL V12.4S, V2.4H, V5.H[2]
SMLAL V13.4S, V2.4H, V5.H[2]
SMLAL V14.4S, V2.4H, V6.H[2]
SMLAL V15.4S, V2.4H, V7.H[2]

SMLAL V14.4S, V2.4H, V7.H[3]
SMLAL V15.4S, V3.4H, V4.H[3]
SMLAL V15.4S, V3.4H, V5.H[3]
SMLAL V14.4S, V3.4H, V5.H[3]
SMLAL V15.4S, V3.4H, V7.H[3]
```

```
SQSHRN V8.4H, V12.4S, #14
SQSHRN V9.4H, V13.4S, #14
SQSHRN V10.4H, V14.4S, #14
SQSHRN V11.4H, V15.4S, #14
```

8. Shifting left and right

This section of the guide introduces the different shift operations that are provided by Neon. An example shows how to use these shifting operations to convert image data between commonly used color depths.

Shifting vectors


Neon vector shifts are very similar to shifts in scalar Arm code. A shift moves the bits in each element of a vector left or right. Bits that fall off the left or right of each element are discarded. These discarded bits are not shifted to adjacent elements.

The number of bits to shift can be specified as follows:

- With a single immediate literal encoded in the instruction
- With a shift vector

When using a shift vector, the shift that is applied to each element of the input vector depends on the corresponding element in the shift vector. The elements in the shift vector are signed values. This means that left, right, and zero shifts are possible, on a per-element basis. The following diagram shows an input vector, v0, and a shift vector v1:

Figure 8-1: SSHL signed shift left instruction



Each vector element shifts as follows:

- Element 0, in the right-most lane of v0, shifts left by 16 bits.
- Element 1 of v0 shifts left by 32 bits. Because the width of the element is also 32 bits, the final value of this element is zero.
- Element 2 of vO shifts right by 16 bits. The negative value in v1 changes the left shift to a right shift
- Element 3, in the left-most lane of v0, is unchanged. This is because the zero value in v1 means no shift.


The negative shift value -16 corresponding to element 2 changes the left shift operation to a right shift. When shifting right, we must consider whether we are dealing with signed or unsigned data. Because the SSHL instruction is a signed shift operation, the new 16 bits introduced in the top half of this element are the same as the top bit of the original element value. That is, the signed shift SSHL is a sign-extending shift. If we use the unsigned USHL instruction instead of the signed SSHL instruction, the new 16 bits would all be zeroes.

Shifting and inserting

Neon also supports shifts with insertion. This operation lets you combine bits from two vectors. For example, the <code>sli</code> shift left and insert instruction shifts each element of the source vector left. The new bits that are inserted at the right of each element are the corresponding bits from the destination vector.

The following image shows two vector registers v1 and v2, each containing four elements. The sli instruction takes each element from v1, shifts it left by 16 bits, then combines it with the corresponding element in v0.

Figure 8-2: SLI shift left and insert instruction



Shifting and accumulation

Finally, the Neon instruction SSRA supports shifting the elements of a vector right, and accumulating the results into another vector. This instruction is useful for situations in which interim calculations are made at a high precision, before the result is combined with a lower precision accumulator.

Instruction modifiers

Each shift instruction can take one or more modifiers. These modifiers do not change the shift operation itself, however the inputs or outputs are adjusted to remove bias or saturate to a range.

The general format of shift instructions with modifiers are as follows:

[<sign>[<sat>]][<round>]SH<dir>[<scale>]

Where the modifiers are as follows:

Modifier	Values	Description	Example instruction
<sign></sign>	S U	Signed or unsigned. Specifies whether vector element values are treated as signed or unsigned.	SSHL - Signed Shift Left USHR - Unsigned
		For left shifts, sign does not matter because all bits simply move from right to left. New bits introduced from the right are always zero.	Shift Right
		However, negative shift vector values turn a left shift into a right shift. For unsigned data, right shifts use zero for the new bits. For signed data, new bits are the same as the top bit of the original element.	
		S indicates signed. U indicates unsigned.	
<sat></sat>	Q	Saturating. Sets each result element to the minimum or maximum of the representable range, if the result exceeds that range. The number of bits and sign type of the vector are used to determine the saturation range.	SQSHL - Signed saturating Shift Left
		Unsigned saturating, indicated by a UQ prefix, is similar to the saturation modifier. The difference is that the result is saturated to an unsigned range when given signed or unsigned inputs.	
<round></round>	R	Rounding. Specifies whether vector element values are rounded after shifting. This operation corrects for the bias that is caused by truncation when shifting right.	URSHR - Unsigned Rounding Shift Right
<dir></dir>	L R	The direction to shift, either left or right.	SHL - Shift Left SRSHR - Signed Rounding Shift Right
<scale></scale>	L, L2 N, N2	Long (L) causes the number of bits in each element of the result to be doubled. Narrow (N) causes the number of bits in each element of the result to be halved.	SHRN - Shift Right Narrow SHRN2 - Shift
		The suffix modifier 2 indicates an operation on the upper half of either the source register, for narrow instructions, or the destination register, for long instructions.	Right Narrow (upper)
			SHLL - Shift Left Long
			SHLL2 - Shift Left Long (upper)

Some combinations of these modifiers do not describe useful operations, so Neon does not provide these instructions. For example, a saturating shift right would be called UQSHR OF SQSHR. However, this operation is unnecessary. Right shifting makes results smaller, so result values can never exceed the available range.

Available shifting instructions

The following table shows all of the shifting instructions that Neon provides:

Neon instruction	Description
RSHRN, RSHRN2	Rounding Shift Right Narrow (immediate).
SHL	Shift Left (immediate).
SHLL, SHLL2	Shift Left Long (by element size).

Neon instruction	Description
SHRN, SHRN2	Shift Right Narrow (immediate).
SLI	Shift Left and Insert (immediate).
SQRSHL	Signed saturating Rounding Shift Left (register).
SQRSHRN, SQRSHRN2	Signed saturating Rounded Shift Right Narrow (immediate).
SQRSHRUN, SQRSHRUN2	Signed saturating Rounded Shift Right Unsigned Narrow (immediate).
SQSHL (immediate)	Signed saturating Shift Left (immediate).
SQSHL (register)	Signed saturating Shift Left (register).
SQSHLU	Signed saturating Shift Left Unsigned (immediate).
SQSHRN, SQSHRN2	Signed saturating Shift Right Narrow (immediate).
SQSHRUN, SQSHRUN2	Signed saturating Shift Right Unsigned Narrow (immediate).
SRI	Shift Right and Insert (immediate).
SRSHL	Signed Rounding Shift Left (register).
SRSHR	Signed Rounding Shift Right (immediate).
SRSRA	Signed Rounding Shift Right and Accumulate (immediate).
SSHL	Signed Shift Left (register).
SSHLL, SSHLL2	Signed Shift Left Long (immediate).
SSHR	Signed Shift Right (immediate).
SSRA	Signed Shift Right and Accumulate (immediate).
UQRSHL	Unsigned saturating Rounding Shift Left (register).
UQRSHRN, UQRSHRN2	Unsigned saturating Rounded Shift Right Narrow (immediate).
UQSHL (immediate)	Unsigned saturating Shift Left (immediate).
UQSHL (register)	Unsigned saturating Shift Left (register).
UQSHRN, UQSHRN2	Unsigned saturating Shift Right Narrow (immediate).
URSHL	Unsigned Rounding Shift Left (register).
URSHR	Unsigned Rounding Shift Right (immediate).
URSRA	Unsigned Rounding Shift Right and Accumulate (immediate).
USHL	Unsigned Shift Left (register).
USHLL, USHLL2	Unsigned Shift Left Long (immediate).
USHR	Unsigned Shift Right (immediate).
USRA	Unsigned Shift Right and Accumulate (immediate).

Example: converting color depth

Converting between color depths is a frequent operation in graphics processing. Often, input or output data is in an RGB565 16-bit color format, but working with the data is much easier in RGB888 format. This is particularly true on Neon, because there is no native support for data types like RGB565.

The following diagram shows the RGB888 and RGB565 color formats:

Figure 8-3: RGB888 and RGB565 color formats



However, Neon can still handle RGB565 data efficiently, and the vector shifts introduced in this section provide a method to do this.

Converting from RGB565 to RGB888

First, we consider converting RGB565 to RGB888. We assume that there are eight 16-bit pixels in register v0. We want to separate reds, greens, and blues into 8-bit elements across three registers v2 to v4.

The following code uses shift instructions to convert RGB565 to RGB888:

```
ushr v1.16b, v0.16b, #3 // Shift red elements right by three bits,
                          // discarding the green bits at the bottom of
                          // the red 8-bit elements.
                         // Shift red elements right and narrow,
// discarding the blue and green bits.
shrn v2.8b, v1.8h, #5
shrn v3.8b, v0.8h, #5
                         // shift green elements right and narrow
                            discarding the blue bits and some red bits
                          // due to narrowing.
shl v3.8b, v3.8b, #2
                         // shift green elements left, discarding the
                          // remaining red bits, and placing green bits
                          // in the correct place.
shl v0.16b, v0.16b, #3 // shift blue elements left to most significant
                          // bits of 8-bit color channel.
xtn v4.8b, v0.8h
                          // remove remaining red and green bits by
                          // narrowing to 8 bits.
```

The effects of each instruction are described in the comments in the preceding code example. In summary, the operation that is performed on each channel is:

- 1. Remove color data for adjacent channels using shifts to push the bits off either end of the element.
- 2. Use a second shift to position the color data in the most significant bits of each element.
- 3. Perform narrowing to reduce the element size from 16-bits to 8-bits.

A small problem

You might notice that, if you use this code to convert to RGB888 format, the whites are not quite white. This is because, for each channel, the lowest two or three bits are zero, rather than one. A white represented in RGB565 as (0x1F, 0x3F, 0x1F) becomes (0xF8, 0xFC, 0xF8) in RGB888. This can be fixed using shift with insert to place some of the most significant bits into the lower bits.

Converting from RGB888 to RGB565

Now, we can look at the reverse operation, converting RGB888 format to RGB565. The RGB888 data is in the format that is produced by the preceding code. Data is separated across three registers v0 to v2, with each vector register containing eight elements of each color. The result is stored as eight 16-bit RGB565 elements in register v3.

The following code converts RGB888 data in registers v0, v1, and v2 to RGB565 data in v3:

```
shll v3.8h, v0.8b, #8 // Shift red elements left to most significant // bits of wider 16-bit elements.

shll v4.8h, v1.8b, #8 // Shift green elements left to most significant // bits of wider 16-bit elements.

sri v3.8h, v4.8h, #5 // Shift green elements right and insert into // red elements.

shll v4.8h, v2.8b, #8 // Shift blue elements left to most significant // bits of wider 16-bit elements.

sri v3.8h, v4.8h, #11 // Shift blue elements right and insert into // red and green elements.
```

Again, the detail is in the comments for each instruction in the preceding code, but the process for each channel is as follows:

- 1. Lengthen each element to 16 bits, and shift the color data into the most significant bits.
- 2. Use shift right with insert to position each color channel in the result register.

Conclusion

The powerful range of shift instructions provided by Neon allows you to do the following:

- Quickly divide and multiply vectors by powers of two, with rounding and saturation.
- Shift and copy bits from one vector to another.
- Make interim calculations at high precision and accumulate results at a lower precision.

Related information

9. Related information

Here are some resources related to material in this guide:

- Neon Programmer's Guide for Armv8-A
- SIMD ISAs on Arm Developer
- Armv8-A Neon optimization presentation video
- Getting Started with Neon Intrinsics on Android video