Writing efficient embedded software

Karthik Ganesan

Introduction

This lab will introduce you to several new concepts, such as:

- 1) using the timer peripheral to measure execution time,
- 2) different ways of producing sinusoidal and square waves and
- 3) using fixed-point numbers for real values.

We will start with the timer peripheral which can be used to measure the execution time for different segments of your code. At the end of this lab document, you will find a table that you will need to fill out. You must show your TA the completed table when you are being marked.

1. Measuring execution time

The timer is a dedicated hardware counter that you use to how many cycles an operation takes. The timer is configured in a similar manner to the other peripherals you have used so far. You can use the HAL_TIM_Base_Start () function to enable the timer. You can get the current timer value using the __HAL_TIM_GET_COUNTER() function. To measure execution time, save the timer value before the operation starts. Then, subtract the saved value from the the timer value once the operation ends. By default, the timer peripheral runs on the same clock as your processor and increments every clock cycle. However, the timer only uses a 16-bit register, so you can only count up to 65,536 cycles before the counter rolls over.

To increase the number of cycles you can count, the timer allows you to use a clock divider to slow the input clock to the timer. This is called the prescalar and can be set to any value from 0 to 65,536. The input clock to the timer is then divided by prescalar + 1. By default, the prescalar is set to 0, which means the clock is divided by 1 and therefore unchanged. You should adjust the prescalar when needed to count operations that take more than 65,536 cycles.

Use the timer to measure the execution time for different segments of code. For example, write a for loop to sum the numbers from 0 to 99. How long does this take? Vary the values and see if you get a linear relationship between the loop bounds and the execution time.

2. Producing a sine wave

In Lab 2, you used the *Wave Gen* capability of the oscilloscope to produce a sine wave. You then used an ADC to read that sine wave and output it using the DAC. You must now create your own sine wave, without using an ADC. You will do this in two different ways in this lab:

- 1) using the sin() function in C and
- 2) using a look up table.

2.1 Using the sin() function

First, you must make a sine wave using the sin() function from the <math.h> include file. Inside your while (1) loop, iterate over one full period of the sine function and output each point using the DAC. Keep in mind that the sin() function accepts inputs in radians. How many radians represents one full period? As a baseline, calculate one output for every 0.01 radians.

Also, keep in mind that the DAC has a resolution of 12-bits and only outputs positive values. You must appropriately scale the output of sin() so that you can use the full range of the DAC output. In the results page, note down the frequency of the produced sine wave. Next, use the timer to measure the number of cycles taken to generate one period of the sine wave and enter that value in the table.

For this lab, the clock frequency of the CPU is set to 100MHz. What is the relationship between the number of points you calculate and the output frequency of the sine wave?

Try it yourself: Try varying the number of points you output for one period and see how this impacts the output quality.

Try it yourself: What happens to the frequency of the sine wave if you use delays between subsequent points? Can you find a formula for the delay you need to get a sine wave of a desired frequency?

2.2 Using a lookup table

In the case above, you call the sin() function to produce each point. However, this function is computationally expensive. We are also needlessly re-calculating points each time. It is therefore more efficient to compute the points once and repeatedly output the stored points.

Write code to generate points for one full period of the sine wave and store it in an array. Such an array is referred to as a 'lookup table' or LUT. You can then simply loop through this LUT to produce one period of the sine wave. You can use the same number of points you used earlier to make your results comparable.

The sin() function works for any value, not just values within one period. Think about how you can use the periodic nature of the sine function to do the same for your code. Once you are done, write down the frequency and the execution time for your LUT code in the results page.

3. Generating arbitrary waveforms

Sine waves can be used to produce many other waveforms, including square waves, sawtooth waves and triangular waves. The Fourier series equations for these three waveforms is provided below.

Square:
$$f(x) = 0.5 + \frac{2}{\pi} \sum_{n=0}^{\infty} \frac{1}{2n+1} \sin((2n+1)x)$$

Sawtooth:
$$f(x) = \frac{1}{2} - \frac{1}{\pi} \sum_{n=1}^{\infty} \frac{1}{n} \sin(nx)$$

Triagular:
$$f(x) = 0.5 + \frac{4}{\pi^2} \sum_{n=0}^{\infty} \frac{(-1)^n}{(2n+1)^2} \sin((2n+1)x)$$

As you can see, we can produce all three waveforms (and many others) just by summing up sine waves. In this lab, we will be generating square waves. As you did with Part 2 above, you will also experiment using the sin() function and a lookup table.

Using the sin() function

Begin by writing code - using the sin() function - to implement the equation above which produced a square wave. Of course, you cannot add an infinite number of sine waves; you must vary the number of terms you add and observe the effect on the output.

You must analyze the impact of varying the number of terms added. How many terms do you need to add for the wave to "look square"? What is the impact on frequency for each additional term you add? You must write down (on the results page) the frequencies you observe, as you vary the number of terms. To avoid having to re-program the board each time, you can configure the pushbutton to add an additional term each time. You should be able to modify the interrupt code you used for Lab 1 to do this.

Using a lookup table

Next, generate a square wave using the LUT. You will need to add many terms to get a good square wave; However, storing a separate table for each sin(x) function (i.e., sin(x), sin(3x), sin(5x) etc) will consume a lot of memory. To avoid this, you should **only** store the values for sin(x) in a table. You must them compute the values for other terms (e.g., sin(3x), sin(5x)) from the sin(x) table. You will also need to make sure you are accessing the right values in your stored array.

Thing about how you can do this. You may want to try write a small C program and run in on your own computer to try this first, before running it on your Nucleo board. Once you have a working implementation, write down the frequencies you get for different number of terms for this version as well.

Try it yourself: Experiment with the other waveforms for which you are given the formulae above.

4. Numerical representations

Thus far, we have used floating point representations for all of our calculations. However, these require dedicated floating point hardware which many embedded systems may not have. We will now explore using fixed point for our calculations, which only requires integer hardware.

You are provided with a fixedpt.h file which contains the code you will need to implement basic fixed point operations. You must fill in the missing code to compute basic arithmetic operations. By default, the provided code implements an Q3.28 fixed point format.

Start by writing some simple operations using fixed point and compare the results to performing the same operations using floating point. For example, take some numbers in floating point, convert them to fixed point before doing calculations. Then convert the results back to floating point and compute the error between the original and converted values. You should try a range of values to make sure you understand the behaviour and limitations of using the fixed point format. What is the biggest number you can represent using the Q3.28 format? See what happens if you try to store a number bigger than this in the fixedpt datatype.

Finally, vary the fixed point format to see the difference in the output quality. Try other representations which use a shorter datatype, such as Q3.12 (which uses 16-bit 'short int') and Q3.4 (which uses 8-bit 'char'). What is the impact on error when switching to these smaller datatypes?

Try it yourself: Measure the difference in cycle count between Q3.28 and Q3.12. Can you think of a use case where Q3.12 would be preferred over Q3.28

4.1 Generating fixed point waves

Calculate points for a sine wave and store them using a fixed point format. Think carefully about how the stored points correspond to the values you should output to the 12-bit DAC? It is highly recommended that you print out a few values, hand-calculate what the value written to the DAC should be before coding this part. Once you get a proper sine wave, write down the frequency and execution time you get on the results page.

Next, repeat the experiments you did for generating a square wave, now using fixed point numbers. Once again, record the frequency your fixed point code while varying the number of terms being added. What do you think is the cause of the difference in frequency compared to your earlier floating point version?

5. In-lab demo

During your lab, you must show your TA the completed results page. You must also demo your code outputting a square wave using both floating point and Q3.28 fixed point formats. As recommended above, setting up the pushbutton on the board to quickly switch between these formats will speed up your demo.

RESULTS

Generating sine waves

	Floatin	Fixed point (Q3.28)		
	sin()	LUT	LUT	
Frequency				
Execution cycles				

Generating square waves

Number of terms	1	2	3	4	5	6
Floating point						
Q3.28 fixed point						