

Scanned by TapScanner

Him: Bimulate & plot characteristics of power MOSFET &

Bostware Used: Multibin.

Theory:

Power MOSFETS

A metal oxide semiconductor field-effect transistors (MOSFET) is a recent device developed by combining the areas of field-effect connect & Mos Technology.

A power Mosfet has 3 terminals called drain, source & gate in place & the corresponding 3 terminals collector, emitter & base for BIT In circuit symbol of power Mosfet arrow indicates the direction of electron flow. A BIT is a current controlled device whereas a power Mosfet is a voltage controlled devices. As its operation depends upon the flow of majority carriers only. MOSFET is a unipolar device The control signal Cor gate current) required in a Mosfet is a unipolar device. The control signal or base current in BIT is much larger than the Cgate current). This is because of the fact that the gate circuit impedance en Mosfet gate to be driven directly from microelectrons circuits. BIT satisfies from 2nd breakdown voltage whereas Mosfet is free from this problem. Power Mosfets are now finding increasing applications in low-power nigh frequency converters Power Mosfets are of 2 types, n-channel enhancement Mosfet & pchanned enhancement MOSFET out & these 2-types n-channel enhancement Mosfet is more common because of higher mobility

FOR EDUCATIONAL USE


q electrons. As such only the type of Mosfet is studied.

A simplified structure of n-channel planar Mosfet of low power rating is showing on p-substrate, 2 heavily doped, n regions are diffused as shown. An insulating layer of silicon dioxide (3io2) is developed on the surface. Now this insulating layer is etched in order to embed metallic source & drain terminals A layer of metal is deposited on sion layer so as to form gate of MosfeT. when gate circuit is open no current flows from drain to source & load because of one reverse-biased n-p junction when gate is made positive with respect to source an electric field is established Eventually induced negative charges in the p-substrate below sion layer are formed. These -ve charges called electrons from n-channel & current can flow from drain to source as shown by the arrow If ves ls made more tre, n-channel becomes more deep & therefore more current flows from 0 to 5. This shows that drain current IB is enhanced by the gradual increase of gate voltage, hence the name enhancement MosfET.

The main disadvantage of n-channel planar Mosfet is that conducting n-channel is between drain & source gives large on state resistance. This leads to high power dissipation in n-channel. This shows that planar Mosfet construction is feasible only for low-power Mosfets.

Diffussed metal-oxide ~ semiconductor (DMOS) structured for n~ channel which is quite common for power Mosfets. On n+ substrate high resistivity n~layer is epitaxially grown the thickness of n~ layer determined the voltage blocking capability of the device. On the other side of nt substrate, a metal layer is desposited to form the drain terminal Now p regions are diffused in the epitaxially grown n layer datexmines. nt layer region are diffused in p regions.

Sundaram



Scanned by TapScanner

As before 5io2 layer is added which is then etched so as to fit metallic source & gate terminals. A power Mosfet actually consists of a parallel connections of thousands of basic Mosfet cells on the same chip of sillicon

## Working of n-channel BMOS power MOSFET:

When gate circuit voltage is zero & VDD is present no, po junctions are reverse biased & no current flows from drain to source When gate terminal is made positive with respect to source an electric field is established & electrons from nochannel in the regions as shown so a current from drain to source is established as indicated by arrows with gate voltage increased current ID also increases as expected length of nochannel can be controlled & therefore on resistance can be made low IF short length is used for the channel

### MOSFET Characteristics:

a) Transfer Characteristics:


This characteristic shows variation of drain current ID as a function of gate-source voltage Ves Fig c shows transfer characteristics for n- channel power Mosfet It is seen that there is threshold voltage Vest below which the device is off. The magnitude of Vest is of order 2 to 3V.

b) Output Characteristics:

Power Mosfet old characteristics indicate variation of drain currentist as a function of VBs as parameter for low values of VDs graph ID-Vos is linear constant value of on resistance RDs=VDs/ID for given ves if VDs 15 t old characteristic 1s flat dr. ID is constant A load fine Intersects old of A&B

A ~ fully on cond^& B~ fully off state: PMOSFET is switch at Aor B. 11 KC BJI

Sundaram



# Insulated Gate Bipolar Transistor (IGBT)


This device combines into the area of power Mosfet technology. This device combines into the advantage of both Mosfet & BIT 50 an IGBT has high ilp impedance line a Mosfet & low-on-state power loss as in a BIT IGBT is also known as metal-oxide insulated gate insulator transistor (MOSIGT), conductively-modulated field effect transistor (COMFET) or gain-modulated FET (GMFET). IGBT is constructed virtually in the same manner as a power MOSFET. There is however a major difference in the substrate. The nt layer substrate at the drain in a power MOSFET is now nt layer substrate at the drain in a power MOSFET is now substituted in the IGBT by a pt layer substrate called collector line a power MOSFET an IGBT has also thousands of basic structure cells connected approximately on single chip of Bilicon.

## WORKING:

Sund it in

when gate is positive with respect to emitter & with gate-emitter voltage more than the threshold voltage of IGBT an n-channel's formed in the p-regions as in power Mosfet. This n-channel short circuits the n- regions with nt emitter regions. An electron movement in the n-channel is formed in turn causes Substantial hole injection from pt substrate layer Into the epitaxial n layer. Eventually a forward current is established

FOR EDUCATIONAL USE



The 3 layers pt, n- & p constitute a porp transistor with pt as emitter n- as base & p as collector Also no, p & nt layers constitute npn transistor. Here no serves as base for pnp transistor & also as collector for npn transistor. P serves as collector for npn transistor. P serves as collector for pnp device & also as base for npn transistor. The two pnp & npn transistors can therefore be connected to given the equivalent CKT of an IGBT.

IGBT characteristics

a) Transfer characteristics:

It is plot of Iqc versus gate~emitter voltage Vqs. This characteristic is identical to the power Mosfet. When Vqs is less than threshold voltage Vqff. IqBT is in off-state. When device is off junction blocks forward voltage. & in case reverse voltage appears across collector & emitter junction I blocks it.

b) BTATIC V-I characteristics:

It shows the plot of collector current Ic vs collector-cmitter voltages vere for various values of gake-cmitter voltages. In forward direction the shape of the olp characteristics is similar to that of BIT But here the controlling

controlled device


Conclusion: The simulation of transfer & output characteristics of power Mosfet & IGBT have implemented on Multisim and well comprehended.

FOR EDUCATIONAL USE


Name: Rahul Vemuri Roll No:33 Class:D16A

#### **Experiment No. 2 A**


Aim: - To Simulate input and output of characteristics of Power MOSFET




#### Transfer characteristics



Output characteristics:







#### **Experiment No. 2 B**


Aim: - To Simulate input and output of characteristics of IGBT


Transfer characteristics





#### **Dutput characteristics**





 $\frac{\text{wge Voltage (V)}}{\text{wge=0.5.4(NCE)}} \text{wge=1.5.4(NCE)} \text{wge=1.5.4(NCE)} \text{wge=1.5.4(NCE)} \text{wge=2.5.4(NCE)} \text{wge=2.5.4(NCE)} \text{wge=2.5.4(NCE)} \text{wge=3.5.4(NCE)} \text{wge=4.5.4(NCE)} \text{wge$