
Experiment No.- 7 To design IIR lowpass filter.

```
clc;clear all;close all;
For data sampled at 20000 Hz, design a lowpass filter with no more
 than 3 dB of ripple
%in a passband from 0 to 4200 Hz, and at least 60 dB of attenuation in
 the stopband.
%Find the filter order and cutoff frequency
fs = 20000;
Wp = 4200/(fs/2);
Ws = 5000/(fs/2);
Rp = 3;
Rs = 60;
[n,Wn] = buttord(Wp,Ws,Rp,Rs);
disp('Order of filter is - ');
disp(n)
disp('Cuttoff frequency (normalized) of filter is - ');
disp(Wn)
%returns the lowest order, n, of the digital Butterworth filter with
%than Rp dB of passband ripple and at least Rs dB of attenuation in
 the stopband.
%Wp and Ws are respectively the passband and stopband edge frequencies
 of the filter.
[b,a] = butter(n,Wn,'Low');
%b,a - Transfer function coefficients
fvtool(b,a)
title(sprintf('n = %d IIR Butterworth Highpass Filter',n))
[z,p,k] = butter(n,Wn);
sos = zp2sos(z,p,k);
%freqz(sos,5120,10000)
%title(sprintf('n = %d Butterworth Lowpass Filter',n))
Order of filter is -
    28
Cuttoff frequency (normalized) of filter is -
    0.4223
```



Published with MATLAB® R2018b