

XST User Guide

8.1i





Xilinx is disclosing this Document and Intellectual Property (hereinafter "the Design") to you for use in the development of designs to operate on, or interface with Xilinx FPGAs. Except as stated herein, none of the Design may be copied, reproduced, distributed, republished, downloaded, displayed, posted, or transmitted in any form or by any means including, but not limited to, electronic, mechanical, photocopying, recording, or otherwise, without the prior written consent of Xilinx. Any unauthorized use of the Design may violate copyright laws, trademark laws, the laws of privacy and publicity, and communications regulations and statutes.

Xilinx does not assume any liability arising out of the application or use of the Design; nor does Xilinx convey any license under its patents, copyrights, or any rights of others. You are responsible for obtaining any rights you may require for your use or implementation of the Design. Xilinx reserves the right to make changes, at any time, to the Design as deemed desirable in the sole discretion of Xilinx. Xilinx assumes no obligation to correct any errors contained herein or to advise you of any correction if such be made. Xilinx will not assume any liability for the accuracy or correctness of any engineering or technical support or assistance provided to you in connection with the Design.

THE DESIGN IS PROVIDED "AS IS" WITH ALL FAULTS, AND THE ENTIRE RISK AS TO ITS FUNCTION AND IMPLEMENTATION IS WITH YOU. YOU ACKNOWLEDGE AND AGREE THAT YOU HAVE NOT RELIED ON ANY ORAL OR WRITTEN INFORMATION OR ADVICE, WHETHER GIVEN BY XILINX, OR ITS AGENTS OR EMPLOYEES. XILINX MAKES NO OTHER WARRANTIES, WHETHER EXPRESS, IMPLIED, OR STATUTORY, REGARDING THE DESIGN, INCLUDING ANY WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, TITLE, AND NONINFRINGEMENT OF THIRD-PARTY RIGHTS.

IN NO EVENT WILL XILINX BE LIABLE FOR ANY CONSEQUENTIAL, INDIRECT, EXEMPLARY, SPECIAL, OR INCIDENTAL DAMAGES, INCLUDING ANY LOST DATA AND LOST PROFITS, ARISING FROM OR RELATING TO YOUR USE OF THE DESIGN, EVEN IF YOU HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. THE TOTAL CUMULATIVE LIABILITY OF XILINX IN CONNECTION WITH YOUR USE OF THE DESIGN, WHETHER IN CONTRACT OR TORT OR OTHERWISE, WILL IN NO EVENT EXCEED THE AMOUNT OF FEES PAID BY YOU TO XILINX HEREUNDER FOR USE OF THE DESIGN. YOU ACKNOWLEDGE THAT THE FEES, IF ANY, REFLECT THE ALLOCATION OF RISK SET FORTH IN THIS AGREEMENT AND THAT XILINX WOULD NOT MAKE AVAILABLE THE DESIGN TO YOU WITHOUT THESE LIMITATIONS OF LIABILITY.

The Design is not designed or intended for use in the development of on-line control equipment in hazardous environments requiring fail-safe controls, such as in the operation of nuclear facilities, aircraft navigation or communications systems, air traffic control, life support, or weapons systems ("High-Risk Applications"). Xilinx specifically disclaims any express or implied warranties of fitness for such High-Risk Applications. You represent that use of the Design in such High-Risk Applications is fully at your risk.

Copyright © 1995-2005 Xilinx, Inc. All rights reserved. XILINX, the Xilinx logo, and other designated brands included herein are trademarks of Xilinx, Inc. PowerPC is a trademark of IBM, Inc. All other trademarks are the property of their respective owners.

About This Guide

This manual describes Xilinx® Synthesis Technology (XST) support for HDL languages, Xilinx® devices, and constraints for the ISE™ software. The manual also discusses FPGA and CPLD optimization techniques and explains how to run XST from Project Navigator Process window and command line.

Guide Contents

This manual contains the following chapters and appendixes.

- [Chapter 1, “Introduction,”](#) provides a basic description of XST and lists supported architectures.
- [Chapter 2, “HDL Coding Techniques,”](#) describes a variety of VHDL and Verilog coding techniques that can be used for various digital logic circuits, such as registers, latches, tristates, RAMs, counters, accumulators, multiplexers, decoders, and arithmetic operations. The chapter also provides coding techniques for state machines and black boxes.
- [Chapter 3, “FPGA Optimization,”](#) explains how constraints can be used to optimize FPGAs and explains macro generation. The chapter also describes the Virtex™ primitives that are supported.
- [Chapter 4, “CPLD Optimization,”](#) discusses CPLD synthesis options and the implementation details for macro generation.
- [Chapter 5, “Design Constraints,”](#) describes constraints supported for use with XST. The chapter explains which attributes and properties can be used with FPGAs, CPLDs, VHDL, and Verilog. The chapter also explains how to set options from the Process Properties dialog box in Project Navigator.
- [Chapter 6, “VHDL Language Support,”](#) explains how VHDL is supported for XST. The chapter provides details on the VHDL language, supported constructs, and synthesis options in relationship to XST.
- [Chapter 7, “Verilog Language Support,”](#) describes XST support for Verilog constructs and meta comments.
- [Chapter 8, “Mixed Language Support,”](#) describes how to run an XST project that mixes Verilog and VHDL designs.
- [Chapter 9, “Log File Analysis,”](#) describes the XST log file, and explains what it contains.
- [Chapter 10, “Command Line Mode,”](#) describes how to run XST using the command line. The chapter describes the XST, run and set commands and their options.
- [Appendix A, “XST Naming Conventions,”](#) discusses net naming and instance naming conventions.

Additional Resources

To find additional documentation, see the Xilinx website at:

<http://www.xilinx.com/literature>.

To search the Answer Database of silicon, software, and IP questions and answers, or to create a technical support WebCase, see the Xilinx website at:

<http://www.xilinx.com/support>.

Conventions

This document uses the following conventions. An example illustrates each convention.

Typographical

The following typographical conventions are used in this document:

Convention	Meaning or Use	Example
Courier font	Messages, prompts, and program files that the system displays	speed grade: - 100
Courier bold	Literal commands that you enter in a syntactical statement	ngdbuild design_name
Helvetica bold	Commands that you select from a menu	File →Open
	Keyboard shortcuts	Ctrl+C
<i>Italic font</i>	Variables in a syntax statement for which you must supply values	ngdbuild design_name
	References to other manuals	See the <i>Development System Reference Guide</i> for more information.
	Emphasis in text	If a wire is drawn so that it overlaps the pin of a symbol, the two nets are <i>not</i> connected.
Square brackets []	An optional entry or parameter. However, in bus specifications, such as bus [7:0] , they are required.	ngdbuild [option_name] design_name
Braces { }	A list of items from which you must choose one or more	lowpwr ={on off}
Vertical bar	Separates items in a list of choices	lowpwr ={on off}

Convention	Meaning or Use	Example
Vertical ellipsis . . .	Repetitive material that has been omitted	IOB #1: Name = QOUT' IOB #2: Name = CLKIN' . .
Horizontal ellipsis ...	Repetitive material that has been omitted	allow block <i>block_name</i> <i>loc1 loc2... locn;</i>

Online Document

The following conventions are used in this document:

Convention	Meaning or Use	Example
Blue text	Cross-reference link to a location in the current file or in another file in the current document	See the section “ Additional Resources ” for details. Refer to “ Title Formats ” in Chapter 1 for details.
Red text	Cross-reference link to a location in another document	See Figure 2-5 in the <i>Virtex-II™ Platform FPGA User Guide</i> .
<u>Blue, underlined text</u>	Hyperlink to a website (URL)	Go to http://www.xilinx.com for the latest speed files.

Table of Contents

Preface: About This Guide

Guide Contents	3
Additional Resources	4
Conventions	4
Typographical	4
Online Document	5

Chapter 1: Introduction

Architecture Support	27
XST Flow	27
What's New	27
HDL Language Support	27
VHDL	27
Verilog	27
Macro Inference	28
Design Constraints	29
FPGA Flow	29
Log File	29
Documentation	29
XST in Project Navigator	29

Chapter 2: HDL Coding Techniques

Introduction	35
Signed/Unsigned Support	46
Registers	47
Log File	48
Related Constraints	48
Flip-flop with Positive-Edge Clock	49
VHDL Code	49
Verilog Code	50
Flip-flop with Negative-Edge Clock and Asynchronous Clear	50
VHDL Code	51
Verilog Code	52
Flip-flop with Positive-Edge Clock and Synchronous Set	52
VHDL Code	53
Verilog Code	54
Flip-flop with Positive-Edge Clock and Clock Enable	54
VHDL Code	55
Verilog Code	56
4-bit Register with Positive-Edge Clock, Asynchronous Set and Clock Enable	56
VHDL Code	57
Verilog Code	57
Latches	58
Log File	58

Related Constraints	58
Latch with Positive Gate	59
VHDL Code	59
Verilog Code.....	60
Latch with Positive Gate and Asynchronous Clear	60
VHDL Code	61
Verilog Code.....	61
4-bit Latch with Inverted Gate and Asynchronous Preset.....	62
VHDL Code	62
Verilog Code.....	63
Tristates	64
Log File	64
Related Constraints	64
Description Using Combinatorial Process and Always Block	64
VHDL Code	65
Verilog Code.....	66
Description Using Concurrent Assignment.....	66
VHDL Code	66
Verilog Code.....	67
Counters	67
Log File	68
Related Constraints	68
4-bit Unsigned Up Counter with Asynchronous Clear	68
VHDL Code	69
Verilog Code.....	69
4-bit Unsigned Down Counter with Synchronous Set	70
VHDL Code	70
Verilog Code.....	71
4-bit Unsigned Up Counter with Asynchronous Load from Primary Input	71
VHDL Code	72
Verilog Code.....	73
4-bit Unsigned Up Counter with Synchronous Load with a Constant	73
VHDL Code	74
Verilog Code.....	75
4-bit Unsigned Up Counter with Asynchronous Clear and Clock Enable	75
VHDL Code	76
Verilog Code.....	77
4-bit Unsigned Up/Down counter with Asynchronous Clear	77
VHDL Code	78
Verilog Code.....	79
4-bit Signed Up Counter with Asynchronous Reset.....	79
VHDL Code	80
Verilog Code.....	81
4-bit Signed Up Counter with Asynchronous Reset and Modulo Maximum	81
VHDL Code	82
Verilog Code.....	83
Related Constraints.....	83
Accumulators	83
Log File	84
Related Constraints	84
4-bit Unsigned Up Accumulator with Asynchronous Clear	85
VHDL Code	85
Verilog Code.....	86

Considerations for Virtex-4 Devices	86
Shift Registers	87
Log File	89
Related Constraints	89
8-bit Shift-Left Register with Positive-Edge Clock, Serial In and Serial Out	89
VHDL Code	90
Verilog Code	91
8-bit Shift-Left Register with Negative-Edge Clock, Clock Enable, Serial In and Serial Out	91
VHDL Code	92
Verilog Code	93
8-bit Shift-Left Register with Positive-Edge Clock, Asynchronous Clear, Serial In and Serial Out	93
VHDL Code	94
Verilog Code	95
8-bit Shift-Left Register with Positive-Edge Clock, Synchronous Set, Serial In and Serial Out	95
VHDL Code	96
Verilog Code	97
8-bit Shift-Left Register with Positive-Edge Clock, Serial In and Parallel Out	97
VHDL Code	98
Verilog Code	99
8-bit Shift-Left Register with Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out	99
VHDL Code	100
Verilog Code	101
8-bit Shift-Left Register with Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out	101
VHDL Code	102
Verilog Code	103
8-bit Shift-Left/Shift-Right Register with Positive-Edge Clock, Serial In and Parallel Out	103
VHDL Code	104
Verilog Code	105
Dynamic Shift Register	105
16-bit Dynamic Shift Register with Positive-Edge Clock, Serial In and Serial Out	105
LOG File	106
Related Constraints	107
VHDL Code	107
Verilog Code	108
Multiplexers	108
Log File	111
Related Constraints	111
4-to-1 1-bit MUX using IF Statement	111
VHDL Code	112
Verilog Code	112
4-to-1 MUX Using Case Statement	113
VHDL Code	113
Verilog Code	114
4-to-1 MUX Using Tristate Buffers	114
VHDL Code	115
Verilog Code	115
No 4-to-1 MUX	116

VHDL Code	116
Verilog Code.....	117
Decoders.....	117
Log File	117
Related Constraints	118
VHDL (One-Hot)	118
Verilog (One-Hot)	119
VHDL (One-Cold)	119
Verilog (One-Cold)	120
Decoders with Unselected Outputs.....	121
VHDL Code (No Decoder Inference)	121
Verilog Code (No Decoder Inference).....	122
VHDL Code (Decoder Inference)	122
Verilog Code (Decoder Inference).....	123
Priority Encoders.....	124
Log File	124
3-Bit 1-of-9 Priority Encoder.....	124
Related Constraint	124
VHDL Code	124
Verilog Code	125
Logical Shifters	126
Log File	126
Related Constraints	126
Example 1	127
VHDL Code	127
Verilog Code.....	128
Example 2	128
VHDL Code	128
Verilog Code.....	129
Example 3	130
VHDL Code	130
Verilog Code.....	131
Arithmetic Operations	131
Adders, Subtractors, Adders/Subtractors	132
Log File	132
Related Constraints.....	132
Unsigned 8-bit Adder.....	132
Unsigned 8-bit Adder with Carry In.....	133
Unsigned 8-bit Adder with Carry Out	135
Unsigned 8-bit Adder with Carry In and Carry Out.....	136
Simple Signed 8-bit Adder	138
Unsigned 8-bit Subtractor.....	140
Unsigned 8-bit Adder/Subtractor	141
Considerations for Virtex-4 Devices	142
Comparators (=, /=, <, <=, >, >=)	143
Log File	143
Unsigned 8-bit Greater or Equal Comparator.....	143
Multipliers.....	145
Large Multipliers Using Block Multipliers	145
Registered Multiplier	145
Considerations for Virtex-4 Devices	145
Multiplication with Constant	146
Log File	146

Related Constraints	147
Unsigned 8x4-bit Multiplier	147
Pipelined Multipliers	148
Multiply Adder/Subtractor	155
Multiplier Adder with 2 Register Levels on Multiplier Inputs	157
Multiplier Adder/Subtractor with 2 Register Levels on Multiplier Inputs	159
Multiply Accumulate (MAC)	161
Multiplier Up Accumulate with Register After Multiplication	163
Multiplier Up/Down Accumulate with Register After Multiplication	164
Dividers	166
Log File	167
Related Constraints	167
Division By Constant 2	167
Resource Sharing	168
Log File	169
Related Constraint	169
Example	169
RAMs/ROMs	171
Log File	172
Related Constraints	173
Virtex-II/Virtex-4/Spartan-3 RAM Read/Write Modes	173
Read-First Mode	173
Write-First Mode	175
No-Change Mode	179
Single-Port RAM with Asynchronous Read	181
VHDL Code	181
Verilog Code	182
Single-Port RAM with False Synchronous Read	183
VHDL	183
Verilog	184
VHDL Code	185
Verilog Code	187
Single-Port RAM with Synchronous Read (Read Through)	187
VHDL Code	188
Verilog Code	189
Single-Port RAM with Enable	189
VHDL Code	190
Verilog Code	191
Dual-Port RAM with Asynchronous Read	192
VHDL Code	193
Verilog Code	194
Dual-Port RAM with False Synchronous Read	195
VHDL Code	195
Verilog Code	197
Dual-Port RAM with Synchronous Read (Read Through)	198
VHDL Code	199
Verilog Code	200
Using More than One Clock	200
Dual-Port RAM with One Enable Controlling Both Ports	204
VHDL Code	205
Verilog Code	206
Dual-Port RAM with Enable on Each Port	207
VHDL Code	208

Verilog Code.....	209
Dual-Port Block RAM with Different Clocks.....	210
VHDL Code	211
Verilog Code.....	212
Dual-Port Block RAM with Two Write Ports	212
VHDL Code	213
Verilog Code	214
Write-First.....	215
Read-First	216
No-Change	216
Multiple-Port RAM Descriptions.....	216
VHDL Code	217
Verilog Code.....	218
Block RAM with Reset.....	218
VHDL Code	220
Verilog Code.....	221
Block RAM with Optional Output Registers.....	221
VHDL Code	221
Verilog Code.....	223
Initializing RAM.....	225
VHDL Code	226
Initializing RAM from an External File.....	229
Using System Tasks to Initialize RAM from an External File	233
Limitations	234
ROMs Using Block RAM Resources	235
VHDL Code	236
Verilog Code.....	239
Pipelined Distributed RAM	242
Limitations	242
Log File.....	243
VHDL Code	244
Verilog Code.....	245
State Machine.....	245
FSM with 1 Process	247
VHDL Code	247
Verilog Code.....	248
FSM with 2 Processes	249
VHDL Code	249
Verilog Code.....	251
FSM with 3 Processes	252
VHDL Code	252
Verilog Code.....	254
State Registers.....	255
Next State Equations	255
Unreachable States	255
FSM Outputs	255
FSM Inputs	255
State Encoding Techniques.....	255
Auto	256
One-Hot	256
Gray	256
Compact	256
Johnson	256

Sequential	256
Speed1.....	256
User.....	256
Log File	257
RAM-based FSM Synthesis.....	258
Safe FSM Implementation.....	259
Black Box Support	259
Log File	260
Related Constraints	260
VHDL Code	260
Verilog Code	261

Chapter 3: FPGA Optimization

Introduction	263
Virtex Specific Synthesis Options	264
Macro Generation.....	265
Arithmetic Functions	265
Loadable Functions	265
Multiplexers	266
Priority Encoder	266
Decoder	266
Shift Register.....	267
RAMs	267
ROMs	268
Using DSP48 Block Resources.....	269
Mapping Logic onto Block RAM	270
VHDL Code	271
Verilog Code	271
LOG	272
VHDL Code	272
Verilog Code	273
LOG	273
Flip-Flop Retiming	274
Incremental Synthesis Flow	274
INCREMENTAL_SYNTHESIS:	274
Example	275
RESYNTHESIZE.....	275
Speed Optimization Under Area Constraint	278
Log File Analysis	280
Design Optimization	280
Resource Usage	280
Device Utilization summary.....	281
Clock Information	281
Timing Report	281
Timing Summary	283
Timing Detail	283
Implementation Constraints.....	284
Virtex Primitive Support	284
VHDL Code	286
Verilog Code	287

Log File	288
Related Constraints	288
Cores Processing	288
Specifying INITs and RLOCs in HDL Code	290
Passing an INIT Value via the LUT_MAP Constraint	290
VHDL Code	290
Verilog Code.....	291
Specifying INIT Value for a Flip-Flop.....	293
VHDL Code	293
Verilog Code.....	294
Specifying INIT and RLOC Value for a Flip-Flop.....	294
VHDL Code	295
Verilog Code.....	296
PCI Flow.....	297

Chapter 4: CPLD Optimization

CPLD Synthesis Options	299
Introduction	299
Global CPLD Synthesis Options	299
Families.....	299
List of Options	300
Implementation Details for Macro Generation.....	300
Log File Analysis.....	301
Constraints	303
Improving Results	303
How to Obtain Better Frequency?.....	303
How to Fit a Large Design?	304

Chapter 5: Design Constraints

Introduction	305
Setting Global Constraints and Options	306
Synthesis Options.....	306
HDL Options	310
Xilinx Specific Options	313
Other XST Command Line Options	316
Custom Compile File List	316
VHDL Attribute Syntax	316
Verilog Meta Comment Syntax	317
Verilog-2001 Attributes.....	317
Syntax.....	317
Example 1	317
Example 2	318
Example 3	318
Example 4	318
Limitations	318
XST Constraint File (XCF).....	318
XCF Syntax and Utilization	318
Native vs. Non-Native UCF Constraints Syntax.....	319
Limitations	319

General Constraints	320
Add I/O Buffers	320
Architecture Support	320
Applicable Elements	320
Propagation Rules	321
Syntax Examples	321
Box Type	321
BOX_TYPE Architecture Support	321
Applicable Elements	322
Propagation Rules	322
Syntax Examples	322
Bus Delimiter	322
Architecture Support	322
Applicable Elements	323
Syntax Examples	323
Case	323
Architecture Support	323
Applicable Elements	323
Syntax Examples	323
Case Implementation Style	324
Architecture Support	324
Applicable Elements	324
Propagation Rules	324
Syntax Examples	324
Full Case (Verilog)	324
Architecture Support	325
Applicable Elements	325
Propagation Rules	325
Syntax Examples	325
Generate RTL Schematic	325
Architecture Support	326
Applicable Elements	326
Syntax Examples	326
Duplication Suffix	326
Architecture Support	326
Applicable Elements	326
Syntax Examples	327
Hierarchy Separator	327
Architecture Support	327
Applicable Elements	327
Syntax Examples	327
Iostandard	328
Keep	328
Library Search Order	328
Architecture Support	328
Applicable Elements	328
Syntax Examples	329
LOC	329
Optimization Effort	329
Architecture Support	329
Applicable Elements	330
Propagation Rules	330
Syntax Examples	330
Project Navigator	331

Optimization Goal	331
Architecture Support	331
Applicable Elements	331
Propagation Rules	331
Syntax Examples	332
Parallel Case (Verilog)	332
Architecture Support	332
Applicable Elements	333
Propagation Rules	333
Syntax Examples	333
RLOC	333
Synthesis Constraint File	334
Architecture Support	334
Applicable Elements	334
Propagation Rules	334
Syntax Examples	334
Translate Off/Translate On (Verilog/VHDL)	335
Architecture Support	335
Applicable Elements	335
Propagation Rules	335
Syntax Examples	335
Use Synthesis Constraints File	335
Architecture Support	335
Applicable Elements	336
Propagation Rules	336
Syntax Examples	336
Verilog Include Directories (Verilog Only)	336
Architecture Support	336
Applicable Elements	336
Propagation Rules	336
Syntax Examples	336
Verilog 2001	337
Architecture Support	337
Applicable Elements	337
Propagation Rules	337
Syntax Examples	337
HDL Library Mapping File (.INI File)	337
Architecture Support	338
Applicable Elements	338
Propagation Rules	338
Syntax Examples	338
Work Directory	339
Architecture Support	339
Applicable Elements	339
Propagation Rules	340
Syntax Examples	340
HDL Constraints	340
Automatic FSM Extraction	340
Architecture Support	340
Applicable Elements	341
Propagation Rules	341
Syntax Examples	341
Enumerated Encoding (VHDL)	342

Architecture Support	342
Applicable Elements	343
Propagation Rules	343
Syntax Examples	343
Equivalent Register Removal	343
Architecture Support	344
Applicable Elements	344
Propagation Rules	344
Syntax Examples	344
FSM Encoding Algorithm	345
Architecture Support	345
Applicable Elements	346
Propagation Rules	346
Syntax Examples	346
Project Navigator	347
Mux Extraction	347
Architecture Support	347
Applicable Elements	348
Propagation Rules	348
Syntax Examples	348
Register Power Up	349
Architecture Support	349
Applicable Elements	349
Propagation Rules	349
Syntax Examples	350
Resource Sharing	350
Architecture Support	351
Applicable Elements	351
Propagation Rules	351
Syntax Examples	351
Recovery State	352
Architecture Support	352
Applicable Elements	352
Propagation Rules	352
Syntax Examples	353
Safe Implementation	353
Architecture Support	353
Applicable Elements	353
Propagation Rules	353
Syntax Examples	354
Signal Encoding	354
Architecture Support	355
Applicable Elements	355
Propagation Rules	355
Syntax Examples	355
FPGA Constraints (non-timing)	356
Buffer Type	356
Architecture Support	356
Applicable Elements	357
Propagation Rules	357
Syntax Examples	357
BUFGCE	357
Architecture Support	358

Applicable Elements	358
Propagation Rules	358
Syntax Examples	358
Cores Search Directories	359
Architecture Support	359
Applicable Elements	359
Propagation Rules	359
Syntax Examples	360
Decoder Extraction	360
Architecture Support	360
Applicable Elements	360
Propagation Rules	361
Syntax Examples	361
DSP Utilization Ratio	362
Architecture Support	362
Applicable Elements	362
Propagation Rules	362
Syntax Examples	362
Project Navigator	363
FSM Style	363
Architecture Support	363
Applicable Elements	364
Propagation Rules	364
Syntax Examples	364
Resynthesize	364
Architecture Support	365
Applicable Elements	365
Propagation Rules	365
Syntax Examples	365
Incremental Synthesis	366
Architecture Support	366
Applicable Elements	366
Propagation Rules	366
Syntax Examples	367
Keep Hierarchy	367
Architecture Support	368
Applicable Elements	369
Propagation Rules	369
Syntax Examples	369
Logical Shifter Extraction	370
Architecture Support	370
Applicable Elements	370
Propagation Rules	371
Syntax Examples	371
Map Logic on BRAM	371
BRAM_MAP Architecture Support	372
BRAM_MAP Applicable Elements	372
BRAM_MAP Propagation Rules	372
BRAM_MAP Syntax Examples	372
Max Fanout	373
Architecture Support	374
Applicable Elements	374
Propagation Rules	374
Syntax Examples	374

Move Last Stage	375
Architecture Support	376
Applicable Elements	377
Propagation Rules	377
Syntax Examples	377
Move First Stage	378
Architecture Support	378
Applicable Elements	378
Propagation Rules	379
Syntax Examples	379
Project Navigator	379
Multiplier Style	379
Architecture Support	380
Applicable Elements	380
Propagation Rules	380
Syntax Examples	380
Mux Style	381
Architecture Support	381
Applicable Elements	382
Propagation Rules	382
Examples	382
Number of Global Clock Buffers	383
Architecture Support	383
Applicable Elements	383
Propagation Rules	383
Syntax Examples	384
Number of Regional Clock Buffers	384
Architecture Support	384
Applicable Elements	385
Propagation Rules	385
Syntax Examples	385
Optimize Instantiated Primitives	385
Architecture Support	385
Applicable Elements	386
Propagation Rules	386
Syntax Examples	386
Pack I/O Registers into IOBs	387
Priority Encoder Extraction	387
Architecture Support	387
Applicable Elements	387
Propagation Rules	387
Syntax Examples	388
RAM Extraction	388
Architecture Support	389
Applicable Elements	389
Propagation Rules	389
Syntax Examples	389
XCF	390
RAM Style	390
Architecture Support	390
Applicable Elements	391
Propagation Rules	391
Syntax Examples	391
Register Balancing	392

Architecture Support	394
Applicable Elements	394
Propagation Rules	394
Syntax Examples	394
Register Duplication	395
Architecture Support	396
Applicable Elements	396
Propagation Rules	396
Syntax Examples	396
ROM Extraction	397
Architecture Support	397
Applicable Elements	397
Propagation Rules	398
Syntax Examples	398
ROM Style	398
Architecture Support	399
Applicable Elements	399
Propagation Rules	399
Syntax Examples	399
Shift Register Extraction	400
Architecture Support	400
Applicable Elements	401
Propagation Rules	401
Syntax Examples	401
Slice Packing	402
Architecture Support	402
Applicable Elements	402
Propagation Rules	403
Syntax Examples	403
Useofskewlines	403
XOR Collapsing	403
Architecture Support	403
Applicable Elements	404
Propagation Rules	404
Syntax Examples	404
Slice Utilization Ratio	405
Architecture Support	405
Applicable Elements	405
Propagation Rules	405
Syntax Examples	406
Slice Utilization Ratio Delta	407
Architecture Support	407
Applicable Elements	407
Propagation Rules	407
Syntax Examples	408
Map Entity on a Single LUT	409
Architecture Support	409
Applicable Elements	410
Propagation Rules	410
Syntax Examples	410
Read Cores	410
Architecture Support	411
Applicable Elements	411
Propagation Rules	411

Syntax Examples	411
Use Carry Chain	412
Architecture Support	412
Applicable Elements	412
Propagation Rules	412
Syntax Examples	412
Convert Tristates to Logic	413
TRISTATE2LOGIC Architecture Support	414
TRISTATE2LOGIC Applicable Elements	414
TRISTATE2LOGIC Propagation Rules	414
TRISTATE2LOGIC Syntax Examples	414
Use Clock Enable	415
Architecture Support	415
Applicable Elements	416
Propagation Rules	416
Syntax Examples	416
Use Synchronous Set	417
Architecture Support	417
Applicable Elements	418
Propagation Rules	418
Syntax Examples	418
VHDL	418
Verilog	418
Use Synchronous Reset	419
Architecture Support	419
Applicable Elements	419
Propagation Rules	419
Syntax Examples	420
Use DSP48	420
Architecture Support	421
Applicable Elements	421
Propagation Rules	421
Syntax Examples	421
CPLD Constraints (non-timing)	422
Clock Enable	422
Architecture Support	423
Applicable Elements	423
Propagation Rules	423
Syntax Examples	423
Data Gate	424
Keep Hierarchy	424
Macro Preserve	424
Architecture Support	424
Applicable Elements	425
Propagation Rules	425
Syntax Examples	425
No Reduce	425
WYSIWYG	425
Architecture Support	426
Applicable Elements	426
Propagation Rules	426
Syntax Examples	426
XOR Preserve	427

Architecture Support	427
Applicable Elements	428
Propagation Rules	428
Syntax Examples	428
Timing Constraints	428
Cross Clock Analysis	429
Architecture Support	429
Applicable Elements	429
Propagation Rules	429
Syntax Examples	429
Write Timing Constraints	430
Architecture Support	430
Applicable Elements	430
Propagation Rules	431
Syntax Examples	431
Clock Signal	431
CLOCK_SIGNAL Architecture Support	431
CLOCK_SIGNAL Applicable Elements	432
CLOCK_SIGNAL Propagation Rules	432
CLOCK_SIGNAL Syntax Examples	432
Global Timing Constraints Support	432
Global Optimization Goal	432
Domain Definitions	433
XCF Timing Constraint Support	433
Period	434
Offset	434
From-To	434
TNM	434
TNM Net	435
TIMEGRP	435
TIG	435
Constraints Summary	435
Implementation Constraints	443
Handling by XST	443
Examples	444
Example 1	444
Example 2	444
Example 3	444
Third Party Constraints	445
Constraints Precedence	449

Chapter 6: VHDL Language Support

Introduction	451
File Type Support	452
Debugging Using Write Operation	454
Limitations	455
Data Types in VHDL	455
Overloaded Data Types	456
Multi-dimensional Array Types	457
Record Types	458
Initial Values	459

Local Reset ¼ Global Reset	459
Default Initial Values on Memory Elements	460
Default Initial Values on Unconnected Ports.....	461
Objects in VHDL	461
Operators	461
Entity and Architecture Descriptions	462
Entity Declaration	462
Architecture Declaration.....	462
Component Instantiation	463
Recursive Component Instantiation	464
Component Configuration	465
Generic Parameter Declaration	465
Generic/Attribute Conflicts	466
Combinatorial Circuits	467
Concurrent Signal Assignments	467
Simple Signal Assignment	467
Selected Signal Assignment	468
Conditional Signal Assignment	468
Generate Statement	468
Combinatorial Process.....	469
If...Else Statement	471
Case Statement	472
For...Loop Statement	473
Sequential Circuits	474
Sequential Process with a Sensitivity List	474
Sequential Process without a Sensitivity List	474
Examples of Register and Counter Descriptions.....	475
Multiple Wait Statements Descriptions	477
Functions and Procedures	478
Assert Statement	480
Packages	482
STANDARD Package	482
IEEE Packages.....	482
Synopsys Packages	483
VHDL Language Support	484
VHDL Reserved Words	490

Chapter 7: Verilog Language Support

Introduction	491
Behavioral Verilog Features	492
Variable Declaration	492
Initial Values.....	492
Arrays.....	493
Multi-dimensional Arrays	494
Data Types	494
Legal Statements	495
Expressions	495
Blocks	498
Modules	498
Module Declaration	498

Verilog Assignments	499
Continuous Assignments	499
Procedural Assignments	499
Combinatorial Always Blocks.....	499
If...Else Statement	500
Case Statement	500
For and Repeat Loops.....	501
While Loops	502
Sequential Always Blocks.....	502
Assign and Deassign Statements	504
Assignment Extension Past 32 Bits	506
Tasks and Functions	506
Recursive Tasks and Functions.....	507
Blocking Versus Non-Blocking Procedural Assignments.....	507
Constants, Macros, Include Files and Comments	508
Constants	508
Macros	508
Include Files	509
Comments.....	509
Generate Statement	510
Generate For	510
Generate If... else.....	510
Generate Case	511
Variable Part Selects	511
Structural Verilog Features.....	512
Parameters	514
Parameter/Attribute Conflicts	514
Verilog Limitations in XST.....	515
Case Sensitivity	515
Blocking and Nonblocking Assignments	516
Integer Handling	517
Verilog Meta Comments	517
Verilog Language Support Tables	518
System Tasks	521
Primitives.....	522
Verilog Reserved Keywords.....	523
Verilog-2001 Support in XST	524

Chapter 8: Mixed Language Support

Introduction	527
Mixed Language Project File	528
VHDL/Verilog Boundary Rules	528
Instantiating a Verilog Module in a VHDL Design	528
Instantiating a VHDL Design Unit in a Verilog Design	529
Port Mapping	530
Generics Support in Mixed Language Projects	530
Library Search Order File.....	531
Project Navigator	531
Command Line.....	531

Search Order Rules	531
Examples	532
Example 1	532
Example 2	532
Example 3	533
Example 4	533

Chapter 9: Log File Analysis

Introduction	535
Reducing the Size of the LOG File	536
Quiet Mode	536
Silent Mode	537
Hiding specific messages	537
Timing Report	538
FPGA Log File	538
CPLD Log File	544

Chapter 10: Command Line Mode

Introduction	549
File Types	549
Names with Spaces	550
Launching XST	550
Setting Up an XST Script	551
Run Command	551
Set Command	553
Elaborate Command	554
Example 1: How to Synthesize VHDL Designs Using Command Line Mode	554
Example 1	555
Script Mode	556
Example 2: How to Synthesize Verilog Designs Using Command Line Mode	557
Example 2	557
Script Mode	558
Example 3: How to Synthesize Mixed VHDL/Verilog Designs Using Command Line Mode	559
Script Mode	560

Appendix A: XST Naming Conventions

Net Naming Conventions	561
Instance Naming Conventions	561
Name Generation Control	562

Index

563

Introduction

This chapter contains the following sections.

- “Architecture Support”
- “XST Flow”
- “What’s New”
- “XST in Project Navigator”

Architecture Support

The software supports the following architecture families in this release.

- Virtex™/-E/-II/-II Pro/-II Pro X/-4
- Spartan™-II/-IIE/-3
- CoolRunner™ XPLA3/-II
- XC9500™/XL/XV

XST Flow

XST is a Xilinx® tool that synthesizes HDL designs to create Xilinx® specific netlist files called NGC files. The NGC file is a netlist that contains both logical design data and constraints that takes the place of both EDIF and NCF files. This manual describes XST support for Xilinx® devices, HDL languages and design constraints. The manual also explains how to use various design optimization and coding techniques when creating designs for use with XST.

What’s New

The following is a list of the major changes to XST for release 8.1i.

HDL Language Support

- All of the coding examples in [Chapter 2, “HDL Coding Techniques”](#) and [Chapter 3, “FPGA Optimization”](#) are now archived and are available in a zip file via ftp links in these chapters. This archive will be updated as changes occur and you no longer need to wait for the next release of this manual for updated coding examples.

VHDL

- Support for File Write capability. See [“File Type Support” in Chapter 6](#).

Verilog

- Support for System Tasks. See “[System Tasks](#)” in Chapter 7.
- Support File Read and Write capability using \$readmemb and \$readmemh. See “[Behavioral Verilog Features](#)” in Chapter 7.
- Support for \$display and \$write assertions. See “[System Tasks](#)” in Chapter 7.
- Support for \$signed and \$unsigned keywords. See “[System Tasks](#)” in Chapter 7.
- Support file handling system tasks. See “[System Tasks](#)” in Chapter 7.
- Support recursive tasks and functions using *automatic* keyword. See “[Recursive Tasks and Functions](#)” in Chapter 7.

Macro Inference

- Improved support for Macro inference for Virtex-4 devices:
 - ◆ Loadable MAC and Loadable Accumulator support.
 - ◆ Improved Macro inference flow, so that DSP48 blocks can be composed more efficiently.
 - ◆ DSP48 recognition and DSP48 chains composition across the hierarchy.
 - ◆ Improved recognition of DSP48 chains (filters, complex multipliers, etc.) and usage of fast DSP48 connections.
 - ◆ Automatic local register balancing, which allows composition of DSP48 blocks.
 - ◆ Automatic available DSP48 resource control per design for all supported macros (except adders).
 - ◆ Ability to specify the number of DSP48 blocks that XST uses via the DSP Utilization Ratio switch. See “[DSP Utilization Ratio](#)” in Chapter 5.
- Support for parity bits usage for block RAM implementation for Virtex-2, Virtex-2 Pro and corresponding Spartan families (Virtex-4 devices are already supported). See “[RAMs/ROMs](#)” in Chapter 2.
- Support for automatic resource choice in ROM implementation when ROM Style is set to *auto*, (small ROMs are implemented as distributed ROMs). See “[RAMs/ROMs](#)” in Chapter 2.
- Inference of Dual-Write Port block RAM for Verilog (VHDL is already supported). See “[Dual-Port Block RAM with Two Write Ports](#)” in Chapter 2.
- Support single and dual-port block RAM initialization via signal declaration mechanism in Verilog (VHDL is already supported.) See “[Initializing RAM](#)” in Chapter 2.
 - ◆ Initialization using initial statement.
 - ◆ Initialization from external text file.
- Support initialization of distributed RAMs via signal initialization process. See “[Initializing RAM](#)” in Chapter 2.
- Support pipelining of distributed RAMs via the new *pipe_distributed* value of the RAM Style constraint. See “[Pipelined Distributed RAM](#)” in Chapter 2 and “[RAM Style](#)” in Chapter 5.
- Support initialization of inferred shift registers via signal initialization process. See “[Specifying INITs and RLOCs in HDL Code](#)” in Chapter 3.

- Inference of shift registers was moved from HDL Synthesis to Advanced HDL Synthesis step in order to reach better quality of results. See [Chapter 9, “Log File Analysis.”](#)

Design Constraints

- Introduced new DSP Utilization Ratio constraint (DSP_UTILIZATION_RATIO) to specify the number of available DSP blocks for synthesis. This constraint is supported only via the command line switch or the XST synthesis properties. See [“DSP Utilization Ratio” in Chapter 5.](#)
- Introduced new Pipeline Distributed RAMs value (PIPE_DISTRIBUTED) for RAM Style constraint. See [“RAM Style” in Chapter 5.](#)
- Introduced the ability to specify the absolute number of slices in Slice Utilization Ratio and Slice Utilization Ratio-Maxmargin constraints. See [“Slice Utilization Ratio”](#) and [“Slice Utilization Ratio Delta” in Chapter 5.](#)

FPGA Flow

Improved messaging related to equivalent register detection and removal.

Log File

- Improved structure of Log file for the Advanced HDL Synthesis step. It now has the same structure as the HDL Synthesis step. See [Chapter 9, “Log File Analysis.”](#)
- Improved reporting related to DSP48 inference. See [Chapter 9, “Log File Analysis.”](#)
- Improved HDL Advisor. XST reports when a latch is inferred from an incomplete case statement.


Documentation

All XST specific constraints were moved from Constraints Guide to XST User's Guide. See [Chapter 5, “Design Constraints.”](#)


XST in Project Navigator

Before synthesizing your design, you can set a variety of options for XST. Following are the instructions to set the options and run XST from Project Navigator. All of these options can also be set from the command line. See [Chapter 5, “Design Constraints,”](#) and [Chapter 10, “Command Line Mode”](#) for details.


1. Select your top-level design in the Sources window.




2. To set the options, right-click **Synthesize - XST** in the Processes window; select **Properties** to display the Process Properties dialog box.



3. Set the desired Synthesis, HDL, and Xilinx® Specific Options in the Process Properties dialog box. For a complete description of these options, refer to “[General Constraints](#)” in Chapter 5.



4. When a design is ready to synthesize, you can invoke XST in Project Navigator. With the top-level source file selected, double-click **Synthesize - XST** in the Processes window.



Note: To run XST from the command line, refer to [Chapter 10, “Command Line Mode”](#) for details.

5. When synthesis is complete, view the results by double-clicking **View Synthesis Report**. Following is a portion of a sample report.




Figure 1-1: View Synthesis Report

HDL Coding Techniques

This chapter contains the following sections:

- “Introduction”
- “Signed/Unsigned Support”
- “Registers”
- “Latches”
- “Tristates”
- “Counters”
- “Accumulators”
- “Shift Registers”
- “Dynamic Shift Register”
- “Multiplexers”
- “Decoders”
- “Priority Encoders”
- “Logical Shifters”
- “Arithmetic Operations”
- “RAMs/ROMs”
- “State Machine”
- “Safe FSM Implementation”
- “Black Box Support”

Introduction

Designs are usually made up of combinatorial logic and macros (for example, flip-flops, adders, subtractors, counters, FSMs, RAMs). The macros greatly improve performance of the synthesized designs. Therefore, it is important to use some coding techniques to model the macros so that they are optimally processed by XST.

During its run, XST first tries to recognize (infer) as many macros as possible. Then all of these macros are passed to the Low Level Optimization step, either preserved as separate blocks or merged with surrounding logic in order to get better optimization results. This filtering depends on the type and size of a macro (for example, by default, 2-to-1 multiplexers are not preserved by the optimization engine). You have full control of the processing of inferred macros through synthesis constraints.

Note: Please refer to Chapter 5, “Design Constraints,” for more details on constraints and their utilization.

There is detailed information about the macro processing in the XST LOG file. It contains the following:

- The set of macros and associated signals, inferred by XST from the VHDL/Verilog source on a block by block basis.

Macro inference is done in two steps: HDL Synthesis and Advanced HDL Synthesis. In the HDL Synthesis step, XST recognizes as many simple macro blocks as possible, such as adders, subtractors, registers, etc. In the Advanced HDL Synthesis step, XST does additional macro processing by improving the macros (for example, pipelining of multipliers) recognized at the HDL synthesis step or by creating the new, more complex ones, such as dynamic shift registers.

Note: Starting with 8.1i release of XST, the Macro Recognition report at the Advanced HDL Synthesis step is formatted the same as the corresponding report at the HDL Synthesis step.

- Starting with release 8.1i, XST gives overall statistics of recognized macros twice. The first place is after the HDL Synthesis step and again after the Advanced HDL Synthesis step.
- Starting with release 8.1i, XST no longer lists statistics of preserved macros in the final report.

The following log sample displays the set of recognized macros on a block by block basis, as well as the overall macro statistics after this step.

```
=====
*          HDL Synthesis
=====
...
Synthesizing Unit <decode>.
    Related source file is "decode.vhd".
    Found 16x10-bit ROM for signal <one_hot>.
    Summary:
        inferred 1 ROM(s).
Unit <decode> synthesized.

Synthesizing Unit <statmach>.
    Related source file is "statmach.vhd".
    Found finite state machine <FSM_0> for signal <current_state>.
-----
| States           | 6
| Transitions     | 11
| Inputs          | 1
| Outputs         | 2
| Clock           | CLK (rising_edge)
| Reset            | RESET (positive)
| Reset type      | asynchronous
| Reset State     | clear
| Power Up State  | clear
| Encoding         | automatic
| Implementation   | LUT
-----
Summary:
    inferred 1 Finite State Machine(s).
Unit <statmach> synthesized.
...
=====
HDL Synthesis Report

Macro Statistics
# ROMs                      : 3
  16x10-bit ROM             : 1
  16x7-bit ROM              : 2
# Counters                   : 2
  4-bit up counter          : 2
=====
...
```

The following log sample displays the additional macro processing done during the Advanced HDL Synthesis step and the overall macro statistics after this step..

```
=====
*          Advanced HDL Synthesis
=====
Analyzing FSM <FSM_0> for best encoding.
Optimizing FSM < MACHINE/current_state/FSM_0> on signal
<current_state[1:3]> with gray encoding.
-----
State      | Encoding
-----
clear      | 000
zero       | 001
start      | 011
counting   | 010
stop       | 110
stopped    | 111
-----
=====
Advanced HDL Synthesis Report

Macro Statistics
# FSMs           : 1
# ROMs          : 3
  16x10-bit ROM : 1
  16x7-bit ROM  : 2
# Counters       : 2
  4-bit up counter : 2
# Registers     : 3
  Flip-Flops/Latches : 3
-----
...
=====
```

This chapter discusses the following Macro Blocks:

- Registers
- Tristates
- Counters
- Accumulators
- Shift Registers
- Dynamic Shift Registers
- Multiplexers
- Decoders
- Priority Encoders
- Logical Shifters
- Arithmetic Operators (Adders, Subtractors, Adders/Subtractors, Comparators, Multipliers, Dividers)
- RAMs
- State Machines
- Black Boxes

For each macro, both VHDL and Verilog examples are given. There is also a list of constraints you can use to control the macro processing in XST.

Note: For macro implementation details please refer to [Chapter 3, “FPGA Optimization”](#) and [Chapter 4, “CPLD Optimization”](#).

[Table 2-1](#) provides a list of all the examples in this chapter, as well as a list of VHDL and Verilog synthesis templates available from the Language Templates in Project Navigator.

To access the synthesis templates from Project Navigator:

1. Select **Edit → Language Templates...**
2. Click the + sign for either VHDL or Verilog.
3. Click the + sign next to Synthesis Templates.

Table 2-1: VHDL and Verilog Examples and Templates

Macro Blocks	Chapter Examples	Language Templates
Registers	Flip-flop with Positive-Edge Clock Flip-flop with Negative-Edge Clock and Asynchronous Clear Flip-flop with Positive-Edge Clock and Synchronous Set Flip-flop with Positive-Edge Clock and Clock Enable Latch with Positive Gate Latch with Positive Gate and Asynchronous Clear 4-bit Latch with Inverted Gate and Asynchronous Preset 4-bit Register with Positive-Edge Clock, Asynchronous Set and Clock Enable	D Flip-Flop D Flip-flop with Asynchronous Reset D Flip-Flop with Synchronous Reset D Flip-Flop with Clock Enable D Latch D Latch with Reset
Tristates	Description Using Combinatorial Process and Always Block Description Using Concurrent Assignment	Process Method (VHDL) Always Method (Verilog) Standalone Method (VHDL and Verilog)

Table 2-1: VHDL and Verilog Examples and Templates

Macro Blocks	Chapter Examples	Language Templates
Counters	4-bit Unsigned Up Counter with Asynchronous Clear 4-bit Unsigned Down Counter with Synchronous Set 4-bit Unsigned Up Counter with Asynchronous Load from Primary Input 4-bit Unsigned Up Counter with Synchronous Load with a Constant 4-bit Unsigned Up Counter with Asynchronous Clear and Clock Enable 4-bit Unsigned Up/Down counter with Asynchronous Clear 4-bit Signed Up Counter with Asynchronous Reset	4-bit asynchronous counter with count enable, asynchronous reset and synchronous load
Accumulators	4-bit Unsigned Up Accumulator with Asynchronous Clear	None

Table 2-1: VHDL and Verilog Examples and Templates

Macro Blocks	Chapter Examples	Language Templates
Shift Registers	<p>8-bit Shift-Left Register with Positive-Edge Clock, Serial In and Serial Out</p> <p>8-bit Shift-Left Register with Negative-Edge Clock, Clock Enable, Serial In and Serial Out</p> <p>8-bit Shift-Left Register with Positive-Edge Clock, Asynchronous Clear, Serial In and Serial Out</p> <p>8-bit Shift-Left Register with Positive-Edge Clock, Synchronous Set, Serial In and Serial Out</p> <p>8-bit Shift-Left Register with Positive-Edge Clock, Serial In and Parallel Out</p> <p>8-bit Shift-Left Register with Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out</p> <p>8-bit Shift-Left Register with Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out</p> <p>8-bit Shift-Left/Shift-Right Register with Positive-Edge Clock, Serial In and Parallel Out</p> <p>8-bit Shift-Left Register with Positive-Edge Clock, Serial In and Serial Out</p>	<p>4-bit Loadable Serial In Serial Out Shift Register</p> <p>4-bit Serial In Parallel out Shift Register</p> <p>4-bit Serial In Serial Out Shift Register</p>

Table 2-1: VHDL and Verilog Examples and Templates

Macro Blocks	Chapter Examples	Language Templates
Shift Registers (continued)	<p>8-bit Shift-Left Register with Negative-Edge Clock, Clock Enable, Serial In and Serial Out</p> <p>8-bit Shift-Left Register with Positive-Edge Clock, Asynchronous Clear, Serial In and Serial Out</p> <p>8-bit Shift-Left Register with Positive-Edge Clock, Synchronous Set, Serial In and Serial Out</p> <p>8-bit Shift-Left Register with Positive-Edge Clock, Serial In and Parallel Out</p> <p>8-bit Shift-Left Register with Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out</p> <p>8-bit Shift-Left Register with Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out</p> <p>8-bit Shift-Left/Shift-Right Register with Positive-Edge Clock, Serial In and Parallel Out</p>	
Multiplexers	<p>4-to-1 1-bit MUX using IF Statement</p> <p>4-to-1 MUX Using Case Statement</p> <p>4-to-1 MUX Using Tristate Buffers</p> <p>No 4-to-1 MUX</p>	<p>4-to-1 MUX Design with CASE Statement</p> <p>4-to-1 MUX Design with Tristate Construct</p>

Table 2-1: VHDL and Verilog Examples and Templates

Macro Blocks	Chapter Examples	Language Templates
Decoders	VHDL (One-Hot) Verilog (One-Hot) VHDL (One-Cold) Verilog (One-Cold)	1-of-8 Decoder, Synchronous with Reset
Priority Encoders	3-Bit 1-of-9 Priority Encoder	8-to-3 encoder, Synchronous with Reset
Logical Shifters	Example 1 Example 2 Example 3	None
Dynamic Shifters	16-bit Dynamic Shift Register with Positive-Edge Clock, Serial In and Serial Out	None

Table 2-1: VHDL and Verilog Examples and Templates

Macro Blocks	Chapter Examples	Language Templates
Arithmetic Operators	Unsigned 8-bit Adder Unsigned 8-bit Adder with Carry In Unsigned 8-bit Adder with Carry Out Unsigned 8-bit Adder with Carry In and Carry Out Simple Signed 8-bit Adder Unsigned 8-bit Subtractor Unsigned 8-bit Adder/Subtractor Unsigned 8-bit Greater or Equal Comparator Unsigned 8x4-bit Multiplier Division By Constant 2 Resource Sharing	N-Bit Comparator, Synchronous with Reset

Table 2-1: VHDL and Verilog Examples and Templates

Macro Blocks	Chapter Examples	Language Templates
RAMs	Single-Port RAM with Asynchronous Read Single-Port RAM with False Synchronous Read Single-Port RAM with Synchronous Read (Read Through) Dual-Port RAM with Asynchronous Read Dual-Port RAM with False Synchronous Read Dual-Port RAM with Synchronous Read (Read Through) Dual-Port Block RAM with Different Clocks Block RAM with Reset Multiple-Port RAM Descriptions	Single-Port RAM Single-Port Distributed RAM Dual-Port RAM Dual-Port Distributed RAM
State Machines	FSM with 1 Process FSM with 2 Processes FSM with 3 Processes	Binary State Machine One-Hot State Machine
Black Boxes	VHDL Code Verilog Code	None

Signed/Unsigned Support

When using Verilog or VHDL in XST, some macros, such as adders or counters, can be implemented for signed and unsigned values.

For Verilog, to enable support for signed and unsigned values, you must enable Verilog-2001. You can enable it by selecting the Verilog 2001 option under the Synthesis Options tab in the Process Properties dialog box in Project Navigator, or by setting the `-verilog2001` command line option to `yes`. See the "VERILOG2001" section in the *Constraints Guide* for details.

For VHDL, depending on the operation and type of the operands, you must include additional packages in your code. For example, in order to create an unsigned adder, you can use the following arithmetic packages and types that operate on unsigned values:

PACKAGE	TYPE
numeric_std	unsigned
std_logic_arith	unsigned
std_logic_unsigned	std_logic_vector

To create a signed adder you can use arithmetic packages and types that operate on signed values.

PACKAGE	TYPE
numeric_std	signed
std_logic_arith	signed
std_logic_signed	std_logic_vector

Please refer to the IEEE VHDL Manual for details on available types.

Registers

XST recognizes flip-flops with the following control signals:

- Asynchronous Set/Clear
- Synchronous Set/Clear
- Clock Enable

Please see the “[Specifying INITs and RLOCs in HDL Code](#)” in Chapter 3 for more information about register initialization.

Log File

The XST log file reports the type and size of recognized flip-flops during the Macro Recognition step.

```
...
=====
*          HDL Synthesis
=====

Synthesizing Unit <registers_5>.
  Related source file is "registers_5.vhd".
  Found 4-bit register for signal <Q>.
  Summary:
    inferred    4 D-type flip-flop(s).
Unit <registers_5> synthesized.

=====
HDL Synthesis Report

Macro Statistics
# Registers           : 1
  4-bit register      : 1

=====
*          Advanced HDL Synthesis
=====

=====
Advance HDL Synthesis Report

Macro Statistics
# Registers           : 4
  Flip-Flops/Latches : 4

=====
...
```


Note: With the introduction of new families such as Virtex-4, XST may optimize different slices of the same register in different ways. For example, XST may push a part of a register into a DSP48 block and another part may be implemented on slices or even become a part of a shift register. Because of, starting from 8.1i, XST reports the total number of FF bits in the design in the HDL Synthesis Report after the Advanced HDL Synthesis step.

Related Constraints

Related constraints are IOB, REGISTER_DUPLICATION, EQUIVALENT_REGISTER_REMOVAL, REGISTER_BALANCING.

Flip-flop with Positive-Edge Clock

The following figure shows a flip-flop with positive-edge clock.



The following table shows pin definitions for a flip-flop with positive edge clock.

IO Pins	Description
D	Data Input
C	Positive Edge Clock
Q	Data Output

VHDL Code

Following is the equivalent VHDL code sample for the flip-flop with a positive-edge clock.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Flip-Flop with Positive-Edge Clock  
--  
library ieee;  
use ieee.std_logic_1164.all;  
  
entity registers_1 is  
    port(C, D : in std_logic;  
          Q      : out std_logic);  
end registers_1;  
  
architecture archi of registers_1 is  
begin  
  
    process (C)  
    begin  
        if (C'event and C='1') then  
            Q <= D;  
        end if;  
    end process;  
  
end archi;
```

When using VHDL, for a positive-edge clock instead of using

```
if (C'event and C='1') then
```

you can also use

```
if (rising_edge(C)) then
```

Verilog Code

Following is the equivalent Verilog code sample for the flip-flop with a positive-edge clock.


These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Flip-Flop with Positive-Edge Clock  
  
module v_registers_1 (C, D, Q);  
    input C, D;  
    output Q;  
    reg Q;  
  
    always @ (posedge C)  
    begin  
        Q <= D;  
    end  
  
endmodule
```

Flip-flop with Negative-Edge Clock and Asynchronous Clear

The following figure shows a flip-flop with negative-edge clock and asynchronous clear.



X3847

The following table shows pin definitions for a flip-flop with negative-edge clock and asynchronous clear.

IO Pins	Description
D	Data Input
C	Negative-Edge Clock
CLR	Asynchronous Clear (active High)
Q	Data Output

VHDL Code

Following is the equivalent VHDL code for a flip-flop with a negative-edge clock and asynchronous clear

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Flip-Flop with Negative-Edge Clock and Asynchronous Clear  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog Code

Following is the equivalent Verilog code for a flip-flop with a negative-edge clock and asynchronous clear.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Flip-Flop with Negative-Edge Clock and Asynchronous Clear
// 

module v_registers_2 (C, D, CLR, Q);
    input C, D, CLR;
    output Q;
    reg Q;


    always @ (negedge C or posedge CLR)
    begin
        if (CLR)
            Q <= 1'b0;
        else
            Q <= D;
    end

endmodule

```

Flip-flop with Positive-Edge Clock and Synchronous Set

The following figure shows a flip-flop with positive-edge clock and synchronous set.



The following table shows pin definitions for a flip-flop with positive-edge clock and synchronous set.

IO Pins	Description
D	Data Input
C	Positive-Edge Clock
S	Synchronous Set (active High)
Q	Data Output

VHDL Code

Following is the equivalent VHDL code for the flip-flop with a positive-edge clock and synchronous set.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Flip-Flop with Positive-Edge Clock and Synchronous Set  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog Code

Following is the equivalent Verilog code for the flip-flop with a positive-edge clock and synchronous set.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Flip-Flop with Positive-Edge Clock and Synchronous Set
// 

module v_registers_3 (C, D, S, Q);
    input C, D, S;
    output Q;
    reg Q;


    always @ (posedge C)
    begin
        if (S)
            Q <= 1'b1;
        else
            Q <= D;
    end

endmodule

```

Flip-flop with Positive-Edge Clock and Clock Enable

The following figure shows a flip-flop with positive-edge clock and clock enable.



The following table shows pin definitions for a flip-flop with positive-edge clock and clock enable.

IO Pins	Description
D	Data Input
C	Positive-Edge Clock
CE	Clock Enable (active High)
Q	Data Output

VHDL Code

Following is the equivalent VHDL code for the flip-flop with a positive-edge clock and clock enable.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Flip-Flop with Positive-Edge Clock and Clock Enable  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog Code

Following is the equivalent Verilog code for the flip-flop with a positive-edge clock and clock enable.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Flip-Flop with Positive-Edge Clock and Clock Enable
// 

module v_registers_4 (C, D, CE, Q);
    input C, D, CE;
    output Q;
    reg Q;


    always @ (posedge C)
    begin
        if (CE)
            Q <= D;
    end

endmodule

```

4-bit Register with Positive-Edge Clock, Asynchronous Set and Clock Enable

The following figure shows a 4-bit register with positive-edge clock, asynchronous set and clock enable.



The following table shows pin definitions for a 4-bit register with positive-edge clock, asynchronous set and clock enable.

IO Pins	Description
D[3:0]	Data Input
C	Positive-Edge Clock
PRE	Asynchronous Set (active High)
CE	Clock Enable (active High)
Q[3:0]	Data Output

VHDL Code

Following is the equivalent VHDL code for a 4-bit register with a positive-edge clock, asynchronous set and clock enable.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 4-bit Register with Positive-Edge Clock, Asynchronous Set and Clock  
Enable  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  
entity registers_5 is  
    port(C, CE, PRE : in std_logic;  
          D         : in std_logic_vector (3 downto 0);  
          Q         : out std_logic_vector (3 downto 0));  
end registers_5;  
  
architecture archi of registers_5 is  
begin  
  
    process (C, PRE)  
    begin  
        if (PRE='1') then  
            Q <= "1111";  
        elsif (C'event and C='1') then  
            if (CE='1') then  
                Q <= D;  
            end if;  
        end if;  
    end process;  
  
end archi;
```

Verilog Code

Following is the equivalent Verilog code for a 4-bit register with a positive-edge clock, asynchronous set and clock enable.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 4-bit Register with Positive-Edge Clock, Asynchronous Set and Clock  
Enable  
//  
  
module v_registers_5 (C, D, CE, PRE, Q);  
    input  C, CE, PRE;  
    input  [3:0] D;  
    output [3:0] Q;  
    reg    [3:0] Q;
```

```

    always @(posedge C or posedge PRE)
    begin
        if (PRE)
            Q <= 4'b1111;
        else
            if (CE)
                Q <= D;
    end

endmodule

```

Latches

XST can recognize latches with the asynchronous set/clear control signals.

Latches can be described using:

- Process (VHDL) and always block (Verilog).
- Concurrent state assignment.

Note: XST does not support Wait statements (VHDL) for latch descriptions.

Log File

The XST log file reports the type and size of recognized latches during the Macro Recognition step.

```

...
Synthesizing Unit <latch>.
Related source file is latch_1.vhd.
WARNING:Xst:737 - Found 1-bit latch for signal <q>.
Summary:
    inferred    1 Latch(s).
Unit <latch> synthesized.

=====
HDL Synthesis Report

Macro Statistics
# Latches          : 1
  1-bit latch      : 1
=====
...


```

Related Constraints

A related constraint is IOB.

Latch with Positive Gate

The following figure shows a latch with a positive gate.



The following table shows pin definitions for a latch with a positive gate.

IO Pins	Description
D	Data Input
G	Positive Gate
Q	Data Output

VHDL Code

Following is the equivalent VHDL code for a latch with a positive gate.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Latch with Positive Gate  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  
entity latches_1 is  
    port(G, D : in std_logic;  
         Q : out std_logic);  
end latches_1;  
  
architecture archi of latches_1 is  
begin  
    process (G, D)  
    begin  
        if (G='1') then  
            Q <= D;  
        end if;  
    end process;  
end archi;
```

Verilog Code

Following is the equivalent Verilog code for a latch with a positive gate.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Latch with Positive Gate
// 


module v_latches_1 (G, D, Q);
    input G, D;
    output Q;
    reg Q;

    always @ (G or D)
    begin
        if (G)
            Q = D;
    end
endmodule

```

Latch with Positive Gate and Asynchronous Clear

The following figure shows a latch with a positive gate and an asynchronous clear.



The following table shows pin definitions for a latch with a positive gate and an asynchronous clear.

IO Pins	Description
D	Data Input
G	Positive Gate
CLR	Asynchronous Clear (active High)
Q	Data Output

VHDL Code

Following is the equivalent VHDL code for a latch with a positive gate and an asynchronous clear.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Latch with Positive Gate and Asynchronous Clear  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog Code

Following is the equivalent Verilog code for a latch with a positive gate and an asynchronous clear.


These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Latch with Positive Gate and Asynchronous Clear  
//  
  
module v_latches_2 (G, D, CLR, Q);  
    input G, D, CLR;  
    output Q;  
    reg Q;  
  
    always @(G or D or CLR)  
    begin  
        if (CLR)  
            Q = 1'b0;  
        else if (G)  
            Q = D;  
    end  
endmodule
```

4-bit Latch with Inverted Gate and Asynchronous Preset

The following figure shows a 4-bit latch with an inverted gate and an asynchronous preset.



The following table shows pin definitions for a latch with an inverted gate and an asynchronous preset.

IO Pins	Description
D[3:0]	Data Input
G	Inverted Gate
PRE	Asynchronous Preset (active High)
Q[3:0]	Data Output

VHDL Code

Following is the equivalent VHDL code for a 4-bit latch with an inverted gate and an asynchronous preset.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 4-bit Latch with Inverted Gate and Asynchronous Preset  
  
library ieee;  
use ieee.std_logic_1164.all;  
  
entity latches_3 is  
    port(D      : in std_logic_vector(3 downto 0);  
          G, PRE : in std_logic;  
          Q      : out std_logic_vector(3 downto 0));  
end latches_3;  
  
architecture archi of latches_3 is  
begin  
    process (PRE, G)  
    begin  
        if (PRE='1') then  
            Q <= "1111";  
        elsif (G='0') then  
            Q <= D;  
        end if;  
    end process;  
end archi;
```

Verilog Code

Following is the equivalent Verilog code for a 4-bit latch with an inverted gate and an asynchronous preset.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 4-bit Latch with Inverted Gate and Asynchronous Preset  
  
module v_latches_3 (G, D, PRE, Q);  
    input G, PRE;  
    input [3:0] D;  
    output [3:0] Q;  
    reg [3:0] Q;  
  
    always @(G or D or PRE)  
    begin  
        if (PRE)  
            Q = 4'b1111;  
        else if (~G)  
            Q = D;  
    end  
endmodule
```

Tristates

Tristate elements can be described using the following:

- Combinatorial process (VHDL) and always block (Verilog).
- Concurrent assignment.

Log File

The XST log reports the type and size of recognized tristates during the Macro Recognition step.

```

...
Synthesizing Unit <three_st>.
Related source file is tristates_1.vhd.
Found 1-bit tristate buffer for signal <o>.
Summary:
        inferred    1 Tristate(s).
Unit <three_st> synthesized.

=====
HDL Synthesis Report

Macro Statistics
# Tristates           : 1
  1-bit tristate buffer : 1
=====
...


```

Related Constraints

A related constraint is TRISTATE2LOGIC.

Description Using Combinatorial Process and Always Block

The following figure shows a tristate element using a combinatorial process and always block.



X9543

The following table shows pin definitions for a tristate element using a combinatorial process and always block.

IO Pins	Description
I	Data Input
T	Output Enable (active Low)
O	Data Output

VHDL Code

Following is VHDL code for a tristate element using a combinatorial process.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Tristate Description Using Combinatorial Process  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  
entity three_st_1 is  
    port(T : in std_logic;  
         I : in std_logic;  
         O : out std_logic);  
end three_st_1;  
  
architecture archi of three_st_1 is  
begin  
  
    process (I, T)  
    begin  
        if (T='0') then  
            O <= I;  
        else  
            O <= 'Z';  
        end if;  
    end process;  
  
end archi;
```

Verilog Code

Following is Verilog code for a tristate element using a combinatorial always block.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Tristate Description Using Combinatorial Always Block
//

module v_three_st_1 (T, I, O);
    input T, I;
    output O;
    reg O;

    always @(T or I)
    begin
        if (~T)
            O = I;
        else
            O = 1'bZ;
    end

endmodule

```

Description Using Concurrent Assignment

In the following two examples, note that comparing to 0 instead of 1 infers a BUFT primitive instead of a BUFE macro. (The BUFE macro has an inverter on the E pin.)

VHDL Code

Following is VHDL code for a tristate element using a concurrent assignment.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

-- 
-- Tristate Description Using Concurrent Assignment
--

library ieee;
use ieee.std_logic_1164.all;

entity three_st_2 is
    port(T : in std_logic;
         I : in std_logic;
         O : out std_logic);
end three_st_2;

architecture archi of three_st_2 is
begin
    O <= I when (T='0') else 'Z';
end archi;

```

Verilog Code

Following is the Verilog code for a tristate element using a concurrent assignment.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Tristate Description Using Concurrent Assignment  
  
module v_three_st_2 (T, I, O);  
    input T, I;  
    output O;  
  
    assign O = (~T) ? I: 1'bZ;  
  
endmodule
```

Counters

XST is able to recognize counters with the following control signals.

- Asynchronous Set/Clear
- Synchronous Set/Clear
- Asynchronous/Synchronous Load (signal and/or constant)
- Clock Enable
- Modes (Up, Down, Up/Down)
- Mixture of all of the above

HDL coding styles for the following control signals are equivalent to the ones described in “Registers” in this chapter.

- Clock
- Asynchronous Set/Clear
- Synchronous Set/Clear
- Clock Enable

Moreover, XST supports both unsigned and signed counters.

Log File

The XST log file reports the type and size of recognized counters during the Macro Recognition step.

```
...
Synthesizing Unit <counter>.
Related source file is counters_1.vhd.
Found 4-bit up counter for signal <tmp>.
Summary:
    inferred    1 Counter(s).
Unit <counter> synthesized.

=====
HDL Synthesis Report

Macro Statistics
# Counters : 1
  4-bit up counter : 1
=====
...
```

Note: During synthesis, XST decomposes Counters on Adders and Registers if they do not contain synchronous load signals. This is done to create additional opportunities for timing optimization. Because of this, counters reported during the Macro Recognition step and in the overall statistics of recognized macros may not appear in the final report. Adders/registers are reported instead.

Related Constraints

There are no related constraints available.

4-bit Unsigned Up Counter with Asynchronous Clear

The following table shows pin definitions for a 4-bit unsigned up counter with an asynchronous clear.

IO Pins	Description
C	Positive-Edge Clock
CLR	Asynchronous Clear (active High)
Q[3:0]	Data Output

VHDL Code

Following is VHDL code for a 4-bit unsigned up counter with an asynchronous clear.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 4-bit unsigned up counter with an asynchronous clear.  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

Following is the Verilog code for a 4-bit unsigned up counter with asynchronous clear.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// 4-bit unsigned up counter with an asynchronous clear.
// 

module v_counters_1 (C, CLR, Q);
    input C, CLR;
    output [3:0] Q;
    reg [3:0] tmp;

    always @(posedge C or posedge CLR)
    begin
        if (CLR)
            tmp <= 4'b0000;
        else
            tmp <= tmp + 1'b1;
    end

    assign Q = tmp;
endmodule

```

4-bit Unsigned Down Counter with Synchronous Set

The following table shows pin definitions for a 4-bit unsigned down counter with a synchronous set.

IO Pins	Description
C	Positive-Edge Clock
S	Synchronous Set (active High)
Q[3:0]	Data Output

VHDL Code

Following is the VHDL code for a 4-bit unsigned down counter with a synchronous set.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

-- 
-- 4-bit unsigned down counter with a synchronous set.
-- 

library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;

entity counters_2 is
    port(C, S : in std_logic;
         Q : out std_logic_vector(3 downto 0));
end counters_2;

architecture archi of counters_2 is
    signal tmp: std_logic_vector(3 downto 0);
begin

```

```

process (C)
begin
    if (C'event and C='1') then
        if (S='1') then
            tmp <= "1111";
        else
            tmp <= tmp - 1;
        end if;
    end if;
end process;

Q <= tmp;

end archi;

```

Verilog Code

Following is the Verilog code for a 4-bit unsigned down counter with synchronous set.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// 4-bit unsigned down counter with a synchronous set.
//

module v_counters_2 (C, S, Q);
    input C, S;
    output [3:0] Q;
    reg [3:0] tmp;

    always @ (posedge C)
    begin
        if (S)
            tmp <= 4'b1111;
        else
            tmp <= tmp - 1'b1;
    end

    assign Q = tmp;

endmodule

```

4-bit Unsigned Up Counter with Asynchronous Load from Primary Input

The following table shows pin definitions for a 4-bit unsigned up counter with an asynchronous load from the primary input.

IO Pins	Description
C	Positive-Edge Clock
ALOAD	Asynchronous Load (active High)
D[3:0]	Data Input
Q[3:0]	Data Output

VHDL Code

Following is the VHDL code for a 4-bit unsigned up counter with an asynchronous load from the primary input.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 4-bit Unsigned Up Counter with Asynchronous Load from Primary Input  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

Following is the Verilog code for a 4-bit unsigned up counter with an asynchronous load from the primary input.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 4-bit Unsigned Up Counter with Asynchronous Load from Primary Input  
  
//  
  
module v_counters_3 (C, ALOAD, D, Q);  
    input C, ALOAD;  
    input [3:0] D;  
    output [3:0] Q;  
    reg [3:0] tmp;  
  
    always @ (posedge C or posedge ALOAD)  
    begin  
        if (ALOAD)  
            tmp <= D;  
        else  
            tmp <= tmp + 1'b1;  
    end  
  
    assign Q = tmp;  
  
endmodule
```

4-bit Unsigned Up Counter with Synchronous Load with a Constant

The following table shows pin definitions for a 4-bit unsigned up counter with a synchronous load with a constant.

IO Pins	Description
C	Positive-Edge Clock
SLOAD	Synchronous Load (active High)
Q[3:0]	Data Output

VHDL Code

Following is the VHDL code for a 4-bit unsigned up counter with a synchronous load with a constant.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 4-bit Unsigned Up Counter with Synchronous Load with a Constant  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

Following is the Verilog code for a 4-bit unsigned up counter with a synchronous load with a constant.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 4-bit Unsigned Up Counter with Synchronous Load with a Constant  
  
//  
  
module v_counters_4 (C, SLOAD, Q);  
    input C, SLOAD;  
    output [3:0] Q;  
    reg [3:0] tmp;  
  
    always @ (posedge C)  
    begin  
        if (SLOAD)  
            tmp <= 4'b1010;  
        else  
            tmp <= tmp + 1'b1;  
    end  
  
    assign Q = tmp;  
  
endmodule
```

4-bit Unsigned Up Counter with Asynchronous Clear and Clock Enable

The following table shows pin definitions for a 4-bit unsigned up counter with an asynchronous clear and a clock enable.

IO Pins	Description
C	Positive-Edge Clock
CLR	Asynchronous Clear (active High)
CE	Clock Enable
Q[3:0]	Data Output

VHDL Code

Following is the VHDL code for a 4-bit unsigned up counter with an asynchronous clear and a clock enable.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 4-bit Unsigned Up Counter with Asynchronous Clear and Clock Enable  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

Following is the Verilog code for a 4-bit unsigned up counter with an asynchronous clear and a clock enable.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 4-bit Unsigned Up Counter with Asynchronous Clear and Clock Enable  
  
//  
  
module v_counters_5 (C, CLR, CE, Q);  
    input C, CLR, CE;  
    output [3:0] Q;  
    reg [3:0] tmp;  
  
    always @ (posedge C or posedge CLR)  
    begin  
        if (CLR)  
            tmp <= 4'b0000;  
        else if (CE)  
            tmp <= tmp + 1'b1;  
    end  
  
    assign Q = tmp;  
  
endmodule
```

4-bit Unsigned Up/Down counter with Asynchronous Clear

The following table shows pin definitions for a 4-bit unsigned up/down counter with an asynchronous clear.

IO Pins	Description
C	Positive-Edge Clock
CLR	Asynchronous Clear (active High)
UP_DOW N	up/down count mode selector
Q[3:0]	Data Output

VHDL Code

Following is the VHDL code for a 4-bit unsigned up/down counter with an asynchronous clear.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 4-bit Unsigned Up/Down counter with Asynchronous Clear  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

Following is the Verilog code for a 4-bit unsigned up/down counter with an asynchronous clear.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 4-bit Unsigned Up/Down counter with Asynchronous Clear  
  
//  
  
module v_counters_6 (C, CLR, UP_DOWN, Q);  
    input C, CLR, UP_DOWN;  
    output [3:0] Q;  
    reg [3:0] tmp;  
  
    always @ (posedge C or posedge CLR)  
    begin  
        if (CLR)  
            tmp <= 4'b0000;  
        else if (UP_DOWN)  
            tmp <= tmp + 1'b1;  
        else  
            tmp <= tmp - 1'b1;  
    end  
  
    assign Q = tmp;  
  
endmodule
```

4-bit Signed Up Counter with Asynchronous Reset

The following table shows pin definitions for a 4-bit signed up counter with an asynchronous reset.

IO Pins	Description
C	Positive-Edge Clock
CLR	Asynchronous Clear (active High)
Q[3:0]	Data Output

VHDL Code

Following is the VHDL code for a 4-bit signed up counter with an asynchronous reset.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 4-bit Signed Up Counter with Asynchronous Reset  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_signed.all;  

```

Verilog Code

Following is the Verilog code for a 4-bit signed up counter with an asynchronous reset.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 4-bit Signed Up Counter with Asynchronous Reset  
  
module v_counters_7 (C, CLR, Q);  
    input C, CLR;  
    output signed [3:0] Q;  
    reg signed [3:0] tmp;  
  
    always @ (posedge C or posedge CLR)  
    begin  
        if (CLR)  
            tmp <= 4'b0000;  
        else  
            tmp <= tmp + 1'b1;  
    end  
  
    assign Q = tmp;  
  
endmodule
```

4-bit Signed Up Counter with Asynchronous Reset and Modulo Maximum

The following table shows pin definitions for a 4-bit signed up counter with an asynchronous reset and a modulo maximum.

IO Pins	Description
C	Positive-Edge Clock
CLR	Asynchronous Clear (active High)
Q[7:0]	Data Output

VHDL Code

Following is the VHDL code for a 4-bit signed up counter with an asynchronous reset and a maximum using the VHDL mod function.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 4-bit Signed Up Counter with Asynchronous Reset and Modulo Maximum  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_arith.all;  

```

Verilog Code

Following is the Verilog code for a 4-bit signed up counter with an asynchronous reset and a modulo maximum.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 4-bit Signed Up Counter with Asynchronous Reset and Modulo Maximum  
  
module v_counters_8 (C, CLR, Q);  
    parameter  
        MAX_SQRT = 4,  
        MAX = (MAX_SQRT*MAX_SQRT);  
  
    input C, CLR;  
    output [MAX_SQRT-1:0] Q;  
    reg [MAX_SQRT-1:0] cnt;  
  
    always @ (posedge C or posedge CLR)  
    begin  
        if (CLR)  
            cnt <= 0;  
        else  
            cnt <= (cnt + 1) %MAX;  
    end  
  
    assign Q = cnt;  
  
endmodule
```

Related Constraints

There are no related constraints available.

Accumulators

An accumulator differs from a counter in the nature of the operands of the add and subtract operation:

- In a counter, the destination and first operand is a signal or variable and the other operand is a constant equal to 1: A <= A + 1.
- In an accumulator, the destination and first operand is a signal or variable, and the second operand is either:
 - ◆ a signal or variable: A <= A + B.
 - ◆ a constant not equal to 1: A <= A + Constant.

An inferred accumulator can be up, down or updown. For an updown accumulator, the accumulated data may differ between the up and down mode:

```
...
if updown = '1' then
    a <= a + b;
else
    a <= a - c;
...
```

XST can infer an accumulator with the same set of control signals available for counters. (Refer to “[Counters](#)” in this chapter for more details.)

Log File

The XST log file reports the type and size of recognized accumulators during the Macro Recognition step.

```
...
Synthesizing Unit <accum>.
Related source file is accumulators_1.vhd.
Found 4-bit up accumulator for signal <tmp>.
Summary:
    inferred    1 Accumulator(s).
Unit <accum> synthesized.

=====
HDL Synthesis Report

Macro Statistics
# Accumulators : 1
    4-bit up accumulator : 1
=====
```

Note: During synthesis, XST decomposes Accumulators on Adders and Registers if they do not contain synchronous load signals. This is done to create additional opportunities for timing optimization. Because of this, Accumulators reported during the Macro Recognition step and in the overall statistics of recognized macros may not appear in the final report. Adders/registers are reported instead.

Related Constraints

Related constraints are USE_DSP48, DSP_UTILIZATION_RATIO and KEEP which are available for Virtex-4 devices.

4-bit Unsigned Up Accumulator with Asynchronous Clear

The following table shows pin definitions for a 4-bit unsigned up accumulator with an asynchronous clear.

IO Pins	Description
C	Positive-Edge Clock
CLR	Asynchronous Clear (active High)
D[3:0]	Data Input
Q[3:0]	Data Output

VHDL Code

Following is the VHDL code for a 4-bit unsigned up accumulator with an asynchronous clear.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
-- 
-- 4-bit Unsigned Up Accumulator with Asynchronous Clear
--

library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;

entity accumulators_1 is
    port(C, CLR : in std_logic;
          D : in std_logic_vector(3 downto 0);
          Q : out std_logic_vector(3 downto 0));
end accumulators_1;

architecture archi of accumulators_1 is
    signal tmp: std_logic_vector(3 downto 0);
begin

    process (C, CLR)
    begin
        if (CLR='1') then
            tmp <= "0000";
        elsif (C'event and C='1') then
            tmp <= tmp + D;
        end if;
    end process;

    Q <= tmp;

end archi;
```

Verilog Code

Following is the Verilog code for a 4-bit unsigned up accumulator with an asynchronous clear.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// 4-bit Unsigned Up Accumulator with Asynchronous Clear
// 

module v_accumulators_1 (C, CLR, D, Q);

    input C, CLR;
    input [3:0] D;
    output [3:0] Q;
    reg [3:0] tmp;

    always @ (posedge C or posedge CLR)
    begin
        if (CLR)
            tmp <= 4'b0000;
        else
            tmp <= tmp + D;
    end
    assign Q = tmp;
endmodule

```

Considerations for Virtex-4 Devices

The Virtex-4 family enables accumulators to be implemented on DSP48 resources. XST can push up to 2 levels of input registers into DSP48 blocks.

XST can implement an accumulator in a DSP48 block if its implementation requires only a single DSP48 resource. If an accumulator macro does not fit in a single DSP48, XST will implement the entire macro using slice logic.

Macro implementation on DSP48 resources is controlled by the USE_DSP48 constraint/command line option, with a default value of *auto*. In this mode, XST implements accumulators taking into account the number of available DSP48 resources on the device.

In *auto* mode the user can control the number of available DSP48 resources for the synthesis by using the DSP_UTILIZATION_RATIO constraint. By default, XST tries to utilize, as much as possible, all available DSP48 resources. See “[Using DSP48 Block Resources](#)” in Chapter 3 for more information.

To deliver the best performance, XST by default tries to infer and implement the maximum macro configuration, including as many registers as possible in the DSP48. If you want to shape a macro in a specific way, you must use the KEEP constraint. For example, if you want to exclude the first register stage from the DSP48, you must place KEEP constraints on the outputs of these registers.

As with other families, for Virtex-4, XST reports the details of inferred accumulators at the HDL Synthesis step. But in the Final Synthesis Report, accumulators are no longer visible, because they are implemented within the MAC implementation mechanism.

Shift Registers

In general, a shift register is characterized by the following control and data signals, which are fully recognized by XST.

- clock
- serial input
- asynchronous set/reset
- synchronous set/reset
- synchronous/asynchronous parallel load
- clock enable
- serial or parallel output. The shift register output mode may be:
 - ◆ serial: only the contents of the last flip-flop are accessed by the rest of the circuit
 - ◆ parallel: the contents of one or several flip-flops, other than the last one, are accessed
- shift modes: left, right, etc.


There are different ways to describe shift registers. For example, in VHDL you can use:

- concatenation operator
`shreg <= shreg (6 downto 0) & SI;`
- "for loop" construct
`for i in 0 to 6 loop
 shreg(i+1) <= shreg(i);
end loop;
shreg(0) <= SI;`
- predefined shift operators; for example, SLL or SRL

Consult the VHDL/Verilog language reference manuals for more information.


FPGAs:

Virtex/-E/-II/-II Pro/-II Pro X/4 and Spartan-II/-IIE/-3 have specific hardware resources to implement shift registers: SRL16 for Virtex /-E/-II/-II Pro/-II Pro X and Spartan-II/-IIE/-3 and SRLC16 for Virtex-II/-II Pro/-II Pro X/4 and Spartan-3. Both are available with or without a clock enable. The following figure shows the pin layout of SRL16E.



X8423

The following figure shows the pin layout of SRLC16.



Note: Synchronous and asynchronous control signals are not available in the SLRC16x primitives.

SRL16 and SRLC16 support only LEFT shift operation for a limited number of IO signals.

- clock
- clock enable
- serial data in
- serial data out

This means that if your shift register *does have*, for instance, a synchronous parallel load, no SRL16 is implemented. XST uses specific internal processing which enables it to produce the best final results.

The XST log file reports recognized shift registers when it can be implemented using SRL16.

See “[Specifying INITs and RLOCs in HDL Code](#)” in Chapter 3 for more information about shift register initialization.

Log File

Starting in the 8.1i release, XST recognizes shift registers in the Advanced HDL Synthesis step. The XST log file reports the size of recognized shift registers during the Macro Recognition step.

```
...
=====
*          HDL Synthesis
=====

Synthesizing Unit <shift_registers_1>.
  Related source file is "shift_registers_1.vhd".
  Found 8-bit register for signal <tmp>.
  Summary:
    inferred   8 D-type flip-flop(s).
Unit <shift_registers_1> synthesized.

=====
*          Advanced HDL Synthesis
=====
...

Synthesizing (advanced) Unit <shift_registers_1>.
  Found 8-bit shift register for signal <tmp<7>>.
Unit <shift_registers_1> synthesized (advanced).

=====
HDL Synthesis Report

Macro Statistics
# Shift Registers           : 1
  8-bit shift register       : 1

...
=====
```

Related Constraints

A related constraint is SHREG_EXTRACT.

8-bit Shift-Left Register with Positive-Edge Clock, Serial In and Serial Out

Note: For this example, XST infers an SRL16.

The following table shows pin definitions for an 8-bit shift-left register with a positive-edge clock, a serial in and a serial out.

IO Pins	Description
C	Positive-Edge Clock
SI	Serial In
SO	Serial Output

VHDL Code

Following is the VHDL code for an 8-bit shift-left register with a positive-edge clock, a serial in and a serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 8-bit Shift-Left Register with Positive-Edge Clock,  
-- Serial In, and Serial Out  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  
entity shift_registers_1 is  
    port(C, SI : in std_logic;  
          SO : out std_logic);  
end shift_registers_1;  
  
architecture archi of shift_registers_1 is  
    signal tmp: std_logic_vector(7 downto 0);  
begin  
  
    process (C)  
    begin  
        if (C'event and C='1') then  
            for i in 0 to 6 loop  
                tmp(i+1) <= tmp(i);  
            end loop;  
            tmp(0) <= SI;  
        end if;  
    end process;  
  
    SO <= tmp(7);  
  
end archi;
```

Verilog Code

Following is the Verilog code for an 8-bit shift-left register with a positive-edge clock, serial in and serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 8-bit Shift-Left Register with Positive-Edge Clock,  
// Serial In, and Serial Out  
  
module v_shift_registers_1 (C, SI, SO);  
    input C,SI;  
    output SO;  
    reg [7:0] tmp;  
  
    always @ (posedge C)  
    begin  
        tmp <= tmp << 1;  
        tmp[0] <= SI;  
    end  
  
    assign SO = tmp[7];  
  
endmodule
```

8-bit Shift-Left Register with Negative-Edge Clock, Clock Enable, Serial In and Serial Out

Note: For this example, XST infers an SRL16E_1.

The following table shows pin definitions for an 8-bit shift-left register with a negative-edge clock, a clock enable, a serial in and a serial out.

IO Pins	Description
C	Negative-Edge Clock
SI	Serial In
CE	Clock Enable (active High)
SO	Serial Output

VHDL Code

Following is the VHDL code for an 8-bit shift-left register with a negative-edge clock, a clock enable, a serial in and a serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 8-bit Shift-Left Register with Negative-Edge Clock, Clock Enable,  
-- Serial In, and Serial Out  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  
entity shift_registers_2 is  
    port(C, SI, CE : in std_logic;  
          SO : out std_logic);  
end shift_registers_2;  
  
architecture archi of shift_registers_2 is  
    signal tmp: std_logic_vector(7 downto 0);  
begin  
  
    process (C)  
    begin  
        if (C'event and C='0') then  
            if (CE='1') then  
                for i in 0 to 6 loop  
                    tmp(i+1) <= tmp(i);  
                end loop;  
                tmp(0) <= SI;  
            end if;  
        end if;  
    end process;  
  
    SO <= tmp(7);  
  
end archi;
```

Verilog Code

Following is the Verilog code for an 8-bit shift-left register with a negative-edge clock, a clock enable, a serial in and a serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 8-bit Shift-Left Register with Negative-Edge Clock, Clock Enable,  
// Serial In, and Serial Out  
  
module v_shift_registers_2 (C, CE, SI, SO);  
    input C,SI, CE;  
    output SO;  
    reg [7:0] tmp;  
  
    always @ (negedge C)  
    begin  
        if (CE)  
        begin  
            tmp <= tmp << 1;  
            tmp[0] <= SI;  
        end  
    end  
  
    assign SO = tmp[7];  
  
endmodule
```

8-bit Shift-Left Register with Positive-Edge Clock, Asynchronous Clear, Serial In and Serial Out

Note: Because this example includes an asynchronous clear, XST does **not** infer an SRL16.

The following table shows pin definitions for an 8-bit shift-left register with a positive-edge clock, an asynchronous clear, a serial in and a serial out.

IO Pins	Description
C	Positive-Edge Clock
SI	Serial In
CLR	Asynchronous Clear (active High)
SO	Serial Output

VHDL Code

Following is the VHDL code for an 8-bit shift-left register with a positive-edge clock, an asynchronous clear, a serial in and a serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 8-bit Shift-Left Register with Positive-Edge Clock,  
-- Asynchronous Clear,Serial In, and Serial Out  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog Code

Following is the Verilog code for an 8-bit shift-left register with a positive-edge clock, asynchronous clear, serial in and serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 8-bit Shift-Left Register with Positive-Edge Clock,  
// Asynchronous Clear, Serial In, and Serial Out  
  
module v_shift_registers_3 (C, CLR, SI, SO);  
    input C,SI,CLR;  
    output SO;  
    reg [7:0] tmp;  
  
    always @ (posedge C or posedge CLR)  
    begin  
        if (CLR)  
            tmp <= 8'b00000000;  
        else  
            tmp <= {tmp[6:0], SI};  
    end  
  
    assign SO = tmp[7];  
  
endmodule
```

8-bit Shift-Left Register with Positive-Edge Clock, Synchronous Set, Serial In and Serial Out

Note: For this example, XST does **not** infer an SRL16.

The following table shows pin definitions for an 8-bit shift-left register with a positive-edge clock, a synchronous set, a serial in and a serial out.

IO Pins	Description
C	Positive-Edge Clock
SI	Serial In
S	Synchronous Set (active High)
SO	Serial Output

VHDL Code

Following is the VHDL code for an 8-bit shift-left register with a positive-edge clock, a synchronous set, a serial in and a serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 8-bit Shift-Left Register with Positive-Edge Clock, Synchronous Set,  
-- Serial In, and Serial Out  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  
entity shift_registers_4 is  
    port(C, SI, S : in std_logic;  
          SO : out std_logic);  
end shift_registers_4;  
  
architecture archi of shift_registers_4 is  
    signal tmp: std_logic_vector(7 downto 0);  
begin  
  
    process (C, S)  
    begin  
        if (C'event and C='1') then  
            if (S='1') then  
                tmp <= (others => '1');  
            else  
                tmp <= tmp(6 downto 0) & SI;  
            end if;  
        end if;  
    end process;  
  
    SO <= tmp(7);  
  
end archi;
```

Verilog Code

Following is the Verilog code for an 8-bit shift-left register with a positive-edge clock, a synchronous set, a serial in and a serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 8-bit Shift-Left Register with Positive-Edge Clock, Synchronous Set,  
// Serial In, and Serial Out  
  
module v_shift_registers_4 (C, S, SI, SO);  
    input C,SI,S;  
    output SO;  
    reg [7:0] tmp;  
  
    always @(posedge C)  
    begin  
        if (S)  
            tmp <= 8'b11111111;  
        else  
            tmp <= {tmp[6:0], SI};  
    end  
  
    assign SO = tmp[7];  
  
endmodule
```

8-bit Shift-Left Register with Positive-Edge Clock, Serial In and Parallel Out

Note: For this example, XST does **not** infer SRL16.

The following table shows pin definitions for an 8-bit shift-left register with a positive-edge clock, a serial in and a parallel out.

IO Pins	Description
C	Positive-Edge Clock
SI	Serial In
PO[7:0]	Parallel Output

VHDL Code

Following is the VHDL code for an 8-bit shift-left register with a positive-edge clock, a serial in and a parallel out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 8-bit Shift-Left Register with Positive-Edge Clock,  
-- Serial In, and Parallel Out  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  
entity shift_registers_5 is  
    port(C, SI : in std_logic;  
          PO : out std_logic_vector(7 downto 0));  
end shift_registers_5;  
  
architecture archi of shift_registers_5 is  
    signal tmp: std_logic_vector(7 downto 0);  
begin  
  
    process (C)  
    begin  
        if (C'event and C='1') then  
            tmp <= tmp(6 downto 0)& SI;  
        end if;  
    end process;  
  
    PO <= tmp;  
  
end archi;
```

Verilog Code

Following is the Verilog code for an 8-bit shift-left register with a positive-edge clock, a serial in and a parallel out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 8-bit Shift-Left Register with Positive-Edge Clock,  
// Serial In, and Parallel Out  
  
module v_shift_registers_5 (C, SI, PO);  
    input C,SI;  
    output [7:0] PO;  
    reg [7:0] tmp;  
  
    always @ (posedge C)  
        tmp <= {tmp[6:0], SI};  
  
    assign PO = tmp;  
  
endmodule
```

8-bit Shift-Left Register with Positive-Edge Clock, Asynchronous Parallel Load, Serial In and Serial Out

Note: For this example, XST does **not** infer SRL16.

The following table shows pin definitions for an 8-bit shift-left register with a positive-edge clock, an asynchronous parallel load, a serial in and a serial out.

IO Pins	Description
C	Positive-Edge Clock
SI	Serial In
ALOAD	Asynchronous Parallel Load (active High)
D[7:0]	Data Input
SO	Serial Output

VHDL Code

Following is VHDL code for an 8-bit shift-left register with a positive-edge clock, an asynchronous parallel load, a serial in and a serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 8-bit Shift-Left Register with Positive-Edge Clock,  
-- Asynchronous Parallel Load, Serial In, and Serial Out  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog Code

Following is the Verilog code for an 8-bit shift-left register with a positive-edge clock, an asynchronous parallel load, a serial in and a serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// 8-bit Shift-Left Register with Positive-Edge Clock,
// Asynchronous Parallel Load, Serial In, and Serial Out
//

module v_shift_registers_6 (C, ALOAD, SI, D, SO);
    input C,SI,ALOAD;
    input [7:0] D;
    output SO;
    reg [7:0] tmp;

    always @ (posedge C or posedge ALOAD)
    begin
        if (ALOAD)
            tmp <= D;
        else
            tmp <= {tmp[6:0], SI};
    end

    assign SO = tmp[7];

endmodule

```

8-bit Shift-Left Register with Positive-Edge Clock, Synchronous Parallel Load, Serial In and Serial Out

Note: For this example, XST does **not** infer SRL16.

The following table shows pin definitions for an 8-bit shift-left register with a positive-edge clock, a synchronous parallel load, a serial in and a serial out.

IO Pins	Description
C	Positive-Edge Clock
SI	Serial In
SLOAD	Synchronous Parallel Load (active High)
D[7:0]	Data Input
SO	Serial Output

VHDL Code

Following is the VHDL code for an 8-bit shift-left register with a positive-edge clock, synchronous parallel load, serial in and serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 8-bit Shift-Left Register with Positive-Edge Clock,  
-- Synchronous Parallel Load, Serial In, and Serial Out  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog Code

Following is the Verilog code for an 8-bit shift-left register with a positive-edge clock, a synchronous parallel load, a serial in and a serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 8-bit Shift-Left Register with Positive-Edge Clock,  
// Synchronous Parallel Load, Serial In, and Serial Out  
  
module v_shift_registers_7 (C, SLOAD, SI, D, SO);  
    input C,SI,SLOAD;  
    input [7:0] D;  
    output SO;  
    reg [7:0] tmp;  
  
    always @ (posedge C)  
    begin  
        if (SLOAD)  
            tmp <= D;  
        else  
            tmp <= {tmp[6:0], SI};  
    end  
  
    assign SO = tmp[7];  
  
endmodule
```

8-bit Shift-Left/Shift-Right Register with Positive-Edge Clock, Serial In and Parallel Out

Note: For this example, XST does **not** infer an SRL16.

The following table shows pin definitions for an 8-bit shift-left/shift-right register with a positive-edge clock, a serial in and a serial out.

IO Pins	Description
C	Positive-Edge Clock
SI	Serial In
LEFT_RIGHT	Left/right shift mode selector
PO[7:0]	Parallel Output

VHDL Code

Following is the VHDL code for an 8-bit shift-left/shift-right register with a positive-edge clock, a serial in and a serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 8-bit Shift-Left/Shift-Right Register with Positive-Edge Clock,  
-- Serial In, and Parallel Out  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog Code

Following is the Verilog code for an 8-bit shift-left/shift-right register with a positive-edge clock, a serial in and a serial out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// 8-bit Shift-Left/Shift-Right Register with Positive-Edge Clock,
// Serial In, and Parallel Out
//

module v_shift_registers_8 (C, SI, LEFT_RIGHT, PO);
    input C,SI,LEFT_RIGHT;
    output PO;
    reg [7:0] tmp;

    always @(posedge C)
    begin
        if (LEFT_RIGHT==1'b0)
            tmp <= {tmp[6:0], SI};
        else
            tmp <= {SI, tmp[7:1]};
    end

    assign PO = tmp;

endmodule

```

Dynamic Shift Register

XST can infer Dynamic shift registers. Once a dynamic shift register has been identified, its characteristics are handed to the XST macro generator for optimal implementation using SRL16x primitives available in Spartan-II/-IIE/-3, Virtex/-II/-II Pro/-II Pro X/-4 or SRLC16x in Virtex-II/-II Pro/-II Pro X/-4 and Spartan-3.

16-bit Dynamic Shift Register with Positive-Edge Clock, Serial In and Serial Out

The following table shows pin definitions for a dynamic register. The register can be either serial or parallel; be left or right; have a synchronous or asynchronous clear; and have a depth up to **16 bits**.

IO Pins	Description
Clk	Positive-Edge Clock
SI	Serial In
AClr	Asynchronous Clear (optional)
SClr	Synchronous Clear (optional)
SLoad	Synchronous Parallel Load (optional)

IO Pins	Description
Data	Parallel Data Input Port (optional)
ClkEn	Clock Enable (optional)
LeftRight	Direction selection (optional)
SerialInRight	Serial Input Right for Bidirectional Shift Register (optional)
PSO[x:0]	Serial or Parallel Output

LOG File

The recognition of dynamic shift registers happens in the Advanced HDL Synthesis step. The XST log file reports the size of recognized dynamic shift registers during the Macro Recognition step:

```

...
=====
*          HDL Synthesis          *
=====

Synthesizing Unit <dynamic_shift_registers_1>.
  Related source file is
  "dynamic_shift_registers_1.vhd".
    Found 1-bit 16-to-1 multiplexer for signal <Q>.
    Found 16-bit register for signal <SRL_SIG>.
  Summary:
    inferred  16 D-type flip-flop(s).
    inferred   1 Multiplexer(s).
Unit <dynamic_shift_registers_1> synthesized.

=====
*          Advanced HDL Synthesis      *
=====

...
Synthesizing (advanced) Unit
<dynamic_shift_registers_1>.
  Found 16-bit dynamic shift register for signal
<Q>.
Unit <dynamic_shift_registers_1> synthesized
(advanced).

=====
HDL Synthesis Report

Macro Statistics
# Shift Registers           : 1
  16-bit dynamic shift register : 1

...

```

Related Constraints

A related constraint is SHREG_EXTRACT.

VHDL Code

Following is the VHDL code for a 16-bit dynamic shift register.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 16-bit dynamic shift register.  
--  
  
library IEEE;  
use IEEE.std_logic_1164.all;  
use IEEE.std_logic_unsigned.all;  
  
entity dynamic_shift_registers_1 is  
    port(CLK : in std_logic;  
          DATA : in std_logic;  
          CE : in std_logic;  
          A : in std_logic_vector(3 downto 0);  
          Q : out std_logic);  
end dynamic_shift_registers_1;  
  
architecture rtl of dynamic_shift_registers_1 is  
    constant DEPTH_WIDTH : integer := 16;  
  
    type SRL_ARRAY is array (0 to DEPTH_WIDTH-1) of std_logic;  
    -- The type SRL_ARRAY can be array  
    -- (0 to DEPTH_WIDTH-1) of  
    -- std_logic_vector(BUS_WIDTH downto 0)  
    -- or array (DEPTH_WIDTH-1 downto 0) of  
    -- std_logic_vector(BUS_WIDTH downto 0)  
    -- (the subtype is forward (see below))  
    signal SRL_SIG : SRL_ARRAY;  
  
begin  
    PROC_SRL16 : process (CLK)  
    begin  
        if (CLK'event and CLK = '1') then  
            if (CE = '1') then  
                SRL_SIG <= DATA & SRL_SIG(0 to DEPTH_WIDTH-2);  
            end if;  
        end if;  
    end process;  
  
    Q <= SRL_SIG(conv_integer(A));  
  
end rtl;
```

Verilog Code

Following is the Verilog code for a 16-bit dynamic shift register.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// 16-bit dynamic shift register.
//

module v_dynamic_shift_registers_1 (Q,CE,CLK,D,A);
    input CLK, D, CE;
    input [3:0] A;
    output Q;
    reg [15:0] data;

    assign Q = data[A];

    always @ (posedge CLK)
    begin
        if (CE == 1'b1)
            data <= {data[14:0], D};
    end

endmodule

```

Multiplexers

XST supports different description styles for multiplexers (MUXes), such as If-Then-Else or Case. When writing MUXes, you must pay particular attention in order to avoid common traps. For example, if you describe a MUX using a Case statement, and you do not specify all values of the selector, you may get latches instead of a multiplexer. Writing MUXes you can also use "don't cares" to describe selector values.

During the Macro Inference step, XST makes a decision to infer or not infer the MUXes. For example, if the MUX has several inputs that are the same, then XST can decide not to infer it. If you do want to infer the MUX, you can force XST by using the design constraint called MUX_EXTRACT.

If you use Verilog, then you must be aware that Verilog Case statements can be full or not full, and they can also be parallel or not parallel. A Case statement is:

- FULL if all possible branches are specified.
- PARALLEL if it does not contain branches that can be executed simultaneously.

The following tables gives three examples of Case statements with different characteristics.

Full and Parallel Case

```
module full (sel, i1, i2, i3, i4, o1);
  input [1:0] sel;
  input [1:0] i1, i2, i3, i4;
  output [1:0] o1;

  reg [1:0] o1;

  always @ (sel or i1 or i2 or i3 or i4)
    begin
      case (sel)
        2'b00: o1 = i1;
        2'b01: o1 = i2;
        2'b10: o1 = i3;
        2'b11: o1 = i4;
      endcase
    end
  endmodule
```

Not Full but Parallel

```
module notfull (sel, i1, i2, i3, o1);
  input [1:0] sel;
  input [1:0] i1, i2, i3;
  output [1:0] o1;

  reg [1:0] o1;

  always @ (sel or i1 or i2 or i3)
    begin
      case (sel)
        2'b00: o1 = i1;
        2'b01: o1 = i2;
        2'b10: o1 = i3;
      endcase
    end
  endmodule
```

Neither Full nor Parallel

```

module notfull_notparallel (sel1, sel2, i1, i2, o1);
    input [1:0] sel1, sel2;
    input [1:0] i1, i2;
    output [1:0] o1;

    reg [1:0] o1;

    always @(sel1 or sel2)
    begin
        case (2'b00)
            sel1: o1 = i1;
            sel2: o1 = i2;
        endcase
    end
endmodule

```

XST automatically determines the characteristics of the Case statements and generates logic using multiplexers, priority encoders and latches that best implement the exact behavior of the Case statement.

This characterization of the Case statements can be guided or modified by using the Case Implementation Style parameter. Please refer to the [Chapter 5, “Design Constraints”](#) for more details. Accepted values for this parameter are *none*, *full*, *parallel* and *full-parallel*.

- If none is used (the default), XST implements the exact behavior of the Case statements.
- If full is used, XST considers that Case statements are complete and avoids latch creation.
- If parallel is used, XST considers that the branches cannot occur in parallel and does not use a priority encoder.
- If full-parallel is used, XST considers that Case statements are complete and that the branches cannot occur in parallel, therefore saving latches and priority encoders.

The following table indicates the *resources* used to synthesize the three examples above using the four Case Implementation Styles. The term "resources" means the functionality. For example, if you code the Case statement neither full nor parallel with Case Implementation Style set to *none*, from the functionality point of view, XST implements a priority encoder + latch. But, it does not inevitably mean that XST infers the priority encoder during the Macro Recognition step.

Parameter Value	Case Implementation		
	Full	Not Full	Neither Full nor Parallel
none	MUX	Latch	Priority Encoder + Latch
parallel	MUX	Latch	Latch
full	MUX	MUX	Priority Encoder
full-parallel	MUX	MUX	MUX

Note: Specifying full, parallel or full-parallel may result in an implementation with a behavior that may differ from the behavior of the initial model.

Log File

The XST log file reports the type and size of recognized MUXs during the Macro Recognition step.

```
...
Synthesizing Unit <mux>.
Related source file is multiplexers_1.vhd.
Found 1-bit 4-to-1 multiplexer for signal <o>.
Summary:
    inferred    1 Multiplexer(s).
Unit <mux> synthesized.

=====
HDL Synthesis Report

Macro Statistics
# Multiplexers          : 1
  1-bit 4-to-1 multiplexer : 1
=====
```

Related Constraints

Related constraints are MUX_EXTRACT, MUX_STYLE and ENUM_ENCODING.

4-to-1 1-bit MUX using IF Statement

The following table shows pin definitions for a 4-to-1 1-bit MUX using an If statement.

IO Pins	Description
a, b, c, d	Data Inputs
s[1:0]	MUX selector
o	Data Output

VHDL Code

Following is the VHDL code for a 4-to-1 1-bit MUX using an If statement.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 4-to-1 1-bit MUX using an If statement.  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog Code

Following is the Verilog code for a 4-to-1 1-bit MUX using an If statement.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 4-to-1 1-bit MUX using an If statement.  
//  
  
module v_multiplexers_1 (a, b, c, d, s, o);  
    input a,b,c,d;  
    input [1:0] s;  
    output o;  
    reg o;  
  
    always @ (a or b or c or d or s)  
    begin  
        if (s == 2'b00) o = a;  
        else if (s == 2'b01) o = b;  
        else if (s == 2'b10) o = c;  
        else o = d;  
    end  
endmodule
```

4-to-1 MUX Using Case Statement

The following table shows pin definitions for a 4-to-1 1-bit MUX using a Case statement.

IO Pins	Description
a, b, c, d	Data Inputs
s[1:0]	MUX selector
o	Data Output

VHDL Code

Following is the VHDL code for a 4-to-1 1-bit MUX using a Case statement.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 4-to-1 1-bit MUX using a Case statement.  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog Code

Following is the Verilog Code for a 4-to-1 1-bit MUX using a Case statement.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// 4-to-1 1-bit MUX using a Case statement.
// 

module v_multiplexers_2 (a, b, c, d, s, o);
    input a,b,c,d;
    input [1:0] s;
    output o;
    reg o;

    always @(a or b or c or d or s)
    begin
        case (s)
            2'b00 : o = a;
            2'b01 : o = b;
            2'b10 : o = c;
            default : o = d;
        endcase
    end
endmodule

```

4-to-1 MUX Using Tristate Buffers

The following table shows pin definitions for a 4-to-1 1-bit MUX using tristate buffers.

IO Pins	Description
a, b, c, d	Data Inputs
s[3:0]	MUX Selector
o	Data Output

VHDL Code

Following is the VHDL code for a 4-to-1 1-bit MUX using tristate buffers.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 4-to-1 1-bit MUX using tristate buffers.  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog Code

Following is the Verilog Code for a 4-to-1 1-bit MUX using tristate buffers.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 4-to-1 1-bit MUX using tristate buffers.  
//  
  
module v_multiplexers_3 (a, b, c, d, s, o);  
    input a,b,c,d;  
    input [3:0] s;  
    output o;  
  
    assign o = s[3] ? a :1'bz;  
    assign o = s[2] ? b :1'bz;  
    assign o = s[1] ? c :1'bz;  
    assign o = s[0] ? d :1'bz;  
endmodule
```

No 4-to-1 MUX

The following example does not generate a 4-to-1 1-bit MUX, but a 3-to-1 MUX with a 1-bit latch. The reason is that not all selector values were described in the If statement. It is supposed that for the s=11 case, "o" keeps its old value, and therefore a memory element is needed.

In this case, XST gives the following HDL Advisor Message:

WARNING:Xst:737 - Found 1-bit latch for signal <o1>.

INFO:Xst - HDL ADVISOR - Logic functions respectively driving the data and gate enable inputs of this latch share common terms. This situation will potentially lead to setup/hold violations and, as a result, to simulation problems. This situation may come from an incomplete case statement (all selector values are not covered). You should carefully review if it was in your intentions to describe such a latch.

The following table shows pin definitions for a 3-to-1 1-bit MUX with a 1-bit latch.

IO Pins	Description
a, b, c, d	Data Inputs
s[1:0]	Selector
o	Data Output

VHDL Code

Following is the VHDL code for a 3-to-1 1-bit MUX with a 1-bit latch.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
-- 
-- 3-to-1 1-bit MUX with a 1-bit latch.
-- 

library ieee;
use ieee.std_logic_1164.all;

entity multiplexers_4 is
    port (a, b, c: in std_logic;
          s : in std_logic_vector (1 downto 0);
          o : out std_logic);
end multiplexers_4;

architecture archi of multiplexers_4 is
begin
    process (a, b, c, s)
    begin
        if (s = "00") then o <= a;
        elsif (s = "01") then o <= b;
        elsif (s = "10") then o <= c;
        end if;
    end process;
end archi;
```

Verilog Code

Following is the Verilog code for a 3-to-1 1-bit MUX with a 1-bit latch.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 3-to-1 1-bit MUX with a 1-bit latch.  
  
module v_multiplexers_4 (a, b, c, s, o);  
    input a,b,c;  
    input [1:0] s;  
    output o;  
    reg o;  
  
    always @(a or b or c or s)  
    begin  
        if (s == 2'b00) o = a;  
        else if (s == 2'b01) o = b;  
        else if (s == 2'b10) o = c;  
    end  
endmodule
```

Decoders

A decoder is a multiplexer whose inputs are all constant with distinct one-hot (or one-cold) coded values. Please refer to “[Multiplexers](#)” in this chapter for more details. This section shows two examples of 1-of-8 decoders using One-Hot and One-Cold coded values.

Log File

The XST log file reports the type and size of recognized decoders during the Macro Recognition step.

```
Synthesizing Unit <dec>.  
Related source file is decoders_1.vhd.  
Found 1-of-8 decoder for signal <res>.  
Summary:  
    inferred 1 Decoder(s).  
Unit <dec> synthesized.  
=====  
HDL Synthesis Report  
  
Macro Statistics  
# Decoders : 1  
 1-of-8 decoder : 1  
=====  
...
```

The following table shows pin definitions for a 1-of-8 decoder.

IO pins	Description
s[2:0]	Selector
res	Data Output

Related Constraints

A related constraint is DECODER_EXTRACT.

VHDL (One-Hot)

Following is the VHDL code for a 1-of-8 decoder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- 1-of-8 decoder (One-Hot)  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog (One-Hot)

Following is the Verilog code for a 1-of-8 decoder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 1-of-8 decoder (One-Hot)  
  
module v_decoders_1 (sel, res);  
    input [2:0] sel;  
    output [7:0] res;  
    reg [7:0] res;  
  
    always @(sel or res)  
    begin  
        case (sel)  
            3'b000 : res = 8'b00000001;  
            3'b001 : res = 8'b00000010;  
            3'b010 : res = 8'b00000100;  
            3'b011 : res = 8'b00001000;  
            3'b100 : res = 8'b00010000;  
            3'b101 : res = 8'b00100000;  
            3'b110 : res = 8'b01000000;  
            default : res = 8'b10000000;  
        endcase  
    end  
endmodule
```

VHDL (One-Cold)

Following is the VHDL code for a 1-of-8 decoder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

-- 
-- 1-of-8 decoder (One-Cold)
--

library ieee;
use ieee.std_logic_1164.all;

entity decoders_2 is
    port (sel: in std_logic_vector (2 downto 0);
          res: out std_logic_vector (7 downto 0));
end decoders_2;

architecture archi of decoders_2 is
begin
    res <= "11111110" when sel = "000" else
        "11111101" when sel = "001" else
        "11111011" when sel = "010" else
        "11110111" when sel = "011" else
        "11101111" when sel = "100" else
        "11011111" when sel = "101" else
        "10111111" when sel = "110" else
        "01111111";
end archi;

```

Verilog (One-Cold)

Following is the Verilog code for a 1-of-8 decoder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

//
// 1-of-8 decoder (One-Cold)
//

module v_decoders_2 (sel, res);
    input [2:0] sel;
    output [7:0] res;
    reg [7:0] res;

    always @(sel)
    begin
        case (sel)
            3'b000 : res = 8'b11111110;
            3'b001 : res = 8'b11111101;
            3'b010 : res = 8'b11111011;
            3'b011 : res = 8'b11110111;
            3'b100 : res = 8'b11101111;
            3'b101 : res = 8'b11011111;
            3'b110 : res = 8'b10111111;
            default : res = 8'b01111111;
        endcase
    end
endmodule

```

Decoders with Unselected Outputs

In the current version, XST does not infer decoders if one or several of the decoder outputs are not selected, except when the unused selector values are consecutive and at the end of the code space. Following is an example:

IO pins	Description
s[2:0]	Selector
res	Data Output

VHDL Code (No Decoder Inference)

For the following VHDL code, XST does not infer a decoder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- No Decoder Inference (unused decoder output)  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  
entity decoders_3 is  
    port (sel: in std_logic_vector (2 downto 0);  
          res: out std_logic_vector (7 downto 0));  
end decoders_3;  
  
architecture archi of decoders_3 is  
begin  
    res <= "00000001" when sel = "000" else  
        -- unused decoder output  
        "XXXXXXXX" when sel = "001" else  
        "00000100" when sel = "010" else  
        "00001000" when sel = "011" else  
        "00010000" when sel = "100" else  
        "00100000" when sel = "101" else  
        "01000000" when sel = "110" else  
        "10000000";  
end archi;
```

Verilog Code (No Decoder Inference)

For the following Verilog code, XST does not infer a decoder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// No Decoder Inference (unused decoder output)  
  
module v_decoders_3 (sel, res);  
    input [2:0] sel;  
    output [7:0] res;  
    reg [7:0] res;  
  
    always @ (sel)  
    begin  
        case (sel)  
            3'b000 : res = 8'b00000001;  
            // unused decoder output  
            3'b001 : res = 8'bxxxxxxxx;  
            3'b010 : res = 8'b00000100;  
            3'b011 : res = 8'b00001000;  
            3'b100 : res = 8'b00010000;  
            3'b101 : res = 8'b00100000;  
            3'b110 : res = 8'b01000000;  
            default : res = 8'b10000000;  
        endcase  
    end  
endmodule
```

VHDL Code (Decoder Inference)

The following VHDL code leads to the inference of a 1-of-8 decoder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- No Decoder Inference (some selector values are unused)  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  
entity decoders_4 is  
    port (sel: in std_logic_vector (2 downto 0);  
          res: out std_logic_vector (7 downto 0));  
end decoders_4;  
  
architecture archi of decoders_4 is  
begin  
    res <= "00000001" when sel = "000" else  
          "00000010" when sel = "001" else  
          "00000100" when sel = "010" else  
          "00001000" when sel = "011" else  
          "00010000" when sel = "100" else  
          "00100000" when sel = "101" else  
          -- 110 and 111 selector values are unused  
          "XXXXXXXX";  
end archi;
```

Verilog Code (Decoder Inference)

The following Verilog code leads to the inference of a 1-of-8 decoder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// No Decoder Inference (some selector values are unused)  
//  
  
module v_decoders_4 (sel, res);  
    input [2:0] sel;  
    output [7:0] res;  
    reg [7:0] res;  
  
    always @(sel or res)  
    begin  
        case (sel)  
            3'b000 : res = 8'b00000001;  
            3'b001 : res = 8'b00000010;  
            3'b010 : res = 8'b00000100;  
            3'b011 : res = 8'b00001000;  
            3'b100 : res = 8'b00010000;  
            3'b101 : res = 8'b00100000;  
            // 110 and 111 selector values are unused  
            default : res = 8'bxxxxxxxx;  
        endcase  
    end  
endmodule
```

Priority Encoders

XST can recognize a priority encoder, but in most cases XST does not infer it. To force priority encoder inference, use the PRIORITY_EXTRACT constraint with the value *force*. Xilinx® strongly suggests that you use this constraint on a signal-by-signal basis; otherwise, the constraint may guide you towards sub-optimal results.

Log File

The XST log file reports the type and size of recognized priority encoders during the Macro Recognition step.

```

...
Synthesizing Unit <priority>.
Related source file is priority_encoders_1.vhd.
Found 3-bit 1-of-9 priority encoder for signal <code>.
Summary:
    inferred    3 Priority encoder(s).
Unit <priority> synthesized.

=====
HDL Synthesis Report

Macro Statistics
# Priority Encoders          : 1
  3-bit 1-of-9 priority encoder : 1
=====
...

```

3-Bit 1-of-9 Priority Encoder

Note: For this example XST may infer a priority encoder. You must use the PRIORITY_EXTRACT constraint with a value *force* to force its inference.

Related Constraint

A related constraint is PRIORITY_EXTRACT.

VHDL Code

Following is the VHDL code for a 3-bit 1-of-9 Priority Encoder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

--
-- 3-Bit 1-of-9 Priority Encoder
--

library ieee;
use ieee.std_logic_1164.all;

entity priority_encoder_1 is
    port ( sel : in std_logic_vector (7 downto 0);

```

```
        code :out std_logic_vector (2 downto 0));
end priority_encoder_1;

architecture archi of priority_encoder_1 is
begin

    code <= "000" when sel(0) = '1' else
        "001" when sel(1) = '1' else
        "010" when sel(2) = '1' else
        "011" when sel(3) = '1' else
        "100" when sel(4) = '1' else
        "101" when sel(5) = '1' else
        "110" when sel(6) = '1' else
        "111" when sel(7) = '1' else
        "---";

end archi;
```

Verilog Code

Following is the Verilog code for a 3-bit 1-of-9 Priority Encoder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// 3-Bit 1-of-9 Priority Encoder  
  
module v_priority_encoder_1 (sel, code);  
    input [7:0] sel;  
    output [2:0] code;  
    reg      [2:0] code;  
  
    always @ (sel)  
    begin  
        if      (sel[0]) code = 3'b000;  
        else if (sel[1]) code = 3'b001;  
        else if (sel[2]) code = 3'b010;  
        else if (sel[3]) code = 3'b011;  
        else if (sel[4]) code = 3'b100;  
        else if (sel[5]) code = 3'b101;  
        else if (sel[6]) code = 3'b110;  
        else if (sel[7]) code = 3'b111;  
        else           code = 3'bxxx;  
    end  
  
endmodule
```

Logical Shifters

Xilinx defines a logical shifter as a combinatorial circuit with 2 inputs and 1 output:

- The first input is a data input that is shifted.
- The second input is a selector whose binary value defines the shift distance.
- The output is the result of the shift operation.

Note: All of these I/Os are mandatory; otherwise, XST does *not* infer a logical shifter.

Moreover, you must adhere to the following conditions when writing your HDL code:

- Use only logical, arithmetic and rotate shift operations. Shift operations that fill vacated positions with values from another signal are not recognized.
- For VHDL, you can only use predefined shift (SLL, SRL, ROL, etc.) or concatenation operations. Please refer to the IEEE VHDL language reference manual for more information on predefined shift operations.
- Use only one type of shift operation.
- The n value in the shift operation must be incremented or decremented only by 1 for each consequent binary value of the selector.
- The n value can be only positive.
- All values of the selector must be presented.

Log File

The XST log file reports the type and size of a recognized logical shifter during the Macro Recognition step.

```

...
Synthesizing Unit <lshift>.
  Related source file is Logical_Shifters_1.vhd.
  Found 8-bit shifter logical left for signal <so>.
  Summary:
    inferred    1 Combinational logic shifter(s).
  Unit <lshift> synthesized.
...
=====
HDL Synthesis Report

Macro Statistics
# Logic shifters           : 1
  8-bit shifter logical left : 1
=====
...

```

Related Constraints

A related constraint is SHIFT_EXTRACT.

Example 1

The following table shows pin descriptions for a logical shifter.

IO pins	Description
D[7:0]	Data Input
SEL	Shift Distance Selector
SO[7:0]	Data Output

VHDL Code

Following is the VHDL code for a logical shifter.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Following is the VHDL code for a logical shifter.  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.numeric_std.all;  
  
entity logical_shifters_1 is  
    port(DI : in unsigned(7 downto 0);  
         SEL : in unsigned(1 downto 0);  
         SO : out unsigned(7 downto 0));  
end logical_shifters_1;  
  
architecture archi of logical_shifters_1 is  
begin  
    with SEL select  
        SO <= DI when "00",  
              DI sll 1 when "01",  
              DI sll 2 when "10",  
              DI sll 3 when others;  
end archi;
```

Verilog Code

Following is the Verilog code for a logical shifter.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Following is the Verilog code for a logical shifter.
// 

module v_logical_shifters_1 (DI, SEL, SO);
    input [7:0] DI;
    input [1:0] SEL;
    output [7:0] SO;
    reg [7:0] SO;

    always @(DI or SEL)
    begin
        case (SEL)
            2'b00 : SO = DI;
            2'b01 : SO = DI << 1;
            2'b10 : SO = DI << 2;
            default : SO = DI << 3;
        endcase
    end
endmodule

```

Example 2

XST does *not* infer a logical shifter for this example, as not all of the selector values are presented.

IO pins	Description
D[7:0]	Data Input
SEL	Shift Distance Selector
SO[7:0]	Data Output

VHDL Code

Following is the VHDL code.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- XST does not infer a logical shifter for this example,  
-- as not all of the selector values are presented.  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.numeric_std.all;  
  
entity logical_shifters_2 is  
    port(DI : in unsigned(7 downto 0);  
          SEL : in unsigned(1 downto 0);  
          SO : out unsigned(7 downto 0));  
end logical_shifters_2;  
  
architecture archi of logical_shifters_2 is  
begin  
    with SEL select  
        SO <= DI when "00",  
        DI sll 1 when "01",  
        DI sll 2 when others;  
end archi;
```

Verilog Code

Following is the Verilog code.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// XST does not infer a logical shifter for this example,  
// as not all of the selector values are presented.  
  
module v_logical_shifters_2 (DI, SEL, SO);  
    input [7:0] DI;  
    input [1:0] SEL;  
    output [7:0] SO;  
    reg [7:0] SO;  
  
    always @(DI or SEL)  
    begin  
        case (SEL)  
            2'b00 : SO = DI;  
            2'b01 : SO = DI << 1;  
            default : SO = DI << 2;  
        endcase  
    end  
endmodule
```

Example 3

XST does *not* infer a logical shifter for this example, as the value is not incremented by 1 for each consequent binary value of the selector.

IO pins	Description
D[7:0]	Data Input
SEL	shift distance selector
SO[7:0]	Data Output

VHDL Code

Following is the VHDL code.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- XST does not infer a logical shifter for this example,  
-- as the value is not incremented by 1 for each consequent  
-- binary value of the selector.  
--  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.numeric_std.all;  
  
entity logical_shifters_3 is  
    port(DI : in unsigned(7 downto 0);  
         SEL : in unsigned(1 downto 0);  
         SO : out unsigned(7 downto 0));  
end logical_shifters_3;  
  
architecture archi of logical_shifters_3 is  
begin  
    with SEL select  
        SO <= DI when "00",  
              DI sll 1 when "01",  
              DI sll 3 when "10",  
              DI sll 2 when others;  
end archi;
```

Verilog Code

Following is the Verilog code.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// XST does not infer a logical shifter for this example,  
// as the value is not incremented by 1 for each consequent  
// binary value of the selector.  
  
//  
  
module v_logical_shifters_3 (DI, SEL, SO);  
    input [7:0] DI;  
    input [1:0] SEL;  
    output [7:0] SO;  
    reg[7:0] SO;  
  
    always @(DI or SEL)  
    begin  
        case (SEL)  
            2'b00 : SO = DI;  
            2'b01 : SO = DI << 1;  
            2'b10 : SO = DI << 3;  
            default : SO = DI << 2;  
        endcase  
    end  
endmodule
```

Arithmetic Operations

XST supports the following arithmetic operations:

- Adders with:
 - ◆ Carry In
 - ◆ Carry Out
 - ◆ Carry In/Out
- Subtractors
- Adders/Subtractors
- Comparators ($=$, $/=$, $<$, \leq , $>$, \geq)
- Multipliers
- Dividers

Adders, subtractors, comparators and multipliers are supported for signed and unsigned operations.

Please refer to “[Signed/Unsigned Support](#)” in this chapter for more information on the signed/unsigned operations support in VHDL.

Moreover, XST performs resource sharing for adders, subtractors, adders/subtractors and multipliers.

Adders, Subtractors, Adders/Subtractors

This section provides HDL examples of adders and subtractors.

Log File

The XST log file reports the type and size of recognized adder, subtractor and adder/subtractor during the Macro Recognition step.

```

...
Synthesizing Unit <adder>.
Related source file is arithmetic_operations_1.vhd.
Found 8-bit adder for signal <sum>.
Summary:
    inferred    1 Adder/Subtracter(s).
Unit <adder> synthesized.

=====
HDL Synthesis Report

Macro Statistics
# Adders/Subtractors      : 1
  8-bit adder             : 1
=====
```

Related Constraints

Related constraints are USE_DSP48, DSP_UTILIZATION_RATIO, and KEEP, which are available for Virtex-4 devices.

Unsigned 8-bit Adder

This subsection contains a VHDL and Verilog description of an unsigned 8-bit adder.

The following table shows pin descriptions for an unsigned 8-bit adder.

IO pins	Description
A[7:0], B[7:0]	Add Operands
SUM[7:0]	Add Result

VHDL Code

Following is the VHDL code for an unsigned 8-bit adder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

[ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip](http://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip).

```
--  
-- Unsigned 8-bit Adder  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity adders_1 is  
    port(A,B : in std_logic_vector(7 downto 0);  
         SUM : out std_logic_vector(7 downto 0));  
end adders_1;  
  
architecture archi of adders_1 is  
begin  
  
    SUM <= A + B;  
  
end archi;
```

Verilog Code

Following is the Verilog code for an unsigned 8-bit adder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Unsigned 8-bit Adder  
//  
  
module vadders_1(A, B, SUM);  
    input [7:0] A;  
    input [7:0] B;  
    output [7:0] SUM;  
  
    assign SUM = A + B;  
  
endmodule
```

Unsigned 8-bit Adder with Carry In

This section contains VHDL and Verilog descriptions of an unsigned 8-bit adder with carry in.

The following table shows pin descriptions for an unsigned 8-bit adder with carry in.

IO pins	Description
A[7:0], B[7:0]	Add Operands
CI	Carry In
SUM[7:0]	Add Result

VHDL Code

Following is the VHDL code for an unsigned 8-bit adder with carry in.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Unsigned 8-bit Adder with Carry In  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity adders_2 is  
    port(A,B : in std_logic_vector(7 downto 0);  
         CI : in std_logic;  
         SUM : out std_logic_vector(7 downto 0));  
end adders_2;  
  
architecture archi of adders_2 is  
begin  
  
    SUM <= A + B + CI;  
  
end archi;
```

Verilog Code

Following is the Verilog code for an unsigned 8-bit adder with carry in.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Unsigned 8-bit Adder with Carry In  
//  
  
module vadders_2(A, B, CI, SUM);  
    input [7:0] A;  
    input [7:0] B;  
    input CI;  
    output [7:0] SUM;  
  
    assign SUM = A + B + CI;  
  
endmodule
```

Unsigned 8-bit Adder with Carry Out

This section contains VHDL and Verilog descriptions of an unsigned 8-bit adder with carry out.

If you use VHDL, then before writing a "+" operation with carry out, please examine the arithmetic package you are going to use. For example, "std_logic_unsigned" does not allow you to write "+" in the following form to obtain Carry Out:

$$\text{Res(9-bit)} = \text{A(8-bit)} + \text{B(8-bit)}$$

The reason is that the size of the result for "+" in this package is equal to the size of the longest argument, that is, 8 bits.

- One solution, for the example, is to adjust the size of operands A and B to 9-bits using concatenation.

$$\text{Res} \leq ("0" \& \text{A}) + ("0" \& \text{B});$$

In this case, XST recognizes that this 9-bit adder can be implemented as an 8-bit adder with carry out.

- Another solution is to convert A and B to integers and then convert the result back to the std_logic vector, specifying the size of the vector equal to 9.

The following table shows pin descriptions for an unsigned 8-bit adder with carry out.

IO pins	Description
A[7:0], B[7:0]	Add Operands
SUM[7:0]	Add Result
CO	Carry Out

VHDL Code

Following is the VHDL code for an unsigned 8-bit adder with carry out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
-- 
-- Unsigned 8-bit Adder with Carry Out
-- 

library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_arith.all;
use ieee.std_logic_unsigned.all;

entity adders_3 is
    port(A,B : in std_logic_vector(7 downto 0);
         SUM : out std_logic_vector(7 downto 0);
         CO : out std_logic);
end adders_3;

architecture archi of adders_3 is
    signal tmp: std_logic_vector(8 downto 0);
begin
```

```

        tmp <= conv_std_logic_vector((conv_integer(A) +
conv_integer(B)),9);
        SUM <= tmp(7 downto 0);
        CO <= tmp(8);

end archi;

```

In the preceding example, two arithmetic packages are used:

- std_logic_arith. This package contains the integer to std_logic conversion function, that is, conv_std_logic_vector.
- std_logic_unsigned. This package contains the unsigned "+" operation.

Verilog Code

Following is the Verilog code for an unsigned 8-bit adder with carry out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/mis.../examples_v7.zip.

```

/*
// Unsigned 8-bit Adder with Carry Out
//

module v_adders_3(A, B, SUM, CO);
    input [7:0] A;
    input [7:0] B;
    output [7:0] SUM;
    output CO;
    wire [8:0] tmp;

    assign tmp = A + B;
    assign SUM = tmp [7:0];
    assign CO = tmp [8];

endmodule

```

Unsigned 8-bit Adder with Carry In and Carry Out

The following table shows pin descriptions for an unsigned 8-bit adder with carry in and carry out.

IO pins	Description
A[7:0], B[7:0]	Add Operands
CI	Carry In
SUM[7:0]	Add Result
CO	Carry Out

VHDL Code

Following is the VHDL code for an unsigned 8-bit adder with carry in and carry out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Unsigned 8-bit Adder with Carry In and Carry Out  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_arith.all;  

```

Verilog Code

Following is the Verilog code for an unsigned 8-bit adder with carry in and carry out.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Unsigned 8-bit Adder with Carry In and Carry Out  
  
module v_adders_4(A, B, CI, SUM, CO);  
    input CI;  
    input [7:0] A;  
    input [7:0] B;  
    output [7:0] SUM;  
    output CO;  
    wire [8:0] tmp;  
  
    assign tmp = A + B + CI;  
    assign SUM = tmp [7:0];  
    assign CO = tmp [8];  
  
endmodule
```

Simple Signed 8-bit Adder

The following table shows pin descriptions for a simple signed 8-bit adder.

IO pins	Description
A[7:0], B[7:0]	Add Operands
SUM[7:0]	Add Result

VHDL Code

Following is the VHDL code for a simple signed 8-bit adder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Signed 8-bit Adder  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_signed.all;  
  
entity adders_5 is  
    port(A,B : in std_logic_vector(7 downto 0);  
         SUM : out std_logic_vector(7 downto 0));  
end adders_5;  
  
architecture archi of adders_5 is  
begin  
  
    SUM <= A + B;  
  
end archi;
```

Verilog Code

Following is the Verilog code for a simple signed 8-bit adder.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Signed 8-bit Adder  
//  
  
module vadders_5 (A,B,SUM);  
    input signed [7:0] A;  
    input signed [7:0] B;  
    output signed [7:0] SUM;  
    wire signed [7:0] SUM;  
  
    assign SUM = A + B;  
  
endmodule
```

Unsigned 8-bit Subtractor

The following table shows pin descriptions for an unsigned 8-bit subtractor.

IO pins	Description
A[7:0], B[7:0]	Sub Operands
RES[7:0]	Sub Result

VHDL Code

Following is the VHDL code for an unsigned 8-bit subtractor.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
-- 
-- Unsigned 8-bit Subtractor
--

library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;

entity adders_6 is
    port(A,B : in std_logic_vector(7 downto 0);
         RES : out std_logic_vector(7 downto 0));
end adders_6;

architecture archi of adders_6 is
begin

    RES <= A - B;

end archi;
```

Verilog Code

Following is the Verilog code for an unsigned 8-bit subtractor.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//
// Unsigned 8-bit Subtractor
//

module v_adders_6(A, B, RES);
    input [7:0] A;
    input [7:0] B;
    output [7:0] RES;

    assign RES = A - B;

endmodule
```

Unsigned 8-bit Adder/Subtractor

The following table shows pin descriptions for an unsigned 8-bit adder/subtractor.

IO pins	Description
A[7:0], B[7:0]	Add/Sub Operands
OPER	Add/Sub Select
SUM[7:0]	Add/Sub Result

VHDL Code

Following is the VHDL code for an unsigned 8-bit adder/subtractor.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Unsigned 8-bit Adder/Subtractor  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity adders_7 is  
    port(A,B : in std_logic_vector(7 downto 0);  
         OPER: in std_logic;  
         RES : out std_logic_vector(7 downto 0));  
end adders_7;  
  
architecture archi of adders_7 is  
begin  
  
    RES <= A + B when OPER='0'  
    else A - B;  
  
end archi;
```

Verilog Code

Following is the Verilog code for an unsigned 8-bit adder/subtractor.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Unsigned 8-bit Adder/Subtractor
//

module v_adders_7(A, B, OPER, RES);
    input OPER;
    input [7:0] A;
    input [7:0] B;
    output [7:0] RES;
    reg [7:0] RES;

    always @ (A or B or OPER)
    begin
        if (OPER==1'b0) RES = A + B;
        else RES = A - B;
    end

endmodule

```

Considerations for Virtex-4 Devices

The Virtex-4 family allows adders/subtractors to be implemented on DSP48 resources. XST supports the registered version of these macros and can push up to 2 levels of input registers and 1 level of output registers into DSP48 blocks. If the Carry In or Add/Sub operation selectors are registered, XST pushes these registers into the DSP48 as well.

XST can implement an adder/subtractor in a DSP48 block if its implementation requires only a single DSP48 resource. If an adder/subtractor macro does not fit in a single DSP48, XST implements the entire macro using slice logic.

Macro implementation on DSP48 blocks is controlled by the USE_DSP48 constraint/command line option with a default value of *auto*. In this mode XST implements adders/subtractors using LUTs. You must set the value of this constraint to *yes* to force XST to push these macros into a DSP48.

Please note that when implementing adders/subtractors on DSP48 blocks, XST does not perform any automatic DSP48 resource control, and as a consequence, the number of generated DSP48 blocks in the NGC netlist may exceed the number of available DSP48 blocks in a target device.

To deliver the best performance, XST by default tries to infer and implement the maximum macro configuration, including as many registers in the DSP48 as possible. If you want to shape a macro in a specific way, you must use the KEEP constraint. For example, if you want to exclude the first register stage from the DSP48, you must place KEEP constraints on the outputs of these registers.

Comparators (=, /=, <, <=, >, >=)

This section contains a VHDL and Verilog description for an unsigned 8-bit greater or equal comparator.

Log File

The XST log file reports the type and size of recognized comparators during the Macro Recognition step.

```
...
Synthesizing Unit <compar>.
Related source file is comparators_1.vhd.
Found 8-bit comparator greatequal for signal <$n0000> created at
line 10.
Summary:
    inferred      1 Comparator(s).
Unit <compar> synthesized.

=====
HDL Synthesis Report

Macro Statistics
# Comparators : 1
  8-bit comparator greatequal : 1
=====
```

Unsigned 8-bit Greater or Equal Comparator

The following table shows pin descriptions for a comparator.

IO pins	Description
A[7:0], B[7:0]	Comparison Operands
CMP	Comparison Result

VHDL Code

Following is the VHDL code for an unsigned 8-bit greater or equal comparator.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Unsigned 8-bit Greater or Equal Comparator  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity comparator_1 is  
    port(A,B : in std_logic_vector(7 downto 0);  
         CMP : out std_logic);  
end comparator_1;  
  
architecture archi of comparator_1 is  
begin  
  
    CMP <= '1' when A >= B else '0';  
  
end archi;
```

Verilog Code

Following is the Verilog code for an unsigned 8-bit greater or equal comparator.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Unsigned 8-bit Greater or Equal Comparator  
//  
  
module v_comparator_1 (A, B, CMP);  
    input [7:0] A;  
    input [7:0] B;  
    output CMP;  
  
    assign CMP = (A >= B) ? 1'b1 : 1'b0;  
  
endmodule
```

Multipliers

When implementing a multiplier, the size of the resulting signal is equal to the sum of 2 operand lengths. If you multiply A (8-bit signal) by B (4-bit signal), then the size of the result must be declared as a 12-bit signal.

Large Multipliers Using Block Multipliers

XST can generate large multipliers using an 18x18 bit block multiplier available in Virtex-II/-II Pro/-II Pro X. For multipliers larger than this, XST can generate larger multipliers using multiple 18x18 bit block multipliers.

Registered Multiplier

For Virtex-II/-II Pro/-II Pro X, in instances where a multiplier would have a registered output, XST infers a unique registered multiplier. This registered multiplier is 18x18 bits.

Under the following conditions, a registered multiplier is not used, and a multiplier + register is used instead.

- Output from the multiplier goes to any component other than the register.
- The MULT_STYLE constraint is set to *lut*.
- The multiplier is asynchronous.
- The multiplier has control signals other than synchronous reset or clock enable.
- The multiplier does not fit in a single 18x18 bit block multiplier.

The following pins are optional for a registered multiplier.

- clock enable port
- synchronous and asynchronous reset, and load ports

Considerations for Virtex-4 Devices

The Virtex-4 family allows multipliers to be implemented on DSP48 resources. XST supports the registered version of these macros and can push up to 2 levels of input registers and 2 levels of output registers into DSP48 blocks.

If a multiplier implementation requires multiple DSP48 resources, XST automatically decomposes it onto multiple DSP48 blocks. Depending on the operand size and to get the best performance, XST may implement most of a multiplier using DSP48 blocks and use slice logic for the rest of the macro. For example, it is not sufficient to use a single DSP48 to implement an 18x18 unsigned multiplier. In this case, XST implements most of the logic in one DSP48 and the rest in LUTs.

For Virtex-4 devices, XST can infer pipelined multipliers, not only for the LUT implementation, but for the DSP48 implementation as well. Please see “[Pipelined Multipliers](#)” for details.

Macro implementation on DSP48 blocks is controlled by the USE_DSP48 constraint/command line option, with a default value of *auto*. In this mode, XST implements multipliers taking into account the number of available DSP48 resources in the device.

In *auto* mode you can control the number of available DSP48 resources for the synthesis via DSP_UTILIZATION_RATIO constraint. By default, XST tries to utilize, as much as possible, all available DSP48 resources. See “[Using DSP48 Block Resources](#)” in Chapter 3 for more information.

Please note that XST can automatically recognize the MULT_STYLE constraint with values *lut* and *block* and then convert internally to USE_DSP48. Xilinx strongly recommends the use of the USE_DSP48 constraint for Virtex-4 designs to define FPGA resources used for multiplier implementation. Xilinx recommends the use of the MULT_STYLE constraint to define the multiplier implementation method on the selected FPGA resources. This means that if USE_DSP48 is set to *auto* or *yes*, you may use *mult_style=pipe_block* to pipeline the DSP48 implementation if the multiplier implementation requires multiple DSP48 blocks. If USE_DSP48 is set to *no*, you can use *mult_style=pipe_lut|KCM|CSD* to define the multiplier implementation method on LUTs.

To deliver the best performance, XST by default tries to infer and implement the maximum macro configuration, including as many registers in the DSP48 as possible. If you want to shape a macro in a specific way, you must use the KEEP constraint. For example, if you want to exclude the first register stage from the DSP48, you must place KEEP constraints on the outputs of these registers.

Multiplication with Constant

When one of the arguments is a constant, XST can create efficient dedicated implementations of a multiplier with constant. There are two methods: Constant Coeficient Multiplier (KCM) and Canonical Signed Digit (CSD).

Please note that dedicated implementations do not always provide the best results for multiplication with constants. Starting in release 6.2i, XST can automatically choose between KCM or standard multiplier implementation. The CSD method cannot be automatically chosen. Use the MULT_STYLE constraint to force CSD implementation.

Note: XST does not support KCM or CSD implementation for signed numbers.

Limitations:

If the either of the arguments is larger than 32 bits, XST does not use KCM or CSD implementation, even if it is specified with the MULT_STYLE constraint.

Log File

The XST log file reports the type and size of recognized multipliers during the Macro Recognition step.

```

...
Synthesizing Unit <mult>.
Related source file is multipliers_1.vhd.
Found 8x4-bit multiplier for signal <res>.
Summary:
        inferred    1 Multiplier(s).
Unit <mult> synthesized.

=====
HDL Synthesis Report

Macro Statistics
# Multipliers : 1
  8x4-bit multiplier : 1
=====
...

```

Related Constraints

Related constraints are MULT_STYLE, USE_DSP48, DSP_UTILIZATION_RATIO and KEEP.

Unsigned 8x4-bit Multiplier

The following table shows pin descriptions for an unsigned 8x4-bit multiplier.

IO pins	Description
A[7:0], B[3:0]	MULT Operands
RES[7:0]	MULT Result

VHDL Code

Following is the VHDL code for an unsigned 8x4-bit multiplier.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Unsigned 8x4-bit Multiplier  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity multipliers_1 is  
    port(A : in std_logic_vector(7 downto 0);  
         B : in std_logic_vector(3 downto 0);  
         RES : out std_logic_vector(11 downto 0));  
end multipliers_1;  
  
architecture beh of multipliers_1 is  
begin  
    RES <= A * B;  
end beh;
```

Verilog Code

Following is the Verilog code for an unsigned 8x4-bit multiplier.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Unsigned 8x4-bit Multiplier  
  
module v_multipliers_1(A, B, RES);  
    input [7:0] A;  
    input [3:0] B;  
    output [11:0] RES;  
  
    assign RES = A * B;  
endmodule
```

Pipelined Multipliers

To increase the speed of designs with large multipliers, XST can infer pipelined multipliers. By interspersing registers between the stages of large multipliers, pipelining can significantly increase the overall frequency of your design. The effect of pipelining is similar to flip-flop retiming which is described in “[Flip-Flop Retiming](#)” in Chapter 3.

To insert pipeline stages, describe the necessary registers in your HDL code and place them after any multipliers, then set the MULT_STYLE constraint to *pipe_lut*. If the target family is Virtex-4 and implementation of a multiplier requires multiple DSP48 blocks, XST can pipeline this implementation as well. You must set the MULT_STYLE constraint for this instance to *pipe_block*.

When XST detects valid registers for pipelining and MULT_STYLE is set to *pipe_lut* or *pipe_block*, XST uses the maximum number of available registers to reach the maximum multiplier speed. XST automatically calculates the maximum number of registers for each multiplier to get the best frequency.

If you have not specified sufficient register stages, and MULT_STYLE is coded directly on a signal, XST guides you via the HDL Advisor to specify the optimum number of register stages. XST does this during the Advanced HDL Synthesis step. If the number of registers placed after the multiplier exceeds the maximum required, and shift register extraction is activated, then XST implements the unused stages as shift registers.

Limitations:

- XST cannot pipeline hardware Multipliers (implementation using MULT18X18S resource).
- XST cannot pipeline multipliers if registers contain asynch set/reset or synch reset signals. XST *can* pipeline if registers contain synch reset signals.

Log File

```
=====
*                               HDL Synthesis
=====

Synthesizing Unit <multipliers_2>.
    Related source file is "multipliers_2.vhd".
    Found 36-bit register for signal <MULT>.
    Found 18-bit register for signal <a_in>.
    Found 18-bit register for signal <b_in>.
    Found 18x18-bit multiplier for signal <mult_res>.
    Found 36-bit register for signal <pipe_1>.
    Found 36-bit register for signal <pipe_2>.
    Found 36-bit register for signal <pipe_3>.
    Summary:
        inferred 180 D-type flip-flop(s).
        inferred 1 Multiplier(s).
Unit <multipliers_2> synthesized.
...
=====
*                               Advanced HDL Synthesis
=====

Synthesizing (advanced) Unit <multipliers_2>.
    Found pipelined multiplier on signal <mult_res>:
        - 4 pipeline level(s) found in a register connected
          to the multiplier macro output.
        Pushing register(s) into the multiplier macro.
INFO:Xst - HDL ADVISOR - You can improve the performance of the
multiplier Mmult_mult_res by adding 1 register level(s).
Unit <multipliers_2> synthesized (advanced).

=====
HDL Synthesis Report

Macro Statistics
# Multipliers : 1
18x18-bit registered multiplier : 1
=====
```

VHDL Code

Use the following templates to implement pipelined multipliers in VHDL.

The following VHDL template shows the multiplication operation placed outside the process block and the pipeline stages represented as single registers.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Pipelined multiplier  
-- The multiplication operation placed outside the  
-- process block and the pipeline stages represented  
-- as single registers.  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.numeric_std.all;  
  
entity multipliers_2 is  
    generic(A_port_size : integer := 18;  
            B_port_size : integer := 18);  
    port(clk : in std_logic;  
          A : in unsigned (A_port_size-1 downto 0);  
          B : in unsigned (B_port_size-1 downto 0);  
          MULT : out unsigned ( (A_port_size+B_port_size-1) downto 0));  
  
    attribute mult_style: string;  
    attribute mult_style of multipliers_2: entity is "pipe_lut";  
  
end multipliers_2;  
  
architecture beh of multipliers_2 is  
    signal a_in, b_in : unsigned (A_port_size-1 downto 0);  
    signal mult_res : unsigned ( (A_port_size+B_port_size-1) downto 0);  
    signal pipe_1,  
          pipe_2,  
          pipe_3 : unsigned ((A_port_size+B_port_size-1) downto 0);  
  
begin  
  
    mult_res <= a_in * b_in;  
  
    process (clk)  
    begin  
        if (clk'event and clk='1') then  
            a_in <= A; b_in <= B;  
            pipe_1 <= mult_res;  
            pipe_2 <= pipe_1;  
            pipe_3 <= pipe_2;  
            MULT <= pipe_3;  
        end if;  
    end process;  
end beh;
```

The following VHDL template shows the multiplication operation placed inside the process block and the pipeline stages represented as single registers.

```
--  
-- Pipelined multiplier  
-- The multiplication operation placed inside the  
-- process block and the pipeline stages represented  
-- as single registers.  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.numeric_std.all;  
  
entity multipliers_3 is  
    generic(A_port_size: integer := 18;  
            B_port_size: integer := 18);  
    port(clk : in std_logic;  
          A : in unsigned (A_port_size-1 downto 0);  
          B : in unsigned (B_port_size-1 downto 0);  
          MULT : out unsigned ((A_port_size+B_port_size-1) downto 0));  
  
    attribute mult_style: string;  
    attribute mult_style of multipliers_3: entity is "pipe_lut";  
  
end multipliers_3;  
  
architecture beh of multipliers_3 is  
    signal a_in, b_in : unsigned (A_port_size-1 downto 0);  
    signal mult_res : unsigned ((A_port_size+B_port_size-1) downto 0);  
    signal pipe_2,  
          pipe_3 : unsigned ((A_port_size+B_port_size-1) downto 0);  
  
begin  
    process (clk)  
    begin  
        if (clk'event and clk='1') then  
            a_in <= A; b_in <= B;  
            mult_res <= a_in * b_in;  
            pipe_2 <= mult_res;  
            pipe_3 <= pipe_2;  
            MULT <= pipe_3;  
        end if;  
    end process;  
end beh;
```

The following VHDL template shows the multiplication operation placed outside the process block and the pipeline stages represented as shift registers.

```

-- 
-- Pipelined multiplier
-- The multiplication operation placed outside the
-- process block and the pipeline stages represented
-- as shift registers.
-- 

library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;

entity multipliers_4 is
    generic(A_port_size: integer := 18;
            B_port_size: integer := 18);
    port(clk : in std_logic;
          A : in unsigned (A_port_size-1 downto 0);
          B : in unsigned (B_port_size-1 downto 0);
          MULT : out unsigned ((A_port_size+B_port_size-1) downto 0));
    attribute mult_style: string;
    attribute mult_style of multipliers_4: entity is "pipe_lut";

end multipliers_4;

architecture beh of multipliers_4 is
    signal a_in, b_in : unsigned (A_port_size-1 downto 0);
    signal mult_res : unsigned ((A_port_size+B_port_size-1) downto 0);

    type pipe_reg_type is array (2 downto 0) of unsigned
        ((A_port_size+B_port_size-1) downto 0);
    signal pipe_regs : pipe_reg_type;

begin

    mult_res <= a_in * b_in;

    process (clk)
    begin
        if (clk'event and clk='1') then
            a_in <= A; b_in <= B;
            pipe_regs <= mult_res & pipe_regs(2 downto 1);
            MULT <= pipe_regs(0);
        end if;
    end process;
end beh;

```

Verilog Code

Use the following templates to implement pipelined multipliers in Verilog.

The following Verilog template shows the multiplication operation placed outside the always block and the pipeline stages represented as single registers.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Pipelined multiplier  
// The multiplication operation placed outside the  
// always block and the pipeline stages represented  
// as single registers.  
  
module v_multipliers_2(clk, A, B, MULT);  
  
    // synthesis attribute mult_style of v_multipliers_2 is "pipe_lut";  
  
    input clk;  
    input [17:0] A;  
    input [17:0] B;  
    output [35:0] MULT;  
    reg [35:0] MULT;  
    reg [17:0] a_in, b_in;  
    wire [35:0] mult_res;  
    reg [35:0] pipe_1, pipe_2, pipe_3;  
  
    assign mult_res = a_in * b_in;  
  
    always @(posedge clk)  
    begin  
        a_in <= A; b_in <= B;  
        pipe_1 <= mult_res;  
        pipe_2 <= pipe_1;  
        pipe_3 <= pipe_2;  
        MULT <= pipe_3;  
    end  
endmodule
```

The following Verilog template shows the multiplication operation placed inside the always block and the pipeline stages are represented as single registers.

```
//  
// Pipelined multiplier  
// The multiplication operation placed inside the  
// process block and the pipeline stages are represented  
// as single registers.  
  
module v_multipliers_3(clk, A, B, MULT);  
  
    // synthesis attribute mult_style of v_multipliers_3 is "pipe_lut";  
  
    input clk;  
    input [17:0] A;  
    input [17:0] B;  
    output [35:0] MULT;  
    reg [35:0] MULT;  
    reg [17:0] a_in, b_in;  
    reg [35:0] mult_res;  
    reg [35:0] pipe_2, pipe_3;  
  
    always @(posedge clk)  
    begin  
        a_in <= A; b_in <= B;  
        mult_res <= a_in * b_in;  
        pipe_2 <= mult_res;  
        pipe_3 <= pipe_2;  
        MULT <= pipe_3;  
    end  
endmodule
```

The following Verilog template shows the multiplication operation placed outside the always block and the pipeline stages represented as shift registers.

```
//  
// Pipelined multiplier  
// The multiplication operation placed outside the  
// always block and the pipeline stages represented  
// as shift registers.  
  
module v_multipliers_4(clk, A, B, MULT);  
  
    // synthesis attribute mult_style of v_multipliers_4 is "pipe_lut";  
  
    input clk;  
    input [17:0] A;  
    input [17:0] B;  
    output [35:0] MULT;  
    reg [35:0] MULT;  
    reg [17:0] a_in, b_in;  
    wire [35:0] mult_res;  
    reg [35:0] pipe_regs [2:0];  
    integer i;  
  
    assign mult_res = a_in * b_in;  
  
    always @(posedge clk)  
    begin  
        a_in <= A; b_in <= B;  
  
        pipe_regs[2] <= mult_res;  
        for (i=0; i<=1; i=i+1) pipe_regs[i] <= pipe_regs[i+1];  
  
        MULT <= pipe_regs[0];  
    end  
  
endmodule
```

Multiply Adder/Subtractor

The Multiply Adder/Subtractor macro is a complex macro consisting of several basic macros such as multipliers, adder/subtractors and registers. The recognition of this complex macro enables XST to implement it on dedicated DSP48 resources available in Virtex-4 devices.

Log File

In the Log file, XST reports the details of inferred multipliers, adder/subtractors and registers at the HDL Synthesis step. The composition of multiply adder/subtractor macros

happens at the Advanced HDL Synthesis step. XST reports information about inferred MACs, because they are implemented within the MAC implementation mechanism.

```
=====
*                         HDL Synthesis
=====

Synthesizing Unit <multipliers_6>.
  Related source file is "multipliers_6.vhd".
  Found 8-bit register for signal <A_reg1>.
  Found 8-bit register for signal <A_reg2>.
  Found 8-bit register for signal <B_reg1>.
  Found 8-bit register for signal <B_reg2>.
  Found 8x8-bit multiplier for signal <mult>.
  Found 16-bit addsub for signal <maddsub>.

  Summary:
    inferred   32 D-type flip-flop(s).
    inferred   1 Adder/Subtractor(s).
    inferred   1 Multiplier(s).

Unit <multipliers_6> synthesized.
...
=====
*                         Advanced HDL Synthesis
=====

...
Synthesizing (advanced) Unit <Mmult_mult>.
  Multiplier <Mmult_mult> in block <multipliers_6> and
  adder/subtractor <maddsub_multaddsub> in block <multipliers_6> are
  combined into a MAC<Mmac_Maddsub_multaddsub>.

  The following registers are also absorbed by the MAC: <A_reg2>
  in block <multipliers_6>, <A_reg1> in block <multipliers_6>, <B_reg2>
  in block <multipliers_6>, <B_reg1> in block <multipliers_6>.

Unit <Mmult_mult> synthesized (advanced).

=====
HDL Synthesis Report

Macro Statistics
# MACs                      : 1
  8x8-to-16-bit MAC          : 1
=====
```

Related Constraints

Related constraints are USE_DSP48, DSP_UTILIZATION_RATIO and KEEP which are available for Virtex-4 devices.

Considerations for Virtex-4 Devices

XST supports the registered version of this macro and can push up to 2 levels of input registers on multiplier inputs, 1 register level on the Adder/Subtractor input and 1 level of output register into the DSP48 block. If the Carry In or Add/Sub operation selectors are registered, XST pushes these registers into the DSP48. In addition, the multiplication operation could be registered as well.

XST can implement a multiply adder/subtractor in a DSP48 block if its implementation requires only a single DSP48 resource. If the macro exceeds the limits of a single DSP48, XST processes it as two separate Multiplier and Adder/Subtractor macros, making independent decisions on each macro. Please refer to the “[Multipliers](#)” and “[Adders, Subtractors, Adders/Subtractors](#)” sections for more information.

Macro implementation on DSP48 blocks is controlled by the USE_DSP48 constraint/command line option, with default value of *auto*. In this mode, XST implements multiply adder/subtractors taking into account the number of available DSP48 resources in the device.

In auto mode the user can control the number of available DSP48 resources for the synthesis via DSP_UTILIZATION_RATIO constraint. By default, XST tries to utilize, as much as possible, all available DSP48 resources. See “[Using DSP48 Block Resources](#)” in [Chapter 3](#) for more information.

To deliver the best performance, XST by default tries to infer and implement the maximum macro configuration, including as many registers in the DSP48 as possible. If you want to shape a macro in a specific way, you must use the KEEP constraint. For example, if you want to exclude the first register stage from the DSP48, you must place KEEP constraints on the outputs of these registers.

In the Log file, XST reports the details of inferred multipliers, adder/subtractors and registers at the HDL Synthesis step. XST reports about inferred MACs during the Advanced HDL Synthesis Step where the MAC implementation mechanism takes place.

Multiplier Adder with 2 Register Levels on Multiplier Inputs

VHDL Code

Use the following templates to implement Multiplier Adder with 2 Register Levels on Multiplier Inputs in VHDL.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

[ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip](http://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip).

```
-- 
-- Multiplier Adder with 2 Register Levels on Multiplier Inputs
--

library IEEE;
use IEEE.STD_LOGIC_1164.ALL;
use IEEE.STD_LOGIC_UNSIGNED.ALL;

entity multipliers_5 is
    generic (p_width: integer:=8);
    port (clk : in std_logic;
          A, B, C : in std_logic_vector(p_width-1 downto 0);
          RES : out std_logic_vector(p_width*2-1 downto 0));
end multipliers_5;

architecture beh of multipliers_5 is
    signal A_reg1, A_reg2,
           B_reg1, B_reg2 : std_logic_vector(p_width-1 downto 0);
    signal multaddsub : std_logic_vector(p_width*2-1 downto 0);
begin

    multaddsub <= A_reg2 * B_reg2 + C;

    process is
        begin
            if rising_edge(clk) then
                A_reg1 <= A;
                B_reg1 <= B;
                A_reg2 <= C;
                B_reg2 <= multaddsub;
            end if;
        end process;
end;
```

```

process (clk)
begin
    if (clk'event and clk='1') then
        A_reg1 <= A; A_reg2 <= A_reg1;
        B_reg1 <= B; B_reg2 <= B_reg1;
    end if;
end process;

RES <= multaddsub;

end beh;

```

Verilog Code

Use the following templates to implement Multiplier Adder with 2 Register Levels on Multiplier Inputs in Verilog.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Multiplier Adder with 2 Register Levels on Multiplier Inputs
//

module v_multipliers_5 (clk, A, B, C, RES);

    input  clk;
    input  [7:0] A;
    input  [7:0] B;
    input  [7:0] C;
    output [15:0] RES;
    reg     [7:0] A_reg1, A_reg2, B_reg1, B_reg2;
    wire    [15:0] multaddsub;

    always @ (posedge clk)
    begin
        A_reg1 <= A; A_reg2 <= A_reg1;
        B_reg1 <= B; B_reg2 <= B_reg1;
    end

    assign multaddsub = A_reg2 * B_reg2 + C;
    assign RES = multaddsub;

endmodule

```

Multiplier Adder/Subtractor with 2 Register Levels on Multiplier Inputs

VHDL Code

Use the following templates to implement Multiplier Adder/Subtractor with 2 Register Levels on Multiplier Inputs in VHDL.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Multiplier Adder/Subtractor with  
-- 2 Register Levels on Multiplier Inputs  
--  
  
library IEEE;  
use IEEE.STD_LOGIC_1164.ALL;  
use IEEE.STD_LOGIC_UNSIGNED.ALL;  

```

Verilog Code

Use the following templates to implement Multiplier Adder/Subtractor with 2 Register Levels on Multiplier Inputs in Verilog.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Multiplier Adder/Subtractor with  
// 2 Register Levels on Multiplier Inputs  
  
module v_multipliers_6 (clk, add_sub, A, B, C, RES);  
  
    input clk,add_sub;  
    input [7:0] A;  
    input [7:0] B;  
    input [7:0] C;  
    output [15:0] RES;  
    reg [7:0] A_reg1, A_reg2, B_reg1, B_reg2;  
    wire [15:0] mult, multaddsub;  
  
    always @ (posedge clk)  
    begin  
        A_reg1 <= A; A_reg2 <= A_reg1;  
        B_reg1 <= B; B_reg2 <= B_reg1;  
    end  
  
    assign mult = A_reg2 * B_reg2;  
    assign multaddsub = add_sub ? C + mult : C - mult;  
    assign RES = multaddsub;  
  
endmodule
```

Multiply Accumulate (MAC)

The Multiply Accumulate macro is a complex macro which consists of several basic macros such as multipliers, accumulators and registers. The recognition of this complex macro enables XST to implement it on dedicated DSP48 resources available on Virtex-4 devices.

Log File

In the Log file, XST reports the details of inferred multipliers, accumulators and registers at the HDL Synthesis step. The composition of multiply accumulate macros happens at the Advanced HDL Synthesis step.

```
=====
*          HDL Synthesis
=====
...
Synthesizing Unit <multipliers_7a>.
    Related source file is "multipliers_7a.vhd".
    Found 8x8-bit multiplier for signal <$n0002> created at line 28.
    Found 16-bit up accumulator for signal <accum>.
    Found 16-bit register for signal <mult>.
    Summary:
        inferred    1 Accumulator(s).
        inferred   16 D-type flip-flop(s).
        inferred    1 Multiplier(s).
Unit <multipliers_7a> synthesized....
=====
*          Advanced HDL Synthesis
=====
...
Synthesizing (advanced) Unit <Mmult_n0002>.
    Multiplier <Mmult_n0002> in block <multipliers_7a> and
    accumulator <accum> in block <multipliers_7a> are combined into a
    MAC<Mmac_accum>.
    The following registers are also absorbed by the MAC: <mult>
    in block <multipliers_7a>.
Unit <Mmult_n0002> synthesized (advanced).

=====
HDL Synthesis Report

Macro Statistics
# MACs : 1
8x8-to-16-bit MAC : 1
=====
```

Related Constraints

Related constraints are USE_DSP48, DSP_UTILIZATION_RATIO and KEEP which are available for Virtex-4 devices.

Considerations for Virtex-4 Devices

The Multiply Accumulate macro is a complex macro which consists of several basic macros as multipliers, accumulators and registers. The recognition of this complex macro enables XST to implement it on dedicated DSP48 resources available in Virtex-4 devices.

XST supports the registered version of this macro, and can push up to 2 levels of input registers into the DSP48 block. If Adder/Subtractor operation selectors are registered, XST pushes these registers into the DSP48. In addition, the multiplication operation could be registered as well.

XST can implement a multiply accumulate in a DSP48 block if its implementation requires only a single DSP48 resource. If the macro exceeds the limits of a single DSP48, XST processes it as 2 separate Multiplier and Accumulate macros, making independent decisions on each macro. Please refer to the “[Multipliers](#)” and “[Accumulators](#)” sections for more information.

Macro implementation on DSP48 blocks is controlled by the USE_DSP48 constraint/command line option, with default value of *auto*. In this mode, XST implements multiply accumulate taking into account the number of available DSP48 resources in the device.

In auto mode the user can control the number of available DSP48 resources for the synthesis via DSP_UTILIZATION_RATIO constraint. By default, XST tries to utilize, as much as possible, all available DSP48 resources. Please refer to "Using DSP48 Block Resources" section in "FPGA Optimization" chapter for more information.

To deliver the best performance, XST by default tries to infer and implement the maximum macro configuration, including as many registers in the DSP48 as possible. If you want to shape a macro in a specific way, you must use the KEEP constraint. For example, if you want to exclude the first register stage from the DSP48, you must place KEEP constraints on the outputs of these registers.

In the Log file, XST reports the details of inferred multipliers, accumulators and registers at the HDL Synthesis step. The composition of multiply accumulate macros happens at Advanced HDL Synthesis step.

Multiplier Up Accumulate with Register After Multiplication

VHDL Code

Use the following templates to implement Multiplier Up Accumulate with Register After Multiplication in VHDL.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Multiplier Up Accumulate with Register After Multiplication  
--  
  
library IEEE;  
use IEEE.STD_LOGIC_1164.ALL;  
use IEEE.STD_LOGIC_UNSIGNED.ALL;  

```

Verilog Code

Use the following templates to implement Multiplier Up Accumulate with Register After Multiplication in Verilog.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Multiplier Up Accumulate with Register After Multiplication
//

module v_multipliers_7a (clk, reset, A, B, RES);

    input  clk, reset;
    input  [7:0] A;
    input  [7:0] B;
    output [15:0] RES;
    reg      [15:0] mult, accum;

    always @(posedge clk)
    begin
        if (reset)
            mult <= 16'b0000000000000000;
        else
            mult <= A * B;
    end

    always @(posedge clk)
    begin
        if (reset)
            accum <= 16'b0000000000000000;
        else
            accum <= accum + mult;
    end

    assign RES = accum;

endmodule

```

Multiplier Up/Down Accumulate with Register After Multiplication.

VHDL Code

Use the following templates to implement Multiplier Up/Down Accumulate with Register After Multiplication in VHDL.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Multiplier Up/Down Accumulate with Register After Multiplication.  
--  
  
library IEEE;  
use IEEE.STD_LOGIC_1164.ALL;  
use IEEE.STD_LOGIC_UNSIGNED.ALL;  

```

Verilog Code

Use the following templates to implement Multiplier Up/Down Accumulate with Register After Multiplication in Verilog.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Multiplier Up/Down Accumulate with Register After Multiplication.
// 

module v_multipliers_7b (clk, reset, add_sub, A, B, RES);

    input  clk, reset, add_sub;
    input  [7:0] A;
    input  [7:0] B;
    output [15:0] RES;
    reg     [15:0] mult, accum;

    always @(posedge clk)
    begin
        if (reset)
            mult <= 16'b0000000000000000;
        else
            mult <= A * B;
    end

    always @(posedge clk)
    begin
        if (reset)
            accum <= 16'b0000000000000000;
        else
            if (add_sub)
                accum <= accum + mult;
            else
                accum <= accum - mult;
    end

    assign RES = accum;

endmodule

```

Dividers

Dividers are only supported when the divisor is a constant and is a power of 2. In that case, the operator is implemented as a shifter; otherwise XST issues an error message.

Log File

When you implement a divider with a constant with the power of 2, XST does not issue any message during the Macro Recognition step. In case your divider does not correspond to the case supported by XST, the following error message displays:

```
...
ERROR:Xst:719 - file1.vhd (Line 172).
Operator is not supported yet : 'DIVIDE'
...
```

Related Constraints

There are no related constraints available.

Division By Constant 2

This section contains VHDL and Verilog descriptions of a Division By Constant 2 divider.

The following table shows pin descriptions for a Division By Constant 2 divider.

IO pins	Description
DI[7:0]	Division Operands
DO[7:0]	Division Result

VHDL

Following is the VHDL code for a Division By Constant 2 divider.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/mis.../examples_v7.zip.

```
-- 
-- Division By Constant 2
--

library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;

entity divider_1 is
    port(DI : in unsigned(7 downto 0);
         DO : out unsigned(7 downto 0));
end divider_1;

architecture archi of divider_1 is
begin
    DO <= DI / 2;
end archi;
```

Verilog

Following is the Verilog code for a Division By Constant 2 divider.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Division By Constant 2  
  
module v_divider_1 (DI, DO);  
    input [7:0] DI;  
    output [7:0] DO;  
  
    assign DO = DI / 2;  
  
endmodule
```

Resource Sharing

The goal of resource sharing (also known as folding) is to minimize the number of operators and the subsequent logic in the synthesized design. This optimization is based on the principle that two similar arithmetic resources may be implemented as one single arithmetic operator if they are never used at the same time. XST performs both resource sharing and, if required, reduces the number of multiplexers that are created in the process.

XST supports resource sharing for adders, subtractors, adders/subtractors and multipliers.

If the optimization goal is SPEED, then the disabling of resource sharing may lead to better results. XST advises you to try to deactivate resource sharing at the Advance HDL Synthesis step in order to improve clock frequency.

Log File

The XST log file reports the type and size of recognized arithmetic blocks and multiplexers during the Macro Recognition step.

```

...
Synthesizing Unit <addsub>.
Related source file is resource_sharing_1.vhd.
Found 8-bit addsub for signal <res>.
Found 8 1-bit 2-to-1 multiplexers.
Summary:
    inferred    1 Adder/Subtracter(s).
    inferred    8 Multiplexer(s).
Unit <addsub> synthesized.

=====
HDL Synthesis Report

Macro Statistics
# Multiplexers : 1
  2-to-1 multiplexer : 1
# Adders/Subtractors : 1
  8-bit addsub : 1
=====
...
=====
*           Advanced HDL Synthesis      *
=====

INFO:Xst - HDL ADVISOR - Resource sharing has identified that some
arithmetic operations in this design can share the same physical
resources for reduced device utilization. For improved clock
frequency you may try to disable resource sharing.
...


```

Related Constraint

The related constraint is RESOURCE_SHARING.

Example

For the following VHDL/Verilog example, XST gives the following solution.



The following table shows pin descriptions for the example.

IO pins	Description
A[7:0], B[7:0], C[7:0]	Operands
OPER	Operation Selector
RES[7:0]	Data Output

VHDL Code

Following is the VHDL example for resource sharing.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
-- 
-- Resource Sharing
--

library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;

entity resource_sharing_1 is
    port(A,B,C : in std_logic_vector(7 downto 0);
         OPER   : in std_logic;
         RES    : out std_logic_vector(7 downto 0));
end resource_sharing_1;

architecture archi of resource_sharing_1 is
begin

    RES <= A + B when OPER='0' else A - C;

end archi;
```

RAMs/ROMs

If you do not want to instantiate RAM primitives to keep your HDL code technology independent, XST offers an automatic RAM recognition capability. XST can infer distributed as well as block RAM. It covers the following characteristics, offered by these RAM types.

- Synchronous write
- Write enable
- RAM enable
- Asynchronous or synchronous read
- Reset of the data output latches
- Data output reset
- Single, dual or multiple-port read
- Single-port/Dual-port write
- Parity bits (Supported for all FPGA devices except Virtex, Virtex-E and corresponding Spartan families.)

Note: XST does not support RAMs/ROMs with negative addresses.

The type of inferred RAM depends on its description.

- RAM descriptions with an asynchronous read generate a distributed RAM macro.
- RAM descriptions with a synchronous read generate a block RAM macro. In some cases, a block RAM macro can actually be implemented with distributed RAM. The decision on the actual RAM implementation is done by the macro generator.

Following is the list of VHDL/Verilog templates that are described below.

- Virtex-II RAM Read/Write modes
 - ◆ Read-First Mode
 - ◆ Write-First Mode
 - ◆ No-Change Mode
- Single-Port RAM with Asynchronous Read
- Single-Port RAM with "False" Synchronous Read
- Single-Port RAM with Synchronous Read (Read Through)
- Single-Port RAM with Enable
- Dual-Port RAM with Asynchronous Read
- Dual-Port RAM with False Synchronous Read
- Dual-Port RAM with Synchronous Read (Read Through)
- Dual-Port RAM with One Enable Controlling Both Ports
- Dual-Port RAM with Enable Controlling Each Port
- Dual-Port RAM with Different Clocks
- Dual-Port RAM with two write ports
- Multiple-Port RAM Descriptions
- RAM with Reset
- Initializing RAM
- ROMs Using RAM Resources

If a given template can be implemented using Block and Distributed RAM, XST implements BLOCK ones. You can use the RAM_STYLE constraint to control RAM implementation and select a desirable RAM type. Please refer to [Chapter 5, “Design Constraints”](#) for more details.

Please note that the following features specifically available with block RAM are *not* yet supported.

- Dual write port
- Parity bits (Virtex, Virtex-E and corresponding Spartan families are not supported.)
- Different aspect ratios on each port

Please refer to [Chapter 3, “FPGA Optimization”](#) for more details on RAM implementation.

Note: Note that XST can implement State Machines (see “[State Machine](#)”) and map general logic (see “[Mapping Logic onto Block RAM](#)” in [Chapter 3](#)) on block RAMs.

Log File

The XST log file reports the type and size of recognized RAM as well as complete information on its I/O ports during the Macro Recognition step.

```
...
Synthesizing Unit <raminfr>.
Related source file is rams_1.vhd.
Found 128-bit single-port distributed RAM for signal <ram>.

-----
| aspect ratio | 32-word x 4-bit
| clock       | connected to signal <clk>
| write enable | connected to signal <we>
| address     | connected to signal <a>
| data in      | connected to signal <di>
| data out     | connected to signal <do>
| ram_style    | Auto
-----

INFO:Xst - For optimized device usage and improved timings, you
may take advantage of available block RAM resources by
registering the read address.

Summary:
        inferred    1 RAM(s).
Unit <raminfr> synthesized.

=====
HDL Synthesis Report

Macro Statistics
# RAMs           : 1
128-bit single-port distributed RAM : 1
=====
```

Related Constraints

Related constraints are RAM_EXTRACT, RAM_STYLE, ROM_EXTRACT and ROM_STYLE.

Beginning in release 7.1i, XST accepts LOC and RLOC constraints on inferred RAMs that can be implemented in a single block RAM primitive. The LOC and RLOC constraints are propagated to the NGC netlist.

Virtex-II/Virtex-4/Spartan-3 RAM Read/Write Modes

Block RAM resources available in Virtex-II/-II Pro/-II Pro X/-4 and Spartan-3 offer different read/write synchronization modes. This section provides coding examples for all three modes that are available: write-first, read-first and no-change.

The following examples describe a simple single-port block RAM. You can deduce descriptions of dual-port block RAMs from these examples. Dual-port block RAMs can be configured with a different read/write mode on each port. Inference supports this capability.

The following table summarizes support for read/write modes according to the targeted family and how XST handles it.

Family	Inferred Modes	Behavior
Spartan-3 Virtex-II, Virtex-II Pro, Virtex-II Pro X Virtex-4	write-first, read-first, no-change	<ul style="list-style-type: none"> Macro inference and generation Attach adequate WRITE_MODE, WRITE_MODE_A, WRITE_MODE_B constraints to generated block RAMs in NCF
Virtex, Virtex-E, Spartan-II Spartan-IIIE	write-first	<ul style="list-style-type: none"> Macro inference and generation No constraint to attach on generated block RAMs
CPLD	none	RAM inference completely disabled

Read-First Mode

The following templates show a single-port RAM in read-first mode.

VHDL Code

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Read-First Mode  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Read-First Mode  
  
module v_rams_01 (clk, en, we, addr, di, do);  
  
    input  clk;  
    input  we;  
    input  en;  
    input  [4:0] addr;  
    input  [3:0] di;  
    output [3:0] do;  
    reg     [3:0] RAM [31:0];  
    reg     [3:0] do;  
  
    always @ (posedge clk)  
    begin  
        if (en)  
            begin  
                if (we)  
                    RAM[addr]<=di;  
                do <= RAM[addr];  
            end  
        end  
    endmodule
```

Write-First Mode

The following templates show a single-port RAM in write-first mode.

VHDL Code

The following template shows the recommended configuration coded in VHDL.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Write-First Mode (template 1)  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity rams_02a is  
    port (clk : in std_logic;  
          we  : in std_logic;  
          en  : in std_logic;  
          addr : in std_logic_vector(4 downto 0);  
          di   : in std_logic_vector(3 downto 0);  
          do   : out std_logic_vector(3 downto 0));  
end rams_02a;  
  
architecture syn of rams_02a is  
    type ram_type is array (31 downto 0)  
        of std_logic_vector (3 downto 0);  
    signal RAM : ram_type;  
begin  
  
    process (clk)  
    begin  
        if clk'event and clk = '1' then  
            if en = '1' then  
                if we = '1' then  
                    RAM(conv_integer(addr)) <= di;  
                    do <= di;  
                else  
                    do <= RAM(conv_integer(addr));  
                end if;  
            end if;  
        end if;  
    end process;  
  
end syn;
```

The following templates show an alternate configuration of a single-port RAM in write-first mode with a registered read address coded in VHDL.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Write-First Mode (template 2)  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

The following template shows the recommended configuration coded in Verilog.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Write-First Mode (template 1)  
  
module v_rams_02a (clk, we, en, addr, di, do);  
  
    input  clk;  
    input  we;  
    input  en;  
    input  [4:0] addr;  
    input  [3:0] di;  
    output [3:0] do;  
    reg    [3:0] RAM [31:0];  
    reg    [3:0] do;  
  
    always @ (posedge clk)  
    begin  
        if (en)  
        begin  
            if (we)  
            begin  
                RAM[addr] <= di;  
                do <= di;  
            end  
            else  
                do <= RAM[addr];  
        end  
    end  
endmodule
```

The following templates show an alternate configuration of a single-port RAM in write-first mode with a registered read address coded in Verilog.

```

// 
// Write-First Mode (template 2)
// 

module v_rams_02b (clk, we, en, addr, di, do);

    input  clk;
    input  we;
    input  en;
    input  [4:0] addr;
    input  [3:0] di;
    output [3:0] do;
    reg    [3:0] RAM [31:0];
    reg    [4:0] read_addr;

    always @(posedge clk)
    begin
        if (en)
        begin
            if (we)
                RAM[addr] <= di;
            read_addr <= addr;
        end
    end

    assign do = RAM[read_addr];

endmodule

```

No-Change Mode

The following templates show a single-port RAM in no-change mode.

VHDL Code

The following template shows the recommended configuration coded in VHDL.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

-- 
-- No-Change Mode (template 1)
-- 

library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_unsigned.all;

entity rams_03 is
    port (clk  : in std_logic;
          we   : in std_logic;
          en   : in std_logic;
          addr : in std_logic_vector(4 downto 0);
          di   : in std_logic_vector(3 downto 0);
          do   : out std_logic_vector(3 downto 0));

```

```

        end rams_03;

architecture syn of rams_03 is
    type ram_type is array (31 downto 0) of std_logic_vector (3 downto
0);
    signal RAM : ram_type;
begin

    process (clk)
    begin
        if clk'event and clk = '1' then
            if en = '1' then
                if we = '1' then
                    RAM(conv_integer(addr)) <= di;
                else
                    do <= RAM( conv_integer(addr));
                end if;
            end if;
        end process;

    end syn;

```

Verilog Code

The following template shows the recommended configuration coded in Verilog.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// No-Change Mode (template 1)
//

module v_rams_03 (clk, we, en, addr, di, do);

    input  clk;
    input  we;
    input  en;
    input  [4:0] addr;
    input  [3:0] di;
    output [3:0] do;
    reg     [3:0] RAM [31:0];
    reg     [3:0] do;


    always @ (posedge clk)
    begin
        if (en)
        begin
            if (we)
                RAM[addr] <= di;
            else
                do <= RAM[addr];
        end
    end

endmodule

```

Single-Port RAM with Asynchronous Read

The following descriptions are directly mappable onto *distributed RAM only*.



X8976

The following table shows pin descriptions for a single-port RAM with asynchronous read.

IO Pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (Active High)
a	Read/Write Address
di	Data Input
do	Data Output

VHDL Code

Following is the VHDL code for a single-port RAM with asynchronous read.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Single-Port RAM with Asynchronous Read  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity rams_04 is  
    port (clk : in std_logic;  
          we  : in std_logic;  
          a   : in std_logic_vector(4 downto 0);  
          di  : in std_logic_vector(3 downto 0);  
          do  : out std_logic_vector(3 downto 0));  
end rams_04;  
  
architecture syn of rams_04 is  
    type ram_type is array (31 downto 0) of std_logic_vector (3 downto  
0);  
    signal RAM : ram_type;  
begin
```

```
process (clk)
begin
    if (clk'event and clk = '1') then
        if (we = '1') then
            RAM(conv_integer(a)) <= di;
        end if;
    end if;
end process;

do <= RAM(conv_integer(a));

end syn;
```

Verilog Code

Following is the Verilog code for a single-port RAM with asynchronous read.


These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Single-Port RAM with Asynchronous Read  
  
module v_rams_04 (clk, we, a, di, do);  
  
    input  clk;  
    input  we;  
    input  [4:0] a;  
    input  [3:0] di;  
    output [3:0] do;  
    reg     [3:0] ram [31:0];  
  
    always @ (posedge clk) begin  
        if (we)  
            ram[a] <= di;  
    end  
  
    assign do = ram[a];  
  
endmodule
```

Single-Port RAM with False Synchronous Read

The following descriptions do not implement true synchronous read access as defined by the Virtex block RAM specification, where the read address is registered. They are *only mappable onto distributed RAM* with an additional buffer on the data output, as shown below.



The following table shows pin descriptions for a single-port RAM with "false" synchronous read.

IO Pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (Active High)
a	Read/Write Address
di	Data Input
do	Data Output

VHDL

Following is the VHDL code for a single-port RAM with "false" synchronous read.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Single-Port RAM with "False" Synchronous Read  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity rams_05 is  
    port (clk : in std_logic;  
          we  : in std_logic;  
          a   : in std_logic_vector(4 downto 0);  
          di  : in std_logic_vector(3 downto 0);  
          do  : out std_logic_vector(3 downto 0));  
end rams_05;  
  
architecture syn of rams_05 is  
    type ram_type is array (31 downto 0)
```

```

        of std_logic_vector (3 downto 0);
signal RAM : ram_type;
begin

    process (clk)
begin
    if (clk'event and clk = '1') then
        if (we = '1') then
            RAM(conv_integer(a)) <= di;
        end if;
        do <= RAM(conv_integer(a));
    end if;
end process;

end syn;

```

Verilog

Following is the Verilog code for a single-port RAM with "false" synchronous read.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

/*
// Single-Port RAM with "False" Synchronous Read
//

module v_rams_05 (clk, we, a, di, do);


    input  clk;
    input  we;
    input  [4:0] a;
    input  [3:0] di;
    output [3:0] do;
    reg     [3:0] ram [31:0];
    reg     [3:0] do;

    always @ (posedge clk) begin
        if (we)
            ram[a] <= di;
        do <= ram[a];
    end

endmodule

```

The following descriptions, featuring an additional reset of the RAM output, are also *only mappable onto Distributed RAM* with an additional resetable buffer on the data output as shown in the following figure:



X8978

The following table shows pin descriptions for a single-port RAM with "false" synchronous read and reset on the output.

IO Pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (active High)
rst	Synchronous Output Reset (active High)
a	Read/Write Address
di	Data Input
do	Data Output

VHDL Code

Following is the VHDL code.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Single-Port RAM with "False" Synchronous Read with  
-- an additional reset of the RAM output,  
--  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity rams_06 is  
    port (clk : in std_logic;  
          we  : in std_logic;  
          rst : in std_logic;  
          a   : in std_logic_vector(4 downto 0);  
          di  : in std_logic_vector(3 downto 0);  
          do  : out std_logic_vector(3 downto 0));  
end rams_06;  
  
architecture syn of rams_06 is  
    type ram_type is array (31 downto 0) of std_logic_vector (3 downto  
0);  
    signal RAM : ram_type;  
begin  
  
    process (clk)  
    begin  
        if (clk'event and clk = '1') then  
  
            if (we = '1') then  
                RAM(conv_integer(a)) <= di;  
            end if;  
  
            if (rst = '1') then  
                do <= (others => '0');  
            else  
                do <= RAM(conv_integer(a));  
            end if;  
  
        end if;  
    end process;  
  
end syn;
```

Verilog Code

Following is the Verilog code.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Single-Port RAM with "False" Synchronous Read with
// an additional reset of the RAM output,
//
module v_rams_06 (clk, we, rst, a, di, do);

    input  clk;
    input  we;
    input  rst;
    input  [4:0] a;
    input  [3:0] di;
    output [3:0] do;
    reg      [3:0] ram [31:0];
    reg      [3:0] do;

    always @ (posedge clk) begin
        if (we)
            ram[a] <= di;


        if (rst)
            do <= 4'b0;
        else
            do <= ram[a];
    end

endmodule

```

Single-Port RAM with Synchronous Read (Read Through)

The following description implements a true synchronous read. A true synchronous read is the synchronization mechanism available in Virtex block RAMs, where the read address is registered on the RAM clock edge. Such descriptions are *directly mappable onto block RAM*, as shown below. (The same descriptions can also be mapped onto *Distributed RAM*).



X8979

The following table shows pin descriptions for a single-port RAM with synchronous read (read through).

IO pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (Active High)
a	Read/Write Address
di	Data Input
do	Data Output

VHDL Code

Following is the VHDL code for a single-port RAM with synchronous read (read through).

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Single-Port RAM with Synchronous Read (Read Through)  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity rams_07 is  
    port (clk : in std_logic;  
          we  : in std_logic;  
          a   : in std_logic_vector(4 downto 0);  
          di  : in std_logic_vector(3 downto 0);  
          do  : out std_logic_vector(3 downto 0));  
end rams_07;  
  
architecture syn of rams_07 is  
    type ram_type is array (31 downto 0) of std_logic_vector (3 downto 0);  
    signal RAM : ram_type;  
    signal read_a : std_logic_vector(4 downto 0);  
begin  
  
    process (clk)  
    begin  
        if (clk'event and clk = '1') then  
            if (we = '1') then  
                RAM(conv_integer(a)) <= di;  
            end if;  
            read_a <= a;  
        end if;  
    end process;  
  
    do <= RAM(conv_integer(read_a));  
  
end syn;
```

Verilog Code

Following is the Verilog code for a single-port RAM with synchronous read (read through). These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Single-Port RAM with Synchronous Read (Read Through)
//

module v_rams_07 (clk, we, a, di, do);

    input  clk;
    input  we;
    input  [4:0] a;
    input  [3:0] di;
    output [3:0] do;
    reg      [3:0] ram [31:0];
    reg      [4:0] read_a;

    always @ (posedge clk) begin
        if (we)
            ram[a] <= di;
        read_a <= a;
    end


    assign do = ram[read_a];

endmodule

```

Single-Port RAM with Enable

The following description implements a single-port RAM with a global enable.



The following table shows pin descriptions for a single-port RAM with enable.

IO pins	Description
clk	Positive-Edge Clock
en	Global Enable

IO pins	Description
we	Synchronous Write Enable (Active High)
a	Read/Write Address
di	Data Input
do	Data Output

VHDL Code

Following is the VHDL code for a single-port block RAM with enable.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/mis.../examples_v7.zip.

```
--  
-- Single-Port RAM with Enable  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity rams_08 is  
    port (clk : in std_logic;  
          en : in std_logic;  
          we : in std_logic;  
          a : in std_logic_vector(4 downto 0);  
          di : in std_logic_vector(3 downto 0);  
          do : out std_logic_vector(3 downto 0));  
end rams_08;  
  
architecture syn of rams_08 is  
    type ram_type is array (31 downto 0) of std_logic_vector (3 downto  
0);  
    signal RAM : ram_type;  
    signal read_a : std_logic_vector(4 downto 0);  
begin  
  
    process (clk)  
    begin  
        if (clk'event and clk = '1') then  
            if (en = '1') then  
                if (we = '1') then  
                    RAM(conv_integer(a)) <= di;  
                end if;  
                read_a <= a;  
            end if;  
        end if;  
    end process;  
  
    do <= RAM(conv_integer(read_a));  
  
end syn;
```

Verilog Code

Following is the Verilog code for a single-port block RAM with enable.


These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Single-Port RAM with Enable  
  
module v_rams_08 (clk, en, we, a, di, do);  
  
    input  clk;  
    input  en;  
    input  we;  
    input  [4:0] a;  
    input  [3:0] di;  
    output [3:0] do;  
    reg     [31:0] ram [31:0];  
    reg     [4:0]  read_a;  
  
    always @ (posedge clk) begin  
        if (en)  
            begin  
                if (we)  
                    ram[a] <= di;  
                read_a <= a;  
            end  
    end  
  
    assign do = ram[read_a];  
  
endmodule
```

Dual-Port RAM with Asynchronous Read

The following example shows where the two output ports are used. It is directly mappable onto *Distributed RAM only*.



The following table shows pin descriptions for a dual-port RAM with asynchronous read.

IO pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (active High)
a	Write Address/Primary Read Address
dpra	Dual Read Address
di	Data Input
spo	Primary Output Port
dpo	Dual Output Port

VHDL Code

Following is the VHDL code for a dual-port RAM with asynchronous read.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Dual-Port RAM with Asynchronous Read  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

Following is the Verilog code for a dual-port RAM with asynchronous read.


These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Dual-Port RAM with Asynchronous Read  
  
module v_rams_09 (clk, we, a, dpra, di, spo, dpo);  
  
    input  clk;  
    input  we;  
    input  [4:0] a;  
    input  [4:0] dpra;  
    input  [3:0] di;  
    output [3:0] spo;  
    output [3:0] dpo;  
    reg     [31:0] ram [31:0];  
  
    always @ (posedge clk) begin  
        if (we)  
            ram[a] <= di;  
    end  
  
    assign spo = ram[a];  
    assign dpo = ram[dpra];  
  
endmodule
```

Dual-Port RAM with False Synchronous Read

The following description is mapped onto Distributed RAM with additional registers on the data outputs. Please note that this template *does not* describe dual-port block RAM.



The following table shows pin descriptions for a dual-port RAM with false synchronous read.

IO Pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (active High)
a	Write Address/Primary Read Address
dpra	Dual Read Address
di	Data Input
spo	Primary Output Port
dpo	Dual Output Port

VHDL Code

Following is the VHDL code for a dual-port RAM with false synchronous read.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Dual-Port RAM with False Synchronous Read  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity rams_10 is  
    port (clk : in std_logic;  
          we : in std_logic;  
          a : in std_logic_vector(4 downto 0);  
          dpra : in std_logic_vector(4 downto 0);  
          di : in std_logic_vector(3 downto 0);  
          spo : out std_logic_vector(3 downto 0);  
          dpo : out std_logic_vector(3 downto 0));  
end rams_10;  
  
architecture syn of rams_10 is  
    type ram_type is array (31 downto 0) of std_logic_vector (3 downto 0);  
    signal RAM : ram_type;  
begin  
  
    process (clk)  
    begin  
        if (clk'event and clk = '1') then  
            if (we = '1') then  
                RAM(conv_integer(a)) <= di;  
            end if;  
  
            spo <= RAM(conv_integer(a));  
            dpo <= RAM(conv_integer(dpra));  
  
        end if;  
    end process;  
  
end syn;
```

Verilog Code

Following is the Verilog code for a dual-port RAM with false synchronous read.


These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Dual-Port RAM with False Synchronous Read  
  
module v_rams_10 (clk, we, a, dpra, di, spo, dpo);  
  
    input  clk;  
    input  we;  
    input  [4:0] a;  
    input  [4:0] dpra;  
    input  [3:0] di;  
    output [3:0] spo;  
    output [3:0] dpo;  
    reg    [3:0] ram [31:0];  
    reg    [3:0] spo;  
    reg    [3:0] dpo;  
  
    always @(posedge clk) begin  
        if (we)  
            ram[a] <= di;  
  
        spo <= ram[a];  
        dpo <= ram[dpra];  
    end  
  
endmodule
```

Dual-Port RAM with Synchronous Read (Read Through)

The following descriptions are *directly mappable onto block RAM*, as shown in the following figure. (They may also be implemented with *Distributed RAM*.).



The following table shows pin descriptions for a dual-port RAM with synchronous read (read through).

IO Pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (Active High)
a	Write Address/Primary Read Address
dpra	Dual Read Address
di	Data Input
spo	Primary Output Port
dpo	Dual Output Port

VHDL Code

Following is the VHDL code for a dual-port RAM with synchronous read (read through).

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Dual-Port RAM with Synchronous Read (Read Through)  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

Following is the Verilog code for a dual-port RAM with synchronous read (read through).

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Dual-Port RAM with Synchronous Read (Read Through)
//

module v_rams_11 (clk, we, a, dpra, di, spo, dpo);

    input  clk;
    input  we;
    input  [4:0] a;
    input  [4:0] dpra;
    input  [3:0] di;
    output [3:0] spo;
    output [3:0] dpo;
    reg    [3:0] ram [31:0];
    reg    [4:0] read_a;
    reg    [4:0] read_dpra;

    always @(posedge clk) begin
        if (we)
            ram[a] <= di;
        read_a <= a;
        read_dpra <= dpra;
    end

    assign spo = ram[read_a];
    assign dpo = ram[read_dpra];

endmodule

```

Using More than One Clock

The two RAM ports may be synchronized on distinct clocks, as shown in the following description. In this case, only a block RAM implementation is applicable.

The following table shows pin descriptions for a dual-port RAM with synchronous read (read through) and two clocks.

IO pins	Description
clk1	Positive-Edge Write/Primary Read Clock
clk2	Positive-Edge Dual Read Clock
we	Synchronous Write Enable (Active High)
add1	Write/Primary Read Address
add2	Dual Read Address
di	Data Input

IO pins	Description
do1	Primary Output Port
do2	Dual Output Port

VHDL Code

Following is the VHDL code.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Dual-Port RAM with Synchronous Read (Read Through)  
-- using More than One Clock  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity rams_12 is  
    port (clk1 : in std_logic;  
          clk2 : in std_logic;  
          we   : in std_logic;  
          add1 : in std_logic_vector(4 downto 0);  
          add2 : in std_logic_vector(4 downto 0);  
          di   : in std_logic_vector(3 downto 0);  
          do1  : out std_logic_vector(3 downto 0);  
          do2  : out std_logic_vector(3 downto 0));  
end rams_12;  
  
architecture syn of rams_12 is  
    type ram_type is array (31 downto 0) of std_logic_vector (3 downto 0);  
    signal RAM : ram_type;  
    signal read_add1 : std_logic_vector(4 downto 0);  
    signal read_add2 : std_logic_vector(4 downto 0);  
begin  
  
    process (clk1)  
    begin  
        if (clk1'event and clk1 = '1') then  
            if (we = '1') then  
                RAM(conv_integer(add1)) <= di;  
            end if;  
            read_add1 <= add1;  
        end if;  
    end process;  
  
    do1 <= RAM(conv_integer(read_add1));  
  
    process (clk2)  
    begin  
        if (clk2'event and clk2 = '1') then  
            read_add2 <= add2;  
        end if;  
    end process;  
  
    do2 <= RAM(conv_integer(read_add2));  
  
end syn;
```

Verilog Code

Following is the Verilog code.


These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Dual-Port RAM with Synchronous Read (Read Through)  
// using More than One Clock  
  
module v_rams_12 (clk1, clk2, we, add1, add2, di, do1, do2);  
  
    input  clk1;  
    input  clk2;  
    input  we;  
    input  [4:0] add1;  
    input  [4:0] add2;  
    input  [3:0] di;  
    output [3:0] do1;  
    output [3:0] do2;  
    reg    [3:0] ram [31:0];  
    reg    [4:0] read_add1;  
    reg    [4:0] read_add2;  
  
    always @ (posedge clk1) begin  
        if (we)  
            ram[add1] <= di;  
        read_add1 <= add1;  
    end  
  
    assign do1 = ram[read_add1];  
  
    always @ (posedge clk2) begin  
        read_add2 <= add2;  
    end  
  
    assign do2 = ram[read_add2];  
  
endmodule
```

Dual-Port RAM with One Enable Controlling Both Ports

The following descriptions are *directly mappable onto block RAM*, as shown in the following figure.



The following table shows pin descriptions for a dual-port RAM with one enable controlling both ports.

IO Pins	Description
clk	Positive-Edge Clock
en	Primary Global Enable (active High)
we	Primary Synchronous Write Enable (active High)
addra	Write Address/Primary Read Address
addrb	Dual Read Address
di	Primary Data Input
doa	Primary Output Port
dob	Dual Output Port

VHDL Code

Following is the VHDL code for a dual-port RAM with one global enable controlling both ports.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Dual-Port RAM with One Enable Controlling Both Ports  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

Following is the Verilog code for a dual-port RAM with one global enable controlling both ports.


These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Dual-Port RAM with One Enable Controlling Both Ports  
  
module v_rams_13 (clk, en, we, addra, addrb, di, doa, dob);  
  
    input clk;  
    input en;  
    input we;  
    input [4:0] addra;  
    input [4:0] addrb;  
    input [3:0] di;  
    output [3:0] doa;  
    output [3:0] dob;  
    reg [3:0] ram [31:0];  
    reg [4:0] read_addra;  
    reg [4:0] read_addrb;  
  
    always @(posedge clk) begin  
        if (en)  
            begin  
                if (we)  
                    ram[addra] <= di;  
                    read_addra <= addra;  
                    read_addrb <= addrb;  
            end  
        end  
  
        assign doa = ram[read_addra];  
        assign dob = ram[read_addrb];  
  
    endmodule
```

Dual-Port RAM with Enable on Each Port

The following descriptions are *directly mappable onto block RAM*, as shown in the following figure.



The following table shows pin descriptions for a dual-port RAM with enable on each port.

IO Pins	Description
clk	Positive-Edge Clock
ena	Primary Global Enable (Active High)
enb	Dual Global Enable (Active High)
wea	Primary Synchronous Write Enable (Active High)
addra	Write Address/Primary Read Address
addrb	Dual Read Address
dia	Primary Data Input
doa	Primary Output Port
dob	Dual Output Port

VHDL Code

Following is the VHDL code for a dual-port RAM with enable on each port.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Dual-Port RAM with Enable on Each Port  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

Following is the Verilog code for a dual-port RAM with enable on each port.


These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Dual-Port RAM with Enable on Each Port  
  
module v_rams_14 (clk,ena,enb,wea,addr_a,addr_b,dia,doa,dob);  
  
    input clk;  
    input ena;  
    input enb;  
    input wea;  
    input [4:0] addr_a;  
    input [4:0] addr_b;  
    input [3:0] dia;  
    output [3:0] doa;  
    output [3:0] dob;  
    reg [3:0] ram [31:0];  
    reg [4:0] read_addr_a;  
    reg [4:0] read_addr_b;  
  
    always @ (posedge clk) begin  
        if (ena)  
            begin  
                if (wea)  
                    ram[addr_a] <= dia;  
                read_addr_a <= addr_a;  
            end  
  
        if (enb)  
            read_addr_b <= addr_b;  
    end  
  
    assign doa = ram[read_addr_a];  
    assign dob = ram[read_addr_b];  
  
endmodule
```

Dual-Port Block RAM with Different Clocks

The following example shows where the two clocks are used.



The following table shows pin descriptions for a dual-port RAM with different clocks.

IO Pins	Description
clka	Positive-Edge Clock
clk b	Positive-Edge Clock
w ea	Primary Synchronous Write Enable (Active High)
addra	Write Address/Primary Read Address
addr b	Dual Read Address
dia	Primary Data Input
doa	Primary Output Port
dob	Dual Output Port

VHDL Code

Following is the VHDL code for a dual-port RAM with different clocks.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Dual-Port Block RAM with Different Clocks  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

Following is the Verilog code for a dual-port RAM with different clocks.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Dual-Port Block RAM with Different Clocks
//

module v_rams_15 (clka, clkb, wea, addra, addrb, dia, doa, dob);

    input  clka;
    input  clkb;
    input  wea;
    input  [4:0] addra;
    input  [4:0] addrb;
    input  [3:0] dia;
    output [3:0] doa;
    output [3:0] dob;
    reg    [3:0] RAM [31:0];
    reg    [4:0] read_addr;
    reg    [4:0] read_addrb;

    always @ (posedge clka)
    begin
        if (wea == 1'b1)
            RAM[addra] <= dia;
        read_addr <= addra;
    end

    always @ (posedge clkb)
    begin
        read_addrb <= addrb;
    end

    assign doa = RAM[read_addr];
    assign dob = RAM[read_addrb];

endmodule

```

Dual-Port Block RAM with Two Write Ports

Starting with release 8.1i, XST supports dual-port block RAMs with two write ports for VHDL and Verilog.

The notion of dual-write ports implies not only distinct data ports, but also possibly distinct write clocks and write enables. Note that distinct write clocks also means distinct read clocks since the dual-port block RAM offers two clocks, one shared by the primary read and write port, the other shared by the secondary read and write port.

In the VHDL he description of this type of block RAM is based on the usage of shared variables. The XST VHDL analyser accepts shared variables, but errors out in the HDL Synthesis step if a shared variable does not describe a valid RAM macro.

VHDL Code

The following VHDL sample shows the most general example; it has different clocks, enables and write enables. These coding examples are accurate as of the date of publication. You can download any updates to these examples from ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Dual-Port Block RAM with Two Write Ports  
--  
  
library IEEE;  
use IEEE.std_logic_1164.all;  
use IEEE.std_logic_unsigned.all;  

```

Because of the shared variable, the description of the different read/write synchronizations may be different from templates recommended for single-write RAMs. Note that the order of appearance of the different lines of code is significant.

Verilog Code

The following Verilog sample shows the most general example. It has different clocks, enables and write enables.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Dual-Port Block RAM with Two Write Ports
//

module v_rams_16
(clka,clkb,ena,enb,wea,web,addr,a,addrb,dia,dib,doa,dob);

    input  clka,clkb,ena,enb,wea,web;
    input  [7:0]  addr,a,addrb;
    input  [15:0] dia,dib;
    output [15:0] doa,dob;
    reg      [15:0] ram [255:0];
    reg      [15:0] doa,dob;

    always @(posedge clka) begin
        if (ena)
            begin
                if (wea)
                    ram[addr] <= dia;
                doa <= ram[addr];
            end
        end
    end

    always @(posedge clkb) begin
        if (enb)
            begin
                if (web)
                    ram[addrb] <= dib;
                dob <= ram[addrb];
            end
        end
    end

endmodule

```

Write-First

Write-first synchronization may be described using either of the following two templates.

Alternative 1

```
process (CLKA)
begin
  if CLKA'event and CLKA = '1' then
    if WEA = '1' then
      RAM(conv_integer(ADDRA)) := DIA;
      DOA <= DIA;
    else
      DOA <= RAM(conv_integer(ADDRA));
    end if;
  end if;
end process;
```

Alternative 2

In this example, the read statement necessarily comes after the write statement.

```
process (CLKA)
begin
  if CLKA'event and CLKA = '1' then
    if WEA = '1' then
      RAM(conv_integer(ADDRA)) := DIA;
    end if;
    DOA <= RAM(conv_integer(ADDRA)); -- The read statement must come
                                     -- AFTER the write statement
  end if;
end process;
```

Although they may look the same except for the signal/variable difference, it is also important to understand the functional difference between this template and the following well known template which describes a read-first synchronization in a single-write RAM:

```
signal RAM : RAMtype;

process (CLKA)
begin
  if CLKA'event and CLKA = '1' then
    if WEA = '1' then
      RAM(conv_integer(ADDRA)) <= DIA;
    end if;
    DOA <= RAM(conv_integer(ADDRA));
  end if;
end process;
```

Read-First

A read-first synchronization is described as follows, where the read statement must come BEFORE the write statement:

```
process (CLKA)
begin
    if CLKA'event and CLKA = '1' then
        DOA <= RAM(conv_integer(ADDRA)); -- The read statement must come
                                         -- BEFORE the write statement
        if WEA = '1' then
            RAM(conv_integer(ADDRA)) := DIA;
        end if;
    end if;
end process;
```


No-Change

The following is a description for a no-change synchronization:

```
process (CLKA)
begin
    if CLKA'event and CLKA = '1' then
        if WEA = '1' then
            RAM(conv_integer(ADDRA)) := DIA;
        else
            DOA <= RAM(conv_integer(ADDRA));
        end if;
    end if;
end process;
```

Multiple-Port RAM Descriptions

XST can identify RAM descriptions with two or more read ports that access the RAM contents at addresses different from the write address. However, there can only be one write port. XST implements the following descriptions by replicating the RAM contents for each output port, as shown:



The following table shows pin descriptions for a multiple-port RAM.

IO pins	Description
clk	Positive-Edge Clock
we	Synchronous Write Enable (Active High)
wa	Write Address

IO pins	Description
ra1	Read Address of the First RAM
ra2	Read Address of the Second RAM
di	Data Input
do1	First RAM Output Port
do2	Second RAM Output Port

VHDL Code

Following is the VHDL code for a multiple-port RAM.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Multiple-Port RAM Descriptions  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity rams_17 is  
    port (clk : in std_logic;  
          we : in std_logic;  
          wa : in std_logic_vector(4 downto 0);  
          ra1 : in std_logic_vector(4 downto 0);  
          ra2 : in std_logic_vector(4 downto 0);  
          di : in std_logic_vector(3 downto 0);  
          do1 : out std_logic_vector(3 downto 0);  
          do2 : out std_logic_vector(3 downto 0));  
end rams_17;  
  
architecture syn of rams_17 is  
    type ram_type is array (31 downto 0) of std_logic_vector (3 downto 0);  
    signal RAM : ram_type;  
begin  
  
    process (clk)  
    begin  
        if (clk'event and clk = '1') then  
            if (we = '1') then  
                RAM(conv_integer(wa)) <= di;  
            end if;  
        end if;  
    end process;  
  
    do1 <= RAM(conv_integer(ra1));  
    do2 <= RAM(conv_integer(ra2));  
  
end syn;
```

Verilog Code

Following is the Verilog code for a multiple-port RAM.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Multiple-Port RAM Descriptions
//

module v_rams_17 (clk, we, wa, ra1, ra2, di, do1, do2);

    input  clk;
    input  we;
    input  [4:0] wa;
    input  [4:0] ra1;
    input  [4:0] ra2;
    input  [3:0] di;
    output [3:0] do1;
    output [3:0] do2;
    reg      [3:0] ram [31:0];

    always @ (posedge clk)
    begin
        if (we)
            ram[wa] <= di;
    end

    assign do1 = ram[ra1];
    assign do2 = ram[ra2];

endmodule

```

Block RAM with Reset


XST supports block RAM with reset on the data outputs, as offered with Virtex, Virtex-II and related block RAM resources. Optionally, you can include a synchronously controlled initialization of the RAM data outputs.

Block RAM with the following synchronization modes can have resetable data ports.

- Read-First Block RAM with Reset
- Write-First Block RAM with Reset
- No-Change Block RAM with Reset
- Registered ROM with Reset
- Supported Dual-Port Templates

Note: Because XST does not support block RAMs with dual-write in a dual-read block RAM description, both data outputs may be reset, but the various read-write synchronizations are only allowed for the primary data output. The dual output may only be used in read-first mode.

The following example shows a Read-First Block RAM with reset.



X10019

The following table shows pin descriptions for a block RAM with reset.

IO pins	Description
clk	Positive-Edge Clock
en	Global Enable
we	Write Enable (active High)
addr	Read/Write Address
rst	Reset for data output
di	Data Input
do	RAM Output Port

VHDL Code

Following is the VHDL code for a read-first RAM with reset.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Block RAM with Reset  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity rams_18 is  
    port (clk : in std_logic;  
          en : in std_logic;  
          we : in std_logic;  
          rst : in std_logic;  
          addr : in std_logic_vector(4 downto 0);  
          di : in std_logic_vector(3 downto 0);  
          do : out std_logic_vector(3 downto 0));  
end rams_18;  
  
architecture syn of rams_18 is  
    type ram_type is array (31 downto 0) of std_logic_vector (3 downto 0);  
    signal ram : ram_type;  
begin  
  
    process (clk)  
    begin  
        if clk'event and clk = '1' then  
            if en = '1' then -- optional enable  
  
                if we = '1' then -- write enable  
                    ram(conv_integer(addr)) <= di;  
                end if;  
  
                if rst = '1' then -- optional reset  
                    do <= (others => '0');  
                else  
                    do <= ram(conv_integer(addr)) ;  
                end if;  
  
            end if;  
        end if;  
    end process;  
  
end syn;
```

Verilog Code

Following is the Verilog code for a read-first RAM with reset.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Block RAM with Reset  
  
module v_rams_18 (clk, en, we, rst, addr, di, do);  
  
    input  clk;  
    input  en;  
    input  we;  
    input  rst;  
    input  [4:0] addr;  
    input  [3:0] di;  
    output [3:0] do;  
    reg    [3:0] ram [31:0];  
    reg    [3:0] do;  
  
    always @ (posedge clk)  
    begin  
        if (en) // optional enable  
        begin  
            if (we) // write enable  
                ram[addr] <= di;  
  
            if (rst) // optional reset  
                do <= 4'b0000;  
            else  
                do <= ram[addr];  
        end  
    end  
  
endmodule
```

Block RAM with Optional Output Registers

For Virtex-4 devices, XST supports block RAMs with optional output registers on the data outputs.

VHDL Code

Following is the VHDL code for a Block Ram with optional output registers.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

-- 
-- Block RAM with Optional Output Registers
--

library IEEE;
library IEEE;
use IEEE.STD_LOGIC_1164.ALL;
use IEEE.STD_LOGIC_UNSIGNED.ALL;

entity rams_19 is
    port (clk1, clk2      : in std_logic;
          we, en1, en2 : in std_logic;
          addr1        : in std_logic_vector(6 downto 0);
          addr2        : in std_logic_vector(6 downto 0);
          di           : in std_logic_vector(7 downto 0);
          res1         : out std_logic_vector(7 downto 0);
          res2         : out std_logic_vector(7 downto 0));
end rams_19;

architecture beh of rams_19 is
    type mem_type is array (127 downto 0) of std_logic_vector (7 downto 0);
    signal mem : mem_type;
    signal do1 : std_logic_vector(7 downto 0);
    signal do2 : std_logic_vector(7 downto 0);
begin

    process (clk1)
    begin
        if rising_edge(clk1) then
            if we = '1' then
                mem(conv_integer(addr1)) <= di;
            end if;
            do1 <= mem(conv_integer(addr1));
        end if;
    end process;

    process (clk2)
    begin
        if rising_edge(clk2) then
            do2 <= mem(conv_integer(addr2));
        end if;
    end process;

    process (clk1)
    begin
        if rising_edge(clk1) then
            if en1 = '1' then
                res1 <= do1;
            end if;
        end if;
    end process;

    process (clk2)
    begin
        if rising_edge(clk2) then
            if en2 = '1' then
                res2 <= do2;
            end if;
        end if;
    end process;

```

```
        end if;
    end process;

end beh;
```

Verilog Code

Following is the Verilog code for a block RAM with optional output registers.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Block RAM with Optional Output Registers  
//  
  
module v_rams_19 (clk1, clk2, we, en1, en2, addr1, addr2, di, res1,  
res2);  
  
    input clk1;  
    input clk2;  
    input we, en1, en2;  
    input [6:0] addr1;  
    input [6:0] addr2;  
    input [7:0] di;  
    output [7:0] res1;  
    output [7:0] res2;  
    reg [7:0] res1;  
    reg [7:0] res2;  
    reg [7:0] RAM [127:0];  
    reg [7:0] do1;  
    reg [7:0] do2;  
  
    always @(posedge clk1)  
    begin  
        if (we == 1'b1)  
            RAM[addr1] <= di;  
        do1 <= RAM[addr1];  
    end  
  
    always @(posedge clk2)  
    begin  
        do2 <= RAM[addr2];  
    end  
  
    always @(posedge clk1)  
    begin  
        if (en1 == 1'b1)  
            res1 <= do1;  
    end  
  
    always @(posedge clk2)  
    begin  
        if (en2 == 1'b1)  
            res2 <= do2;  
    end  
  
endmodule
```

During the HDL Synthesis process, XST recognizes a BRAM and 2 optional output registers as separate objects from the BRAM. It is at the Advanced HDL Synthesis step that XST pushes the optional registers to BRAM. Following is the resulting log file.

```
=====
*          HDL Synthesis
=====
...
Synthesizing Unit <rams_19>.
  Related source file is "rams_19.vhd".
  Found 128x8-bit dual-port block RAM for signal <mem>.

-----
| mode           | read-first
| dual mode     | read-first
| aspect ratio   | 128-word x 8-bit
| clock          | connected to signal <clk1>    | rise
| dual clock    | connected to signal <clk2>    | rise
| write enable   | connected to signal <we>       | high
| address         | connected to signal <addr1>
| dual address   | connected to signal <addr2>
| data in          | connected to signal <di>
| data out         | connected to signal <do1>
| dual data out  | connected to signal <do2>
| ram_style       | Auto
-----

Found 8-bit register for signal <res1>.
Found 8-bit register for signal <res2>.
Summary:
  inferred    1 RAM(s).
  inferred   16 D-type flip-flop(s).
Unit <rams_19> synthesized.
```

```
=====
HDL Synthesis Report

Macro Statistics
# Block RAMs          : 1
 128x8-bit dual-port block RAM : 1
# Registers          : 2
 8-bit register        : 2
=====
```

```
=====
*           Advanced HDL Synthesis
=====
INFO:Xst:1954 - Data output of block RAM <Mram_mem> in block <rams_19> is tied to
register <res1> in block <rams_19>. The register is absorbed by the block RAM and
provides isolation from the interconnect routing delay for maximal operating
frequency.
INFO:Xst:1955 - Dual data output of block RAM <Mram_mem> in block <rams_19> is
tied to register <res2> in block <rams_19>. The register is absorbed by the block
RAM and provides isolation from the interconnect routing delay for maximal
operating frequency.
Advanced Registered AddSub inference ...

=====
HDL Synthesis Report

Macro Statistics
# Block RAMs          : 1
128x8-bit dual-port block RAM : 1
=====
...
```

Initializing RAM

Starting with the 8.1i release of XST, block and distributed RAM initial contents can be specified by initialization of the signal describing the memory array in your HDL code. You can do this directly in your HDL code, or you can specify a file containing the initialization data.

XST supports initialization for single and dual-port RAMs. Please note that this mechanism is supported only for Virtex-II, Virtex-II Pro, Spartan-3 and Virtex-4 device families.

Note: XST supports RAM initialization in both VHDL and Verilog.

VHDL Code

Specify RAM initial contents by initializing the signal describing the memory array in your VHDL code as in the following example:

```

...
type ram_type is array (0 to 63) of std_logic_vector(19 downto 0);
signal RAM : ram_type :=
(
  X"0200A", X"00300", X"08101", X"04000", X"08601", X"0233A",
  X"00300", X"08602", X"02310", X"0203B", X"08300", X"04002",
  X"08201", X"00500", X"04001", X"02500", X"00340", X"00241",
  X"04002", X"08300", X"08201", X"00500", X"08101", X"00602",
  X"04003", X"0241E", X"00301", X"00102", X"02122", X"02021",
  X"00301", X"00102", X"02222", X"04001", X"00342", X"0232B",
  X"00900", X"00302", X"00102", X"04002", X"00900", X"08201",
  X"02023", X"00303", X"02433", X"00301", X"04004", X"00301",
  X"00102", X"02137", X"02036", X"00301", X"00102", X"02237",
  X"04004", X"00304", X"04040", X"02500", X"02500", X"02500",
  X"0030D", X"02341", X"08201", X"0400D");
...
process (clk)
begin
  if rising_edge(clk) then
    if we = '1' then
      RAM(conv_integer(a)) <= di;
    end if;
    ra <= a;
  end if;
end process;
...
do <= RAM(conv_integer(ra));

```

The RAM initial contents can be specified in hexadecimal, as in the previous example, or in binary as shown in the following example:

```

...
type ram_type is array (0 to SIZE-1) of std_logic_vector(15 downto 0);
signal RAM : ram_type :=
(
  "0111100100000101",
  "0000010110111101",
  "1100001101010000",
  ...
  "0000100101110011");
...

```

Specify a single-port RAM initial contents using the following VHDL code.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Initializing Block RAM (Single-Port BRAM)  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Specify a dual-port RAM initial contents using the following VHDL code:

```
--  
-- Initializing Block RAM (Dual-Port BRAM)  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity rams_20b is  
    port (clk1 : in std_logic;  
          clk2 : in std_logic;  
          we : in std_logic;  
          addr1 : in std_logic_vector(7 downto 0);  
          addr2 : in std_logic_vector(7 downto 0);  
          di : in std_logic_vector(15 downto 0);  
          do1 : out std_logic_vector(15 downto 0);  
          do2 : out std_logic_vector(15 downto 0));  
end rams_20b;  
  
architecture syn of rams_20b is  
  
type ram_type is array (255 downto 0) of std_logic_vector (15 downto 0);  
signal RAM : ram_type:= (255 downto 100 => X"B8B8", 99 downto 0 => X"8282");  
  
begin  
  
process (clk1)  
begin  
    if rising_edge(clk1) then  
        if we = '1' then  
            RAM(conv_integer(addr1)) <= di;  
        end if;  
        do1 <= RAM(conv_integer(addr1));  
    end if;  
end process;  
  
process (clk2)  
begin  
    if rising_edge(clk2) then  
        do2 <= RAM(conv_integer(addr2));  
    end if;  
end process;  
  
end syn;
```

Initializing RAM from an External File

To initialize RAM from values contained in an external file, use a read function in your VHDL code. Please refer to the “[File Type Support](#)” in [Chapter 6](#) for more information. Set up the initialization file as follows.

- Use each line of the initialization file to represent the initial contents of a given row in the RAM.
- RAM contents can be represented in binary or hexadecimal.
- There should be as many lines in the file as there are rows in the RAM array.
- Below is a sample of the contents of a file initializing an 8 x 32-bit RAM with binary values:

```
00001111000011110000111100001111  
01001010001000001100000010000100  
0000000000111100000000001000001  
11111101010000011100010000100100  
00001111000011110000111100001111  
01001010001000001100000010000100  
0000000000111100000000001000001  
11111101010000011100010000100100
```

In the following example, the loop that generates the initial value is controlled by testing that we are in the RAM address range.

VHDL Code

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Initializing Block RAM from external data file  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Note: If there are not enough lines in the external data file, XST will issue the following message.

ERROR:Xst - raminitfile1.vhd line 40: Line <RamFileLine> has not enough elements for target <RAM<63>>.

Verilog Code

Specify RAM initial contents by initializing the signal describing the memory array in your Verilog code using initial statement as in the following example:

```
...
reg [19:0] ram [63:0];
initial begin
    ram[63] = 20'h0200A; ram[62] = 20'h00300; ram[61] = 20'h08101;
    ram[60] = 20'h04000; ram[59] = 20'h08601; ram[58] = 20'h0233A;
    ...
    ram[2] = 20'h02341; ram[1] = 20'h08201; ram[0] = 20'h0400D;
end
...
always @(posedge clk)
begin
    if (we)
        ram[addr] <= di;
    do <= ram[addr];
end
```

The RAM initial contents can be specified in hexadecimal, as in the previous example, or in binary as shown in the following example:

```
...
reg [15:0] ram [63:0];

type ram_type is array (0 to SIZE-1) of std_logic_vector(15 downto 0);
initial begin
    ram[63] = 16'b0111100100000101;
    ram[62] = 16'b0000010110111101;
    ram[61] = 16'b1100001101010000;
    ...
    ram[0] = 16'b00000100101110011;
end
...
```

Specify initial contents for a single-port RAM using the following Verilog code.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// Initializing Block RAM (Single-Port BRAM)
// 

module v_rams_20a (clk, we, addr, di, do);
    input  clk;
    input  we;
    input  [5:0] addr;
    input  [19:0] di;
    output [19:0] do;

    reg [19:0] ram [63:0];
    reg [19:0] do;

    initial begin
        ram[63] = 20'h0200A; ram[62] = 20'h00300; ram[61] = 20'h08101;
        ram[60] = 20'h04000; ram[59] = 20'h08601; ram[58] = 20'h0233A;
        ram[57] = 20'h00300; ram[56] = 20'h08602; ram[55] = 20'h02310;
        ram[54] = 20'h0203B; ram[53] = 20'h08300; ram[52] = 20'h04002;
        ram[51] = 20'h08201; ram[50] = 20'h00500; ram[49] = 20'h04001;
        ram[48] = 20'h02500; ram[47] = 20'h00340; ram[46] = 20'h00241;
        ram[45] = 20'h04002; ram[44] = 20'h08300; ram[43] = 20'h08201;
        ram[42] = 20'h00500; ram[41] = 20'h08101; ram[40] = 20'h00602;
        ram[39] = 20'h04003; ram[38] = 20'h0241E; ram[37] = 20'h00301;
        ram[36] = 20'h00102; ram[35] = 20'h02122; ram[34] = 20'h02021;
        ram[33] = 20'h00301; ram[32] = 20'h00102; ram[31] = 20'h02222;

        ram[30] = 20'h04001; ram[29] = 20'h00342; ram[28] = 20'h0232B;
        ram[27] = 20'h00900; ram[26] = 20'h00302; ram[25] = 20'h00102;
        ram[24] = 20'h04002; ram[23] = 20'h00900; ram[22] = 20'h08201;
        ram[21] = 20'h02023; ram[20] = 20'h00303; ram[19] = 20'h02433;
        ram[18] = 20'h00301; ram[17] = 20'h04004; ram[16] = 20'h00301;
        ram[15] = 20'h00102; ram[14] = 20'h02137; ram[13] = 20'h02036;
        ram[12] = 20'h00301; ram[11] = 20'h00102; ram[10] = 20'h02237;
        ram[9] = 20'h04004; ram[8] = 20'h00304; ram[7] = 20'h04040;
        ram[6] = 20'h02500; ram[5] = 20'h02500; ram[4] = 20'h02500;
        ram[3] = 20'h0030D; ram[2] = 20'h02341; ram[1] = 20'h08201;
        ram[0] = 20'h0400D;
    end

    always @(posedge clk)
    begin
        if (we)
            ram[addr] <= di;
        do <= ram[addr];
    end
endmodule

```

Specify initial contents for a dual-port RAM contents using the following Verilog code.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Initializing Block RAM (Dual-Port BRAM)  
  
module v_rams_20b (clk1, clk2, we, addr1, addr2, di, do1, do2);  
    input  clk1, clk2;  
    input  we;  
    input  [7:0]  addr1, addr2;  
    input  [15:0] di;  
    output [15:0] do1, do2;  
  
    reg [15:0] ram [255:0];  
    reg [15:0] do1, do2;  
    integer index;  
  
    initial begin  
        for (index = 0 ; index <= 99 ; index = index + 1) begin  
            ram[index] = 16'h8282;  
        end  
  
        for (index = 100 ; index <= 255 ; index = index + 1) begin  
            ram[index] = 16'hB8B8;  
        end  
    end  
  
    always @(posedge clk1)  
begin  
    if (we)  
        ram[addr1] <= di;  
    do1 <= ram[addr1];  
end  
  
    always @(posedge clk2)  
begin  
    do2 <= ram[addr2];  
end  
  
endmodule
```

Using System Tasks to Initialize RAM from an External File

- To initialize RAM from values contained in an external file, use a **\$readmemb** or **\$readmemh** system task in your Verilog code. See “[Behavioral Verilog Features](#)” in [Chapter 7](#) for more information. Set up the initialization file as follows.
 - ◆ Arrange each line of the initialization file to represent the initial contents of a given row in the RAM.
 - ◆ RAM contents can be represented in binary or hexadecimal.
 - ◆ Use **\$readmemb** for binary and **\$readmemh** for hexadecimal representation. Xilinx strongly suggests that you use index parameters in these system tasks as in the following example in order to avoid the possible difference between XST and simulator behavior:

```
$readmemb("rams_20c.data",ram, 0, 7);
```

- ◆ You should create as many lines in the file as there are rows in the RAM array.
- ◆ Following is a sample of the contents of a file initializing an 8 x 32-bit RAM with binary values:

```
00001111000011110000111100001111
01001010001000001100000010000100
0000000000111100000000001000001
1111101010000011100010000100100
00001111000011110000111100001111
01001010001000001100000010000100
0000000000111100000000001000001
1111101010000011100010000100100
```

Use the following examples to initialize RAM from values contained in an external file.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
/*
// Initializing Block RAM from external data file
//

module v_rams_20c (clk, we, addr, din, dout);
    input clk;
    input we;
    input [2:0] addr;
    input [31:0] din;
    output [31:0] dout;

    reg [31:0] ram [0:7];
    reg [31:0] dout;

    initial
    begin
        $readmemb("rams_20c.data",ram, 0, 7);
    end

    always @(posedge clk)
    begin
        if (we)
            ram[addr] <= din;
        dout <= ram[addr];
    end

endmodule
```

Limitations

- Initialization of inferred RAMs from RTL code is not supported via INIT constraints. Use of INIT constraints is only supported if RAM primitives are directly instantiated from the UNISIM library.

ROMs Using Block RAM Resources

XST can use block RAM resources to implement ROMs with synchronous outputs or address inputs. These ROMs are implemented as single-port block RAMs. The use of block RAM resources to implement ROMs is controlled by the ROM_STYLE constraint. Please see [Chapter 5, “Design Constraints”](#) for details about the ROM_STYLE attribute. Please see [Chapter 3, “FPGA Optimization”](#) for details on ROM implementation.

Here is a list of VHDL/Verilog templates described below.

- ROM with registered output
- ROM with registered address

The following table shows pin descriptions for a registered ROM.

IO Pins	Description
clk	Positive-Edge Clock
en	Synchronous Enable (active High)
addr	Read Address
data	Data Output

VHDL Code

Following is the recommended VHDL code for a ROM with registered output.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- ROMs Using Block RAM Resources.  
-- VHDL code for a ROM with registered output (template 1)  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Following is alternate VHDL code for a ROM with registered output.

```
--  
-- ROMs Using Block RAM Resources.  
-- VHDL code for a ROM with registered output (template 2)  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Following is VHDL code for a ROM with registered address.

```
--  
-- ROMs Using Block RAM Resources.  
-- VHDL code for a ROM with registered address  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  
  
entity rams_21c is  
port (clk : in std_logic;  
      en : in std_logic;  
      addr : in std_logic_vector(4 downto 0);  
      data : out std_logic_vector(3 downto 0));  
end rams_21c;  
  
architecture syn of rams_21c is  
type rom_type is array (31 downto 0) of std_logic_vector (3 downto 0);  
constant ROM : rom_type :=("0001","0010","0011","0100","0101",  
                           "0110","0111","1000","1001","1010",  
                           "1011","1100","1101","1110","1111",  
                           "0001","0010","0011","0100","0101",  
                           "0110","0111","1000","1001","1010",  
                           "1011","1100","1101","1110","1111",  
                           "1111","1111");  
  
signal raddr : std_logic_vector(4 downto 0);  
begin  
  
process (clk)  
begin  
  if (clk'event and clk = '1') then  
    if (en = '1') then  
      raddr <= addr;  
    end if;  
  end if;  
end process;  
  
data <= ROM(conv_integer(raddr));  
  
end syn;
```

Verilog Code

Following is Verilog code for a ROM with registered output.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// ROMs Using Block RAM Resources.  
// Verilog code for a ROM with registered output (template 1)  
  
module v_rams_21a (clk, en, addr, data);  
  
    input      clk;  
    input      en;  
    input [4:0] addr;  
    output reg [3:0] data;  
  
    always @ (posedge clk) begin  
        if (en)  
            case(addr)  
                5'b00000: data <= 4'b0010;  
                5'b00001: data <= 4'b0010;  
                5'b00010: data <= 4'b1110;  
                5'b00011: data <= 4'b0010;  
                5'b00100: data <= 4'b0100;  
                5'b00101: data <= 4'b1010;  
                5'b00110: data <= 4'b1100;  
                5'b00111: data <= 4'b0000;  
                5'b01000: data <= 4'b1010;  
                5'b01001: data <= 4'b0010;  
                5'b01010: data <= 4'b1110;  
                5'b01011: data <= 4'b0010;  
                5'b01100: data <= 4'b0100;  
                5'b01101: data <= 4'b1010;  
                5'b01110: data <= 4'b1100;  
                5'b01111: data <= 4'b0000;  
                5'b10000: data <= 4'b0010;  
                5'b10001: data <= 4'b0010;  
                5'b10010: data <= 4'b1110;  
                5'b10011: data <= 4'b0010;  
                5'b10100: data <= 4'b0100;  
                5'b10101: data <= 4'b1010;  
                5'b10110: data <= 4'b1100;  
                5'b10111: data <= 4'b0000;  
                5'b11000: data <= 4'b1010;  
                5'b11001: data <= 4'b0010;  
                5'b11010: data <= 4'b1110;  
                5'b11011: data <= 4'b0010;  
                5'b11100: data <= 4'b0100;  
                5'b11101: data <= 4'b1010;  
                5'b11110: data <= 4'b1100;  
                5'b11111: data <= 4'b0000;  
            endcase  
        end  
    endmodule
```

Following is alternate Verilog code for a ROM with registered output.

```

// 
// ROMs Using Block RAM Resources.
// Verilog code for a ROM with registered output (template 2)
//

module v_rams_21b (clk, en, addr, data);

    input      clk;
    input      en;
    input [4:0] addr;
    output reg [3:0] data;
    reg        [3:0] rdata;

    always @(addr) begin
        case(addr)
            5'b00000: rdata = 4'b0010;
            5'b00001: rdata = 4'b0010;
            5'b00010: rdata = 4'b1110;
            5'b00011: rdata = 4'b0010;
            5'b00100: rdata = 4'b0100;
            5'b00101: rdata = 4'b1010;
            5'b00110: rdata = 4'b1100;
            5'b00111: rdata = 4'b0000;
            5'b01000: rdata = 4'b1010;
            5'b01001: rdata = 4'b0010;
            5'b01010: rdata = 4'b1110;
            5'b01011: rdata = 4'b0010;
            5'b01100: rdata = 4'b0100;
            5'b01101: rdata = 4'b1010;
            5'b01110: rdata = 4'b1100;
            5'b01111: rdata = 4'b0000;
            5'b10000: rdata = 4'b0010;
            5'b10001: rdata = 4'b0010;
            5'b10010: rdata = 4'b1110;
            5'b10011: rdata = 4'b0010;
            5'b10100: rdata = 4'b0100;
            5'b10101: rdata = 4'b1010;
            5'b10110: rdata = 4'b1100;
            5'b10111: rdata = 4'b0000;
            5'b11000: rdata = 4'b1010;
            5'b11001: rdata = 4'b0010;
            5'b11010: rdata = 4'b1110;
            5'b11011: rdata = 4'b0010;
            5'b11100: rdata = 4'b0100;
            5'b11101: rdata = 4'b1010;
            5'b11110: rdata = 4'b1100;
            5'b11111: rdata = 4'b0000;
        endcase
    end

    always @(posedge clk) begin
        if (en)
            data <= rdata;
    end
endmodule

```

Following is Verilog code for a ROM with registered address.

```
//  
// ROMs Using Block RAM Resources.  
// VHDL code for a ROM with registered address  
  
module v_rams_21c (clk, en, addr, data);  
  
    input      clk;  
    input      en;  
    input [4:0] addr;  
    output reg [3:0] data;  
    reg        [4:0] raddr;  
  
    always @ (posedge clk) begin  
        if (en)  
            raddr <= addr;  
    end  
  
    always @ (raddr) begin  
        case(raddr)  
            5'b00000: data = 4'b0010;  
            5'b00001: data = 4'b0010;  
            5'b00010: data = 4'b1110;  
            5'b00011: data = 4'b0010;  
            5'b00100: data = 4'b0100;  
            5'b00101: data = 4'b1010;  
            5'b00110: data = 4'b1100;  
            5'b00111: data = 4'b0000;  
            5'b01000: data = 4'b1010;  
            5'b01001: data = 4'b0010;  
            5'b01010: data = 4'b1110;  
            5'b01011: data = 4'b0010;  
            5'b01100: data = 4'b0100;  
            5'b01101: data = 4'b1010;  
            5'b01110: data = 4'b1100;  
            5'b01111: data = 4'b0000;  
            5'b10000: data = 4'b0010;  
            5'b10001: data = 4'b0010;  
            5'b10010: data = 4'b1110;  
            5'b10011: data = 4'b0010;  
            5'b10100: data = 4'b0100;  
            5'b10101: data = 4'b1010;  
            5'b10110: data = 4'b1100;  
            5'b10111: data = 4'b0000;  
            5'b11000: data = 4'b1010;  
            5'b11001: data = 4'b0010;  
            5'b11010: data = 4'b1110;  
            5'b11011: data = 4'b0010;  
            5'b11100: data = 4'b0100;  
            5'b11101: data = 4'b1010;  
            5'b11110: data = 4'b1100;  
            5'b11111: data = 4'b0000;  
        endcase  
    end  
  
endmodule
```

Pipelined Distributed RAM

To increase the speed of designs, XST can infer pipelined distributed RAM. By interspersing registers between the stages of distributed RAM, pipelining can significantly increase the overall frequency of your design. The effect of pipelining is similar to flip-flop retiming which is described in “[Flip-Flop Retiming](#)” in Chapter 3.

To insert pipeline stages, describe the necessary registers in your HDL code and place them after any distributed RAM, then set the RAM_STYLE constraint to *pipe_distributed*.

When it detects valid registers for pipelining and RAM_STYLE is set to *pipe_distributed*, XST uses the maximum number of available registers to reach the maximum distributed RAM speed. XST automatically calculates the maximum number of registers for each RAM to get the best frequency.

If you have not specified sufficient register stages and RAM_STYLE is coded directly on a signal, XST guides you via the HDL Advisor to specify the optimum number of register stages. XST does this during the Advanced HDL Synthesis step. If the number of registers placed after the multiplier exceeds the maximum required, and shift register extraction is activated, then XST implements the unused stages as shift registers.

Limitations

XST cannot pipeline RAM if registers contain asynchronous set/reset or synchronous reset signals. XST can pipeline RAM if registers contain synchronous reset signals.

Log File

```
=====
*          HDL Synthesis          *
=====

Synthesizing Unit <rams_22>.
Related source file is "rams_22.vhd".
Found 64x4-bit single-port distributed RAM for signal <RAM>.

-----
| aspect ratio      | 64-word x 4-bit           |               |
| clock             | connected to signal <clk> | rise          |
| write enable      | connected to signal <we>  | high          |
| address           | connected to signal <addr>|               |
| data in            | connected to signal <di>  |               |
| data out           | connected to internal node|               |
| ram_style          | distributed                |               |
-----
```

Found 4-bit register for signal <do>.

Summary:

```
    inferred     1 RAM(s).
    inferred     4 D-type flip-flop(s).
```

Unit <rams_22> synthesized.

```
=====
HDL Synthesis Report
```

Macro Statistics

```
# LUT RAMs           : 1
64x4-bit single-port distributed RAM: 1
# Registers         : 1
4-bit register       : 1
```

```
=====
*          Advanced HDL Synthesis          *
=====
```

Synthesizing (advanced) Unit <rams_22>.

Found pipelined ram on signal <_n0001>:

```
    - 1 pipeline level(s) found in a register on signal <_n0001>.
    Pushing register(s) into the ram macro.
```

INFO:Xst - HDL ADVISOR - You can improve the performance of the ram Mram_RAM by adding 1 register level(s) on output signal _n0001.

Unit <rams_22> synthesized (advanced).

```
=====
HDL Synthesis Report
```

Macro Statistics

```
# LUT RAMs           : 1
64x4-bit registered single-port distributed RAM: 1
```

VHDL Code

Use the following template to implement pipelined distributed RAM in VHDL.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- Pipeline distributed RAMs  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.std_logic_unsigned.all;  

```

Verilog Code

Use the following template to implement pipelined distributed RAM in Verilog.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.


```
//  
// Pipeline distributed RAMs  
  
module v_rams_22 (clk, we, addr, di, do);  
  
    input  clk;  
    input  we;  
    input  [5:0] addr;  
    input  [3:0] di;  
    output [3:0] do;  
    reg      [3:0] RAM [63:0];  
    reg      [3:0] do;  
  
    // synthesis attribute ram_style of RAM is "pipe_distributed"  
  
    always @(posedge clk)  
    begin  
        if (we)  
            RAM[addr] <= di;  
        else  
            do <= RAM[addr];  
    end  
  
endmodule
```

State Machine

XST proposes a large set of templates to describe Finite State Machines (FSMs). By default, XST tries to distinguish FSMs from VHDL/Verilog code, and apply several state encoding techniques (it can re-encode the user's initial encoding) to get better performance or less area. However, you can disable FSM extraction by using the `FSM_EXTRACT` design constraint.

Note: XST can handle only synchronous state machines.

There are many ways to describe FSMs. A traditional FSM representation incorporates Mealy and Moore machines, as in the following figure. Please note that XST supports both of these models:




For HDL, process (VHDL) and always blocks (Verilog) are the most suitable ways for describing FSMs. (For description convenience Xilinx® uses "process" to refer to both: VHDL processes and Verilog always blocks.)

You may have several processes (1, 2 or 3) in your description, depending upon how you consider and decompose the different parts of the preceding model. Following is an example of the Moore Machine with Asynchronous Reset, "RESET".

- 4 states: s1, s2, s3, s4
- 5 transitions
- 1 input: "x1"
- 1 output: "outp"

This model is represented by the following bubble diagram:



FSM with 1 Process

Please note, in this example output signal "outp" is a *register*.

VHDL Code

Following is the VHDL code for an FSM with a single process.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- State Machine with a single process.  
--  
  
library IEEE;  
use IEEE.std_logic_1164.all;  
entity fsm_1 is  

```

Verilog Code

Following is the Verilog code for an FSM with a single always block.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// State Machine with a single always block.
//

module v_fsm_1 (clk, reset, x1, outp);
    input  clk, reset, x1;
    output outp;
    reg    outp;
    reg    [1:0] state;

parameter s1 = 2'b00; parameter s2 = 2'b01;
parameter s3 = 2'b10; parameter s4 = 2'b11;

initial begin
    state = 2'b00;
end


always@(posedge clk or posedge reset)
begin
    if (reset)
        begin
            state <= s1; outp <= 1'b1;
        end
    else
        begin
            case (state)
                s1: begin
                    if (x1==1'b1)
                        begin
                            state <= s2;
                            outp <= 1'b1;
                        end
                    else
                        begin
                            state <= s3;
                            outp <= 1'b0;
                        end
                end
                s2: begin
                    state <= s4; outp <= 1'b1;
                end
                s3: begin
                    state <= s4; outp <= 1'b0;
                end
                s4: begin
                    state <= s1; outp <= 1'b0;
                end
            endcase
        end
end
endmodule

```

FSM with 2 Processes

To eliminate a register from the "outputs", you can remove all assignments "outp <=..." from the Clock synchronization section.

This can be done by introducing two processes as shown in the following figure.



X8986

VHDL Code

Following is VHDL code for an FSM with two processes.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- State Machine with two processes.  
--  
  
library IEEE;  
use IEEE.std_logic_1164.all;  
entity fsm_2 is  
    port ( clk, reset, x1 : IN std_logic;  
          outp           : OUT std_logic);  
end entity;  
  
architecture beh1 of fsm_2 is  
    type state_type is (s1,s2,s3,s4);  
    signal state: state_type ;  
begin  
  
    process1: process (clk,reset)  
    begin  
        if (reset ='1') then state <=s1;  
        elsif (clk='1' and clk'Event) then  
            case state is  
                when s1 =>  if x1='1' then  
                                state <= s2;  
                            else  
                                state <= s3;  
                            end if;  
                when s2 => state <= s4;  
                when s3 => state <= s4;  
                when s4 => state <= s1;  
            end case;  
        end if;  
    end process process1;  
  
    process2 : process (state)  
    begin  
        case state is  
            when s1 => outp <= '1';  
            when s2 => outp <= '1';  
            when s3 => outp <= '0';  
            when s4 => outp <= '0';  
        end case;  
    end process process2;  
  
end beh1;
```

Verilog Code

Following is the Verilog code for an FSM with two always blocks.


These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// State Machine with two always blocks.  
  
module v_fsm_2 (clk, reset, x1, outp);  
    input  clk, reset, x1;  
    output outp;  
    reg    outp;  
    reg    [1:0] state;  
  
parameter s1 = 2'b00; parameter s2 = 2'b01;  
parameter s3 = 2'b10; parameter s4 = 2'b11;  
  
initial begin  
    state = 2'b00;  
end  
  
always @(posedge clk or posedge reset)  
begin  
    if (reset)  
        state <= s1;  
    else  
        begin  
            case (state)  
                s1: if (x1==1'b1)  
                    state <= s2;  
                else  
                    state <= s3;  
                s2: state <= s4;  
                s3: state <= s4;  
                s4: state <= s1;  
            endcase  
        end  
end  
  
always @ (state)  
begin  
    case (state)  
        s1: outp = 1'b1;  
        s2: outp = 1'b1;  
        s3: outp = 1'b0;  
        s4: outp = 1'b0;  
    endcase  
end  
  
endmodule
```

FSM with 3 Processes

You can also separate the NEXT State function from the state register:



Separating the NEXT State function from the state register provides the following description:

VHDL Code

Following is the VHDL code for an FSM with three processes.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
--  
-- State Machine with three processes.  
  
library IEEE;  
use IEEE.std_logic_1164.all;  
entity fsm_3 is  
    port ( clk, reset, x1 : IN std_logic;  
          outp           : OUT std_logic);  
end entity;  
  
architecture beh1 of fsm_3 is  
    type state_type is (s1,s2,s3,s4);  
    signal state, next_state: state_type ;  
begin  
  
    process1: process (clk,reset)  
    begin  
        if (reset ='1') then  
            state <=s1;  
        elsif (clk='1' and clk'Event) then  
            state <= next_state;  
        end if;  
    end process process1;  
  
    process2 : process (state, x1)  
    begin  
        case state is  
            when s1 =>  if x1='1' then  
                            next_state <= s2;  
                        else  
                            next_state <= s3;  
                        end if;  
            when s2 => next_state <= s4;  
            when s3 => next_state <= s4;  
            when s4 => next_state <= s1;  
        end case;  
    end process process2;  
  
    process3 : process (state)  
    begin  
        case state is  
            when s1 => outp <= '1';  
            when s2 => outp <= '1';  
            when s3 => outp <= '0';  
            when s4 => outp <= '0';  
        end case;  
    end process process3;  
  
end beh1;
```

Verilog Code

Following is the Verilog code for an FSM with three always blocks.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

// 
// State Machine with three always blocks.
// 

module v_fsm_3 (clk, reset, x1, outp);
    input clk, reset, x1;
    output outp;
    reg outp;
    reg [1:0] state;
    reg [1:0] next_state;

    parameter s1 = 2'b00; parameter s2 = 2'b01;
    parameter s3 = 2'b10; parameter s4 = 2'b11;

    initial begin
        state = 2'b00;
    end

    always @(posedge clk or posedge reset)
    begin
        if (reset) state <= s1;
        else state <= next_state;
    end

    always @(state or x1)
    begin
        case (state)
            s1: if (x1==1'b1)
                  next_state = s2;
            else
                  next_state = s3;
            s2: next_state = s4;
            s3: next_state = s4;
            s4: next_state = s1;
        endcase
    end

    always @ (state)
    begin
        case (state)
            s1: outp = 1'b1;
            s2: outp = 1'b1;
            s3: outp = 1'b0;
            s4: outp = 1'b0;
        endcase
    end

endmodule

```

State Registers

State registers must be initialized with an asynchronous or synchronous signal. XST does not support FSM without initialization signals. Please refer to “[Registers](#)” in this chapter for templates on how to write Asynchronous and Synchronous initialization signals.

In VHDL, the type of a state register can be a different type: integer, bit_vector, std_logic_vector, for example. But it is common and convenient to define an enumerated type containing all possible state values and to declare your state register with that type.

In Verilog, the type of state register can be an integer or a set of defined parameters. In the following Verilog examples the state assignments could have been made like this:

```
parameter [3:0]
    s1 = 4'b0001,
    s2 = 4'b0010,
    s3 = 4'b0100,
    s4 = 4'b1000;
reg [3:0] state;
```

These parameters can be modified to represent different state encoding schemes.

Next State Equations

Next state equations can be described directly in the sequential process or in a distinct combinational process. The simplest template is based on a Case statement. If using a separate combinational process, its sensitivity list should contain the state signal and all FSM inputs.

Unreachable States

XST can detect unreachable states in an FSM. It lists them in the log file in the HDL Synthesis step.

FSM Outputs

Non-registered outputs are described either in the combinational process or in concurrent assignments. Registered outputs must be assigned within the sequential process.

FSM Inputs

Registered inputs are described using internal signals, which are assigned in the sequential process.

State Encoding Techniques

XST supports the following state encoding techniques.

- Auto
- One-Hot
- Gray
- Compact
- Johnson
- Sequential

- User
- Speed1

Auto

In this mode, XST tries to select the best suited encoding algorithm for each FSM.

One-Hot

One-hot encoding is the default encoding scheme. Its principle is to associate one code bit and also one flip-flop to each state. At a given clock cycle during operation, one and only one bit of the state variable is asserted. Only two bits toggle during a transition between two states. One-hot encoding is very appropriate with most FPGA targets where a large number of flip-flops are available. It is also a good alternative when trying to optimize speed or to reduce power dissipation.

Gray

Gray encoding guarantees that only one bit switches between two consecutive states. It is appropriate for controllers exhibiting long paths without branching. In addition, this coding technique minimizes hazards and glitches. Very good results can be obtained when implementing the state register with T flip-flops.

Compact

Compact encoding consists of minimizing the number of bits in the state variables and flip-flops. This technique is based on hypercube immersion. Compact encoding is appropriate when trying to optimize area.

Johnson

Like Gray, Johnson encoding shows benefits with state machines containing long paths with no branching.

Sequential

Sequential encoding consists of identifying long paths and applying successive radix two codes to the states on these paths. Next state equations are minimized.

Speed1

Speed1 encoding is oriented for speed optimization. The number of bits for a state register depends on the particular FSM, but generally it is greater than the number of FSM states.

User

In this mode, XST uses original encoding, specified in the HDL file. For example, if you use enumerated types for a state register, then in addition you can use the ENUM_ENCODING constraint to assign a specific binary value to each state. Please refer to [Chapter 5, “Design Constraints”](#) for more details.

Log File

The XST log file reports the full information of recognized FSM during the Macro Recognition step. Moreover, if you allow XST to choose the best encoding algorithm for your FSMs, it reports the one it chose for each FSM.

As soon as encoding is selected, XST reports the original and final FSM encoding. Please note that if the target family is an FPGA, XST reports this encoding at the HDL Synthesis step. If the target family is a CPLD, then XST reports this encoding at the Low Level Optimization step.

```
...
Synthesizing Unit < fsm_1>.
Related source file is "/state_machines_1.vhd".
Found finite state machine <FSM_0> for signal <state>.
-----
| States          | 4
| Transitions    | 5
| Inputs          | 1
| Outputs         | 4
| Clock           | clk (rising_edge)
| Reset            | reset (positive)
| Reset type      | asynchronous
| Reset State     | s1
| Power Up State | s1
| Encoding         | automatic
| Implementation   | LUT
-----
Found 1-bit register for signal <outp>.
Summary:
    inferred    1 Finite State Machine(s).
    inferred    1 D-type flip-flop(s).
Unit < fsm_1 > synthesized.

=====
HDL Synthesis Report

Macro Statistics
# Registers          : 1
1-bit register       : 1
=====
```

```
=====
*          Advanced HDL Synthesis      *
=====

Advanced Registered AddSub inference ...
Analyzing FSM <FSM_0> for best encoding.
Optimizing FSM <state/FSM_0> on signal <state[1:2]> with gray
encoding.

-----
State | Encoding
-----
s1   | 00
s2   | 01
s3   | 11
s4   | 10
-----
=====

HDL Synthesis Report

Macro Statistics
# FSMs : 1
=====
```

RAM-based FSM Synthesis

Large FSMs can be made more compact and faster by implementing them in the block RAM resources provided in Virtex and later technologies. You can direct XST to use block RAM resources for FSMs by using the `FSM_STYLE` constraint. Values for `FSM_STYLE` are *lut* and *bram*. The *lut* option is the default and it causes XST to map the FSM using LUTs. The *bram* option directs XST to map the FSM onto block RAM.

In Project Navigator, invoke this constraint by choosing either **LUT** or **Bram** from the drop down list to the right of **FSM Style** under the **HDL Options** tab of the **Process Properties** dialog box. From the command line, use the `-fsm_style` command line switch. You can also use the `FSM_STYLE` constraint in your HDL code. See the *Constraints Guide* for more information.

If it cannot implement a state machine on block RAM, XST:

- generates a warning message with the reason for the warning in the Advanced HDL Synthesis step of the log file.
- automatically implements the state machine using LUTs.

For example, if FSM has a asynchronous reset, it cannot be implemented using block RAM. In this case XST informs the user:

```
...
=====
*           Advanced HDL Synthesis
=====

WARNING:Xst - Unable to fit FSM <FSM_0> in BRAM (reset is
asynchronous).
Selecting encoding for FSM_0 ...
Optimizing FSM <FSM_0> on signal <current_state> with one-hot
encoding.
...
```

Safe FSM Implementation

XST can add logic to your FSM implementation that will let your state machine recover from an invalid state. If during its execution, a state machine gets into an invalid state, the logic added by XST will bring it back to a known state, called a recovery state. This is known as Safe Implementation mode. To activate Safe FSM implementation, select the Safe Implementation option from the Synthesis Properties dialog box in Project Navigator or apply the `SAFE_IMPLEMENTATION` constraint to the hierarchical block or signal that represents the state register. See “[Safe Implementation](#)” in Chapter 5 for details about the `SAFE_IMPLEMENTATION` constraint.

By default, XST automatically selects a reset state as the recovery state. If the FSM does not have an initialization signal, XST selects a power-up state as the recovery state. You can manually define the recovery state by applying the `RECOVERY_STATE` constraint. See “[Recovery State](#)” in Chapter 5 for details about the `RECOVERY_STATE` constraint.

Black Box Support

Your design may contain EDIF or NGC files generated by synthesis tools, schematic editors or any other design entry mechanism. These modules must be instantiated in your code to be connected to the rest of your design. You can do this in XST by using black box instantiation in the VHDL/Verilog code. The netlist is propagated to the final top-level netlist without being processed by XST. Moreover, XST enables you to attach specific constraints to these black box instantiations, which are passed to the NGC file.

In addition, you may have a design block for which you have an RTL model, as well as your own implementation of this block in the form of an EDIF netlist. The RTL model is only valid for simulation purposes, but by using the `BOX_TYPE` constraint you can direct XST to skip synthesis of this RTL code and create a black box. The EDIF netlist is linked to the synthesized design during NGDBuild. Please see “[General Constraints](#)” in Chapter 5 for more information. Also see the *Constraints Guide* for details.

Note: Remember that once you make a design a black box, each instance of that design is a black box. While you can attach constraints to the instance, XST ignores any constraint attached to the original design.

Log File

From the flow point of view, the recognition of black boxes in XST is done before the macro inference process. Therefore the LOG file differs from the one generated for other macros.

```

...
Analyzing Entity <black_b> (Architecture <archi>).

WARNING:Xst:766 - black_box_1.vhd (Line 15). Generating a Black Box
for component <my_block>.
Entity <black_b> analyzed. Unit <black_b> generated
....
```

Related Constraints

XST has a BOX_TYPE constraint that can be applied to black boxes. However, it was introduced essentially for Virtex Primitive instantiation in XST. Please read “[Virtex Primitive Support](#)” in Chapter 3 in before using this constraint.

VHDL Code

Following is the VHDL code for a black box.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```

--
-- Black Box
--

library ieee;
use ieee.std_logic_1164.all;

entity black_box_1 is
    port(DI_1, DI_2 : in std_logic;
         DOUT : out std_logic);
end black_box_1;

architecture archi of black_box_1 is

    component my_block
        port (I1 : in std_logic;
              I2 : in std_logic;
              O : out std_logic);
    end component;

begin

    inst: my_block port map (I1=>DI_1,I2=>DI_2,O=>DOUT);

end archi;
```

Verilog Code

Following is the Verilog code for a black box.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

```
//  
// Black Box  
  
module v_my_block (in1, in2, dout);  
    input in1, in2;  
    output dout;  
endmodule  
  
module v_black_box_1 (DI_1, DI_2, DOUT);  
    input DI_1, DI_2;  
    output DOUT;  
  
    v_my_block inst (  
        .in1(DI_1),  
        .in2(DI_2),  
        .dout(DOUT));  
  
endmodule
```

Note: Please refer to the VHDL/Verilog language reference manuals for more information on component instantiation.

FPGA Optimization

This chapter contains the following sections:

- “Introduction”
- “Virtex Specific Synthesis Options”
- “Macro Generation”
- “Using DSP48 Block Resources”
- “Mapping Logic onto Block RAM”
- “Flip-Flop Retiming”
- “Incremental Synthesis Flow”
- “Speed Optimization Under Area Constraint”
- “Log File Analysis”
- “Implementation Constraints”
- “Virtex Primitive Support”
- “Cores Processing”
- “Specifying INITs and RLOCs in HDL Code”
- “PCI Flow”

Introduction

XST performs the following steps during FPGA synthesis and optimization:

- Mapping and optimization on an entity/module by entity/module basis.
- Global optimization on the complete design.

The output of this process is an NGC file.

This chapter describes the following:

- Constraints that can be applied to tune the synthesis and optimization process.
- Macro generation.
- Information in the log file.
- Timing model used during the synthesis and optimization process.
- Constraints available for timing-driven synthesis.
- Information on the generated NGC file.
- Information on support for primitives.

Virtex Specific Synthesis Options

XST supports a set of options that allows the tuning of the synthesis process according to the user constraints. This section lists the options that relate to the FPGA-specific optimization of the synthesis process. For details about each option, see “[FPGA Constraints \(non-timing\)](#)” in Chapter 5.

Following is a list of FPGA options.

- BUFGCE
- Buffer Type
- Decoder Extraction
- FSM Style
- Global Optimization Goal
- Incremental Synthesis
- Keep Hierarchy
- Logical Shifter Extraction
- Map Logic on BRAM
- Max Fanout
- Move First Stage
- Move Last Stage
- Multiplier Style
- Mux Style
- Number of Global Clock Buffers
- Optimize Instantiated Primitives
- Pack I/O Registers into IOBs
- Priority Encoder Extraction
- RAM Style
- Register Balancing
- Register Duplication
- Resynthesize
- Shift Register Extraction
- Signal Encoding
- Slice Packing
- Use Carry Chain
- Write Timing Constraints
- XOR Collapsing

Macro Generation

The Virtex Macro Generator module provides the XST HDL Flow with a catalog of functions. These functions are identified by the inference engine from the HDL description; their characteristics are handed to the Macro Generator for optimal implementation. The set of inferred functions ranges in complexity from simple arithmetic operators such as adders, accumulators, counters and multiplexers to more complex building blocks such as multipliers, shift registers and memories.

Inferred functions are optimized to deliver the highest levels of performance and efficiency for Virtex architectures and then integrated into the rest of the design. In addition, the generated functions are optimized through their borders depending on the design context.

This section categorizes, by function, all available macros and briefly describes technology resources used in the building and optimization phase.

Macro Generation can be controlled through attributes. These attributes are listed in each subsection. For general information on attributes see [Chapter 5, “Design Constraints”](#).

XST uses dedicated carry chain logic to implement many macros. In some situations carry chain logic may lead to sub-optimal optimization results. Use the `USE_CARRY_CHAIN` constraint to direct XST to deactivate this feature. Please refer to [Chapter 5, “Design Constraints”](#) for more information.

Arithmetic Functions

For Arithmetic functions, XST provides the following elements:

- Adders, Subtracters and Adder/Subtracters
- Cascadable Binary Counters
- Accumulators
- Incrementers, Decrementers and Incrementer/Decrementers
- Signed and Unsigned Multipliers

XST uses fast carry logic (MUXCY) to provide fast arithmetic carry capability for high-speed arithmetic functions. The sum logic formed from two XOR gates is implemented using LUTs and the dedicated carry-XORs (XORCY). In addition, XST benefits from a dedicated carry-ANDs (MULTAND) resource for high-speed multiplier implementation.

Loadable Functions

For Loadable functions XST provides the following elements.

- Loadable Up, Down and Up/Down Binary Counters
- Loadable Up, Down and Up/Down Accumulators

XST can provide synchronously loadable, cascadable binary counters and accumulators inferred in the HDL flow. Fast carry logic is used to cascade the different stages of the macros. Synchronous loading and count functions are packed in the same LUT primitive for optimal implementation.

For Up/Down counters and accumulators, XST uses the dedicated carry-ANDs to improve the performance.

Multiplexers

For multiplexers, the Macro Generator provides the following two architectures.

- MUXFx based multiplexers
- Dedicated Carry-MUXs based multiplexers

For Virtex-E, MUXFx based multiplexers are generated by using the optimal tree structure of MUXF5, MUXF6 primitives, which allows compact implementation of large inferred multiplexers. For example, XST can implement an 8:1 multiplexer in a single CLB. In some cases dedicated carry-MUXs are generated; these can provide more efficient implementations, especially for very large multiplexers.

For Virtex-II, Virtex-II Pro, Virtex-II Pro X and Virtex-4 devices, XST can implement a 16:1 multiplexer in a single CLB using a MUXF7 primitive, and it can implement a 32:1 multiplexer across two CLBs using a MUXF8.

To have better control of the implementation of the inferred multiplexer, XST offers a way to select the generation of either the MUXF5/MUXF6 or Dedicated Carry-MUXs architectures. The attribute `MUX_STYLE` specifies that an inferred multiplexer be implemented on a MUXFx based architecture if the value is `MUXF`, or a Dedicated Carry-MUXs based architecture if the value is `MUXCY`.

You can apply this attribute to either a signal that defines the multiplexer or the instance name of the multiplexer. This attribute can also be global.

The attribute `MUX_EXTRACT` with, respectively, the value `no` or `force` can be used to disable or force the inference of the multiplexer.

Priority Encoder

The if/elsif structure described in the “[Priority Encoders](#)” in Chapter 2 is implemented with a 1-of-n priority encoder.

XST uses the MUXCY primitive to chain the conditions of the priority encoder, which results in its high-speed implementation.

You can enable/disable priority encoder inference using the `PRIORITY_EXTRACT` constraint.

Generally, XST does not infer and so does not generate a large number of priority encoders. Therefore, Xilinx recommends that you use the `PRIORITY_EXTRACT` constraint with the `force` option if you would like to use priority encoders.

Decoder

A decoder is a demultiplexer whose inputs are all constant with distinct one-hot (or one-cold) coded values. An n-bit or 1-of-m decoder is mainly characterized by an m-bit data output and an n-bit selection input, such that $n^{**}(2-1) < m \leq n^{**}2$.

Once XST has inferred the decoder, the implementation uses the MUXF5 or MUXCY primitive depending on the size of the decoder.

You can enable/disable decoder inference using the `DECODER_EXTRACT` property.

Shift Register

Two types of shift register are built by XST:

- Serial shift register with single output.
- Parallel shift register with multiple outputs.

The length of the shift register can vary from 1 bit to 16 bits as determined from the following formula:

$$\text{Width} = (8 \cdot A_3) + (4 \cdot A_2) + (2 \cdot A_1) + A_0 + 1$$

If A_3, A_2, A_1 and A_0 are all zeros (0000), the shift register is one-bit long. If they are all ones (1111), it is 16-bits long.

For serial shift register SRL16, flip-flops are chained to the appropriate width.

For a parallel shift register, each output provides a width of a given shift register. For each width a serial shift register is built, it drives one output, and the input of the next shift register.

You can enable/disable shift register inference using the SHREG_EXTRACT constraint.

RAMs

Two types of RAM are available in the inference and generation stages: distributed and block RAMs.

- If the RAM is asynchronous READ, Distributed RAM is inferred and generated.
- If the RAM is synchronous READ, block RAM is inferred. In this case, XST can implement block RAM or distributed RAM. The default is block RAM.

For Virtex, Virtex-E, Virtex-II, Virtex-II Pro, Virtex-II Pro X, Virtex-4, Spartan™-II, Spartan-IIIE and Spartan-3 devices, XST uses the following primitives.

- RAM16X1S and RAM32X1S for Single-Port Synchronous Distributed RAM
- RAM16X1D primitives for Dual-Port Synchronous Distributed RAM

For Virtex-II, Virtex-II Pro, Virtex-II Pro X, Virtex-4 and Spartan-3 devices, XST uses the following primitives.

- For Single-Port Synchronous Distributed RAM:
 - ◆ For Distributed Single-Port RAM with *positive* clock edge:
RAM16X1S, RAM16X2S, RAM16X4S, RAM16X8S,
RAM32X1S, RAM32X2S, RAM32X4S, RAM32X8S,
RAM64X1S, RAM64X2S, RAM128X1S,
 - ◆ For Distributed Single-Port RAM with *negative* clock edge:
RAM16X1S_1, RAM16X2S_1, RAM16X4S_1, RAM16X8S_1,
RAM32X1S_1, RAM32X2S_1, RAM32X4S_1, RAM32X8S_1,
RAM64X1S_1, RAM64X2S_1, RAM128X1S_1,
- For Dual-Port Synchronous Distributed RAM:
 - ◆ For Distributed Dual-Port RAM with *positive* clock edge:
RAM16X1D, RAM32X1D, RAM64X1D
 - ◆ For Distributed Dual-Port RAM with *negative* clock edge:
RAM16X1D_1, RAM32X1D_1, RAM64X1D_1

For block RAM XST uses:

- RAMB4_Sn primitives for Single-Port Synchronous Block RAM
- RAMB4_Sm_Sn primitives for Dual-Port Synchronous Block RAM

In order to have better control of the implementation of the inferred RAM, XST offers a way to control RAM inference, and to select the generation of distributed RAM or block RAMs (if possible).

The RAM_STYLE attribute specifies that an inferred RAM be generated using:

- Block RAM if the value is *block*.
- Distributed RAM if the value is *distributed*.

You can apply the RAM_STYLE attribute either to a signal that defines the RAM or the instance name of the RAM. This attribute can also be global.

If the RAM resources are limited, XST can generate additional RAMs using registers. To do this use the RAM_EXTRACT attribute with the value set to *no*.

ROMs

A ROM can be inferred when all assigned contexts in a Case or If...else statement are constants. Macro inference only considers ROMs of at least 16 words with no width restriction. For example, the following HDL equation can be implemented with a ROM of 16 words of 4 bits.

```
data = if address = 0000 then 0010
      if address = 0001 then 1100
      if address = 0010 then 1011
      ...
      if address = 1111 then 0001
```

A ROM can also be inferred from an array composed entirely of constants, as in the following HDL example.

```
type ROM_TYPE is array(15 downto 0)of std_logic_vector(3 downto 0);
constant ROM : rom_type := ("0010", "1100", "1011", ..., "0001");
...
data <= ROM(conv_integer(address));
```

The ROM_EXTRACT attribute can be used to disable the inference of ROMs. Use the value *yes* to enable ROM inference, and *no* to disable ROM inference. The default is *yes*.

Two types of ROM are available in the inference and generation stages: Distributed ROM and Block ROM.

- Distributed ROMs are generated by using the optimal tree structure of LUT, MUXF5, MUXF6, MUXF7 and MUXF8 primitives which allows compact implementation of large inferred ROMs.
- Block ROMs are generated by using block RAM resources. When a synchronous ROM is identified, it can be inferred either as a distributed ROM plus a register, or it can be inferred using block RAM resources.

The ROM_STYLE attribute specifies what kind of synchronous ROM XST infers as follows.

- If set to *block*, and the ROM fits entirely on a single block of RAM, XST infers the ROM using block RAM resources.
- If set to *distributed*, XST infers a distributed ROM plus register.

- If set to *auto*, XST determines the most efficient method to use and infers the ROM accordingly. *Auto* is the default.

You can apply ROM_STYLE as a VHDL attribute or a Verilog meta comment to an individual signal, or to the entity/module of the ROM. This attribute can also be applied globally from the Process Properties dialog box in Project Navigator, or from the command line.

Using DSP48 Block Resources

XST can automatically implement several macros on a DSP48 block. Supported macros are the following:

- adders/subtractors
- accumulators
- multipliers
- multiply adder/subtractors
- multiply accumulate (MAC)

XST supports the registered versions of these macros as well.

Macro implementation on DSP48 blocks is controlled by the USE_DSP48 constraint/command line option with a default value of *auto*.

In *auto* mode, XST attempts to implement accumulators, multipliers, multiply adder/subtractors and MACs on DSP48 resources. XST does not implement adders/subtractors on DSP48 resources in *auto* mode. To push adder/subtractors into a DSP48, set the USE_DSP48 constraint/command line option value to *yes*.

XST performs automatic resource control in *auto* mode for all macros except adders/subtractors. In this mode you can control the number of available DSP48 resources for the synthesis using the DSP_UTILIZATION_RATIO constraint. By default, XST tries to utilize, as much as possible, all available DSP48 resources.

To deliver the best performance, XST by default tries to infer and implement the maximum macro configuration, including as many registers in the DSP48 as possible. If you want to shape a macro in a specific way, you must use the KEEP constraint. For example, if your design has a multiplier with 2 register levels on each input, and you would like to exclude the first register stage from the DSP48, you must place KEEP constraints on the outputs of these registers.

Please refer to [Chapter 2, “HDL Coding Techniques”](#) for detailed information on individual macro processing.

If your design contains several interconnected macros, where each macro can be implemented on DSP48, XST attempts to interconnect DSP48 blocks using fast BCIN/BCOUT and PCIN/PCOUT connections. Such situations are typical in filter and complex multiplier descriptions.

Starting in 8.1i release, XST can build complex DSP macros and DSP48 chains across the hierarchy when the [Keep Hierarchy](#) option is set to *no*. This is the default in ISE.

Mapping Logic onto Block RAM

If there are unused block RAM resources and your design does not fit into your target device, you can place some of your design logic into block RAM. To do this, you must decide what part of the HDL design is to be placed in block RAM and put this part of the RTL description in a separate hierarchical block. Attach a BRAM_MAP constraint to this separate block either directly in HDL code or via the XCF file.

Please note that in the current release XST cannot automatically decide what logic could be placed in block RAM.

When placing logic into a separate block it must satisfy the following criteria.

- All outputs must be registered.
- The block may contain only one level of registers, which are output registers.
- All output registers must have the same control signals.
- The output registers must have a Synchronous Reset signal.
- The block cannot contain multisources or tristate busses.
- The KEEP attribute is not allowed on intermediate signals.

XST attempts to map the logic onto block RAM during the Advanced Synthesis step. If any of the listed requirements are not satisfied, XST does not map the logic onto block RAM, and generates a warning message with the reason for the warning. If the logic cannot be placed in a single block RAM primitive, XST spreads it over several block RAMs.

The following example places 8-bit adders with constant in a single block RAM primitive.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

VHDL Code

```
--  
-- The following example places 8-bit adders with  
-- constant in a single block RAM primitive  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
use ieee.numeric_std.all;  
  
entity logic_bram_1 is  
port (clk, rst : in std_logic;  
      A,B : in unsigned (3 downto 0);  
      RES : out unsigned (3 downto 0));  
  
attribute bram_map: string;  
attribute bram_map of logic_bram_1: entity is "yes";  
end logic_bram_1;  
  
architecture beh of logic_bram_1 is  
begin  
    process (clk)  
    begin  
        if (clk'event and clk='1') then  
            if (rst = '1') then  
                RES <= "0000";  
            else  
                RES <= A + B + "0001";  
            end if;  
        end if;  
    end process;  
end beh;
```

Verilog Code

```
//  
// The following example places 8-bit adders with  
// constant in a single block RAM primitive  
//  
  
module v_logic_bram_1 (clk, rst, A, B, RES);  
  
    input  clk, rst;  
    input  [3:0] A, B;  
    output [3:0] RES;  
    reg    [3:0] RES;  
  
    // synthesis attribute bram_map of v_logic_bram_1 is yes  
  
    always @(posedge clk)  
    begin  
        if (rst)  
            RES <= 4'b0000;  
        else  
            RES <= A + B + 8'b0001;  
    end  
endmodule
```

LOG

```

...
=====
*                      HDL Synthesis
=====
Synthesizing Unit <logic_bram_1>.
    Related source file is "bram_map_1.vhd".
    Found 4-bit register for signal <RES>.
    Found 4-bit adder for signal <$n0001> created at line 29.
    Summary:
        inferred    4 D-type flip-flop(s).
        inferred    1 Adder/Subtractor(s).
Unit <logic_bram_1> synthesized.

=====
*                      Advanced HDL Synthesis
=====
...
Entity <logic_bram_1> mapped on BRAM.
...
=====
HDL Synthesis Report

Macro Statistics
# Block RAMs           : 1
 256x4-bit single-port block RAM   : 1

...

```

In the following example, an asynchronous reset is used instead of a synchronous one and so, the logic is not mapped onto block RAM.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

VHDL Code

```

--
-- In the following example, an asynchronous reset is used and
-- so, the logic is not mapped onto block RAM
--

library ieee;
use ieee.std_logic_1164.all;
use ieee.numeric_std.all;

entity logic_bram_2 is
port (clk, rst : in std_logic;
      A,B      : in unsigned (3 downto 0);
      RES      : out unsigned (3 downto 0));

```

```

        attribute bram_map : string;
        attribute bram_map of logic_bram_2 : entity is "yes";

end logic_bram_2;

architecture beh of logic_bram_2 is
begin

    process (clk, rst)
    begin
        if (rst='1') then
            RES <= "0000";
        elsif (clk'event and clk='1') then
            RES <= A + B + "0001";
        end if;
    end process;

end beh;

```

Verilog Code

```

// 
// In the following example, an asynchronous reset is used and
// so, the logic is not mapped onto block RAM
//

module v_logic_bram_2 (clk, rst, A, B, RES);

    input  clk, rst;
    input  [3:0] A, B;
    output [3:0] RES;
    reg      [3:0] RES;

    // synthesis attribute bram_map of v_logic_bram_2 is yes

    always @ (posedge clk or posedge rst)
    begin
        if (rst)
            RES <= 4'b0000;
        else
            RES <= A + B + 8'b0001;
    end

endmodule

```

LOG

```

...
=====
*                               Advanced HDL Synthesis
=====
...
INFO:Xst:1789 - Unable to map block <no_logic_bram> on BRAM.
Output FF <RES> must have a synchronous reset.

```

Flip-Flop Retiming

Flip-flop Retiming is a technique that consists of moving flip-flops and latches across logic for the purpose of improving timing, thus increasing clock frequency. Flip-flop retiming can be either forward or backward. Forward retiming moves a set of flip-flops that are the input of a LUT to a single flip-flop at its output. Backward retiming moves a flip-flop that is at the output of a LUT to a set of flip-flops at its input. Flip-flop retiming can significantly increase the number of flip-flops in the design, and it may remove some flip-flops. Nevertheless, the behavior of the designs remains the same. Only timing delays are modified.

Flip-flop Retiming is part of global optimization, and it respects the same constraints as all the other optimization techniques. Retiming is an iterative process, therefore a flip-flop that is the result of a retiming can be moved again in the same direction (forward or backward) if it results in better timing. The only limit for the retiming is when the timing constraints are satisfied, or if no more improvements in timing can be obtained.

For each flip-flop moved, a message is printed specifying the original and new flip-flop names, and if it is a forward or backward retiming.

Note the following limitations.

- Flip-flop retiming is not applied to flip-flops that have the IOB=TRUE property.
- Flip-flops are not moved forward if the flip-flop or the output signal has the KEEP property.
- Flip-flops are not moved backward if the input signal has the KEEP property.
- Instantiated flip-flops are not moved.
- Flip-flops with both a set and a reset are not moved.

Flip-flop retiming can be controlled by applying the REGISTER_BALANCING, MOVE_FIRST_STAGE and MOVE_LAST_STAGE constraints.

Incremental Synthesis Flow

The main goal of Incremental Synthesis flow is to reduce the overall time that the designer spends in completing a project. This can be achieved by allowing you to re-synthesize only the modified portions of the design instead of the entire design. We may consider two main categories of incremental synthesis:

- Block Level: The synthesis tool re-synthesizes the entire block if at least one modification was made inside this block.
- Gate or LUT Level: The synthesis tool tries to identify the exact changes made in the design and generates the final netlist with minimal changes.

XST supports block level incremental synthesis with some limitations.

Incremental Synthesis is implemented using two constraints:
INCREMENTAL_SYNTHESIS and RESYNTHESIZE.

INCREMENTAL_SYNTHESIS:

Use the INCREMENTAL_SYNTHESIS constraint to control the decomposition of the design on several logic groups.

- If this constraint is applied to a specific block, this block with all its descendants is considered as one logic group, until the next INCREMENTAL_SYNTHESIS constraint is found. During synthesis, XST generates a single NGC file for the logic group.
- Beginning in release 7.1i, you can apply the INCREMENTAL_SYNTHESIS constraint to a block that is instantiated a multiple number of times.
- If a single block is changed then the entire logic group is resynthesized and a new NGC file(s) is generated.

Example

[Figure 3-1](#) shows how blocks are grouped by use of the INCREMENTAL_SYNTHESIS constraint. Consider the following:

- LEVA, LEVA_1, LEVA_2, my_add, my_sub as one logic group.
- LEVB, my_and, my_or and my_sub as another logic group.
- TOP is considered separately as a single logic group.




Figure 3-1: Grouping through Incremental Synthesis

RESYNTHESIZE

XST is able to automatically recognize what blocks were changed and to resynthesize only changed ones. This detection is done at the file level. This means that if an HDL file contains two blocks, both blocks are considered modified. If these two blocks belong to the same logic group then there is no impact on the overall synthesis time. If the HDL file contains two blocks that belong to different logic groups, both logic groups are considered changed and so are resynthesized. Xilinx recommends that you only keep different blocks in the a single HDL file if they belong to the same logic group.

Use the RESYNTHESIZE constraint to force resynthesis of the blocks that were not changed.

Note: In the current release, XST runs HDL synthesis on the entire design. However, during low level optimization XST re-optimizes modified blocks only.

In this example, XST generates three NGC files as shown in the following log file segment:

```
...
=====
*
*          Final Report
*
=====

Final Results
Top Level Output File Name      : c:\users\incr_synt\new.ngc
Output File Name                : c:\users\incr_synt\leva.ngc
Output File Name                : c:\users\incr_synt\levb.ngc

=====
...
```

If you made changes to block "LEVA_1", XST automatically resynthesizes the entire logic group, including LEVA, LEVA_1, LEVA_2 and my_and, my_sub as shown in the following log file segment.

```
...
=====
*
*          Low Level Synthesis
*
=====

Final Results
Incremental synthesis      Unit <my_and> is up to date ...
Incremental synthesis      Unit <my_and> is up to date ...
Incremental synthesis      Unit <my_and> is up to date ...
Incremental synthesis      Unit <my_and> is up to date ...

Optimizing unit <my_sub> ...
Optimizing unit <my_add> ...
Optimizing unit <leva_1> ...
Optimizing unit <leva_2> ...
Optimizing unit <leva> ...

=====
...
```

If you make no changes to the design, during Low Level synthesis, XST reports that all blocks are up to date and the previously generated NGC files are kept unchanged, as shown in the following log file segment.

```
...
=====
*
*           Low Level Synthesis
*
=====

Incremental synthesis: Unit <my_and> is up to date ...
Incremental synthesis: Unit <my_or> is up to date ...
Incremental synthesis: Unit <my_sub> is up to date ...
Incremental synthesis: Unit <my_add> is up to date ...
Incremental synthesis: Unit <levb> is up to date ...
Incremental synthesis: Unit <leva_1> is up to date ...
Incremental synthesis: Unit <leva_2> is up to date ...
Incremental synthesis: Unit <leva> is up to date ...
Incremental synthesis: Unit <top> is up to date ...

=====
```

If you changed one timing constraint, then XST cannot detect this modification. To force XST to resynthesize the required blocks, use the RESYNTHESIZE constraint. For example, if "LEVA" must be resynthesized, then apply the RESYNTHESIZE constraint to this block. All blocks included in the <leva> logic group are re-optimized and new NGC files are generated as shown in the following log file segment.

```
...
=====
*
*           Low Level Synthesis
*
=====

Incremental synthesis: Unit <my_and> is up to date ...
Incremental synthesis: Unit <my_or> is up to date ...
Incremental synthesis: Unit <levb> is up to date ...
Incremental synthesis: Unit <top> is up to date ...
...
Optimizing unit <my_sub> ...
Optimizing unit <my_add> ...
Optimizing unit <leva_1> ...
Optimizing unit <leva_2> ...
Optimizing unit <leva> ...

=====
```

If you have previously run XST in non-incremental mode and then switched to incremental mode, or the decomposition of the design has changed, you must delete all previously generated NGC files before continuing. Otherwise XST issues an error.

In the previous example, adding "incremental_synthesis=true" to the block LEVA_1, XST gives the following error:

```
ERROR:Xst:624 - Could not find instance <inst_leva_1> of cell <leva_1>
in <leva>
```

The problem most likely occurred because the design was previously run in non-incremental synthesis mode. To fix the problem, remove the existing NGC files from the project directory.

Please note that if you modified the HDL in the top level block of the design, and at the same time changed the name of top level block, XST cannot detect design modifications and resynthesize the top-level block. Force resynthesis by using the RESYNTHESIZE constraint.

Speed Optimization Under Area Constraint

XST performs timing optimization under area constraint. This option, "Slice Utilization Ratio," is available under the XST Synthesis Options in the Process Properties dialog box in Project Navigator. By default this constraint is set to 100% of the selected device size.

This constraint has influence at low level synthesis only (it does not control the inference process). If this constraint is specified, XST makes an area estimation, and if the specified constraint is met, XST continues timing optimization trying not to exceed the constraint. If the size of the design is more than requested, then XST tries to reduce the area first and if the area constraint is met, then starts timing optimization. In the following example the area constraint was specified as 100% and initial estimation shows that in fact it occupies 102% of the selected device. XST starts optimization and reaches 95%.

```
...
=====
*                               Low Level Synthesis
*
=====
Found area constraint ratio of 100 (+ 5) on block tge,
actual ratio is 102.
Optimizing block <tge> to meet ratio 100 (+ 5) of 1536 slices :
Area constraint is met for block <tge>, final ratio is 95.
=====
...
```

If the area constraint cannot be met, then XST ignores it during timing optimization and runs low level synthesis in order to reach the best frequency. In the following example, the

target area constraint is set to 70%. XST was not able to satisfy it and so gives the corresponding warning message.

```
...
=====
*
*           Low Level Synthesis
*
=====

Found area constraint ratio of 70 (+ 5) on block fpga_hm, actual
ratio is 64.
Optimizing block <fpga_hm> to meet ratio 70 (+ 5) of 1536 slices :
WARNING:Xst - Area constraint could not be met for block <tge>, final
ratio is 94
...
=====
...
=====
```

Note: "(+5)" stands for the max margin of the area constraint. This means that if the area constraint is not met, but the difference between the requested area and obtained area during area optimization is less or equal than 5%, then XST runs timing optimization taking into account the achieved area, not exceeding it.

In the following example the area was specified as 55%. XST achieved only 60%. But taking into account that the difference between requested and achieved area is not more than 5%, XST considers that the area constraint was met.

```
...
=====
*
*           Low Level Synthesis
*
=====

Found area constraint ratio of 55 (+ 5) on block fpga_hm, actual
ratio is 64.
Optimizing block <fpga_hm> to meet ratio 55 (+ 5) of 1536 slices :
Area constraint is met for block <fpga_hm>, final ratio is 60.
...
=====
```

The SLICE_UTILIZATION_RATIO constraint can be attached to a specific block of a design. Note that you can specify an absolute number of slices as well as a percentage of the total number. Please see "[Slice Utilization Ratio](#)" in [Chapter 5](#) for more information.

Log File Analysis

The XST log file related to FPGA optimization contains the following sections.

- Design optimization
- Resource usage report
- Timing report

Design Optimization

During design optimization, XST reports the following.

- Potential removal of equivalent flip-flops
Two flip-flops (latches) are equivalent when they have the same data and control pins.
- Register replication

Register replication is performed either for timing performance improvement or for satisfying MAX_FANOUT constraints. Register replication can be turned off using the REGISTER_DUPLICATION constraint.

Following is a portion of the log file.

```
Starting low level synthesis ...
Optimizing unit <down4cnt> ...
Optimizing unit <doc_readwrite> ...
...
Optimizing unit <doc> ...
Building and optimizing final netlist ...
The FF/Latch <doc_readwrite/state_D2> in Unit <doc> is equivalent to
the following 2 FFs/Latches, which will be removed :
<doc_readwrite/state_P2> <doc_readwrite/state_M2>
Register doc_reset_I_reset_out has been replicated 2 time(s)
Register wr_1 has been replicated 2 time(s)
```

Resource Usage

In the Final Report, the Cell Usage section reports the count of all the primitives used in the design. These primitives are classified in the following groups:

- BELS
This group contains all the logical cells that are basic elements of the Virtex technology, for example, LUTs, MUXCY, MUXF5, MUXF6, MUXF7, MUXF8.
- Flip-flops and Latches
This group contains all the flip-flops and latches that are primitives of the Virtex technology, for example, FDR, FDRE, LD.
- RAMS
This group contains all the RAMs.
- SHIFTERS
This group contains all the shift registers that use the Virtex primitives. They are SRL16, SRL16_1, SRL16E, SRL16E_1, and SRLC*.
- Tristates
This group contains all the tristate primitives, namely the BUFT.

- Clock Buffers
This group contains all the clock buffers, namely BUFG, BUFGP, BUFGDLL.
- IO Buffers
This group contains all the standard I/O buffers, except the clock buffer, namely IBUF, OBUF, IOBUF, OBUFT, IBUF_GTL ...
- LOGICAL
This group contains all the logical cells primitives that are not basic elements, namely AND2, OR2, ...
- OTHER
This group contains all the cells that have not been classified in the previous groups.

The following section is an example of an XST report for cell usage:

```
=====
...
Cell Usage :
# BELS : 70
#      LUT2 : 34
#      LUT3 : 3
#      LUT4 : 34
# FlipFlops/Latches : 9
#      FDC : 8
#      FDP : 1
# Clock Buffers : 1
#      BUFGP : 1
# IO Buffers : 24
#      IBUF : 16
#      OBUF : 8
=====
```

Device Utilization summary

Where XST estimates the number of slices, gives the number of flip-flops, IOBs, BRAMS, etc. This report is very close to the one produced by MAP.

Clock Information

A short table gives information about the number of clocks in the design, how each clock is buffered and how many loads it has.

Timing Report

At the end of the synthesis, XST reports the timing information for the design. The report shows the information for all four possible domains of a netlist: "register to register", "input to register", "register to outpad" and "inpad to outpad".

The following is an example of a timing report section in the XST log:

NOTE: THESE TIMING NUMBERS ARE ONLY A SYNTHESIS ESTIMATE.
 FOR ACCURATE TIMING INFORMATION PLEASE REFER TO THE TRACE REPORT
 GENERATED AFTER PLACE-and-ROUTE.

Clock Information:

Clock Signal	Clock buffer(FF name)	Load
clk	BUFGP	9

Timing Summary:

Speed Grade: -6

Minimum period: 7.523ns (Maximum Frequency: 132.926MHz)
 Minimum input arrival time before clock: 8.945ns
 Maximum output required time after clock: 14.220ns
 Maximum combinational path delay: 10.889ns

Timing Detail:

All values displayed in nanoseconds (ns)

=====

Timing constraint: Default period analysis for Clock 'clk'
 Clock period: 7.523ns (frequency: 132.926MHz)
 Total number of paths / destination ports: 63 / 22

Delay: 7.523ns (Levels of Logic = 2)
 Source: sdstate_FFD1
 Destination: sdstate_FFD2
 Source Clock: clk rising
 Destination Clock: clk rising

Data Path: sdstate_FFD1 to sdstate_FFD2

Cell:in->out	fanout	Gate Delay	Net Delay	Logical Name(NetName)
FDC:C->Q	15	1.372	2.970	state_FFD1 (state_FFD1)
LUT3:I1->O	1	0.738	1.26	LUT_54 (N39)
LUT3:I1->O	1	0.738	0.00	I_next_state_2 (N39)
FDC:D		0.440		state_FFD2

Total 7.523ns (3.288ns logic, 4.235ns route)
 (43.7% logic, 56.3% route)

Cell:in->out	fanout	Gate Delay	Net Delay	Logical Name (Net Name)
--------------	--------	------------	-----------	-------------------------

FDC:C->Q	15	1.372	2.970	I_state_2
begin scope: 'block1'				
LUT3:I1->O	1	0.738	1.265	LUT_54
end scope: 'block1'				
LUT3:I0->O	1	0.738	0.000	I_next_state_2
FDC:D		0.440		I_state_2

Total 7.523ns

Timing Summary

The Timing Summary section gives a summary of the timing paths for all 4 domains:

- The path from any clock to any clock in the design:
Minimum period: 7.523ns (Maximum Frequency: 132.926MHz)
- The maximum path from all primary inputs to the sequential elements:
Minimum input arrival time before clock: 8.945ns
- The maximum path from the sequential elements to all primary outputs:
Maximum output required time before clock: 14.220ns
- The maximum path from inputs to outputs:
Maximum combinational path delay: 10.899ns

If there is no path in the domain concerned, "No path found" is then printed instead of the value.

Timing Detail


The Timing Detail section describes the most critical path in detail for each region:

The start point and end point of the path, the maximum delay of this path, and the slack. The start and end points can be: **Clock** (with the phase: rising/falling) or **Port**:

Path from Clock 'sysclk' rising to Clock 'sysclk' rising : 7.523ns
(Slack: -7.523ns)

The detailed path shows the cell type, the input and output of this gate, the fanout at the output, the gate delay, the net delay estimated and the name of the instance. When entering a hierarchical block, **begin scope** is printed, and similarly **end scope** is printed when exiting a block.

The preceding report corresponds to the following schematic:



In addition, the Timing Report section shows the number of analyzed paths and ports. If XST is run with timing constraints, it displays the number of failed paths and ports as well. The number of analyzed and failed paths shows you how many timing problems there are in the design. The number of analyzed and failed ports may show you how they are spread in the design. The number of ports in a timing report represent the number of destination elements for a timing constraint.

For example, if you use the following timing constraints:

```
TIMESPEC "TSidentifier"=FROM "source_group" TO "dest_group" value units;
then the number of ports corresponds to the number of elements in the destination group.
```

For a given timing constraint, XST may report that the number of failed paths is 100. But the number of failed destination ports is only two flip-flops. This means that it is sufficient to only analyze the design description for these two flip-flops to detect what should be changed in order to meet timing.

Implementation Constraints

XST writes all implementation constraints generated from HDL or constraint file attributes (LOC, ...) into the output NGC file.

KEEP properties are generated by the buffer insertion process (for maximum fanout control or for optimization purposes).

Virtex Primitive Support

XST enables you to instantiate Virtex primitives directly in your VHDL/Verilog code. Virtex primitives such as MUXCY_L, LUT4_L, CLKDLL, RAMB4_S1_S16, IBUFG_PCI33_5, and NAND3b2 can be manually inserted in your HDL design through instantiation. These primitives are not by default optimized by XST and are available in the final NGC file. Use the Optimize Instantiated Primitives synthesis option to optimize instantiated primitives and obtain better results. Timing information is available for most of the primitives, allowing XST to perform efficient timing-driven optimization.

Some of these primitives can be generated through attributes.

- BUFFER_TYPE (CLOCK_BUFFER) can be assigned to the primary input or internal signal to force the use of BUFGDLL, IBUFG, BUFR or BUFGP. The same constraints can be used to disable buffer insertion.
- IOSTANDARD can be used to assign an I/O standard to an I/O primitive. For example:

```
// synthesis attribute IOSTANDARD of in1 is PCI33_5
assigns PCI33_5 I/O standard to the I/O port.
```

The primitive support is based on the notion of the black box. Refer to “[Safe FSM Implementation](#)” in Chapter 2 for the basics of the black box support.

There is a significant difference between black box and primitive support. Assume you have a design with a submodule called MUXF5. In general, the MUXF5 can be your own functional block or a Virtex primitive. So, to avoid confusion about how XST interprets this module, use a special constraint, called BOX_TYPE. This attribute must be attached to the component declaration of MUXF5.

- If the BOX_TYPE attribute is attached to the MUXF5 with a value of:
 - ◆ *primitive*, or *black_box*, XST tries to interpret this module as a Virtex primitive and use its parameters, for instance, in critical path estimation.
 - ◆ *user_black_box*, XST processes it as a regular user black box. If the name of the user black box is the same as that of a Virtex primitive, XST renames it to a unique

name and generates a warning message with the reason for the warning. For example, MUX5 could be renamed to MUX51 as in the following log sample:

```
...
=====
*           Low Level Synthesis
=====

WARNING:Xst:79 - Model 'muxf5' has different characteristics in
destination library
WARNING:Xst:80 - Model name has been changed to 'muxf51'
...
```

- If the BOX_TYPE attribute is not attached to the MUXF5. Then XST processes this block as a user hierarchical block. If the name of the user black box is the same as that of a Virtex primitive, XST renames it to a unique name and then generates a warning message with the reason for the warning.

To simplify the instantiation process, XST comes with VHDL and Verilog Virtex libraries. These libraries contain the complete set of Virtex primitives declarations with a BOX_TYPE constraint attached to each component. If you use:

- VHDL—You must declare library "unisim" with its package "vcomponents" in your source code.

```
library unisim;
use unisim.vcomponents.all;
```

The source code of this package can be found in the `vhdl\src\unisims_vcomp.vhd` file of the XST installation.

- Verilog—Starting in release 6.1i, the "unisim" library is already precompiled and XST automatically links it with your design.

Please note that you must use UPPERCASE for generic (VHDL) and parameter (Verilog) values when instantiating primitives.

For example the ODDR element has the following component declaration in UNISIM library:

```
component ODDR
  generic
    (DDR_CLK_EDGE : string := "OPPOSITE_EDGE";
     INIT : bit := '0';
     SRTYPE : string := "SYNC");

  port(Q : out std_ulogic;
       C : in std_ulogic;
       CE : in std_ulogic;
       D1 : in std_ulogic;
       D2 : in std_ulogic;
       R : in std_ulogic;
       S : in std_ulogic);

end component;
```

When you instantiate this primitive in your code, the values of DDR_CLK_EDGE and SRTYPE generics must be in uppercase. If not, XST generates a Warning message stating that unknown values are used.

Some primitives, like LUT1, enable you to use an INIT during instantiation. There are two ways to pass an INIT to the final netlist.

- Attach an INIT attribute to the instantiated primitive.
- Pass the INIT via the generics mechanism in VHDL, or the parameters mechanism in Verilog. Xilinx recommends this method, as it allows you to use the same code for synthesis and simulation.

VHDL Code

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

Following is the VHDL code for passing an INIT value via the INIT constraint.

```
--  
-- Passing an INIT value via the INIT constraint.  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Following is the VHDL code for passing an INIT value via the generics mechanism.

```
-- 
-- Passing an INIT value via the generics mechanism.
-- 

library ieee;
use ieee.std_logic_1164.all;

library unisim;
use unisim.vcomponents.all;

entity primitive_2 is
    port(I0,I1 : in std_logic;
         O      : out std_logic);
end primitive_2;

architecture beh of primitive_2 is
begin

    inst: LUT2 generic map (INIT=>"1")
        port map (I0=>I0,I1=>I1,O=>O);

end beh;
```

Verilog Code

These coding examples are accurate as of the date of publication. You can download any updates to these examples from ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

Following is the Verilog code for passing an INIT value via the INIT constraint.

```
// 
// Passing an INIT value via the INIT constraint.
// 

module v_primitive_1 (I0,I1,O);
    input I0,I1;
    output O;

    LUT2 inst (.I0(I0), .I1(I1), .O(O));

    // synthesis attribute INIT of inst is "1"

endmodule
```

Following is the Verilog code for passing an INIT value via the parameters mechanism.

```
// 
// Passing an INIT value via the parameters mechanism.
// 

module v_primitive_2 (I0,I1,O);
    input I0,I1;
    output O;

    LUT2 #(4'h1) inst (.I0(I0), .I1(I1), .O(O));

endmodule
```

Following is the Verilog code for passing an INIT value via the defparam mechanism.

```

// 
// Passing an INIT value via the defparam mechanism.
//

module v_primitive_3 (I0,I1,O);
    input I0,I1;
    output O;

    LUT2 inst (.I0(I0), .I1(I1), .O(O));
    defparam inst.INIT = 4'h1;

endmodule

```

Log File

XST does not issue any message concerning instantiation of Virtex primitives during HDL synthesis because the BOX_TYPE attribute with its value, *primitive*, is attached to each primitive in the UNISIM library.

Please note that if you instantiate a block (non primitive) in your design and the block has no contents (no logic description) or the block has a logic description, but you attach a BOX_TYPE constraint to it with a value of *user_black_box*, XST issues a warning message as in the following log file sample:

```

...
Analyzing Entity <black_b> (Architecture <archi>).
WARNING : (VHDL_0103). c:\jm\des.vhd (Line 23).
Generating a Black Box for component <my_block>.
Entity <black_b> analyzed. Unit <black_b> generated.
...

```

Related Constraints

Related constraints are BOX_TYPE and the various PAR constraints that can be passed from HDL to NGC without processing.

Cores Processing

If a design contains cores, represented by an EDIF or an NGC file, XST can automatically read them for timing estimation and area utilization control. The Read Cores option in the Synthesis Options in the Process Properties dialog box in Project Navigator allows you to enable or disable this feature. Using the `read_cores` option of the `run` command from the command line, you can also specify *optimize*. This enables cores processing, and allows XST to integrate the core netlist into the overall design.

By default, XST reads cores. In the following VHDL example, the block "my_add" is an adder, which is represented as a black box in the design whose netlist was generated by CORE Generator™.

```
library ieee;
use ieee.std_logic_1164.all;
use ieee.std_logic_signed.all;

entity read_cores is
port(
    A, B : in std_logic_vector (7 downto 0);
    a1, b1 : in std_logic;
    SUM : out std_logic_vector (7 downto 0);
    res : out std_logic);
end read_cores;

architecture beh of read_cores is
component my_add
port (
    A, B : in std_logic_vector (7 downto 0);
    S : out std_logic_vector (7 downto 0));
end component;

begin
    res <= a1 and b1;
    inst: my_add port map (A => A, B => B, S => SUM);
end beh;
```

If Read Cores is disabled, XST estimates Maximum Combinational Path Delay as 6.639ns (critical path goes through a simple AND function) and an area of one slice.

If Read Cores is enabled then XST displays the following messages during Low Level Synthesis.

```
...
=====
*
*           Low Level Synthesis
*
=====

Launcher: Executing edif2ngd -noa "my_add.edn" "my_add.ngo"
INFO:NgdBuild - Release 6.1i - edif2ngd G.21
INFO:NgdBuild - Copyright (c) 1995-2003 Xilinx, Inc. All rights reserved.
Writing the design to "my_add.ngo"...
Loading core <my_add> for timing and area information for instance <inst>.

=====
...
```

Estimation of Maximum Combinational Path Delay is 8.281ns with an area of five slices. Please note that by default, XST reads EDIF/NGC cores from the current (project) directory. If the cores are not in the project directory, you must use the Cores Search Directories synthesis option to specify which directory the cores are in.

Specifying INITs and RLOCs in HDL Code

Using the UNISIM library allows you to directly instantiate LUT components in your HDL code. To specify a function that a particular LUT must execute, apply an INIT constraint to the instance of the LUT. If you want to place an instantiated LUT or register in a particular slice of the chip, then attach an RLOC constraint to the same instance.

It is not always convenient to calculate INIT functions and different methods that can be used to achieve this. Instead, you can describe the function that you want to map onto a single LUT in your VHDL or Verilog code in a separate block. Attaching a LUT_MAP constraint (XST is able to automatically recognize the XC_MAP constraint supported by Synplicity) to this block indicates to XST that this block must be mapped on a single LUT. XST automatically calculates the INIT value for the LUT and preserves this LUT during optimization.

Passing an INIT Value via the LUT_MAP Constraint

The following examples show how to pass an INIT value using the LUT_MAP constraint. In these examples, the "top" block contains the instantiation of two AND gates, described in "and_one" and "and_two" blocks. XST generates two LUT2s and does not merge them. Please refer to the "["Map Entity on a Single LUT" in Chapter 5](#)" for more information.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

VHDL Code

Following is the VHDL code for passing an INIT value via the LUT_MAP constraint.

```
--  
-- Mapping on LUTs via LUT_MAP constraint  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
entity and_one is  
    port (A, B : in std_logic;  
          REZ : out std_logic);  
  
    attribute LUT_MAP: string;  
    attribute LUT_MAP of and_one: entity is "yes";  
end and_one;  
  
architecture beh of and_one is  
begin  
    REZ <= A and B;  
end beh;  
  
-----  
  
library ieee;  
use ieee.std_logic_1164.all;  
entity and_two is  
    port(A, B : in std_logic;  
          REZ : out std_logic);  
  
    attribute LUT_MAP: string;
```

```
        attribute LUT_MAP of and_two: entity is "yes";
end and_two;

architecture beh of and_two is
begin
    REZ <= A or B;
end beh;

-----
library ieee;
use ieee.std_logic_1164.all;
entity init_rlocs_1 is
    port(A,B,C : in std_logic;
         REZ : out std_logic);
end init_rlocs_1;

architecture beh of init_rlocs_1 is

component and_one
port(A, B : in std_logic;
      REZ : out std_logic);
end component;

component and_two
port(A, B : in std_logic;
      REZ : out std_logic);
end component;

signal tmp: std_logic;
begin
    inst_and_one: and_one port map (A => A, B => B, REZ => tmp);
    inst_and_two: and_two port map (A => tmp, B => C, REZ => REZ);
end beh;
```

Verilog Code

Following is the Verilog code for passing an INIT value via the LUT_MAP constraint.

```
// 
// Mapping on LUTs via LUT_MAP constraint
//

module v_and_one (A, B, REZ);
    input A, B;
    output REZ;

    // synthesis attribute LUT_MAP of v_and_one is "yes"
    and and_inst(REZ, A, B);

endmodule

// -----
module v_and_two (A, B, REZ);
    input A, B;
    output REZ;
```

```
// synthesis attribute LUT_MAP of v_and_two is "yes"
or or_inst(REZ, A, B);

endmodule

// -----
module v_inits_rlocs_1 (A, B, C, REZ);
    input A, B, C;
    output REZ;

    wire tmp;

    v_and_one inst_and_one (A, B, tmp);
    v_and_two inst_and_two (tmp, C, REZ);

endmodule
```

Specifying INIT Value for a Flip-Flop

If a function cannot be mapped on a single LUT, XST issues an Error and interrupts the synthesis process. If you would like to define an INIT value for a flip-flop or a shift register, described at RTL level, you can assign its initial value in the signal declaration stage. This value is not ignored during synthesis and is propagated to the final netlist as an INIT constraint attached to the flip-flop or shift register. In the following examples, a 4-bit register is inferred for signal "tmp". An INIT value equal "1011" is attached to the inferred register and propagated to the final netlist.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from
ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

VHDL Code

Following is the VHDL code for specifying an INIT value for a flip-flop.

```
--  
-- Specification on an INIT value for a  
-- flip-flop, described at RTL level  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  

```

Verilog Code

Following is the VHDL code for specifying an INIT value for a flip-flop.

```
//  
// Specification on an INIT value for a flip-flop,  
// described at RTL level  
  
module v_inits_rlocs_2 (clk, di, do);  
    input  clk;  
    input  [3:0] di;  
    output [3:0] do;  
    reg    [3:0] tmp;  
  
    initial begin  
        tmp = 4'b1011;  
    end  
  
    always @ (posedge clk)  
    begin  
        tmp <= di;  
    end  
  
    assign do = tmp;  
  
endmodule
```

Specifying INIT and RLOC Value for a Flip-Flop

To infer a register as in the previous example, and place it in a specific location of a chip, attach an RLOC constraint to the "tmp" signal as in the following examples. XST propagates it to the final netlist. Please note that this feature is supported for registers, and also for inferred block RAM if it can be implemented on a single block RAM primitive.

These coding examples are accurate as of the date of publication. You can download any updates to these examples from

ftp://ftp.xilinx.com/pub/documentation/misc/examples_v7.zip.

VHDL Code

Following is the VHDL code for specifying an INIT and RLOC value for a flip-flop.

```
--  
-- Specification on an INIT and RLOC values for a  
-- flip-flop, described at RTL level  
--  
  
library ieee;  
use ieee.std_logic_1164.all;  
  
entity init_rlocs_3 is  
    port (CLK : in std_logic;  
          DI : in std_logic_vector(3 downto 0);  
          DO : out std_logic_vector(3 downto 0));  
end init_rlocs_3;  
  
architecture beh of init_rlocs_3 is  
    signal tmp: std_logic_vector(3 downto 0):="1011";  
  
    attribute RLOC: string;  
    attribute RLOC of tmp: signal is "X3Y0 X2Y0 X1Y0 X0Y0";  
begin  
  
    process (CLK)  
    begin  
        if (clk'event and clk='1') then  
            tmp <= DI;  
        end if;  
    end process;  
  
    DO <= tmp;  
  
end beh;
```

Verilog Code

Following is the Verilog code for specifying an INIT value for a flip-flop.

```
//  
// Specification on an INIT and RLOC values for a flip-flop,  
// described at RTL level  
  
module v_inits_rlocs_3 (clk, di, do);  
    input  clk;  
    input  [3:0] di;  
    output [3:0] do;  
    reg    [3:0] tmp;  
  
    initial begin  
        tmp = 4'b1011;  
    end  
  
    // synthesis attribute RLOC of tmp is "X3Y0 X2Y0 X1Y0 X0Y0"  
  
    always @(posedge clk)  
    begin  
        tmp <= di;  
    end  
  
    assign do = tmp;  
  
endmodule
```

PCI Flow

To successfully use PCI flow with XST (i.e. to satisfy all placement constraints and meet timing requirements) set the following options.

- For VHDL designs, ensure that the names in the generated netlist are all in uppercase. Note that by default, the case for VHDL synthesis flow is *lower*. Specify the case by selecting the Case option under the Synthesis Options tab in the Process Properties dialog box within Project Navigator.
- For Verilog designs, ensure that Case is set to *Maintain*, which is a default value. Specify Case as described above.
- Preserve the hierarchy of the design. Specify the Keep Hierarchy setting by selecting the Keep Hierarchy option under the Synthesis Options tab in the Process Properties dialog box within Project Navigator.
- Preserve equivalent flip-flops, which XST removes by default. Specify the Equivalent Register Removal setting by selecting the Equivalent Register Removal option under the Xilinx® Specific Options tab in the Process Properties dialog box within Project Navigator.
- Prevent logic and flip-flop replication caused by high fanout flip-flop set/reset signals. Do this by:
 - ◆ Setting a high maximum fanout value for the entire design via the Max Fanout menu in the Synthesis Options tab in the Process Properties dialog box within Project Navigator.
or
 - ◆ Setting a high maximum fanout value for the initialization signal connected to the RST port of PCI core by using the MAX_FANOUT attribute (for example: max_fanout=2048).
- Prevent XST from automatically reading PCI cores for timing and area estimation. In reading PCI cores, XST may perform some logic optimization in the user's part of the design that does not allow the design to meet timing requirements or might even lead to errors during MAP. Disable Read Cores by unchecking the Read Cores option under the Synthesis Options tab in the Process Properties dialog box in Project Navigator.

Note: By default, XST reads cores for timing and area estimation.

CPLD Optimization

This chapter contains the following sections.

- “CPLD Synthesis Options”
- “Implementation Details for Macro Generation”
- “Log File Analysis”
- “Constraints”
- “Improving Results”

CPLD Synthesis Options

This section describes the CPLD-supported families and their specific options.

Introduction

XST performs device specific synthesis for CoolRunner™ XPLA3/-II and XC9500™/XL/XV families, and generates an NGC file ready for the CPLD fitter.

The general flow of XST for CPLD synthesis is the following:

1. HDL synthesis of VHDL/Verilog designs
2. Macro inference
3. Module optimization
4. NGC file generation

Global CPLD Synthesis Options

This section describes supported CPLD families and lists the XST options related *only* to CPLD synthesis that can only be set from the Process Properties dialog box in Project Navigator.

Families

Five families are supported by XST for CPLD synthesis:

- CoolRunner XPLA3
- CoolRunner -II
- XC9500
- XC9500XL™
- XC9500XV™

The synthesis for the CoolRunner, XC9500XL, and XC9500XV families includes clock enable processing; you can allow or invalidate the clock enable signal (when invalidating, it is replaced by equivalent logic). Also, the selection of the macros which use the clock enable (counters, for instance) depends on the family type. A counter with clock enable is accepted for the CoolRunner, XC9500XL and XC9500XV families, but rejected (replaced by equivalent logic) for XC9500 devices.

List of Options

Following is a list of CPLD synthesis options that you can set from the Process Properties dialog box in Project Navigator. For details about each option, refer to “[CPLD Constraints \(non-timing\)](#)” in Chapter 5.

- [Keep Hierarchy](#)
- [Macro Preserve](#)
- [XOR Preserve](#)
- [Equivalent Register Removal](#)
- [Clock Enable](#)
- [WYSIWYG](#)
- [No Reduce](#)

Implementation Details for Macro Generation

XST processes the following macros:

- adders
- subtractors
- add/sub
- multipliers
- comparators
- multiplexers
- counters
- logical shifters
- registers (flip-flops and latches)
- XORs

The macro generation is decided by the Macro Preserve option, which can take two values:

- yes* — macro generation is allowed.
- no* — macro generation is inhibited.

The general macro generation flow is the following:

1. HDL infers macros and submits them to the low-level synthesizer.
2. Low-level synthesizer accepts or rejects the macros depending on the resources required for the macro implementations.

An accepted macro is generated by an internal macro generator. A rejected macro is replaced by equivalent logic generated by the HDL synthesizer. A rejected macro may be decomposed by the HDL synthesizer into component blocks so that one component may be a new macro requiring fewer resources than the initial one, and another smaller macro

may be accepted by XST. For instance, a flip-flop macro with clock enable (CE) cannot be accepted when mapping onto the XC9500. In this case the HDL synthesizer submits two new macros:

- a flip-flop macro without clock enable signal.
- a MUX macro implementing the clock enable function.

A generated macro is optimized separately and then merged with surrounded logic because the optimization process gives better results for larger components.

Log File Analysis

XST messages related to CPLD synthesis are located after the following message:

```
=====
*           Low Level Synthesis      *
=====
```

The log file produced by XST contains:

- Tracing of progressive unit optimizations:
Optimizing unit *unit_name* ...
 - Information, warnings or fatal messages related to unit optimization:
 - ◆ When equation shaping is applied (XC9500 devices only):
Collapsing ...
 - ◆ Removing equivalent flip-flops:
Register *ff1* equivalent to *ff2* has been removed
 - ◆ User constraints fulfilled by XST:
implementation constraint: *constraint_name[=value]: signal_name*
 - Final results statistics:
Final Results
Top Level Output file name : *file_name*
Output format : ngc
Optimization goal : {area | speed}
Target Technology : {9500 | 9500xl | 9500xv | xpla3 | xbr | cr2s}
Keep Hierarchy : {yes | soft | no}
Macro Preserve : {yes | no}
XOR Preserve : {yes | no}
- Design Statistics
NGC Instances: *nb_of_instances*
I/Os: *nb_of_io_ports*

```
Macro Statistics
# FSMs: nb_of_FSMs
# Registers: nb_of_registers
# Tristates: nb_of_tristates
# Comparators: nb_of_comparators
n-bit comparator {equal | not equal | greater| less | greatequal
| lessequal}:
nb_of_n_bit_comparators
# Multiplexers: nb_of_multiplexers
n-bit m-to-1 multiplexer :
nb_of_n_bit_m_to_1_multiplexers
# Adders/Subtractors: nb_of_adds_subs
n-bit adder: nb_of_n_bit_adds
n-bit subtractor: nb_of_n_bit_subs
# Multipliers: nb_of_multipliers
# Logic Shifters: nb_of_logic_shifters
# Counters: nb_of_counters
n-bit {up | down | updown} counter:
nb_of_n_bit_counters
# XORs: nb_of_xors
Cell Usage :
# BELS: nb_of_bels
# AND...: nb_of_and...
# OR...: nb_of_or...
# INV: nb_of_inv
# XOR2: nb_of_xor2
# GND: nb_of_gnd
# VCC: nb_of_vcc
# FlipFlops/Latches: nb_of_ff_latch
# FD...: nb_of_fd...
# LD...: nb_of_ld...
# Tri-States: nb_of_tristates
# BUFE: nb_of_bufe
# BUFT: nb_of_buft
# IO Buffers: nb_of_iobuffers
# IBUF: nb_of_ibuf
# OBUF: nb_ofobuf
# IOBUF: nb_of_iobuf
# OBUFE: nb_ofobufe
# OBUFT: nb_ofobuft
# Others: nb_of_others
```

Constraints

The constraints (attributes) specified in the HDL design or in the constraint files are written by XST into the NGC file as signal properties.

Improving Results

XST produces optimized netlists for the CPLD fitter, which fits them in specified devices and creates the download programmable files. The CPLD low-level optimization of XST consists of logic minimization, subfunction collapsing, logic factorization, and logic decomposition. The result of the optimization process is an NGC netlist corresponding to Boolean equations, which are reassembled by the CPLD fitter to fit the best of the macrocell capacities. A special XST optimization process, known as equation shaping, is applied for XC9500/XL/XV devices when the following options are selected:

- Keep Hierarchy: **No**
- Optimization Effort: **2 or High**
- Macro Preserve: **No**

The equation shaping processing also includes a critical path optimization algorithm, which tries to reduce the number of levels of critical paths.

The CPLD fitter multi-level optimization is still recommended because of the special optimizations done by the fitter (D to T flip-flop conversion, De Morgan Boolean expression selection).

How to Obtain Better Frequency?

The frequency depends on the number of logic levels (logic depth). In order to reduce the number of levels, the following options are recommended.

- Optimization Effort: **2 or High** — this value implies the calling of the collapsing algorithm, which tries to reduce the number of levels without increasing the complexity beyond certain limits.
- Optimization Goal: **Speed** — the priority is the reduction of number of levels.

The following tries, in this order, may give successively better results for frequency:

Try 1: Select only optimization effort 2 and speed optimization. The other options have default values:

- Optimization effort: **2 or High**
- Optimization Goal: **Speed**

Try 2: Flatten the user hierarchy. In this case the optimization process has a global view of the design, and the depth reduction may be better:

- Optimization effort: **1/Normal or 2/High**
- Optimization Goal: **Speed**
- Keep Hierarchy: **no**

Try 3: Merge the macros with surrounded logic. The design flattening is increased:

- Optimization effort: **1 or Normal**
- Optimization Goal: **Speed**
- Keep Hierarchy: **no**
- Macro Preserve **no**

Try 4: Apply the equation shaping algorithm. Options to be selected:

- Optimization effort: **2 or High**
- Macro Preserve: **no**
- Keep Hierarchy: **no**

The CPU time increases from Try 1 to Try 4.

Obtaining the best frequency depends on the CPLD fitter optimization. Xilinx recommends running the multi-level optimization of the CPLD fitter with different values for the -ptterms options, starting with 20 and finishing with 50 with a step of 5. Statistically the value 30 gives the best results for frequency.

How to Fit a Large Design?

If a design does not fit in the selected device, exceeding the number of device macrocells or device P-Term capacity, you must select an area optimization for XST. Statistically, the best area results are obtained with the following options:

- Optimization effort: **1/Normal or 2/High**
- Optimization Goal: **Area**
- Default values for other options

Another option that you can try is "-wysiwyg yes". This option may be useful when the design cannot be simplified by the optimization process and the complexity (in number of P-Terms) is near the device capacity. It may be that the optimization process, trying to reduce the number of levels, creates larger equations, therefore increasing the number of P-Terms and so preventing the design from fitting. By validating this option, the number of P-Terms is not increased, and the design fitting may be successful.

Design Constraints

This chapter describes constraints, options, and attributes supported for use with XST.

This chapter contains the following sections.

- “Introduction”
- “Setting Global Constraints and Options”
- “VHDL Attribute Syntax”
- “Verilog Meta Comment Syntax”
- “Verilog-2001 Attributes”
- “XST Constraint File (XCF)”
- “General Constraints”
- “HDL Constraints”
- “FPGA Constraints (non-timing)”
- “CPLD Constraints (non-timing)”
- “Timing Constraints”
- “Constraints Summary”
- “Implementation Constraints”
- “Third Party Constraints”
- “Constraints Precedence”

Introduction

Constraints are essential to help you meet your design goals or obtain the best implementation of your circuit. Constraints are available in XST to control various aspects of the synthesis process itself, as well as placement and routing. Synthesis algorithms and heuristics have been tuned to automatically provide optimal results in most situations. In some cases, however, synthesis may fail to initially achieve optimal results; some of the available constraints allow you to explore different synthesis alternatives to meet your specific needs.

The following mechanisms are available to specify constraints.

- Options provide global control on most synthesis aspects. They can be set either from within the Process Properties dialog box in Project Navigator or by setting options of the run command from the command line.
- VHDL attributes can be directly inserted into your VHDL code and attached to individual elements of the design to control both synthesis, and placement and routing.
- Constraints can be added as Verilog meta comments in your Verilog code.
- Constraints can be specified in a separate constraint file.

Typically, global synthesis settings are defined within the Process Properties dialog box in Project Navigator or with command line arguments, while VHDL attributes or Verilog meta comments can be inserted in your source code to specify different choices for individual parts of the design. Note that the local specification of a constraint overrides its global setting. Similarly, if a constraint is set both on a node (or an instance) and on the enclosing design unit, the former takes precedence for the considered node (or instance).

Setting Global Constraints and Options

This section explains how to set global constraints and options from the Process Properties dialog box within Project Navigator.

For a description of each constraint that applies generally — that is, to FPGAs, CPLDs, VHDL, and Verilog — refer to the *Constraints Guide*.

Note: Except for the Value fields with check boxes, there is a pull-down arrow or browse button in each Value field. However, you cannot see the arrow until you click in the Value field.

Synthesis Options

To specify the HDL synthesis options from Project Navigator:

1. Select a source file from the Source file window.
2. Right-click on **Synthesize - XST** in the Process window.
3. Select **Properties**.
4. When the Process Properties dialog box displays, click the Synthesis Options tab.

5. Depending on the device family you have selected (FPGA or CPLD), one of two dialog boxes displays:




Figure 5-1: Synthesis Options (FPGA)




Figure 5-2: Synthesis Options (CPLD)

Following is a list of the synthesis options that can be selected from the dialog boxes.

- Optimization Goal
- Optimization Effort
- Use Synthesis Constraints File
- Synthesis Constraint File
- Library Search Order
- Keep Hierarchy*
- Global Optimization Goal
- Generate RTL Schematic
- Read Cores*
- Cores Search Directories*
- Write Timing Constraints
- Cross Clock Analysis*
- Hierarchy Separator*
- Bus Delimiter*
- Slice Utilization Ratio*
- Case*
- Work Directory*
- HDL Library Mapping File (.INI File)*
- Verilog 2001
- Verilog Include Directories (Verilog Only)*
- Custom Compile File List*
- Other XST Command Line Options*

* To view these options, go to the **Property Display Level** drop down menu at the bottom of the window, and select **Advanced**.

HDL Options

With the Process Properties dialog box displayed for the **Synthesize - XST** process, select the HDL Options tab. For FPGA device families the following dialog box displays.




Figure 5-3: HDL Options Tab (FPGAs)

Following is a list of all HDL Options that can be set within the HDL Options tab of the Process Properties dialog box for FPGA devices:

- [FSM Encoding Algorithm](#)
- [Safe Implementation](#)
- [Case Implementation Style](#)
- [FSM Style*](#)
- [RAM Extraction](#)
- [RAM Style](#)
- [ROM Extraction](#)
- [ROM Style](#)
- [Mux Extraction](#)
- [Mux Style](#)
- [Decoder Extraction](#)
- [Priority Encoder Extraction](#)
- [Shift Register Extraction](#)
- [Logical Shifter Extraction](#)
- [XOR Collapsing](#)
- [Resource Sharing](#)
- [Multiplier Style **](#)
- [Use DSP48**](#)

* To view this option, go to the **Property Display Level** drop down menu at the bottom of the window, and select **Advanced**.

** When working with Virtex-4 devices, Use DSP48 replaces Multiplier Style in this dialog box.

For CPLD device families the following dialog box displays.




Figure 5-4: HDL Options Tab (CPLDs)

Following is a list of all HDL Options that can be set within the HDL Options tab of the Process Properties dialog box for CPLD devices:

- FSM Encoding Algorithm
- Safe Implementation
- Case Implementation Style
- Mux Extraction
- Resource Sharing

Xilinx Specific Options

From the Process Properties dialog box for the **Synthesize - XST** process, select the Xilinx Specific Options tab to display the options.

For FPGA device families, the following dialog box displays:




Figure 5-5: Xilinx Specific Options (FPGAs)

Following is the list of the Xilinx Specific Options for FPGAs:

- Add I/O Buffers
- Max Fanout
- Number of Global Clock Buffers*
- Number of Regional Clock Buffers*
- Register Duplication
- Equivalent Register Removal
- Register Balancing
- Move First Stage
- Move Last Stage
- Convert Tristates to Logic**
- Use Clock Enable
- Use Synchronous Set
- Use Synchronous Reset
- Optimize Instantiated Primitives

* To view these options, go the **Property Display Level** drop down menu at the bottom of the window, and click **Advanced**.

** Convert Tristate to Logic only appears when working with applicable devices.

For CPLD device families the following dialog box displays.




Figure 5-6: Xilinx Specific Options (CPLDs)

Following is a list of the Xilinx Specific Options:

- Add I/O Buffers
- Equivalent Register Removal
- Clock Enable
- Macro Preserve
- XOR Preserve
- WYSIWYG

Other XST Command Line Options

Any XST command line option can be set via the Other XST Command Line Options property in the Process Properties dialog box. This is an advanced property. Use the syntax described in [Chapter 10, “Command Line Mode.”](#) Separate multiple options with a space.

While the Other XST Command Line Options property is intended for XST options not listed in the Process Properties dialog box, if an option already listed as a dialog box property is entered, precedence is given to the option entered here. Illegal or unrecognized options cause XST to stop processing and generate a message like the following one.

```
ERROR:Xst:1363 - Option "-verilog2002" is not available for command run.
```

Custom Compile File List

By using the Custom Compile File List property, you can change the order in which source files are processed by XST. With this property, you select a user-defined compile list file that XST uses to determine the order in which it processes libraries and design files. Otherwise, XST uses an automatically generated list.

This user-defined file must list all design files and their libraries in the order in which they are to be compiled, from top to bottom. Type each file/library pair on its own line, with a semicolon separating the library from the file. The format is as follows:

```
library_name;file_name
[library_name;file_name]
...
```

Following is an example:

```
work;stopwatch.vhd
work;statmach.vhd
...
```

Note: This property is not connected to the Custom Compile File List property in the Simulation Properties dialog box, which means that a different compile list file is used for synthesis than for simulation.

VHDL Attribute Syntax

You can describe constraints with VHDL attributes in your VHDL code. Before it can be used, an attribute must be declared with the following syntax.

```
attributeAttributeName : Type ;
```

Example:

```
attribute RLOC : string ;
```

The attribute type defines the type of the attribute value. The only allowed type for XST is **string**. An attribute can be declared in an entity or architecture. If declared in the entity, it is visible both in the entity and the architecture body. If the attribute is declared in the architecture, it cannot be used in the entity declaration. Once declared a VHDL attribute can be specified as follows:

```
attributeAttributeName of ObjectList : ObjectType isAttributeValue ;
```

Examples:

```
attribute RLOC of u123 : label is R11C1.S0 ;
attribute bufg of my_signal : signal is sr;
```

The object list is a comma separated list of identifiers. Accepted object types are entity, component, label, signal, variable and type.

Verilog Meta Comment Syntax

Constraints can be specified as follows in Verilog code:

```
// synthesis attribute AttributeName [of] ObjectName [is]
   AttributeValue
```

Example:

```
// synthesis attribute RLOC of u123 is R11C1.S0
// synthesis attribute HU_SET u1 MY_SET
// synthesis attribute bufg of my_clock is "clk";
```

Note: The parallel_case, full_case, translate_on and translate_off directives follow a different syntax described in “[Verilog Meta Comments](#)” in Chapter 7.

Verilog-2001 Attributes

XST supports Verilog-2001 attribute statements. Attributes are comments that are used to pass specific information to software tools such as synthesis tools. Verilog-2001 attributes can be specified anywhere for operators or signals within module declarations and instantiations.

Note: Other attribute declarations may be supported by the compiler, but are ignored by XST.

Attributes can be used to:

- Set constraints on individual objects (for example, module, instance, net).
- Set FULL_CASE and PARALLEL_CASE synthesis directives.

Syntax

Attributes must be bounded by the characters (* and *), and are written using the following syntax:

```
(* attribute_name = attribute_value *)
```

Where:

- The attribute must precede the signal, module or instance declaration it refers to.
- The *attribute_value* must be a string; no integer or scalar values are allowed.
- The *attribute_value* must be between quotes.
- The default value is 1. (* **attribute_name** *) is the same as (* **attribute_name** = "1" *).

Example 1

```
(* clock_buffer = "IBUFG" *) input CLK;
```

Example 2

```
(* INIT = "0000" *) reg [3:0] d_out;
```

Example 3

```
always@(current_state or reset)
begin (* parallel_case *) (* full_case *)
    case (current_state)
        ...
    endcase
end
```

Example 4

```
(* mult_style = "pipe_lut" *) MULT my_mult (a, b, c);
```

Limitations

Verilog-2001 attributes are not supported for the following.

- signal declarations
- statements
- port connections
- expression operators

XST Constraint File (XCF)

XST constraints can be specified in a file called the Xilinx Constraint File (XCF). The XCF must have an extension of .xcf. You can specify the constraint file in ISE™, by going to the **Synthesis - XST** Process Properties, clicking the Synthesis Options tab, enabling the Use Synthesis Constraints File option by clicking the check box, clicking the value field for the **Synthesis Constraints File** option, and typing the constraint file name. You can also browse for an existing file to use by clicking the box to the right of the value field. Also, to quickly enable/disable the use of a constraint file by XST, you can check or uncheck the Use Synthesis Constraint File option in this same menu. By selecting this option, you invoke the –iuc command line switch.

To specify the constraint file in command line mode, use the –uc switch with the *run* command. See [Chapter 10, “Command Line Mode”](#) for details on the *run* command and running XST from the command line.

XCF Syntax and Utilization

The XCF syntax enables you to specify a specific constraint for the entire device (globally) or for specific modules in your design. The XCF syntax is basically the same as the UCF syntax for applying constraints to nets or instances, but with an extension to the syntax to allow constraints to be applied to specific levels of hierarchy. You can use the keyword MODEL to define the entity/module that the constraint is applied to. If a constraint is applied to an entity/module, the constraint is applied to each instance of the entity/module.

In general, users should define constraints within the ISE process properties dialog box (or the XST run script, if running on the command line), then use the XCF file to specify exceptions to these general constraints. The constraints specified in the XCF file are applied ONLY to the module listed, and not to any submodules below it.

To apply a constraint to the entire entity/module use the following syntax:

```
MODEL entityname constraintname = constraintvalue;
```

Examples:

```
MODEL top mux_extract = false;
MODEL my_design max_fanout = 256;
```

Note: If the entity *my_design* is instantiated several times in the design, the *max_fanout=256* constraint is applied to each instance of *my_design*.

To apply constraints to specific instances or signals within an entity/module, use the INST or NET keywords:

```
BEGIN MODEL entityname
  INST instancename constraintname = constraintvalue ;
  NET signalname constraintname = constraintvalue ;
END;
```

Examples:

```
BEGIN MODEL crc32
  INST stopwatch opt_mode = area ;
  INST U2 ram_style = block ;
  NET myclock clock_buffer = true ;
  NET data_in iob = true ;
END;
```

See “[Constraints Summary](#)” for the complete list of synthesis constraints that you can apply for XST.

Native vs. Non-Native UCF Constraints Syntax

From a UCF syntax point of view, all constraints supported by XST can be divided into two groups: native UCF constraints, and non-native UCF constraints. Only Timing and Area Group constraints use native UCF syntax.

For all non-native UCF constraints, use the MODEL or BEGIN MODEL... END; constructs. This is true for pure XST constraints such as FSM_EXTRACT or RAM_STYLE, as well as for implementation non-timing constraints, such as RLOC or KEEP.

For native UCF constraints, such as PERIOD, OFFSET, TNM_NET, TIMEGRP, TIG, FROM-TO etc., use native UCF syntax, which includes the use of wildcards and hierarchical names. Do not use these constraints inside the BEGIN MODEL... END construct, otherwise XST issues an error.

IMPORTANT: If you specify timing constraints in the XCF file, Xilinx strongly suggests that you use '/' character as a hierarchy separator instead of '_'. Please refer to “[Hierarchy Separator](#)” for details on its usage.

Limitations

XCF syntax has the following limitations.

- Nested model statements are not supported in the current release.
- Instance or signal names listed between the BEGIN MODEL statement and the END statement are only the ones visible inside the entity. Hierarchical instance or signal names are not supported.
- Wildcards in instance and signal names are not supported, except in timing constraints.

- Not all native UCF constraints are supported in the current release. Refer to the *Constraints Guide* for more information.

General Constraints

This section lists various constraints that you can use with XST. These constraints apply to FPGAs, CPLDs, VHDL, and Verilog. You can set some of these options under the Synthesis Options tab of the Process Properties dialog box in Project Navigator. See “[Constraints Summary](#)” for a complete list of constraints supported by XST.

Add I/O Buffers

Add I/O Buffers, (-iobuf) enables or disables I/O buffer insertion. XST automatically inserts Input/Output Buffers into the design. You can manually instantiate I/O Buffers for some or all the I/Os, and XST will insert I/O Buffers only for the remaining I/Os. If you do not want XST to insert any I/O Buffers, set this option to **no**. This option is useful to synthesize a part of a design to be instantiated later on.

IOBUF enables or disables I/O buffer insertion. Allowed values are **yes**, **no**. By default, buffer insertion is enabled (**yes**).

When the **yes** value is selected, IBUF and OBUF primitives are generated. IBUF/OBUF primitives are connected to I/O ports of the top-level module. When XST is called to synthesize an internal module that will be instantiated later in a larger design, you must select the **no** this option. If I/O buffers are added to a design, this design cannot be used as a submodule of another design.

Architecture Support

The following table indicates supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

Add I/O Buffers can only be applied globally.

Propagation Rules

Applies to all buffers inserted into a design.

Syntax Examples

XST Command Line

Define globally with the **-iobuf** command line option of the **run** command. Following is the basic syntax:

```
-iobuf {yes|no}
```

The default is **yes**.

Project Navigator

Specify globally with the **Add IO Buffers** option in the Xilinx Specific Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Box Type

BOX_TYPE is a synthesis constraint. It currently takes three possible values: **primitive**, **black_box**, and **user_black_box**, which instruct XST not to synthesize the behavior of a module. Please note that the **black_box** value is equivalent to **primitive** and will eventually become obsolete.

The main difference between the **primitive (black_box)** and **user_black_box** is that if the **user_black_box** value is specified, XST reports inference of a black box in the LOG file, but does not do this if **primitive** is specified.

Please note that if the **box_type** is applied to at least a single instance of a block at a particular hierarchical level, then **box_type** is propagated to all other instances of this block at this hierarchical level. This feature was implemented for Verilog and XCF only in order to have a VHDL-like support, where **box_type** can be applied to a component.

BOX_TYPE Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes

Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

The constraint applies to the following design elements:

VHDL: component, entity

Verilog: module, instance

XCF: model, instance

Propagation Rules

Applies to the design element to which it is attached.

Syntax Examples

VHDL

Before using BOX_TYPE, declare it with the following syntax:

```
attribute box_type: string;
```

After declaring BOX_TYPE, specify the VHDL constraint as follows:

```
attribute box_type of {component_name|entity_name}: {component|entity}
is "{primitive|black_box|user_black_box}";
```

Verilog

Specify as follows:

```
// synthesis attribute box_type [of] {module_name|instance_name} [is]
"primitive|black_box|user_black_box";
```

XCF

```
MODEL "entity_name" box_type="{primitive|black_box|user_black_box}";
BEGIN MODEL "entity_name"
INST "instance_name" box_type="{primitive|black_box|user_black_box}";
END;
```

Bus Delimiter

The Bus Delimiter (-bus_delimiter) command line option defines the format used to write the signal vectors in the result netlist. The available possibilities are <>, [], {}, (). The default is <>.

Architecture Support

The Bus Delimiter (-bus_delimiter) command line option is architecture independent

Applicable Elements

Applies to syntax

Syntax Examples

XST Command Line

Define this option globally with the **-bus_delimiter** command line option of the **run** command. Following is the basic syntax:

```
-bus_delimiter {<>|[]|{}|()
```

The default is <>.

Project Navigator

Set globally with the **Bus Delimiter** option in the Synthesis Options tab of the Process Properties dialog box in the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Case

The Case command line option (**-case**) determines if instance and net names are written in the final netlist using all lower or upper case letters or if the case is maintained from the source. Note that the case can be maintained for either Verilog or VHDL synthesis flow.

Architecture Support

The Case command line option (**-case**) is architecture independent.

Applicable Elements

Applies to syntax

Syntax Examples

XST Command Line

Define globally with the **-case** command line option of the **run** command. Following is the basic syntax:

```
-case {upper|lower|maintain}
```

The default **maintain**.

Project Navigator

Set globally with the **Case** option in the Synthesis Options tab of the Process Properties dialog box in the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Case Implementation Style

The Case Implementation Style (`-vlgcase`) command line option instructs XST how to interpret Verilog Case statements. It has three possible values: **full**, **parallel** and **full-parallel**.

- If the option is not specified, then XST implements the exact behavior of the case statements.
- If **full** is used, XST assumes that the case statements are complete and avoids latch creation.
- If **parallel** is used, XST assumes that the branches cannot occur in parallel and does not use a priority encoder.
- If **full-parallel** is used, XST assumes that the case statements are complete and that the branches cannot occur in parallel, therefore saving latches and priority encoders.

See “[Multiplexers](#)” in Chapter 2, as well as, “[Full Case \(Verilog\)](#)” and “[Parallel Case \(Verilog\)](#)” for more information.

Architecture Support

Case Implementation Style is architecture independent and valid for Verilog designs only.

Applicable Elements

`VLCASE` can only be applied globally.

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define globally with the `-vlgcase` command line option of the `run` command.

```
-vlgcase {full|parallel|full-parallel}
```

By default, there is no value.

Project Navigator

Specify globally with the **Case Implementation Style** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

Allowed values are **Full**, **Parallel**, and **Full-Parallel**. By default, the value is blank.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Full Case (Verilog)

The Full Case (FULL_CASE) directive is used to indicate that all possible selector values have been expressed in a case, casex or casez statement. The directive prevents XST from creating additional hardware for those conditions not expressed. See “[Multiplexers](#)” in Chapter 2 for more information.

Architecture Support

The Full Case directive is architecture independent and valid for Verilog designs only.

Applicable Elements

You can apply FULL_CASE to case statements in Verilog meta comments.

Propagation Rules

Not applicable.

Syntax Examples

Verilog

The directive is exclusively available as a meta comment in your Verilog code and cannot be specified in a VHDL description or in a separate constraint file. The syntax differs from the standard meta comment syntax as shown in the following:

```
// synthesis full_case
```

The Verilog 2001 syntax is as follows: (* full_case *)

Since the directive does not contain a target reference, the meta comment immediately follows the selector.

Example:

```
casex select // synthesis full_case or (* full_case *)
 4'b1xxx: res = data1;
 4'bx1xx: res = data2;
 4'bxx1x: res = data3;
 4'bxxx1: res = data4;

endcase
```

XST Command Line

Define globally with the **-vlgcase** command line option of the **run** command using the **full** option. Following is the basic syntax:

```
-vlgcase {full|parallel|full-parallel}
```

Project Navigator

For Verilog files only, specify globally in the Synthesis Options tab of the Process Properties dialog box within the Project Navigator.

With a Verilog design selected in the Sources window, right-click **Synthesize** in the Processes window to access the Synthesis Options tab of the Process Properties dialog box. For **Case Implementation Style**, select **Full** as a Value.

Generate RTL Schematic

The Generate RTL Schematic (-rtlview) command line option enables XST to generate a netlist file, representing an RTL structure of the design. This netlist can be viewed by the RTL and Technology Viewers. This option has three possible values: **yes**, **no** and **only**. When the **only** value is specified, XST stops the synthesis process just after the RTL view is generated. The file containing the RTL view has an NGR file extension.

Architecture Support

The Generate RTL Schematic command line option is technology independent.

Applicable Elements

Applies to a file

Syntax Examples

XST Command Line

Define globally with the **-rtlview** command line option of the **run** command. Following is the basic syntax:

```
-rtlview {yes|no|only}
```

From the command line, the default is **no**.

Project Navigator

Set globally with the **Generate RTL Schematic** option in the Synthesis Options tab of the Process Properties dialog box in the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

From Project Navigator, the default is **yes**.

Duplication Suffix

The Duplication Suffix (**-duplication_suffix**) command line option controls how XST names replicated flip-flops. By default, when XST replicates a flip-flop, it creates a name for the new flip-flop by taking the name of the original flip-flop and adding "*n*" to the end of it, where *n* is an index number. For example, if the original flip-flop name is `my_ff`, and this flip-flop was replicated three times, XST generates flip-flops with the following names: `my_ff_1`, `my_ff_2` and `my_ff_3`.

Using the Duplication Suffix command line option, you can specify a text string to append to the end of the default name. You can use the `%d` escape character to specify where in the name the index number appears. For example, for the flip-flop named `my_ff`, if you specify `_dupreg_%d` with the Duplication Suffix option, XST generates the following names: `my_ff_dupreg_1`, `my_ff_dupreg_2`, and `my_ff_dupreg_3`. Please note that `%d` can be placed anywhere in the suffix definition. For example, if the Duplication Suffix value is specified as `_dup_%d_reg`, XST generates the following names: `my_ff_dup_1_reg`, `my_ff_dup_2_reg` and `my_ff_dup_3_reg`.

Architecture Support

The Duplication Suffix command line option is technology independent.

Applicable Elements

Applies to a file.

Syntax Examples

XST Command Line

Define globally with the **-duplication_suffix** command line option of the **run** command. Following is the basic syntax:

```
-duplication_suffix string%dstring
```

The default is `_%d`.

Project Navigator

The Duplication Suffix option does not appear on the Process Properties dialog box. Set it globally with the **Other** option in the Synthesis Options tab of the Process Properties dialog box in the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box. Specify the option in the **Other XST Command Line Options** menu item. See XST Command Line example for coding details.

Hierarchy Separator

The Hierarchy Separator (`-hierarchy_separator`) command line option defines the hierarchy separator character that is used in name generation when the design hierarchy is flattened.

There are two supported characters, `'_'` and `'/'`. The default is `'/'` for newly created projects.

If a design contains a sub-block with instance `INST1`, and this sub-block contains a net, called `TMP_NET`, then the hierarchy is flattened and the hierarchy separator character is `'_'`. The name of `TMP_NET` becomes `INST1_TMP_NET`. If the hierarchy separator character is `'/'`, then the name of the net will be `'INST1/TMP_NET'`. Using `'/'` as a hierarchy separator is very useful in the design debugging process because this separator makes it much easier to identify a name if it is hierarchical.

Architecture Support

The Hierarchy Separator command line option is technology independent.

Applicable Elements

Applies to a file.

Syntax Examples

XST Command Line

Define this option globally with the **-hierarchy_separator** command line option of the **run** command. Following is the basic syntax:

```
-hierarchy_separator {_|/}
```

The default is `'/'` for newly created projects.

Project Navigator

Set globally with the **Hierarchy Separator** option in the Synthesis Options tab of the Process Properties dialog box in the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

From Project Navigator, the default is '/'.

Iostandard

Use the IOSTANDARD constraint to assign an I/O standard to an I/O primitive. See “[IOSTANDARD](#)” in the *Constraints Guide* for details.

Keep

The KEEP constraint is an advanced mapping constraint. When a design is mapped, some nets may be absorbed into logic blocks. When a net is absorbed into a block, it can no longer be seen in the physical design database. This may happen, for example, if the components connected to each side of a net are mapped into the same logic block. The net may then be absorbed into the block containing the components. KEEP prevents this from happening.

Please note that the KEEP constraint preserves the existence of the signal in the final netlist, but not its structure. For example, if your design has a 2-bit multiplexer selector and you attach a KEEP constraint to it, then this signal will be preserved in the final netlist. But the multiplexer could be automatically reencoded by XST using one-hot encoding. As a consequence, this signal in the final netlist will be four bits wide instead of the original two. To preserve the structure of the signal, in addition to the KEEP constraint you must also use the ENUM_ENCODING constraint. See “[Enumerated Encoding \(VHDL\)](#)” for more information.

See “[KEEP](#)” in the *Constraints Guide* for details.

Library Search Order

The Library Search Order (-lso) command line option is related to the use of mixed language (VHDL/Verilog) projects support. It allows you to specify the order in which various library files are used.

It can be invoked by specifying the file containing the search order in the value field to the right of **Library Search** option under the Synthesis Options tab in the Process Properties dialog box in Project Navigator, or with the **-lso** command line option.

Architecture Support

The Library Search Order command line option is architecture independent

Applicable Elements

Applies to a file.

Syntax Examples

XST Command Line

Define this option globally with the **-lso** command line option of the **run** command. Following is the basic syntax:

```
-lso {_|/}
```

The default is '/' for newly created projects.

See the “[Library Search Order File](#)” in [Chapter 8](#) for details.

Project Navigator

Set globally with the **Library Search** option in the Synthesis Options tab of the Process Properties dialog box in the Project Navigator. See the “[Library Search Order File](#)” in [Chapter 8](#) for details.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

LOC

The LOC constraint defines where a design element can be placed within an FPGA/CPLD. See “[LOC](#)” in the *Constraints Guide* for details.

Optimization Effort

The Optimization Effort (OPT_LEVEL) constraint defines the synthesis optimization effort level. Allowed values are **1** (normal optimization) and **2** (higher optimization). The default optimization effort level is **1** (Normal).

- **1 (Normal)**
Very fast processing, especially for hierarchical designs. This is the default mode and suggested for use with a majority number of designs.
- **2 (Higher Optimization)**
Time consuming processing—sometimes with better results in the number of macrocells or maximum frequency.

Note: In speed optimization mode, Xilinx strongly suggests using **1** (Normal) optimization effort for the majority of designs. Selecting optimization level **2** usually results in increased synthesis run times and does not always bring optimization gain.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes

Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

OPT_LEVEL can be applied globally or to an entity or module.

Propagation Rules

Applies to the entity or module to which it is attached.

Syntax Examples

VHDL

Before using OPT_LEVEL, declare it with the following syntax:

```
attribute opt_level: string;
```

After declaring OPT_LEVEL, specify the VHDL constraint as follows:

```
attribute opt_level of entity_name: entity is "{1|2}";
```

Verilog

Specify as follows:

```
// synthesis attribute opt_level [of] module_name [is] "{1|2}";
```

XCF

```
MODEL "entity_name" opt_level={1|2};
```

XST Command Line

Define OPT_LEVEL globally with the **-opt_level** command line option. Following is the basic syntax:

```
-opt_level {1|2}
```

The default is 1.

Project Navigator

Define globally with the **Optimization Effort** option in the Synthesis Options tab of the Process Properties dialog box in Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Optimization Goal

The Optimization Goal (OPT_MODE) constraint defines the synthesis optimization strategy. Available strategies are *speed* and *area*. By default, XST optimizations are speed-oriented.

- *speed*
Priority is to reduce the number of logic levels and therefore to increase frequency.
- *area*
Priority is to reduce the total amount of logic used for design implementation and therefore to improve design fitting.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

You can apply OPT_MODE globally or to an entity or module.

Propagation Rules

Applies to the entity or module to which it is attached.

Syntax Examples

VHDL

Before using OPT_MODE, declare it with the following syntax:

```
attribute opt_mode: string;
```

After declaring OPT_MODE, specify the VHDL constraint as follows:

```
attribute opt_mode of entity_name: entity is "{speed|area}";
```

Verilog

Specify OPT_MODE as follows:

```
// synthesis attribute opt_mode [of] module_name [is] {speed|area}
```

XCF

```
MODEL "entity_name" opt_mode={speed|area};
```

XST Command Line

Define globally with the **-opt_mode** command line option of the **run** command. Following is the basic syntax:

```
-opt_mode {AREA|SPEED}
```

The default is **SPEED**.

Project Navigator

Define globally with the **Optimization Goal** option in the Synthesis Options tab of the Process Properties dialog box in Project Navigator. The default is **Speed**.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Parallel Case (Verilog)

The PARALLEL_CASE directive is used to force a case statement to be synthesized as a parallel multiplexer and prevents the case statement from being transformed into a prioritized if/elsif cascade. See “[Multiplexers](#)” in Chapter 2 of this guide.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-III	Yes
Spartan-3	Yes
Spartan-3E	Yes

Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

You can apply PARALLEL_CASE to case statements in Verilog meta comments only.

Propagation Rules

Not applicable.

Syntax Examples

Verilog

The directive is exclusively available as a meta comment in your Verilog code and cannot be specified in a VHDL description or in a separate constraint file. The syntax differs from the standard meta comment syntax as shown in the following:

```
// synthesis parallel_case
```

Since the directive does not contain a target reference, the meta comment immediately follows the selector.

Example:

```
casex select // synthesis parallel_case
 4'b1xxx: res = data1;
 4'bx1xx: res = data2;
 4'bxx1x: res = data3;
 4'bxxx1: res = data4;

endcase
```

XST Command Line

Define PARALLEL_CASE globally with the **-vlgcase** command line option of the **run** command. Following is the basic syntax:

```
-vlgcase {full|parallel|full-parallel}
```

RLOC

The RLOC constraint is a basic mapping and placement constraint. This constraint groups logic elements into discrete sets and allows you to define the location of any element within the set relative to other elements in the set, regardless of eventual placement in the overall design. See “**RLOC**” in the *Constraints Guide* for details.

Synthesis Constraint File

The Synthesis Constraint File (-uc) command line option specifies a synthesis constraint file for XST to use. The XCF must have an extension of .xcf. If the extension is not .xcf, XST will error out and stop processing.

Please refer to “[XST Constraint File \(XCF\)](#)” for details on using the constraint file.

Architecture Support

The following table indicates supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes
CoolRunner-IIS	Yes

Applicable Elements

Applies to a file

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Specify a file name with the **-uc** command line option of the **xrun** command. Following is the basic syntax:

```
-uc filename
```

Project Navigator

Specify a synthesis file with the **Use Synthesis Constraints File** option in the Synthesis Options tab of the Process Properties dialog box in the Project Navigator.

With a design selected in the Sources window, right-click Synthesize in the Processes window to access the appropriate Process Properties dialog box.

Translate Off/Translate On (Verilog/VHDL)

The Translate Off (TRANSLATE_OFF) and Translate On (TRANSLATE_ON) directives can be used to instruct XST to ignore portions of your VHDL or Verilog code that are not relevant for synthesis; for example, simulation code. The TRANSLATE_OFF directive marks the beginning of the section to be ignored, and the TRANSLATE_ON directive instructs XST to resume synthesis from that point.

Note: TRANSLATE_OFF and TRANSLATE_ON are also Synplicity and Synopsys constraints that are supported by XST in Verilog. Automatic conversion is also available in VHDL and Verilog.

Note: TRANSLATE_ON/TRANSLATE_OFF can be used with the following words:

- synthesis
- synopsys
- pragma

Architecture Support

TRANSLATE_OFF and TRANSLATE_ON directives are architecture independent

Applicable Elements

TRANSLATE_OFF and TRANSLATE_ON can be applied locally only.

Propagation Rules

Instructs synthesis tool to enable or disable portions of code.

Syntax Examples

VHDL

In your VHDL code, the directives should be written as follows:

```
-- synthesis translate_off  
...code not synthesized...  
-- synthesis translate_on
```

Verilog

The directives are available as VHDL or Verilog meta comments. The Verilog syntax differs from the standard meta comment syntax presented earlier in this chapter, as shown below.

```
// synthesis translate_off  
...code not synthesized...  
// synthesis translate_on
```

Use Synthesis Constraints File

The Use Synthesis Constraints File (-iuc) command line option allows you to ignore the constraint file during synthesis.

Architecture Support

The Use Synthesis Constraints File command line option is architecture independent.

Applicable Elements

Applies to a file

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define globally with the **-iuc** command line option of the **run** command. Following is the basic syntax:

```
-iuc {yes|no}
```

The default is **no**.

Project Navigator

Set globally by selecting the **Use Synthesis Constraints File** option under the Synthesis Options tab in the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Verilog Include Directories (Verilog Only)

Use the Verilog Include Directories option (**-vlgincdir**) to enter discrete paths to your Verilog Include Directories.

Architecture Support

The Use Synthesis Constraints File command line option is architecture independent.

Applicable Elements

Directories

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define this option globally with the **-vlgincdir** command line option of the **run** command. Allowed values are names of directories. Please refer to “Names with Spaces” in Chapter 10 for more information.

```
-vlgincdir {directory_path [directory_path]}
```

There is no default.

Project Navigator

Define globally with the **Verilog Include Directories** option of the Synthesis Options tab in the Process Properties dialog box in the Project Navigator. Allowed values are names of directories. There is no default.

You must have Property Display Level set to Advanced in the Processes tab of the Preferences dialog box (**Edit → Preferences**) to display the Verilog Search Paths option.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Verilog 2001

The Verilog 2001(-verilog2001) command line option enables or disables interpreted Verilog source code as the Verilog 2001 standard. By default Verilog source code is interpreted as the Verilog 2001 standard.

Architecture Support

The Verilog 2001 command line option is architecture independent.

Applicable Elements

Applies to syntax

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define globally with the **-verilog2001** command line option of the **run** command. Following is the basic syntax:

```
-verilog2001 {yes | no}
```

The default is **yes**.

Project Navigator

Set globally with the **Verilog 2001** option in the Synthesis Options tab of the Process Properties dialog box in the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

HDL Library Mapping File (.INI File)

Use the HDL Library Mapping File command (-xsthdpini) to define the library mapping.

There is a library mapping file and two associated parameters: XSTHDPINI and XSTHDPDIR. The library mapping file contains the library name and the directory in which this library is compiled. XST maintains two library mapping files:

- The "pre-installed" file, which is installed during the Xilinx® software installation.
- The "user" file, which users may define for their own projects.

The "pre-installed" (default) INI file is named "xhdp.ini," and is located in %XILINX%\vhdl\xst. These files contain information about the locations of the standard VHDL and UNISIM libraries. These should not be modified, but the syntax can be used for user library mapping. This file appears as follows:

```
-- Default lib mapping for XST
std=$XILINX/vhdl/xst/std
ieee=$XILINX/vhdl/xst/unisim
unisim=$XILINX/vhdl/xst/unisim
aim=$XILINX/vhdl/xst/aim
pls=$XILINX/vhdl/xst/pls
```

You can use this file format to define where each of your own libraries must be placed. By default, all compiled VHDL files will be stored in the "xst" sub-directory of the ISE™ project directory. You can place your custom INI file anywhere on a disk by using one of the following methods:

- Selecting the **VHDLINI File** option in the "Synthesis Options" tab of the Synthesis process properties in Project Navigator.
- Setting up the -xsthdpini parameter, using the following command in stand-alone mode:

```
set -xsthdpini file_name
```

You can give this library mapping file any name you wish, but it is best to keep the .ini classification. The format is:

```
library_name=path_to_compiled_directory
```

Note: (Use "--" for comments.)

Sample text for "my.ini":

```
work1=H:\Users\conf\my_lib\work1
work2=C:\mylib\work2
```

Architecture Support

The HDL Library Mapping File command is architecture independent.

Applicable Elements

Files

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define globally with the **set -xsthdpini** command line option before running the **run** command. Following is the basic syntax:

```
set -xsthdpini file_name
```

The command can accept a single file only.

Project Navigator

Define globally with the **VHDLINI File** option of the Synthesis Options tab in the Process Properties dialog box in the Project Navigator.

You must have Property Display Level set to Advanced in the Processes tab of the Preferences dialog box (**Edit → Preferences**) to display the VHDLINI File option.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Work Directory

The Work Directory (-xsthdpdir) parameter defines the location in which VHDL-compiled files must be placed if the location is not defined by library mapping files. You can access this switch by using one of the following methods:

- Selecting the **VHDL Working Directory** menu in the "Synthesis Options" tab of the Synthesis process properties in Project Navigator.
- Using the following command in stand-alone mode:

```
set -xsthdpdir directory
```

Example:

Suppose three different users are working on the same project. They must share one standard, pre-compiled library, **shlib**. This library contains specific macro blocks for their project. Each user also maintains a local work library, but User 3 places it outside the project directory (i.e., in c:\temp). Users 1 and 2 will share another library ("lib12") between them, but not with User 3. The settings required for the three users are as follows:

User 1:

```
Mapping file:  
schlib=z:\sharedlibs\shlib  
lib12=z:\userlibs\lib12
```

User 2:

```
Mapping file:  
schlib=z:\sharedlibs\shlib  
lib12=z:\userlibs\lib12
```

User 3:

```
Mapping file:  
schlib=z:\sharedlibs\shlib
```

User 3 will also set:

```
XSTHDPDIR = c:\temp
```

Architecture Support

The Work Directory command is architecture independent.

Applicable Elements

Directories

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define this parameter globally with the **set -xsthdpdir** command line option before running the **run** command. Following is the basic syntax:

```
set -xsthdpdir directory
```

The command can accept a single path only. You must specify the directory you want to use. There is no default.

Project Navigator

Define globally with the **VHDL Work Directory** option of the Synthesis Options tab in the Process Properties dialog box in the Project Navigator.

You must have Property Display Level set to Advanced in the Processes tab of the Preferences dialog box (**Edit → Preferences**) to display the option.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

HDL Constraints

This section describes encoding and extraction constraints. Most of the constraints can be set globally in the HDL Options tab of the Process Properties dialog box in Project Navigator. The only constraints that *cannot* be set in this dialog box are Enumerated Encoding, Signal Encoding, and Recovery State. The constraints described in this section apply to FPGAs, CPLDs, VHDL, and Verilog.

Note: Please note that in many cases, a particular constraint can be applied globally to an entire entity or model, or alternatively, it can be applied locally to individual signals, nets or instances. See [Table 5-1](#) for valid constraint targets.

Automatic FSM Extraction

The Automatic FSM Extraction (FSM_EXTRACT) constraint enables or disables finite state machine extraction and specific synthesis optimizations. This option must be enabled in order to set values for the FSM Encoding Algorithm and FSM Flip-Flop Type.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIE	Yes

Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

FSM_EXTRACT can be applied globally or to a VHDL entity, Verilog module or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using FSM_EXTRACT, declare it with the following syntax:

```
attribute fsm_extract: string;
```

After declaring FSM_EXTRACT, specify the VHDL constraint as follows:

```
attribute fsm_extract of {entity_name|signal_name}: {entity|signal} is
"yes";
```

Verilog

Specify as follows:

```
// synthesis attribute fsm_extract [of] {module_name|signal_name} [is]
yes;
```

XCF

```
MODEL "entity_name" fsm_extract={yes|no|true|false};
```

```
BEGIN MODEL "entity_name"
  NET "signal_name" fsm_extract={yes|no|true|false};
END;
```

XST Command Line

Define globally with the **-fsm_extract** command line option of the **run** command. Following is the basic syntax:

```
-fsm_extract {yes|no}
```

The default is **yes**.

Project Navigator

In Project Navigator, Automatic FSM Extraction is controlled by the **FSM Encoding Algorithm** menu under the HDL Options tab of the Process Properties dialog box. Note that the FSM Encoding Algorithm menu controls both the Automatic FSM Extraction (**-fsm_extract**) option and the FSM Encoding (**-fsm_encoding**) option. These options are set as follows:

- If the FSM Encoding Algorithm menu is set to **None**, and **-fsm_extract** is set to **no** and the **-fsm_encoding** has no influence on the synthesis.
- In all other cases, **-fsm_extract** is set to **yes** and **-fsm_encoding** is set to the value selected in the menu. See “[FSM Encoding Algorithm](#)” for more information about **-fsm_encoding**.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the HDL Options tab of the Process Properties dialog box. Select a value from the drop-down list box.

Enumerated Encoding (VHDL)

The Enumerated Encoding (ENUM_ENCODING) constraint can be used to apply a specific encoding to a VHDL enumerated type. The constraint value is a string containing space-separated binary codes. You can only specify ENUM_ENCODING as a VHDL constraint on the considered enumerated type.

When describing a finite state machine using an enumerated type for the state register, you may specify a particular encoding scheme with ENUM_ENCODING. In order for this encoding to be actually used by XST, you must also set **FSM_ENCODING** to **user** for the considered state register.

Note: Because it must preserve the external design interface, XST ignores the ENUM_ENCODING constraint when it is used on a port.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes

Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

ENUM_ENCODING can be applied to a type or signal.

Note: Because ENUM_ENCODING must preserve the external design interface, XST ignores the ENUM_ENCODING constraint when it is used on a port.

Propagation Rules

Applies to the type or signal to which it is attached.

Syntax Examples

VHDL

You can specify ENUM_ENCODING as a VHDL constraint on the considered enumerated type, as shown in the example below.

```
...
architecture behavior of example is
type statetype is (ST0, ST1, ST2, ST3);
attribute enum_encoding of statetype : type is "001 010 100 111";
signal state1 : statetype;
signal state2 : statetype;
begin
...

```

XCF

```
BEGIN MODEL "entity_name"
  NET "signal_name" enum_encoding="string";
END;
```

Equivalent Register Removal

The Equivalent Register Removal (EQUIVALENT_REGISTER_REMOVAL) constraint enables or disables removal of equivalent registers, described at the RTL Level. By default XST does not remove equivalent flip-flops if they are instantiated from a Xilinx® primitive library. Flip-flop optimization includes the removal of equivalent flip-flops for FPGA and CPLDs and flip-flops with constant inputs for CPLDs. This processing increases the fitting success as a result of the logic simplification implied by the flip-flops elimination. Two values are available (**true** and **false** are available in XCF as well):

- **yes** (check box is checked)
Flip-flop optimization is allowed. This is the default.
- **no** (check box is not checked)
Flip-flop optimization is inhibited.

The flip-flop optimization algorithm is time consuming. When fast processing is desired, use **no**.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-III	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

You can apply EQUIVALENT_REGISTER_REMOVAL globally or to an entity, module, or signal.

Propagation Rules

Removes equivalent flip-flops and flip-flops with constant inputs.

Syntax Examples

VHDL

Before using EQUIVALENT_REGISTER_REMOVAL, declare it with the following syntax:

```
attribute shift_extract: string;
```

After declaring EQUIVALENT_REGISTER_REMOVAL, specify the VHDL constraint as follows:

```
attribute equivalent_register_removal of {entity_name|signal_name}:
{signal|entity} is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute equivalent_register_removal [of]
{module_name|signal_name} [is] "yes";
```

XCF

```
MODEL "entity_name" equivalent_register_removal={true|false|yes|no};
```

```
BEGIN MODEL "entity_name"
  NET "signal_name" equivalent_register_removal={true|false|yes|no};
END;
```

XST Command Line

Define globally with the **-equivalent_register_removal** command line option of the **run** command. Following is the basic syntax:

```
-equivalent_register_removal {yes|no}
```

The default is **yes**.

Project Navigator

You can define **Equivalent Register Removal** in the Xilinx Specific Option tab in the Process Properties dialog box within the Project Navigator. The default is **yes** (check box is checked).

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

FSM Encoding Algorithm

The FSM Encoding Algorithm (FSM_ENCODING) constraint selects the finite state machine coding technique to use. The Automatic FSM Extraction option must be enabled in order to select a value for the FSM Encoding Algorithm. Available property values are **auto**, **one-hot**, **compact**, **sequential**, **gray**, **johnson**, **speed1**, and **user**. **FSM_ENCODING** defaults to **auto**, meaning that the best coding technique is automatically selected for each individual state machine.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes

Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

FSM_ENCODING can be applied globally or to a VHDL entity, Verilog module, or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using FSM_ENCODING, declare it with the following syntax:

```
attribute fsm_encoding: string;
```

After declaring FSM_ENCODING, specify the VHDL constraint as follows:

```
attribute fsm_encoding of {entity_name|signal_name}: {entity|signal} is
  " {auto|one-hot|compact|gray|sequential|johnson|speed1|user}";
```

The default is **auto**.

Verilog

Specify as follows:

```
// synthesis attribute fsm_encoding [of] {module_name|signal_name}
  [is] {auto|one-hot|compact|gray|sequential|johnson|speed1|user};
```

The default is **auto**.

XCF

```
MODEL "entity_name" fsm_encoding={auto|one-hot
  |compact|sequential|gray|johnson|speed1|user};
```

```
BEGIN MODEL "entity_name"
  NET "signal_name" fsm_encoding={auto|one-hot
    |compact|sequential|gray|johnson|speed1|user};
END;
```

XST Command Line

Define globally with the **-fsm_encoding** command line option of the **run** command. Following is the basic syntax:

```
-fsm_encoding {Auto|One-Hot|Compact|Sequential|Gray|Johnson|Speed1|User}
```

The default is **auto**.

Project Navigator

In Project Navigator, FSM Encoding is controlled by the **FSM Encoding Algorithm** menu under the HDL Options tab of the Process Properties dialog box. Note that the FSM Encoding Algorithm menu controls both the Automatic FSM Extraction (**-fsm_extract**) option and the FSM Encoding (**-fsm_encoding**) option. Use these options as follows:

- If the FSM Encoding Algorithm menu is set to **None**, and **-fsm_extract** is set to **no** and the **-fsm_encoding** has no influence on the synthesis.
- In all other cases, **-fsm_extract** is set to **yes** and **-fsm_encoding** is set to the value selected in the menu. See “[Automatic FSM Extraction](#)” for more information about **-fsm_extract**.

With a design selected in the Sources window, right-click Synthesize in the Processes window to access the HDL Options tab of the Process Properties dialog box. Select a value from the drop-down list box.

Mux Extraction

The Mux Extract (MUX_EXTRACT) constraint enables or disables multiplexer macro inference. Allowed values are **yes**, **no** and **force** (the values **true** and **false** are also available in XCF).

By default, multiplexer inference is enabled (**yes**). For each identified multiplexer description, based on some internal decision rules, XST actually creates a macro or optimizes it with the rest of the logic. The **force** value overrides those decision rules and forces XST to create the MUX macro.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes

Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

You can apply MUX_EXTRACT globally or to a VHDL entity, a Verilog module, or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using MUX_EXTRACT, declare it with the following syntax:

```
attribute mux_extract: string;
```

After declaring MUX_EXTRACT, specify the VHDL constraint as follows:

```
attribute mux_extract of {signal_name|entity_name}: {entity|signal} is
  " {yes|no|force}";
```

The default value is YES.

Verilog

Specify as follows:

```
// synthesis attribute mux_extract [of] {module_name|signal_name} [is]
  {yes|no|force};
```

The default value is yes.

XCF

```
MODEL "entity_name" mux_extract={yes|no|force|true|false};

BEGIN MODEL "entity_name"
  NET "signal_name" mux_extract={yes|no|force|true|false};
END;
```

XST Command Line

Define globally with the **-mux_extract** command line option of the **run** command. Following is the basic syntax:

```
-mux_extract {yes|no|force}
```

The default value is yes.

Project Navigator

Specify globally with the **Mux Extraction** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Register Power Up

XST will not automatically figure out and enforce register power-up values. You must explicitly specify them if needed with the Register Power Up (REGISTER_POWERUP) constraint. This XST synthesis constraint can be assigned to a VHDL enumerated type, or it may be directly attached to a VHDL signal or a Verilog register node through a VHDL attribute or Verilog meta comment. The constraint value may be a binary string or a symbolic code value.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	No
Virtex-E	No
Spartan-II	No
Spartan-IIIE	No
Spartan-3	No
Spartan-3E	No
Virtex-II	No
Virtex-II Pro	No
Virtex-II Pro X	No
Virtex-4	No
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

Signals and types

Propagation Rules

Applies to the signal or type to which it is attached.

Syntax Examples

VHDL

Following are some examples of REGISTER_POWERUP.

- Example 1

The register is defined with a predefined VHDL type such as std_logic_vector. The constraint value is necessarily a binary code.

```
signal myreg : std_logic_vector (3 downto 0);
attribute register_powerup of myreg : signal is "0001";
```

- Example 2

The register is defined with an enumerated type (symbolic state machine). The constraint is attached to the signal and its value is one of the symbolic states defined. Actual power-up code will differ depending on the way the state machine is encoded.

```
type state_type is (s1, s2, s3, s4, s5);
signal state1 : state_type;
attribute register_powerup of state1 : signal is "s2";
```

- Example 3

The constraint is attached to an enumerated type. All registers defined with that type inherit the constraint.

```
type state_type is (s1, s2, s3, s4, s5);
attribute register_powerup of state_type : type is "s1";
signal state1, state2 : state_type;
```

- Example 4

For enumerated type objects, the power-up value may also be defined as a binary code. However, if automatic encoding is enabled and leads to a different encoding scheme (in particular a different code width), the power-up value will be ignored.

```
type state_type is (s1, s2, s3, s4, s5);
attribute enum_encoding of state_type : type is "001 011 010 100 111";
attribute register_powerup of state_type : type is "100";
signal state1 : state_type;
```

Verilog

```
//synthesis attribute register_powerup [of] {signal_name} [is] value;
```

XCF

```
BEGIN MODEL "entity_name"
  NET "signal_name" register_powerup="string";
END;
```

Resource Sharing

The Resource Sharing (RESOURCE_SHARING) constraint enables or disables resource sharing of arithmetic operators. Allowed values are **yes** (check box is checked) and **no** (check box is not checked). (**true** and **false** values are also available in XCF). By default, resource sharing is enabled.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

You can apply RESOURCE_SHARING globally or to design elements.

Propagation Rules

Applies to the entity or module to which it is attached.

Syntax Examples

VHDL

Before using RESOURCE_SHARING declare it with the following syntax:

```
attribute resource_sharing: string;
```

After declaring RESOURCE_SHARING, specify the VHDL constraint as follows:

```
attribute resource_sharing of entity_name: entity is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute resource_sharing [of] module_name [is] "yes";
```

XCF

```

MODEL "entity_name" resource_sharing={yes|no|true|false};

BEGIN MODEL "entity_name"
    NET "signal_name" resource_sharing={yes|no|true|false};
END;

```

XST Command Line

Define globally with the **-resource_sharing** command line option of the **run** command. Following is the basic syntax:

```
-resource_sharing {yes|no}
```

The default is **yes**.

Project Navigator

Specify globally with the **Resource Sharing** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Recovery State

The Recovery State (SAFE_RECOVERY_STATE) constraint defines a recovery state for use when a finite state machine (FSM) is implemented in Safe Implementation mode. This means that if during its work, the FSM gets into an invalid state, XST generates additional logic to force the FSM to a valid recovery state. By implementing FSM in safe mode, XST collects all code not participating in the normal FSM behavior and considers it as illegal. XST generates logic that returns the FSM synchronously to the known state (reset state, power up state or state specified by the user via SAFE_RECOVERY_STATE constraint). See “[Safe Implementation](#)” for more information.

Architecture Support

The SAFE_RECOVERY_STATE constraint is architecture independent.

Applicable Elements

This constraint can be applied to a signal representing state register.

Propagation Rules

Applies to a signal to which it is attached.

Syntax Examples

VHDL

Before using SAFE_RECOVERY_STATE, declare it with the following syntax:

```
attribute safe_recovery_state: string;
```

After declaring SAFE_RECOVERY_STATE, specify the VHDL constraint as follows:

```
attribute safe_recovery_state of {signal_name}:{signal} is "s1";
```

Verilog

Specify as follows:

```
// synthesis attribute safe_recovery_state [of] {signal_name} [is] "s1"
```

XCF

```
BEGIN MODEL "entity_name"  
    NET "signal_name" safe_recovery_state="s1";  
END;
```

Safe Implementation

The Safe Implementation (SAFE_IMPLEMENTATION) constraint implements finite state machines (FSMs) in Safe Implementation mode. Safe Implementation means that XST generates additional logic that forces an FSM to a valid state (recovery state) if an FSM gets into an invalid state. By default, XST automatically selects *reset* as the recovery state. If the FSM does not have an initialization signal, XST selects *power-up* as the recovery state. The recovery state can be manually defined via the RECOVERY_STATE constraint.

- To activate Safe FSM implementation from Project Navigator, select the Safe Implementation option from the HDL Options tab of the Synthesis Process Properties dialog box in Project Navigator.
- To activate Safe FSM implementation from your HDL code, apply the SAFE_IMPLEMENTATION constraint to the hierarchical block or signal that represents the state register in the FSM.

See “[Recovery State](#)” for more information.

Architecture Support

The SAFE_IMPLEMENTATION constraint is architecture independent.

Applicable Elements

This constraint can be applied to an entire design via an XST command line, to a particular block (entity, architecture, component), and to a signal.

Propagation Rules

Applies to an entity, component, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using SAFE_IMPLEMENTATION, declare it with the following syntax:

```
attribute safe_implementation: string;
```

After declaring SAFE_IMPLEMENTATION, specify the VHDL constraint as follows:

```
attribute safe_implementation of
{entity_name|component_name|signal_name}: {entity|component|signal} is
"yes";
```

Verilog

Specify as follows:

```
// synthesis attribute safe_implementation [of]
{module_name|signal_name} [is] "yes";
```

XCF

```
MODEL "entity_name" safe_implementation={yes|no|true|false};
BEGIN MODEL "entity_name"
NET "signal_name" safe_implementation={yes|no|true|false};
END;
```

XST Command Line

Define globally with the **-safe_implementation** command line option of the **run** command. Following is the basic syntax:

```
-safe_implementation {yes|no}
```

The default is **no**.

Project Navigator

Specify globally with the **Safe Implementation** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Signal Encoding

The Signal Encoding (SIGNAL_ENCODING) constraint selects the coding technique to use for internal signals. Available property values are auto, one-hot, and user. Selecting "one-hot" forces the encoding to a one-hot encoding, and "user" forces XST to keep the user's encoding. SIGNAL_ENCODING defaults to auto, meaning that the best coding technique is automatically selected for each individual signal.

Architecture Support

The following table indicates supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

SIGNAL_ENCODING can be applied globally or to a VHDL entity, Verilog module, or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using SIGNAL_ENCODING, declare it with the following syntax:

```
attribute SIGNAL_ENCODING: string;
```

After declaring SIGNAL_ENCODING, specify the VHDL constraint as follows:

```
attribute SIGNAL_ENCODING of
{component_name|signal_name|entity_name|label_name}:
{component|signal|entity|label} is "{auto|one-hot|user}";
```

The default is **auto**.

Verilog

Specify as follows:

```
// synthesis attribute SIGNAL_ENCODING [of]
{module_name|instance_name|signal_name} [is] {auto|one-hot|user};
```

The default is **auto**.

XCF

```
MODEL "entity_name" SIGNAL_ENCODING = {auto|one-hot|user};
```

```
BEGIN MODEL "entity_name"
NET "net_name" SIGNAL_ENCODING = {auto|one-hot|user};
END;
```

XST Command Line

Define globally with the **-signal_encoding** command line option of the **run** command. Following is the basic syntax:

```
-signal_encoding {auto|one-hot|user}
```

The default is **auto**

FPGA Constraints (non-timing)

This section describes FPGA HDL options. These options apply only to FPGAs—not CPLDs.

Note: Please note that in many cases, a particular constraint can be applied globally to an entire entity or model, or alternatively, it can be applied locally to individual signals, nets or instances. See [Table 5-1](#) for valid constraint targets.

Buffer Type

Buffer Type (BUFFER_TYPE) is a new name for the CLOCK_BUFFER constraint. Since CLOCK_BUFFER will become obsolete in future releases, Xilinx strongly suggest that you use this new name. This constraint selects the type of buffer to be inserted on the input port or internal net.

Note: Please note that **bufx** value is supported for Virtex-4 devices only.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes

Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Signals

Propagation Rules

Applies to the signal to which it is attached.

Syntax Examples

VHDL

Before using BUFFER_TYPE, declare it with the following syntax:

```
attribute buffer_type: string;
```

After declaring BUFFER_TYPE, specify the VHDL constraint as follows:

```
attribute buffer_type of signal_name: signal is
  "bufgDLL|ibufg|bufgp|ibuf|bufr|none";
```

Verilog

Specify BUFFER_TYPE as follows:

```
// synthesis attribute buffer_type [of] signal_name [is]
  {bufgDLL|ibufg|bufgp|ibuf|bufr|none};
```

XCF

```
BEGIN MODEL "entity_name"
  NET "signal_name"  buffer_type={bufgDLL|ibufg|bufgp|ibuf|bufr|none};
END;
```

BUFGCE

The BUFGCE constraint implements BUFGMUX functionality by inferring a BUFGMUX primitive. This operation reduces the wiring: clock and clock enable signals are driven to n sequential components by a single wire.

This constraint must be attached to the primary clock signal and may have two values: **yes** and **no**. This constraint is accessible through HDL code. If **bufgce=yes**, then XST will implement BUFGMUX functionality if possible (all flip-flops must have the same clock enable signal).

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	No
Virtex-E	No
Spartan-II	No
Spartan-IIIE	No
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Clock signals.

Propagation Rules

Applies to the signal to which it is attached.

Syntax Examples

VHDL

Before using BUFGCE, declare it with the following syntax:

```
attribute bufgce : string;
```

After declaring BUFGCE, specify the VHDL constraint as follows:

```
attribute bufgce of signal_name: signal is "{yes(no)}";
```

Verilog

Specify BUFGCE as follows:

```
// synthesis attribute bufgce [of] signal_name [is] yes
```

XCF

```
BEGIN MODEL "entity_name"  
    NET "primary_clock_signal"  
    bufgce={yes|no|true|false};  
END;
```

Cores Search Directories

The Cores Search Directories command line switch (`-sd`) tells XST to look for cores in directories other than the default one (by default XST searches for cores in the directory specified in the `-ifn` switch).

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Can be applied globally to an entire design.

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define this option globally with the **-sd** command line option of the **xrun** command. Allowed values are names of directories. Please refer to “[Names with Spaces](#)” in Chapter 10 for more information.

```
-sd {directory_path [directory_path]}
```

There is no default.

Project Navigator

Specify globally with the **Cores Search Directory** option in the Synthesis Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Decoder Extraction

The Decoder Extraction (DECODER_EXTRACT) constraint enables or disables decoder macro inference.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Can be applied globally or to an entity, module or signal.

Propagation Rules

Following is a list of propagation rules.

- When attached to a net or signal, DECODER_EXTRACT applies to the attached signal.
- When attached to an entity or module, DECODER_EXTRACT is propagated to all applicable elements in the hierarchy within the entity or module.

Syntax Examples

VHDL

Before using DECODER_EXTRACT, declare it with the following syntax:

```
attribute decoder_extract: string;
```

After declaring DECODER_EXTRACT, specify the VHDL constraint as follows:

```
attribute decoder_extract of {entity_name|signal_name} :  
{entity|signal} is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute decoder_extract [of] {module_name|signal_name}  
[is] "yes";
```

XCF

```
MODEL "entity_name" decoder_extract={yes|no|true|false};  
  
BEGIN MODEL "entity_name"  
NET "signal_name" decoder_extract={yes|no|true|false};  
END;
```

XST Command Line

Define DECODER_EXTRACT globally with the **-decoder_extract** command line option of the **run** command. Following is the basic syntax:

```
-decoder_extract {yes|no}
```

The default is **yes**.

Project Navigator

Defined globally with the **Decoder Extraction** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator. Allowed values are **yes** (check box is checked) and **no** (check box is not checked). By default, decoder inference is enabled (check box is checked).

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

DSP Utilization Ratio

The DSP Utilization Ratio (DSP_UTILIZATION_RATIO) constraint defines the number of DSP slices (in absolute number or percent of slices) that XST must not exceed during synthesis optimization. The default value is 100% of the target device.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	No
Virtex-E	No
Spartan-II	No
Spartan-IIIE	No
Spartan-3	No
Spartan-3E	No
Virtex-II	No
Virtex-II Pro	No
Virtex-II Pro X	No
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Can be applied globally to an entire design.

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define this option globally with the **-dsp_utilization_ratio** command line option of the **run** command.

Following is the basic syntax:

```
-dsp_utilization_ratio number[% | #]
```

To specify a percent of total slices use %. To specify an absolute number of slices use #. The default is %. For example:

- To specify 50% of DSP blocks of the target device enter the following.
`-dsp_utilization_ratio 50`
- To specify 50% of DSP blocks of the target device enter the following.
`-dsp_utilization_ratio 50%`
- To specify 50 of DSP blocks enter the following.
`-dsp_utilization_ratio 50#`

Project Navigator

Specify globally by selecting the **DSP Utilization Ratio** option under the Synthesis Options tab in the Process Properties dialog box. In Project Navigator, you can only define the value of this option as a percentage value. The definition of the value in the form of absolute number of slices is not supported.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

FSM Style

The FSM Style constraint (FSM_STYLE) can be used to make large FSMs more compact and faster by implementing them in the block RAM resources provided in Virtex™ and later technologies. You can direct XST to use block RAM resources rather than LUTs (the default) to implement FSMs by using the FSM_STYLE design constraint. This is both a global and a local constraint.

Architecture Support

The following table lists supported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Can be applied globally or to a VHDL entity, Verilog module, or signal

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using FSM_STYLE, declare it with the following syntax:

```
attribute fsm_style: string;
```

After declaring FSM_STYLE, specify the VHDL constraint as follows:

```
attribute fsm_style of {entity_name|signal_name}: {entity|signal} is  

"{lut|bram}";
```

The default is **lut**.

Verilog

Specify as follows:

```
// synthesis attribute FSM_STYLE [of]  

{module_name|instance_name|signal_name} [is] {lut|bram};
```

UCF

The basic UCF syntax is:

```
INST "instance_name" FSM_STYLE={lut|bram};
```

XCF

```
MODEL "entity_name" FSM_STYLE = {lut|bram};
```

```
BEGIN MODEL "entity_name"  

INST "instance_name" FSM_STYLE = {lut|bram};  

NET "net_name" FSM_STYLE = {lut|bram};  

END;
```

Project Navigator

Define globally with the **FSM Style** option in the Synthesis Options tab of the Process Properties dialog box.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Resynthesize

The RESYNTHESIZE constraint is related to Incremental Synthesis Flow. It forces or prevents resynthesis of groups created via the INCREMENTAL_SYNTHESIS constraint. See “[Incremental Synthesis](#)” for more information. Allowed values are **yes** and **no** (the values **true** and **false** are available in XCF also). No global option is available.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

RESYNTHESIZE can be only applied to design elements.

Propagation Rules

Applies to the entity or module to which it is attached.

Syntax Examples

VHDL

Before using RESYNTHESIZE declare it with the following syntax:

```
attribute resynthesize: string;
```

After declaring RESYNTHESIZE, specify the VHDL constraint as follows:

```
attribute resynthesize of entity_name: entity is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute resynthesize [of] module_name [is] "yes";
```

XCF

```
MODEL "entity_name" resynthesize={true|false|yes|no};
```

Incremental Synthesis

The Incremental Synthesis (INCREMENTAL_SYNTHESIS) constraint controls the decomposition of a design into several subgroups. This can be applied on a VHDL entity or Verilog module so that XST generates a single and separate NGC file for it and its descendants. See the “[Incremental Synthesis Flow](#)” in Chapter 3, for more information.

Note: The INCREMENTAL_SYNTHESIS switch is not accessible via the Synthesize - XST Process Properties dialog box. This directive is only available via VHDL attributes or Verilog meta comments, or via an XST constraint file.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

INCREMENTAL_SYNTHESIS can be applied globally or to a VHDL entity or Verilog module.

Propagation Rules

Applies to the entity or module to which it is attached.

Syntax Examples

VHDL

Before using INCREMENTAL_SYNTHESIS, declare it with the following syntax:

```
attribute incremental_synthesis: string;
```

After declaring INCREMENTAL_SYNTHESIS, specify the VHDL constraint as follows:

```
attribute incremental_synthesis of entity_name: entity is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute incremental_synthesis [of] module_name [is]
"yes";
```

XCF

```
MODEL "entity_name" incremental_synthesis={yes|no|true|false};
```

Keep Hierarchy

The Keep Hierarchy (KEEP_HIERARCHY) constraint is a synthesis and implementation constraint. If hierarchy is maintained during Synthesis, the Implementation tools will use this constraint to preserve the hierarchy throughout the implementation process and allow a simulation netlist to be created with the desired hierarchy.

XST can flatten the design to get better results by optimizing entity/module boundaries. You can set KEEP_HIERARCHY to **true** so that the generated netlist is hierarchical and respects the hierarchy and interface of any entity or module of your design.


This option is related to the hierarchical blocks (VHDL entities, Verilog modules) specified in the HDL design and does not concern the macros inferred by the HDL synthesizer. Three values are available for this option:

- **true**: allows the preservation of the design hierarchy, as described in the HDL project. If this value is applied to synthesis, it will also be propagated to implementation.
- **false**: hierarchical blocks are merged in the top level module.
- **soft**: allows the preservation of the design hierarchy in synthesis, but the KEEP_HIERARCHY constraint is not propagated to implementation.

For CPLDs, the default is **true**. For FPGAs, the default is **false**.

In general, an HDL design is a collection of hierarchical blocks, and preserving the hierarchy gives the advantage of fast processing because the optimization is done on separate pieces of reduced complexity. Nevertheless, very often, merging the hierarchy blocks improves the fitting results (fewer PTerms and device macrocells, better frequency) because the optimization processes (collapsing, factorization) are applied globally on the entire logic.

In the following figure, if KEEP_HIERARCHY is set to the entity or module I2, the hierarchy of I2 will be in the final netlist, but its contents I4, I5 will be flattened inside I2. Also I1, I3, I6, I7 will be flattened.



X9542

Figure 5-7: **KEEP_HIERARCHY EXAMPLE**

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-III	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner-II	Yes

Applicable Elements

KEEP_HIERARCHY is attached to logical blocks, including blocks of hierarchy or symbols.

Propagation Rules

Applies to the entity or module to which it is attached.

Syntax Examples

Schematic

Attach to the entity or module symbol.

Attribute Name—KEEP_HIERARCHY

Attribute Values—TRUE, FALSE

VHDL

Before using KEEP_HIERARCHY, declare it with the following syntax:

```
attribute keep_hierarchy : string;
```

After declaring KEEP_HIERARCHY, specify the VHDL constraint as follows:

```
attribute keep_hierarchy of architecture_name: architecture is
  true|false|soft;
```

The default is **false** for FPGAs and **true** for CPLDs.

Verilog

Specify as follows:

```
// synthesis attribute keep_hierarchy [of] module_name [is]
{true|false|soft};
```

UCF

For instances:

```
INST "instance_name" KEEP_HIERARCHY={true|false|soft};
```

XCF

```
MODEL "entity_name" keep_hierarchy={true|false|soft};
```

XST Command Line

Define globally with the **-keep_hierarchy** command line option of the **run** command. Following is the basic syntax:

```
-keep_hierarchy {true|false|soft}
```

The default is **false** for FPGAs and **true** for CPLDs.

See [Chapter 10, “Command Line Mode,”](#) for more information.

Project Navigator

Specify globally with the **Keep Hierarchy** option in the Synthesis Options tab of the Process Properties dialog box within the Project Navigator. With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the Process Properties dialog box.

Logical Shifter Extraction

The Logical Shifter Extraction (SHIFT_EXTRACT) constraint enables or disables logical shifter macro inference. Allowed values are **yes** (check box is checked) and **no** (check box is not checked). The values **true** and **false** are available in XCF also. By default, logical shifter inference is enabled (**yes**).

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

You can apply SHIFT_EXTRACT globally or to design elements and nets.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using SHIFT_EXTRACT declare it with the following syntax:

```
attribute shift_extract: string;
```

After declaring SHIFT_EXTRACT, specify the VHDL constraint as follows:

```
attribute shift_extract of {entity_name|signal_name}: {signal|entity}
is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute shift_extract [of] {module_name|signal_name}
[is] "yes";
```

XCF

```
MODEL "entity_name" shift_extract={yes|no|true|false};

BEGIN MODEL "entity_name"
  NET "signal_name" shift_extract={yes|no|true|false};
END;
```

XST Command Line

Define globally with the **-shift_extract** command line option of the **run** command. Following is the basic syntax:

```
-shift_extract {yes|no}
```

The default is **yes**.

Project Navigator

Specify globally with the **Logical Shifter Extraction** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Map Logic on BRAM

The Map Logic on BRAM (BRAM_MAP) constraint is used to map an entire hierarchical block on the block RAM resources available in Virtex and later technologies. The values are **yes** and **no**, with **no** being the default. This is both a global and a local constraint. See “[Mapping Logic onto Block RAM](#)” in Chapter 3, for more information.

BRAM_MAP Architecture Support

The following table lists supported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

BRAM_MAP Applicable Elements

BRAMs

BRAM_MAP Propagation Rules

You must isolate the logic (including output register) to be mapped on ram in a separate hierarchical level. The logic must fit on a single block RAM, otherwise it will not be mapped. Ensure that the whole entity fits, not just part of it.

The attribute BRAM_MAP is set on the instance or entity. If no block RAM can be inferred, the logic is passed on to Global Optimization where it will be optimized. The macros *will not* be inferred. Check to be sure that XST has mapped the logic.

BRAM_MAP Syntax Examples

VHDL

Before using BRAM_MAP, declare it with the following syntax:

```
attribute BRAM_MAP: string;
```

After declaring BRAM_MAP, specify the VHDL constraint as follows:

```
attribute BRAM_MAP of component_name: component is
" {yes|no|true|false}";
```

Verilog

Specify as follows:

```
// synthesis attribute BRAM_MAP [of] module_name [is]
{yes|no|true|false};
```

XCF

```
MODEL "entity_name" BRAM_MAP = {yes|no|true|false};

BEGIN MODEL "entity_name"
INST "instance_name" BRAM_MAP = {yes|no|true|false};
END;
```

Max Fanout

The Max Fanout (MAX_FANOUT) constraint limits the fanout of nets or signals. The constraint value is an integer, and the default is 100 for Virtex, Virtex-E, Spartan-II, and Spartan-IIE; and 500 for Spartan-3, Virtex-II, Virtex-II Pro, Virtex-II Pro X, and Virtex-4. It is both a global and a local constraint.

Large fanouts can cause routability problems, therefore XST tries to limit fanout by duplicating gates or by inserting buffers. This limit is not a technology limit but a guide to XST. It may happen that this limit is not exactly respected, especially when this limit is small (below 30).

In most cases, fanout control is performed by duplicating the gate driving the net with a large fanout. If the duplication cannot be performed, then buffers will be inserted. These buffers will be protected against logic trimming at the implementation level by defining a KEEP attribute in the NGC file.

If the register replication option is set to **no**, only buffers are used to control fanout of flip-flops and latches.

MAX_FANOUT is global for the design, but you can control maximum fanout independently for each entity or module or for given individual signals by using constraints.

If the actual net fanout is less than MAX_FANOUT value, then XST behavior depends on the way the MAX_FANOUT is specified.

- If MAX_FANOUT value is set via Project Navigator, in command line or attached to a specific hierarchical block, then XST interprets its value as a guidance.
- If MAX_FANOUT is attached to a specific net, then XST does not perform logic replication. Please note that putting MAX_FANOUT on the net may prevent XST from having better timing optimization.

For example, suppose that the critical path goes through the net, which actual fanout is 80 and set MAX_FANOUT value to 100. If MAX_FANOUT is specified via Project Navigator, then XST may replicate it, trying to improve timing. If MAX_FANOUT is attached to the net itself, then XST will not perform logic replication.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

You can apply MAX_FANOUT globally or to a VHDL entity, a Verilog module, or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using MAX_FANOUT, declare it with the following syntax:

```
attribute MAX_FANOUT: string;
```

After declaring MAX_FANOUT, specify the VHDL constraint as follows:

```
attribute MAX_FANOUT of {signal_name|entity_name}: {signal|entity} is
"integer";
```

Verilog

Specify as follows:

```
// synthesis attribute MAX_FANOUT [of] {signal_name/module_name} [is]
integer;
```

XCF

```
MODEL "entity_name" max_fanout=integer;  
  
BEGIN MODEL "entity_name"  
    NET "signal_name" max_fanout=integer;  
END;
```

XST Command Line

Define globally with the **-max_fanout** command line option of the **run** command. Following is the basic syntax:

```
-max_fanout integer
```

The default value of integer is 100 for Virtex /E, Spartan-II/IIE. It is 500 for Spartan-3, Virtex-II/II Pro/II Pro X/4.

Project Navigator

Set globally with the **Max Fanout** option in the Xilinx Specific Options tab in Process Properties dialog box within the Project Navigator.


With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Move Last Stage

The Move Last Stage (MOVE_LAST_STAGE) constraint controls the retiming of registers with paths going to primary outputs. The Move Last Stage (MOVE_LAST_STAGE) constraint, as well as MOVE_FIRST_STAGE constraint, relates to the Register Balancing process.

Definitions:

- A flip-flop (FF in the diagram) belongs to the First Stage if it is on the paths coming from primary inputs.
- A flip-flop belongs to the Last Stage if it is on the paths going to primary outputs.



X9564

During the register balancing process flip-flops belonging to the First Stage will be moved forward and flip-flops, belonging to the last stage will be moved backward. This process can dramatically increase input-to-clock and clock-to-output timing, which is not desirable. To prevent this, you may use OFFSET_IN_BEFORE and OFFSET_IN_AFTER constraints.

In the case:

- The design does not have a strong requirements, or
- You would like to see the first results without touching the first and last flip-flop stages

Two additional constraints can be used: MOVE_FIRST_STAGE and MOVE_LAST_STAGE. Both constraints may have two values: **yes** and **no**.

- MOVE_FIRST_STAGE=no will prevent the first flip-flop stage from moving.
- MOVE_LAST_STAGE=no will prevent the last flip-flop stage from moving.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes

Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

These two constraints can be applied only to the following:

- entire design
- single modules or entities
- primary clock signal

Propagation Rules

See “[Move Last Stage](#)” description for details.

Syntax Examples

VHDL

Before using MOVE_LAST_STAGE, declare it with the following syntax:

```
attribute move_last_stage : string;
```

After declaring MOVE_LAST_STAGE, specify the VHDL constraint as follows:

```
attribute move_last_stage of {entity_name|signal_name} :
{signal|entity} is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute move_last_stage [of] {module_name|signal_name}
[is] yes;
```

XCF

```
MODEL "entity_name" move_last_stage={{yes|no|true|false}};
```

```
BEGIN MODEL "entity_name"
  NET "primary_clock_signal"  move_last_stage={yes|no|true|false};
END;
```

XST Command Line

Define globally with the **-move_last_stage** command line option of the **run** command. Following is the basic syntax:

```
-move_last_stage {yes|no}
```

The default is **yes**.

Project Navigator

Specify **Move Last Flip-Flop Stage** this option in the Xilinx Specific Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Move First Stage

The Move First Stage (MOVE_FIRST_STAGE) constraint controls the retiming of registers with paths coming from primary inputs. See “[Move Last Stage](#)” for details.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

These two constraints can be applied only to the following:

- entire design
- single modules or entities
- primary clock signal

Propagation Rules

See “[Move Last Stage](#)” definition for details.

Syntax Examples

VHDL

Before using MOVE_FIRST_STAGE, declare it with the following syntax:

```
attribute move_first_stage : string;
```

After declaring MOVE_FIRST_STAGE, specify the VHDL constraint as follows:

```
attribute move_first_stage of {entity_name|signal_name} :  
{signal|entity} is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute move_first_stage [of] {module_name|signal_name}  
[is] yes;
```

XCF

```
MODEL "entity_name" move_first_stage={yes|no|true|false};  
  
BEGIN MODEL "entity_name"  
NET "primary_clock_signal" move_first_stage={yes|no|true|false};  
END;
```

XST Command Line

Define globally with the **-move_first_stage** command line option of the **run** command. Following is the basic syntax:

```
-move_first_stage {yes|no}
```

The default is **yes**.

Project Navigator

Set with the **Move First Flip-Flop Stage** option in the Xilinx Specific Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Multiplier Style

The Multiplier Style (MULT_STYLE) constraint controls the way the macrogenerator implements the multiplier macros. Allowed values are **auto**, **block**, **lut**, **pipe_block**, **kcm**, **csd**, and **pipe_lut**. Please note that **pipe_block** value is supported for Virtex-4 devices only. For Virtex, Virtex-E, Spartan-II, and Spartan-IIIE, the default is **lut**, meaning that XST looks for the best implementation for each considered macro. For Virtex-II, Virtex-II Pro, Virtex-II Pro X, and Virtex-4, the default is **auto**.

The **pipe_lut** option is for pipeline slice-based multipliers. The implementation style can be manually forced to use block multiplier or LUT resources available in Virtex-II, Virtex-II Pro, Virtex-II Pro X, and Virtex-4 devices.

The pipe_block option is to pipeline DSP48 based multipliers and available for Virtex-4 family only.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	No
Virtex-E	No
Spartan-II	No
Spartan-IIIE	No
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Can be applied globally or to a VHDL entity, a Verilog module, or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using MULT_STYLE, declare it with the following syntax:

```
attribute mult_style: string;
```

After declaring MULT_STYLE, specify the VHDL constraint as follows:

```
attribute mult_style of {signal_name|entity_name}: {signal|entity} is
"auto|block|lut|pipe_lut|pipe_block|csd|kcm";
```

For Virtex, Virtex-E, Spartan-II, and Spartan-IIIE, the default is **lut**. For Virtex-II, Virtex-II Pro, Virtex-II Pro X, Virtex-4, and Spartan-3, the default is **auto**.

Verilog

Specify as follows:

```
// synthesis attribute mult_style [of] {module_name|signal_name} [is]
{auto|block|lut|pipe_lut|pipe_block|csd|kcm};
```

For Virtex, Virtex-E, Spartan-II, and Spartan-IIIE, the default is **lut**. For Virtex-II, Virtex-II Pro, Virtex-II Pro X, Virtex-4, and Spartan-3, the default is **auto**.

XCF

```
MODEL "entity_name"
mult_style={auto|block|lut|pipe_lut|pipe_block|csd|kcm};
```

```
BEGIN MODEL "entity_name"
  NET "signal_name"
  mult_style={auto|block|lut|pipe_lut|pipe_block|csd|kcm};
END;
```

XST Command Line

Define globally with the **-mult_style** command line option of the **run** command. Following is the basic syntax:

```
-mult_style {auto|block|lut|pipe_lut|pipe_block|kcm}
```

For Virtex, Virtex-E, Spartan-II, and Spartan-IIIE, the default is **lut**. For Virtex-II, Virtex-II Pro, Virtex-II Pro X, Virtex-4, and Spartan-3, the default is **auto**.

Project Navigator

Set globally with the **Multiplier Style** property in the HDL Options tab of the Process Properties dialog box in Project Navigator.

With a source file selected in the Sources in Project window, right-click **Synthesize** in the Processes for Source window to access the appropriate Process Properties dialog box.

Mux Style

The Mux Style (MUX_STYLE) constraint controls the way the macrogenerator implements the multiplexer macros. Allowed values are auto, muxf and muxcy. The default value is **auto**, meaning that XST looks for the best implementation for each considered macro. Available implementation styles for the Virtex, Virtex-E, and Spartan-II, Spartan-IIIE series are based on either MUXF5 and MUXF6 resources, or MUXCY resources. In addition, Spartan-3, Virtex-II, Virtex-II Pro, Virtex-II Pro X, and Virtex-4 can use MUXF7, and MUXF8 resources as well.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes

Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Can be applied globally or to a VHDL entity, a Verilog module, or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Examples

VHDL

Before using MUX_STYLE, declare it with the following syntax:

```
attribute mux_style: string;
```

After declaring MUX_STYLE, specify the VHDL constraint as follows:

```
attribute mux_style of {signal_name|entity_name}: {signal|entity} is
  " {auto|muxf|muxcy}";
```

The default value is **auto**.

Verilog

Specify as follows:

```
// synthesis attribute mux_style [of] {module_name|signal_name} [is]
  {auto|muxf|muxcy};
```

The default value is **auto**.

XCF

```
MODEL "entity_name" mux_style={auto|muxf|muxcy};
```

```
BEGIN MODEL "entity_name"
  NET "signal_name" mux_style={auto|muxf|muxcy};
END;
```

XST Command Line

Define globally with the **-mux_style** command line option of the **run** command. Following is the basic syntax:

```
-mux_style {auto|muxf|muxcy}
```

The default is **auto**.

Project Navigator

Set globally with the **Mux Style** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Number of Global Clock Buffers

The Number of Global Clock Buffers (-bufg) constraint controls the maximum number of BUFGs created by XST. The constraint value is an integer. The default value depends on the target family and is equal to the maximum number of available BUFGs.

Architecture Support

The following table indicates supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIE	Yes
Spartan-3	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No
CoolRunner-IIS	No

Applicable Elements

Global only

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define this option globally with the **-bufg** command line option of the **run** command. Following is the basic syntax:

```
-bufg integer
```

The constraint value is an *integer* and the default values are different for different architectures. The defaults for selected architectures are: 4 for Virtex, Virtex-E, Spartan™-II, Spartan-IIIE; 8 for Spartan-3; 16 for Virtex-II, Virtex-II Pro, Virtex-II Pro X; and 32 for Virtex-4. The number of BUFGs cannot exceed the maximum number of BUFGs for the target device.

Project Navigator

Specify globally by selecting the **Number of Clock Buffers** option under the Xilinx Specific Options tab in the Process Properties dialog box.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Number of Regional Clock Buffers

The Number of Regional Clock Buffers (**-bufr**) constraint controls the maximum number of BUFRs created by XST. The constraint value is an integer. The default value depends on the target family and is equal to the maximum number of available BUFRs.

Architecture Support

The following table indicates supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No
CoolRunner-IIS	No

Applicable Elements

Global only

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define this option globally with the **-bufnr** command line option of the **run** command.

Following is the basic syntax:

```
-bufnr integer
```

This constraint is available for Virtex-4 devices only. The constraint value is an integer and the default value is different for each Virtex-4 device.

The number of BUFRs cannot exceed the maximum number of BUFRs for the target device.

Project Navigator

Specify globally by selecting the **Number of Regional Clock Buffers** option under the Xilinx Specific Options tab in the Process Properties dialog box.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Optimize Instantiated Primitives

By default, XST does not optimize instantiated primitives in HDL code. The Optimize Instantiated Primitives (OPTIMIZE_PRIMITIVES) constraint is used to deactivate the default. This constraint allows XST to optimize Xilinx library primitives that have been instantiated in HDL.

Architecture Support

The following table lists supported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes

Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Hierarchical blocks, components, and instances.

Propagation Rules

Applies to the component or instance to which it is attached.

Syntax Examples

Schematic

Attach to a valid instance.

Attribute Name—OPTIMIZE_PRIMITIVES

Attribute Value—YES and NO (Default)

VHDL

Before using OPTIMIZE_PRIMITIVES, declare it with the following syntax:

```
attribute OPTIMIZE_PRIMITIVES: string;
```

After declaring OPTIMIZE_PRIMITIVES, specify the VHDL constraint as follows:

```
attribute OPTIMIZE_PRIMITIVES of
{component_name|entity_name|label_name}: {component|entity|label} is
" {yes|no}";
```

Verilog

Specify as follows:

```
// synthesis attribute OPTIMIZE_PRIMITIVES [of]
{module_name|instance_name|signal_name} [is] {yes|no};
```

UCF

The basic UCF syntax is:

```
INST "instance_name" OPTIMIZE_PRIMITIVES={yes|no};
```

XCF

```
MODEL "entity_name" OPTIMIZE_PRIMITIVES = {yes|no};
```

Project Navigator

Set globally with the **Optimize Instantiated Primitives** property in the Xilinx Specific Options tab of the Process Properties dialog box within the Project Navigator.

With a source file selected in the Sources in Project window, right-click **Synthesize** in the Processes for Source window to access the appropriate Process Properties dialog box.

Pack I/O Registers into IOBs

The Pack I/O Registers into IOBs (IOB) constraint packs flip-flops in the I/Os to improve input/output path timing. See “**IOB**” in the *Constraints Guide* for details.

Priority Encoder Extraction

The Priority Encoder Extraction (PRIORITY_EXTRACT) constraint enables or disables priority encoder macro inference. Allowed values are **yes**, **no** and **force**. (**true** and **false** ones are available in XCF as well).

By default, priority encoder inference is enabled (**yes**). For each identified priority encoder description, based on some internal decision rules, XST will actually create a macro or optimize it with the rest of the logic. The **force** value allows to override those decision rules and force XST to extract the macro.

Priority encoder rules are currently very restrictive. Based on architectural considerations, the **force** value will allow you to override these rules and potentially improve the quality of your results.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Apply globally or to an entity, module, or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using PRIORITY_EXTRACT, declare it with the following syntax:

```
attribute priority_extract: string;
```

After declaring PRIORITY_EXTRACT, specify the VHDL constraint as follows:

```
attribute priority_extract of {signal_name|entity_name} :  
{signal|entity} is "{yes|no|force}";
```

The default value is **yes**.

Verilog

Specify as follows:

```
// synthesis attribute priority_extract [of] {module_name|signal_name}  
[is] {yes|no|force};
```

XCF

```
MODEL "entity_name" priority_extract={yes|no|force|true|false};
```

```
BEGIN MODEL "entity_name"  
NET "signal_name" priority_extract={yes|no|force|true|false};  
END;
```

XST Command Line

Define globally with the **-priority_extract** command line option of the **run** command. Following is the basic syntax:

```
-priority_extract {yes|no|force}
```

The default is **yes**.

Project Navigator

Set globally with the **Priority Encoder Extraction** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

RAM Extraction

The RAM Extraction (RAM_EXTRACT) constraint enable or disables RAM macro inference. Allowed values are **yes** and **no**. The values **true** and **false** are also available in XCF. By default, RAM inference is enabled (**yes**).

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Apply globally, or to an entity, module, or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using RAM_EXTRACT, declare it with the following syntax:

```
attribute ram_extract: string;
```

After declaring RAM_EXTRACT, specify the VHDL constraint as follows:

```
attribute ram_extract of {signal_name|entity_name}: {signal|entity} is
"yes";
```

Verilog

Specify as follows:

```
// synthesis attribute ram_extract [of] {module_name|signal_name} [is]
yes;
```

XCF

```

MODEL "entity_name" ram_extract={true|false|yes|no};

BEGIN MODEL "entity_name"
NET "signal_name" ram_extract={true|false|yes|no};
END;

```

XST Command Line

Define globally with the **-ram_extract** command line option of the **run** command. Following is the basic syntax:

```
-ram_extract {yes|no}
```

The default is **yes**.

Project Navigator

Set globally with the **RAM Extraction** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

RAM Style

The RAM Style (RAM_STYLE) constraint controls the way the macrogenerator implements the inferred RAM macros. Allowed values are **auto**, **block** and **distributed** and **pipe_distributed**. The default value is **auto**, meaning that XST looks for the best implementation for each inferred RAM. The implementation style can be manually forced to use block RAM or distributed RAM resources available in the Virtex and Spartan-II series.

Note: You can only specify the **pipe_distributed** value through VHDL/Verilog or XCF constraints.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes

Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Apply globally or to an entity, module, or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using RAM_STYLE, declare it with the following syntax:

```
attribute ram_style: string;
```

After declaring RAM_STYLE, specify the VHDL constraint as follows:

```
attribute ram_style of {signal_name|entity_name}: {signal|entity} is
  "auto|block|distributed|pipe_distributed";
```

The default value is **auto**.

Verilog

Specify as follows:

```
// synthesis attribute ram_style [of] {module_name|signal_name} [is]
  {auto|block|distributed|pipe_distributed};
```

The default value is **auto**.

XCF

```
MODEL "entity_name"
ram_style={auto|block|distributed|pipe_distributed};
```

```
BEGIN MODEL "entity_name"
  NET "signal_name"
    ram_style={auto|block|distributed|pipe_distributed};
END;
```

XST Command Line

Define globally with the **-ram_style** command line option of the **run** command. Following is the basic syntax:

```
-ram_style {auto|distributed|block}
```

The default is **auto**.

Note: The **pipe_distributed** value is not accessible via command line.

Project Navigator

Set globally with the **RAM Style** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Register Balancing

The Register Balancing (REGISTER_BALANCING) constraint enables flip-flop retiming. The main goal of register balancing is to move flip-flops and latches across logic to increase clock frequency. There are two categories of register balancing:

- Forward Register Balancing will move a set of flip-flops that are at the inputs of a LUT to a single flip-flop at its output.




Figure 5-8: Forward Register Balancing

- Backward Register Balancing will move a flip-flop which is at the output of a LUT to a set of flip-flops at its inputs.




Figure 5-9: Backward Register Balancing

As a consequence the number of flip-flops in the design can be increased or decreased.

This constraint may have the following values: **yes**, **no**, **forward**, and **backward**. The values **true** and **false** ones are also available in XCF. The default is **no**, meaning that XST will not perform flip-flop retiming. **Yes** means that both forward and backward retiming are possible. **Forward** means that only forward retiming is allowed, while **backward** means that only backward retiming is allowed.

This constraint can be applied:

- Globally to the entire design via command line or GUI
- To an entity or module
- To a signal corresponding to the flip-flop description (RTL)
- Flip-flop instance
- Primary Clock Signal. In this case the register balancing will be performed only for flip-flops synchronized by this clock.

There are two additional constraints, called **Move First Stage** and **Move Last Stage**, that control the register balancing process.

Several constraints have their influence on the register balancing process:

- Hierarchy Treatment
 - ◆ If the hierarchy is preserved, then flip-flops will be moved only inside the block boundaries.
 - ◆ If the hierarchy is flattened, then flip-flops may leave the block boundaries.
- IOB=TRUE

Register Balancing will be not applied to the flip-flops having this property.
- KEEP

If applied to the output flip-flop signal, then the flip-flop will not be moved forward.




Figure 5-10: Applied to the Output Flip-Flop Signal

- If applied to the input flip-flop signal, then the flip-flop will not be moved backward.




Figure 5-11: Applied to the Input Flip-Flop Signal

- If applied to both the input and output of the flip-flop, it is equivalent to **REGISTER_BALANCING=no**.
- When moving flip-flops, XST applies the following naming conventions:
 - ◆ Backward Register Balancing—The new flip-flop will have the same name as the original flip-flop with an indexed suffix as in the following.
OriginalFFName_BRBId
 - ◆ Forward Register Balancing—When replacing several flip-flops with one, select the name based on the name of the LUT across which the flip-flops are moving as in the following.
LutName_BRBId

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Apply globally or to an entity, module, or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using REGISTER_BALANCING, declare it with the following syntax:

```
attribute register_balancing: string;
```

After declaring REGISTER_BALANCING, specify the VHDL constraint as follows:

```
attribute register_balancing of {signal_name|entity_name} :  
{signal|entity} is "{yes|no|forward|backward}";
```

The default value is **no**.

Verilog

Specify as follows:

```
// synthesis attribute register_balancing [of]  
{module_name|signal_name} [is] {yes|no|forward|backward};
```

The default value is **no**.

XCF

```
MODEL "entity_name" register_balancing={yes|no|true|false|forward|  
backward};
```

```
BEGIN MODEL "entity_name"  
NET "primary_clock_signal"  
register_balancing={yes|no|true|false|forward|backward};  
INST "instance_name" register_balancing={yes|no|true|false|forward|  
backward};  
END;
```

XST Command Line

Define globally with the **-register_balancing** command line option of the **run** command. Following is the basic syntax:

```
-register_balancing {yes|no|forward|backward}
```

The default is **no**.

Project Navigator

Set with the **Register Balancing** option in the Xilinx Specific Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Register Duplication

The Register Duplication (REGISTER_DUPLICATION) constraint enables or disables register replication. Allowed values are **yes** and **no**. (The values **true** and **false** are also available in XCF. The default is **yes**, and means that register replication is enabled, and is performed during timing optimization and fanout control.)

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Apply globally or to an entity or module.

Propagation Rules

Applies to the entity or module to which it is attached.

Syntax Examples

VHDL

Before REGISTER_DUPLICATION can be used, it must be declared with the following syntax:

```
attribute register_duplication: string;
```

After declaring REGISTER_DUPLICATION, specify the VHDL constraint as follows:

```
attribute register_duplication of entity_name: entity is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute register_duplication [of] module_name [is]
"yes";
```

XCF

```

MODEL "entity_name" register_duplication={true|false|yes|no} ;

BEGIN MODEL "entity_name"
  NET "signal_name" register_duplication={true|false|yes|no} ;
END;

```

Project Navigator

Specify globally with the **Register Duplication** option in the Xilinx Specific Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

ROM Extraction

The ROM Extraction (ROM_EXTRACT) constraint enables or disables ROM macro inference. Allowed values are **yes**, and **no**. The values **true** and **false** ones are also available in XCF. The default is **yes**. Typically, a ROM can be inferred from a Case statement where all assigned contexts are constant values.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Apply globally or to a design element, or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using ROM_EXTRACT, declare it with the following syntax:

```
attribute rom_extract: string;
```

After declaring ROM_EXTRACT, specify the VHDL constraint as follows:

```
attribute rom_extract of {signal_name|entity_name}: {signal|entity} is  
"yes";
```

Verilog

Specify as follows:

```
// synthesis attribute rom_extract [of] {module_name|signal_name} [is]  
yes;
```

XCF

```
MODEL "entity_name" rom_extract={yes|no|true|false};  
  
BEGIN MODEL "entity_name"  
    NET "signal_name" rom_extract={yes|no|true|false};  
END;
```

XST Command Line

Define globally with the **-rom_extract** command line option of the **run** command. Following is the basic syntax:

```
-rom_extract {yes|no}
```

The default is **yes**.

Project Navigator

Set globally with the **ROM Extraction** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

ROM Style

ROM Style (ROM_STYLE) controls the way the macrogenerator implements the inferred ROM macros. ROM_EXTRACT must be set to **yes** to use ROM_STYLE. Allowed values are **auto**, **block** and **distributed**. The default value is **auto**, meaning that XST looks for the best implementation for each inferred ROM. The implementation style can be manually forced to use block ROM or distributed ROM resources available in the Virtex series, Spartan-II and Spartan-3 devices.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Apply globally or to an entity, module, or signal.

Propagation Rules

Applies to the entity, module, or signal to which it is attached.

Syntax Examples

VHDL

ROM_EXTRACT must be set to **yes** to use ROM_STYLE.

Before using ROM_STYLE, declare it with the following syntax:

```
attribute rom_style: string;
```

After declaring ROM_STYLE, specify the VHDL constraint as follows:

```
attribute rom_style of {signal_name|entity_name}: {signal|entity} is
" {auto|block|distributed}";
```

The default value is **auto**.

Verilog

ROM_EXTRACT must be set to **yes** to use ROM_STYLE.

Specify as follows:

```
// synthesis attribute rom_style [of] {module_name|signal_name} [is]
{auto|block|distributed};
```

The default value is **auto**.

XCF

ROM_EXTRACT must be set to **yes** to use ROM_STYLE.

```
MODEL "entity_name" rom_style={auto|block|distributed};
```

```
BEGIN MODEL "entity_name"
  NET "signal_name"  rom_style={auto|block|distributed};
END;
```

XST Command Line

ROM_EXTRACT must be set to **yes** to use ROM_STYLE.

Define globally with the **-rom_style** command line option of the **run** command. Following is the basic syntax:

```
-rom_style {auto|distributed|block}
```

The default is **auto**.

Project Navigator

ROM Extraction must be set to **yes** to use **ROM Style**.

Set globally with the **ROM Style** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Shift Register Extraction

The Shift Register Extraction (SHREG_EXTRACT) constraint enables or disables shift register macro inference. Allowed values are **yes** (check box is checked) and **no** (check box is not checked). The values **true** and **false** ones are available in XCF. By default, shift register inference is enabled.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes

Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Apply globally or to design elements and signals.

Propagation Rules

Applies to design elements or signals to which it is attached.

Syntax Examples

VHDL

Before using SHREG_EXTRACT, declare it with the following syntax:

```
attribute shreg_extract : string;
```

After declaring SHREG_EXTRACT, specify the VHDL constraint as follows:

```
attribute shreg_extract of {signal_name|entity_name} : {signal|entity}
is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute shreg_extract [of] {module_name|signal_name}
[is] "yes";
```

XCF

```
MODEL "entity_name" shreg_extract={yes|no|true|false};
```

```
BEGIN MODEL "entity_name"
NET "signal_name" shreg_extract={yes|no|true|false};
END;
```

XST Command Line

Define globally with the **-shreg_extract** command line option of the **run** command. Following is the basic syntax:

```
-shreg_extract {yes|no}
```

The default is **yes**.

Project Navigator

Set globally with the **Shift Register Extraction** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Slice Packing

The Slice Packing (-slice_packing) option enables the XST internal packer. The packer attempts to pack critical LUT-to-LUT connections within a slice or a CLB. This exploits the fast feedback connections among the LUTs in a CLB.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Apply globally.

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define globally with the **-slice_packing** command line option of the **run** command. Following is the basic syntax:

```
-slice_packing {yes|no}
```

The default is **yes**.

Project Navigator

Set globally with the **Slice Packing** option in the Xilinx Specific Options tab in the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Uselowskewlines

The USELOWSKEWLINES constraint is a basic routing constraint. From a Synthesis point of view it prevents XST from using dedicated clock resources and logic replication, based on the value of the MAX_FANOUT constraint. It specifies the use of low skew routing resources for any net. See “[USELOWSKEWLINES](#)” in the *Constraints Guide* for details.

XOR Collapsing

The XOR Collapsing (XOR_COLLAPSE) constraint controls whether cascaded XORs should be collapsed into a single XOR. Allowed values are **yes** (check box is checked) and **no** (check box is not checked). The values **true** and **false** ones are available in XCF. By default, XOR collapsing is enabled (**yes**).

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-III	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes

Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Apply to cascaded XORs.

Propagation Rules

Not applicable

Syntax Examples

VHDL

Before XOR_COLLAPSE can be used, it must be declared with the following syntax:

```
attribute xor_collapse: string;
```

After declaring XOR_COLLAPSE, specify the VHDL constraint as follows:

```
attribute xor_collapse {signal_name|entity_name}: {signal|entity} is
"yes";
```

The default value is **yes**.

Verilog

Specify as follows:

```
// synthesis attribute xor_collapse [of] {module_name|signal_name}
[is] yes;
```

The default value is **yes**.

XCF

```
MODEL "entity_name" xor_collapse={yes|no|true|false};
```

```
BEGIN MODEL "entity_name"
NET "signal_name" xor_collapse={yes|no|true|false};
END;
```

XST Command Line

Define globally with the **-xor_collapse** command line option of the **run** command. Following is the basic syntax:

```
-xor_collapse {yes|no}
```

The default is **yes**.

Project Navigator

Set globally with the **XOR Collapsing** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Slice Utilization Ratio

The Slice Utilization Ratio (SLICE_UTILIZATION_RATIO) constraint defines the area size in absolute number or percent of total number of slices that XST must not exceed during timing optimization.

If the area constraint cannot be satisfied, XST will make timing optimization regardless of the area constraint.

Please refer to [“Speed Optimization Under Area Constraint”](#) for more information.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Applies globally or to a VHDL entity or Verilog module.

Propagation Rules

Applies to the entity or module to which it is attached.

Syntax Examples

VHDL

Before using SLICE_UTILIZATION_RATIO, declare it with the following syntax:

```
attribute slice_utilization_ratio: string;
```

After declaring SLICE_UTILIZATION_RATIO, specify the VHDL constraint as follows:

```
attribute slice_utilization_ratio of entity_name : entity is "integer";
attribute slice_utilization_ratio of entity_name : entity is
"integer%";
attribute slice_utilization_ratio of entity_name : entity is
"integer#";
```

Note: In the preceding example, XST interprets the integer values in the first two attributes as a percentage and in the last attribute as an absolute number of slices.

Verilog

Specify as follows:

```
// synthesis attribute slice_utilization_ratio [of] module_name} [is]
integer;
// synthesis attribute slice_utilization_ratio [of] module_name} [is]
integer% ;
// synthesis attribute slice_utilization_ratio [of] module_name} [is]
integer#;
```

Note: In the preceding example, XST interprets the integer values in the first two attributes as a percentage and in the last attribute as an absolute number of slices.

XCF

```
MODEL "entity_name" slice_utilization_ratio_maxmargin=integer;
MODEL "entity_name" slice_utilization_ratio_maxmargin="integer%";
MODEL "entity_name" slice_utilization_ratio_maxmargin="integer#";
```

Note: In the preceding example, XST interprets the integer values in the first two lines as a percentage and in the last line as an absolute number of slices.

Note: Be sure to observe the following:

- There must be no space between the integer value and % and # characters.
- You must surround the integer value and %/# mark with double quotes ("") because % and # are special characters in XCF.

XST Command Line

Define globally with the **-slice_utilization_ratio** command line option of the **run** command. Following is the basic syntax:

```
-slice_utilization_ratio integer
-slice_utilization_ratio integer%
-slice_utilization_ratio integer#
```

Note: In the preceding example, XST interprets the integer values in the first two lines as a percentage and in the last line as an absolute number of slices.

The integer value range is **0** to **100**.

Project Navigator

Set globally with the **Slice Utilization Ratio** option in the Synthesis Options tab of the Process Properties dialog box in the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Note: In Project Navigator, you can only define the value of this option as a percentage. The definition of the value in the form of absolute number of slices is not supported.

Slice Utilization Ratio Delta

The Slice Utilization Ratio Delta (SLICE_UTILIZATION_RATIO_MAXMARGIN) constraint is closely related to the SLICE_UTILIZATION_RATIO constraint. It defines the tolerance margin for the SLICE_UTILIZATION_RATIO constraint. The value of the parameter can be defined in the form of percentage as well as an absolute number of slices.

If the ratio is within the margin set, the constraint is met and timing optimization can continue. See “[Speed Optimization Under Area Constraint](#)” in Chapter 3 for more information.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Applies globally or to a VHDL entity or Verilog module.

Propagation Rules

Applies to the entity or module to which it is attached.

Syntax Examples

VHDL

Before using SLICE_UTILIZATION_RATIO_MAXMARGIN, declare it with the following syntax:

```
attribute slice_utilization_ratio_maxmargin: string;
```

After declaring SLICE_UTILIZATION_RATIO_MAXMARGIN, specify the VHDL constraint as follows:

```
attribute slice_utilization_ratio_maxmargin of entity_name : entity is  

"integer";  

attribute slice_utilization_ratio_maxmargin of entity_name : entity is  

"integer%";  

attribute slice_utilization_ratio_maxmargin of entity_name : entity is  

"integer#";
```

Note: In the preceding example, XST interprets the integer values in the first two attributes as a percentage and in the last attribute as an absolute number of slices.

Integer range is **0** to **100**.

Verilog

Specify as follows:

```
// synthesis attribute slice_utilization_ratio_maxmargin [of]  

module_name [is] integer;  

// synthesis attribute slice_utilization_ratio_maxmargin [of]  

module_name [is] "integer%";  

// synthesis attribute slice_utilization_ratio_maxmargin [of]  

module_name [is] "integer#";
```

Note: In the preceding example, XST interprets the integer values in the first two attributes as a percentage and in the last attribute as an absolute number of slices.

XCF

```
MODEL "entity_name" slice_utilization_ratio_maxmargin=integer;  

MODEL "entity_name" slice_utilization_ratio_maxmargin="integer%";  

MODEL "entity_name" slice_utilization_ratio_maxmargin="integer#";
```

Note: In the preceding example, XST interprets the integer values in the first two lines as a percentage and in the last line as an absolute number of slices.

Note: Be sure to observe the following:

- There must be no space between the integer value and % and # characters.
- You must surround the integer value and %/# mark with double quotes ("") because % and # are special characters in XCF.

Integer range is **0** to **100**.

XST Command Line

Define globally with the **-slice_utilization_ratio_maxmargin** command line option of the **run** command. Following is the basic syntax:

```
-slice_utilization_ratio_maxmargin integer
-slice_utilization_ratio_maxmargin integer%
-slice_utilization_ratio_maxmargin integer#
```

Note: In the preceding example, XST interprets the integer values in the first two lines as a percentage and in the last line as an absolute number of slices.

The integer range is **0** to **100**.

Map Entity on a Single LUT

The Map Entity on a Single LUT (LUT_MAP) constraint forces XST to map a single block into a single LUT. If a described function on an RTL level description does not fit in a single LUT, XST issues an error message.

Using the UNISIM library allows you to directly instantiate LUT components in your HDL code. To specify a function that a particular LUT must execute, apply an INIT constraint to the instance of the LUT. If you want to place an instantiated LUT or register in a particular slice, then attach an RLOC constraint to the same instance.

It is not always convenient to calculate INIT functions and different methods can be used to achieve this. Instead, you can describe the function that you want to map onto a single LUT in your VHDL or Verilog code in a separate block. Attaching a LUT_MAP constraint (XST is able to automatically recognize the XC_MAP constraint supported by Synplicity) to this block will indicate to XST that this block must be mapped on a single LUT. XST will automatically calculate the INIT value for the LUT and preserve this LUT during optimization.

Please refer to “[Specifying INITs and RLOCs in HDL Code](#)” in Chapter 3 for more information.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes

XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Applies to a VHDL entity or Verilog module.

Propagation Rules

Applies to the entity or module to which it is attached.

Syntax Examples

VHDL

Before using LUT_MAP, declare it with the following syntax:

```
attribute lut_map: string;
```

After declaring LUT_MAP, specify the VHDL constraint as follows:

```
attribute lut_map of entity_name : entity is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute lut_map [of] module_name [is] "yes";
```

XCF

```
MODEL "entity_name" lut_map={yes|true};
```

Read Cores

The Read Cores (`-read_cores`) command line option enables or disables XST to read EDIF or NGC core files for timing estimation and device utilization control. Please refer to “[Cores Processing](#)” in Chapter 3 for more information. The Read Cores command line option has three possible values:

- **no**: disables cores processing
- **yes**: enables cores processing, but maintains the core as a black box and does not further incorporate the core into the design
- **optimize**: enables cores processing, and merges the core’s netlist into the overall design

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Applies globally.

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define globally with the **-read_cores** command line option of the **run** command. Following is the basic syntax:

```
-read_cores {yes|no|optimize}
```

The default is **yes**.

Project Navigator

Set globally with the **Read Cores** option in the Synthesis Options tab of the Process Properties dialog box.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Note: The *optimize* option is not available in Project Navigator.

Use Carry Chain

XST uses carry chain resources to implement certain macros, but there are situations where you can get better results by avoiding the use of carry chain. The Use Carry Chain (USE_CARRY_CHAIN) constraint can deactivate carry chain use for macro generation. It is both a global and a local constraint, and has values of **yes** or **no**, with **yes** being the default.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-III	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

Applicable Elements

Applies to Signals, as well as globally.

Propagation Rules

Applies to the signal to which it is attached.

Syntax Examples

Schematic

Attach to a valid instance.

Attribute Name—USE_CARRY_CHAIN

Attribute Value—YES, NO

VHDL

Before using USE_CARRY_CHAIN, declare it with the following syntax:

```
attribute USE_CARRY_CHAIN: string;
```

After declaring USE_CARRY_CHAIN, specify the VHDL constraint as follows:

```
attribute USE_CARRY_CHAIN of signal_name: signal is "{yes|no}";
```

Verilog

Specify as follows:

```
// synthesis attribute USE_CARRY_CHAIN [of] signal_name [is] {yes|no};
```

XCF

```
MODEL "entity_name" use_carry_chain={yes|no|true|false};
BEGIN MODEL "entity_name"
NET "signal_name" use_carry_chain={yes|no|true|false};
END;
```

XST Command Line

Define globally with the **-use_carry_chain** command line option of the **run** command. Following is the basic syntax:

```
-use_carry_chain {yes|no}
```

The default is **yes**.

Convert Tristates to Logic

Since some devices do not support internal tristates, XST automatically replaces tristates with equivalent logic. Because the logic generated from tristates can be combined and optimized with surrounding logic, the replacement of internal tristates by logic for other devices can lead to better speed, and in some cases, better area optimization. But in general tristate to logic replacement may lead to area increase. If the optimization goal is Area, you should apply the TRISTATE2LOGIC constraint set to **no**.

Limitations:

- Only internal tristates are replaced by logic, which means that the tristates of the top module connected to output pads are preserved.
- Internal tristates are not replaced by logic for modules when incremental synthesis is active.
- This switch does not apply to technologies that do not have internal tristates, like Spartan-3 or Virtex-4 devices. In this case, the conversion of tristates to logic is performed automatically. Please note, that in some situations XST is not able to make the replacement automatically, due to the fact that this may lead to wrong design behavior or multi-source. This may happen when the hierarchy is preserved or XST does not have full design visibility (for example, design is synthesized on a block-by-block basis). In these cases XST gives a warning message at low level optimization step. Depending on the particular design situation, you may continue the design flow and the replacement could be done by MAP, or you can force the replacement by applying TRISTATE2LOGIC set to **yes** on a particular block or signal. Please refer to Answer Record #20048 for more information.

Allowed values are **yes** and **no** (**true** and **false** are available in XCF as well). By default, tristate to logic transformation is enabled (**yes**).

TRISTATE2LOGIC Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-III	Yes
Spartan-3	No
Spartan-3E	No
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	No
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner II	No

TRISTATE2LOGIC Applicable Elements

This constraint can be applied to an entire design via the XST command line, to a particular block (entity, architecture, component), or to a signal.

TRISTATE2LOGIC Propagation Rules

Applies to an entity, component, module or signal to which it is attached.

TRISTATE2LOGIC Syntax Examples

VHDL

Before using TRISTATE2LOGIC, declare it with the following syntax:

```
attribute tristate2logic: string;
```

After declaring TRISTATE2LOGIC, specify the VHDL constraint as follows:

```
attribute tristate2logic of {entity_name|component_name|signal_name}:
{entity|component|signal} is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute tristate2logic [of] {module_name|signal_name}
[is] "yes";
```

XCF

```
MODEL "entity_name" tristate2logic={yes|no|true|false};
BEGIN MODEL "entity_name"
  NET "signal_name" tristate2logic={yes|no|true|false};
END;
```

XST Command Line

Define globally with the **-tristate2logic** command line option of the **run** command. Following is the basic syntax:

```
-tristate2logic {yes|no}
```

The default is **yes**.

Project Navigator

Set TRISTATE2LOGIC, globally with the **Convert Tristates To Logic** option in the Xilinx Specific Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Use Clock Enable

The Use Clock Enable (USE_CLOCK_ENABLE) constraint enables or disables the use of the clock enable function in flip-flops. The disabling of the clock enable function is typically used for ASIC prototyping on FPGAs.

By detecting this constraint with a value of **no** or **false**, XST avoids using CE resources in the final implementation. Moreover, for some designs, putting the Clock Enable function on the data input of the flip-flop allows better logic optimization and therefore better QOR. In **auto** mode, XST tries to estimate a trade off between using a dedicated clock enable input of a flip-flop input and putting clock enable logic on the D input of a flip-flop. In a case where a flip-flop is instantiated by the user, XST removes the clock enable only if the Optimize Instantiated Primitives switch is set to **yes**.

Allowed values are **auto**, **yes**, and **no**. The values **true** and **false** are also available in XCF. By default, the use of clock enable signal is enabled (**auto**).

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes

Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner II	No

Applicable Elements

Applies to an entire design via XST command line, to a particular block (entity, architecture, component), to a signal representing flip-flop, and to an instance representing instantiated flip-flop.

Propagation Rules

Applies to an entity, component, module, signal, or instance to which it is attached.

Syntax Examples

VHDL

Before using USE_CLOCK_ENABLE, declare it with the following syntax:

```
attribute use_clock_enable: string;
```

After declaring USE_CLOCK_ENABLE, specify the VHDL constraint as follows:

```
attribute use_clock_enable of
  {entity_name|component_name|signal_name|instance_name}:
    {entity|component|signal|label} is "no";
```

Verilog

Specify as follows:

```
// synthesis attribute use_clock_enable [of]
  {module_name|signal_name|isntance_name} [is] no;
```

XCF

```
MODEL "entity_name" use_clock_enable={auto|yes|true|no|false};
BEGIN MODEL "entity_name"
  NET "signal_name" use_clock_enable={auto|yes|true|no|false};
  INST "instance_name" use_clock_enable={auto|yes|true|no|false};
END;
```

XST Command Line

Define globally with the **-use_clock_enable** command line option of the **run** command. Following is the basic syntax:

```
-use_clock_enable {auto|yes|no}
```

The default is **auto**.

Project Navigator

Set globally with the **Use Clock Enable** option in the Xilinx Specific Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Use Synchronous Set

The Use Synchronous Set (USE_SYNC_SET) constraint enables or disables the use of synchronous set function in flip-flops. The disabling of the synchronous set function is typically used for ASIC prototyping on FPGAs. Detecting this constraint with a value of **no** or **false**, XST avoids using synchronous reset resources in the final implementation. Moreover, for some designs, putting synchronous reset function on data input of the flip-flop allows better logic optimization and therefore better QOR. In **auto** mode, XST tries to estimate a trade off between using dedicated Synchronous Set input of a flip-flop input and putting Synchronous Set logic on the D input of a flip-flop. In a case where a flip-flop is instantiated by the user, XST removes the synchronous reset only if the Optimize Instantiated Primitives switch is set to **yes**.

Allowed values are **auto**, **yes**, and **no**. The values **true** and **false** are also available in XCF. By default, the use of synchronous reset signal is enabled (**auto**).

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No

CoolRunner XPLA3	No
CoolRunner II	No

Applicable Elements

Applies to an entire design via an XST command line, to a particular block (entity, architecture, component), to a signal representing a flip-flop, and to an instance representing an instantiated flip-flop.

Propagation Rules

Applies to an entity, component, module, signal, or instance to which it is attached.

Syntax Examples

VHDL

Before using USE_SYNC_SET, declare it with the following syntax:

```
attribute use_sync_set: string;
```

After declaring USE_SYNC_SET, specify the VHDL constraint as follows:

```
attribute use_sync_set of
  {entity_name|component_name|signal_name|instance_name}:
  {entity|component|signal|label} is "no";
```

Verilog

Specify as follows:

```
// synthesis attribute use_sync_set [of]
{module_name|signal_name|instance_name} [is] no;
```

XCF

```
MODEL "entity_name" use_sync_set={auto|yes|true|no|false};
BEGIN MODEL "entity_name"
  NET "signal_name" use_sync_set={auto|yes|true|no|false};
  INST "instance_name" use_sync_set={auto|yes|true|no|false};
END;
```

XST Command Line

Define globally with the **-use_sync_set** command line option of the **run** command. Following is the basic syntax:

```
-use_sync_set {auto|yes|no}
```

The default is **auto**.

Project Navigator

Set globally with the **Use Synchronous Set** option in the Xilinx Specific Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Use Synchronous Reset

The Use Synchronous Reset (USE_SYNC_RESET) constraint enables or disables the usage of synchronous reset function of flip-flops. The disabling of the Synchronous Reset function could be used for ASIC prototyping flow on FPGAs.

Detecting this constraint with a value of **no** or **false**, XST avoids using synchronous reset resources in the final implementation. Moreover, for some designs, putting synchronous reset function on data input of the flip-flop allows better logic optimization and therefore better QOR. In **auto** mode, XST tries to estimate a trade off between using a dedicated Synchronous Reset input on a flip-flop input and putting Synchronous Reset logic on the D input of a flip-flop. In a case where a flip-flop is instantiated by the user, XST removes the synchronous reset only if the Optimize Instantiated Primitives switch is set to **yes**.

Allowed values are **auto**, **yes**, and **no**. The values **true** and **false** ones are also available in XCF. By default, the use of synchronous reset signal is enabled (**auto**).

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner II	No

Applicable Elements

Applies to an entire design via XST command line, to a particular block (entity, architecture, component), to a signal representing a flip-flop, and to an instance representing an instantiated flip-flop.

Propagation Rules

Applies to an entity, component, module, signal, or instance to which it is attached.

Syntax Examples

VHDL

Before using USE_SYNC_RESET, declare it with the following syntax:

```
attribute use_sync_reset: string;
```

After declaring USE_SYNC_RESET, specify the VHDL constraint as follows:

```
attribute use_sync_reset of
{entity_name|component_name|signal_name|instance_name} :
{entity|component|signal|label} is "no";
```

Verilog

Specify as follows:

```
// synthesis attribute use_sync_reset [of]
{module_name|signal_name|instance_name} [is] no;
```

XCF

```
MODEL "entity_name" use_sync_reset={auto|yes|true|no|false};
BEGIN MODEL "entity_name"
NET "signal_name" use_sync_reset={auto|yes|true|no|false};
INST "instance_name" use_sync_reset={auto|yes|true|no|false};
END;
```

XST Command Line

Define globally with the **-use_sync_reset** command line option of the **run** command. Following is the basic syntax:

```
-use_sync_reset {auto|yes|no}
```

The default is **auto**.

Project Navigator

Set globally with the **Use Synchronous Reset** option in the Xilinx Specific Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Use DSP48

XST enables you to use the resources of the DSP48 blocks introduced in Virtex-4 devices. The default value is **auto**. In **auto** mode, XST automatically implements such macros as MAC and accumulates on DSP48, but some of them as adders are implemented on slices. You have to force their implementation on DSP48 using a value of **yes** or **true**. Please refer to the [Chapter 2, “HDL Coding Techniques”](#) for supported macros and their implementation control.

Several macros (e.g., MAC), which can be placed on DSP48 are in fact a composition of more simple macros like multipliers, accumulators, and registers. In order to present the best performance, XST by default tries to infer and implement the maximum macro configuration. If you want to shape a macro in a specific way, use the KEEP constraint. For example, DSP48 allows you to implement a multiple with two input registers. If you want

to leave the first register stage outside of the DSP48, place the KEEP constraint in their outputs.

Allowed values are **auto**, **yes** and **no**. The values **true** and **false** are also available in XCF. By default, safe implementation is enabled (**auto**).

In **auto** mode you can control the number of available DSP48 resources for synthesis via the [DSP Utilization Ratio](#) constraint. By default, XST tries to utilize, as much as possible, all available DSP48 resources. Refer to “[Using DSP48 Block Resources](#)” in Chapter 3 for more information.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	No
Virtex-E	No
Spartan-II	No
Spartan-IIIE	No
Spartan-3	No
Spartan-3E	No
Virtex-II	No
Virtex-II Pro	No
Virtex-II Pro X	No
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner II	No

Applicable Elements

Applies to an entire design via an XST command line, to a particular block (entity, architecture, component), and to a signal representing a macro described at the RTL level.

Propagation Rules

Applies to an entity, component, module, or signal to which it is attached.

Syntax Examples

VHDL

Before using USE_DSP48, declare it with the following syntax:

```
attribute use_dsp48: string;
```

After declaring USE_DSP48, specify the VHDL constraint as follows:

```
attribute use_dsp48 of {entity_name|component_name|signal_name} :
{entity|component|signal} is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute use_dsp48 [of] {module_name|signal_name} [is]
"yes";
```

XCF

```
MODEL "entity_name" use_dsp48={auto|yes|no|true|false};
BEGIN MODEL "entity_name"
  NET "signal_name" use_dsp48={auto|yes|no|true|false};
END;
```

XST Command Line

Define globally with the **-use_dsp48** command line option of the **run** command. Following is the basic syntax:

```
use_dsp48 {auto|yes|no}
```

The default is **auto**.

Project Navigator

Set globally with the **Use DSP48** option in the HDL Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

CPLD Constraints (non-timing)

This section lists options that only apply to CPLDs—not FPGAs.

Note: Please note that in many cases, a particular constraint can be applied globally to an entire entity or model, or alternatively, it can be applied locally to individual signals, nets or instances. See [Table 5-1](#) for valid constraint targets.

Clock Enable

The Clock Enable (**-pld_ce**) constraint specifies how sequential logic should be implemented when it contains a clock enable, either using the specific device resources available for that or generating equivalent logic.

This option allows you to specify the way the clock enable function will be implemented if presented in the design. Two values are available:

- **yes** (check box is checked): the synthesizer implements the use of the clock enable signal of the device
- **no** (check box is not checked): the clock enable function will be implemented through equivalent logic

Keeping or not keeping the clock enable signal depends on the design logic. Sometimes, when the clock enable is the result of a Boolean expression, saying **no** with this option may improve the fitting result because the input data of the flip-flop is simplified when it is merged with the clock enable expression.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	No
Virtex-E	No
Spartan-II	No
Spartan-IIIE	No
Spartan-3	No
Spartan-3E	No
Virtex-II	No
Virtex-II Pro	No
Virtex-II Pro X	No
Virtex-4	No
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner II	Yes

Applicable Elements

Applies to an entire design via an XST command line

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define globally with the **-pld_ce** command line option of the **run** command. Following is the basic syntax:

```
-pld_ce {yes|no}
```

The default is **yes**.

Project Navigator

Set globally with the **Clock Enable** option in the Xilinx Specific Options tab of the Process Properties dialog box within the Project Navigator.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Data Gate

The CoolRunner-II DataGate (DATA_GATE) feature provides direct means of reducing power consumption in your design. Each I/O pin input signal passes through a latch that can block the propagation of incident transitions during periods when such transitions are not of interest to your CPLD design. Input transitions that do not affect the CPLD design function still consume power, if not latched, as they are routed among the CPLD's Function Blocks. By asserting the DataGate control I/O pin on the device, selected I/O pin inputs become latched, thereby eliminating the power dissipation associated with external transitions on those pins. See "["DATA_GATE"](#)" in the *Constraints Guide* for details

Keep Hierarchy

This option is related to the hierarchical blocks (VHDL entities, Verilog modules) specified in the HDL design and does not concern the macros inferred by the HDL synthesizer. The Keep Hierarchy (KEEP_HIERARCHY) constraint enables or disables hierarchical flattening of user-defined design units, and controls whether it is passed on as an implementation constraint. See "["Keep Hierarchy"](#)" for more information.

Macro Preserve

The Macro Preserve (-pld_mp) option is useful for making the macro handling independent of design hierarchy processing. This allows you to merge all hierarchical blocks in the top module, while still keeping the macros as hierarchical modules. You can also keep the design hierarchy except for the macros, which are merged with the surrounding logic. Merging the macros sometimes gives better results for design fitting. Two values are available for this option:

- **yes** (check box is checked): macros are preserved and generated by Macro+.
- **no** (check box is not checked): macros are rejected and generated by HDL synthesizer

Depending on the Flatten Hierarchy value, a rejected macro becomes a hierarchical block (**Flatten Hierarchy=no**) or is merged in the design logic (**Flatten Hierarchy=yes**). Very small macros (2-bit adders, 4-bit multiplexers) are always merged, independent of the Macro Preserve or Flatten Hierarchy options.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	No
Virtex-E	No
Spartan-II	No
Spartan-IIIE	No
Spartan-3	No
Spartan-3E	No

Virtex-II	No
Virtex-II Pro	No
Virtex-II Pro X	No
Virtex-4	No
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner II	Yes

Applicable Elements

Applies to an entire design via an XST command line.

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define this option globally with the **-pld_mp** command line option of the **run** command. Following is the basic syntax:

```
-pld_mp {yes|no}
```

The default is **yes**.

Project Navigator

Specify globally with the **Macro Preserve** option in the Xilinx Specific Options tab of the Process Properties dialog box.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

No Reduce

The No Reduce (NOREDUCE) constraint prevents minimization of redundant logic terms that are typically included in a design to avoid logic hazards or race conditions. This constraint also identifies the output node of a combinatorial feedback loop to ensure correct mapping. See “**NOREDUCE**” in the *Constraints Guide* for details.

WYSIWYG

The goal of the WYSIWYG option is to have a netlist as much as possible reflect the user specification. That is, all the nodes declared in the HDL design are preserved.

If WYSIWYG mode is enabled (**yes**), then XST preserves all the user internal signals (nodes), creates SOURCE_NODE constraints in the NGC file for all these nodes, and skips design optimization (collapse, factorization); only boolean equation minimization is performed.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	No
Virtex-E	No
Spartan-II	No
Spartan-IIIE	No
Spartan-3	No
Spartan-3E	No
Virtex-II	No
Virtex-II Pro	No
Virtex-II Pro X	No
Virtex-4	No
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner II	Yes

Applicable Elements

Applies to an entire design via an XST command line.

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define globally with the **-wysiwyg** command line option of the **run** command. Following is the basic syntax:

```
-wysiwyg {yes|no}
```

The default is **no**.

Project Navigator

Specify globally with the **WYSIWYG** option in the Xilinx Specific Options tab of the Process Properties dialog box.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

XOR Preserve

The XOR Preserve (-pld_xp) constraint enables or disables hierarchical flattening of XOR macros. Allowed values are **yes** (check box is checked) and **no** (check box is not checked). By default, XOR macros are preserved (check box is checked).

The XORs inferred by HDL synthesis are also considered as macro blocks in the CPLD flow, but they are processed separately to give more flexibility for the use of device macrocells XOR gates. Therefore, you can decide to flatten its design (Flatten Hierarchy *yes*, Macro Preserve *no*) but you want to preserve the XORs. Preserving XORs has a great impact on reducing design complexity. Two values are available for this option:

- **yes**—XOR macros are preserved
- **no**—XOR macros are merged with surrounded logic

Preserving the XORs, generally, gives better results; that is, the number of PTerms is lower. The *no* value is useful to obtain completely flat netlists. Sometimes, applying the global optimization on a completely flat design improves the design fitting.

You obtain a completely flattened design when selecting the following options:

- Flatten Hierarchy—**yes**
- Macro Preserve—**no**
- XOR Preserve—**no**

The *no* value for this option does not guarantee the elimination of the XOR operator from the EDIF netlist. During the netlist generation, the netlist mapper tries to recognize and infer XOR gates in order to decrease the logic complexity. This process is independent of the XOR preservation done by HDL synthesis and is guided only by the goal of complexity reduction.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	No
VirTEX-E	No
Spartan-II	No
Spartan-III	No
Spartan-3	No
Spartan-3E	No
Virtex-II	No
Virtex-II Pro	No
Virtex-II Pro X	No
Virtex-4	No
XC9500, XC9500XL, XC9500XV	Yes

CoolRunner XPLA3	Yes
CoolRunner II	Yes

Applicable Elements

Applies to an entire design via an XST command line.

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define this constraint globally with the **-pld_xp** command line option of the **run** command. Following is the basic syntax:

```
-pld_xp {yes|no}
```

The default is **yes**.

Project Navigator

Specify globally with the **XOR Preserve** option in the Xilinx Specific Options tab of the Process Properties dialog box.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Timing Constraints

Timing constraints supported by XST can be applied either via the **-glob_opt** command line switch, which is the same as selecting Global Optimization Goal from the Synthesis Options tab of the Process Properties menu in Project Navigator, or via the constraints file.

- Using the **-glob_opt**/Global Optimization Goal method allows you to apply the five global timing constraints (ALLCLOCKNETS, OFFSET_IN_BEFORE, OFFSET_OUT_AFTER, INPAD_TO_OUTPAD and MAX_DELAY). These constraints are applied globally to the entire design. You cannot specify a value for these constraints as XST optimizes them for the best performance. Note that these constraints are overridden by constraints specified in the constraints file.
- Using the constraint file method you can specify timing constraints using native UCF syntax. XST supports constraints such as TNM_NET, TIMEGRP, PERIOD, TIG, FROM-TO etc., including wildcards and hierarchical names.

Note: Timing constraints are only written to the NGC file when the Write Timing Constraints property is checked **yes** in the Process Properties dialog box in Project Navigator, or the **-write_timing_constraints** option is specified when using the command line. By default, they are not written to the NGC file.

Regardless of the way timing constraints are specified, there are three additional options that affect timing constraint processing. These are:

- Cross Clock Analysis
- Write Timing Constraints
- Clock Signal

Cross Clock Analysis

The Cross Clock Analysis command (`-cross_clock_analysis`) allows inter-clock domain analysis during timing optimization. By default (`no`), XST does not perform this analysis.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner II	Yes

Applicable Elements

Applies to an entire design via an XST command line.

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define globally with the **-cross_clock_analysis** command line option of the **run** command. Following is the basic syntax:

```
-cross_clock_analysis {yes|no}
```

The default is **yes**.

Project Navigator

Specify globally with the **Cross Clock Analysis** option in the Synthesis Options tab of the Process Properties dialog box.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Write Timing Constraints

The Write Timing Constraints option (**-write_timing_constraints**) in one of your status reports enables or disables propagation of timing constraints to the NGC file that are specified in HDL code. These timing constraints in the NCG file will be used during place and route, as well as synthesis optimization.

Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	Yes
CoolRunner XPLA3	Yes
CoolRunner II	Yes

Applicable Elements

Applies to an entire design via an XST command line.

Propagation Rules

Not applicable.

Syntax Examples

XST Command Line

Define globally with the **-write_timing_constraints** command line option of the **run** command. Following is the basic syntax:

```
-write_timing_constraints {yes|no}
```

The default is **yes**.

Project Navigator

Specify globally with the **Write Timing Constraints** option in the Synthesis Options tab of the Process Properties dialog box.

With a design selected in the Sources window, right-click **Synthesize** in the Processes window to access the appropriate Process Properties dialog box.

Clock Signal

If a clock signal goes through combinatorial logic before being connected to the clock input of a flip-flop, XST cannot identify what input pin or internal signal is the real clock signal. The **CLOCK_SIGNAL** constraint allows you to define the clock signal.

CLOCK_SIGNAL Architecture Support

The following table lists supported and unsupported architectures.

Architecture	Supported/Unsupported
Virtex	Yes
Virtex-E	Yes
Spartan-II	Yes
Spartan-IIIE	Yes
Spartan-3	Yes
Spartan-3E	Yes
Virtex-II	Yes
Virtex-II Pro	Yes
Virtex-II Pro X	Yes
Virtex-4	Yes
XC9500, XC9500XL, XC9500XV	No
CoolRunner XPLA3	No
CoolRunner-II	No

CLOCK_SIGNAL Applicable Elements

Signals

CLOCK_SIGNAL Propagation Rules

Applies to a clock signal.

CLOCK_SIGNAL Syntax Examples

VHDL

Before using CLOCK_SIGNAL, declare it with the following syntax:

```
attribute clock_signal : string;
```

After declaring CLOCK_SIGNAL, specify the VHDL constraint as follows:

```
attribute clock_signal of signal_name : signal is "yes";
```

Verilog

Specify as follows:

```
// synthesis attribute clock_signal [of] signal_name [is] "yes";
```

XCF

```
BEGIN MODEL "entity_name"
  NET "primary_clock_signal" {clock_signal={yes|no|true|false}};
END;
```

Global Timing Constraints Support

XST supports the following global timing constraints.

Global Optimization Goal

XST can optimize different regions (register to register, inpad to register, register to outpad, and inpad to outpad) of the design depending on the global optimization goal. Please refer to “[Incremental Synthesis Flow](#)” in [Chapter 3](#) for a detailed description of supported timing constraints. The Global Optimization Goal (`-glob_opt`) command line option selects the global optimization goal.

Note: You cannot specify a value for Global Optimization Goal/`-glob_opt`. XST optimizes the entire design for the best performance.

The following constraints can be applied by using the Global Optimization Goal option.

- ◆ **ALLCLOCKNETS**: optimizes the period of the entire design.
- ◆ **OFFSET_IN_BEFORE**: optimizes the maximum delay from input pad to clock, either for a specific clock or for an entire design.
- ◆ **OFFSET_OUT_AFTER**: optimizes the maximum delay from clock to output pad, either for a specific clock or for an entire design.
- ◆ **INPAD_TO_OUTPAD**: optimizes the maximum delay from input pad to output pad throughout an entire design.
- ◆ **MAX_DELAY**: incorporates all previously mentioned constraints.

These constraints affect the entire design and only apply if no timing constraints are specified via the constraint file.

Define this option globally with the **-glob_opt** command line option of the **run** command. Following is the basic syntax:


```
-glob_opt {allclocknets|offset_in_before|offset_out_after  
|inpad_to_outpad |max_delay}
```

You can specify **-glob_opt** globally with the Global Optimization Goal option in the Synthesis Options tab of the Process Properties dialog box within the Project Navigator.

Domain Definitions

The possible domains are illustrated in the following schematic.

- **ALLCLOCKNETS** (register to register): identifies by default, all paths from register to register on the same clock for all clocks in a design. To take into account inter-clock domain delays, the command line switch **-cross_clock_analysis** must be set to yes.
- **OFFSET_IN_BEFORE** (inpad to register): identifies all paths from all primary input ports to either all sequential elements or the sequential elements driven by the given clock signal name.
- **OFFSET_OUT_AFTER** (register to outpad): is similar to the previous constraint, but sets the constraint from the sequential elements to all primary output ports.
- **INPAD_TO_OUTPAD** (inpad to outpad): sets a maximum combinational path constraint.
- **MAX_DELAY**: identifies all paths defined by the following timing constraints: ALLCLOCKNETS, OFFSET_IN_BEFORE, OFFSET_OUT_AFTER, INPAD_TO_OUTPAD



XCF Timing Constraint Support

IMPORTANT: If you specify timing constraints in the XCF file, Xilinx strongly suggests that you use '/' character as a hierarchy separator instead of '_'. Please refer to "[Hierarchy Separator](#)" page 327 for details on its usage.

IMPORTANT: If all or part of a specified timing constraint is not supported by XST, then XST generates a warning about this and ignores the unsupported timing constraint or unsupported part of it in the Timing Optimization step. If the Write Timing Constraints option is set to *yes*, XST propagates the entire constraint to the final netlist, even if it was ignored at the Timing Optimization step.

The following timing constraints are supported in the XST Constraints File (XCF).

Period

PERIOD is a basic timing constraint and synthesis constraint. A clock period specification checks timing between all synchronous elements within the clock domain as defined in the destination element group. The group may contain paths that pass between clock domains if the clocks are defined as a function of one or the other.

See “[PERIOD](#)” in the *Constraints Guide* for details.

XCF Syntax:

```
NET netname PERIOD = value [{HIGH | LOW} value];
```

Offset

OFFSET is a basic timing constraint. It specifies the timing relationship between an external clock and its associated data-in or data-out pin. OFFSET is used only for pad-related signals, and cannot be used to extend the arrival time specification method to the internal signals in a design.

OFFSET allows you to:

- Calculate whether a setup time is being violated at a flip-flop whose data and clock inputs are derived from external nets.
- Specify the delay of an external output net derived from the Q output of an internal flip-flop being clocked from an external device pin.

See “[OFFSET](#)” in the *Constraints Guide* for details.

XCF Syntax:

```
OFFSET = {IN|OUT} offset_time [units] {BEFORE|AFTER}
clk_name [TIMEGRP group_name];
```

From-To

FROM-TO defines a timing constraint between two groups. A group can be user-defined or predefined (FFS, PADS, RAMS). See “[FROM-TO](#)” in the *Constraints Guide* for details.

XCF Syntax:

```
TIMESPEC TSname = FROM group1 TO group2 value;
```

TNM

TNM is a basic grouping constraint. Use TNM (Timing Name) to identify the elements that make up a group which you can then use in a timing specification. TNM tags specific FFS, RAMS, LATCHES, PADS, BRAMS_PORTA, BRAMS_PORTB, CPUS, HSIOS, and MULTS as members of a group to simplify the application of timing specifications to the group.

The RISING and FALLING keywords may also be used with TNMs. See “[TNM](#)” in the *Constraints Guide* for details.

XCF Syntax:

```
{INST | NET | PIN} inst_net_or_pin_name TNM = [predefined_group:] identifier;
```

TNM Net

TNM_NET is essentially equivalent to TNM on a net *except* for input pad nets. (Special rules apply when using TNM_NET with the PERIOD constraint for Virtex, Virtex-E, Virtex-II, Virtex-II Pro, Virtex-II Pro X, Virtex-4 or Spartan-3 DLL/DCMs. See the "PERIOD Specifications on CLKDLLs and DCMs" subsection of "["PERIOD"](#)" in the *Constraints Guide*.)

A TNM_NET is a property that you normally use in conjunction with an HDL design to tag a specific net. All downstream synchronous elements and pads tagged with the TNM_NET identifier are considered a group. See "["TNM_NET"](#)" in the *Constraints Guide* for details.

XCF Syntax:

```
NET netname TNM_NET = [predefined_group:] identifier;
```

TIMEGRP

TIMEGRP is a basic grouping constraint. In addition to naming groups using the TNM identifier, you can also define groups in terms of other groups. You can create a group that is a combination of existing groups by defining a TIMEGRP constraint.

You can place TIMEGRP constraints in a constraints file (XCF or NCF). You can use TIMEGRP attributes to create groups using the following methods.

- Combining multiple groups into one
- Defining flip-flop subgroups by clock sense

See "["TIMEGRP"](#)" in the *Constraints Guide* for details.

XCF Syntax:

```
TIMEGRP newgroup = existing_grp1 existing_grp2 [existing_grp3 ...];
```

TIG

The TIG constraint causes all paths going through a specific net to be ignored for timing analyses and optimization purposes. This constraint can be applied to the name of the signal affected. See "["TIG"](#)" in the *Constraints Guide* for details.

XCF Syntax:

```
NET net_name TIG;
```

Constraints Summary

Table 5-1 summarizes all available XST-specific non-timing related options. This table shows the allowed values for each constraint, the type of objects they can be applied to, and any usage restrictions. Default values are indicated in bold.

Note: Please note that in many cases, a particular constraint can be applied globally to an entire entity or model, or alternatively, it can be applied locally to individual signals, nets or instances.

Table 5-1: XST-Specific Non-timing Options

Constraint Name	Constraint Value	XCF Constraint Syntax Target	VHDL Target	Verilog Target	Cmd Line	Cmd Value
XST Constraints						
box_type	primitive, black_box, user_black_box	model, inst(in model)	VHDL: component, entity Verilog: label, module	component, entity	no	na
buffer_type	bufgdll, ibufg, bufgp , ibuf, none	net (in model)	signal	signal	no	bufgdll, ibufg, bufgp , ibuf, bufr, none
bufgce	yes , no, true , false	net (in model)	primary clock signal	primary clock signal	no	na
bram_map	yes , no , true, false	model	VHDL: entity Verilog: module	entity	-bram_map	yes , no
clock_buffer	bufgdll, ibufg, bufgp , ibuf, none	net (in model)	signal	signal	no	na
clock_signal	yes , no, true , false	clock signal, net (in model)	clock signal	clock signal	no	na
decoder_extract	yes , no true , false	model, net (in model)	entity, signal	entity, signal	-decoder_extract	yes , no
dsp_utilization_ratio	na	na	na	na	-dsp_utilization_ratio	<i>integer</i> , <i>integer%</i> , <i>integer#</i>
enable_auto_floorplanning	na	na	na	na	-enable_auto_floorplanning	no , incremental- _design
enum_encoding	string containing space-separated binary codes	net (in model)	type	signal	no	na
equivalent_register_-removal	yes , no, true , false	model, net (in model)	entity, signal	module, signal	-equivalent_register_-removal	yes , no
fsm_encoding	auto , one-hot, compact, sequential, gray, johnson, speed1,user	model, net (in model)	entity, signal	module, signal	-fsm_encoding	auto , one-hot, compact, sequential, gray, johnson, speed1, user
fsm_extract	yes , no, true , false	model, net (in model)	entity, signal	module, signal	-fsm_extract	yes , no

Table 5-1: XST-Specific Non-timing Options

Constraint Name	Constraint Value	XCF Constraint Syntax Target	VHDL Target	Verilog Target	Cmd Line	Cmd Value
fsm_style	lut , bram	model, net (in model)	entity, signal	module, signal	-fsm_style	lut , bram
full_case	na	na	case statement	case statement	no	na
incremental_synthesis	yes , no , true , false	model	entity	module	no	na
iob	true, false, auto	net(in model), inst(in model)	signal, instance	signal, instance	-iob	true, false, auto
iostandard	<i>string</i> : See <i>Constraints Guide</i> for details	net(in model), inst(in model)	signal, instance	signal, instance	no	na
keep	yes , no , true , false	net (in model)	signal	signal	no	na
keep_hierarchy	yes , no , true , false , soft	model	entity	module	-keep_hierarchy	yes , no , soft
loc	<i>string</i>	net(in model), inst(in model)	signal (primary IO), ,instance1	signal (primary IO), instance	no	na
lut_map	yes , no , true , false	model	entity, architecture	module	no	na
max_fanout	<i>integer</i>	model, net (in model)	entity, signal	module, signal	-max_fanout	<i>integer</i>
move_first_stage	yes , no , true , false	model, primary clock signal, net (in model)	entity, primary clock signal	module, primary clock signal	-move_first_stage	yes , no
move_last_stage	yes , no , true , false	model, primary clock signal, net (in model)	entity, primary clock signal	module, primary clock signal	-move_last_stage	yes , no
mult_style	auto , block, lut, pipe_lut, kcm,csd	model, net (in model)	entity, signal	module, signal	-mult_style	auto , block, lut, pipe_lut
mux_extract	yes , no , force, true , false	model, net (in model)	entity, signal	module, signal	-mux_extract	yes , no , force
mux_style	auto , muxf, muxcy	model, net (in model)	entity, signal	module, signal	-mux_style	auto , muxf, muxcy
noreduce	yes , no , true , false	net (in model)	signal	signal	no	na
optimize_primitives	yes , no , true , false	model, instance (in model)	entity, instance	module, instance	-optimize_primitives	yes, no

Table 5-1: XST-Specific Non-timing Options

Constraint Name	Constraint Value	XCF Constraint Syntax Target	VHDL Target	Verilog Target	Cmd Line	Cmd Value
opt_level	1, 2	model	entity	module	-opt_level	1, 2
opt_mode	speed , area	model	entity	module	-opt_mode	speed , area
parallel_case	na	na	case statement	case statement	no	na
priority_extract	yes , no, force, true , false	model, net (in model)	entity, signal	module, signal	-priority_extract	yes , no, force
ram_extract	yes , no, true , false	model, net (in model)	entity, signal	module, signal	-ram_extract	yes , no
ram_style	auto , block, distributed, pipe_distributed	model, net (in model)	entity, signal	module, signal	-ram_style	auto , block, distributed
register_balancing	yes, no , forward, backward, true , false	model, net (in model), inst (in model)	entity, signal, FF instance name, primary clock signal	module, signal, FF instance name, primary clock signal	-register_balancing	yes, no, forward, backward
register_duplication	yes , no, true , false	model, net (in model)	entity, signal	module	-register_duplication	yes , no
register_powerup	<i>string</i>	net (in model)	type	signal	no	na
resource_sharing	yes , no true , false	model, net (in model)	entity, signal	module, signal	-resource_sharing	yes , no
resynthesize	yes , no, true , false	model	entity	module	no	na
rom_extract	yes , no, true , false	model, net (in model)	entity, signal	module, signal	-rom_extract	yes , no
rom_style	auto , block, distributed	model, net (in model)	entity, signal	module, signal	-rom_style	auto , block, distributed
safe_implementation	yes, no , true, false	model, net (in model)	entity, signal	module, signal	-safe_implementation	yes, no
safe_recovery_state	<i>string</i>	net (in model)	signal	signal	no	na
shift_extract	yes , no true , false	model, net (in model)	entity, signal	module, signal	-shift_extract	yes , no
shreg_extract	yes , no, true , false	model, net (in model)	entity, signal	module, signal	-shreg_extract	yes , no
signal_encoding	auto , one-hot, user	model, net (in model)	entity, signal	module, signal	-signal_encoding	auto , one-hot, user
slice_utilization_ratio	<i>integer</i> <i>integer%</i> <i>integer#</i> (range 0-100)	model	entity	module	-slice_utilization_ratio	<i>integer</i> <i>integer%</i> <i>integer#</i> (range 0-100)

Table 5-1: XST-Specific Non-timing Options

Constraint Name	Constraint Value	XCF Constraint Syntax Target	VHDL Target	Verilog Target	Cmd Line	Cmd Value
slice_utilization_ratio_maxmargin	<i>integer integer% integer# (range 0-100)</i>	model	entity	module	-slice_utilization_ratio_maxmargin	<i>integer integer% integer# (range 0-100)</i>
translate_off	na	na	local, no target	local, no target	no	na
translate_on	na	na	local, no target	local, no target	no	na
use_carry_chain	yes, no, true , false	model, net (in model)	entity, signal	module, signal	-use_carry_chain	yes, no
use_clock_enable	auto , yes, no, true, false	model, net (in model) inst(in model)	entity, signal, FF instance name	module, signal, FF instance name	-use_clock_enable	auto , yes, no
use_dsp48	auto , yes, no, true, false	model, net (in model)	entity, signal	module, signal	-use_dsp48	auto , yes, no
use_sync_reset	auto , yes no, true, false	model, net (in model) inst(in model)	entity, signal, FF instance name	module, signal, FF instance name	-use_sync_reset	auto , yes, no
use_sync_set	auto , yes, no, true, false	model, net (in model) inst(in model)	entity, signal, FF instance name	module, signal, FF instance name	-use_sync_set	auto , yes, no
uselowskewlines	yes, no, true , false	net (in model)	signal	signal	no	na
xorCollapse	yes, no true , false	model, net (in model)	entity, signal	module, signal	-xorCollapse	yes, no

XST Command Line Only Options

arch	na	na	na	na	-arch	<i>architecture_name</i>
bufg	na	na	na	na	-bufg	<i>integer</i>
bufr	na	na	na	na	-bufr	<i>integer</i>
bus_delimiter	na	na	na	na	-bus_delimiter	<>, [], { }, ()
case	na	na	na	na	-case	upper,lower, maintain
duplication_suffix	na	na	na	na	-duplication_suffix	<i>string%wstring</i>

Table 5-1: XST-Specific Non-timing Options

Constraint Name	Constraint Value	XCF Constraint Syntax Target	VHDL Target	Verilog Target	Cmd Line	Cmd Value
ent	na	na	na	na	-ent	<i>entity_name</i> Note: Valid only when old VHDL project format is used (-ifmt VHDL). Please use project format (-ifmt mixed) and -top switch to specify which top level block to synthesize.
hierarchy_separator	na	na	na	na	-hierarchy_separator	<i>_</i> / default is /
hdl_compilation_order	na	na	na	na	-hdl_compilation_order	yes, no
ifn	na	na	na	na	-ifn	auto, user
ifmt	na	na	na	na	-ifmt	vhdl, verilog, mixes
iobuf	na	na	na	na	-iobuf	yes, no
iuc	na	na	na	na	-iuc	yes, no
lso	na	na	na	na	-lso	<i>file_name</i>
ofn	na	na	na	na	-ofn	<i>file_name</i>
ofmt	na	na	na	na	-ofmt	ngc
p	na	na	na	na	-p	part-package-speed for example: xcv50-fg456-5: xcv50-fg456-6
pld_ce	na	na	na	na	-pld_ce	yes, no
pld_ffopt	na	na	na	na	-pld_ffopt	yes, no
pld_mp	na	na	na	na	-pld_mp	yes, no
pld_xp	na	na	na	na	-pld_xp	yes, no
read_cores	na	na	na	na	-read_cores	yes, no, optimize
rtlview	na	na	na	na	-rtlview	yes, no, only

Table 5-1: XST-Specific Non-timing Options

Constraint Name	Constraint Value	XCF Constraint Syntax Target	VHDL Target	Verilog Target	Cmd Line	Cmd Value
sd	na	na	na	na	-sd	<i>directory_path</i>
top	na	na	na	na	-top	<i>block_name</i>
tristate2logic	yes, no, true, false (internal tristates only)	model, net (in model)	entity, signal	module, signal	-tristate2logic	yes, no
slice_packing	na	na	na	na	-slice_packing	yes, no
uc	na	na	na	na	-uc	<i>file_name.xcf</i>
verilog2001	na	na	na	na	-verilog2001	yes, no
vlgcase	na	na	na	na	-vlgcase	full, parallel, full-parallel
vlgincldir	na	na	na	na	-vlgincldir	<i>dir_path</i>
work_lib	na	na	na	na	-work_lib	<i>dir_name, work</i>
wysiwyg	na	na	na	na	-wysiwyg	yes, no
xsthdpdir	<i>directory_path</i>	na	na	na	-xsthdpdir	yes, no
xsthdpini	<i>file_name</i>	na	na	na	-xsthdpini	<i>file_name</i>

The following table shows the timing constraints supported by XST that you can invoke only from the command line, or the Process Properties dialog box in Project Navigator.

Table 5-2: XST Timing Constraints Supported Only by Command Line/Process Properties Dialog Box

Option	Process Property (ProjNav)	Values	Technology
glob_opt	Global Optimization Goal	allclocknets inpad_to_outpad offset_in_before offset_out_after max_delay	Spartan-II/IIE/3, Virtex/II/II Pro/ II Pro X/E/4, XC9500™, CoolRunner™ XPLA3/II
cross_clock_analysis	Cross Clock Analysis	yes, no	Spartan-II/IIE/3, Virtex/II/II Pro/ II Pro X/E/4, XC9500, CoolRunner XPLA3/II
write_timing_constraints	Write Timing Constraints	yes, no	Spartan-II/IIE/3, Virtex/II/II Pro/ II Pro X/E/4, XC9500, CoolRunner XPLA3/II

The following table shows the timing constraints supported by XST that you can invoke only through the Xilinx® Constraint File (XCF).

Table 5-3: XST Timing Constraints Supported Only in XCF

Name	Value	Target	Technology
period	See the <i>Constraints Guide</i> for details.	See the <i>Constraints Guide</i> for details.	Spartan-II/IIE/3, Virtex/II/II Pro/ II Pro X/E/4
offset	See the <i>Constraints Guide</i> for details.	See the <i>Constraints Guide</i> for details.	Spartan-II/IIE/3, Virtex/II/II Pro/ II Pro X/E/4
timespec	See the <i>Constraints Guide</i> for details.	See the <i>Constraints Guide</i> for details.	Spartan-II/IIE/3, Virtex/II/II Pro/ II Pro X/E/4
tsidentifier	See the <i>Constraints Guide</i> for details.	See the <i>Constraints Guide</i> for details.	Spartan-II/IIE/3, Virtex/II/II Pro/ II Pro X/E/4
tmn	See the <i>Constraints Guide</i> for details.	See the <i>Constraints Guide</i> for details.	Spartan-II/IIE/3, Virtex/II/II Pro/ II Pro X/E/4
tnm_net	See the <i>Constraints Guide</i> for details.	See the <i>Constraints Guide</i> for details.	Spartan-II/IIE/3, Virtex/II/II Pro/ II Pro X/E/4
timegrp	See the <i>Constraints Guide</i> for details.	See the <i>Constraints Guide</i> for details.	Spartan-II/IIE/3, Virtex/II/II Pro/ II Pro X/E/4
tig	See the <i>Constraints Guide</i> for details.	See the <i>Constraints Guide</i> for details.	Spartan-II/IIE/3, Virtex/II/II Pro/ II Pro X/E/4
from... to...	See the <i>Constraints Guide</i> for details.	See the <i>Constraints Guide</i> for details.	Spartan-II/IIE/3, Virtex/II/II Pro/ II Pro X/E/4

Implementation Constraints

This section explains how XST handles implementation constraints. See the *Constraints Guide* for details on the implementation constraints supported by XST.

Handling by XST

Implementation constraints control placement and routing. They are not directly useful to XST, and are simply propagated and made available to the implementation tools. When the `-write_timing_constraints` switch is set to *yes*, the constraints are written in the output NGC file (Note: TIG is propagated regardless of the setting). In addition, the object that an implementation constraint is attached to is preserved.

A binary equivalent of the implementation constraints is written to the NGC file, but since it is a binary file, you cannot edit the implementation constraints there. Alternatively, you can code implementation constraints in the XCF file according to one of the following syntaxes.

To apply a constraint to an entire entity, use one of the following two XCF syntaxes:

```
MODEL EntityName propertyName;  
MODEL EntityName propertyName=PropertyValue;
```

To apply a constraint to specific instances, nets or pins within an entity, use one of the two following syntaxes:

```
BEGIN MODEL EntityName  
  {NET | INST | PIN}{NetName | InstName | SigName} propertyName;  
END;  
  
BEGIN MODEL EntityName  
  {NET | INST | PIN}{NetName | InstName | SigName} propertyName=PropertyValue;  
END;
```

When written in VHDL code, they should be specified as follows:

```
attribute propertyName of {NetName | InstName | PinName} : {signal | label}  
is "PropertyValue";
```

In a Verilog description, they should be written as follows:

```
// synthesis attribute propertyName of {NetName | InstName | PinName} is  
"PropertyValue";
```

In Verilog-2001, where descriptions must precede the signal, module or instance they refer to, it should be written as follows:

```
(* propertyName="PropertyValue" *)
```

Examples

Following are three examples.

Example 1

When targeting an FPGA device, use the RLOC constraint to indicate the placement of a design element on the FPGA die relative to other elements. Assuming an SRL16 instance of name srl1 to be placed at location R9C0.S0, you may specify the following in your Verilog code:

```
// synthesis attribute RLOC of srl1 : "R9C0.S0";
```

You may specify the same attribute in the XCF file with the following lines:

```
BEGIN MODEL ENTNAME
    INST srl1 RLOC=R9C0.S0;
END;
```

The binary equivalent of the following line is written to the output NGC file:

```
INST srl1 RLOC=R9C0.S0;
```

Example 2

The NOREDUCE constraint, available with CPLDs, prevents the optimization of the boolean equation generating a given signal. Assuming a local signal is assigned the arbitrary function below, and a NOREDUCE constraint attached to the signal s:

```
signal s : std_logic;
attribute NOREDUCE : boolean;
attribute NOREDUCE of s : signal is "true";
...
s <= a or (a and b);
```

You may specify the same attribute in the XCF file with the following lines:

```
BEGIN MODEL ENTNAME
    NET s NOREDUCE;
    NET s KEEP;
END;
```

The following statements are written to the NGC file:

```
NET s NOREDUCE;
NET s KEEP;
```

Example 3

The PWR_MODE constraint, available when targeting CPLD families, controls the power consumption characteristics of macrocells. The following VHDL statement specifies that the function generating signal s should be optimized for low power consumption.

```
attribute PWR_MODE : string;
attribute PWR_MODE of s : signal is "LOW";
```

You may specify the same attribute in the XCF file with the following lines:

```
MODEL ENTNAME
    NET s PWR_MODE=LOW;
    NET s KEEP;
END;
```

The following statement is written to the NGC file by XST:

```
NET s PWR_MODE=LOW;
NET s KEEP;
```

If the attribute applies to an instance (for example, IOB, DRIVE, IOSTANDARD) and if the instance is not available (not instantiated) in the HDL source, then the HDL attribute can be applied to the signal on which XST infers the instance.

Third Party Constraints

This section describes constraints of third-party synthesis vendors that are supported by XST. For each of the constraints, [Table 5-4](#) gives the XST equivalent. For information on what these constraints actually do, please refer to the corresponding vendor documentation. Note that "NA" stands for "Not Available".

Table 5-4: Third Party Constraints

Name	Vendor	XST Equivalent	Automatic Recognition	Available For
black_box	Synplicity	box_type	na	VHDL/ Verilog
black_box_pad_pin	Synplicity	na	na	na
black_box_tri_pins	Synplicity	na	na	na
cell_list	Synopsys	na	na	na
clock_list	Synopsys	na	na	na
Enum	Synopsys	na	na	na
full_case	Synplicity/ Synopsys	full_case	na	Verilog
ispad	Synplicity	na	na	na
map_to_module	Synopsys	na	na	na
net_name	Synopsys	na	na	na
parallel_case	Synplicity Synopsys	parallel_case	na	Verilog
return_port_name	Synopsys	na	na	na
resource_sharing_directives	Synopsys	resource_sharing directives	na	VHDL/ Verilog
set_dont_touch_network	Synopsys	not required	na	na
set_dont_touch	Synopsys	not required	na	na
set_dont_use_cel_name	Synopsys	not required	na	na
set_prefer	Synopsys	na	na	na
state_vector	Synopsys	na	na	na
syn_allow_retiming	Synplicity	register_balancing	na	VHDL/ Verilog

Table 5-4: Third Party Constraints

Name	Vendor	XST Equivalent	Automatic Recognition	Available For
syn_black_box	Synplicity	box_type	na	VHDL/ Verilog
syn_direct_enable	Synplicity	na	na	na
syn_edif_bit_format	Synplicity	na	na	na
syn_edif_scalar_format	Synplicity	na	na	na
syn_encoding	Synplicity	fsm_encoding	yes Note: The value <i>safe</i> is not supported for automatic recognition. Please use <i>safe_implementation</i> constraint in XST to activate this mode.	VHDL/ Verilog
syn_enum_encoding	Synplicity	enum_encoding	na	VHDL
syn_hier	Synplicity	keep_hierarchy	<ul style="list-style-type: none"> • syn_hier = hard recognized as keep_hierarchy = soft • syn_hier = remove recognized as keep_hierarchy = no. Note: XST only supports the values <i>hard</i> and <i>remove</i> for syn_hier in automatic recognition.	VHDL/ Verilog
syn_isclock	Synplicity	na	na	na
syn_keep	Synplicity	keep*	yes	VHDL/ Verilog
syn_maxfan	Synplicity	max_fanout	yes	VHDL/ Verilog
syn_netlist_hierarchy	Synplicity	keep_hierarchy	na	VHDL/ Verilog
syn_noarrayports	Synplicity	na	na	na
syn_noclockbuf	Synplicity	buffer_type	yes	VHDL/ Verilog
syn_noprune	Synplicity	optimize_primitives	yes	VHDL/ Verilog
syn_pipeline	Synplicity	Register Balancing	na	VHDL/ Verilog
syn_probe	Synplicity	equivalent_register-_removal	yes	VHDL/ Verilog
syn_ramstyle	Synplicity	na	na	NA

Table 5-4: Third Party Constraints

Name	Vendor	XST Equivalent	Automatic Recognition	Available For
syn_reference_clock	Synplicity	na	na	NA
syn_romstyle	Synplicity	na	na	NA
syn_sharing	Synplicity	register_duplication	yes	VHDL/ Verilog
syn_state_machine	Synplicity	fsm_extract	na	VHDL/ Verilog
syn_tco <n>	Synplicity	na	na	na
syn_tpd <n>	Synplicity	na	na	na
syn_tristate	Synplicity	na	na	na
syn_tristatetomux	Synplicity	na	na	na
syn_tsu <n>	Synplicity	na	na	na
syn_useenables	Synplicity	na	na	na
syn_useioff	Synplicity	iob	na	VHDL/ Verilog
synthesis translate_off / synthesis translate_on	Synplicity / Synopsys	synthesis translate_off / synthesis translate_on	yes	VHDL/ Verilog
xc_alias	Synplicity	na	na	na
xc_clockbuftype	Synplicity	buffer_type	na	VHDL/ Verilog
xc_fast	Synplicity	fast	na	VHDL/ Verilog
xc_fast_auto	Synplicity	fast	na	VHDL/ Verilog
xc_global_buffers	Synplicity	bufg	na	VHDL/ Verilog
xc_ioff	Synplicity	iob	na	VHDL/ Verilog
xc_isgsr	Synplicity	na	na	na
xc_loc	Synplicity	loc	yes	VHDL/ Verilog
xc_map	Synplicity	lut_map	yes Note: Only the value <i>lut</i> is supported for automatic recognition	VHDL/ Verilog
xc_ncf_auto_relax	Synplicity	na	na	na

Table 5-4: Third Party Constraints

Name	Vendor	XST Equivalent	Automatic Recognition	Available For
xc_nodelay	Synplicity	nodelay	na	VHDL/ Verilog
xc_padtype	Synplicity	iostandard	na	VHDL/ Verilog
xc_props	Synplicity	na	na	na
xc_pullup	Synplicity	pullup	pullup	VHDL/ Verilog
xc_rloc	Synplicity	rloc	yes	VHDL/ Verilog
xc_fast	Synplicity	fast	na	VHDL/ Verilog
xc_slow	Synplicity	na	na	na
xc_usest	Synplicity	u_set	yes	VHDL/ Verilog

* You must use the KEEP constraint instead of SIGNAL_PRESERVE.

Verilog example:

```
module testkeep (in1, in2, out1);
    input in1;
    input in2;
    output out1;

    wire aux1;
    wire aux2;

    // synthesis attribute keep of aux1 is "true"
    // synthesis attribute keep of aux2 is "true"

    assign aux1 = in1;
    assign aux2 = in2;
    assign out1 = aux1 & aux2;

endmodule
```

The KEEP constraint can also be applied through the separate synthesis constraint file:

XCF Example Syntax:

```
BEGIN MODEL testkeep
    NET aux1 KEEP=true;
END;
```

These are the only two ways of preserving a signal/net in an HDL design and preventing optimization on the signal or net during synthesis.

Constraints Precedence

Priority depends on the file in which the constraint appears. A constraint in a file accessed later in the design flow overrides a constraint in a file accessed earlier in the design flow. Priority is as follows (first listed is the highest priority, last listed is the lowest).

1. Synthesis Constraint File
2. HDL file
3. Command Line/Process Properties dialog box in Project Navigator

VHDL Language Support

This chapter explains how VHDL is supported for XST. The chapter provides details on the VHDL language, supported constructs, and synthesis options in relationship to XST. The sections in this chapter are as follows:

- “Introduction”
- “File Type Support”
- “Data Types in VHDL”
- “Record Types”
- “Initial Values”
- “Objects in VHDL”
- “Operators”
- “Entity and Architecture Descriptions”
- “Combinatorial Circuits”
- “Sequential Circuits”
- “Functions and Procedures”
- “Assert Statement”
- “Packages”
- “VHDL Language Support”
- “VHDL Reserved Words”

For a complete specification of the VHDL hardware description language, refer to the IEEE VHDL Language Reference Manual.

For a detailed description of supported design constraints, refer to [Chapter 5, “Design Constraints.”](#) For a description of VHDL attribute syntax, see “[VHDL Attribute Syntax](#)” in [Chapter 5.](#)

Introduction

VHDL is a hardware description language that offers a broad set of constructs for describing even the most complicated logic in a compact fashion. The VHDL language is designed to fill a number of requirements throughout the design process:

- Allows the description of the structure of a system — how it is decomposed into subsystems, and how those subsystems are interconnected.
- Allows the specification of the function of a system using familiar programming language forms.

- Allows the design of a system to be simulated prior to being implemented and manufactured. This feature allows you to test for correctness without the delay and expense of hardware prototyping.
- Provides a mechanism for easily producing a detailed, device-dependent version of a design to be synthesized from a more abstract specification. This feature allows you to concentrate on more strategic design decisions, and reduce the overall time to market for the design.

File Type Support

XST supports a limited File Read and File Write capability for VHDL. You can use this file read capability, for example, to initialize RAMs from an external file. You can use file write capability for debugging processes or to write a specific constant or generic value to an external file. Please refer to “[Initializing RAM](#)” in [Chapter 2](#) for more information.

You can use any of the following read functions, which are supported by the standard, std.textio and ieee.std_logic_textio packages, respectively:

Table 6-1: Supported File Types

Function	Package
file (type "text" only)	standard
access (type "line" only)	standard
file_open (file, name, open_kind)	standard
file_close (file)	standard
endfile (file)	standard
text	std.textio
line	std.textio
width	std.textio
readline (text, line)	std.textio
readline (line, bit, boolean)	std.textio
read (line, bit)	std.textio
readline (line, bit_vector, boolean)	std.textio
read (line, bit_vector)	std.textio
read (line, boolean, boolean)	std.textio
read (line, boolean)	std.textio
read (line, character, boolean)	std.textio
read (line, character)	std.textio
read (line, string, boolean)	std.textio
read (line, string)	std.textio
write (file, line)	std.textio

Table 6-1: Supported File Types

Function	Package
write (line, bit, boolean)	std.textio
write (line, bit)	std.textio
write (line, bit_vector, boolean)	std.textio
write (line, bit_vector)	std.textio
write (line, boolean, boolean)	std.textio
write (line, boolean)	std.textio
write (line, character, boolean)	std.textio
write (line, character)	std.textio
write (line, string, boolean)	std.textio
write (line, string)	std.textio
read (line, std_ulogic, boolean)	ieee.std_logic_textio
read (line, std_ulogic)	ieee.std_logic_textio
read (line, std_ulogic_vector), boolean	ieee.std_logic_textio
read (line, std_ulogic_vector)	ieee.std_logic_textio
read (line, std_logic_vector, boolean)	ieee.std_logic_textio
read (line, std_logic_vector)	ieee.std_logic_textio
write (line, std_ulogic, boolean)	ieee.std_logic_textio
write (line, std_ulogic)	ieee.std_logic_textio
write (line, std_ulogic_vector, boolean)	ieee.std_logic_textio
write (line, std_ulogic_vector)	ieee.std_logic_textio
write (line, std_logic_vector, boolean)	ieee.std_logic_textio
write (line, std_logic_vector)	ieee.std_logic_textio
hread	ieee.std_logic_textio

Please refer to “[Initializing RAM](#)” in Chapter 2 for examples on how to use a file read operation.

Debugging Using Write Operation

The following example shows how you can use a write operation for a debugging process.

```
-- 
-- Print 2 constants to the output file
--

library IEEE;
use IEEE.STD_LOGIC_1164.ALL;
use IEEE.STD_LOGIC_arith.ALL;
use IEEE.STD_LOGIC_UNSIGNED.ALL;
use STD.TEXTIO.all;
use IEEE.STD_LOGIC_TEXTIO.all;

entity file_support_1 is
    generic (data_width: integer:= 4);
    port( clk, sel: in std_logic;
          din: in std_logic_vector (data_width - 1 downto 0);
          dout: out std_logic_vector (data_width - 1 downto 0));
end file_support_1;

architecture Behavioral of file_support_1 is
    file results : text is out "test.dat";
    constant base_const: std_logic_vector(data_width - 1 downto 0):=
conv_std_logic_vector(3,data_width);
    constant new_const:  std_logic_vector(data_width - 1 downto 0):=
base_const + "1000";
begin

    process(clk)
        variable txtline : LINE;
    begin
        write(txtline,string'("-----"));
        writeline(results, txtline);
        write(txtline,string'("Base Const: "));
        write(txtline,base_const);
        writeline(results, txtline);

        write(txtline,string'("New Const: "));
        write(txtline,new_const);
        writeline(results, txtline);
        write(txtline,string'("-----"));
        writeline(results, txtline);

        if (clk'event and clk='1') then
            if (sel = '1') then
                dout <= new_const;
            else
                dout <= din;
            end if;
        end if;
    end process;

end Behavioral;
```

Limitations

- During a std_logic read operation, the only characters that may appear in the file being read are '0' and '1'. Other std_logic values are not supported (for example, 'X' or 'Z' are not supported). If any line of the file includes characters other than '0' and '1', XST rejects the design. If a space character is detected in the file, that character will be ignored.
- Avoid using identical names for files placed in different directories.
- Avoid using conditional calls to *read* procedures, as shown in the following example. This can cause problems during simulation.

```
if SEL = '1' then
    read (MY_LINE, A(3 downto 0));
else
    read (MY_LINE, A(1 downto 0));
end if;
```

- When using the endfile function, if you use the following description style:

```
while (not endfile (MY_FILE)) loop
    readline (MY_FILE, MY_LINE);
    read (MY_LINE, MY_DATA);
end loop;
```

XST rejects the design and generates the following error message:

Line <MY_LINE> has not enough elements for target <MY_DATA>.

To fix the problem, add "exit when endfile (MY_FILE);" to the while loop as shown in the following example:

```
while (not endfile (MY_FILE)) loop
    readline (MY_FILE, MY_LINE);
    exit when endfile (MY_FILE);
    read (MY_LINE, MY_DATA);
end loop;
```

Data Types in VHDL

XST accepts the following VHDL basic types:

- Enumerated Types:
 - ◆ BIT ('0','1')
 - ◆ BOOLEAN (false, true)
 - ◆ REAL (\$-. to \$+.)
 - ◆ STD_LOGIC ('U','X','0','1','Z','W','L','H','-') where:
 - 'U' means uninitialized
 - 'X' means unknown
 - '0' means low
 - '1' means high
 - 'Z' means high impedance
 - 'W' means weak unknown
 - 'L' means weak low
 - 'H' means weak high

'-' means don't care

For XST synthesis, the '0' and 'L' values are treated identically, as are '1' and 'H'. The 'X', and '-' values are treated as don't care. The 'U' and 'W' values are not accepted by XST. The 'Z' value is treated as high impedance.

- ◆ User defined enumerated type:

```
type COLOR is (RED,GREEN,YELLOW);
```

- Bit Vector Types:

- ◆ BIT_VECTOR

- ◆ STD_LOGIC_VECTOR

Unconstrained types (types whose length is not defined) are not accepted.

- Integer Type: INTEGER

The following types are VHDL predefined types.

- BIT
- BOOLEAN
- BIT_VECTOR
- INTEGER
- REAL

The following types are declared in the STD_LOGIC_1164 IEEE package.

- STD_LOGIC
- STD_LOGIC_VECTOR

This package is compiled in the IEEE library. In order to use one of these types, the following two lines must be added to the VHDL specification:

```
library IEEE;
use IEEE.STD_LOGIC_1164.all;
```

Overloaded Data Types

The following basic types can be overloaded.

- Enumerated Types:

- ◆ STD_ULOGIC: contains the same nine values as the STD_LOGIC type, but does not contain predefined resolution functions
- ◆ X01: subtype of STD_ULOGIC containing the 'X', '0' and '1' values
- ◆ X01Z: subtype of STD_ULOGIC containing the 'X', '0', '1' and 'Z' values
- ◆ UX01: subtype of STD_ULOGIC containing the 'U', 'X', '0' and '1' values
- ◆ UX01Z: subtype of STD_ULOGIC containing the 'U', 'X', '0', '1' and 'Z' values

- Bit Vector Types:

- ◆ STD_ULOGIC_VECTOR
- ◆ UNSIGNED
- ◆ SIGNED

Unconstrained types (types whose length is not defined) are not accepted.

- Integer Types:
 - ◆ NATURAL
 - ◆ POSITIVE

Any integer type within a user-defined range. As an example, "type MSB is range 8 to 15;" means any integer greater than 7 or less than 16.

The types NATURAL and POSITIVE are VHDL predefined types.

The types STD_ULONGIC (and subtypes X01, X01Z, UX01, UX01Z), STD_LOGIC, STD_ULONGIC_VECTOR and STD_LOGIC_VECTOR are declared in the STD_LOGIC_1164 IEEE package. This package is compiled in the library IEEE. In order to use one of these types, the following two lines must be added to the VHDL specification:

```
library IEEE;
use IEEE.STD_LOGIC_1164.all;
```

The types UNSIGNED and SIGNED (defined as an array of STD_LOGIC) are declared in the STD_LOGIC_ARITH IEEE package. This package is compiled in the library IEEE. In order to use these types, the following two lines must be added to the VHDL specification:

```
library IEEE;
use IEEE.STD_LOGIC_ARITH.all;
```

Multi-dimensional Array Types

XST supports multi-dimensional array types of up to three dimensions. Arrays can be signals, constants, or VHDL variables. You can do assignments and arithmetic operations with arrays. You can also pass multi-dimensional arrays to functions, and use them in instantiations.

The array must be fully constrained in all dimensions. An example is shown below:

```
subtype WORD8 is STD_LOGIC_VECTOR (7 downto 0);
type TAB12 is array (11 downto 0) of WORD8;
type TAB03 is array (2 downto 0) of TAB12;
```

You can also declare an array as a matrix, as in the following example:

```
subtype TAB13 is array (7 downto 0, 4 downto 0)
of STD_LOGIC_VECTOR (8 downto 0);
```

The following examples demonstrate the various uses of multi-dimensional array signals and variables in assignments.

Consider the declarations:

```
subtype WORD8 is STD_LOGIC_VECTOR (7 downto 0);
type TAB05 is array (4 downto 0) of WORD8;
type TAB03 is array (2 downto 0) of TAB05;

signal WORD_A : WORD8;
signal TAB_A, TAB_B : TAB05;
signal TAB_C, TAB_D : TAB03;
constant CST_A : TAB03 := (
("0000000", "0000001", "0000010", "0000011", "0000100")
("0010000", "0010001", "0010010", "0100011", "0010100")
("0100000", "0100001", "0100010", "0100011", "0100100"));
```

A multi-dimensional array signal or variable can be completely used:

```
TAB_A <= TAB_B;
TAB_C <= TAB_D;
TAB_C <= CNST_A;
```

Just an index of one array can be specified:

```
TAB_A (5) <= WORD_A;
TAB_C (1) <= TAB_A;
```

Just indexes of the maximum number of dimensions can be specified:

```
TAB_A (5) (0) <= '1';
TAB_C (2) (5) (0) <= '0'
```

Just a slice of the first array can be specified:

```
TAB_A (4 downto 1) <= TAB_B (3 downto 0);
```

Just an index of a higher level array and a slice of a lower level array can be specified:

```
TAB_C (2) (5) (3 downto 0) <= TAB_B (3) (4 downto 1);
TAB_D (0) (4) (2 downto 0) <= CNST_A (5 downto 3)
```

Now add the following declaration:

```
subtype MATRIX15 is array(4 downto 0, 2 downto 0)
of STD_LOGIC_VECTOR (7 downto 0);
```

A multi-dimensional array signal or variable can be completely used:

```
MATRIX15 <= CNST_A;
```

Just an index of one row of the array can be specified:

```
MATRIX15 (5) <= TAB_A;
```

Just indexes of the maximum number of dimensions can be specified:

```
MATRIX15 (5,0) (0) <= '1';
```

Just a slice of one row can be specified:

```
MATRIX15 (4,4 downto 1) <= TAB_B (3 downto 0);
```

Note: Indices may be variable.

Record Types

XST supports record types. An example of a record is shown below.

```
type REC1 is record
    field1: std_logic;
    field2: std_logic_vector (3 downto 0)
end record;
```

- Record types can contain other record types.
- Constants can be record types.
- Record types cannot contain attributes.
- XST supports aggregate assignments to record signals.

Initial Values

In VHDL, you can initialize registers when you declare them.

The value:

- Must be a constant.
- Cannot depend on earlier initial values.
- Cannot be a function or task call.
- Can be a parameter value propagated to a register.

When you give a register an initial value in a declaration, XST sets this value on the output of the register at global reset, or at power up. A value assigned this way is carried in the NGC file as an INIT attribute on the register, and is independent of any local reset.

Example:

```
signal arb_onebit : std_logic := '0';
signal arb_priority : std_logic_vector(3 downto 0) := "1011";
```

You can also assign a set/reset value to a register via your behavioral VHDL code. Do this by assigning a value to a register when the register's reset line goes to the appropriate value as in the following example.

Example:

```
process (clk, rst)
begin
    if rst='1' then
        arb_onebit <= '0';
    end if;
end process;
```

When you set the initial value of a variable in the behavioral code, it is implemented in the design as a flip-flop whose output can be controlled by a local reset; as such it is carried in the NGC file as an FDP or FDC flip-flop.

Local Reset ≠ Global Reset

Note that local reset is independent of global reset. Registers controlled by a local reset may be set to a different value from registers whose value is only reset at global reset (power up). In the following example, the register arb_onebit is set to '1' at global reset, but a pulse on the local reset (rst) can change its value to '0'.

Example:

```
entity top is
  Port (
    clk, rst : in std_logic;
    a_in : in std_logic;
    dout : out std_logic);
end top;
```

```

architecture Behavioral of top is
signal arb_onebit : std_logic := '1';

begin
  process (clk, rst)
  begin
    if rst='1' then
      arb_onebit <= '0';
    elsif (clk'event and clk='1') then
      arb_onebit <= a_in;
    end if;
  end process;

  dout <= arb_onebit;
end Behavioral;

```

This sets the initial value on the register's output to '1' at initial power up, but since this is dependent upon a local reset, the value changes to '0' whenever the local set/reset is activated.

Default Initial Values on Memory Elements

Because every memory element in a Xilinx® FPGA must come up in a known state, in certain cases, XST does not use IEEE standards for initial values. In the previous example, if signal `arb_onebit` were not initialized to '1', XST would assign it a default of '0' as its initial state. In this case, XST does not follow the IEEE standard, where 'U' is the default for `std_logic`. This process of initialization is the same for both registers and RAMs.

Where possible, XST adheres to the IEEE VHDL standard when initializing signal values. If no initial values are supplied in the VHDL code, XST uses the default values (where possible) as outlined in the XST column in [Table 6-2](#).

Table 6-2: Initial Values

Type	IEEE	XST
bit	'0'	'0'
<code>std_logic</code>	'U'	'0'
<code>bit_vector</code> (3 downto 0)	"0000"	"0000"
<code>std_logic_vector</code> (3 downto 0)	"0000"	"0000"
integer (unconstrained)	integer'left	integer'left
integer range 7 downto 0	integer'left = 7	integer'left = 7 (coded as "111")
integer range 0 to 7	integer'left = 0	integer'left = 0 (coded as "000")
Boolean	FALSE	FALSE (coded as '0')
<code>enum(S0,S1,S2,S3)</code>	type'left = S0	type'left = S0 (coded as "000")

Default Initial Values on Unconnected Ports

Output ports that are left unconnected default to the values noted in the XST column of [Table 6-2](#). If the output port has an initial condition, XST ties the unconnected output port to the explicitly defined initial condition. According to the IEEE VHDL specification, input ports cannot be left unconnected. As a result, XST always gives an error if an input port is not connected; even the **open** keyword will not suffice for an unconnected input port.

Objects in VHDL

VHDL objects include signals, variables, and constants.

Signals can be declared in an architecture declarative part and used anywhere within the architecture. Signals can also be declared in a block and used within that block. Signals can be assigned by the assignment operator "<=".

Example:

```
signal sig1 : std_logic;
sig1 <= '1';
```

Variables are declared in a process or a subprogram, and used within that process or that subprogram. Variables can be assigned by the assignment operator ":=".

Example:

```
variable var1 : std_logic_vector (7 downto 0);
var1 := "01010011";
```

Constants can be declared in any declarative region, and can be used within that region. Their value cannot be changed once declared.

Example:

```
signal sig1 : std_logic_vector (5 downto 0);
constant init0 : std_logic_vector (5 downto 0) := "010111";
sig1 <= init0;
```

Operators

Supported operators are listed in [Table 6-9](#). This section provides an example of how to use each shift operator.

Example: sll (Shift Left Logical)

```
sig1 <= A(4 downto 0) sll 2
```

logically equivalent to:

```
sig1 <= A(2 downto 0) & "00";
```

Example: srl (Shift Right Logical)

```
sig1 <= A(4 downto 0) srl 2
```

logically equivalent to:

```
sig1 <= "00" & A(4 downto 2);
```

Example: sla (Shift Left Arithmetic)

```
sig1 <= A(4 downto 0) sla 2
```

logically equivalent to:

```
sig1 <= A(2 downto 0) & A(0) & A(0);
```

Example: sra (Shift Right Arithmetic)

```
sig1 <= A(4 downto 0) sra 2
```

logically equivalent to:

```
sig1 <= <= A(4) & A(4) & A(4 downto 2);
```

Example: rol (Rotate Left)

```
sig1 <= A(4 downto 0) rol 2
```

logically equivalent to:

```
sig1 <= A(2 downto 0) & A(4 downto 3);
```

Example: ror (Rotate Right)

```
A(4 downto 0) ror 2
```

logically equivalent to:

```
sig1 <= A(1 downto 0) & A(4 downto 2);
```

Entity and Architecture Descriptions

A circuit description consists of two parts: the interface (defining the I/O ports) and the body. In VHDL, the entity corresponds to the interface and the architecture describes the behavior.

Entity Declaration

The I/O ports of the circuit are declared in the entity. Each port has a name, a mode (in, out, inout or buffer) and a type (ports A, B, C, D, E in the Example 6-1).

Note that types of ports must be constrained, and not more than one-dimensional array types are accepted as ports.

Architecture Declaration

Internal signals may be declared in the architecture. Each internal signal has a name and a type (signal T in Example 6-1).

Example 6-1 Entity and Architecture Declaration

```
Library IEEE;
use IEEE.std_logic_1164.all;
entity EXAMPLE is
  port (
    A,B,C : in std_logic;
    D,E : out std_logic );
end EXAMPLE;
```

```
architecture ARCHI of EXAMPLE is
    signal T : std_logic;
begin
    ...
end ARCHI;
```

Component Instantiation

Structural descriptions assemble several blocks and allow the introduction of hierarchy in a design. The basic concepts of hardware structure are the component, the port and the signal. The component is the building or basic block. A port is a component I/O connector. A signal corresponds to a wire between components.

In VHDL, a component is represented by a design entity. This is actually a composite consisting of an entity declaration and an architecture body. The entity declaration provides the "external" view of the component; it describes what can be seen from the outside, including the component ports. The architecture body provides an "internal" view; it describes the behavior or the structure of the component.

The connections between components are specified within component instantiation statements. These statements specify an instance of a component occurring inside an architecture of another component. Each component instantiation statement is labeled with an identifier. Besides naming a component declared in a local component declaration, a component instantiation statement contains an association list (the parenthesized list following the reserved word port map) that specifies which actual signals or ports are associated with which local ports of the component declaration.

Note: XST supports unconstrained vectors in component declarations.

Example 6-2 gives the structural description of a half adder composed of four nand2 components.

Example 6-2 Structural Description of a Half Adder

```
entity NAND2 is
    port (
        A,B : in BIT;
        Y : out BIT );
    end NAND2;

architecture ARCHI of NAND2 is
begin
    Y <= A nand B;
end ARCHI;

entity HALFADDER is
    port (
        X,Y : in BIT;
        C,S : out BIT );
    end HALFADDER;
```

```

architecture ARCHI of HALFADDER is
component NAND2
port (
    A,B : in BIT;
    Y : out BIT );
end component;

for all : NAND2 use entity work.NAND2(ARCHI);
signal S1, S2, S3 : BIT;
begin
    NANDA : NAND2 port map (X,Y,S3);
    NANDB : NAND2 port map (X,S3,S1);
    NANDC : NAND2 port map (S3,Y,S2);
    NANDD : NAND2 port map (S1,S2,S);
    C <= S3;
end ARCHI;

```

The synthesized top level netlist is shown in the following figure.




Figure 6-1: Synthesized Top Level Netlist

Recursive Component Instantiation

XST supports recursive component instantiation (please note that direct instantiation is not supported for recursion). Example 6-3 shows a 4-bit shift register description:

Example 6-3 4-bit shift register with Recursive Component Instantiation

```

library ieee;
use ieee.std_logic_1164.all;
library unisim;
use unisim.vcomponents.all;

entity single_stage is
generic (sh_st: integer:=4);
port (
    CLK : in std_logic;
    DI : in std_logic;
    DO : out std_logic );
end entity single_stage;

```

```

architecture recursive of single_stage is
component single_stage
  generic (sh_st: integer);
  port (
    CLK : in std_logic;
    DI  : in std_logic;
    DO  : out std_logic );
end component;

signal tmp : std_logic;

begin
  GEN_FD_LAST: if sh_st=1 generate
    inst_fd: FD port map (D=>DI, C=>CLK, Q=>DO);
  end generate;
  GEN_FD_INTERM: if sh_st /= 1 generate
    inst_fd: FD port map (D=>DI, C=>CLK, Q=>tmp);
    inst_sstage: single_stage generic map (sh_st => sh_st-1)
      port map (DI=>tmp, CLK=>CLK, DO=>DO);
  end generate;
end recursive;

```

Component Configuration

Associating an entity/architecture pair to a component instance provides the means of linking components with the appropriate model (entity/architecture pair). XST supports component configuration in the declarative part of the architecture:

```

for instantiation_list: component_name use
  LibName.entity_Name(Architecture_Name);

```

Example 6-2, Structural Description of a Half Adder, shows how to use a configuration clause for component instantiation. The example contains the following "for all" statement:

```

for all : NAND2 use entity work.NAND2(ARCHI);

```

This statement indicates that all NAND2 components use the entity NAND2 and Architecture ARCHI.

Note: When the configuration clause is missing for a component instantiation, XST links the component to the entity with the same name (and same interface) and the selected architecture to the most recently compiled architecture. If no entity/architecture is found, a black box is generated during synthesis.

Generic Parameter Declaration

Generic parameters may be declared in the entity declaration part. XST supports all types for generics including integer, boolean, string, real, std_logic_vector, etc. An example of using generic parameters would be setting the width of the design. In VHDL, describing circuits with generic ports has the advantage that the same component can be repeatedly instantiated with different values of generic ports as shown in Example 6-4.

Example 6-4 Generic Instantiation of Components

```

Library IEEE;
use IEEE.std_logic_1164.all;
use IEEE.std_logic_unsigned.all;

entity addern is
    generic (width : integer := 8);
    port (
        A,B : in std_logic_vector (width-1 downto 0);
        Y   : out std_logic_vector (width-1 downto 0) );
end addern;

architecture bhv of addern is
begin
    Y <= A + B;
end bhv;

Library IEEE;
use IEEE.std_logic_1164.all;

entity top is
    port (
        X, Y, Z : in std_logic_vector (12 downto 0);
        A, B : in std_logic_vector (4 downto 0);
        S :out std_logic_vector (16 downto 0) );
end top;

architecture bhv of top is
component addern
    generic (width : integer := 8);
    port (
        A,B : in std_logic_vector (width-1 downto 0);
        Y   : out std_logic_vector (width-1 downto 0) );
end component;

for all : addern use entity work.addern(bhv);
signal C1 : std_logic_vector (12 downto 0);
signal C2, C3 : std_logic_vector (16 downto 0);
begin
    U1 : addern generic map (n=>13) port map (X,Y,C1);
    C2 <= C1 & A;
    C3 <= Z & B;
    U2 : addern generic map (n=>17) port map (C2,C3,S);
end bhv;

```

Generic/Attribute Conflicts

Since generics and attributes can be applied to both instances and components in your VHDL code, and attributes can also be specified in a constraints file, from time to time, conflicts will arise. To resolve these conflicts, XST uses the following rules of precedence.

1. Whatever is specified on an instance (lower level) takes precedence over what is specified on a component (higher level).

2. If a generic and an attribute are specified on either the same instance or the same component, the generic takes precedence, and XST issues a message warning of the conflict.
3. An attribute specified in the XCF file will always take precedence over attributes or generics specified in your VHDL code.

Note: When an attribute specified on an instance overrides a generic specified on a component in XST, it is possible that your simulation tool may nevertheless use the generic. This may cause the simulation results to not match the synthesis results.

Use the following matrix as a guide in determining precedence.

	Generic on an Instance	Generic on a Component
Attribute on an Instance	Apply Generic (XST issues warning message)	Apply Attribute (possible simulation mismatch)
Attribute on a Component	Apply Generic	Apply Generic (XST issues warning message)
Attribute in XCF	Apply Attribute (XST issues warning message)	Apply Attribute

Note: Security attributes on the block definition always have higher precedence than any other attribute or generic.

Combinatorial Circuits

The following subsections describe how XST uses various VHDL constructs for combinatorial circuits.

Concurrent Signal Assignments

Combinatorial logic may be described using concurrent signal assignments, which can be defined within the body of the architecture. VHDL offers three types of concurrent signal assignments: simple, selected and conditional. You can describe as many concurrent statements as needed; the order of concurrent signal definition in the architecture is irrelevant.

A concurrent assignment is made of two parts: left hand side, and right hand side. The assignment changes when any signal in the right part changes. In this case, the result is assigned to the signal on the left part.

Simple Signal Assignment

The following example shows a simple assignment.

T <= A and B;

Selected Signal Assignment

The following example shows a selected signal assignment.

Example 6-5 MUX Description Using Selected Signal Assignment

```

library IEEE;
use IEEE.std_logic_1164.all;

entity select_bhv is
    generic (width: integer := 8);
    port (
        a, b, c, d : in std_logic_vector (width-1 downto 0);
        selector : in std_logic_vector (1 downto 0);
        T : out std_logic_vector (width-1 downto 0) );
end select_bhv;

architecture bhv of select_bhv is
begin
    with selector select
        T <= a when "00",
                  b when "01",
                  c when "10",
                  d when others;
end bhv;

```

Conditional Signal Assignment

The following example shows a conditional signal assignment.

Example 6-6 MUX Description Using Conditional Signal Assignment

```

entity when_ent is
    generic (width: integer := 8);
    port (
        a, b, c, d : in std_logic_vector (width-1 downto 0);
        selector : in std_logic_vector (1 downto 0);
        T : out std_logic_vector (width-1 downto 0) );
end when_ent;

architecture bhv of when_ent is
begin
    T <= a when selector = "00" else
          b when selector = "01" else
          c when selector = "10" else
          d;
end bhv;

```

Generate Statement

Repetitive structures are declared with the "generate" VHDL statement. For this purpose, "for I in 1 to N generate" means that the bit slice description is repeated N times. As an example, Example 6-7 gives a description of an 8-bit adder by declaring the bit slice structure.

Example 6-7 8 Bit Adder Described with a "for...generate" Statement

```

entity EXAMPLE is
  port (
    A,B  : in BIT_VECTOR (0 to 7);
    CIN  : in BIT;
    SUM  : out BIT_VECTOR (0 to 7);
    COUT : out BIT );
end EXAMPLE;

architecture ARCHI of EXAMPLE is
  signal C : BIT_VECTOR (0 to 8);
begin
  C(0) <= CIN;
  COUT <= C(8);
  LOOP_ADD : for I in 0 to 7 generate
    SUM(I) <= A(I) xor B(I) xor C(I);
    C(I+1) <= (A(I) and B(I)) or (A(I) and C(I)) or (B(I) and C(I));
  end generate;
end ARCHI;

```

The "if condition generate" statement is supported for static (non-dynamic) conditions. Example 6-8 shows such an example. It is a generic N-bit adder with a width ranging between 4 and 32.

Example 6-8 N Bit Adder Described with an "if...generate" and a "for... generate" Statement

```

entity EXAMPLE is
  generic (N : INTEGER := 8);
  port (
    A,B : in BIT_VECTOR (N downto 0);
    CIN : in BIT;
    SUM : out BIT_VECTOR (N downto 0);
    COUT : out BIT );
end EXAMPLE;

architecture ARCHI of EXAMPLE is
  signal C : BIT_VECTOR (N+1 downto 0);
begin
  L1: if (N>=4 and N<=32) generate
    C(0) <= CIN;
    COUT <= C(N+1);
    LOOP_ADD : for I in 0 to N generate
      SUM(I) <= A(I) xor B(I) xor C(I);
      C(I+1) <= (A(I) and B(I)) or (A(I) and C(I)) or (B(I) and C(I));
    end generate;
  end generate;
end ARCHI;

```

Combinatorial Process

A process assigns values to signals differently than when using concurrent signal assignments. The value assignments are made in a sequential mode. The latest assignments may cancel previous ones. See Example 6-9. First the signal *S* is assigned to 0, but later on (for (A and B) =1), the value for *S* is changed to 1.

Example 6-9 Assignments in a Process

```

entity EXAMPLE is
  port (
    A, B : in BIT;
    S : out BIT );
end EXAMPLE;

architecture ARCHI of EXAMPLE is
begin
  process (A, B)
  begin
    S <= '0' ;
    if ((A and B) = '1') then
      S <= '1' ;
    end if;
  end process;
end ARCHI;

```

A process is called combinatorial when its inferred hardware does not involve any memory elements. Said differently, when all assigned signals in a process are always explicitly assigned in all paths of the Process statements, then the process is combinatorial.

A combinatorial process has a sensitivity list appearing within parentheses after the word "process". A process is activated if an event (value change) appears on one of the sensitivity list signals. For a combinatorial process, this sensitivity list must contain all signals which appear in conditions (if, case, etc.), and any signal appearing on the right hand side of an assignment.

If one or more signals are missing from the sensitivity list, XST generates a warning for the missing signals and adds them to the sensitivity list. In this case, the result of the synthesis may be different from the initial design specification.

A process may contain local variables. The variables are handled in a similar manner as signals (but are not, of course, outputs to the design).

In Example 6-10, a variable named AUX is declared in the declarative part of the process and is assigned to a value (with ":=") in the statement part of the process. Examples 6-10 and 6-11 are two examples of a VHDL design using combinatorial processes.

Example 6-10 Combinatorial Process

```

library ASYL;
use ASYL.ARITH.all;

entity ADDSUB is
  port (
    A,B : in BIT_VECTOR (3 downto 0);
    ADD_SUB : in BIT;
    S : out BIT_VECTOR (3 downto 0));
end ADDSUB;

architecture ARCHI of ADDSUB is
begin
  process (A, B, ADD_SUB)
    variable AUX : BIT_VECTOR (3 downto 0);

```

```

begin
    if ADD_SUB = '1' then
        AUX := A + B ;
    else
        AUX := A - B ;
    end if;
    S <= AUX;
end process;
end ARCHI;

```

Example 6-11 Combinatorial Process

```

entity EXAMPLE is
    port (
        A, B : in BIT;
        S : out BIT  );
end EXAMPLE;

architecture ARCHI of EXAMPLE is
begin
    process (A,B)
        variable X, Y : BIT;
    begin
        X := A and B;
        Y := B and A;
        if X = Y then
            S <= '1' ;
        end if;
    end process;
end ARCHI;

```

Note: In combinatorial processes, if a signal is not explicitly assigned in all branches of "if" or "case" statements, XST generates a latch to hold the last value. To avoid latch creation, ensure that all assigned signals in a combinatorial process are always explicitly assigned in all paths of the Process statements.

Different statements can be used in a process:

- Variable and signal assignment
- If statement
- Case statement
- For...Loop statement
- Function and procedure call

The following sections provide examples of each of these statements.

If...Else Statement

If...else statements use true/false conditions to execute statements. If the expression evaluates to true, the first statement is executed. If the expression evaluates to false (or x or z), the Else statement is executed. A block of multiple statements may be executed using begin and end keywords. If... else statements may be nested. Example 6-12 shows the use of an If...else statement.

Example 6-12 MUX Description Using If...Else Statement

```

library IEEE;
use IEEE.std_logic_1164.all;

entity mux4 is
    port (
        a, b, c, d : in std_logic_vector (7 downto 0);
        sel1, sel2 : in std_logic;
        outmux : out std_logic_vector (7 downto 0));
end mux4;

architecture behavior of mux4 is
begin
    process (a, b, c, d, sel1, sel2)
    begin
        if (sel1 = '1') then
            if (sel2 = '1') then
                outmux <= a;
            else
                outmux <= b;
            end if;
        else
            if (sel2 = '1') then
                outmux <= c;
            else
                outmux <= d;
            end if;
        end if;
    end process;
end behavior;

```

Case Statement

Case statements perform a comparison to an expression to evaluate one of a number of parallel branches. The Case statement evaluates the branches in the order they are written; the first branch that evaluates to true is executed. If none of the branches match, the default branch is executed. Example 6-13 shows the use of a Case statement.

Example 6-13 MUX Description Using the Case Statement

```

library IEEE;
use IEEE.std_logic_1164.all;

entity mux4 is
    port (
        a, b, c, d : in std_logic_vector (7 downto 0);
        sel : in std_logic_vector (1 downto 0);
        outmux : out std_logic_vector (7 downto 0));
end mux4;

```

```

architecture behavior of mux4 is
begin
    process (a, b, c, d, sel)
    begin
        case sel is
            when "00" => outmux <= a;
            when "01" => outmux <= b;
            when "10" => outmux <= c;
            when others => outmux <= d; -- case statement must be complete
        end case;
    end process;
end behavior;

```

For...Loop Statement

The For statement is supported for:

- Constant bounds
- Stop test condition using operators `<`, `<=`, `>` or `>=`
- Next step computation falling within one of the following specifications:
 - ◆ $var = var + step$
 - ◆ $var = var - step$
 (where *var* is the loop variable and *step* is a constant value)
- Next and Exit statements are supported

Example 6-14 shows the use of a For...loop statement.

Example 6-14 For...Loop Description

```

library IEEE;
use IEEE.std_logic_1164.all;
use IEEE.std_logic_unsigned.all;

entity countzeros is
    port (
        a : in std_logic_vector (7 downto 0);
        Count : out std_logic_vector (2 downto 0) );
    end mux4;

architecture behavior of mux4 is
    signal Count_Aux: std_logic_vector (2 downto 0);
begin
    process (a)
    begin
        Count_Aux <= "000";
        for i in a'range loop
            if (a[i] = '0') then
                Count_Aux <= Count_Aux + 1; -- operator "+" defined
                                         -- in std_logic_unsigned
            end if;
        end loop;
        Count <= Count_Aux;
    end process;
end behavior;

```

Sequential Circuits

Sequential circuits can be described using sequential processes. The following two types of descriptions are allowed by XST:

- sequential processes with a sensitivity list
- sequential processes without a sensitivity list

Sequential Process with a Sensitivity List

A process is sequential when it is not a combinatorial process. In other words, a process is sequential when some assigned signals are not explicitly assigned in all paths of the statements. In this case, the hardware generated has an internal state or memory (flip-flops or latches).

Example 6-15 provides a template for describing sequential circuits. Also refer to the chapter describing macro inference for additional details (registers, counters, etc.).

Example 6-15 Sequential Process with Asynchronous, Synchronous Parts

```
process (CLK, RST)    ...
begin
    if RST = <'0' | '1'> then
        -- an asynchronous part may appear here
        -- optional part
        .....
    elsif <CLK'EVENT | not CLK'STABLE>
        and CLK = <'0' | '1'> then
            -- synchronous part
            -- sequential statements may appear here
        end if;
end process;
```

Note: Asynchronous signals must be declared in the sensitivity list. Otherwise, XST generates a warning and adds them to the sensitivity list. In this case, the behavior of the synthesis result may be different from the initial specification.

Sequential Process without a Sensitivity List

Sequential processes without a sensitivity list must contain a Wait statement. The Wait statement must be the first statement of the process. The condition in the Wait statement must be a condition on the clock signal. Several Wait statements in the same process are accepted, but a set of specific conditions must be respected. See “[Multiple Wait Statements Descriptions](#)” for details. An asynchronous part cannot be specified within processes without a sensitivity list.

Example 6-16 shows the skeleton of such a process. The clock condition may be a falling or a rising edge.

Example 6-16 Sequential Process Without a Sensitivity List

```
process ...
begin
    wait until <CLK'EVENT | not CLK' STABLE> and CLK = <'0' | '1'>;
    ... -- a synchronous part may be specified here.
end process;
```

Note: XST does not support clock and clock enable descriptions within the same Wait statement. Instead, code these descriptions as in Example 6-17.

Note: XST does not support Wait statements for latch descriptions.

Example 6-17 Clock and Clock Enable

Not supported:

```
wait until CLOCK'event and CLOCK = '0' and ENABLE = '1' ;
```

Supported:

```
wait until CLOCK'event and CLOCK = '0' ;
if ENABLE = '1' then ...
```

Examples of Register and Counter Descriptions

Example 6-18 describes an 8-bit register using a process with a sensitivity list. Example 6-19 describes the same example using a process without a sensitivity list containing a Wait statement.

Example 6-18 8 bit Register Description Using a Process with a Sensitivity List

```
entity EXAMPLE is
port (
    DI : in BIT_VECTOR (7 downto 0);
    CLK : in BIT;
    DO : out BIT_VECTOR (7 downto 0) );
end EXAMPLE;
```

```
architecture ARCHI of EXAMPLE is
begin
    process (CLK)
    begin
        if CLK'EVENT and CLK = '1' then
            DO <= DI ;
        end if;
    end process;
end ARCHI;
```

Example 6-19 8 bit Register Description Using a Process without a Sensitivity List

```
entity EXAMPLE is
port (
    DI : in BIT_VECTOR (7 downto 0);
    CLK : in BIT;
    DO : out BIT_VECTOR (7 downto 0) );
end EXAMPLE;
```

```

architecture ARCHI of EXAMPLE is
begin
    process begin
        wait until CLK'EVENT and CLK = '1';
        DO <= DI;
    end process;
end ARCHI;

```

Example 6-20 describes an 8-bit register with a clock signal and an asynchronous reset signal.

Example 6-20 8 bit Register Description Using a Process with a Sensitivity List

```

entity EXAMPLE is
port (
    DI : in BIT_VECTOR (7 downto 0);
    CLK : in BIT;
    RST : in BIT;
    DO : out BIT_VECTOR (7 downto 0));
end EXAMPLE;

architecture ARCHI of EXAMPLE is
begin
    process (CLK, RST)
    begin
        if RST = '1' then
            DO <= "00000000";
        elsif CLK'EVENT and CLK = '1' then
            DO <= DI ;
        end if;
    end process;
end ARCHI;

```

Example 6-21 8 bit Counter Description Using a Process with a Sensitivity List

```

library ASYL;
use ASYL.PKG_ARITH.all;

entity EXAMPLE is
port (
    CLK : in BIT;
    RST : in BIT;
    DO : out BIT_VECTOR (7 downto 0));
end EXAMPLE;

architecture ARCHI of EXAMPLE is
begin
    process (CLK, RST)
        variable COUNT : BIT_VECTOR (7 downto 0);
    begin
        if RST = '1' then
            COUNT := "00000000";
        elsif CLK'EVENT and CLK = '1' then
            COUNT := COUNT + "00000001";
        end if;
        DO <= COUNT;
    end process;
end ARCHI;

```

Multiple Wait Statements Descriptions

Sequential circuits can be described with multiple Wait statements in a process. When using XST, several rules must be respected to use multiple Wait statements. These rules are as follows:

- The process must only contain one Loop statement.
- The first statement in the loop must be a Wait statement.
- After each Wait statement, a Next or Exit statement must be defined.
- The condition in the Wait statements must be the same for each Wait statement.
- This condition must use only one signal — the clock signal.
- This condition must have the following form:

```
"wait [on clock_signal] until [(clock_signal'EVENT |  
not clock_signal'STABLE) and ] clock_signal = {'0' | '1'};"
```

Example 6-22 uses multiple Wait statements. This example describes a sequential circuit performing four different operations in sequence. The design cycle is delimited by two successive rising edges of the clock signal. A synchronous reset is defined providing a way to restart the sequence of operations at the beginning. The sequence of operations consists of assigning each of the four inputs: DATA1, DATA2, DATA3 and DATA4 to the output RESULT.

Example 6-22 Sequential Circuit Using Multiple Wait Statements

```
library IEEE;  
use IEEE.STD_LOGIC_1164.all;  
  
entity EXAMPLE is  
port (  
    DATA1, DATA2, DATA3, DATA4 : in STD_LOGIC_VECTOR (3 downto 0);  
    RESULT : out STD_LOGIC_VECTOR (3 downto 0);  
    CLK : in STD_LOGIC;  
    RST : in STD_LOGIC );  
end EXAMPLE;  
  
architecture ARCH of EXAMPLE is  
begin  
process begin  
    SEQ_LOOP : loop  
        wait until CLK'EVENT and CLK = '1';  
        exit SEQ_LOOP when RST = '1';  
        RESULT <= DATA1;  
  
        wait until CLK'EVENT and CLK = '1';  
        exit SEQ_LOOP when RST = '1';  
        RESULT <= DATA2;  
  
        wait until CLK'EVENT and CLK = '1';  
        exit SEQ_LOOP when RST = '1';  
        RESULT <= DATA3;  
  
        wait until CLK'EVENT and CLK = '1';  
        exit SEQ_LOOP when RST = '1';  
        RESULT <= DATA4;  
    end loop;  
end process;  
end ARCH;
```

Functions and Procedures

The declaration of a function or a procedure provides a mechanism for handling blocks used multiple times in a design. Functions and procedures can be declared in the declarative part of an entity, in an architecture or in packages. The heading part contains the parameters: input parameters for functions and input, output and inout parameters for procedures. These parameters can be unconstrained. This means that they are not constrained to a given bound. The content is similar to the combinatorial process content. Resolution functions are not supported except the one defined in the IEEE std_logic_1164 package.

Example 6-23 shows a function declared within a package. The "ADD" function declared here is a single bit adder. This function is called 4 times with the proper parameters in the architecture to create a 4-bit adder. The same example described using a procedure is shown in Example 6-24.

Example 6-23 Function Declaration and Function Call

```

package PKG is
    function ADD (A,B, CIN : BIT )
        return BIT_VECTOR;
end PKG;

package body PKG is
    function ADD (A,B, CIN : BIT )
        return BIT_VECTOR is
        variable S, COUT : BIT;
        variable RESULT : BIT_VECTOR (1 downto 0);
    begin
        S := A xor B xor CIN;
        COUT := (A and B) or (A and CIN) or (B and CIN);
        RESULT := COUT & S;
        return RESULT;
    end ADD;
end PKG;

use work.PKG.all;

entity EXAMPLE is
    port (
        A,B : in BIT_VECTOR (3 downto 0);
        CIN : in BIT;
        S : out BIT_VECTOR (3 downto 0);
        COUT : out BIT );
end EXAMPLE;

architecture ARCHI of EXAMPLE is
    signal S0, S1, S2, S3 : BIT_VECTOR (1 downto 0);
begin
    S0 <= ADD (A(0), B(0), CIN);
    S1 <= ADD (A(1), B(1), S0(1));
    S2 <= ADD (A(2), B(2), S1(1));
    S3 <= ADD (A(3), B(3), S2(1));
    S  <= S3(0) & S2(0) & S1(0) & S0(0);
    COUT <= S3(1);
end ARCHI;
```

Example 6-24 Procedure Declaration and Procedure Call

```

package PKG is
  procedure ADD (
    A,B, CIN : in BIT;
    C : out BIT_VECTOR (1 downto 0) );
end PKG;

package body PKG is
  procedure ADD (
    A,B, CIN : in BIT;
    C : out BIT_VECTOR (1 downto 0)
  ) is
    variable S, COUT : BIT;
  begin
    S := A xor B xor CIN;
    COUT := (A and B) or (A and CIN) or (B and CIN);
    C := COUT & S;
  end ADD;
end PKG;

use work.PKG.all;

entity EXAMPLE is
  port (
    A,B : in BIT_VECTOR (3 downto 0);
    CIN : in BIT;
    S : out BIT_VECTOR (3 downto 0);
    COUT : out BIT );
end EXAMPLE;

architecture ARCHI of EXAMPLE is
begin
  process (A,B,CIN)
    variable S0, S1, S2, S3 : BIT_VECTOR (1 downto 0);
  begin
    ADD (A(0), B(0), CIN, S0);
    ADD (A(1), B(1), S0(1), S1);
    ADD (A(2), B(2), S1(1), S2);
    ADD (A(3), B(3), S2(1), S3);
    S <= S3(0) & S2(0) & S1(0) & S0(0);
    COUT <= S3(1);
  end process;
end ARCHI;

```

XST supports recursive functions as well. Example 6-25 represents n! function.

Example 6-25 Recursive Function

```

function my_func(x : integer) return integer is
begin
  if x = 1 then
    return x;
  else
    return (x*my_func(x-1));
  end if;
end function my_func;

```

Assert Statement

XST supports the use of the Assert statement. By using the Assert statement, designers can detect undesirable conditions in their VHDL designs such as bad values for generics, constants and generate conditions, or bad values for parameters in called functions. For any failed condition in an Assert statement, XST, according to the severity level, generates a warning message with the reason for the warning, or rejects the design and generates an error message and the reason for the rejection.

Note: XST supports the Assert statement only with static condition.

The following example contains a block, SINGLE_SRL, that describes a shift register. The size of the shift register depends on the SRL_WIDTH generic value. The Assert statement ensures that the implementation of a single shift register does not exceed the size of a single SRL.

Since the size of the SRL is 16 bit, and XST implements the last stage of the shift register using a flip-flop in a slice, then the maximum size of the shift register cannot exceed 17 bits. The SINGLE_SRL block is instantiated twice in the entity named TOP, the first time with SRL_WIDTH equal to 13, and the second time with SRL_WIDTH equal to 18:

```
library ieee;
use ieee.std_logic_1164.all;

entity SINGLE_SRL is
    generic (SRL_WIDTH : integer := 16);
    port (
        clk : in std_logic;
        inp : in std_logic;
        outp : out std_logic);
end SINGLE_SRL;

architecture beh of SINGLE_SRL is
    signal shift_reg : std_logic_vector (SRL_WIDTH-1 downto 0);
begin

    assert SRL_WIDTH <= 17
    report "The size of Shift Register exceeds the size of a single SRL"
    severity FAILURE;

    process (clk)
    begin
        if (clk'event and clk = '1') then
            shift_reg <= shift_reg (SRL_WIDTH-1 downto 1) & inp;
        end if;
    end process;
    outp <= shift_reg(SRL_WIDTH-1);
end beh;
```

```
library ieee;
use ieee.std_logic_1164.all;

entity TOP is
  port (
    clk : in std_logic;
    inp1, inp2 : in std_logic;
    outp1, outp2 : out std_logic);
end TOP;

architecture beh of TOP is
  component SINGLE_SRL is
    generic (SRL_WIDTH : integer := 16);
    port(
      clk : in std_logic;
      inp : in std_logic;
      outp : out std_logic);
  end component;
begin
  inst1: SINGLE_SRL generic map (SRL_WIDTH => 13)
    port map(
      clk => clk,
      inp => inp1,
      outp => outp1 );
  inst2: SINGLE_SRL generic map (SRL_WIDTH => 18)
    port map(
      clk => clk,
      inp => inp2,
      outp => outp2 );
end beh;
```

Running this example through XST results in the following error message generated by the Assert statement.

```
...
=====
*                      HDL Analysis
=====
Analyzing Entity <top> (Architecture <beh>).
Entity <top> analyzed. Unit <top> generated.

Analyzing generic Entity <single_srl> (Architecture <beh>).
  SRL_WIDTH = 13
Entity <single_srl> analyzed. Unit <single_srl> generated.

Analyzing generic Entity <single_srl> (Architecture <beh>).
  SRL_WIDTH = 18
ERROR:Xst - assert_1.vhd line 15: FAILURE: The size of Shift Register
exceeds the size of a single SRL
...
```

Packages

VHDL models may be defined using packages. Packages contain type and subtype declarations, constant definitions, function and procedure definitions, and component declarations.

This mechanism provides the ability to change parameters and constants of the design (for example, constant values, function definitions). Packages may contain two declarative parts: package declaration and body declaration. The body declaration includes the description of function bodies declared in the package declaration.

XST provides full support for packages. To use a given package, the following lines must be included at the beginning of the VHDL design:

```
library lib_pack;
-- lib_pack is the name of the library specified
-- where the package has been compiled (work by default)
use lib_pack.pack_name.all;
-- pack_name is the name of the defined package.
```

XST also supports predefined packages; these packages are pre-compiled and can be included in VHDL designs. These packages are intended for use during synthesis, but may also be used for simulation.

STANDARD Package

The Standard package contains basic types (bit, bit_vector, and integer). The STANDARD package is included by default.

IEEE Packages

The following IEEE packages are supported.

- std_logic_1164: defines types std_logic, std_ulogic, std_logic_vector, std_ulogic_vector, and conversion functions based on these types.
- numeric_bit: supports types unsigned, signed vectors based on type bit, and all overloaded arithmetic operators on these types. It also defines conversion and extended functions for these types.
- numeric_std: supports types unsigned, signed vectors based on type std_logic. This package is equivalent to std_logic_arith.
- math_real: supports the following.
 - ◆ Real number constants as shown in the following table:

Constant	Value	Constant	Value
math_e	e	math_log_of_2	$\ln 2$
math_1_over_e	$1/e$	math_log_of_10	$\ln 10$
math_pi	π	math_log2_of_e	$\log_2 e$
math_2_pi	2π	math_log10_of_e	$\log_{10} e$
math_1_over_pi	$1/\pi$	math_sqrt_2	$\sqrt{2}$
math_pi_over_2	$\pi/2$	math_1_oversqrt_2	$1/\sqrt{2}$

Constant	Value	Constant	Value
math_pi_over_3	$\pi/ 3$	math_sqrt_pi	$\sqrt{\pi}$
math_pi_over_4	$\pi/ 4$	math_deg_to_rad	$2\pi/ 360$
math_3_pi_over_2	$3\pi/ 2$	math_rad_to_deg	$360/ 2\pi$

- ◆ Real number functions as shown in the following table:

ceil(x)	realmax(x,y)	exp(x)	cos(x)	cosh(x)
floor(x)	realmin(x,y)	log(x)	tan(x)	tanh(x)
round(x)	sqrt(x)	log2(x)	arcsin(x)	arcsinh(x)
trunc(x)	cbrt(x)	log10(x)	arctan(x)	arccosh(x)
sign(x)	"**"(n,y)	log(x,y)	arctan(y,x)	arctanh(x)
"mod"(x,y)	"**"(x,y)	sin(x)	sinh(x)	

- ◆ The procedure *uniform*, which generates successive values between 0.0 and 1.0.

Note: Functions and procedures in the math_real package, as well as the real type, are for calculations only. They are not supported for synthesis in XST.

Example:

```
library ieee;
use IEEE.std_logic_signed.all;
signal a, b, c : std_logic_vector (5 downto 0);
c <= a + b;
-- this operator "+" is defined in package std_logic_signed.
-- Operands are converted to signed vectors, and function "+"
-- defined in package std_logic_arith is called with signed
-- operands.
```

Synopsys Packages

The following Synopsys packages are supported in the IEEE library.

- std_logic_arith: supports types unsigned, signed vectors, and all overloaded arithmetic operators on these types. It also defines conversion and extended functions for these types.
- std_logic_unsigned: defines arithmetic operators on std_ulogic_vector and considers them as unsigned operators.
- std_logic_signed: defines arithmetic operators on std_logic_vector and considers them as signed operators.
- std_logic_misc: defines supplemental types, subtypes, constants, and functions for the std_logic_1164 package (and_reduce, or_reduce,...).

VHDL Language Support

The following tables indicate which VHDL constructs are supported in XST. For more information about these constructs, refer to the sections following the tables.

Table 6-3: Design Entities and Configurations

Entity Header	Generics	Supported (integer type only)
	Ports	Supported (no unconstrained ports)
	Entity Declarative Part	Supported
	Entity Statement Part	Unsupported
Architecture Bodies	Architecture Declarative Part	Supported
	Architecture Statement Part	Supported
Configuration Declarations	Block Configuration	Supported
	Component Configuration	Supported
Subprograms	Functions	Supported
	Procedures	Supported

Table 6-3: Design Entities and Configurations

Packages	STANDARD	Type TIME is not supported
	TEXTIO	Supported
	STD_LOGIC_1164	Supported
	STD_LOGIC_ARITH	Supported
	STD_LOGIC_SIGNED	Supported
	STD_LOGIC_UNSIGNED	Supported
	STD_LOGIC_MISC	Supported
	NUMERIC_BIT	Supported
	NUMERIC_EXTRA	Supported
	NUMERIC_SIGNED	Supported
	NUMERIC_UNSIGNED	Supported
	NUMERIC_STD	Supported
	MATH_REAL	Supported
	ASYL.ARITH	Supported
	ASYL.SL_ARITH	Supported
	ASYL.PKG RTL	Supported
	ASYL.ASYL1164	Supported
Enumeration Types	BOOLEAN, BIT	Supported
	STD_ULOGIC, STD_LOGIC	Supported
	XO1, UX01, XO1Z, UX01Z	Supported
	Character	Supported
Integer Types	INTEGER	Supported
	POSITIVE	Supported
	NATURAL	Supported
Physical Types	TIME	Ignored
	REAL	Supported (only in functions for constant calculations)

Table 6-3: Design Entities and Configurations

Composite	BIT_VECTOR	Supported
	STD_ULOGIC_VECTOR	Supported
	STD_LOGIC_VECTOR	Supported
	UNSIGNED	Supported
	SIGNED	Supported
	Record	Supported
	Access	Supported
	File	Supported

Table 6-4: Mode

In, Out, Inout	Supported
Buffer	Supported
Linkage	Unsupported

Table 6-5: Declarations

Type	Supported for enumerated types, types with positive range having constant bounds, bit vector types, and multi-dimensional arrays
Subtype	Supported

Table 6-6: Objects

Constant Declaration	Supported (deferred constants are not supported)
Signal Declaration	Supported ("register" or "bus" type signals are not supported)
Variable Declaration	Supported
File Declaration	Supported
Alias Declaration	Supported
Attribute Declaration	Supported for some attributes, otherwise skipped (see Chapter 5, "Design Constraints")
Component Declaration	Supported

Table 6-7: Specifications

Attribute	Only supported for some predefined attributes: HIGH, LOW, LEFT, RIGHT, RANGE, REVERSE_RANGE, LENGTH, POS, ASCENDING, EVENT, LAST_VALUE. Otherwise, ignored.
Configuration	Supported only with the "all" clause for instances list. If no clause is added, XST looks for the entity/architecture compiled in the default library.
Disconnection	Unsupported

Table 6-8: Names

Simple Names	Supported
Selected Names	Supported
Indexed Names	Supported
Slice Names	Supported (including dynamic ranges)

Note: XST does not allow underscores as the first character of signal names (for example, _DATA_1).

Table 6-9: Expressions

Operators	Logical Operators: and, or, nand, nor, xor, xnor, not	Supported
	Relational Operators: =, /=, <, <=, >, >=	Supported
	& (concatenation)	Supported
	Adding Operators: +, -	Supported
	*	Supported
	/,rem	Supported if the right operand is a constant power of 2
	mod	Supported
	Shift Operators: sll, srl, sla, sra, rol, ror	Supported
	abs	Supported
	**	Only supported if the left operand is 2
	Sign: +, -	Supported

Table 6-9: Expressions

Operands	Abstract Literals	Only integer literals are supported
	Physical Literals	Ignored
	Enumeration Literals	Supported
	String Literals	Supported
	Bit String Literals	Supported
	Record Aggregates	Supported
	Array Aggregates	Supported
	Function Call	Supported
	Qualified Expressions	Supported for accepted predefined attributes
	Types Conversions	Supported
	Allocators	Unsupported
	Static Expressions	Supported

Table 6-10: Supported VHDL Statements

Wait Statement	Wait on <i>sensitivity_list</i> until <i>Boolean_expression</i> . See “ Sequential Circuits ” for details.	Supported with one signal in the sensitivity list and in the Boolean expression. In case of multiple Wait statements, the sensitivity list and the Boolean expression must be the same for each Wait statement. Note: XST does not support Wait statements for latch descriptions.
	Wait for <i>time_expression</i> ... See “ Sequential Circuits ” for details.	Unsupported
	Assertion Statement	Supported (only for static conditions)
	Signal Assignment Statement	Supported (delay is ignored)
	Variable Assignment Statement	Supported
	Procedure Call Statement	Supported
	If Statement	Supported
	Case Statement	Supported

Table 6-10: Supported VHDL Statements

Loop Statement	"for... loop... end loop"	Supported for constant bounds only
	"while... loop... end loop"	Supported
	"loop ... end loop"	Only supported in the particular case of multiple Wait statements
	Next Statement	Supported
	Exit Statement	Supported
	Return Statement	Supported
	Null Statement	Supported
Concurrent Statement	Process Statement	Supported
	Concurrent Procedure Call	Supported
	Concurrent Assertion Statement	Ignored
	Concurrent Signal Assignment Statement	Supported (no "after" clause, no "transport" or "guarded" options, no waveforms)
	Component Instantiation Statement	Supported
	"For ... Generate"	Statement supported for constant bounds only
	"If ... Generate"	Statement supported for static condition only

VHDL Reserved Words

The following table shows the VHDL reserved words.

abs	configuration	impure	null	rem	type
access	constant	in	of	report	unaffected
after	disconnect	inertial	on	return	units
alias	downto	inout	open	rol	until
all	else	is	or	ror	use
and	elsif	label	others	select	variable
architecture	end	library	out	severity	wait
array	entity	linkage	package	signal	when
assert	exit	literal	port	shared	while
attribute	file	loop	postponed	sla	with
begin	for	map	procedure	sll	xnor
block	function	mod	process	sra	xor
body	generate	nand	pure	srl	
buffer	generic	new	range	subtype	
bus	group	next	record	then	
case	guarded	nor	register	to	
component	if	not	reject	transport	

Verilog Language Support

This chapter contains the following sections.

- “Introduction”
- “Behavioral Verilog Features”
- “Variable Part Selects”
- “Structural Verilog Features”
- “Parameters”
- “Parameter/Attribute Conflicts”
- “Verilog Limitations in XST”
- “Verilog Meta Comments”
- “Verilog Language Support Tables”
- “Primitives”
- “Verilog Reserved Keywords”
- “Verilog-2001 Support in XST”

For detailed information about Verilog design constraints and options, refer to [Chapter 5, “Design Constraints”](#). For information about the Verilog attribute syntax, see [“Verilog Meta Comment Syntax” in Chapter 5](#).

For information on setting Verilog options in the Process window of Project Navigator, refer to [“General Constraints” in Chapter 5](#).

Introduction

Complex circuits are commonly designed using a top down methodology. Various specification levels are required at each stage of the design process. As an example, at the architectural level, a specification may correspond to a block diagram or an Algorithmic State Machine (ASM) chart. A block or ASM stage corresponds to a register transfer block (for example register, adder, counter, multiplexer, glue logic, finite state machine) where the connections are N-bit wires. Use of an HDL language like Verilog allows expressing notations such as ASM charts and circuit diagrams in a computer language. Verilog provides both behavioral and structural language structures which allow expressing design objects at high and low levels of abstraction. Designing hardware with a language like Verilog allows usage of software concepts such as parallel processing and object-oriented programming. Verilog has a syntax similar to C and Pascal, and is supported by XST as IEEE 1364.

The Verilog support in XST provides an efficient way to describe both the global circuit and each block according to the most efficient "style." Synthesis is then performed with the best synthesis flow for each block. Synthesis in this context is the compilation of high-level

behavioral and structural Verilog HDL statements into a flattened gate-level netlist, which can then be used to custom program a programmable logic device such as the Virtex™ FPGA family. Different synthesis methods are used for arithmetic blocks, glue logic, and finite state machines.

This manual assumes that you are familiar with the basic notions of Verilog. Please refer to the IEEE Verilog HDL Reference Manual for a complete specification.

Behavioral Verilog Features

This section contains descriptions of the behavioral features of Verilog.

Variable Declaration

Variables in Verilog may be declared as integers or real. These declarations are intended only for use in test code. Verilog provides data types such as reg and wire for actual hardware description.

The difference between reg and wire is whether the variable is given its value in a procedural block (reg) or in a continuous assignment (wire) Verilog code. Both reg and wire have a default width being one bit wide (scalar). To specify an N-bit width (vectors) for a declared reg or wire, the left and right bit positions are defined in square brackets separated by a colon. In Verilog-2001, both reg and wire data types can be signed or unsigned.

Example:

```
reg [3:0] arb_priority;
wire [31:0] arb_request;
wire signed [8:0] arb_signed;
```

where arb_request[31] is the MSB and arb_request[0] is the LSB.

Initial Values

In Verilog-2001, you can initialize registers when you declare them.

The value:

- Must be a constant.
- Cannot depend on earlier initial values.
- Cannot be a function or task call.
- Can be a parameter value propagated to the register.
- All bits of vector must be specified.

When you give a register an initial value in a declaration, XST sets this value on the output of the register at global reset, or at power up. A value assigned this way is carried in the NGC file as an INIT attribute on the register, and is independent of any local reset.

Example:

```
reg arb_onebit = 1'b0;
reg [3:0] arb_priority = 4'b1011;
```

You can also assign a set/reset (initial) value to a register via your behavioral Verilog code. Do this by assigning a value to a register when the register's reset line goes to the appropriate value as in the following example.

Example:

```
always @ (posedge clk)
begin
    if (rst)
        arb_onebit <= 1'b0;
    end
end
```

When you set the initial value of a variable in the behavioral code, it is implemented in the design as a flip-flop whose output can be controlled by a local reset; as such it is carried in the NGC file as an FDP or FDC flip-flop.

Local Reset ≠ Global Reset

Note that local reset is independent of global reset. Registers controlled by a local reset may be set to a different value than ones whose value is only reset at global reset (power up). In the following example, the register, arb_onebit, is set to '0' at global reset, but a pulse on the local reset (rst) can change its value to '1'.

Example:

```
module mult(clk, rst, A_IN, B_OUT);
    input clk,rst,A_IN;
    output B_OUT;

    reg arb_onebit = 1'b0;

    always @(posedge clk or posedge rst)
    begin
        if (rst)
            arb_onebit <= 1'b1;
        else
            arb_onebit <= A_IN;
        end
    end
    B_OUT <= arb_onebit;
endmodule
```

This sets the set/reset value on the register's output at initial power up, but since this is dependent upon a local reset, the value changes whenever the local set/reset is activated.

Arrays

Verilog allows arrays of reg and wires to be defined as in the following two examples:

```
reg [3:0] mem_array [31:0];
```

The above describes an array of 32 elements each, 4 bits wide which can be assigned via behavioral Verilog code.

```
wire [7:0] mem_array [63:0];
```

The above describes an array of 64 elements each 8 bits wide which can only be assigned via structural Verilog code.

Multi-dimensional Arrays

XST supports multi-dimensional array types of up to two dimensions. Multi-dimensional arrays can be any net or any variable data type. You can code assignments and arithmetic operations with arrays, but you cannot select more than one element of an array at one time. You cannot pass multi-dimensional arrays to system tasks or functions, or regular tasks or functions.

Examples

The following describes an array of 256 x 16 wire elements each 8 bits wide, which can only be assigned via structural Verilog code.

```
wire [7:0] array2 [0:255][0:15];
```

The following describes an array of 256 x 8 register elements, each 64 bits wide, which can be assigned via behavioral Verilog code.

```
reg [63:0] regarray2 [255:0][7:0];
```

The following is a three dimensional array. It can be described as an array of 15 arrays of 256 x 16 wire elements, each 8 bits wide, which can be assigned via structural Verilog code.

```
wire [7:0] array3 [0:15][0:255][0:15];
```

Data Types

The Verilog representation of the bit data type contains the following four values:

- 0: logic zero
- 1: logic one
- x: unknown logic value
- z: high impedance

XST includes support for the following Verilog data types:

- Net: wire, tri, triand/wand, trior/wor
- Registers: reg, integer
- Supply nets: supply0, supply1
- Constants: parameter
- Multi-Dimensional Arrays (Memories)

Net and registers can be either single bit (scalar) or multiple bit (vectors).

The following example gives some examples of Verilog data types (as found in the declaration section of a Verilog module).

Example 7-1 Basic Data Types

```
wire net1;                                // single bit net
reg r1;                                    // single bit register
tri [7:0] bus1;                            // 8 bit tristate bus
reg [15:0] bus1;                           // 15 bit register
reg [7:0] mem[0:127];                      // 8x128 memory register
parameter state1 = 3'b001;                  // 3 bit constant
parameter component = "TMS380C16";          // string
```

Legal Statements

The following are statements that are legal in behavioral Verilog.

Variable and signal assignment:

- Variable = expression
- if (condition) statement
- if (condition) statement else statement
- case (expression)
- expression: statement

...

default: statement

endcase

- for (variable = expression; condition; variable = variable + expression) statement
- while (condition) statement
- forever statement
- functions and tasks

Note: All variables are declared as integer or reg. A variable cannot be declared as a wire.

Expressions

An expression involves constants and variables with arithmetic (+, -, *, **, /, %), logical (&, &&, |, ||, ^, ~, ^~, ^~, <<, >>, <<<, >>>), relational (<, ==, ===, <=, >=, !=, !==, >), and conditional (?) operators. The logical operators are further divided as bit-wise versus logical depending on whether it is applied to an expression involving several bits or a single bit. The following table lists the expressions supported by XST.

Table 7-1: Expressions

Concatenation	{}	Supported
Replication	{()}	Supported
Arithmetic	+,-,*,**	Supported
	/	Supported only if second operand is a power of 2
Modulus	%	Supported only if second operand is a power of 2
Addition	+	Supported
Subtraction	-	Supported
Multiplication	*	Supported

Table 7-1: Expressions

Power	<code>**</code>	<p>Supported</p> <ul style="list-style-type: none"> Both operands must be constants with the second operand being non-negative. If the first operand is a 2, then the second operand may be a variable. XST does not support the real data type. Any combination of operands that results in a real type causes an error. The values X (unknown) and Z (high impedance) are not allowed.
Division	<code>/</code>	<p>Supported</p> <p>XST generates incorrect logic for the division operator between signed and unsigned constants. Example: <code>-1235/3'b111</code></p>
Relational	<code>>, <, >=, <=</code>	Supported
Logical Negation	<code>!</code>	Supported
Logical AND	<code>&&</code>	Supported
Logical OR	<code> </code>	Supported
Logical Equality	<code>==</code>	Supported
Logical Inequality	<code>!=</code>	Supported
Case Equality	<code>====</code>	Supported
Case Inequality	<code>!==</code>	Supported
Bitwise Negation	<code>~</code>	Supported
Bitwise AND	<code>&</code>	Supported
Bitwise Inclusive OR	<code> </code>	Supported
Bitwise Exclusive OR	<code>^</code>	Supported
Bitwise Equivalence	<code>~^, ^~</code>	Supported
Reduction AND	<code>&</code>	Supported
Reduction NAND	<code>~&</code>	Supported
Reduction OR	<code> </code>	Supported
Reduction NOR	<code>~ </code>	Supported
Reduction XOR	<code>^</code>	Supported

Table 7-1: Expressions

Reduction XNOR	$\sim\wedge, \wedge\sim$	Supported
Left Shift	$<<$	Supported
Right Shift Signed	$>>>$	Supported
Left Shift Signed	$<<<$	Supported
Right Shift	$>>$	Supported
Conditional	$?:$	Supported
Event OR	or, ','	Supported

The following table lists the results of evaluating expressions using the more frequently used operators supported by XST.

Note: The (==) and (!==) are special comparison operators useful in simulations to check if a variable is assigned a value of (x) or (z). They are treated as (==) or (!=) in synthesis.

Table 7-2: Results of Evaluating Expressions

a b	$a==b$	$a==>b$	$a!=b$	$a!=>b$	$a&b$	$a&&b$	$a b$	$a b$	a^b
0 0	1	1	0	0	0	0	0	0	0
0 1	0	0	1	1	0	0	1	1	1
0 x	x	0	x	1	0	0	x	x	x
0 z	x	0	x	1	0	0	x	x	x
1 0	0	0	1	1	0	0	1	1	1
1 1	1	1	0	0	1	1	1	1	0
1 x	x	0	x	1	x	x	1	1	x
1 z	x	0	x	1	x	x	1	1	x
x 0	x	0	x	1	0	0	x	x	x
x 1	x	0	x	1	x	x	1	1	x
x x	x	1	x	0	x	x	x	x	x
x z	x	0	x	1	x	x	x	x	x
z 0	x	0	x	1	0	0	x	x	x
z 1	x	0	x	1	x	x	1	1	x
z x	x	0	x	1	x	x	x	x	x
z z	x	1	x	0	x	x	x	x	x

Blocks

Block statements are used to group statements together. XST only supports sequential blocks. Within these blocks, the statements are executed in the order listed. Parallel blocks are not supported by XST. Block statements are designated by **begin** and **end** keywords, and are discussed within examples later in this chapter.

Modules

In Verilog a design component is represented by a module. The connections between components are specified within module instantiation statements. Such a statement specifies an instance of a module. Each module instantiation statement must be given a name (instance name). In addition to the name, a module instantiation statement contains an association list that specifies which actual nets or ports are associated with which local ports (formals) of the module declaration.

All procedural statements occur in blocks that are defined inside modules. There are two kinds of procedural blocks: the initial block and the always block. Within each block, Verilog uses a begin and end to enclose the statements. Since initial blocks are ignored during synthesis, only always blocks are discussed. Always blocks usually take the following format:

```
always
  begin
    statement
    ....
  end
```

where each statement is a procedural assignment line terminated by a semicolon.

Module Declaration

In the module declaration, the I/O ports of the circuit are declared. Each port has a name and a mode (in, out, and inout) as shown in the example below.

```
module EXAMPLE (A, B, C, D, E);
  input A, B, C;
  output D;
  inout E;
  wire D, E;
  ...
  assign E = oe ? A : 1'bz;
  assign D = B & E;
  ...
endmodule
```

The input and output ports defined in the module declaration called EXAMPLE are the basic input and output I/O signals for the design. The inout port in Verilog is analogous to a bi-directional I/O pin on the device with the data flow for output versus input being controlled by the enable signal to the tristate buffer. The preceding example describes E as a tristate buffer with a high-true output enable signal. If oe = 1, the value of signal A is output on the pin represented by E. If oe = 0, then the buffer is in high impedance (Z) and any input value driven on the pin E (from the external logic) is brought into the device and fed to the signal represented by D.

Verilog Assignments

There are two forms of assignment statements in the Verilog language:

- Continuous Assignments
- Procedural Assignments

Continuous Assignments

Continuous assignments are used to model combinatorial logic in a concise way. Both explicit and implicit continuous assignments are supported. Explicit continuous assignments are introduced by the **assign** keyword after the net has been separately declared. Implicit continuous assignments combine declaration and assignment.

Note: Delays and strengths given to a continuous assignment are ignored by XST.

Example of an explicit continuous assignment:

```
wire par_eq_1;
.....
assign par_eq_1 = select ? b : a;
```

Example of an implicit continuous assignment:

```
wire temp_hold = a | b;
```

Note: Continuous assignments are only allowed on wire and tri data types.

Procedural Assignments

Procedural assignments are used to assign values to variables declared as regs and are introduced by always blocks, tasks, and functions. Procedural assignments are usually used to model registers and FSMs.

XST includes support for combinatorial functions, combinatorial and sequential tasks, and combinatorial and sequential always blocks.

Combinatorial Always Blocks

Combinatorial logic can be modeled efficiently using two forms of time control, the # and @ Verilog time control statements. The # time control is ignored for synthesis and hence this section describes modeling combinatorial logic with the @ statement.

A combinatorial always block has a sensitivity list appearing within parentheses after the word "always @". An always block is activated if an event (value change or edge) appears on one of the sensitivity list signals. This sensitivity list can contain any signal that appears in conditions (If, Case, for example), and any signal appearing on the right hand side of an assignment. By substituting a * without parentheses, for a list of signals, the always block is activated for an event in any of the always block's signals as described above.

Note: In combinatorial processes, if a signal is not explicitly assigned in all branches of "If" or "Case" statements, XST generates a latch to hold the last value. To avoid latch creation, be sure that all assigned signals in a combinatorial process are always explicitly assigned in all paths of the process statements.

Different statements can be used in a process:

- Variable and signal assignment
- If... else statement
- Case statement
- For and while loop statement
- Function and task call

The following sections provide examples of each of these statements.

If...Else Statement

If... else statements use true/false conditions to execute statements. If the expression evaluates to true, the first statement is executed. If the expression evaluates to false (or x or z), the else statement is executed. A block of multiple statements may be executed using begin and end keywords. If...else statements may be nested. The following example shows how a MUX can be described using an If...else statement.

Example 7-2 MUX Description Using If... Else Statement

```
module mux4 (sel, a, b, c, d, outmux);
    input [1:0] sel;
    input [1:0] a, b, c, d;
    output [1:0] outmux;
    reg [1:0] outmux;

    always @(sel or a or b or c or d)
    begin
        if (sel[1])
            if (sel[0])
                outmux = d;
            else
                outmux = c;
        else
            if (sel[0])
                outmux = b;
            else
                outmux = a;
        end
    endmodule
```

Case Statement

Case statements perform a comparison to an expression to evaluate one of a number of parallel branches. The Case statement evaluates the branches in the order they are written. The first branch that evaluates to true is executed. If none of the branches match, the default branch is executed.

Note: Do not use unsized integers in case statements. Always size integers to a specific number of bits, or results can be unpredictable.

Casez treats all z values in any bit position of the branch alternative as a don't care.

Casex treats all x and z values in any bit position of the branch alternative as a don't care.

The question mark (?) can be used as a "don't care" in either the casez or casex case statements. The following example shows how a MUX can be described using a Case statement.

Example 7-3 MUX Description Using Case Statement

```

module mux4 (sel, a, b, c, d, outmux);
  input [1:0] sel;
  input [1:0] a, b, c, d;
  output [1:0] outmux;
  reg [1:0] outmux;

  always @(sel or a or b or c or d)
    begin
      case (sel)
        2'b00: outmux = a;
        2'b01: outmux = b;
        2'b10: outmux = c;
        default: outmux = d;
      endcase
    end
  endmodule

```

The preceding Case statement evaluates the values of the input sel in priority order. To avoid priority processing, it is recommended that you use a parallel-case Verilog meta comment which ensures parallel evaluation of the sel inputs as in the following.

Example:

```
case(sel) //synthesis parallel_case
```

For and Repeat Loops

When using always blocks, repetitive or bit slice structures can also be described using the "for" statement or the "repeat" statement.

The "for" statement is supported for:

- Constant bounds
- Stop test condition using operators <, <=, > or >=
- Next step computation falling in one of the following specifications:
 - ◆ $var = var + step$
 - ◆ $var = var - step$

(where *var* is the loop variable and *step* is a constant value).

The repeat statement is only supported for constant values.

The following example shows the use of a For Loop.

Example 7-4 For Loop Description

```

module countzeros (a, Count);
  input [7:0] a;
  output [2:0] Count;
  reg [2:0] Count;
  reg [2:0] Count_Aux;
  integer i;

```

```

always @(a)
begin
    Count_Aux = 3'b0;
    for (i = 0; i < 8; i = i+1)
        begin
            if (!a[i])
                Count_Aux = Count_Aux+1;
        end
    Count = Count_Aux;
end
endmodule

```

While Loops

When using always blocks, use the "while" statement to execute repetitive procedures. A "while" loop executes other statements until its test expression becomes false. It is not executed if the test expression is initially false.

- The test expression is any valid Verilog expression.
- To prevent endless loops, use the "-loop_iteration_limit" switch.
- While loops can have Disable statements. The Disable statement must be used inside a labeled block, since the syntax is "disable <blockname>."

The following example shows the use of a While Loop.

Example 7-5 While Loop Description

```

parameter P = 4;
always @(ID_complete)
begin : UNIDENTIFIED
    integer i;
    reg found;
    unidentified = 0;
    i = 0;
    found = 0;
    while (!found && (i < P))
        begin
            found = !ID_complete[i];
            unidentified[i] = !ID_complete[i];
            i = i + 1;
        end
    end

```

Sequential Always Blocks

Sequential circuit description is based on always blocks with a sensitivity list.

The sensitivity list contains a maximum of three edge-triggered events: the clock signal event (which is mandatory), possibly a reset signal event, and a set signal event. One, and only one "If...else" statement is accepted in such an always block.

An asynchronous part may appear before the synchronous part in the first and the second branch of the "If...else" statement. Signals assigned in the asynchronous part must be assigned to the constant values '0', '1', 'X' or 'Z' or any vector composed of these values.

These same signals must also be assigned in the synchronous part (that is, the last branch of the "if-else" statement). The clock signal condition is the condition of the last branch of the "if-else" statement. The following example gives the description of an 8-bit register.

Example 7-6 8 Bit Register Using an Always Block

```
module seq1 (DI, CLK, DO);
    input [7:0] DI;
    input CLK;
    output [7:0] DO;
    reg [7:0] DO;

    always @ (posedge CLK)
        DO <= DI ;
endmodule
```

The following example gives the description of an 8-bit register with a clock signal and an asynchronous reset signal.

Example 7-7 8 Bit Register with Asynchronous Reset (high-true) Using an Always Block

```
module EXAMPLE (DI, CLK, RST, DO);
    input [7:0] DI;
    input CLK, RST;
    output [7:0] DO;
    reg [7:0] DO;

    always @ (posedge CLK or posedge RST)
        if (RST == 1'b1)
            DO <= 8'b00000000;
        else
            DO <= DI;
endmodule
```

The following example describes an 8-bit counter.

Example 7-8 8 Bit Counter with Asynchronous Reset (low-true) Using an Always Block

```
module seq2 (CLK, RST, DO);
    input CLK, RST;
    output [7:0] DO;
    reg [7:0] DO;

    always @ (posedge CLK or posedge RST)
        if (RST == 1'b1)
            DO <= 8'b00000000;
        else
            DO <= DO + 8'b00000001;
endmodule
```

Assign and Deassign Statements

Assign and deassign statements are supported within simple templates.

The following is an example of the general template for assign / deassign statements:

```
module assig (RST, SELECT, STATE, CLOCK, DATA_IN);
    input RST;
    input SELECT;
    input CLOCK;
    input [0:3] DATA_IN;
    output [0:3] STATE;
    reg [0:3] STATE;

    always @ (RST)
        if(RST)
            begin
                assign STATE = 4'b0;
            end
        else
            begin
                deassign STATE;
            end

    always @ (posedge CLOCK)
        begin
            STATE <= DATA_IN;
        end
endmodule
```

The main limitations on support of the assign/deassign statement in XST are as follows:

- For a given signal, there must be only one assign/deassign statement. For example, XST rejects the following design:

```
module dflop (RST, SET, STATE, CLOCK, DATA_IN);
    input RST;
    input SET;
    input CLOCK;
    input DATA_IN;
    output STATE;
    reg STATE;

    always @ (RST)           // block b1
        if(RST)
            assign STATE = 1'b0;
        else
            deassign STATE;

    always @ (SET)           // block b1
        if(SET)
            assign STATE = 1'b1;
        else
            deassign STATE;

    always @ (posedge CLOCK) // block b2
        begin
            STATE <= DATA_IN;
        end
endmodule
```

- The assign/deassign statement must be performed in the same always block through an if/else statement. For example, XST rejects the following design:

```
module dflop (RST, SET, STATE, CLOCK, DATA_IN);  
    input RST;  
    input SET;  
    input CLOCK;  
    input DATA_IN;  
    output STATE;  
  
    reg STATE;  
  
    always @ (RST or SET)          // block b1  
        case ({RST,SET})  
            2'b00: assign STATE = 1'b0;  
            2'b01: assign STATE = 1'b0;  
            2'b10: assign STATE = 1'b1;  
            2'b11: deassign STATE;  
        endcase  
  
    always @ (posedge CLOCK)      // block b2  
        begin  
            STATE <= DATA_IN;  
        end  
endmodule
```

- You cannot assign a bit/part select of a signal through an assign/deassign statement. For example, XST rejects the following design:

```
module assig (RST, SELECT, STATE, CLOCK,DATA_IN);  
    input RST;  
    input SELECT;  
    input CLOCK;  
    input [0:7] DATA_IN;  
    output [0:7] STATE;  
  
    reg [0:7] STATE;  
  
    always @ (RST)          // block b1  
        if(RST)  
            begin  
                assign STATE[0:7] = 8'b0;  
            end  
        else  
            begin  
                deassign STATE[0:7];  
            end  
  
    always @ (posedge CLOCK) // block b2  
        begin  
            if (SELECT)  
                STATE [0:3] <= DATA_IN[0:3];  
            else  
                STATE [4:7] <= DATA_IN[4:7];  
        end
```

Assignment Extension Past 32 Bits

If the expression on the left-hand side of an assignment is wider than the expression on the right-hand side, the left-hand side is padded to the **left** according to the following rules.

- If the right-hand expression is signed, the left-hand expression is padded with the sign bit (0 for positive, 1 for negative, z for high impedance or x for unknown).
- If the right-hand expression is unsigned, the left-hand expression is padded with '0's.
- For unsized x or z constants only the following rule applies. If the value of the right-hand expression's left-most bit is z (high impedance) or x (unknown), regardless of whether the right-hand expression is signed or unsigned, the left-hand expression is padded with that value (z or x, respectively).

Note: The above rules follow the Verilog-2001 standard, and are not backward compatible with Verilog-1995.

Tasks and Functions

The declaration of a function or task is intended for handling blocks used multiple times in a design. They must be declared and used in a module. The heading part contains the parameters: input parameters (only) for functions and input/output/inout parameters for tasks. The return value of a function can be declared either signed or unsigned. The content is similar to the combinatorial always block content.

Example 7-9 shows a function declared within a module. The ADD function declared is a single-bit adder. This function is called 4 times with the proper parameters in the architecture to create a 4-bit adder. The same example, described with a task, is shown in Example 7-10.

Example 7-9 Function Declaration and Function Call

```

module comb15 (A, B, CIN, S, COUT);
    input [3:0] A, B;
    input CIN;
    output [3:0] S;
    output COUT;
    wire [1:0] S0, S1, S2, S3;
    function signed [1:0] ADD;
        input A, B, CIN;
        reg S, COUT;
        begin
            S = A ^ B ^ CIN;
            COUT = (A&B) | (A&CIN) | (B&CIN);
            ADD = {COUT, S};
        end
    endfunction

    assign S0 = ADD (A[0], B[0], CIN),
          S1 = ADD (A[1], B[1], S0[1]),
          S2 = ADD (A[2], B[2], S1[1]),
          S3 = ADD (A[3], B[3], S2[1]),
          S = {S3[0], S2[0], S1[0], S0[0]},

          COUT = S3[1];
endmodule

```

Example 7-10 Task Declaration and Task Enable

```

module EXAMPLE (A, B, CIN, S, COUT);
    input [3:0] A, B;
    input CIN;
    output [3:0] S;
    output COUT;
    reg [3:0] S;
    reg COUT;
    reg [1:0] S0, S1, S2, S3;

    task ADD;
        input A, B, CIN;
        output [1:0] C;
        reg [1:0] C;
        reg S, COUT;

        begin
            S = A ^ B ^ CIN;
            COUT = (A&B) | (A&CIN) | (B&CIN);
            C = {COUT, S};
        end
    endtask

    always @(A or B or CIN)
    begin
        ADD (A[0], B[0], CIN, S0);
        ADD (A[1], B[1], S0[1], S1);
        ADD (A[2], B[2], S1[1], S2);
        ADD (A[3], B[3], S2[1], S3);
        S = {S3[0], S2[0], S1[0], S0[0]};
        COUT = S3[1];
    end
endmodule

```

Recursive Tasks and Functions

Verilog-2001 adds support for recursive tasks and functions. You can only use recursion with the *automatic* keyword.

The syntax using recursion is shown in the following example:

```

function automatic [31:0] fac;
    input [15:0] n;
    if (n == 1)
        fac = 1;
    else
        fac = n * fac(n-1); //recursive function call
endfunction

```

Blocking Versus Non-Blocking Procedural Assignments

The # and @ time control statements delay execution of the statement following them until the specified event is evaluated as true. Use of blocking and non-blocking procedural assignments have time control built into their respective assignment statement.

The # delay is ignored for synthesis.

The syntax for a blocking procedural assignment is shown in the following example:

```
reg a;
a = #10 (b | c);
or
if (in1) out = 1'b0;
else out = in2;
```

As the name implies, these types of assignments block the current process from continuing to execute additional statements at the same time. These should mainly be used in simulation.

Non-blocking assignments, on the other hand, evaluate the expression when the statement executes, but allow other statements in the same process to execute as well at the same time. The variable change only occurs after the specified delay.

The syntax for a non-blocking procedural assignment is as follows:

```
variable <= @(posedge_or_negedge_bit) expression;
```

The following shows an example of how to use a non-blocking procedural assignment.

```
if (in1) out <= 1'b1;
else out <= in2;
```

Constants, Macros, Include Files and Comments

This section discusses constants, macros, include files, and comments.

Constants

By default, constants in Verilog are assumed to be decimal integers. They can be specified explicitly in binary, octal, decimal or hexadecimal by prefacing them with the appropriate syntax. For example, 4'b1010, 4'o12, 4'd10 and 4'ha all represent the same value.

Macros

Verilog provides a way to define macros as shown in the following example.

```
`define TESTEQ1 4'b1101
```

Later in the design code a reference to the defined macro is made as follows.

```
if (request == `TESTEQ1)
```

This is shown in the following example.

```
`define myzero 0
assign mysig = `myzero;
```

Verilog provides the `ifdef and `endif constructs to determine whether a macro is defined or not. These constructs are used to define conditional compilation. If the macro called out by the `ifdef command has been defined, that code is compiled. If not, the code following the `else command is compiled. The `else is not required, but the `endif must complete the conditional statement. The `ifdef and `endif constructs are shown in the following example.

```

`ifdef MYVAR
module if_MYVAR_is_declared;
...
endmodule
`else
module if_MYVAR_is_not_declared;
...
endmodule
`endif

```

Include Files

Verilog allows separating source code into more than one file. To use the code contained in another file, the current file has the following syntax:

```
`include "path/file-to-be-included"
```

Note: The path can be relative or absolute.

Multiple `include statements are allowed in a single Verilog file. This feature makes your code modular and more manageable in a team design environment where different files describe different modules of the design.

To have the file in your `include statement recognized, you must identify the directory where it resides either to ISE™ or to XST.

- By default, ISE searches the ISE project directory, so adding the file to your project directory will identify the file to ISE.
- You can direct ISE to a different directory by including a path (relative or absolute) in the `include statement in your source code.
- You can point XST directly to your include file directory by using the Verilog Include Directories option. See “[Verilog Include Directories \(Verilog Only\)](#)” in Chapter 5.
- If the include file is required for ISE to construct the design hierarchy, this file must either reside in the project directory, or be referenced by a relative or absolute path. The file *need not* be added to the project.

Be aware that conflicts can occur. For example, at the top of a Verilog file you might see the following:

```

`timescale 1 ns/1 ps
`include "modules.v"
...

```

If the specified file (in this case, `modules.v`) has been added to an ISE project directory *and* is specified with an `include, conflicts may occur and an error message displays:

```
ERROR:Xst:1068 - fifo.v, line 2. Duplicate declarations of
module 'RAMB4_S8_S8'
```

Comments

There are two forms of comments in Verilog similar to the two forms found in a language like C++.

- `//` Allows definition of a one-line comment.
- `/*` You can define a multi-line comment by enclosing it as illustrated by this sentence `*/`

Generate Statement

Generate is a construct that allows you to dynamically create Verilog code from conditional statements. This allows you to create repetitive structures or structures that are only appropriate under certain conditions. Structures that are likely to be created via a generate statement are:

- primitive or module instances
- initial or always procedural blocks
- continuous assignments
- net and variable declarations
- parameter redefinitions
- task or function definitions

XST supports the following types of generate statements:

- generate for
- generate if
- generate case

Generate For

Use a **generate for** loop to create one or more instances that can be placed inside a module. Use the generate for loop the same way you would a normal Verilog for loop with the following limitations.

- The index for a generate for loop must have a genvar variable.
- The assignments in the for loop control must refer to the genvar variable.
- The contents of the for loop must be enclosed by **begin** and **end** statements, and the **begin** statement must be named with a unique qualifier.

The following is an example of an 8-bit adder using a generate for loop.

```
generate
    genvar i;

    for (i=0; i<=7; i=i+1)
        begin : for_name
            adder add (a[8*i+7 : 8*i], b[8*i+7 : 8*i],
                       ci[i], sum_for[8*i+7 : 8*i], c0_or[i+1]);
        end
    endgenerate
```

Generate If... else

A **generate if** statement can be used inside a generate block to conditionally control what objects get generated.

The following is an example of a generate If... else statement. The generate controls what type of multiplier is instantiated. Please note that the contents of each branch of the if... else statement must be enclosed by **begin** and **end** statements, and the **begin** statement must be named with a unique qualifier.

```

generate
    if (IF_WIDTH < 10)
        begin : if_name
            adder #(IF_WIDTH) u1 (a, b, sum_if);
        end
    else
        begin : else_name
            subtractor #(IF_WIDTH) u2 (a, b, sum_if);
        end
    endgenerate

```

Generate Case

A **generate case** statement can be used inside a generate block to conditionally control what objects get generated. Use a generate case statement when there are several conditions to be tested to determine what the generated code would be. Please note that each test statement in a generate case statement must be enclosed by **begin** and **end** statements, and the **begin** statement must be named with a unique qualifier.

The following is an example of a generate case statement. The generate controls what type of adder is instantiated.

```

generate
    case (WIDTH)
        1:
            begin : case1_name
                adder #(WIDTH*8) x1 (a, b, ci, sum_case, c0_case);
            end
        2:
            begin : case2_name
                adder #(WIDTH*4) x2 (a, b, ci, sum_case, c0_case);
            end
        default:
            begin : d_case_name
                adder x3 (a, b, ci, sum_case, c0_case);
            end
    endcase
endgenerate

```

Variable Part Selects

Verilog 2001 adds the capability to use variables to select a group of bits from a vector. A variable part select is defined by the starting point of its range and the width of the vector, instead of being bounded by two explicit values. The starting point of the part select can vary, but the width of the part select remains constant.

- **+**: —Indicates that the part select increases from the starting point.
- **-**: —Indicates that the part select decreases from the starting point.

Example:

```

reg [3:0] data;
reg [3:0] select; // a value from 0 to 7
wire [7:0] byte = data[select +: 8];

```

Structural Verilog Features

Structural Verilog descriptions assemble several blocks of code and allow the introduction of hierarchy in a design. The basic concepts of hardware structure are the module, the port and the signal. The component is the building or basic block. A port is a component I/O connector. A signal corresponds to a wire between components.

In Verilog, a component is represented by a design module. The module declaration provides the "external" view of the component; it describes what can be seen from the outside, including the component ports. The module body provides an "internal" view; it describes the behavior or the structure of the component.

The connections between components are specified within component instantiation statements. These statements specify an instance of a component occurring within another component or the circuit. Each component instantiation statement is labeled with an identifier. Besides naming a component declared in a local component declaration, a component instantiation statement contains an association list (the parenthesized list) that specifies which actual signals or ports are associated with which local ports of the component declaration.

The Verilog language provides a large set of built-in logic gates which can be instantiated to build larger logic circuits. The set of logical functions described by the built-in gates includes AND, OR, XOR, NAND, NOR and NOT.

Here is an example of building a basic XOR function of two single bit inputs a and b.

```
module build_xor (a, b, c);
    input a, b;
    output c;
    wire c, a_not, b_not;
    not a_inv (a_not, a);
    not b_inv (b_not, b);
    and a1 (x, a_not, b);
    and a2 (y, b_not, a);
    or out (c, x, y);
endmodule
```

Each instance of the built-in modules has a unique instantiation name such as a_inv, b_inv, out. The wiring up of the gates describes an XOR gate in structural Verilog.

Example 7-11 gives the structural description of a half adder composed of four, 2 input nand modules.

Example 7-11 Structural Description of a Half Adder

```
module halfadd (X, Y, C, S);
    input X, Y;
    output C, S;
    wire S1, S2, S3;
    nand NANDA (S3, X, Y);
    nand NANDB (S1, X, S3);
    nand NANDC (S2, S3, Y);
    nand NANDD (S, S1, S2);
    assign C = S3;
endmodule
```




Figure 7-1: Synthesized Top Level Netlist

The structural features of Verilog HDL also allow you to design circuits by instantiating pre-defined primitives such as gates, registers and Xilinx® specific primitives like CLKDLL and BUFGs. These primitives are other than those included in the Verilog language. These pre-defined primitives are supplied with the XST Verilog libraries (`unisim_comp.v`).

Example 7-12 Structural Instantiation of Register and BUFG

```
module foo (sysclk, in, reset, out);
    input sysclk, in, reset;
    output out;
    reg out;
    wire sysclk_out;

    FDC register (sysclk, reset, in, out); //position based referencing
    BUFG clk (.O(sysclk_out), .I(sysclk)); //name based referencing
    ...
endmodule
```

The `unisim_comp.v` library file supplied with XST, includes the definitions for FDC and BUFG.

```
module FDC ( C, CLR, D, Q );
    input C;
    input CLR;
    input D;
    output Q;
endmodule

// synthesis attribute BOX_TYPE of FDC is "BLACK_BOX"

module BUFG ( O, I );
    output O;
    input I;
endmodule

// synthesis attribute BOX_TYPE of BUFG is "BLACK_BOX"
```

Parameters

Verilog modules support defining constants known as parameters which can be passed to module instances to define circuits of arbitrary widths. Parameters form the basis of creating and using parameterized blocks in a design to achieve hierarchy and stimulate modular design techniques. The following is an example of the use of parameters. Null string parameters are not supported.

Example 7-13 Using Parameters

```

module lpm_reg (out, in, en, reset, clk);
    parameter SIZE = 1;
    input in, en, reset, clk;
    output out;
    wire [SIZE-1 : 0] in;
    reg [SIZE-1 : 0] out;
    always @(posedge clk or negedge reset)
        begin
            if (!reset)
                out <= 1'b0;
            else
                if (en)
                    out <= in;
                else
                    out <= out;      //redundant assignment
        end
    endmodule
module top ();      //portlist left blank intentionally
    ...
    wire [7:0] sys_in, sys_out;
    wire sys_en, sys_reset, sysclk;
    lpm_reg #8 buf_373 (sys_out, sys_in, sys_en, sys_reset, sysclk);
    ...
endmodule

```

Instantiation of the module lpm_reg with a instantiation width of 8 causes the instance buf_373 to be 8 bits wide.

Parameter/Attribute Conflicts

Since parameters and attributes can be applied to both instances and modules in your Verilog code, and attributes can also be specified in a constraints file, from time to time, conflicts will arise. To resolve these conflicts, XST uses the following rules of precedence.

1. Whatever is specified on an instance (lower level) takes precedence over what is specified on a module (higher level).
2. If a parameter and an attribute are specified on either the same instance or the same module, the parameter takes precedence, and XST issues a message warning of the conflict.
3. An attribute specified in the XCF file will always take precedence over attributes or parameters specified in your Verilog code.

Note: When an attribute specified on an instance overrides a parameter specified on a module in XST, it is possible that your simulation tool may nevertheless use the parameter. This may cause the simulation results to not match the synthesis results.

Use the following matrix as a guide in determining precedence.

	Parameter on an Instance	Parameter on a Module
Attribute on an Instance	Apply Parameter (XST issues warning message)	Apply Attribute (possible simulation mismatch)
Attribute on a Module	Apply Parameter	Apply Parameter (XST issues warning message)
Attribute in XCF	Apply Attribute (XST issues warning message)	Apply Attribute

Note: Security attributes on the module definition always have higher precedence than any other attribute or parameter.

Verilog Limitations in XST

This section describes Verilog limitations in XST support for case sensitivity, and blocking and nonblocking assignments.

Case Sensitivity

XST supports case sensitivity as follows:

- Designs can use case equivalent names for I/O ports, nets, regs and memories.
- Equivalent names are renamed using a postfix ("rnm<Index>").
- A rename construct is generated in the NGC file.
- Designs can use Verilog identifiers that differ only in case. XST renames them using a postfix as with equivalent names.

Following is an example.

```
module upperlower4 (input1, INPUT1, output1, output2);
    input input1;
    input INPUT1;
```

For the above example, INPUT1 is renamed to INPUT1_rnm0.

The following restrictions apply for Verilog within XST:

- Designs using equivalent names (named blocks, tasks, and functions) are rejected.

Example:

```
...
always @(clk)
begin: fir_main5
    reg [4:0] fir_main5_w1;
    reg [4:0] fir_main5_W1;
```

This code generates the following error message:

```
ERROR:Xst:863 - "design.v", line 6: Name conflict
(<fir_main5/fir_main5_w1> and <fir_main5/fir_main5_W1>)
```

- Designs using case equivalent module names are also rejected.

Example:

```
module UPPERLOWER10 (...);
...
module upperlower10 (...);
...
```

This example generates the following error message:

```
ERROR:Xst:909 - Module name conflict (UPPERLOWER10 and upperlower10).
```

Blocking and Nonblocking Assignments

XST rejects Verilog designs if a given signal is assigned through both blocking and nonblocking assignments as in the following example.

```
always @ (in1)
begin
    if (in2)
        out1 = in1;
    else
        out1 <= in2;
end
```

If a variable is assigned in both a blocking and nonblocking assignment, the following error message is generated:

```
ERROR:Xst:880 - "design.v", line n: Cannot mix blocking and non blocking
assignments on signal <out1>.
```

There are also restrictions when mixing blocking and nonblocking assignments on bits and slices.

The following example is rejected even if there is no real mixing of blocking and non blocking assignments:

```
if (in2)
begin
    out1[0] = 1'b0;
    out1[1] <= in1;
end
else
begin
    out1[0] = in2;
    out1[1] <= 1'b1;
end
```

Errors are checked at the signal level, not at the bit level.

If there is more than a single blocking/non blocking error, only the first one is reported.

In some cases, the line number for the error might be incorrect (as there might be multiple lines where the signal has been assigned).

Integer Handling

There are several cases where XST handles integers differently from other synthesis tools, and so they must be coded in a particular way.

In **Case** statements, do not use unsized integers in case item expressions, as this causes unpredictable results. In the following example, the case item expression "4" is an unsized integer that causes unpredictable results. To avoid problems, size the "4" to 3 bits as shown below.

```
reg [2:0] condition1;

always @(condition1)
begin
    case(condition1)
        4      : data_out = 2;      // < will generate bad logic
        3'd4  : data_out = 2;      // < will work
    endcase
end
```

In **concatenations**, do not use unsized integers, as this causes unpredictable results. If you must use an expression that results in an unsized integer, assign the expression to a temporary signal, and use the temporary signal in the concatenation as shown below.

```
reg [31:0] temp;
assign temp = 4'b1111 % 2;
assign dout = {12/3,temp,din};
```

Verilog Meta Comments

XST supports meta comments in Verilog. Meta comments are comments that are understood by the Verilog parser.

Meta comments can be used as follows:

- Set constraints on individual objects (for example, module, instance, net).
- Set directives on synthesis:
 - ◆ parallel_case and full_case directives.
 - ◆ translate_on translate_off directives.
 - ◆ all tool specific directives (for example, syn_sharing), refer to [Chapter 5, “Design Constraints”](#) for details.

Meta comments can be written using the C-style (*/* ... */*) or the Verilog style (*// ...*) for comments. C-style comments can be multiple line. Verilog style comments end at the end of the line.

XST supports the following:

- Both C-style and Verilog style meta comments
- translate_on translate_off directives


```
// synthesis translate_on
// synthesis translate_off
```
- parallel_case, full_case directives


```
// synthesis parallel_case full_case
// synthesis parallel_case
// synthesis full_case
```

- Constraints on individual objects

The general syntax is:

```
// synthesis attribute AttributeName [of] ObjectName [is]AttributeValue
```

Examples:

```
// synthesis attribute RLOC of u123 is R11C1.S0
// synthesis attribute HUSET u1 MY_SET
// synthesis attribute fsm_extract of State2 is "yes"
// synthesis attribute fsm_encoding of State2 is "gray"
```

For a full list of constraints, refer to [Chapter 5, “Design Constraints.”](#)

Verilog Language Support Tables

The following tables indicate which Verilog constructs are supported in XST. Previous sections in this chapter describe these constructs and their use within XST.

Note: XST does not allow underscores as the first character of signal names (for example, _DATA_1).

Table 7-3: Constants

Integer Constants	Supported
Real Constants	Supported
Strings Constants	Unsupported

Table 7-4: Data Types

Nets	net type	wire	Supported
		tri	Supported
		supply0, supply1	Supported
		wand, wor, triand, trior	Supported
		tri0, tri1, trireg	Unsupported
	drive strength		Ignored
Registers	reg		Supported
	integer		Supported
	real		Unsupported
	realtime		Unsupported

Table 7-4: Data Types

Vectors	net		Supported	
	reg		Supported	
	vectored		Supported	
	scalared		Supported	
Multi-Dimensional Arrays (<= 2 dimensions)			Supported	
Parameters			Supported	
Named Events			Unsupported	

Table 7-5: Continuous Assignments

Drive Strength	Ignored
Delay	Ignored

Table 7-6: Procedural Assignments

Blocking Assignments		Supported
Non-Blocking Assignments		Supported
Continuous Procedural Assignments	assign	Supported with limitations See “ Assign and Deassign Statements ”
	deassign	
	force	Unsupported
	release	Unsupported
if Statement	if, if else	Supported
case Statement	case, casex, casez	Supported
forever Statement		Unsupported
repeat Statement		Supported (repeat value must be constant)
while Statement		Supported

Table 7-6: Procedural Assignments

for Statement		Supported (bounds must be static)
fork/join Statement		Unsupported
Timing Control on Procedural Assignments	delay (#)	Ignored
	event (@)	Unsupported
	wait	Unsupported
	named events	Unsupported
Sequential Blocks		Supported
Parallel Blocks		Unsupported
Specify Blocks		Ignored
initial Statement		Supported
always Statement		Supported
task		Supported
functions		Supported (Constant Functions Unsupported)
disable Statement		Supported

Table 7-7: System Tasks and Functions

System Tasks	Ignored
System Functions	Unsupported

Table 7-8: Design Hierarchy

Module definition	Supported
Macromodule definition	Unsupported
Hierarchical names	Unsupported
defparam	Supported
Array of instances	Supported

Table 7-9: Compiler Directives

`celldesignate `endcelldesignate	Ignored
`default_nettype	Supported
`define	Supported
`ifdef `else `endif	Supported
`undef, `ifndef, `elsif,	Supported
`include	Supported
`resetall	Ignored
`timescale	Ignored
`unconnected_drive `nounconnected_drive	Ignored
`uselib	Unsupported
`file, `line	Supported

System Tasks

Table [Table 7-10](#) shows XST's support for system tasks.

Table 7-10: System Task Support

\$display	Supported*
\$fclose	Supported
\$fdisplay	Supported
\$fgets	Supported
\$finish	Ignored
\$fopen	Supported
\$fscanf	Supported**
\$fwrite	Supported
\$monitor	Ignored
\$random	Ignored
\$readmemb	Supported
\$readmemh	Supported
\$signed	Supported
\$stop	Ignored
\$strobe	Ignored
\$time	Ignored

Table 7-10: System Task Support

\$unsigned	Supported
\$write	Supported*
all others	Ignored

*Escape sequences are limited to %d, %b, %h, %o, %c and %s

**Escape sequences are limited to %b and %d

Any system tasks that are not supported are ignored by the XST Verilog compiler.

The \$signed and \$unsigned system tasks can be called on any expression using the following syntax:

```
$signed(expr) or $unsigned(expr)
```

The return value from these calls will be of the same size as the input value, and its sign will be forced regardless of any previous sign.

The \$readmemb and \$readmemh system tasks can be used to initialize block memories. See “[Using System Tasks to Initialize RAM from an External File](#)” in Chapter 2 for more information.

The remainder of the system tasks can be used to display information to your computer screen and log file during processing, or to open and use a file during synthesis. You must call these tasks from within initial blocks. XST supports a subset of escape sequences, specifically %h, %d, %o, %b, %c and %s. Following is sample code showing the syntax for \$display that reports the value of a binary constant in decimal format:

```
parameter c = 8'b00101010;
initial
begin
    $display ("The value of c is %d", c);
end
```

The following information is written to the log file during the HDL Analysis phase:

```
Analyzing top module <example>.
c = 8'b00101010
"foo.v" line 9: $display : The value of c is 42
```

Primitives

XST supports certain gate level primitives. The supported syntax is as follows:

```
gate_type instance_name (output, inputs, ...);
```

The following example shows Gate Level Primitive Instantiations.

```
and U1 (out, in1, in2);
bufif1 U2 (triout, data, trienable);
```

The following table shows which primitives are supported.

Table 7-11: Primitives

Gate Level Primitives	and nand nor or xnor xor	Supported
	buf not	Supported
	bufif0 bufif1 notif0 notif1	Supported
	pulldown pullup	Unsupported
	drive strength	Ignored
	delay	Ignored
	array of primitives	Supported
Switch Level Primitives	cmos nmos pmos rcmos rnmos rpmos	Unsupported
	rtran rtranif0 rtranif1 tran tranif0 tranif1	Unsupported
User Defined Primitives		Unsupported

Verilog Reserved Keywords

The following table shows the Verilog reserved keywords.

Table 7-12: Verilog Reserved Keywords.

always	end	ifnone	not	rnmos	tri
and	endcase	incdir*	notif0	rpmos	tri0
assign	endconfig*	include*	notif1	rtran	tri1
automatic	endfunction	initial	or	rtranif0	triand
begin	endgenerate	inout	output	rtranif1	trior
buf	endmodule	input	parameter	scalared	trireg
bufif0	endprimitive	instance*	pmos	show- cancelled*	use*
bufif1	endspecify	integer	posedge	signed	vectored
case	endtable	join	primitive	small	wait
casex	endtask	large	pull0	specify	wand
casez	event	liblist*	pull1	specparam	weak0
cell*	for	library*	pullup	strong0	weak1
cmos	force	localparam*	pulldown	strong1	while
config*	forever	macromodule	pulsestyle- _ondetect*	supply0	wire

Table 7-12: Verilog Reserved Keywords.

deassign	fork	medium	pulsestyle-_onevent*	supply1	wor
default	function	module	rcmos	table	xnor
defparam	generate	nand	real	task	xor
design*	genvar	negedge	realtime	time	
disable	highz0	nmos	reg	tran	
edge	highz1	nor	release	tranif0	
else	if	noshow-cancelled*	repeat	tranif1	

* These keywords are reserved by Verilog, but not supported by XST.

Verilog-2001 Support in XST

XST 6.1i supports the following Verilog-2001 features. For details on Verilog-2001, see *Verilog-2001: A Guide to the New Features* by Stuart Sutherland, or *IEEE Standard Verilog Hardware Description Language* manual, (IEEE Standard 1364-2001).

- Generate statements
- Combined port/data type declarations
- ANSI-style port lists
- Module parameter port lists
- ANSI C style task/function declarations
- Comma separated sensitivity list
- Combinatorial logic sensitivity
- Default nets with continuous assigns
- Disable default net declarations
- Indexed vector part selects
- Multi-dimensional arrays
- Arrays of net and real data types
- Array bit and part selects
- Signed reg, net, and port declarations
- Signed based integer numbers
- Signed arithmetic expressions
- Arithmetic shift operators
- Automatic width extension past 32 bits
- Power operator
- N sized parameters
- Explicit in-line parameter passing
- Fixed local parameters
- Enhanced conditional compilation

- File and line compiler directives
- Variable part selects
- Recursive Tasks and Functions

Mixed Language Support

This chapter contains the following sections:

- “Introduction”
- “Mixed Language Project File”
- “VHDL/Verilog Boundary Rules”
- “Port Mapping”
- “Generics Support in Mixed Language Projects”
- “Library Search Order File”

Introduction

XST supports mixed VHDL/Verilog projects. This chapter explains how to create mixed language projects and what the current limitations are. The following are key features of mixed language support:

- Mixing of VHDL and Verilog is restricted to design unit (cell) instantiation only. A VHDL design can instantiate a Verilog module, and a Verilog design can instantiate a VHDL entity. Any other kind of mixing between VHDL and Verilog is not supported.
- In a VHDL design, a restricted subset of VHDL types, generics and ports is allowed on the boundary to a Verilog module. Similarly, in a Verilog design, a restricted subset of Verilog types, parameters and ports is allowed on the boundary to a VHDL entity or configuration.
- XST binds VHDL design units to a Verilog module during the Elaboration step.
- Component instantiation based on default binding is used for binding Verilog modules to a VHDL design unit.

Note: Configuration specification, direct instantiation and component configurations are not supported for a Verilog module instantiation in VHDL.

In supporting mixed projects:

- VHDL and Verilog project files are unified.
- VHDL and Verilog libraries are logically unified.
- Specification of work directory for compilation (xsthdpdir), previously available only for VHDL, is also available for Verilog.
- The xhdp.ini mechanism for mapping a logical library name to a physical directory name on the host file system, previously available only for VHDL, is also available for Verilog.

- Mixed language projects accept a search order used for searching unified logical libraries in design units (cells). During elaboration, XST follows this search order for picking and binding a VHDL entity or a Verilog module to the mixed language project.

Mixed Language Project File

XST uses a dedicated mixed language project file to support mixed VHDL/Verilog designs. You can use this mixed language format not only for mixed projects, but also for purely VHDL or Verilog projects. If you use Project Navigator to run XST, Project Navigator creates the project file, and it is always a mixed language project file. If you run XST from the command line, you must create a mixed language project file for your mixed language projects.

To create a mixed language project file at the command line, use the `-ifmt` command line switch set to *mixed* or with its value omitted. Please note that you can still use the VHDL and Verilog formats for existing designs. To use the VHDL format, set `-ifmt` to *vhdl*, and to use the Verilog format, set `-ifmt` to *verilog*.

The syntax for invoking a library or any external file in a mixed language project is as follows:

```
language library file_name.ext
```

The following is an example of how to invoke libraries in a mixed language project:

```
vhdl      work      my_vhdl1.vhd
verilog   work      my_vlg1.v
vhdl      my_vhdl_lib my_vhdl2.vhd
verilog   my_vlg_lib  my_vlg2.v
```

Each line specifies a single HDL design file:

- The first column specifies whether the HDL file is VHDL or Verilog.
- The second column specifies the logic library, where the HDL is compiled. By default the logic library is "work".
- The third column specifies the name of the HDL file.

VHDL/Verilog Boundary Rules

The boundary between VHDL and Verilog is enforced at the design unit level. A VHDL design can instantiate a Verilog module. A Verilog design can instantiate a VHDL entity.

Instantiating a Verilog Module in a VHDL Design

To instantiate a Verilog module in your VHDL design, do the following.

1. Declare a VHDL component with the same name (respecting case sensitivity) as the Verilog module you want to instantiate. If the Verilog module name is not all lower case, use the Case property to preserve the case of your Verilog module. In Project Navigator, select *Maintain* for the Case option under the Synthesis Options tab in the Process Properties dialog box, or set the `-case` command line option to *maintain* at the command line.
2. Instantiate your Verilog component as if you were instantiating a VHDL component.

Note: Using a VHDL configuration declaration, one could attempt to bind this component to a particular design unit from a particular library. Please note that such binding is not supported. Only default Verilog module binding is supported.

The only Verilog construct that can be instantiated in a VHDL design is a Verilog module. No other Verilog constructs are visible to VHDL code.

During elaboration, all components subject to default binding are regarded as design units with the same name as the corresponding component name. In the binding process, XST treats a component name as a VHDL design unit name and searches for it in the logical library "work." If a VHDL design unit is found, then XST binds it. If XST cannot find a VHDL design unit, it treats the component name as a Verilog module name and searches for it using a case sensitive search. XST searches for the Verilog module in the user specified list of unified logical libraries in the user specified search order. See "[Library Search Order File](#)" for search order details. XST selects the first Verilog module matching the name, and binds it.

Note: Please remember that since libraries are unified, a Verilog cell by the same name as that of a VHDL design unit cannot co-exist in the same logical library. A newly compiled cell/unit overrides a previously compiled one.

Instantiating a VHDL Design Unit in a Verilog Design

To instantiate a VHDL entity, declare a module name with the same as name as the VHDL entity (optionally followed by an architecture name) that you want to instantiate, and perform a normal Verilog instantiation. The only VHDL construct that can be instantiated in a Verilog design is a VHDL entity. No other VHDL constructs are visible to Verilog code. When you do this, XST uses the entity/architecture pair as the Verilog/VHDL boundary.

XST performs the binding during elaboration. In the binding process, XST searches for a Verilog module name (it ignores any architecture name specified in the module instantiation) using the name of the instantiated module in the user specified list of unified logical libraries in the user specified order. See "[Library Search Order File](#)" for search order details. If found, XST binds the name. If XST cannot find a Verilog module, it treats the name of the instantiated module as a VHDL entity, and searches for it using a case sensitive search for a VHDL entity. XST searches for the VHDL entity in the user specified list of unified logical libraries in the user specified order, assuming that a VHDL design unit was stored with extended identifier. See "[Library Search Order File](#)" for search order details. If found, XST binds the name. XST selects the first VHDL entity matching the name, and binds it.

XST has the following limitations when instantiating a VHDL design unit from a Verilog module:

- Explicit port association must be used. That is, formal and effective port names must be specified in the port map.
- All parameters must be passed at instantiation, even if they are unchanged.
- The parameter override shall be named and not ordered. The parameter override must be done through instantiation and not through defparams.

The following is an example of the correct use of parameter override.

```
ff #(.init(2'b01)) u1 (.sel(sel), .din(din), .dout(dout));
```

The following is an *incorrect* use of the of parameter override, and is not accepted by XST.

```
ff u1 (.sel(sel), .din(din), .dout(dout));
defparam u1.init = 2'b01;
```

Port Mapping

XST uses the following rules and limitations for port mapping in mixed language projects.

- For VHDL entities instantiated in Verilog designs, XST supports the following port types.
 - ◆ in
 - ◆ out
 - ◆ inout
- Note:** XST does not support VHDL buffer and linkage ports.
- For Verilog modules instantiated in VHDL designs, XST supports the following port types.
 - ◆ input
 - ◆ output
 - ◆ inout
- Note:** XST does not support connection to bi-directional pass switches in Verilog.
- XST does not support unnamed Verilog ports for mixed language boundaries.
- Use an equivalent component declaration for connecting to a case sensitive port in a Verilog module. By default, XST assumes Verilog ports are in all lower case.
- XST supports the following VHDL data types for mixed language designs.
 - ◆ bit
 - ◆ bit_vector
 - ◆ std_logic
 - ◆ std_ulogic
 - ◆ std_logic_vector
 - ◆ std_ulogic_vector

XST supports the following Verilog data types for mixed language designs.

- ◆ wire
- ◆ reg

Generics Support in Mixed Language Projects

XST supports the following VHDL generic types, and their Verilog equivalents for mixed language designs.

- integer
- real
- string
- boolean

Library Search Order File

The Library Search Order (LSO) file specifies the search order that XST uses to link the libraries used in VHDL/Verilog mixed language designs. By default, XST searches the files specified in the project file in the order in which they appear in that file. XST uses the default search order when either the DEFAULT_SEARCH_ORDER keyword is used in the LSO file or the LSO file is not specified.

Project Navigator

In Project Navigator, the default name for the LSO file is *project_name.lso*. If a *project_name.lso* file does not already exist, Project Navigator automatically creates one. If Project Navigator detects an existing *project_name.lso* file, this file is preserved and used as it is. Please remember that in Project Navigator, the name of the project is the name of the top-level block. In creating a default LSO file, Project Navigator places the DEFAULT_SEARCH_ORDER keyword in the first line of the file.

Command Line

When using XST from the command line, specify the Library Search Order file by using the –lso command line switch. If the –lso switch is omitted, XST automatically uses the default library search order without using an LSO file.

Search Order Rules

XST follows the following search order rules when processing a mixed language project.

- When the LSO file contains only the DEFAULT_SEARCH_ORDER keyword, XST:
 - ◆ searches the specified library files in the order in which they appear in the project file.
 - ◆ updates the LSO file by:
 - removing the DEFAULT_SEARCH_ORDER keyword.
 - adding the list of libraries to the LSO file in the order in which they appear in the project file.

See “[Example 1](#)”.

- When the LSO file contains the DEFAULT_SEARCH_ORDER keyword, and a list of the libraries, XST:
 - ◆ searches the specified library files in the order in which they appear in the project file.
 - ◆ ignores the list of library files in the LSO file.
 - ◆ leaves the LSO file unchanged.

See “[Example 2](#)”.

- When the LSO file contains a list of the libraries without the DEFAULT_SEARCH_ORDER keyword, XST:
 - ◆ searches the library files in the order in which they appear in the LSO file.
 - ◆ leaves the LSO file unchanged.

See “[Example 3](#)”.

- When the LSO file is empty, XST:
 - ◆ generates a warning message stating that the LSO file is empty.
 - ◆ searches the files specified in the project file using the default library search order.
 - ◆ updates the LSO file by adding the list of libraries in the order that they appear in the project file.
 - When the LSO file contains a library name that does not exist in the project or INI file, and the LSO file does not contain the DEFAULT_SEARCH_ORDER keyword, XST ignores the library.
- See “[Example 4](#)”.

Examples

Example 1

For a project file, `my_proj.prj`, with the following contents:

```

vhdl      vhlib1  f1.vhd
verilog   rtfllib f1.v
vhdl      vhlib2  f3.vhd
LSO file Created by ProjNav

```

and an LSO file, `my_proj.lso`, created by Project Navigator, with the following contents:

```
DEFAULT_SEARCH_ORDER
```

XST uses the following search order.

```

vhlib1
rtfllib
vhlib2

```

After processing, the contents of `my_proj.lso` will be:

```

vhlib1
rtfllib
vhlib2

```

Example 2

For a project file, `my_proj.prj`, with the following contents:

```

vhdl      vhlib1  f1.vhd
verilog   rtfllib f1.v
vhdl      vhlib2  f3.vhd

```

and an LSO file, `my_proj.lso`, created with the following contents:

```

rtfllib
vhlib2
vhlib1
DEFAULT_SEARCH_ORDER

```

XST uses the following search order.

```
vhlib1  
rtfllib  
vhlib2
```

After processing, the contents of my_proj.lso will be:

```
rtfllib  
vhlib2  
vhlib1  
DEFAULT_SEARCH_ORDER
```

Example 3

For a project file, my_proj.prj, with the following contents:

```
vhdl      vhlib1  f1.vhd  
verilog   rtfllib  f1.v  
vhdl      vhlib2  f3.vhd
```

and an LSO file, my_proj.lso, created with the following contents:

```
rtfllib  
vhlib2  
vhlib1
```

XST uses the following search order.

```
rtfllib  
vhlib2  
vhlib1
```

After processing, the contents of my_proj.lso will be:

```
rtfllib  
vhlib2  
vhlib1
```

Example 4

For a project file, my_proj.prj, with the following contents:

```
vhdl      vhlib1  f1.vhd  
verilog   rtfllib  f1.v  
vhdl      vhlib2  f3.vhd
```

and an LSO file, my_proj.lso, created with the following contents:

```
personal_lib  
rtfllib  
vhlib2  
vhlib1
```

XST uses the following search order.

```
rtfllib  
vhlib2  
vhlib1
```

After processing, the contents of my_proj.lso will be:

```
rtfllib  
vhlib2  
vhlib1
```

Log File Analysis

This chapter contains the following sections:

- “Introduction”
- “Reducing the Size of the LOG File”
- “Timing Report”
- “FPGA Log File”
- “CPLD Log File”

Introduction

The XST log file related to FPGA optimization contains the following sections:

- Copyright Statement
- Table of Contents

Use this section to quickly navigate to different LOG file sections.

Note: These headings are not linked. Use the Find function in your text editor to navigate.

- Synthesis Options Summary
- HDL Compilation

See “HDL Analysis” below.

- HDL Analysis

During HDL Compilation and HDL Analysis, XST parses and analyzes VHDL/Verilog files and gives the names of the libraries into which they are compiled. During this step XST may report potential mismatches between synthesis and simulation results, potential multi-sources, and other issues.

- HDL Synthesis

During this step, XST tries to recognize as many basic macros as possible to create a technology specific implementation. This is done on a block by block basis. At the end of this step XST gives an HDL Synthesis Report.

See [Chapter 2, “HDL Coding Techniques”](#) for more details about the processing of each macro and the corresponding messages issued during the synthesis process.

- Advanced HDL Synthesis

During this step XST performs advanced macro recognition and inference. In this step, XST recognizes dynamic shift registers, implements pipelined multipliers, codes state machines, etc. This report contains a summary of recognized macros in the overall design, sorted by macro type.

- Low Level Synthesis

During this step XST reports the potential removal of equivalent flip-flops, register replication, etc.

For more information, see “[Log File Analysis](#)” in Chapter 3.

- Final Report

The Final report is different for FPGA and CPLD flows as follows.

- ◆ FPGA and CPLD: includes the output file name, output format, target family and cell usage.
- ◆ FPGA only: In addition to the above, the report includes the following information for FPGAs.
 - Device Utilization Summary: where XST estimates the number of slices, gives the number of flip-flops, IOBs, BRAMs, etc. This report is very close to the one produced by MAP.
 - Clock Information: gives information about the number of clocks in the design, how each clock is buffered and how many loads it has.
 - Timing report: contains Timing Summary and Detailed Timing Report. For more information, see “[Log File Analysis](#)” in Chapter 3.
 - Encrypted Modules: if a design contains encrypted modules, XST hides the information about these modules.

Reducing the Size of the LOG File

There are several ways to reduce the size of the LOG file, generated by XST. They are as follows:

- Quiet Mode
- Silent Mode
- Hiding specific messages

When running XST from within Project Navigator, you can use a Message Filtering wizard to select specific messages to filter out of the log file. See *Using the Message Filters* in the ISE™ Help for more information.

Quiet Mode

Quiet mode allows you to limit the number of messages that are printed to the computer screen (stdout).

Quiet mode can be invoked by using the `-intstyle` command line switch with its value set to either `ise` or `xflow` as appropriate. The `ise` option formats messages for ISE, while the `xflow` option formats messages for XFLOW use. You can also use the old `-quiet` switch, but Xilinx strongly recommends that you not use this method because it will become obsolete in coming releases.

Normally, XST prints the entire log to stdout. In quiet mode, XST does *not* print the following portions of the log to stdout:

- Copyright Message
- Table Of Contents
- Synthesis Options Summary

- The following portions of the Final Report
 - ◆ Final Results header for CPLDs
 - ◆ Final Results section for FPGAs
 - ◆ The following note in the Timing Report

NOTE: THESE TIMING NUMBERS ARE ONLY A SYNTHESIS ESTIMATE. FOR ACCURATE TIMING INFORMATION PLEASE REFER TO THE TRACE REPORT GENERATED AFTER PLACE-AND-ROUTE.

- ◆ Timing Detail
- ◆ CPU (XST run time)
- ◆ Memory usage

Note: Device Utilization Summary, Clock Information, and Timing Summary are still available for FPGAs.

Silent Mode

Silent mode allows you keep any messages from going to the computer screen (stdout), while XST continues to generate the entire LOG file. Silent mode can be invoked using `-intstyle` switch with value set to *silent*.

Hiding specific messages

You can hide specific messages generated by XST at the HDL or Low Level Synthesis steps in specific situations by using the `XIL_XST_HIDEMESSAGES` environment variable. This environment variable can have one of the following values.

- *none* — maximum verbosity. All messages are printed out. This is the default.
- *hdl_level* — reduce verbosity during VHDL/Verilog Analysis and HDL Basic and Advanced Synthesis.
- *low_level* — reduce verbosity during Low-level Synthesis
- *hdl_and_low_levels* — reduce verbosity at all stages.

The following messages are hidden when *hdl_level* and *hdl_and_low_levels* values are specified for the `XIL_XST_HIDEMESSAGES` environment variable.

- WARNING:HDLCompilers:38 - *design.v* line 5 Macro '*my_macro*' redefined
Note: Note: this message is issued by the Verilog compiler only.
- WARNING:Xst:916 - *design.vhd* line 5: Delay is ignored for synthesis.
- WARNING:Xst:766 - *design.vhd* line 5: Generating a Black Box for component *comp*.
- Instantiating component *comp* from Library *lib*.
- Set user-defined property "LOC = X1Y1" for instance *inst* in unit *block*.
- Set user-defined property "RLOC = X1Y1" for instance *inst* in unit *block*.
- Set user-defined property "INIT = 1" for instance *inst* in unit *block*.
- Register *reg1* equivalent to *reg2* has been removed.

The following messages are hidden when low_level and hdl_and_low_levels values are specified for the XIL_XST_HIDEMESSAGES environment variable.

- WARNING:Xst:382 - Register *reg1* is equivalent to *reg2*.
- Register *reg1* equivalent to *reg2* has been removed.
- WARNING:Xst:1710 - FF/Latch *reg* (without init value) is constant in block *block*.
- WARNING:Xst 1293 - FF/Latch *reg* is constant in block *block*.
- WARNING:Xst:1291 - FF/Latch *reg* is unconnected in block *block*.
- WARNING:Xst:1426 - The value init of the FF/Latch *reg* hinders the constant cleaning in the block *block*. You could achieve better results by setting this init to value.

Timing Report

At the end of synthesis, XST reports the timing information for the design. The report shows the information for all four possible domains of a netlist: "register to register", "input to register", "register to outpad" and "inpad to outpad".

See the TIMING REPORT section of the example given in the "[FPGA Log File](#)" section for an example of the timing report sections in the XST log.

FPGA Log File

The following is an example of an XST log file for FPGA synthesis.

```
Release 8.1i - I.18
Copyright (c) 1995-2005 Xilinx, Inc. All rights reserved.
```

```
-->
```

TABLE OF CONTENTS

- 1) Synthesis Options Summary
- 2) HDL Compilation
- 3) HDL Analysis
- 4) HDL Synthesis
 - 4.1) HDL Synthesis Report
- 5) Advanced HDL Synthesis
 - 5.1) Advanced HDL Synthesis Report
- 6) Low Level Synthesis
- 7) Final Report
 - 7.1) Device utilization summary
 - 7.2) TIMING REPORT

```
=====
*           Synthesis Options Summary          *
=====
---- Source Parameters
Input File Name      : "stopwatch.prj"
Input Format         : mixed
Ignore Synthesis Constraint File : NO

---- Target Parameters
Output File Name     : "stopwatch"
Output Format        : NGC
Target Device        : xc4vfx12-12-sf363

---- Source Options
Top Module Name      : stopwatch
Automatic FSM Extraction : YES
FSM Encoding Algorithm : Auto
FSM Style            : lut
RAM Extraction       : Yes
RAM Style            : Auto
ROM Extraction        : Yes
```

```
ROM Style : Auto
Mux Extraction : YES
Mux Style : Auto
Decoder Extraction : YES
Priority Encoder Extraction : YES
Shift Register Extraction : YES
Logical Shifter Extraction : YES
XOR Collapsing : YES
Resource Sharing : YES
Automatic Register Balancing : No

---- Target Options
Add IO Buffers : YES
Global Maximum Fanout : 500
Add Generic Clock Buffer(BUFG) : 32
Number of Regional Clock Buffers : Default
Register Duplication : YES
Equivalent register Removal : YES
Slice Packing : YES
Pack IO Registers into IOBs : auto

---- General Options
Optimization Goal : Speed
Optimization Effort : 1
Keep Hierarchy : NO
Global Optimization : AllClockNets
RTL Output : Yes
Write Timing Constraints : NO
Hierarchy Separator : -
Bus Delimiter : <>
Case Specifier : maintain
Slice Utilization Ratio : 100
Slice Utilization Ratio Delta : 5

---- Other Options
lso : stopwatch.lso
Read Cores : YES
cross_clock_analysis : NO
verilog2001 : YES
safe_implementation : No
use_DSP48 : auto
Optimize Instantiated Primitives : NO
use_clock_enable : Auto
use_sync_set : Auto
use_sync_reset : Auto

=====
===== * HDL Compilation * =====
===== Compiling vhdl file "c:/temp/timer/ise/smallcntr.vhd" in Library work.
Entity <smallcntr> compiled.
Entity <smallcntr> (Architecture <inside>) compiled.
Compiling vhdl file "c:/temp/timer/ise/statmach.vhd" in Library work.
Entity <statmach> compiled.
Entity <statmach> (Architecture <inside>) compiled.
Compiling vhdl file "c:/temp/timer/ise/decode.vhd" in Library work.
Entity <decode> compiled.
Entity <decode> (Architecture <behavioral>) compiled.
Compiling vhdl file "c:/temp/timer/ise/cnt60.vhd" in Library work.
Entity <cnt60> compiled.
Entity <cnt60> (Architecture <inside>) compiled.
Compiling vhdl file "c:/temp/timer/ise/hex2led.vhd" in Library work.
Entity <HEX2LED> compiled.
Entity <HEX2LED> (Architecture <HEX2LED_arch>) compiled.
Compiling vhdl file "c:/temp/timer/ise/stopwatch.vhd" in Library work.
Entity <stopwatch> compiled.
Entity <stopwatch> (Architecture <inside>) compiled.
```

```
=====
*          HDL Analysis          *
=====
Analyzing Entity <stopwatch> (Architecture <inside>).
WARNING:Xst:766 - "c:/temp/timer/ise/stopwatch.vhd" line 68: Generating a Black Box for component <tenths>.
Entity <stopwatch> analyzed. Unit <stopwatch> generated.

Analyzing Entity <statmach> (Architecture <inside>).
Entity <statmach> analyzed. Unit <statmach> generated.

Analyzing Entity <decode> (Architecture <behavioral>).
Entity <decode> analyzed. Unit <decode> generated.

Analyzing Entity <cnt60> (Architecture <inside>).
Entity <cnt60> analyzed. Unit <cnt60> generated.

Analyzing Entity <smallcntr> (Architecture <inside>).
Entity <smallcntr> analyzed. Unit <smallcntr> generated.

Analyzing Entity <hex2led> (Architecture <hex2led_arch>).
Entity <hex2led> analyzed. Unit <hex2led> generated.

=====
*          HDL Synthesis          *
=====

Synthesizing Unit <smallcntr>.
  Related source file is "c:/temp/timer/ise/smallcntr.vhd".
  Found 4-bit up counter for signal <qoutsig>.
  Summary:
    inferred   1 Counter(s).
Unit <smallcntr> synthesized.

Synthesizing Unit <hex2led>.
  Related source file is "c:/temp/timer/ise/hex2led.vhd".
  Found 16x7-bit ROM for signal <LED>.
  Summary:
    inferred   1 ROM(s).
Unit <hex2led> synthesized.

Synthesizing Unit <cnt60>.
  Related source file is "c:/temp/timer/ise/cnt60.vhd".
Unit <cnt60> synthesized.

Synthesizing Unit <decode>.
  Related source file is "c:/temp/timer/ise/decode.vhd".
  Found 16x10-bit ROM for signal <one_hot>.
  Summary:
    inferred   1 ROM(s).
Unit <decode> synthesized.

Synthesizing Unit <statmach>.
  Related source file is "c:/temp/timer/ise/statmach.vhd".
  Found finite state machine <FSM_0> for signal <current_state>.
-----
| States      | 6
| Transitions | 11
| Inputs       | 1
| Outputs      | 2
| Clock        | CLK (rising_edge)
| Reset         | RESET (positive)
| Reset type   | asynchronous
| Reset State  | clear
| Power Up State | clear
| Encoding     | automatic
| Implementation | LUT
-----
Summary:
  inferred   1 Finite State Machine(s).
Unit <statmach> synthesized.

Synthesizing Unit <stopwatch>.
  Related source file is "c:/temp/timer/ise/stopwatch.vhd".
WARNING:Xst:646 - Signal <strtstopinv> is assigned but never used.
Unit <stopwatch> synthesized.
```

```
=====
HDL Synthesis Report
```

```
Macro Statistics
# ROMs : 3
 16x10-bit ROM : 1
 16x7-bit ROM : 2
# Counters : 2
 4-bit up counter : 2
```

```
=====
*           Advanced HDL Synthesis      *
=====
```

```
Analyzing FSM <FSM_0> for best encoding.
Optimizing FSM < MACHINE/current_state/FSM_0 > on signal <current_state[1:3]> with gray encoding.
```

State	Encoding
clear	000
zero	001
start	011
counting	010
stop	110
stopped	111

```
=====
Advanced HDL Synthesis Report
```

```
Macro Statistics
# FSMS : 1
# ROMs : 3
 16x10-bit ROM : 1
 16x7-bit ROM : 2
# Counters : 2
 4-bit up counter : 2
# Registers : 3
 Flip-Flops/Latches : 3
```

```
=====
*           Low Level Synthesis      *
=====
```

```
Optimizing unit <stopwatch> ...
```

```
Mapping all equations...
Building and optimizing final netlist ...
Found area constraint ratio of 100 (+ 5) on block stopwatch, actual ratio is 0.
```

```
=====
*           Final Report          *
=====
```

```
Final Results
RTL Top Level Output File Name : stopwatch.ngr
Top Level Output File Name : stopwatch
Output Format : NGC
Optimization Goal : Speed
Keep Hierarchy : NO
```

```
Design Statistics
# IOs : 27
```

```
Cell Usage :
# BELS : 47
# LUT2 : 1
# LUT2_L : 2
# LUT3 : 2
# LUT3_L : 3
# LUT4 : 28
# LUT4_D : 3
# LUT4_L : 8
# FlipFlops/Latches : 11
# FDC : 11
# Clock Buffers : 1
# BUFGP : 1
# IO Buffers : 26
```

```
#      IBUF          : 2
#      OBUF          : 24
# Others          : 1
# tenths         : 1
=====
```

Device utilization summary:

Selected Device : 4vfx12sf363-12

Number of Slices:	26	out of	5472	0%
Number of Slice Flip Flops:	11	out of	10944	0%
Number of 4 input LUTs:	47	out of	10944	0%
Number of bonded IOBs:	27	out of	240	11%
Number of GCLKs:	1	out of	32	3%

```
=====
TIMING REPORT
```

NOTE: THESE TIMING NUMBERS ARE ONLY A SYNTHESIS ESTIMATE.
FOR ACCURATE TIMING INFORMATION PLEASE REFER TO THE TRACE REPORT
GENERATED AFTER PLACE-and-ROUTE.

Clock Information:

```
-----
Clock Signal           | Clock buffer(FF name) | Load |
-----+-----+-----+
CLK        | BUFGP            | 11   |
```

Timing Summary:

Speed Grade: -12

Minimum period: 1.922ns (Maximum Frequency: 520.305MHz)
Minimum input arrival time before clock: 1.637ns
Maximum output required time after clock: 3.918ns
Maximum combinational path delay: 3.623ns

Timing Detail:

All values displayed in nanoseconds (ns)

```
=====
Timing constraint: Default period analysis for Clock 'CLK'
Clock period: 1.922ns (frequency: 520.305MHz)
Total number of paths / destination ports: 77 / 11
```

Delay: 1.922ns (Levels of Logic = 2)
Source: MACHINE_current_state_FFd2 (FF)
Destination: sixty_lsbcount_qoutsig_0 (FF)
Source Clock: CLK rising
Destination Clock: CLK rising

Data Path: MACHINE_current_state_FFd2 to sixty_lsbcount_qoutsig_0
Gate Net
Cell:in->out fanout Delay Delay Logical Name (Net Name)
----- -----
FDC:C->Q 8 0.265 0.598 MACHINE_current_state_FFd2
 (MACHINE_current_state_FFd2)
LUT4_D:I1->O 3 0.143 0.576 cnt60enable11 (cnt60enable)
LUT3_L:I0->LO 1 0.143 0.000 sixty_lsbcount_qoutsig_3_rstpot
 (N39)
FDC:D 0.197 sixty_lsbcount_qoutsig_3
----- -----
Total 1.922ns (0.748ns logic, 1.174ns route)
 (38.9% logic, 61.1% route)

```
=====
Timing constraint: Default OFFSET IN BEFORE for Clock 'CLK'
Total number of paths / destination ports: 11 / 11
```

Offset: 1.637ns (Levels of Logic = 2)
Source: XCOUNTER:Q_THRESH0 (PAD)
Destination: sixty_lsbcount_qoutsig_0 (FF)
Destination Clock: CLK rising

```

Data Path: XCOUNTER:Q_THRESH0 to sixty_lsbcount_qoutsig_0
          Gate      Net
Cell:in->out   fanout   Delay   Delay  Logical Name (Net Name)
-----
tenths:Q_THRESH0    2  0.000  0.578  XCOUNTER (xtermcnt)
LUT4_D:I0->O       3  0.143  0.576  cnt60enable11 (cnt60enable)
LUT3_L:I0->LO      1  0.143  0.000  sixty_lsbcount_qoutsig_3_rstpot
                                         (N39)
FDC:D               0.197           sixty_lsbcount_qoutsig_3
-----
Total=              1.637ns (0.483ns logic, 1.154ns route)
                                         (29.5% logic, 70.5% route)

=====
Timing constraint: Default OFFSET OUT AFTER for Clock 'CLK'
  Total number of paths / destination ports: 61 / 16
-----
Offset:            3.918ns (Levels of Logic = 2)
Source:            sixty_lsbcount_qoutsig_0 (FF)
Destination:       ONESOUT<6> (PAD)
Source Clock:     CLK rising

Data Path: sixty_lsbcount_qoutsig_0 to ONESOUT<6>
          Gate      Net
Cell:in->out   fanout   Delay   Delay  Logical Name (Net Name)
-----
FDC:C->Q        12  0.265  0.702  sixty_lsbcount_qoutsig_0
                                         (sixty_lsbcount_qoutsig_0)
LUT4:I0->O       1  0.143  0.394  Mrom_data_lsble_Mrom_LED6
                                         (ONESOUT_6_OBUF)
OBUF:I->O         2.414           ONESOUT_6_OBUF (ONESOUT<6>)
-----
Total             3.918ns (2.822ns logic, 1.097ns route)
                                         (72.0% logic, 28.0% route)

=====
Timing constraint: Default path analysis
  Total number of paths / destination ports: 41 / 11
-----
Delay:            3.623ns (Levels of Logic = 2)
Source:            XCOUNTER:Q<1> (PAD)
Destination:      TENTHSOUT<9> (PAD)

Data Path: XCOUNTER:Q<1> to TENTHSOUT<9>
          Gate      Net
Cell:in->out   fanout   Delay   Delay  Logical Name (Net Name)
-----
tenths:Q<1>     10  0.000  0.671  XCOUNTER (Q<1>)
LUT4:I0->O       1  0.143  0.394  TENTHSOUT<9>1 (TENTHSOUT_9_OBUF)
OBUF:I->O         2.414           TENTHSOUT_9_OBUF (TENTHSOUT<9>)
-----
Total             3.623ns (2.557ns logic, 1.066ns route)
                                         (70.6% logic, 29.4% route)

=====
CPU : 40.87 / 41.37 s | Elapsed : 57.00 / 59.00 s
-->

Total memory usage is 203496 kilobytes

Number of errors   :   0 (   0 filtered)
Number of warnings :   3 (   0 filtered)
Number of infos   :   0 (   0 filtered)

```

CPLD Log File

The following is an example of an XST log file for CPLD synthesis.

```
Release 8.1i - I.18
Copyright (c) 1995-2005 Xilinx, Inc. All rights reserved.
```

TABLE OF CONTENTS

- 1) Synthesis Options Summary
- 2) HDL Compilation
- 3) HDL Analysis
- 4) HDL Synthesis
 - 4.1) HDL Synthesis Report
- 5) Advanced HDL Synthesis
 - 5.1) Advanced HDL Synthesis Report
- 6) Low Level Synthesis
- 7) Final Report

```
=====
*                               Synthesis Options Summary *
=====

---- Source Parameters
Input File Name           : "stopwatch.prj"
Input Format               : mixed

---- Target Parameters
Output File Name          : "stopwatch"
Output Format              : NGC
Target Device              : XC9500XL CPLDs

---- Source Options
Top Module Name            : stopwatch
Automatic FSM Extraction  : YES
FSM Encoding Algorithm    : Auto
Mux Extraction             : YES
Resource Sharing           : YES

---- Target Options
Add IO Buffers             : YES
Equivalent register Removal: YES
MACRO Preserve              : YES
XOR Preserve                : YES

---- General Options
Optimization Goal          : Speed
Optimization Effort         : 1
Keep Hierarchy              : YES
RTL Output                  : Yes
Hierarchy Separator         : _
Bus Delimiter               : <>
Case Specifier              : maintain

---- Other Options
lso                         : stopwatch.lso
verilog2001                 : YES
safe_implementation          : No
Clock Enable                 : YES
wysiwyg                     : NO
=====
```

```
=====
*          HDL Compilation          *
=====
Compiling vhdl file "c:/temp/timer/ise/smallcntr.vhd" in Library work.
Entity <smallcntr> compiled.
Entity <smallcntr> (Architecture <inside>) compiled.
Compiling vhdl file "c:/temp/timer/ise/statmach.vhd" in Library work.
Entity <statmach> compiled.
Entity <statmach> (Architecture <inside>) compiled.
Compiling vhdl file "c:/temp/timer/ise/decode.vhd" in Library work.
Entity <decode> compiled.
Entity <decode> (Architecture <behavioral>) compiled.
Compiling vhdl file "c:/temp/timer/ise/cnt60.vhd" in Library work.
Entity <cnt60> compiled.
Entity <cnt60> (Architecture <inside>) compiled.
Compiling vhdl file "c:/temp/timer/ise/hex2led.vhd" in Library work.
Entity <HEX2LED> compiled.
Entity <HEX2LED> (Architecture <HEX2LED_arch>) compiled.
Compiling vhdl file "c:/temp/timer/ise/stopwatch.vhd" in Library work.
Entity <stopwatch> compiled.
Entity <stopwatch> (Architecture <inside>) compiled.

=====
*          HDL Analysis           *
=====
Analyzing Entity <stopwatch> (Architecture <inside>).
WARNING:Xst:766 - "c:/temp/timer/ise/stopwatch.vhd" line 68: Generating a Black Box for
component <tenths>.
Entity <stopwatch> analyzed. Unit <stopwatch> generated.

Analyzing Entity <statmach> (Architecture <inside>).
Entity <statmach> analyzed. Unit <statmach> generated.

Analyzing Entity <decode> (Architecture <behavioral>).
Entity <decode> analyzed. Unit <decode> generated.

Analyzing Entity <cnt60> (Architecture <inside>).
Entity <cnt60> analyzed. Unit <cnt60> generated.

Analyzing Entity <smallcntr> (Architecture <inside>).
Entity <smallcntr> analyzed. Unit <smallcntr> generated.

Analyzing Entity <hex2led> (Architecture <hex2led_arch>).
Entity <hex2led> analyzed. Unit <hex2led> generated.

=====
*          HDL Synthesis          *
=====
Synthesizing Unit <smallcntr>.
Related source file is "c:/temp/timer/ise/smallcntr.vhd".
Found 4-bit up counter for signal <qoutsig>.
Summary:
inferred    1 Counter(s).
Unit <smallcntr> synthesized.
```

```
Synthesizing Unit <hex2led>.
  Related source file is "c:/temp/timer/ise/hex2led.vhd".
  Found 16x7-bit ROM for signal <LED>.
  Summary:
    inferred    1 ROM(s).
Unit <hex2led> synthesized.
```

```
Synthesizing Unit <cnt60>.
  Related source file is "c:/temp/timer/ise/cnt60.vhd".
Unit <cnt60> synthesized.
```

```
Synthesizing Unit <decode>.
  Related source file is "c:/temp/timer/ise/decode.vhd".
  Found 16x10-bit ROM for signal <one_hot>.
  Summary:
    inferred    1 ROM(s).
Unit <decode> synthesized.
```

```
Synthesizing Unit <statmach>.
  Related source file is "c:/temp/timer/ise/statmach.vhd".
  Found finite state machine <FSM_0> for signal <current_state>.
```

States	6
Transitions	11
Inputs	1
Outputs	2
Clock	CLK (rising_edge)
Reset	RESET (positive)
Reset type	asynchronous
Reset State	clear
Power Up State	clear
Encoding	automatic
Implementation	automatic

```
Summary:
inferred    1 Finite State Machine(s).
Unit <statmach> synthesized.
```

```
Synthesizing Unit <stopwatch>.
  Related source file is "c:/temp/timer/ise/stopwatch.vhd".
WARNING:Xst:646 - Signal <strtstopinv> is assigned but never used.
Unit <stopwatch> synthesized.
```

HDL Synthesis Report

Macro Statistics	
# ROMs	: 3
16x10-bit ROM	: 1
16x7-bit ROM	: 2
# Counters	: 2
4-bit up counter	: 2

```
=====
*          Advanced HDL Synthesis      *
=====

Analyzing FSM <FSM_0> for best encoding.
Optimizing FSM </FSM_0> on signal <current_state[1:3]> with sequential encoding.
-----
 State | Encoding
-----
 clear | 000
 zero  | 001
 start | 010
 counting | 011
 stop   | 100
 stopped | 101
-----
=====

Advanced HDL Synthesis Report

Macro Statistics
# ROMs           : 3
 16x10-bit ROM : 1
 16x7-bit ROM  : 2
# Counters       : 2
 4-bit up counter : 2
# Registers     : 7
 Flip-Flops/Latches : 7
=====
=====

*          Low Level Synthesis      *
=====

Optimizing unit <stopwatch> ...
Optimizing unit <decode> ...
Optimizing unit <cnt60> ...
Optimizing unit <smallcntr> ...
Optimizing unit <hex2led> ...
Optimizing unit <statmach> ...
  implementation constraint: INIT=r : current_state_FFd3
  implementation constraint: INIT=r : current_state_FFd1
  implementation constraint: INIT=r : current_state_FFd2
```

```
=====
*                               Final Report
=====
Final Results
RTL Top Level Output File Name      : stopwatch.ngr
Top Level Output File Name         : stopwatch
Output Format                      : NGC
Optimization Goal                  : Speed
Keep Hierarchy                     : YES
Target Technology                  : XC9500XL CPLDs
Macro Preserve                      : YES
XOR Preserve                       : YES
Clock Enable                        : YES
wysiwyg                            : NO

Design Statistics
# IOs                             : 27

Cell Usage :
# BELS                           : 417
# AND2                           : 105
# AND3                           : 8
# AND4                           : 2
# INV                            : 176
# OR2                            : 124
# OR3                            : 1
# XOR2                           : 1
# FlipFlops/Latches              : 11
# FDCE                           : 8
# FTC                            : 3
# IO Buffers                      : 27
# IBUF                           : 3
# OBUF                           : 24
# Others                          : 1
# tenths                         : 1
=====
CPU : 14.07 / 14.50 s | Elapsed : 19.00 / 20.00 s
```

-->

Total memory usage is 82568 kilobytes

Number of errors : 0 (0 filtered)
Number of warnings : 3 (0 filtered)
Number of infos : 0 (0 filtered)

Command Line Mode

This chapter describes how to run XST using the command line. The chapter contains the following sections.

- “Introduction”
- “Launching XST”
- “Setting Up an XST Script”
- “Run Command”
- “Set Command”
- “Elaborate Command”
- “Example 1: How to Synthesize VHDL Designs Using Command Line Mode”
- “Example 2: How to Synthesize Verilog Designs Using Command Line Mode”
- “Example 3: How to Synthesize Mixed VHDL/Verilog Designs Using Command Line Mode”

Introduction

You can run synthesis with XST in command line mode instead of from the Process window in Project Navigator. To run synthesis from the command line, you must use the XST executable file. If you work on a workstation, the name of the executable is "xst". On a PC, the name of the executable is "xst.exe".

File Types

XST generates the following types of files:

- Design output file, NGC (.ngc)

This file is generated in the current output directory (see the –ofn option). If run in incremental synthesis mode, XST generates multiple NGC files.

- RTL netlist for RTL and Technology Viewers (.ngr)
- Synthesis LOG file (.srp)
- Temporary files

Temporary files are generated in the XST temp directory. By default the XST temp directory is /tmp on workstations and the directory specified by either the TEMP or TMP environment variables under Windows. The XST temp directory can be changed by using the **set -tmpdir <directory>** directive.

- VHDL/Verilog compilation files

VHDL/Verilog compilation files are generated in the temp directory. The default temp directory is the "xst" subdirectory of the current directory.

Note: Xilinx strongly suggests that you *clean the XST temp directory* regularly. This directory contains the files resulting from the compilation of *all VHDL and Verilog* files during all XST sessions. Eventually, the number of files stored in the temp directory may severely impact CPU performances. This directory is not automatically cleaned by XST.

Names with Spaces

Starting in release 7.1i, XST supports file and directory names with spaces. If a file or directory name contains spaces, you must enclose this name in double quotes (" ") as in the following example.

```
"C:\my project"
```

Due to this change, the command line syntax for switches supporting multiple directories (**-sd**, **-vlgincdir**) has changed. If multiple directories are specified for these switches, you must enclose them in braces ({}) as in the following example.

```
-vlgincdir {"C:\my project" C:\temp}
```

Note: In previous releases multiple directories were included in double quotes (""). This previous convention is still supported by XST if directory names do not contain spaces. Xilinx strongly suggests that you change existing scripts to the new syntax.

Launching XST

You can run XST in two ways.

- XST Shell — Type **xst** to enter directly into an XST shell. Enter your commands and execute them. To run synthesis, specify a complete command with all required options before running. XST does not accept a mode where you can first enter **set option_1**, then **set option_2**, and then enter **run**.

All of the options must be set up at once. Therefore, this method is very cumbersome and Xilinx suggests that you use the script file method.

- Script File — You can store your commands in a separate script file and run all of them at once. To execute your script file, run the following workstation or PC command:

```
xst -ifn in_file_name -ofn out_file_name -intstyle {silent|ise|xflow}
```

Note: The **-ofn** option is not mandatory. If you omit it, XST automatically generates a log file with the file extension .srp, and all messages display on the screen. Use the **-intstyle silent** option and the **XIL_XST_HIDEMESSAGES** environment variable to limit the number of messages printed to the screen. See the “Reducing the Size of the LOG File” in Chapter 9 for more information.

For example, assume that the text below is contained in a file foo.scr.

```
run
-ifn tt1.prj
-top tt1
-ifmt MIXED
-opt_mode SPEED
-opt_level 1
-ofn tt1.ngc
-p <parttype>
```

This script file can be executed under XST using the following command:

```
xst -ifn foo.scr
```

You can also generate a log file with the following command:

```
xst -ifn foo.scr -ofn foo.log
```

A script file can be run either using **xst -ifn** *script name*, or executed under the XST prompt, by using the **script** *script_name* command.

```
script foo.scr
```

If you make a mistake in an XST command, command option or its value, XST issues an error message and stops execution. For example, if in the previous script example VHDL is incorrectly spelled (VHDLL), XST gives the following error message:

```
--> ERROR:Xst:1361 - Syntax error in command run for option "-ifmt" :
parameter "VHDLL" is not allowed.
```

Setting Up an XST Script

An XST script is a set of commands, each command having various options. XST recognizes the following commands:

- run
- set
- elaborate

Run Command

Following is a description of the run command.

- The command begins with a keyword **run**, which is followed by a set of options and its values.
run *option_1 value option_2 value ...*
- Each option name starts with dash (-). For instance: -ifn, -ifmt, -ofn.
- Each option has one value. There are no options without a value.
- The value for a given option can be one of the following:
 - ◆ Predefined by XST (for instance, yes or no).
 - ◆ Any string (for instance, a file name or a name of the top level entity). There are options like -vlgincdir that accept several directories as values. The directories

must be separated by spaces, and enclosed altogether by braces ({{}}) as in the following example.

```
-vlgincdir {c:\vlg1 c:\vlg2}
```

Please refer to “Names with Spaces,” page 550 for more information.

- ◆ An integer.

Note: Table 5-1, page 436 summarizes all available XST-specific non-timing related options which includes all run command options and their values.

If you are working from the command line on a Unix system, XST provides an online Help function. The following information is available by typing *help* at the command line. XST’s help function can give you a list of supported families, available commands, switches and their values for each supported family.

- To get a detailed explanation of an XST command, use the following syntax.

```
help -arch family_name -command command_name
```

where:

- ◆ *family_name* is a list of supported Xilinx® families in the current version of XST.
- ◆ *command_name* is one of the following XST commands: **run**, **set**, **elaborate**, **time**.
- To get a list of supported families, type *help* at the command line prompt with no argument. XST displays the following message.

```
--> help
```

```
ERROR:Xst:1356 - Help : Missing "-arch <family>". Please specify what
family you want to target
```

available families:

```
spartan3
spartan2
spartan2e
virtex
virtex2
virtex2p
virtex4
virtexe
xbr
xc9500
xc9500xl
xpla3
```

- To get a list of available commands for a specific family, type the following at the command line prompt with no argument.

```
help -arch family_name.
```

For example:

```
help -arch virtex
```

Example

Use the following command to get a list of available options and values for the run command for Virtex™-II.

```
--> help -arch virtex2 -command run
```

This command gives the following output.

```
-mult_style           : Multiplier Style
                      block / lut / auto / pipe_lut
-bufg                : Maximum Global Buffers
                      *
-bufgce              : BUFGCE Extraction
                      YES / NO
-decoder_extract     : Decoder Extraction
                      YES / NO
.....
-ifn : *
-ifmt : Mixed / VHDL / Verilog
-ofn : *
-ofmt : NGC / NCD
-p : *
-ent : *
-top : *
-opt_mode : AREA / SPEED
-opt_level : 1 / 2
-keep_hierarchy : YES / NO
-vlgincdir : *
-verilog2001 : YES / NO
-vlgcase : Full / Parallel / Full-Parallel
....
```

Set Command

In addition to the run command, XST also recognizes the set command. This command accepts the options shown in the following table.

Note: See [Chapter 5, “Design Constraints”](#) for more information about the options listed in this table.

Table 10-1: Set Command Options

Set Command Options	Description	Values
<code>-tmpdir</code>	Location of all temporary files generated by XST during a session	Any valid path to a directory
<code>-xsthdpdir</code>	Work Directory — location of all files resulting from VHDL/Verilog compilation	Any valid path to a directory
<code>-xsthdpini</code>	HDL Library Mapping File (.INI File)	<i>file_name</i>

Elaborate Command

The goal of this command is to pre-compile VHDL/Verilog files in a specific library or to verify Verilog files without synthesizing the design. Taking into account that the compilation process is included in the "run", this command remains optional.

The elaborate command accepts the options shown in the following table.

Note: See Chapter 5, "Design Constraints" for more information about the options listed in this table.

Table 10-2: Elaborate Command Options

Elaborate Command Options	Description	Values
-ifn	Project File	<i>file_name</i>
-ifmt	Format	vhdl, verilog, mixed
-lso	Library Search Order	<i>file_name.lso</i>
-work_lib	Work Library for Compilation — library where the top level block was compiled	<i>name, work</i>
-verilog2001	Verilog-2001	yes, no
-vlgincdir	Verilog Include Directories	Any valid path to directories separated by spaces, and enclosed in braces ({}))

Example 1: How to Synthesize VHDL Designs Using Command Line Mode

The goal of this example is to synthesize a hierarchical VHDL design for a Virtex FPGA using Command Line Mode.

The example uses a VHDL design, called watchvhd. The files for watchvhd can be found in the ISEexamples\watchvhd directory of the ISE™ installation directory.

This design contains 7 entities:

- stopwatch
- statmach
- tenths (a CORE Generator™ core)
- decode
- smallcntr
- cnt60
- hex2led

Example 1

1. Create a new directory, named vhdl_m.
2. Copy the following files from the ISEexamples\watchvhd directory of the ISE installation directory to the newly created vhdl_m directory.
 - ◆ stopwatch.vhd
 - ◆ statmach.vhd
 - ◆ decode.vhd
 - ◆ cnt60.vhd
 - ◆ smallcntr.vhd
 - ◆ tenths.vhd
 - ◆ hex2led.vhd

To synthesize the design, which is now represented by seven VHDL files, create a project.

Please note that starting from the 6.1i release, XST supports Mixed VHDL/Verilog projects and therefore, Xilinx strongly suggests that you use the new project format whether it is a real mixed language project or not. In this example we use the new project format. To create a project file containing only VHDL files, place a list of VHDL files preceded by keyword **VHDL** in a separate file. The order of the files is not important. XST can recognize the hierarchy, and compile VHDL files in the correct order.

For the example, perform the following steps:

1. Open a new file, called watchvhd.prj
2. Enter the names of the VHDL files in any order into this file and save the file:

```
vhdl work statmach.vhd  
vhdl work decode.vhd  
vhdl work stopwatch.vhd  
vhdl work cnt60.vhd  
vhdl work smallcntr.vhd  
vhdl work tenths.vhd  
vhdl work hex2led.vhd
```

3. To synthesize the design, execute the following command from XST shell or via script file:

```
run -ifn watchvhd.prj -ifmt mixed -top stopwatch -ofn watchvhd.ngc -  
ofmt NGC  
-p xcv50-bg256-6 -opt_mode Speed -opt_level 1
```

Note: It is mandatory to specify a top-level design block via the **-top** command line switch.

If you want to synthesize just "hex2led" and check its performance independently of the other blocks, you can specify the top-level entity to synthesize on the command line, using the **-top** option (refer to [Table 5-1, page 436](#) for more details):

```
run -ifn watchvhd.prj -ifmt mixed -ofn watchvhd.ngc -ofmt NGC  
-p xcv50-bg256-6 -opt_mode Speed -opt_level 1 -top hex2led
```

During VHDL compilation, XST uses the library "work" as the default. If some VHDL files must be compiled to different libraries, then you can add the name of the library just before the file name. Suppose that "hex2led" must be compiled into the library, called `my_lib`. Then the project file must be:

```
vhdl work statmach.vhd
vhdl work decode.vhd
vhdl work stopwatch.vhd
vhdl work cnt60.vhd
vhdl work smallcntr.vhd
vhdl work vhdl tenths.vhd
vhdl my_lib work hex2led.vhd
```

Sometimes, XST is not able to recognize the order and issues the following message.

```
WARNING:XST:3204. The sort of the vhdl files failed, they will be
compiled in the order of the project file.
```

In this case you must do the following:

- Put all VHDL files in the correct order.
- Add **-hdl_compilation_order** switch with value **user** to the XST run command:


```
run -ifn watchvhd.prj -ifmt mixed -top stopwatch -ofn watchvhd.ngc
          -ofmt NGC -p xcv50-bg256-6 -opt_mode Speed -opt_level 1 -top hex2led
          -hdl_compilation_order user
```

Script Mode

It can be very tedious work to enter XST commands directly in the XST shell, especially when you have to specify several options and execute the same command several times. You can run XST in a script mode as follows:

1. Open a new file named `xst.txt` in the current directory. Put the previously executed XST shell command into this file and save it.

```
run -ifn watchvhd.prj -ifmt mixed -top stopwatch -ofn watchvhd.ngc
    -ofmt NGC -p xcv50-bg256-6 -opt_mode Speed -opt_level 1
```

2. From the tcsh or other shell, enter the following command to start synthesis.

```
xst -ifn stopwatch.xst
```

During this run, XST creates the following files.

- ◆ `watchvhd.ngc`: an NGC file ready for the implementation tools
 - ◆ `xst.srp`: the xst log file
3. If you want to save XST messages in a different log file, for example, `watchvhd.log`, execute the following command.

```
xst -ifn stopwatch.xst -ofn watchvhd.log
```

You can improve the readability of the `xst.txt` file, especially if you use many options to run synthesis, by placing each option with its value on a separate line, respecting the following rules:

- The first line must contain only the run command without any options.
- There must be no blank lines in the middle of the command.
- Each line (except the first one) must start with a dash (-).

For the previous command example, `xst.scr` should look like the following:

```
run
-ifn watchvhd.vhd
-ifmt mixed
-top stopwatch
-ofn watchvhd.ngc
-ofmt NGC
-p xcv50-bg256-6
-opt_mode Speed
-opt_level 1
```

Example 2: How to Synthesize Verilog Designs Using Command Line Mode

The goal of this example is to synthesize a hierarchical Verilog design for a Virtex FPGA using Command Line Mode.

Example 2 uses a Verilog design, called `watchver`. These files can be found in the `ISEexamples\watchver` directory of the ISE installation directory.

- `stopwatch.v`
- `statmach.v`
- `decode.v`
- `cnt60.v`
- `smallcntr.v`
- `tenths.v`
- `hex2led.v`

This design contains seven modules:

- `stopwatch`
- `statmach`
- `tenths` (a CORE Generator core)
- `decode`
- `cnt60`
- `smallcntr`
- `hex2led`

Example 2

1. Create a new directory named `vlg_m`.
2. Copy the `watchver` design files from the `ISEexamples\watchver` directory of the ISE installation directory to the newly created `vlg_m` directory.

Note: It is mandatory to specify the top-level design block via the `-top` command line switch.

To synthesize the design, which is now represented by seven Verilog files, create a project. Please note that starting from the 6.1i release XST supports Mixed VHDL/Verilog projects and therefore, Xilinx strongly suggests that you use the new project format whether it is a

real mixed language project or not. In this example, we use the new project format. To create a project file containing only Verilog files, place a list of Verilog files preceded by the keyword *verilog* in a separate file. The order of the files is not important. XST can recognize the hierarchy and compile Verilog files in the correct order. For our example:

1. Open a new file, called `watchver.v`.
2. Enter the names of the Verilog files into this file in any order and save it:

```
verilog work decode.v
verilog work statmach.v
verilog work stopwatch.v
verilog work cnt60.v
verilog work smallcntr.v
verilog work hex2led.v
```

3. To synthesize the design, execute the following command from the XST shell or via a script file:

```
run -ifn watchver.v -ifmt mixed -top stopwatch -ofn watchver.ngc
      -ofmt NGC -p xcv50-bg256-6 -opt_mode Speed -opt_level 1
```

If you want to synthesize just HEX2LED and check its performance independently of the other blocks, you can specify the top-level module to synthesize in the command line, using the `-top` option (please refer to [Table 5-1, page 436](#) for more information):

```
run -ifn watchver.v -ifmt Verilog -ofn watchver.ngc -ofmt NGC
      -p xcv50-bg256-6 -opt_mode Speed -opt_level 1 -top HEX2LED
```

Script Mode

It can be very tedious work entering XST commands directly into the XST shell, especially when you have to specify several options and execute the same command several times. You can run XST in script mode as follows.

1. Open a new file called `design.xst` in the current directory. Put the previously executed XST shell command into this file and save it.

```
run -ifn watchver.prj -ifmt mixed -ofn watchver.ngc
      -ofmt NGC -p xcv50-bg256-6 -opt_mode Speed -opt_level 1
```

2. From the tcsh or other shell, enter the following command to start synthesis.

```
xst -ifn design.xst
```

During this run, XST creates the following files.

- ◆ `watchvhd.ngc`: an NGC file ready for the implementation tools
 - ◆ `design.srp`: the xst script log file
3. If you want to save XST messages in a different log file, for example, `watchver.log`, execute the following command.

```
xst -ifn design.xst -ofn watchver.log
```

You can improve the readability of the `design.xst` file, especially if you use many options to run synthesis. You can place each option with its value on a separate line, respecting the following rules:

- The first line must contain only the `run` command without any options.
- There must be no blank lines in the middle of the command.
- Each line (except the first one) must start with a dash (-).

For the previous command example, the stopwatch.xst file should look like the following:

```
run
-ifn watchver.prj
-ifmt mixed
-top stopwatch
-ofn watchver.ngc
-ofmt NGC
-p xcv50-bg256-6
-opt_mode Speed
-opt_level 1
```

Example 3: How to Synthesize Mixed VHDL/Verilog Designs Using Command Line Mode

The goal of this example is to synthesize a hierarchical mixed VHDL/Verilog design for a Virtex FPGA using Command Line Mode.

1. Create a new directory, named vhdl_verilog.
2. Copy the following files from the ISEexamples\watchvhd directory of the ISE installation directory to the newly created vhdl_verilog directory.
 - ◆ stopwatch.vhd
 - ◆ statmach.vhd
 - ◆ decode.vhd
 - ◆ cnt60.vhd
 - ◆ smallcntr.vhd
 - ◆ tenths.vhd
3. Copy the following file from the ISEexamples\watchver directory of the ISE installation directory to the newly created vhdl_verilog directory:
 - ◆ hex2led.v

To synthesize the design, which is now represented by six VHDL files and one Verilog file, create a project. To create a project file, place a list of VHDL files preceded by keyword *vhdl*, and a list of Verilog files preceded by keyword *verilog* in a separate file. The order of the files is not important. XST is able to recognize the hierarchy, and compile HDL files in the correct order.

For our example:

1. Open a new file called *watchver.prj*.
2. Enter the names of the files into this file in any order and save it:

```
vhdl work decode.vhd
vhdl work statmach.vhd
vhdl work stopwatch.vhd
vhdl work cnt60.vhd
vhdl work smallcntr.vhd
vhdl work tenths.vhd
verilog work hex2led.v
```

3. To synthesize the design, execute the following command from the XST shell or via a script file:

```
run -ifn watchver.prj -ifmt mixed -top stopwatch -ofn watchver.ngc
    -ofmt NGC -p xcv50-bg256-6 -opt_mode Speed -opt_level 1
```

Note: It is mandatory to specify the top-level design block via the **-top** command line switch.

If you want to synthesize just HEX2LED and check its performance independently of the other blocks, you can specify it as the top level module to synthesize on the command line by using the **-top** option (please refer to [Table 5-1, page 436](#) for more information):

```
run -ifn watchver.prj -ifmt mixed -top hex2led -ofn watchver.ngc
    -ofmt NGC -p xcv50-bg256-6 -opt_mode Speed -opt_level 1
```

Script Mode

It can be very tedious work entering XST commands directly into the XST shell, especially when you have to specify several options and execute the same command several times. You can run XST in a script mode as follows.

1. Open a new file called `xst.txt` in the current directory. Put the previously executed XST shell command into this file and save it.

```
run -ifn watchver.prj -ifmt mixed -top stopwatch -ofn watchver.ngc
    -ofmt NGC -p xcv50-bg256-6 -opt_mode Speed -opt_level 1
```

2. From the tcsh or other shell, enter the following command to start synthesis.

```
xst -ifn stopwatch.xst
```

During this run, XST creates the following files:

- ◆ `watchver.ngc`: an NGC file ready for the implementation tools
- ◆ `xst.srp`: the `xst` script log file

3. If you want to save XST messages in a different log file for example, `watchver.log`, execute the following command.

```
xst -ifn stopwatch.xst -ofn watchver.log
```

You can improve the readability of the `xst.scr` file, especially if you use many options to run synthesis. You can place each option with its value on a separate line, respecting the following rules:

- The first line must contain only the `run` command without any options.
- There must be no blank lines in the middle of the command.
- Each line (except the first one) must start with a dash (-).

For the previous command example, the `stopwatch.xst` file should look like the following:

```
run
-ifn watchver.prj
-ifmt mixed
-ofn watchver.ngc
-ofmt NGC
-p xcv50-bg256-6
-opt_mode Speed
-opt_level 1
```

XST Naming Conventions

This appendix discusses net naming and instance naming conventions. The appendix contains the following sections.

- “Net Naming Conventions”
- “Instance Naming Conventions”
- “Name Generation Control”

Net Naming Conventions

These rules are listed in order of naming priority.

1. Maintain external pin names.
2. Keep hierarchy in signal names, using underscores as hierarchy designators.
3. Maintain output signal names of registers, including state bits. Use the hierarchical name from the level where the register was inferred.
4. Ensure that output signals of clock buffers get *_clockbuffertype* (like _BUFGP or _IBUFG) follow the clock signal name.
5. Maintain input nets to registers and tristates names.
6. Maintain names of signals connected to primitives and black boxes.
7. Name output net names of IBUFs using the form *net_name_IBUF*. For example, for an IBUF with an output net name of DIN, the output IBUF net name is DIN_IBUF.
Name input net names to OBUFs using the form *net_name_OBUF*. For example, for an OBUF with an input net name of DOUT, the input OBUF net name is DOUT_OBUF.

Instance Naming Conventions

These rules are listed in order of naming priority.

1. Keep hierarchy in instance names, using underscores as hierarchy designators.
2. Name register instances, including state bits, for the output signal.
3. Name clock buffer instances *_clockbuffertype* (like _BUFGP or _IBUFG) after the output signal.
4. Maintain instantiation instance names of black boxes.
5. Maintain instantiation instance names of library primitives.
6. Name input and output buffers using the form _IBUF or _OBUF after the pad name.
7. Name Output instance names of IBUFs using the form *instance_name_IBUF*.
Name input instance names to OBUFs using the form *instance_name_OBUF*.

Name Generation Control

You can control aspects of the way names are written using the following properties. You can apply these properties by either using the ISE™ Synthesis Properties dialog box or using the appropriate command line options. See [Chapter 5, “Design Constraints”](#) for more information on using these properties.

- hierarchy separator (HIERARCHY_SEPARATOR)
- bus delimiter (BUS_DELIMITER)
- case processing (CASE)
- duplication suffix (DUPLICATION_SUFFIX)

Index

Symbols

507
\$display 521
fclose 521
\$fdisplay 521
\$fgets 521
\$finish 521
\$fopen 521
\$fscanf 521
\$fwrite 521
\$monitor 521
\$random 521
\$readmemb 233, 521, 522
\$readmemh 233, 522
\$readmenh 521
\$signed 521, 522
\$stop 521
\$strobe 521
\$time 521
\$unsigned 522
\$write 522
%b 522
%c 522
%d 522
%h 522
%o 522
%s 522
@ 507

A

accumulator 83
 4-bit unsigned up accumulator with asynchronous clear 85
add I/O buffers 314, 315, 320
add io buffers 321
adder 132
 simple signed 8-bit adder 138
 unsigned 8-bit adder 132
 unsigned 8-bit adder with carry in 133
 unsigned 8-bit adder with carry in and carry out 136
 unsigned 8-bit adder with carry out 135
adder/subtractor 132
 unsigned 8-bit adder/subtractor 141
addition 495

advanced HDL synthesis 535
alias declaration 486
allclocknets 432, 433
always statement 520
arch 439
 architecture body 484
 architecture declaration 462
 architecture support 27
arithmetic 495
 arithmetic operation 131
array of instances 520
assert statement 480
assign statement 504
assignment extension past 32 bits 506
attribute 487
 attribute declaration 486
automatic FSM extraction 340, 345, 347

B

backward register balancing 394
begin model... end 319
bit vector types 456
bitwise equivalence 496
bitwise exclusive or 496
bitwise inclusive or 496
bitwise negation 496
black box support 259
black_box 445
black_box_pad_pin 445
black_box_tri_pins 445
block multiplier 145
block RAM 225
block statement 498
blocking and nonblocking assignments 516
blocking assignment 519
blocking procedural assignments 507
blocking versus von-blocking 507
box type 321
box_type 259, 321, 436
BRAM 372
bram_map 371, 372, 436
buffer type 356
buffer_type 356, 357, 436
bufg 383, 384, 439
bufgce 357, 358, 436
bufgmux 357

bufr 385, 439
bus delimiter 309, 322
bus_delimiter 322, 439, 562

C

case 309, 439, 562
case equality 496
case implementation style 110, 311, 312, 324, 325
case inequality 496
case option 323
case statement 108, 110, 519
casex 500
casez 500
cell_list 445
celldefine 521
clock enable 315, 422, 423
clock information 536
clock signal 431
clock_buffer 356, 436
clock_list 445
clock_signal 431, 432, 436
combinatorial process 469
command line 549
comparator 143

 unsigned 8-bit greater or equal comparator 143
compilation files 550
component configuration 465
component declaration 486
component instantiation 463
composite 486
concatenation 495
concurrent signal assignments 467
concurrent statement 489
conditional 497
configuration 487
 configuration declaration 484
constant declaration 486
constraint file 306
constraints precedence 449
continuous procedural assignment 519
convert tristates to logic 413, 415
CoolRunner 27
CoolRunner XPLA3 27
CoolRunner-II 27
cores search directories 309, 359

cores search directory 360
counter 67
 4-bit signed up counter with asynchronous reset 79
 4-bit signed up counter with asynchronous reset and modulo maximum 81
 4-bit unsigned down counter with synchronous set 70
 4-bit unsigned up counter with asynchronous clear 68
 4-bit unsigned up counter with asynchronous clear and clock enable 75
 4-bit unsigned up counter with asynchronous load from primary input 71
 4-bit unsigned up counter with synchronous load with a constant 73
 4-bit unsigned up/down counter with asynchronous clear 77

CPLD
 constraints 422
 fitter 299, 303
 fitter multi-level optimization 303
 log file 544
 log file analysis 301
 low-level optimization 303
 synthesis options 299

cross clock analysis 309, 429, 430, 441
cross_clock_analysis 429, 441
csd 146
custom compile file list 309, 316

D

data gate 424
data types 494
data_gate 424
deassign statement 504
decoder 117
 one-cold 119, 120
 one-hot 118, 119
 unselected outputs 121
decoder extraction 311, 360, 361
decoder_extract 360, 361, 436
default initial values on memory elements 460
default initial values on unconnected ports 461
default_nettype 521
default_search_order 531

define 521
defparam 520
delay 519
design constraints 305
design entities and configurations 484
device utilization summary 536
DFF with positive-edge clock 49
disable statement 520
disconnection 487
distributed RAM 225
divider 166
 division by constant 2 167
division 496
drive strength 519
DSP
 DSP Utilization Ratio 362
 DSP utilization ratio 421
 dsp_utilization_ratio 362, 436
 use DSP48 420
DSP48 157, 269, 380, 420
DSP48 block resources 269
dual-port RAM 225, 228, 233
duplication suffix 326
duplication_suffix 326, 439, 562
dynamic shift register 105
 16-bit dynamic shift register with positive-edge clock, serial in and serial out 105

E

elaborate command 554
else 521
elsif 521
enable_auto_floorplanning 436
encrypted modules 536
endcelldefine 521
endfile 452
endif 521
ent 440
entity declaration 462
entity header 484
enum 445
enum_encoding 342, 343, 436
enumerated encoding 342
enumerated types 455, 456
enumeration type 485
equivalent register removal 314, 315, 343, 345

equivalent_register_removal 343, 344, 436

escape sequences 522
event or 497

F

file 521
file declaration 486
file read 452
file type support 452
file types 549
File Write 452
file_close 452
file_open 452
final report 536
finite state machine 245, 345
flatten hierarchy 424, 427
flip-flop retiming 392
flip-flop with positive-edge clock 49
for statement 520
forever statement 519
fork/join statement 520
format 554
forward register balancing 394
FPGA
 constraints 356
 HDL options 356
 log file 538

from... to.. 442

from-to 434

FSM 245, 352

FSM encoding algorithm 311, 312, 340, 342, 345, 347

FSM flip-flop type 340

FSM style 311, 363, 364

fsm_encoding 342, 345, 346, 436

fsm_extract 340, 341, 347, 436

fsm_style 258, 363, 364, 437

full 324

full case 108, 324

full_case 324, 437, 445

full-parallel 324

function 478, 520

G

gate level primitive 523

general constraints 320
generate case 511
generate for 510
generate if else 510
generate RTL schematic 309, 325
generate statement 510
generic parameter declaration 465
generic/attribute conflicts 466
glob_opt 428, 432, 441
global constraints and options 306
global optimization goal 309, 428, 432, 441
global reset 459
global timing constraints 428

H

HDL
analysis 535
compilation 535
constraints 340
options 310
synthesis 535
HDL library mapping file 309, 337, 338, 553
HDL options tab 340
HDL synthesis report 535
hdl_compilation_order 440
hierarchical names 520
hierarchy separator 309, 327, 328
hierarchy_separator 327, 433, 440, 562
hread 453

I

I/O buffers 320
ibuf 320
IEEE package 482
if statement 519
ifdef 521
ifmt 440, 554
ifn 440, 554
if-then-else 108
implementation constraints 443
include 521
include files 509
incremental synthesis 366
incremental_synthesis 364, 366, 437

ifndef 521
indexed names 487
initial statement 520
initial values 459
initialization data 225
initialization file 229, 233
Initialize RAM 233
inpad_to_outpad 432, 433
input/output buffers 320
instance naming convention 561
integer constants 518
integer handling 517
integer type 456, 485
iob 387, 437
iobuf 320, 440
iostandard 328, 437
ispad 445
iuc 335, 440

K

kcm 146
keep 328, 437
keep hierarchy 309, 367, 370, 424
keep_hierarchy 367, 369, 424, 437

L

latch 58
4-bit latch with inverted gate and asynchronous preset 62
latch with positive gate 59
latch with positive gate and asynchronous clear 60
launching XST 550
left shift 497
left shift signed 497
library search option 328, 329
library search order 309, 328, 554
library search order file 531
line 521
loc 329, 437
local reset 459
log file analysis 535
logical and 496
logical equality 496
logical inequality 496
logical negation 496

logical or 496
logical shifter extraction 311, 370, 371
logical shifters 126
loop statement 489
low level optimization 35
low level synthesis 536
lso 328, 440, 531, 554
LSO file 531
lut_map 409, 410, 437

M

macro generation 263, 300
macro preserve 315, 424, 425, 427
macro preserve option 300
macromodule definition 520
map entity on a single LUT 409
map logic on BRAM 371
map_to_module 445
max fanout 314, 373, 375
max_delay 432, 433
max_fanout 373, 374, 375, 403, 437
mealy 246
meta comments 517
mixed language generics support 530
mixed language instantiation 528
mixed language port mapping 530
mixed language project file 528
mixed language support 527
mode 486
model 318, 319
module definition 520
modulus 495
moore machine 246
move first flip-flop stage 379
move first stage 314, 378
move last flip-flop stage 378
move last stage 314, 375
move_first_stage 376, 378, 379, 437
move_last_stage 375, 376, 377, 437
mult_style 145, 146, 379, 380, 437
multi-dimensional array 519
multiple wait statements 477
multiplexer 105, 108
4-to-1 1-bit MUX using if statement 111
4-to-1 MUX using case statement 113
4-to-1 MUX using tristate buffers 114

full 108
 full and parallel case 109
 neither full nor parallel 110
 no 4-to-1 MUX 116
 not full but parallel 109
 parallel 108
 multiplication 495
 multiplication with constant 146
 multiplier 145
 pipelined multiplier 148
 unsigned 8x4-bit multiplier 147
 multiplier style 311, 379, 381
 MUX 108
 MUX extraction 311, 312, 347, 349
 MUX Style 311
 mux style 381, 383
 mux_extract 108, 347, 437
 mux_style 381, 382, 437
 MUXCY 381
 MUXF5 381
 MUXF6 381
 MUXF7 381
 MUXF8 381

N

named events 519
 names with spaces 550
 native constraints 319
 net naming conventions 561
 net_name 445
 nets 518
 NGC 549
 ngc 299, 303
 no reduce 425
 non-blocking assignment 519
 non-blocking procedural assignments 507
 non-timing constraints 319
 noreduce 425, 437
 nounconnected_drive 521
 number of clock buffers 314, 384
 number of global clock buffers 383
 number of regional clock buffers 314, 385

O

obuf 320

offset 434, 442
 offset_in_before 432, 433
 offset_out_after 432, 433
 ofmt 440
 ofn 440
 one-cold 117
 one-hot 117
 operator 487
 opt_level 329, 330, 438
 opt_mode 331, 438
 optimization effort 303, 309, 329
 optimization goal 303, 309, 331, 332
 optimize instantiated primitives 314, 385, 386
 optimize_primitives 385, 386, 437
 other XST command line options 309, 316
 overloaded data Types
 bit vector types 456
 overloaded data types
 integer types 457

P

p 440
 pack I/O registers into iob 387
 package 485
 packages 482
 parallel 324
 parallel block 520
 parallel case 108
 parallel_case 332, 333, 438, 445
 parameter 519
 part select 511
 period 434, 442
 physical type 485
 pipe_block 379
 pipe_distributed 242, 390
 pipe_lut 148, 380
 pipelined distributed RAM 242
 pipelining 242
 pld_ce 422, 423, 440
 pld_ffopt 440
 pld_mp 424, 425, 440
 pld_xp 427, 428, 440
 power 496
 priority encoder
 3-bit 1-of-9 priority encoder 124
 priority encoder extraction 311, 387, 388

priority encoders 124
 priority_extract 124, 387, 388, 438
 procedure 478
 project file 554
 project navigator 29

Q

quiet mode 536

R

RAM extraction 311, 388
 RAM initial contents 226
 RAM macro inference 388
 RAM Style 392
 RAM style 311, 390
 RAM/ROM 171
 block RAM with reset 218
 dual-port block RAM with different clocks 210
 dual-port block RAM with two write ports 212
 dual-port RAM with asynchronous read 192
 dual-port RAM with enable on each port 207
 dual-port RAM with false synchronous read 195
 dual-Port RAM with one enable controlling both ports 204
 dual-port RAM with synchronous read (read through) 198
 initializing block RAM 225
 multiple-port RAM 216
 no-change mode 179
 ROM using block RAM resources 235
 ROM with registered address 235
 ROM with registered output 235
 single-port RAM with asynchronous read 181
 single-port RAM with enable 189
 single-port RAM with false synchronous read 183
 single-port RAM with synchronous read (read through) 187
 write-first mode 175
 ram_extract 388, 390, 438
 ram_style 390, 438

read cores 309, 410, 411
read_cores 410, 440
readline 452
real constants 518
record types 458
recovery state 352
recovery_state 259, 353
recursion 507
recursive component instantiation 464
Recursive Functions 525
Recursive Tasks 525
recursive tasks and functions 507
reduction and 496
reduction nand 496
reduction nor 496
reduction or 496
reduction xnor 497
reduction xor 496
register 518
 flip-flop with positive-edge clock 49
register balancing 314, 392, 395
register duplication 314, 395, 397
register power up 349
register_balancing 392, 394, 438
register_duplication 395, 396, 438
register_powerup 349, 438
registered multiplier 145
registers 47
 4-bit register with positive-edge clock, asynchronous set and clock enable 56
 DFF with positive-edge clock 49
 flip-flop with positive-edge clock and clock enable 54
 flip-flop with positive-edge clock and synchronous set 52
relational 496
repeat statement 519
resetall 521
resolution functions 478
Resource Sharing 352
resource sharing 168, 311, 312, 350
resource_sharing 350, 438
resource_sharing directives 445
resynthesize 364, 365, 438
return_port_name 445
right shift 497
right shift signed 497
rloc 333

ROM
 extraction 311, 397
 implementation 235
 style 311, 398
ROM extraction 398, 400
ROM style 400
rom_extract 397, 398, 438
rom_style 235, 398, 399, 438
rtlview 325, 440
run command 551

S

Safe Implementation 354
safe implementation 311, 312, 352, 353
safe_implementation 353, 438
safe_recovery_state 352, 438
script file 550
sd 359, 441
selected names 487
sequential block 520
sequential circuits 474
sequential process with a sensitivity list 474
sequential process without a sensitivity list 474
set command 553
set command options 553
set_dont_touch 445
set_dont_touch_network 445
set_dont_use_cel_name 445
set_prefer 445
shift register 87
 8-bit shift-left register with negative-edge clock, clock enable, serial In and serial out 91
 8-bit shift-left register with positive-edge clock, asynchronous clear, serial in and serial out 93
 8-bit shift-left register with positive-edge clock, asynchronous parallel load, serial in and serial out 99
 8-bit shift-left register with positive-edge clock, serial in and parallel out 97
 8-bit shift-left register with positive-edge clock, serial In and serial out 89
 8-bit shift-left register with positive-edge clock, synchronous parallel load, serial in and serial out 101

8-bit shift-left register with positive-edge clock, synchronous set, serial in and serial out 95
8-bit shift-left/shift-right register with positive-edge clock, serial in and parallel out 103
shift register extraction 311, 400, 402
shift_extract 370, 438
shlib 339
shreg_extract 400, 401, 438
signal declaration 486
signal encoding 354
signal_encoding 354, 355, 356, 438
signed values 47
signed/unsigned support 46
silent mode 537
simple names 487
single-port RAM 227
slice names 487
slice packing 402, 403
slice utilization ratio 309, 405, 407
slice utilization ratio delta 407
slice_packing 402, 403, 441
slice_utilization_ratio 405, 406, 407, 438
slice_utilization_ratio_maxmargin 407, 408, 439
source_node 425
Spartan 27
Spartan-3 27
Spartan-II 27
specify block 520
Specifying INITs 290
specifying RLOCs 290
SRL16E 87
SRLC16 88
standard package 482
state machine 245
 auto 256
 compact 256
 gray 256
 johnson 256
 next state equation 255
 one-hot 256
 RAM-based FSM synthesis 258
 safe FSM implementation 259
 sequential 256
 speed1 256
 state encoding technique 255
 state register 255

unreachable state 255
user 256
state_vector 445
string constants 518
structural Verilog description 512
subprogram 484
subtraction 495
subtracter 132
 unsigned 8-bit subtractor 140
switch level primitives 523
syn_allow_retimig 445
syn_black_box 446
syn_direct_enable 446
syn_edif_bit_format 446
syn_edif_scalar_format 446
syn_encoding 446
syn_enum_encoding 446
syn_hier 446
syn_isclock 446
syn_keep 446
syn_maxfan 446
syn_netlist_hierarchy 446
syn_noarrayports 446
syn_noclockbuf 446
syn_noprune 446
syn_pipeline 446
syn_probe 446
syn_ramstyle 446
syn_reference_clock 447
syn_romstyle 447
syn_sharing 447
syn_state_machine 447
syn_tco 447
syn_tpd 447
syn_tristate 447
syn_tristatetomux 447
syn_tsu 447
syn_useenables 447
syn_useioff 447
Synopsys 445, 447
synopsis package 483
Synplicity 445, 447
synthesis constraint file 309, 334
synthesis options 306
synthesis options summary 535
synthesis translate_off 447
synthesis translate_on 447
system function 520

system task 520
system tasks 521, 522

T

task 520
temp directory 549
temporary files 549
third party constraints 445
tig 435, 442
time control statements 507
timegrp 435, 442
timescale 521
timespec 442
timing constraints 428
timing control on procedural assignment 520
timing report 536, 538
tnm 442
tmpdir 549, 553
tnm 434
tnm net 435
tnm_net 442
top 441
translate_off 335, 439
translate_on 335, 439
tristate 64
 combinatorial process and always block 64
 concurrent assignment 66
tristate replaced by logic 314, 413
tristate2logic 413, 414, 441
tsidentifier 442

U

uc 318, 334, 441
unconnected_drive 521
undef 521
uperand 488
use carry chain 412
use clock enable 314, 417
use DSP48 311, 420, 422
use synchronous reset 314, 419, 420
use synchronous set 314, 417, 418
use synthesis constraint file 318
use synthesis constraints file 309, 334, 335, 336
use_carry_chain 412, 413, 439

use_clock_enable 415, 416, 439
use_dsp48 421, 422, 439
use_sync_reset 419, 420, 439
use_sync_set 417, 439
uselib 521
use_lowskewlines 403, 439
user defined primitives 523
user-defined compile list 316

V

variable declaration 486, 492
arrays 493
initial values 492
multi-dimensional arrays 494
variable part selects 511
vector 519
Verilog
 assign statements in 504
 assignments in 499
 case statement in 500
 case statements 324
 combinatorial aways blocks in 499
 comments in 509
 constants in 508
 continuous assignments in 499
 deassign statements in 504
 expressions in 495
 for loops in 501
 if else statement in 500
 language support 491, 518
 legal statements in 495
 limitations 515
 macros in 508
 meta comment syntax 317
 meta comments 306
 module declaration in 498
 modules in 498
 parameters in 514
 primitives in 522
 procedural assignments in 499
 repeat loops in 501
 reserved keywords in 523
 sequential always blocks in 502
 while loops in 502
Verilog 2001 309, 337
Verilog include directories 309, 336, 337, 554

Verilog-2001 507, 554
verilog2001 441, 554
Verilog-2001 attribute 317
Verilog-2001 Support 524
VHDL
 attribute 316
 attribute syntax 316
 attributes 306
 case statement in 472
 combinatorial circuits 467
 conditional signal assignment in 468
 data types in 455
 for loop statement in 473
 generate statement in 468
 if else statement in 471
 language 451
 language support 451, 484
 multi-dimensional array types in 457
 objects 461
 objects in 461
 operators 461
 operators in 461
 overloaded data types in 456
 record types in 458
 reserved word 490
 selected signal assignment in 468
 simple signal assignment in 467
 working directory 339
VHDL ini file 338, 339
VHDL work directory 340
VHDL/Verilog boundary rules 528
Virtex 27
vlgcase 324, 333, 441
vlgincdir 336, 441, 554

W

wait statement 488
What's New 27
When 34
while statement 519
work directory 309, 339, 553
work library 554
work_lib 441, 554
write timing constraints 309, 430, 431, 434, 441
write_timing_constraints 430, 431, 441, 443

wysiwyg 315, 425, 426, 441

X

xc_alias 447
xc_clockbuftype 447
xc_fast 447, 448
xc_fast_auto 447
xc_global_buffers 447
xc_ioff 447
xc_isgsr 447
xc_loc 447
xc_map 409, 447
xc_ncf_auto_relax 447
xc_nodelay 448
xc_padtype 448
xc_props 448
xc_pullup 448
xc_rloc 448
xc_slow 448
XC9500 27
XC9500XL 27
XC9500XV 27
XCF 318, 434
XCF file 443
XCF syntax 318, 443
XCF timing constraint 433
Xilinx specific options 313
XOR 427
XOR collapsing 311, 403, 405
XOR macros 427
XOR Preserve 428
XOR preserve 315, 427
xorCollapse 403, 404, 439
XST constraint file 318
XST constraints file 434
XST flow 27
XST in project navigator 29
XST log file 36
XST script 551
XST shell 550
xsthdpdir 339, 340, 441, 553
xsthdpini 337, 338, 441, 553
XST-specific non-timing options 436

