# **SKILL Development of Parameterized Cells**

**Version 5.1.41** 

**Lecture Manual** 

October 15, 2004



 $\hbox{@ }1990\mbox{-}2004$  Cadence Design Systems, Inc. All rights reserved.

Printed in the United States of America.

Cadence Design Systems, Inc., 555 River Oaks Parkway, San Jose, CA 95134, USA

#### **Cadence Trademarks**

1st Silicon Success® First Encounter®
Allegro® FormalCheck®
Assura<sup>TM</sup> HDL-ICE®
BlackTie® Incisive<sup>TM</sup>
BuildGates® IP Gallery<sup>TM</sup>
Cadence® (brand and logo) Nano Encounter<sup>TM</sup>

CeltIC<sup>™</sup> NanoRoute<sup>™</sup>
ClockStorm® NC-Verilog®

ClockStorm® NC-Verilog® SourceLink® online customer support
CoBALT<sup>TM</sup> OpenBook® online documentation library SPECCTRA®
Concept® Orcad® SPECCTRAQuest®

OPlace<sup>®</sup>

 $SeismIC^{TM}$ 

Spectre®

UltraSim®

Verilog®

Virtuoso®

Verifault-XL®

VoltageStorm®

TtME®

SignalStorm®

Silicon Design Chain<sup>TM</sup>

Silicon Ensemble®

SoC Encounter<sup>TM</sup>

Quest®

Concept<sup>®</sup> Orcad® Conformal® Orcad Capture® Connections® Orcad Layout® PacifIC<sup>TM</sup> Design Foundry® Diva® Palladium<sup>TM</sup> Dracula® Pearl® Encounter<sup>TM</sup> PowerSuite<sup>TM</sup> Fire & Ice® PSpice®

#### Other Trademarks

All other trademarks are the exclusive property of their respective owners.

#### **Confidentiality Notice**

No part of this publication may be reproduced in whole or in part by any means (including photocopying or storage in an information storage/retrieval system) or transmitted in any form or by any means without prior written permission from Cadence Design Systems, Inc. (Cadence).

Information in this document is subject to change without notice and does not represent a commitment on the part of Cadence. The information contained herein is the proprietary and confidential information of Cadence or its licensors, and is supplied subject to, and may be used only by Cadence's customer in accordance with, a written agreement between Cadence and its customer. Except as may be explicitly set forth in such agreement, Cadence does not make, and expressly disclaims, any representations or warranties as to the completeness, accuracy or usefulness of the information contained in this document. Cadence does not warrant that use of such information will not infringe any third party rights, nor does Cadence assume any liability for damages or costs of any kind that may result from use of such information.

RESTRICTED RIGHTS LEGEND Use, duplication, or disclosure by the Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

UNPUBLISHED This document contains unpublished confidential information and is not to be disclosed or used except as authorized by written contract with Cadence. Rights reserved under the copyright laws of the United States.

# Table of Contents SKILL Development of Parameterized Cells

Module 1	Introduction to Parameterized Cells	
	Course Objectives	1-3
	Audience	1-5
	Agenda	1-7
	Curriculum Planning	1-11
	Product Documentation	1-13
	Customer Support	1-15
	What Is a Parameterized Cell?	1-17
	Creating a Pcell	1-19
	Advantages of SKILL Pcells	1-21
	Pcell Example	1-23
	Pcell Layout Examples	1-25
	SKILL Pcells and Relative Object Design	1-27
Module 2	Introduction to Relative Object Design	
	Module Objectives	2-3
	What Is Relative Object Design?	2-5
	Why Relative Object Design?	2-7
	ROD Concepts	2-9
	Named Objects	2-11
	Named Object Example	2-13
	Accessing an Object Without ROD	2-15
	Object Handles	2-17
	System-Defined Handles	
	User-Defined Handles	2-21
	Object Alignment	2-23
	Connectivity	2-25
	Creating Nets and Pins Without ROD	
	Multipart Paths	
	Multipart Path Example: Bus	
	Multipart Path Example: Guard-Ring	
	ROD Object ID	
	ROD Object Structure	
	ROD Object Structure Example	
	Example: Accessing Handles	

	Creating ROD Objects	2-43
	Creating Multipart Paths	2-45
	Lab Overview	2-47
Module 3	Exploring Relative Object Design	
	Module Objectives	3-3
	Handles for Width and Length	3-5
	Multipart Path Bounding Boxes	3-7
	Path and Polygon Segments	3-9
	Rectangle Segments	3-11
	Segment Point Handles	3-13
	Polygon Segment Point Handles	3-15
	Segment Point Handles for Paths	3-17
	Point Handles for Multisegment Paths	3-19
	Point Handles for Extended-Type Paths	3-21
	Segment Length Handles	3-23
	Segment Length Handles for Multisegment Paths	3-25
	Relative Object Design Functions	
	rodCreateRect	3-29
	rodCreateRect ?subRectArray Option	3-31
	rodCreatePolygon	
	rodCreatePath	3-35
	rodCreatePath: Master Path Arguments	3-37
	rodCreatePath with Offset Subpath	
	rodCreatePath with Enclosed Subpath	
	rodCreatePath with Subrectangles	
	ROD Connectivity Arguments	
	Creating Objects from Other Objects	
	rodAlign	
	Lab Overview	
Module 4	Creating and Using SKILL Parameterized Cells	
	Module Objectives	4-3
	How Pcells Function	4-5
	Defining Parameter Values	4-7
	Creating a SKILL Pcell	4-9
	pcDefinePCell Syntax	4-11
	Using the pcCellView Variable	
	SKILL Pcell Example	

	Using the SKILL Operator ~> with Pcells	4-17
	Creating Instances Within Pcells	4-19
	Accessing Technology File Data	4-21
	Safety Rules for Creating SKILL Pcells	4-23
	Supported SKILL Functions for Pcells	4-25
	What to Avoid When Creating Pcells	4-27
	Debugging Pcells	4-31
	Pcell Debugging Techniques	4-33
	Incremental Composition	4-35
	Interactive Trials	4-37
	Visibility by Global Variables	4-39
	Visibility by Labels	4-41
	Lab Overview	4-43
Module 5	Going Further with SKILL Pcells	
	Module Objectives	
	Using Component Description Format	
	CDF Example	
	Parameter Precedence	
	Adding CDF Parameters	
	Stretchable Pcells	
	Example: rodAssignHandleToParameter	
	Interactive Feedback	
	Controlling Parameter Values	
	Lab Overview	
	Sample Pcells	5-23
	Concepts in Sample Pcells	5-25
	Pcell Code Encapsulation	
	Advantages of Code Encapsulation	
	Disadvantages of Code Encapsulation	
	Automatic Abutment in Virtuoso XL	
	Abutment Requirements	
	Abutment Automatic Spacing in Virtuoso XL	5-37
	Setting Up Cells for Abutment	5-39
	Abutment Function	5-41
	Abutment Function Return Values	5-43
	Auto-Abutment Action Sequence	
	Auto-Abutment Process	5-47
	Abutment Facts	5-49
	Abutment Fiction	5-51

	Multiple Abutment Pins	5-53
	Lab Overview	5-55
Module 6	Creating and Using Qcells (Optional)	
	Module Objectives	6-3
	Qcell Overview	6-5
	Qcell and Pcell Comparison	6-7
	Qcell Functionality	6-9
	Defining and Installing Qcells—Overview	6-11
	Qcell cdsMos—Layers	6-13
	Qcell cdsVia—Layers	6-21
	Qcell Guard-Ring—Overview	6-27
	Qcell Guard-Ring—Rules	6-31
	Qcell Guard-Ring—Parameter Defaults	6-33
	Qcell—Rules Browser	6-35
	Qcell—View Device Configuration	6-37
	Qcells—Create Device	6-39
	Qcells—Create Guard-Ring	
	Editing Placed Qcells	6-43
	Lab Overview	6-47
Appendix .	A Technology File and Translator Information  Module Objectives	A-3
	DFII Technology Files—Controls	
	DFII Technology Files—layerRules	
	DFII Technology Files—physicalRules	A-11
	DFII Technology Files—electricalRules	A-15
	DFII Technology File—Devices	A-17
	DFII Technology File—lxRules	A-23
	DFII Technology File—lxRules—MPPs	A-27
	VCAR Rules	A-33
	VCAR Rules—Layers	A-35
	VCAR Rules—Layers Example	A-37
	VCAR Rules—Vias	A-39
	VCAR Rules—Via Example	A-41
	VCAR Rules—Equivalent Layers	A-43
	VCAR Rules—Boundary Layers	A-45
	VCAR Rules—Scopes	A-47
	VCAR Rules—Scopes Example	A-49

VCAR Rules—Keepouts	A-51
VCAR Rules—Keepouts Example	A-55
VCAR Rules—Conductors	A-57
VCAR Rules—Conductors Example	A-59



## **Introduction to Parameterized Cells**

### **Module 1**

## **Course Objectives**

- Understand how relative object design (ROD) SKILL functions can help you create layout objects and parameterized cells (pcells)
- Examine the architecture of ROD objects
- Explore the versatility of ROD objects
- Create and manipulate ROD objects interactively
- Learn the concepts involved in developing pcells with SKILL
- Define and use pcells
- Make your pcells process-independent by applying technology file rules
- Create a parameterized inverter layout
- Create pcells with stretch handles
- Create pcells with auto-abutment for the Virtuoso® XL Layout Editor

## **Terms and Definitions**

Pcell	A design data generator that accepts specifications (parameters) to determine the final structure of the cell it creates.
Qcell	A parameterized cell (currently MOS device, substrate/well tie, cdsVia or MPP guard-ring) designed to be created and used by layout designers who are not programmers.
Relative object design	A physical design facility available within Cadence® Design Framework II.
ROD	An acronym for relative object design.
ROD objects	Physical design structures such as rectangles and polygons created with relative object design facilities.
SKILL	A programming language integral to Design Framework II providing user-extensibility in the design environment.

## **Audience**

This course is primarily for layout designers, especially those interested in programmatic cell development.

### **Prerequisites:**

- Hands-on experience with Design Framework II and Virtuoso Layout Editor
- Familiarity with SKILL
- Experience using a UNIX workstation
- Working knowledge of at least one text editor

You should be comfortable with this course if you have used the Virtuoso Layout Editor to create or edit layout designs.

You must also have significant exposure to SKILL. It is not required that you have taken the Cadence SKILL Programming class, but you should know most of the basics such as:

- SKILL syntax
- SKILL language fundamentals such as symbols, lists, expressions, and procedures
- Rudimentary SKILL functions such as *car*, *cdr*, *foreach*, and *if*
- Familiarity with cellview structure and database access

In general, if you have the experience listed above, you already possess the necessary skills with UNIX and its facilities.

## **Agenda**

### Day 1

9:00 a.m. Welcome Introduction to Parameterized Cells 9:15 a.m. Introduction to Relative Object Design 9:45 a.m. 10:45 a.m. Break Lab: Introduction to Relative Object Design 11:00 a.m. 12:00 p.m. Lunch 1:00 p.m. **Exploring Relative Object Design** 2:30 p.m. Lab: Exploring Relative Object Design 4:30 p.m. Creating and Using SKILL Parameterized Cells (part 1) Adjourn 5:00 p.m.


## Agenda (continued)

### Day 2

- 9:00 a.m. Creating and Using SKILL Parameterized Cells (part 2)
- 10:00 a.m. Lab: Creating and Using SKILL Parameterized Cells
- 12:00 p.m. Lunch
  - 1:00 p.m. Going Further with SKILL Pcells
  - 2:30 p.m. Lab: Going Further with SKILL Pcells
  - 5:00 p.m. Adjourn

## **Curriculum Planning**

Cadence offers courses that are closely related to this one. You can use this course map to plan your future curriculum.



For more information about Cadence courses:

- 1. Point your web browser to <u>cadence.com</u>.
- 2. Click Education.
- 3. Click the **Course catalog** link near the top of the center column.
- 4. Click a Cadence technology platform (such as **Custom IC Design**).
- 5. Click a course name.

The browser displays a course description and gives you an opportunity to enroll.

### **Product Documentation**


CDSDoc is the Cadence online product documentation system.

Documentation for each product installs automatically when you install the product. Documents are available in both HTML and PDF format.

The Library window lets you access documents by product family, product name, or type of document.

You can access CDSDoc from:

- The graphical user interface, by using the Help menu in windows and the Help button on forms
- The command line
- SourceLink® online customer support (if you have a license agreement)



To access CDSDoc from a Cadence software application, click **Help**. The document page is loaded into your browser. After the document page opens, click the **Library** button to open the CDSDoc Library window.

To access CDSDoc from the UNIX command line, enter *cdsdoc* & in a terminal window. When the Library window appears, navigate to the manual you want, then click **Open**. The manual appears in your browser.

To access CDSDoc from the Windows environment, navigate to the <*release*>\*tools*\*bin* directory and double-click **cdsdoc.exe**, or select **Start—Programs—Cadence** <**release>—Online Documentation**. When the Library window appears, navigate to the manual you want, then click **Open**. The manual appears in your browser.

## **Customer Support**

# SourceLink Online Customer Support

sourcelink.cadence.com

- Search the solutions database and the entire site.
- Access all documentation.
- Find answers 24x7.

If you don't find a solution on the SourceLink site...

If you have a Cadence software support service agreement, you can get help from SourceLink online customer support.

The web site gives you access to application notes, frequently asked questions (FAQ), installation information, known problems and solutions (KPNS), product manuals, product notes, software rollup information, and solutions information.



Submit a service request online.

### **Online Form**

From the SourceLink web site, fill out the Service Request Creation form.



Customer Support

Service Request If your problem requires more than customer support, then a product change request (PCR) is initiated.



### To view information in SourceLink:

- 1. Point your web browser to sourcelink.cadence.com.
- 2. Log in.
- 3. Enter search criteria.

You can search by product, release, document type, or keyword. You can also browse by product, release, or document type.

### What Is a Parameterized Cell?

A parameterized cell, or pcell, is a programmable design entity that lets you create a customized instance each time you place it.

Pcells provide the following advantages:

- Speed up entering layout data by eliminating the need to create duplicate versions of the same functional part
- Save disk space by creating a library of cells for similar parts that are all linked to the same source
- Eliminate errors that can result in maintaining multiple versions of the same cell
- Eliminate the need to explode levels of hierarchy when you want to change a small detail of a design


The peell you create is called a *master*. A master is the SKILL code you write to define the structure of the cell and the parameters you assign to it. After you compile the master, it is stored in the database in the form of a SKILL procedure.

The edits you make to the master appear in the cell instances when you compile the master. You must make all changes to the master. You cannot edit an instance of a pcell.

## **Creating a Pcell**

There are two methods for creating pcells in the Design Framework II environment:

- Graphically, using the pcell editing commands in the Virtuoso layout editor
- Textually, using Cadence SKILL commands



### **Graphical Pcells**

To create a pcell graphically, you create and edit the cell using the Virtuoso layout editor. You then add parameters to the cell, compile it to a master pcell, and test the master. Then you are ready to place an instance of the pcell.

### **Textual Pcells (SKILL Pcells)**

If you need to create complex pcells, you will want to create them textually. Most pcells are easier to create and maintain with SKILL than with the graphical interface.

### **Editing Pcells**

Remember that you cannot edit an *instance* of a pcell (other than changing the parameter values on the instance). If you wish to change the structure or behavior of a pcell, you must edit the pcell *master*.

## **Advantages of SKILL Pcells**

There are several advantages to creating pcells with SKILL:

- Easier creation of complex designs
- Easier maintenance of pcell code
- Process portability and independence

### Easier creation of complex designs

Some structures are nearly impossible to create graphically. You can create them and define parameters for them using SKILL code. In high-frequency design, many complex structures are used. A good example is a spiral inductor with parameterized line width, spacing, number of turns, and overall width. This structure is difficult to define with a graphical pcell, but fairly easy to define with code, particularly with SKILL.

### Easier maintenance of pcell code

Software engineers use *makefiles* to build large programs from source code and binaries. Component libraries are software, too. However, component layouts are not normally produced with source code. Therefore, there is no automatic revision control for component layouts. Using SKILL to create peells lets you define component layouts within code. Then you can include your peell code in a UNIX makefile and benefit from the revision control normally used to build and maintain a library of source code files.

### **Process portability and independence**


You can use the same components in multiple libraries but with different design rules. For example, suppose the same device type is used in five different fabrication processes. Each process is implemented in a different library, and each library has its own technology file specifying unique spacing rules. The same SKILL pcell code supports all five processes by accessing the spacing rules from each technology file. Then device layouts can differ for each process even though you use the same pcell source code to create them.

## **Pcell Example**

Suppose you wish to create a programmable transistor layout in which you are able to specify these parameters:


- Gate width
- Gate length
- Number of gates

The master cell for your design might look like this:



Original transistor (master)

# **Pcell Layout Examples**



With these parameters, your pcell could be used to create layouts such as these.

# SKILL Pcells and Relative Object Design

Parameterized cells can be powerful tools in your design methodology. Combined with relative object design (ROD), you can rapidly define technology-independent cells that are customizable to almost any application.

ROD alleviates much of the tedious work involved in creating and aligning layout shapes. Understanding ROD is a crucial element of a good pcell development strategy.

In the next module, you will be introduced to the features and functions provided by relative object design.

SKILL peells are not new to Design Framework II. In the past, however, SKILL peell developers were required to use a collection of low-level database routines to create polygons and rectangles in their peells. In addition, SKILL peells often involved many tedious calculations of offsets to properly align these geometries.

Relative object design has eliminated much of this tedium.



# Introduction to Relative Object Design

#### **Module 2**

# **Module Objectives**

- Define relative object design (ROD)
- Explain why ROD was created
- Introduce ROD concepts

#### **Terms and Definitions**

ROD	Acronym for relative object design.
SKILL	An extension language for Design Framework II.

### What Is Relative Object Design?

Relative object design is a set of high-level SKILL functions for defining simple or complex layout objects and persistent spatial relationships between them.

#### With ROD, you can:

- Create simple shapes such as rectangles
- Create complex shapes such as guard-rings, buses, and transistors
- Associate a signal with a shape
- Align ROD objects with each other or with fixed coordinates
- Assign a name to a shape
- Access points and other information stored on ROD objects through all levels of hierarchy
- Create parameterized cells (pcells) using ROD constructs

Relative object design (ROD) is new functionality for Cadence® Design Framework II.

ROD allows you to create objects and define their relationships at a high level of abstraction, so you can concentrate on your design objectives. ROD automatically handles the intricacies of traversing the design hierarchy and simplifies the calculations required to create and align geometries.

Generally, with a single ROD function call, you can accomplish a task that otherwise would require several lower-level SKILL function calls. For example, without ROD, creating the connectivity for a pin requires a series of low-level SKILL function calls. Using the ROD function for creating rectangles, you create a rectangle and simply designate it as a pin.

## Why Relative Object Design?

SKILL and the Design Framework II database functions offer a means for creating layout objects in a procedural fashion. However, this approach demands extensive knowledge of SKILL and tedious computation of coordinates and offsets.

ROD simplifies creation of layout entities in SKILL by providing these facilities:

- An object can be accessed in a hierarchy by its name
- Points on an object can be referenced by name
- A persistent alignment between objects can be established by calling one simple procedure
- Complex structures involving objects on several layers can be created by calling a single ROD procedure
- Technology information can be used so that ROD structures are process-independent

Historically, using programs to create large macro cells and full-chip assemblies required a massive effort by SKILL developers. ROD provides high-level design capture support so that even designers with limited programming experience can create complex cells easily, and those with advanced programming abilities can generate sophisticated cells and blocks with less effort than previously required.

Once you capture a design in the form of parameterized code, you can generate a variety of cell modules using different parameter values and/or different technology rules. Also, creating a single design description that captures your intention reduces errors that come from manipulating low-level layout objects independently of each other.

As with other types of pcells, a major advantage to ROD pcells is that you can utilize rules from your technology file, making your cells tolerant of changes in your technology.

### **ROD Concepts**

Relative object design involves the following concepts:

- Named objects
- Object handles
- Object alignment
- Connectivity assignment
- Multipart paths
- ROD object structure

ROD is a new technology for Design Framework II.


To understand the benefits ROD brings to your design process, it is crucial to understand the concepts it introduces. These concepts will be explained in the next few slides.

### **Named Objects**


ROD allows you to assign a name to any shape. Any instance already has a name, and ROD allows you to reference an instance by its name. A ROD object you create is assigned a default name (such as *rect0*) if you do not specify one.

You can access information about a shape or an instance in a hierarchy by using its *hierarchical name* from the top-level cellview. A *hierarchical name* consists of the names of the instances (through which you need to descend to reach the desired object), separated by slashes. Each slash indicates a level of hierarchy.

A metal path named carryln




An instance named 15



When you name an existing database shape using the ROD naming function, the function creates ROD information associated with the shape. This information is stored in a *ROD object*, and is identified by a unique ROD object ID. The information contained in a ROD object includes its name and database ID. When you create a new shape with a ROD creation function, the function creates a named database shape and a ROD object.

Most ROD functions accept a ROD object ID as input.

## **Named Object Example**



This example shows a cellview with an instance of *inverter* named *INV1*. An instance of *nTrans* named *ntr1* resides in the definition of the *inverter*. A ROD rectangle named *polyRect* resides in the definition of the *nTrans* cell.

The hierarchical name to the ROD rectangle depicted here would be:

```
INV1/ntr1/polyRect
```

Below is an example of a hierarchical name:

```
polyObj = rodGetObj("INV1/ntr1/polyRect" geGetEditCellView())
```

Note the simplicity of accessing the desired shape in this example.

Prior to the introduction of ROD, this type of operation was not as simple. In order to access a given shape through a design hierarchy, you were required to manually descend through the design hierarchy using low-level SKILL database access calls. Then, you had to determine, in some manner, the exact shape you desired in the cellview.

Clearly, the advantage of named objects can be seen in contrast to the previous approach.

#### **Accessing an Object Without ROD**

Below is an example of accessing the poly rectangle *without* ROD:

The steps you see here are:

- Obtain the desired instance (*INV1*) in the top-level cellview.
- $\blacksquare$  Locate the desired instance (ptr1) within the master view of INV1.
- $\blacksquare$  Examine the shapes in the master view of *ptr1* to determine the desired rectangle.

This example illustrates the effort involved to access a shape through a limited amount of hierarchy. The process becomes more involved when more hierarchy is encountered.

### **Object Handles**

A handle is an item of information about a ROD object, such as a point on the object's bounding box.

There are two kinds of ROD handles:

- System-defined
- User-defined

Handles are attributes of ROD objects. You can access handles through all levels of hierarchy.


Most handles are system-defined, but you can employ user-defined handles in your design flow to store additional information you can require on the ROD objects you create.

## **System-Defined Handles**

System-defined handles (or system handles) are:

- Automatically defined when a ROD object is created
- Calculated on-demand as they are accessed (not stored in memory)

This example shows the names of the handles for the bounding box points of an arbitrary polygon:



For every ROD object, the system automatically defines the following types of handles:

- Bounding box point handles
- Bounding box width and length handles
- Segment point handles
- Segment length handles

There are nine system-defined point handles associated with the bounding box around every ROD object:

- One at each corner
- One in the center of each edge
- One in the center of the bounding box

You can abbreviate bounding box point handle names as follows:


Abbrev.	Handle Name	Abbrev.
uL	lowerLeft	1L
uC	lowerCenter	1C
uR	lowerRight	1R
cL	centerCenter	cC
cR		
	uL uC uR cL	uL lowerLeft  uC lowerCenter  uR lowerRight  cL centerCenter

#### **User-Defined Handles**

User-defined handles (or user handles) are:

- Created by you to store calculations, special coordinates, or other data relevant to your design flow
- Stored in memory and saved to the Design Framework II database

For example, you might have a ROD path that implements a route in your design. Depending on your design flow, you could associate a handle with the path designating a value for the path's maximum allowable length:



Once created, a user-defined handle can be accessed just like a system handle.


Information stored in user-defined handles can have any of the following data types:

point	integer
Boolean	floating-point number
string	SKILL expression

To change the value or type of a user-defined handle, you must delete the existing handle using *rodDeleteHandle* and replace it with another call to *rodCreateHandle*.

### **Object Alignment**

You can align ROD objects with respect to one another. Once established, the alignment is enforced when either object is moved. The example below shows an alignment made between the center-points of two rectangles:



#### The code to create such an alignment might look like this:

The alignment between two objects is preserved when you manipulate either object, and when you save and close the layout cellview. For example, when you move a reference object, the aligned object moves with it.

An alignment can involve any named geometry at any level of hierarchy and any design rule that is defined in your technology file.

The system automatically recalculates the alignment of named objects when:

- The layout cellview is opened in edit mode
- Either object involved in an alignment is edited in any way (for example, moved, rotated, or stretched), at any level of the hierarchy

You can use a SKILL expression with technology file variables to calculate the separation across one or more levels of hierarchy. The system automatically reevaluates SKILL expressions used in alignment whenever it needs to recalculate the alignment.

### Connectivity

For a ROD shape, such as a rectangle or path, you can specify connectivity by associating the shape with a specific terminal and net. You can also make the shape into a pin.

This is accomplished as the object is created by using the *ROD connectivity* arguments available with the object creation function, such as *rodCreateRect*.

For example, you can define a simple rectangle as a pin using code similar to this:

Prior to the introduction of ROD, to add connectivity to a given shape you were forced to use several calls to low-level SKILL database functions. You can now establish connectivity for a shape as it is created by using ROD connectivity options. The options include facilities for creating labels to annotate shapes with connectivity.

#### **Creating Nets and Pins Without ROD**

Prior to the introduction of ROD, these steps were necessary to create a rectangular pin and assign it to a net.

```
; Get the current cellview.
cv = geGetEditCellView()

; Create the pin shape.
myPin = dbCreateRect(cv list("metall" "pin") list(4:7 5:8))

; Create the pin's net.
net = dbCreateNet(cv "data")

; Assign the pin to the net.
dbCreatePin(net myPin)
```

Clearly, the elegance of creating the object and its connectivity in one ROD call can be seen in comparison.

When creating a repeated object with connectivity, the connectivity applies to all objects in the set. To mimic this functionality without ROD, you must create a loop that calls these low-level database functions for each shape.

### **Multipart Paths**

A multipart path is a ROD object composed of multiple shapes. You can create a multipart path with a single call to *rodCreatePath*, which you can use to define complex structures such as:

- Buses
- Guard-rings
- Contact arrays
- Transistors

A multipart path consists of a single master path and one or more subparts, which can be any of the following:

- Offset subpaths
- Enclosure subpaths
- Sets of subrectangles


With *rodCreatePath*, you can create any number of subparts. All subparts exist in relation to and depend on the master path.

You can create connectivity for any or all parts in a multipart path by associating them with a specific terminal and net. You can also make one or more parts into pins. When you specify that a master path or a subpath is a pin, the entire path becomes a pin. When you specify that a set of subrectangles is a pin, each rectangle in that set of subrectangles becomes a pin.

You can specify a master path as choppable or not choppable. When a master path is choppable, all its subpaths and subrectangles must be choppable. When a master path is not choppable, then you can specify its subpaths and subrectangles as choppable or not choppable.

When you modify a multipart path with the layout editor, changes to the master path affect all parts of the multipart path. For example, stretching a segment of a multipart path stretches all subpaths and sets of subrectangles in the segment.

### **Multipart Path Example: Bus**




You can create a bus using the *offsetSubPath* option to *rodCreatePath*. As you vary the geometry of the master path, the subpaths automatically adjust accordingly.

The lower metal route is the master path, and the other routes are each an offset subpath of the master path.

Below is a code fragment for a bus structure such as the one depicted in this example:

```
routeWidth = routeSpacing = 1.0
rodCreatePath(
                   "metal1"
   ?layer
   ?pts
                   list(20:-20 40:-20 40:-30 80:-30)
   ?width
                   routeWidth
   ?justification "center"
                   geGetEditCellView()
   ?cvId
   ?offsetSubPath
   list(
      list(
         ?layer
                        "metal1"
         ?justification "left"
                        routeSpacing
         ?sep
      ) ;end subpath1
      list(
         ?layer
                        "metal1"
         ?justification "left"
                        (routeSpacing * 2.0) + routeWidth
         ?sep
      ) ; end subpath2
   ) ; offsetSubPath
) ; rodCreatePath
```

# Multipart Path Example: Guard-Ring



You can create guard-rings with a single call to *rodCreatePath*. Any or all layers on the structure can be made choppable.

The master path here is the metal route, the contacts are implemented with the optional *subRect* keyword argument, and the diffusion region is implemented with the *encSubPath* keyword argument.

Below is a code fragment for a structure such as the one depicted in this example:

```
rodCreatePath(
                geGetEditCellView()
   ?cvId
   ?endType
               "variable"
                list("metal1" "drawing")
   ?layer
   ?width
                contWidth + 2.0 * metalContEnclose
                list(0.0:0.0 9.0:0.0 9.0:2.0 15.0:2.0)
   ?pts
   ?beginExt
               contWidth/2.0 + metalContEnclose
   ?endExt
                contWidth/2.0 + metalContEnclose
   ?subRect
   list(
      list(
         ?layer
                      "cont"
         ?beginOffset -metalContEnclose
         ?endOffset
                      -metalContEnclose
   ?encSubPath
   list(
      list(
                    list("ndiff" "drawing")
         ?layer
         ?enclosure metalContEnclose - diffContEnclose
```


### **ROD Object ID**

Every named database object (instances, layout cellviews, ROD shapes) has ROD information associated with it. This information is stored in a *ROD object*.

Each ROD object has a unique ROD object ID that is similar to a database ID.

ROD objects and database objects have different printed representations:

```
rodRect = rodGetObj("myRect" geGetEditCellView())
=> rodObj:18636824
rodRect~>dbId
=> db:17103916
```



A ROD object is also a database object, but exists in relation to its associated named database object. For example, a rectangle created with *rodCreateRect* will consist of a ROD object (an item in the database) and a rectangle object (also an item in the database). The ROD object is associated with the rectangle object. You can access the database object associated with a ROD object by using the ~> operator to retrieve the *dbId* attribute of the ROD object.

The value of the ROD object ID is returned when you execute the function *rodGetObj*, *rodNameShape*, or a *rodCreate* function, such as *rodCreateRect*. You might want to store the value returned in a variable so that you can refer to it later.

Many ROD procedures return ROD object IDs. These include:

- rodGetObj
- rodCreateRect
- rodCreatePath
- rodAlign

#### **ROD Object Structure**

A ROD object contains the following information:

- Hierarchical name
- Cellview ID
- Database ID
- Transformation information (rotation, magnification, and offset)
- Alignment information (if any)
- Number of segments (if the object is a shape)
- Names of user-defined handles (if any)
- Names of system-defined handles

You can access predefined attributes for any of the following named objects: instances, cellviews, and named rectangles, polygons, and paths.

- Use the ROD object ID and the SKILL operator ~> with:
  - □ One question mark (?) to get a list of the names of all attributes.
  - ☐ Two question marks (??) to get the names and values of all attributes.
  - ☐ The name of an attribute to get the value of that attribute.
- Use *rodGetHandle* with the ROD object ID and the name of the handle. For example:

```
rodGetHandle(rodObj "upperCenter")
```

## **ROD Object Structure Example**

#### Create a ROD rectangle:

```
rodRect = rodCreateRect(?cvId geGetEditCellView() ?layer "metal1")
=> rodObj:18636824
```

#### Examine the resulting ROD object:

```
rodRect~>?
=> (name cvId dbId transform align numSegments
    userHandleNames systemHandleNames)
rodRect~>name
=> "rect0"
rodRect~>dbId~>objType
=> "rect"
```

Below is the output produced by using the ~>?? database query on the ROD rectangle defined in this example:

```
rodRect~>??
=> ("rodObj:18636824" name "rect0" cvId db:16985132
      dbId db:17091952 transform
       ((0.0 \ 0.0) \ "R0" \ 1.0) \ align
      nil numSegments 4 userHandleNames nil
       systemHandleNames
       ("width" "length" "lowerLeft" "lowerCenter" "lowerRight"
        "centerLeft" "centerCenter" "centerRight" "upperLeft"
       "upperCenter" "upperRight" "length0" "start0" "mid0" "end0"
        "length1" "start1" "mid1" "end1" "length2"
        "start2" "mid2" "end2" "length3" "start3"
        "mid3" "end3" "lengthLast" "startLast" "midLast"
        "endLast"
```

#### **Example: Accessing Handles**

For the ROD object assigned to the SKILL variable *rodRect* in the previous example, below is a demonstration of accessing its handles:

```
rodRect~>systemHandleNames
=>("width" "length" "lowerLeft" "lowerCenter"
   "lowerRight" "centerLeft" "centerCenter" "centerRight"
   "upperLeft" "upperCenter" "upperRight" "length0"
   "start0" "mid0" "end0" "length1" "start1" "mid1" "end1"
   "length2" "start2" "mid2" "end2" "length3" "start3"
   "mid3" "end3" "lengthLast" "startLast" "midLast"
   "endLast")
rodRect~>centerCenter
=> (0.3 0.3)
rodRect~>length
=> 0.6
```


When you use the ROD object ID to access a point handle for a named object, the system automatically transforms (converts) the coordinates of the point up through the hierarchy into the coordinate system of the top-most cellview containing the object. The values of system-defined handles are calculated on demand, when you reference them.

This automatic coordinate conversion replaces manual calculations that were required before the introduction of ROD.

#### **Creating ROD Objects**

The primary goal of relative object design is to provide powerful new SKILL functions for creating and manipulating physical design data, as illustrated below:

You may also create ROD objects interactively within the Virtuoso® Layout Editor. The option form associated with each shape creation command allows you to specify whether or not the new shape will be treated as a ROD object. Below is the option form for creating rectangles:



The Virtuoso Layout Editor provides support for creating all types of ROD objects:


- Rectangles
- Polygons
- Simple paths
- Multipart paths

However, some types of shapes may *not* be treated as ROD objects:

- Circles
- Ellipses
- Donuts

## **Creating Multipart Paths**

For users of Virtuoso XL, an interface is provided in the layout editor under **Create—Multipart Path** for interactively specifying multipart paths.



Remember that a Virtuoso XL license is required to use the multipart path graphical user interface. However, you may use the *rodCreatePath* function with either a Virtuoso Layout Editor license or a Virtuoso XL Layout Editor license.

#### **Lab Overview**

Lab 2-1: Creating Aligned Rectangles

Lab 2-2: Using ROD in a SKILL Procedure

Lab 2-3: Using ROD to Create a Cell

Lab 2-4: Creating ROD Objects Interactively



# **Exploring Relative Object Design**

#### **Module 3**

## **Module Objectives**


- Investigate ROD handles
- Understand fundamental ROD functions
- Learn how to create new ROD objects from existing ROD objects

#### **Terms and Definitions**

ROD object	The in-memory representation of a relative object design shape or instance.
ROD connectivity	A feature within ROD allowing you to associate an electrical signal with an object as the object is created.
ROD handles	A method of accessing ROD object information.

#### Handles for Width and Length


For a single-layer path, the system calculates values for the *width* and *length* handles associated with the bounding box, as shown below.



The *width* and *length* handles of a single-layer path are the same as the *width* and *length* handles for rectangles and polygons; these handles correspond directly to the width and length of the object's bounding box.

## **Multipart Path Bounding Boxes**

For a multipart path, the values the system calculates for *width* and *length* handles are always for the bounding box around the master path. However, the system provides an additional handle called *mppBBox* containing a list of the lower-left and upper-right coordinates of the bounding box around the entire multipart path.




The value of the *mppBBox* is simply a list of two points: the location of the lower-left corner and the location of the upper-right corner of the rectangle enclosing all shapes in the multipart path.

There are no *length* and *width* handles for *mppBBox* itself. There are also no point handles such as *upperLeft* or *centerCenter* on the *mppBBox*. If necessary for your design flow, you must calculate information such as this from the list of points comprising the *mppBBox*.

#### Path and Polygon Segments

In addition to calculating values associated with the bounding box around a ROD object, the system also calculates values for point handles on segments.


For ROD objects that have segments, the system creates segment point handles and names them *segmentX*, where X is the segment number, beginning at zero. The system numbers segments in the direction in which the shape was created.



Be aware that, on a given ROD shape, there are no handles called *segment0*, *segment1*, and so forth. Rather, these are simply the names used to refer to the segments of a ROD path, polygon, or rectangle.

#### **Rectangle Segments**

Rectangles are an exception. The system treats all rectangles the same: the starting point is always in the lower-left corner, and the segments are numbered in a clockwise direction.



#### **Segment Point Handles**

For polygons and rectangles, the system calculates the following point handles:

- For each segment, three point handles
  - One at the beginning of the segment (startX)
  - One at the middle of the segment (midX)
  - One at the and end of the segment (endX)

The *endX* handle for a segment and the *startX* handle for the next segment share the same point.

- For the last segment, the three handles described above, plus three more handles:
  - startLast
  - midLast
  - endLast


#### Why are there different names for the same point?

In some cases, the system provides more than one handle for the same point. Although multiple handles for the same point might seem redundant, they provide you with flexibility.

For example, if you do not know the number of segments an object has, you can refer to points on the last segment by using point handle names containing the word *Last*. Therefore, you can write code that is independent of the number of segments in a given shape. The shape can change as your design evolves without requiring you to change the code that accesses points on the shape.

## **Polygon Segment Point Handles**

The six-sided polygon in the following figure was created starting in the upper-left corner of the highest segment, with the segments defined clockwise.



The starting point of the first segment is also the ending point of the sixth segment, so the value of the *start0* point handle is the same as the value of the *end5* point handle. The system also calculates values for three additional point handles for the last segment of the polygon, which in this case is the sixth segment. The illustration shows three system-defined segment point handles for the same point: *start0*, *end5*, and *endLast*.

#### **Segment Point Handles for Paths**


When naming segment point handles for paths, the system takes into account the direction of the path. The names of handles on the left in relation to the direction of the path contain the word *Left*, and the names of handles on the right contain the word *Right*.

Imagine a path as a road, and you were driving on it in the direction shown, then the handles on the top edge of the segment are named *Left* segment handles and handles on the bottom edge of the segment are named *Right* segment handles.



#### **Point Handles for Multisegment Paths**


The point handle names for a multisegment path are shown below:



For paths, the system calculates the values of two additional point handles: *startCenter0* and *endCenterLast*. For most types of paths, the *startCenter0* and *endCenterLast* handles have the same values as the *start0* and *endLast* handles.

#### **Point Handles for Extended-Type Paths**


For paths with the layer extending beyond the centerline, which have an end type of *variable*, *offset*, or *octagon*, the *startCenter0* and *endCenterLast* handles have different values than the *start0* and *endLast* handles.



## **Segment Length Handles**


The system provides one segment length handle for each segment for objects that have segments. For paths, the system provides a length handle for the centerline of each segment, excluding extensions, if any.

The system names length handles *lengthX*, where *X* is the segment number. The handle for the length of the first segment is *length0*. The system also provides the handle *lengthLast* for the last segment.



# **Segment Length Handles for Multisegment Paths**

An example of the length handles for a path is shown below:



The *length* and *width* handles for a path typically do not reflect the actual distance from the beginning of a path to its end. To obtain this distance, you need to write a SKILL function similar to this:

```
procedure(SPCgetRodPathLength(rodId)
  let(((totalLength 0))
    ; Step through each of the segments of the path.
    for(i 0 rodId~>numSegments - 1
        ; Add the length of the current segment to the total.
        totalLength = totalLength +
            rodGetHandle(rodId symbolToString(concat("length" i)))
    ) ;end of for
    ; Return the total length of the path.
        totalLength
    ) ;end of let
) ;end of procedure
```

# **Relative Object Design Functions**

These functions comprise the foundation of ROD functionality:

Object creation		
rodCreatePath	rodCreatePolygon	rodCreateRect
Object alignment		
rodAlign	rodUnalign	
Object information		
rodGetObj	rodlsObj	
rodNameShape	rodUnNameShape	rodGetNamedShapes
rodGetHandle	rodIsHandle	
rodCreateHandle	rodDeleteHandle	
Point arithmetic		
rodAddPoints	rodAddToX	rodPointX
rodSubPoints	rodAddToY	rodPointY

#### **Object creation**

These functions take the place of low-level database functions such as *dbCreateRect* and *dbCreatePath*. Because of the built-in connectivity arguments available in ROD functions, you need not call other low-level functions such as *dbCreatePin* and *dbCreateNet*.

#### **Object alignment**

The seemingly simplistic function called *rodAlign* combined with ROD handles alleviates much of the tedious offset calculation required to arrange shapes and instances in your designs.

#### **Object information**

These functions assist in identifying specific shapes or instances throughout the design hierarchy and provide detailed information about those shapes. They replace the need to call low-level database functions to traverse through hierarchy.

#### **Point arithmetic**

Although you can replace these functions with calls to *car*, *cadr*, and *nth*, the ROD point arithmetic functions help make your code easier to read and understand.

### rodCreateRect

This function creates a single rectangle, an array of rectangles, or fills a bounding box with rectangles.

```
rodCreateRect(
  [?name
                               ;; Name the rectangle
                t namel
                               ;; Layer to draw rectangle on
  ?layer
                txl_layer
  [?width
                n width]
                               ;; Rectangle width
  [?length
                n length]
                               ;; Rectangle length
                               ;; Location of lower left point
  [?origin
                l_origin]
  ?bBox
                l bBox]
                               ;; Bounding box
  [?elementsX
                x elementsX]
                               ;; Number of columns
  [?elementsY
                x elementsY]
                               ;; Number of rows
  [?spaceX
                n spaceX]
                               ;; X & Y separation of
  [?spaceY
                n spaceY]
                                    repeated rectangles
                               ;;
  [?cvId
                d cvId]
                               ;; Cellview to contain objects
                               ;; Fill this box with rects
  [?fillBBox
                l fillBBox]
  [?fromObj
                Rl fromObj]
                               ;; Use object(s) to form new object
                txf_size]
  [?size
                               ;; Up/down-size new object
  [?subRectArray | subrectArgs] ;; Definition of subrect array
  /* ROD Connectivity Arguments */
```

#### **Examples:**


1. Create a single rectangle with a specific bounding box:

2. Create a rectangle named *myRect* using *width* and *length* keyword arguments:

3. Create a 3-by-2 array of unit squares starting at the origin. Separate them by 1 unit horizontally and 2 units vertically:

# rodCreateRect ?subRectArray Option

This option allows you to fill a rectangle with subrectangles. A typical application is to fill a metal rectangle with contacts or vias.



Using rodCreateRect and the ?subRectArray argument you can define:

- A single master rectangle enclosing a two-dimensional array of subrectangles or overlapped by a two-dimensional array of subrectangles
- A single master rectangle with stacked arrays of rectangles

The benefits of the using this option are:

- Subrectangles are ordinary shapes with no ROD attributes (faster)
- You can stretch the master rectangle and the array of subrectangles will automatically regenerate to fit the new size.

#### Related SKILL commands:

- rodFillBBoxWithRects( ?cvId ?layer ?fillBBox ?width ?length ?gap ?spaceX ?spaceY ?prop ?returnBoolean )
  - ☐ This command fills a bounding box with rectangles.
  - ☐ It creates as many rectangles as will fit within the bounding box you specify.
  - □ Unlike *rodCreateRect()*, the default *?gap* argument value will create distributed rectangles which completely fill a region
  - ☐ The rectangles created are ordinary unnamed shapes, identified only by *dbids*. These are regular database shapes which require less overhead and contribute to faster performance of the pcell.
- dbCreateViaShapeArray( <cvId> <layer> <netId> <startX> <startY> <pitchX> <pitchY> <rect\_width> <rect\_length> <rows> <cols>)
  - ☐ This command creates an array of via shapes (rectangles) on the given layer and adds all the shapes to the given net.
  - Like *rodFillBBoxWithRects()*, the rectangles created are ordinary unnamed shapes, identified only by *dbids*. These are regular database shapes which require less overhead and contribute to faster performance of the pcell.

### rodCreatePolygon

This function creates one polygon using the points you specify.

```
rodCreatePolygon(
  [?name
             t_name]
                         ;; Name of the resulting polygon
  ?layer
          txl_layer
                         ;; Layer on which to draw polygon
  [?pts
             l_pts]
                         ;; Vertices of the polygon
            d_cvId]
  [?cvId
                         ;; Cellview in which to create the polygon
  [?fromObj Rl fromObj]
                        ;; Use object(s) to form new object
  [?size
             txf_size] ;; Up/down-size new object
  /* ROD Connectivity Arguments */
```

#### **Example:**

Create a *metal1* polygon named *myPolygon* with vertices at these points:

9:4 11:4 11:1 5:1 5:2 9:2

rodCreatePolygon(
 ?cvId geGetEditCellView()
 ?name "myPolygon"
 ?layer "metall"
 ?pts list(9:4 11:4 11:1 5:1 5:2 9:2)

### rodCreatePath

This function creates a path consisting of one or more shapes. The resulting object is known as a *simple path* if it consists of a single shape. A path with multiple shapes is known as a *multipart path*.

The function is composed of three sections:

The *rodCreatePath* function offers an enormous number of options allowing you to create a wide variety of physical structures with just one command.

Notice that the master path specification is required, and that connectivity and subpath specifications are optional. Without subpath specifications, you create a simple path. If you include subpath specifications, you create a multipart path.

### rodCreatePath: Master Path Arguments

These arguments may be used to specify the master path:

```
rodCreatePath(
   [?name
                                      ;; Name of resulting path
                    t name]
                                      ;; Layer on which to draw path
   ?layer
                    txl_layer
   [?width
                    n width]
                                      ;; Path width
  [?pts
                    l_pts]
                                      ;; Points on the path
   [?justification
                    t justification]
                                      ;; Path offset method
   [?offset
                    n offset]
                                      ;; Distance to offset master
   [?endType
                    t_endType]
                                      ;; Type of end structure
   [?beginExt
                    n_beginExt]
                                      ;; Extension at path beginning
   [?endExt
                    n endExt]
                                      ;; Extension at path ending
   [?choppable
                    g_choppable]
                                      ;; Responds to chop command?
   [?cvId
                    d_cvId]
                                      ;; Cellview to contain the path
   [?fromObj
                    Rl fromObj]
                                      ;; Use obj(s) to form new obj
   [?size
                    txf size]
                                      ;; Up/down-size new object
   [?startHandle
                    l startHandle]
                                      ;; Begin at this source handle
   [?endHandle
                    l endHandlel
                                      ;; End at this source handle
   /* ROD Connectivity Arguments and subpath specifications */ )
```

#### **Examples:**

1. Create a simple path:

2. Create a simple path with end extensions:

# rodCreatePath with Offset Subpath

You can use these optional arguments to specify one or more subpaths offset from the master path:

```
list(;; Offset Subpath Arguments
  list(
     ?layer
                   txl_layer ;; Subpath drawn on this layer
     [?width
                    n width]
                                     ;; Subpath width
     [?sep
                    n_sep]
                           ;; Separation from master path
     [?justification t_justification] ;; Method of offset
     [?beginOffset n beginOffset] ;; Offset beginning of subpath
     [?endOffset n endOffset] ;; Offset ending of subpath
     [?choppable q_choppable]
                                     ;; Subpath responds to chop?
     /* ROD Connectivity Arguments */
  ) ;; End of first offset subpath description
   ... ;; More offset subpath arguments
) ;; End of offset subpath arguments
```

#### **Example:**

Create a two-bit bus using a multipart path:

```
rodCreatePath(
   ?cvId
                geGetEditCellView()
   ?layer
                "metal1"
   ?width
                0.8
                list(20:-20 40:-20 40:-30 80:-30)
   ?pts
   ?offsetSubPath
   list(
      list(
         ?layer
                        "metal1"
         ?justification "left" ;; Sub-path on "left" side of
                                 ;; master path.
                        0.6
         ?sep
```

# rodCreatePath with Enclosed Subpath

You can use these optional arguments to specify one or more subpaths either enclosing or enclosed by the master path:

#### **Example:**

Create a *metal1* path enclosed by n-type diffusion:

```
rodCreatePath(
         ?cvId
                      geGetEditCellView()
         ?layer
                      "metal1"
         ?width
                     0.8
                     list(20:-20 40:-20 40:-30 80:-30)
         ?pts
         ?encSubPath
         list(
            list(
               ?layer "ndiff"
               ?enclosure -0.6 ;; Amount diffusion overlaps
metal
                                  ;; Note: this is a negative value
```

# rodCreatePath with Subrectangles

You can use these optional arguments to specify one or more sets of repeated rectangles subordinate to the master path:

```
list( ;; Subrectangle Arguments
  list(
     ?layer
                   txl_layer
                                    ;; Subrects drawn on this layer
     [?width
                                     ;; Width of each subrectangle
                    n width]
     [?length
                   n length]
                                     ;; Length of each subrectangle
     [?gap
                   t_gap]
                                     ;; Method for excess space
     [?sep
                    n_sep]
                              ;; Offset from center or edge
     [?justification t justification]
                                    ;; Use center or edge of master
     [?beginOffset n_beginOffset] ;; Offset for beginning rect
     [?endOffset n_endOffset] ;; Offset for ending rect
     [?space
                                     ;; Space between rectangles
                n space]
     [?choppable
                    g_choppable]
                                     ;; Responds to chop command?
     /* ROD Connectivity Arguments */
  ) ;; End of first list for subrectangles
   ... ;; More subrectangle arguments
) ;; End of subrectangle arguments
```

#### **Example:**

Create a multipart path consisting of a metal stripe and an embedded array of contacts:

```
rodCreatePath(
  ?cvId
              geGetEditCellView()
  ?layer "metal1"
  ?width 2.0
  ?pts list(0.0:0.0 0.0:10.0)
  ?subRect
  list(
     list(
        ?layer
                  "cont"
        ?beginOffset -0.5 ;; Negative values specify rects
        ?endOffset -0.5; overlapped by master path.
```

# **ROD Connectivity Arguments**

When you use a ROD function to create a shape, such as a rectangle or path, you can specify connectivity for the shape by associating it with a specific terminal and net. You can also make the shape into a pin. If a shape is a pin, you can create a label for it.

```
;; Name of terminal
[?termName
                        t termName]
[?termIOType
                        t_termIOType]
                                                ;; I/O type
[?pin
                        g_pin]
                                                ;; Is the object a pin?
[?pinAccessDir
                        tl pinAccessDirl
                                                ;; Access direction
[?pinLabel
                        q pinLabel]
                                                ;; Add a label?
[?pinLabelHeight
                        n_pinLabelHeight]
                                                ;; Label height
[?pinLabelLayer
                        txl pinLabelLayer]
                                                ;; Draw on this layer
[?pinLabelFont
                        t_pinLabelFont]
                                                ;; Use this font
[?pinLabelDrafting
                        g_pinLabelDrafting]
                                                ;; Use drafting?
[?pinLabelOrient
                        t pinLabelOrient]
                                                ;; Label orientation
[?pinLabelOffsetPoint
                        l_pinLabelOffsetPoint] ;; Offset label
[?pinLabelJust
                        t pinLabelJust]
                                                ;; Label justification
[?pinLabelRefHandle
                        t pinLabelRefHandle]
                                                ;; ROD handle for loc
```

#### **Examples:**

Assume a layout editor window is open and this command has been executed:

```
cv = geGetEditCellView()
```

Each example provides connectivity arguments for this call to *rodCreateRect*:

1. Associate the rectangle with an input signal called *clock*:

```
/* ROD Connectivity Arguments */
?termName "clock"
?termIOType "input"
```


2. Associate the rectangle with an input signal called *clock*; make the rectangle a pin; give the pin a label; anchor the label to the upper-center of the rectangle:


# **Creating Objects from Other Objects**

Using the *rodCreateRect*, *rodCreatePolygon*, or *rodCreatePath* function, you can create a new rectangle, polygon, or path from one or more existing ROD objects.

- The existing objects are referred to as source objects, and the new object is referred to as the generated object
- You use the ?fromObj keyword argument to specify the source objects
- You can specify a difference in the size between the generated object and the source objects
- You use the ?size keyword argument to specify the scaling factor for the new object

source object: diffusion region





The code for the example shown here might look something like this:

```
cv = geGetEditCellView() ;; Get the current cellview ID
diffObj = rodCreateRect( ;; Create the P-diffusion rectangle
   ?cvId
           CV
   ?layer "pdiff"
   ?bBox list(1:1 6:4)
wellObj = rodCreateRect( ;; Create the N-well rectangle
   ?cvId
           CV
   ?layer "nwell"
   ?fromObj diffObj ;; P-diffusion rect is source object
                         ;; N-well is 0.8 units larger than
   ?size 0.8
p-diff
```

# rodAlign

This function aligns a named object by a point handle on that object to a specific point or to a point handle on a reference object.

```
rodAlign(
   ?aliqnObj
                     d aliqnObj
                                      ;; Object to be aligned
   [?alignHandle
                     t_alignHandle]
                                      ;; Point on object to align
                                      ;; Align to this object
   [?refObj
                     d_refObj]
   [?refHandle
                     t refHandle]
                                      ;; Point to align to on ref obj
   [?refPoint
                     l refPoint]
                                      ;; Fixed point to align to
   [?maintain
                     q maintain]
                                      ;; Alignment persistent?
   [?xSep
                     txf xSep]
                                      ;; Horizontal offset
                                      ;; Vertical offset
   [?ySep
                     txf_ySep]
```

#### **Examples:**

Assume a layout editor window is open and these commands have been executed:

1. Align the lower-left corner of *bigRect* to a fixed point:

```
rodAlign(
    ?alignObj bigRect
    ?alignHandle "lowerLeft"
    ?refPoint 2.5:4
)
```

2. Align the upper-left corner of *smallRect* to the upper-right corner of *bigRect*:

```
rodAlign(
    ?alignObj smallRect
    ?alignHandle "upperLeft"
    ?refObj bigRect
    ?refHandle "upperRight"
)Lab Overview
```

### **Lab Overview**

Lab 3-1: Investigating ROD Object Structure

Lab 3-2: Creating ROD Objects from Other ROD Objects



# **Creating and Using SKILL Parameterized Cells**

#### **Module 4**


# **Module Objectives**

- Understand how a pcell functions
- Understand cell parameters
- Learn how to create a pcell
- Learn how to use technology information
- Understand the safety rules for creating pcells
- Learn pcell debugging techniques

### **How Pcells Function**

When you successfully compile a pcell, a *master cell* is created for it. The master cell contains the SKILL code of the cell's definition along with the cell's parameters and their default values.

One submaster cell exists in virtual memory for each unique set of parameter values assigned to instances of the master cell.



A submaster cell resides in virtual memory for the duration of your editing session and is accessible by all cellviews. When you create an instance in a cellview, and a submaster with the same parameter values already exists in virtual memory, no new submaster is generated; the new instance references the existing submaster cell.


When you close all cellviews that reference a particular submaster cell, the database software automatically purges (removes) the referenced submaster cell from virtual memory but does not remove the master pcell from your disk.

When you exit the Cadence® software, the database software automatically purges all submaster cells from virtual memory. Purging does not remove master peells from your disk.

# **Defining Parameter Values**

You can specify parameter values other than the defaults for your pcells by changing their values on the instance. To do this, you can use the property editor form (**Edit—Properties**) in a layout editor window.

After you invoke the property editor, you select the **Parameter** option:



You can also create a Component Description Format (CDF) description to specify the value for a peell parameter. You can create CDFs for a cell or for a whole library. CDFs defined for a cell apply to all cellviews; for example, to parameters shared by schematic and layout cellviews. CDFs defined for a library apply to all cells in the library.

You will learn more about using CDFs with pcells in a later module.


## **Creating a SKILL Pcell**

The *pcDefinePCell* function lets you pass a SKILL definition for a pcell to the pcell compiler. This creates a pcell master.

You use the SKILL function called *load* to compile the cell.

```
load("file name")
```

When you compile pcell SKILL code, the compiler attaches the compiled code to the master cell.



Compiled code stored on disk

Each call to *pcDefinePCell* creates one pcell master cellview. You can create one source code file for each pcell or define several pcells in one file.

Pcells created with SKILL work just like graphical pcells. You can create instances of the pcell and modify its parameter values to suit your needs.

You do not need the source file containing the *pcDefinePCell* calls to be able to use your pcell. But save the source file so you can revise it later.

# pcDefinePCell Syntax

Below is a description of the syntax for *pcDefinePCell*:

```
pcDefinePCell(
    l_cellIdentifier
    l_formalArgs
    body of code
)
=> d cellViewId/nil
```

The *pcDefinePCell* function has three sections:

- A list identifying the cellview to be created
- A list of parameters and their default values
- A single SKILL construct, typically a let statement, with calls to the functions that define the contents of the cell

#### l\_cellIdentifier

This is a list containing the library database ID, cell name, view name, and view type. View type is optional and defaults to *maskLayout*. An example appears below:

```
list(ddGetObj("stdcells") "inv" "layout")
```

#### **l\_formalArgs**

The parameter declaration section, containing a list of input parameters and their default values, all enclosed in parentheses. An example appears below:

```
(xDistance 4.2)
(yDistance 0.8)
(layer "metal1")
```

#### body of code

The SKILL code that creates geometries and pins.

## Using the pcCellView Variable

pcCellView is an internal variable automatically created by pcDefinePCell. pcCellView contains the dbld (database identification) of the cell you are creating.

Within the body of your pcell code, use the *pcCellView* variable as the cellview identifier for which you create objects.

#### For example:

```
pcDefinePCell(
      Identify the target cellview.
   list(ddGetObj("example") "mycell" "layout")
      Declare formal parameter name-value pairs.
   (\ldots)
      Define the contents of the cellview.
   let((inst)
      inst = dbCreateInst( pcCellView ... )
```

For convenience, you might assign *pcCellView* to a variable with a shorter name. For example:

```
let((cv ...)
    cv = pcCellView
    ...
    dbCreateInst( cv ... )
    ...
)
```

There are some SKILL functions that recognize the presence of this variable, and will use its value when a cellview ID is required. In particular, all ROD functions that require a cellview ID will use *pcCellView* implicitly.

#### **SKILL Pcell Example**

Below is a complete pcell definition that implements a parameterized rectangle:


```
pcDefinePCell(
      Identify the target cellview.
   list(ddGetObj("example") "rectangle" "layout")
     Declare formal parameter name-value pairs.
      (xDistance 4.2) ;; Parameter for rectangle width.
      (yDistance 0.8) ;; Parameter for rectangle length.
     (layer "metal1") ;; Parameter for layer rectangle appears on.
   let(()
                         ; ;
                            Define the contents of the cellview.
      rodCreateRect(
                         ;; Create the rectangle.
         ?layer list(layer "drawing")
         ?width xDistance
         ?length yDistance
      ) ;; rodCreateRect
   ) ;; let
) ;; pcDefinePCell
```

Notice in this example how the cell's parameters are used in the call to *rodCreateRect*. The width, length, and drawing layer of the rectangle are determined by the values of the *xDistance*, *yDistance*, and *layer* parameters. Hence, you can change the behavior of each cell instance by varying the values of its parameters.

# Using the SKILL Operator ~> with Pcells

When you use the SKILL operator ~> to access information about the master cell of a pcell instance, you must look two levels above the instance. If you look at only one level above, you access information about the pcell submaster.

```
inst = car(geGetSelectedSet())
inst~>master    ;; returns the submaster for the pcell
inst~>master~>superMaster    ;; returns the pcell master
```



You can inspect the local parameter values on a given instance by referencing its *submaster* like this:

```
inst = car(geGetSelectedSet())
inst~>master~>parameters~>value~>??
```

You can obtain the *default* parameter values by looking at the instance's *superMaster* like this:

inst~>master~>superMaster~>parameters~>value~>??

## **Creating Instances Within Pcells**

It is often useful to create instances of other cells within a pcell. You can also create pcell instances within a pcell. For example, you might get the database ID of a cellview in this manner:

```
cellId = dbOpenCellViewByType( "example" "rectangle" "layout")
```

You might create an instance of this cell in the body of your pcell like this:

```
dbCreateInst( pcCellView cellId nil xPos:yPos orientation 1)
```

If the cellview you wish to instantiate is a pcell itself, you might use code like this:

```
dbCreateParamInst( pcCellView cellId nil xPos:yPos orientation 1
    ; Set parameters for this instance.
    list(
        list( "xDistance" "float" 10.5 )
        list( "yDistance" "float" 3.4 )
    ) ; close parameter list
) ; dbCreateParamInst
```

Notice in both cases that you use *pcCellView* to specify the cellview in which the new instance is to be created.

## **Accessing Technology File Data**

You can access nominal and minimum dimensions and other technology file information from within a pcell, using *tech* procedures.

You use *techGetTechFile* gain access to the technology information for the cell you are creating:

```
tfId = techGetTechFile(pcCellView)
```

You then use functions such as *techGetSpacingRule* and *techGetOrderedSpacingRule* to retrieve technology information. For example:

```
; Get the minimum poly width.
polyWidth = techGetSpacingRule(tfId "minWidth" "poly")
; Get the minimum poly enclosure of contact.
polyContEnclose = techGetOrderedSpacingRule(
    tfId "minEnclosure" "poly" "cont"
)
```

Use *tech* procedures to keep process-specific information, such as layer-to-layer spacings, localized to the technology file. Make sure rules you want to read from the technology file are defined there before you load your pcell code; otherwise, the pcell compilation fails.

It is beneficial to have a text-file containing the technology for the target library available as you develop your peells.

# Safety Rules for Creating SKILL Pcells

The purpose for creating a pcell is to automate the creation of data. Pcells should be designed as stand-alone entities, independent of the environment in which they are created and independent of the variety of environments in which you or someone else might want to use them.

If you use SKILL functions that are unsupported and/or not intended for use in pcells, your pcell code will probably fail when you try to translate your design to a format other than Design Framework II or when you use the pcell in a different Cadence application.

Although it is possible to create peells dependent upon something in your current or local environment, and/or using functions not supported or not recommended, your peell code is likely to fail when you try to translate it for a different environment. And although it is possible to load, read, and write to files in the UNIX file system from within a peell, do not do so. You cannot control the file permission settings in other locations, so reading or writing from a peell can cause the peell to fail in other directories, other environments, and during evaluation by translators.

Functions that are not supported for use by customers within SKILL pcells usually belong to specific applications (tools); they are unknown to other environments, to other tools, and to data translators. For example, if you create a pcell in the *icfb* environment and include place-and-route functions, the pcell will fail in the layout environment. Also, application-specific functions that are not supported for customer use can disappear or change, without notice.

Create peells using only the recommended, supported functions. Generally, you can identify them by their prefixes. However, you can also use all of the basic SKILL language functions that are defined in the SKILL Language Reference Manual; these functions do not have prefixes.

## **Supported SKILL Functions for Pcells**

When you create SKILL functions within pcells, use only the following functions:

- The SKILL functions documented in the SKILL Language Reference Manual. For example: car, if, foreach, sprintf, while.
- SKILL functions from the following families:
  - □ db
  - dd
  - cdf
  - rod
  - tech
- The following four *pc* SKILL functions:
  - pcExprToString
  - pcFix
  - pcRound
  - pcTechFile

You can use only these four pc SKILL functions because:

- Most supported *pc* functions correspond to the graphical user interface commands. You can use them to create peells in the graphical peell environment, but you cannot use them in the body of SKILL peell code.
- Both the Pcell graphical user interface and the Pcell Compiler are coded using *pc* SKILL functions. You cannot use the graphical user interface or compiler functions at all.

## What to Avoid When Creating Pcells

Do **not** use functions with application-specific prefixes such as:

ael	ge	las	pr
de	hu	le	sch

#### **Examples:**

aelSignum	deGetViewType	geGetEditCellview
hiDisplayForm	lasGenCell	IeCreateContact
prAlignCell	schReplaceProperty	

Although it is possible to call procedures with other prefixes from within a pcell, you will not be able to view the pcell in a different environment or translate it into the format required by another database. Most translators, including the physical design translators and the Cadence Design Framework II-Virtuoso® Chip Assembly Router translator, can translate only basic SKILL functions, the four *pc* functions, and functions in the SKILL families *db*, *dd*, *cdf*, *rod*, and *tech*.

Procedures in any application-specific family are at a higher level of functionality than can be used in a pcell safely. For example, if you create a pcell using *le* functions, the pcell works only in environments that include the Virtuoso Layout Editor. You cannot use a translator to export your design from the DFII database.

When a translator cannot evaluate a function, one of the following happens:

- The translator fails and issues an undefined function error message.
- The translator continues, issues a warning message, and translates the data incorrectly.

## What to Avoid When Creating Pcells (continued)

You must remember these specific rules when developing your pcells:

- Do not prompt the user for input.
- Do not load, read, or write to files in the UNIX file system.
- Do not run any external program that starts another process.
- Do not generate output with printf, fprintf, or println.

If you need to drive external programs to calculate cell shapes, do it in SKILL. Use CDF callback procedures to save the resulting dimensional information in a string, and then pass the string as input to a SKILL pcell.

#### **Debugging Pcells**

Inevitably, an error of some kind will occur in your pcell code as it is executed. Pcell code is executed when the cell is defined (by executing the *pcDefinePCell* function) or when parameters on an instance of the cell are changed.

When an error is encountered, you see messages in the CIW indicating a problem. In the layout editor window, each instance of the pcell affected by the error is replaced by a rectangle containing the following message:

```
pcellEvalFailed
```

At this point, you might be inclined to print variables to the CIW with *println* or *printf*, but that does not work.

#### **Example Output for Compilation Error**

Below is an example of the output you might see in the CIW for a compilation error:

```
load "inv.il"
Generating Pcell for 'inv layout'.
*Error* eval: undefined function - makeAnError
*Error* load: error while loading file - "inv.il"
```

#### **Debugging Non-Pcell SKILL**

For simple problems with non-pcell SKILL code, you can use standard printing functions such as *println* and *printf* to display in the CIW information internal to the functions you write. For more complex problems, you can use the SKILL debugger to trace variables and function calls.

#### **Debugging Pcell Code**

Pcell SKILL code differs from other SKILL code in that it is evaluated in its own subenvironment. In this environment, standard printing functions such as *println* and *printf* exist, but their output is disconnected from the CIW. You cannot use the SKILL debugger in pcell code.

## **Pcell Debugging Techniques**

- Build your cells in small increments (incremental composition)
- Execute portions of the code in the CIW (interactive trials)
- Temporarily assign global variables with debugging information (visibility by global variables)
- Create a label containing debugging information as part of the cell's definition (visibility by labels)

While not as elegant as an interactive debugger, you can use the techniques mentioned here effectively to analyze and solve problems that occur in your pcell code. In general, the goal is to simply reveal information internal to the cell's definition in some manner. These techniques all satisfy that goal.

Incremental composition and interactive trials are pro-active measures to help reduce the number of errors that may occur as you develop your pcell.

Visibility by global variables and visibility by labels are reactive measures for handling the inevitable errors that will occur either during development of the pcell or as it is being used in your design flow.

# **Incremental Composition**

It is beneficial to define new functionality in small portions. For example, in a standard cell design flow, you might begin by implementing only the supply rails. You might then create and arrange the necessary transistors.

As you add more to the definition of the pcell, you test the cell to ensure the new features work. When an error is encountered, you know that it is most likely related to the code you added or modified in the last increment.

The intent of this technique is to limit the amount of debugging effort required by limiting the amount of code to inspect. This also allows you to focus your testing primarily on the newest features added.

#### **Interactive Trials**

To develop the body of a pcell, you need not actually execute the cell's code within the *pcDefinePCell* construct. Instead, you can enter the code defining the cell's structure into the CIW and observe the results.

This technique is complimentary to the incremental composition technique.

To prepare for interactive trials, you should follow these steps:

- 1. Open an empty cellview for edit.
- 2. Enter this command into the CIW to mimic the behavior of *pcDefinePCell*:

  pcCellView = geGetEditCellView()
- 3. Define any parameters as global variables. For example, you would enter the following commands into the CIW for a cell with parameters *cellHeight* and *cellWidth*:

```
cellHeight = 32.0
cellWidth = 12.5
```

This also mimics the behavior of *pcDefinePCell*.

## Visibility by Global Variables

To observe information internal to your pcell, you can assign various data to global variables within the body of the pcell. For example, assume you need to know the center point of a particular rectangle after it has been aligned:

As long as the variable *GateCenter* is not declared in the local variable list of the *let* statement, you will be able to retrieve the desired point from the variable in the CIW after the cell has been compiled.

You can use *sprintf* to create a descriptive string with several items of information and assign the string to a global variable. For example:

```
pcDefinePCell(
    ...
let(( ... )
    ...
    DebugString = sprintf(nil
        "Buffer center = %L; width = %g; length = %g"
        rodGetObj("buffer")~>centerCenter
        rodGetObj("buffer")~>width
        rodGetObj("buffer")~>length
    )
    ...
)
```

#### Important

The global variables you create for debugging should be temporary. You should remove them from your code as soon as they are no longer needed.

#### **Visibility by Labels**

You can also place debugging information directly into the pcell by adding a label. For example, to determine the location of a calculated point you can add a label with code such as this:

```
let((tfId specialPoint offset1 offset2 ... )
   specialPoint = offset1/2.0:cellWidth - offset2
  dbCreateLabel(
     pcCellView
                                ;; cellview label appears in
      list("label" "drawing") ;; layer on which label appears
      specialPoint
                            ;; where label appears
      sprintf(nil "special point = %L" specialPoint) ;; label text
      "centerCenter"
                                 ;; label justification
      "R0"
                                 ;; label orientation
      "stick"
                                 ;; font
      0.75
                                 ;; height for the label
```

Notice that in this debugging technique, you can automatically include location information in the label's position.

#### Important

As with visibility by global variables, you should remove or comment-out debugging labels when they are no longer needed.

#### **Lab Overview**

- Lab 4-1: Creating a Simple SKILL Pcell
- Lab 4-2: Creating an Elementary Transistor Structure
- Lab 4-3: Adding Source and Drain Connections Using Multipart Paths
- Lab 4-4: Multipart Path Transistor
- Lab 4-5: Experimenting with Process Independence



# **Going Further with SKILL Pcells**

### **Module 5**

### **Module Objectives**

- Understand how to use component description format (CDF) properties with pcells
- Create and use pcell stretch handles
- Explore the sample pcell library
- Understand pcell code encapsulation
- Learn how to create abuttable pcells for the Virtuoso® XL Layout Editor environment

### **Terms and Definitions**

CDF	Component description format: A facility for displaying and maintaining instance parameters.
	mamaming instance parameters.

# **Using Component Description Format**

Component description format (CDF) provides a standard method for describing components. You can use the component description format to describe parameters and attributes of parameters for individual components and libraries of components.


You can create a Component Description Format (CDF) property to specify the value for a pcell parameter. You can create CDFs for a cell or for a whole library. CDFs defined for a cell apply to all views of that cell; for example, to parameters shared by schematic and layout cellviews. CDFs defined for a library apply to all cells in the library.

A CDF is treated similarly to a parameter. Creating CDFs allows you to store all component-specific data required for a cell or a library in one location. CDF data is independent of application or view type.

If you want all cellviews of a cell to share the same parameters, use CDF to define the parameters. The CDFs apply to all views of the cell: layout, schematic, symbolic, abstract, extracted, and so forth. You can also assign parameters to a library of cells so that they are shared by all views of all cells in the library.

## **CDF Example**

In the case of a standard cell, you can define a CDF for the cell that provides a list of standard sizes. When the user selects a certain size, various parameters on the cell, such as transistor widths and lengths, are set to predetermined values.




Without any CDF parameters, property editor and add component forms will contain only fields that correspond to the pcell parameters.

When CDF parameters are added, they override the default values of parameters present on the pcell. You can choose to make none, some, or all of the original pcell parameters available as CDF parameters and you can add any new parameters you deem necessary.

In this example, all of the original peell parameters have been made available as CDF parameters, and a cyclic field has been added for choosing the instance size from a list of standard sizes.

### **Parameter Precedence**

Be careful when you choose where you set default values. Once the system finds a value for a parameter, it stops looking. For example, if you set a parameter value in the pcell *pcDefinePCell* code (number 4) and also in a CDF for the pcell (number 2), changing the parameter value in the pcell code does not cause a change in the pcell.



If you are uncertain if a CDF default is taking precedence over your pcell default, you can use **Tools—CDF—Edit** to inspect and edit the CDF for a cell or a library.

## **Adding CDF Parameters**

Below is an example of the code you might use to add a CDF parameter to a pcell.

```
; Get the database ID for this cellview.
cellId = ddGetObj("stdcells" "inv")
  Create new base CDF information for this cell.
cdfId = cdfCreateBaseCellCDF( cellId )
  Add a CDF parameter for standard sizes.
cdfCreateParam( cdfId
            "size"
   ?name
   ?type "cyclic"
   ?prompt "Size"
   ?choices list("A" "B" "C" "D" "E" "F")
   ?defValue "C"
   ?callback "SPCsetInvSize()"
  Save the new CDF for the cell.
cdfSaveCDF(cdfId)
```

The code for the CDF callback, *SPCsetInvSize*, might look something like this:


```
procedure(SPCsetInvSize()
   let(()
         Set the cell height to a standard value.
      cdfgData->cellHeight->value = 28
         Set other parameters based on the "size" selection.
      case(cdfqData->size->value
         ("A"
            cdfqData->pWidth->value = 4.0
            cdfqData->pLength->value = 1.2
            cdfqData->nWidth->value = 2.0
            cdfgData->nLength->value = 0.6
         ("B"
```

### Stretchable Pcells


You can make pcell instances "stretchable" by assigning point handles to the parameters of the pcell with the *rodAssignHandleToParameter* function. This kind of handle is called a *stretch handle*.

Stretch handles display as small diamonds

You see feedback as you stretch the pcell



The final effect is the same as entering the new parameter value using the property editor



A pcell with stretch handles is called a *stretchable pcell*. Assigning stretch handles to pcell parameters lets you graphically change the value of those parameters for pcell instances after you place them. You do this by selecting one or more handles and using the **Stretch** command.

You are not actually stretching objects within the pcell or stretching the pcell itself. Instead, you are graphically updating the value of the parameters associated with the selected handles. Graphically stretching a pcell instance has the same result as editing its parameters using the Edit Properties form.

**Note:** You cannot undo stretching a pcell instance.

# **Example: rodAssignHandleToParameter**

Below is a code fragment demonstrating how you can implement the stretch handles seen in the transistor example:

```
transObj = rodCreatePath(
rodAssignHandleToParameter(
   ?parameter
             "width"
  ?rodObj transObj
  ?stretchDir "Y"
  ?handleName "upperCenter"
rodAssignHandleToParameter(
   ?parameter
             "length"
  ?rodObj
              transObj
   ?stretchDir "X"
   ?handleName "centerRight"
```


In this example, the transistor is implemented as a multipart path with the poly stripe comprising the master path. Notice that the calls to *rodAssignHandleToParameter* associate stretch targets on the path by means of handle names.

Below is a summary of this function:

```
rodAssignHandleToParameter(
 ?parameter S_parameter
 ?rodObj R_rodObj
 ?handleName Sl_handleName
 [?displayName S_displayName]
 [?displayExpressionS_displayExpression]
 [?stretchDir S_stretchDir]
 [?stretchType S_stretchType]
 [?moveOrigin q moveOrigin]
 [?updateIncrementf updateIncrement]
 [?userData
                q userData]
 [?userFunction Sl_userFunction]
) ; end rodAssignHandleToParameter
=> t | nil
```

### **Interactive Feedback**

Stretch handles can be embellished to provide you with the current parameter value as you stretch a handle:



To do this, you specify a string for the *displayName* keyword argument. The string will appear as a label with the current value of the parameter as shown above.

In the example seen here, you might use code similar to the following to implement the interactive feedback:

```
theRect = rodCreateRect( ... )
rodAssignHandleToParameter(
 ?parameter "xDistance"
 ?rodObj theRect
 ?stretchDir "X"
 ?handleName "centerRight"
 ?displayName "xDistance"
rodAssignHandleToParameter(
 ?parameter "yDistance"
 ?rodObj
         theRect
 ?stretchDir "Y"
 ?handleName "upperCenter"
 ?displayName "yDistance"
```

# **Controlling Parameter Values**


Depending upon your design flow, you might need to

- Constrain the range of values for a given stretch handle, or
- Perform a calculation to determine the actual value for the parameter based on the current stretch location.

To do these, you specify a *user* function and pass the function user data.

userFunction: Keyword argument to specify the user function.

userData: Keyword argument to specify data to pass to the user function.



### Example:

The function you specify to the *userFunction* keyword argument should be written to accept one argument. The value of this argument is a data structure (known as a *defstruct* in SKILL). It contains a number of fields as depicted below:

```
procedure(MYuserFunction(SPCInfo)
                         ; Name of the handle being stretched.
  SPCInfo->handleName
  SPCInfo->increment
                         ; default = updatePcellIncrement env. var
  SPCInfo->origInstId
                         ; ID of the instance being stretched.
  SPCInfo->parameter
                         ; Parameter name affected by the stretch.
  SPCInfo->paramVal
                         ; Current value of the affected parameter.
  SPCInfo->rodObj
                         ; Stretched handle belongs to this ROD obj.
  SPCInfo->stretchDir
                         ; Stretch direction for this handle.
  SPCInfo->stretchMaster; Interim stretched cellview ID.
                         ; Passed by means of userData keyword arg.
  SPCInfo->userData
  SPCInfo->parameters
                         ; Allows you to change parameter values on
                   ; stretched instance.
```

The value of *SPCInfo->userData* is specified by the value of the *userData* keyword argument in the call to *rodAssignHandleToParameter*. This is how you can pass information from within your peell to the user function you define for the stretch handle.

### **Lab Overview**

Lab 5-1: Pcell Hierarchy

Lab 5-2: Using ROD Points in Hierarchy

Lab 5-3: Adding a CDF Parameter to the Inverter Cell

Lab 5-4: Pcell Stretch Handles

## **Sample Pcells**

A library of sample peells is available in your Virtuoso Layout Editor installation. This library contains examples of peells built from ROD constructs including:

- A variety of transistors
  - Simple and multi-fingered MOS devices
  - Bent MOS devices
  - Simple bipolar devices
- Several resistor cells
- A capacitor cell
- An inverter

Documentation is available in CDSDoc to guide you through the library installation and to describe the function of each pcell:

Sample Parameterized Cells Installation and Reference

#### **Purpose of Sample Pcells**

The sample peells are not intended to be immediately production worthy for every design methodology, process, and application. Rather, these are examples from which you can learn the versatility of ROD and a multitude of parameterized cell concepts. In many cases, however, you can modify these cells to suit your particular needs.

#### **Installing Sample Pcells**

Before you can use the sample pcells, you must install them into a library. During the installation process, you have the opportunity to specify the layer definitions and design rules of your technology file. The installation script defines new device classes in your technology file and defines devices for each new class.

## **Concepts in Sample Pcells**

The sample pcell library demonstrates a number of advanced pcell concepts:

- CDF properties
- Stretch handles
- Pcell code encapsulation
- Message handling for automatic abutment in Virtuoso XL

The example peells library offers an excellent learning experience in that it provides you with functioning examples in your technology of the concepts mentioned above.

You have already covered the first two topics in the advanced concepts list, so we now focus on pcell code encapsulation and message handling for automatic abutment in Virtuoso XL.

# **Pcell Code Encapsulation**

Typically, the body of a *pcDefinePCell* statement includes all code necessary to define the structure and behavior of a given pcell. However, you can simply call a single function as the body of the pcell. Hence, the code to define the pcell's structure and behavior can be *encapsulated* in a function you write:

) ; procedure

```
; Typical pcell code.
                                      ; Encapsulated pcell code.
pcDefinePCell(
                                      pcDefinePCell(
  list( ... ) ; Cell ID.
                                        list( ... ) ; Cell ID.
  ( ... ) ; Formal
                                        ( ... ); Formal parameters.
parameters.
                                        MYpcellCreate( ... )
  let((... tmpVars ...)
                                      ) ; pcDefinePCell
    rodCreateRect(...)
     rodAlign(...)
                                      procedure(MYpcellCreate( ... )
                                        let((... tmpVars ...)
  ) ; let
                                          rodCreateRect(...)
) ; pcDefinePCell
                                          rodAlign(...)
                                        ) ; let
```

The function you define to build the contents of the pcell is known as a *constructor function*. This function should not rely upon the context of executing within a pcell body. In particular, you should observe these rules as you write constructor functions:

1. One argument to the peell constructor function must be for the target cellview identifier:

```
procedure(MYpcellCreate(cvId ... )
   ...
)
```

2. When you call the constructor function from within the pcell definition, you pass the *pcCellView* variable to this cellview ID argument:

```
pcDefinePCell(
  list( ... ) ; Cell-view.
  ( ... ) ; Formal arguments.
  MYpcellCreate(pcCellView ... )
)
```

3. Behavior of the constructor function must be controlled exclusively by passing peell parameters through constructor function arguments.

```
pcDefinePCell(
  list( ... ) ; Cell-view.
  ( (metalLayer "metal1") (rows 4) ... ) ; Formal arguments.
  MYpcellCreate(pcCellView metalLayer rows ... )
)
```

## **Advantages of Code Encapsulation**

- You can use SKILL development tools, including the SKILL debugger, on the pcell constructor function.
- You can change the behavior of the pcell without re-compiling it—you simply load the new constructor function code.
- You can use the constructor function to create non-pcell layout data.

#### **Use of SKILL Development Tools**

This is perhaps the most significant advantage of pcell code encapsulation. Because the function you write can be executed outside the scope of the pcell body, you can use the SKILL debugger, SKILL profiler, and the other SKILL development utilities in addition to simple development and debugging techniques such as using *printf* within your code.

#### No Need to Re-compile

This advantage allows you to have a single pcell that behaves quite differently depending upon from which file its constructor function is loaded. To obtain similar behavior with the traditional pcell definition method, you must re-compile the cell, possibly causing adverse effects for others using the cell at that moment.

#### **Creating Non-pcell Layout Data**

In some cases, you may want to add layout data directly into a given cellview, rather than adding the layout data in an instance, as is the case when you use pcells. With encapsulated code, you simply call the constructor function with the ID of the destination cellview. By doing so, the constructor function performs its shape creation and other tasks within the destination cellview.

### **Disadvantages of Code Encapsulation**

- Pcell constructor functions must be defined in the current Design Framework II session.
  - **Solution**: Use the *libInit.il* mechanism or code in your *.cdsinit* file to load functions referenced in your pcells.
- Pcell constructor code must follow the library or libraries where it is used.
  - **Solution**: Store needed code within the library directory or enforce a regimented project directory structure in your design flow.
- Pcell instances must be "refreshed" in the current design session when the constructor function changes.
  - **Solution**: Restart design session or execute code to purge instance masters.
- Your design Design Framework II session contains more function definitions.

To use the *libInit.il* mechanism, do the following:

- 1. Create a subdirectory in your library directory with a name such as *pcellSKILL*.
- 2. Place the source file within the *pcellSKILL* subdirectory.
- 3. Create a file named *libInit.il* in the library directory. The system loads the *libInit.il* file automatically when the library is opened.
- 4. Within the *libInit.il* file, add some code similar to this:

To refresh instance masters in the current design session after you have redefined a pcell constructor function, execute code similar to this:


```
foreach(master dbGetOpenCellViews()
  unless(geGetCellViewWindow(master) ; Master not open in a window.
   dbPurge(master) ; Remove master from memory.
)
```

Then use **Window**—**Redraw** in your editor windows.


### **Automatic Abutment in Virtuoso XL**

The Virtuoso XL abutment capability lets you create a connection between two cells overlapping each other without introducing design-rule violations or connectivity errors. The two sets of shapes must include pins connected to the same net.


#### **How Automatic Abutment Works**



1. Before move and before automatic abutment




2. Move the devices to overlap pins and trigger automatic abutment




3. After automatic abutment


#### Three abutment scenarios depending upon connectivity of the devices



A. Same net — no external connections



B. Same net — external connections



C. Different nets


Devices can be abutted only between pins of different instances. Abutment of pins requires the following conditions:

- Both instances must be peells set up for abutment or cells with abutment properties.
- Both instances must be from the same master or have the *abutClass* property. To abut two different cells, you must add the property *abutClass* to the pin of each cell and enter the same abutment class name as the value for each property. If two similar pcells have different parameter values, they have different sub-masters; in that case, abutment works only if they have the same master.
- Both instance pins must be connected to the same net.
- Both instance pins must be defined on shapes of the same layer or on layers that are defined as equivalent layers in the technology file.
- Both instance pins must have opposite abutment directions; for example, *right* for a pin on the cell's right side and *left* for a pin on the cell's left side.
- The shapes of the two pins must be identical, or one of them must be able to be completely contained within the other.
- During placement, the Connectivity Extractor and Auto Abutment options in the Virtuoso XL Options form must be turned on.

## **Abutment Requirements**

The diffusion area on your pcell must have at least three regions:

- Left finger
- Body of the pcell
- Right finger



You must control the creation of the end fingers to include metal and contacts/vias through CDF parameters.

#### Abutment notes:


- Do not change the origin of the pcell during abutment. The origin should remain constant whether abutting or not. Placing it on the lower left corner of the diffusion pin will cause the pcell to "shift" during abutment.
- Do not delete the abutting pins during abutment. You will not be able to restore them.
- If you have special needs like guard-rings, trenches or well/substrate ties, you will need to define your own abutment functions to control both instances during abutment.

# **Abutment Automatic Spacing in Virtuoso XL**


In Virtuoso XL you can assign automatic spacing properties to pins of instances so that if these pins are on different nets or the pins cannot abut for any reason, the software automatically separates the instances by the distance and in the direction you specify. The Virtuoso XL properties to set are:

Property	Value Type	Valid Values
vxlInstSpacingDir	SKILL list	one or more of the following: left, right, top, bottom
vxlInstSpacingRule	float	number > 0

#### With Auto Space turned off



#### With Auto Space turned on



# **Setting Up Cells for Abutment**

You can set up both regular cells and pcells for abutment. In either case, you need to manage these properties on the cell's abuttable pins:

abutFunction

A callback that you create to process abutment and un-abutment.

abutOffset

Sets an offset based on the reference edge.

abutAccessDir

Provides information to make sure the proper edges are abutting.

abutClass

Allows two different cells to abut, even if their master cells are not the same.

You can also place these properties on a cellview to provide abutment function for all pins on the cell. Pins with local values for these properties override the corresponding properties at the cellview-level.

### **Abutment Function**

The abutment function is a user-defined Cadence® SKILL function that is executed before abutment takes place. Auto-abutment passes this function eight arguments in a list made up of the following information in this order:

- 1. The dbld of the cell being abutted
- 2. The dbld of the cell being abutted to
- 3. The dbld of the pin figure of the cell being abutted
- 4. The dbld of the pin figure of the cell being abutted to
- 5. The abutment access direction of pin being abutted (an integer)
- 6. An integer with a valid value of 1 or 2 that indicates connection condition
- 7. An integer specifying auto-abutment events
- 8. A dbld that is the abutment group pointer available to events 2 and 3.

The value of argument five (abutment access direction) has these meanings:

1 = top

2 = bottom

4 = left

8 = right

The value of argument six (connection condition) has these meanings:

1 = pins are connected to the same net and do not connect to any other pin

2 = pins are connected to the same net and the net connects to other pins

The value of argument seven (auto-abutment events) has these meanings:

1 = abutFunction must compute and return abutment offset (in the direction of abutment)

2 = abutFunction must adjust peell parameters for abutment (called before the offset event)

3 = abutFunction must adjust pcell parameters for un-abutment

Argument eight (abutment group pointer) is used to store information so that un-abutment can return pins to their original state. It is a generally accepted method to use the *group* attribute of a cell to hold original parameter values prior to modification by abutment.

### **Abutment Function Return Values**

Abutment function returns different values for different auto-abutment events:


Event 1: Abutment offset event


Abutment function returns either:


- Offset needed to abut the cells in direction of abutment
- A list of two numbers: the above offset and the distance in user units that the abutting cell is moved perpendicularly to the abutting edge.
- **Event 2:** Adjust pcell parameters for abutment event Abutment function returns *t* for success, *nil* for failure.
- Event 3: Adjust pcell parameters for un-abutment event

Abutment function can return anything; the value returned is not used.

# **Auto-Abutment Action Sequence**








- 1. Before abutment
- 2. Abutment is triggered
- 3. Connectivity is accessed Pcellparameters are adjusted Abutment event #2



4. Spacing is calculated
Abutment event #1
Reference edges are spaced



5. Cells are aligned perpendicular to abutment direction

- Abutment event occurs
- Auto-abutment is triggered
- Connectivity is assessed
- Pin permutation takes place
- Pcell parameters are adjusted (event type 2)
- Abutment spacing is calculated (event type 1)
- Cells are spaced in the abutment direction by reference edges
- Cells are aligned perpendicular to the abutment direction

### **Auto-Abutment Process**

When you move and drop an instance such that one of its pins overlaps a pin on another instance in the Virtuoso XL editor, the following events occur.

- 1. Overlapping pins trigger auto-abutment.
- 2. Auto-abutment identifies cells for abutment by master name or class.
- 3. Auto-abutment calls abutFunction.
- 4. If necessary, *abutFunction* adjusts parameters of the pcells and calculates reference edge offsets of the conventional cells.
- 5. Pcells calculate a new configuration based on any parameters changed by abutFunction.
- 6. If the cells can be abutted (the abutment connection condition is 1 or 2), the cells are abutted to the reference edges and the pins are aligned perpendicular to the direction of abutment. If the cells cannot be abutted (the abutment connection condition is 3), they remain in their original configuration.

Perhaps the best way to learn about the events occurring in the abutment process is to trace the flow through an example abut function. You can do this by placing informational statements within the abut function. You will do this as part of the exercises for this section.

### **Abutment Facts**

### Fact—Abutment uses pcell parameters to modify the pcells

Pcells can only be modified by their formal parameters. Abutment is set up through the parameters on the pcell. Abutment functions modify the appropriate parameters on the instances.

### Fact—Abutment works only when using VXL

Abutment requires connectivity information on the placements. If instances are unabutted outside of VXL, the abut function will be called with the unabut parameters. The instances will not reabut until VXL is turned back on.

### Fact—Previously designed pcells may work well in VXL

If the pcells already have pins, they work immediately in VXL and Virtuoso Chip Assembly Router. Update the abutment properties on the pins if abutment is required.

### **Abutment Fiction**

### Fiction—Only pcells can abut

Abutment is triggered by pins on the instance. Any instance with pins can use abutment as long as the pins are set up for abutment. Standard cells can benefit from adding abutment properties to the pins for alignment and spacing.

#### Fiction—ROD must be used in order to have abutment


As long as the pins on the super have the correct properties, it doesn't matter how they were created. Old-style pcells with abutment properties added to the pins will work as well.

#### Fiction—Abutment functions are hard to write or understand

Pcells are manipulated through their parameters. The pcell drawing routines must be aware of the abutment requirements. The abutment functions manipulate only the parameters.

# **Multiple Abutment Pins**

You may define multiple abutment pins in a single device. These pins may trigger different abutment functions depending upon the connection you make. Here is an example containing a guard-ring with pins to assist in abutting with other guard-rings. These pins are in addition to the transistor pins.




### Notes on multiple abutment pins:

- Any pair of pins with the correct properties can trigger auto-abutment. But, once auto-abutment has been triggered, other pins on the same edge that touch pins on the cell it is abutted to will not re-trigger auto-abutment.
- If each pin being abutted has a different *abutFunction* defined, auto-abutment calls only the function defined by the pin in the cell being moved.

### **Lab Overview**

Lab 5-5: Auto-Abutment for Virtuoso XL



# **Creating and Using Qcells (Optional)**

### **Module 6**

# **Module Objectives**

Install and use quick cells (qcells)

## **Terms and Definitions**

Qcell	Quick cells (qcells) are parameterized cells (currently MOS devices, substrate/well ties, cdsVias and MPP guard-rings) designed to be created and used by layout designers who are not programmers.
Qcell guard-ring	Quick cell guard-rings are special types of multipart paths whose ends abut. They are intended to be either p-diffusion or n-diffusion, and are used to enclose one or more objects.

### **Qcell Overview**

What is a qcell? What is the benefit of a qcell?

Quick cells (qcells) are parameterized cells (currently MOS devices, substrate/well ties, cdsVias and MPP guard-rings) designed to be created and used by layout designers who are not programmers. Their advantages are:

- Productivity
  - 100% UI-driven
  - No SKILL programming required
- Usability
  - Intuitive "wizard"-like menus, options and graphical browsers
  - Easy to learn and use
  - Simple storage method (technology file)
- Performance
  - Fast, because of C-based implementation
- Compatibility
  - Between Virtuoso® Layout Editor Turbo (non-connectivity) and Virtuoso XL Layout Editor (connectivity)

Quick cells are parameterized cells that are compiled into the software. You can use them to customize certain features to meet your technology's needs.

# **Qcell and Pcell Comparison**

	Qcell	Pcell
Creation	Wizard	Write a SKILL program
Maintenance	Cadence R&D	Change a SKILL program
Use	Special GUI	Create Instance function
Enhancement	PCR enhancement*	Update a SKILL program
Performance	Faster	Optimize a SKILL program
Devices	Fixed number	Any devices you need

<sup>\*</sup>There is a limited SKILL extension that allows quells to be enhanced by the user that can address new requirements.

Qcells and pcells can be used together in the same design. You can improve performance by using qcells for the standard devices while maintaining flexibility by using pcells for the other devices.

In the lab directory there is a paper that discusses qcell/pcell interoperability and the SKILL extension to qcells.

It is titled Advanced Techniques with Qcells: Abutment and SKILL Interfaces and can be found at


```
~/Skill_PCells_5_1_41/extra/Qcells_ICU2004.pdf
```


The paper was written by Ted Paone and Liang Tao and was presented at the International Cadence Users Group Conference, September 13-15, 2004, in Santa Clara, CA.


# **Qcell Functionality**

How do I access quell functionality?

- In IC, ICOA and VCE 5.1.41
- Required licenses
  - □ The creation and editing of qcells are licensed features through VLE Turbo (product #311) or VXL (product #3000).
  - The installation of qcells does not require a license.







# Defining and Installing Qcells—Overview

■ The quell installation GUI simplifies the task of defining parameterized cells and guard-rings. Access the GUI via:

CIW—Tools—Technology File Manager—QCell

- Device types that qcell currently supports:
  - MOS
  - Substrate/well tie
  - cdsVia
  - MPP guard-ring
- Qcells are stored in the technology file.
  - □ A MOS qcell is defined in the ASCII technology file cdsMosDevice subclass of the devices class.
  - A via, substrate tie, or well tie qcell is defined in the ASCII technology file cdsViaDevice subclass of the devices class.
  - A guard-ring qcell is special MPP and is defined in the ASCII technology file lxMPPTemplates subclass of the lxRules class.
- You need write permission to the technology file to save qcells.

If you want the quells saved permanently, you must save the technology file to disk before exiting the design session. The quell utility saves the technology file:

- Whenever you use Technology File Manager to save the technology file to disk at any time during the design session
- Whenever you delete a quell during a quell install session
- When you exit the design session. The system displays a dialog box asking if you want to save the technology file.

If you opt not to save the technology file, the software displays a dialog box asking if you want to save the cellviews you created during the session. If you opt to save the cellviews, they will be available in subsequent design sessions, but will not appear as qcells. No guard-rings defined during the session will be available because they exist only in the technology file.


### Important

When you delete a quell via the quell installation GUI, the software removes it from both virtual memory and disk. Once deleted, it is irretrievable.

# Qcell cdsMos—Layers

The Layers options define which layers are within the qcell device.

Set the device type and name of the quell to define.




#### Layers definition:

- Only layers defined in the LSW as valid layers are displayed in the cyclic fields.
- If a layer has a function specified in the technology file in the *layerFunctions* subclass of the *layerRules* class, then a cyclic field displays that layer only when its assigned function is appropriate to the layer use in the MOS device.

■ If more than one implant/well layer is needed, click on **Add Implant Layer** or **Add Well Layer** and the form will be expanded with more layers.

### Qcell cdsMos—Rules

Process design rules such as Contact, Minimum Dimensions, Minimum Spacing and Minimum Enclosure are defined for the cdsMos device.




You can move to the next form section without having completed the Rules section of the form. However, if you click the **OK** or **Apply** button on the form with required rules unspecified, a warning dialog box appears with the message "All Rules must be specified" and the cursor is returned to the first empty rule value field.

### Qcell cdsMos—Stretch Handles

The Stretch Handles options tell the quell which features you want stretchable as well as the direction to stretch them.




#### Stretch handle locations on the qcell cdsMos:



### **Qcell cdsMos—Parameter Defaults**

The Parameter Defaults options set the default placement method for the device.




Qcells abut only to other qcells that have the same abutment class and to SKILL pcells with the same abutment class and underlying abutment code. Once the MOS device definition is installed, the information from this field updates the VXL component type data, which you can view in the VXL Edit Component Types form.

#### Illustrations for various row and column selections:


#### Rows Centered:

Any extra space is distributed equally above and below the rows.




#### Columns Centered:

Any extra space is distributed equally to the right and the left of the columns.




#### Rows Bottom:

Any extra space is placed below the rows.




#### Columns Towards Gate:

Any extra space is placed to the side of the columns closest to the gate.




#### Rows Top:

Any extra space is placed above the rows.



#### Columns Away From Gate:

Any extra space is placed to the side of the columns furthest away from the gate.




SKILL Development of Parameterized Cells

## Qcell cdsVia—Layers

To define the type of cdsVia and the layers it will use:

- Set the device type and the name of the qcell to define the qcell device.
- Specify the layers. Layers required for substrate/well ties or vias are diffusion, contact, metal, and/or implant.




The cdsVia devices need to be defined. For each type of via, define whether it is a substrate contact or a via between two metals (also between poly and metal).

The Stretch Handles option is grayed out for the cdsVia device type.

### Qcell cdsVia—Rules

Rules are defined for the via or contact to control the design rules of your technology.




#### Process design rules for the via:

- Substrate tie
- Well tie
  - Contact
  - ☐ Diffusion minimum spacing
  - ☐ Minimum enclosures
  - Optional directional enclosure overrides

### **Qcell cdsVia—Parameter Defaults**

The Parameter Defaults options set the default via array size, position and class for the device.




Parameter defaults include such things as the number of rows and columns, the justification and the abutment class. As you place the cdsVia qcell, you have the option to change the setting for that one placement to fit the needs of that area of the layout that you are working with.

## **Qcell Guard-Ring—Overview**

What is a qcell guard-ring?

Qcell guard-rings are special types of multipart paths whose ends abut. They are intended to be either p-diffusion or n-diffusion, and are used to enclose one or more objects. Each guard-ring consists of a master path with flush or offset ends, one set of subrectangles, and one or two offset subpaths, on any layer or layers.


**Note:** The technology file associated with the library you are using might contain guard-rings and other types of MPPs created outside of the qcell software. As long as the MPP matches qcell guard-ring specifications, the guard-ring is recognized by qcell.



Qcell guard-rings are commonly used to assist with MOS layout where the designer would want to protect critical devices.

# **Qcell Guard-Ring—Layers**

The Layers setting defines which layers will be used within the device you are installing.




Qcell guard-rings can be set up for as many unique guard-ring types that you will use within your technology. They are customizable from the GUI.

## **Qcell Guard-Ring—Rules**

You can set the process design rules for the guard-ring. Rules include:

- Contact spacing and dimensions
- Diffusion enclosing contact and/or diffusion width
- Metal1 width and/or offset




The qcell guard-ring rules lets you customize the object to adhere to their technology's rules.

## **Qcell Guard-Ring—Parameter Defaults**


Parameter defaults can be used to customize the settings to your preferences. Defaults that can be set for the guard-ring are:


- Diffusion path choppable
- Contact spacing method
  - Distribute
  - Minimum



All parts of the guard-ring (such as Metal, Contact and Implant layers) other than Diffusion (master path) are always choppable.

The illustration shows two types of contact spacing methods: distributed and minimum.






**Distributed Contact Spacing** 

**Minimum Contact Spacing** 

#### **Qcell—Rules Browser**

The Rules Browser displays a graphical representation of a generic qcell.


An arrow indicates the physical area where the rule applies: a white arrow for a required rule and a red arrow for an optional rule.



The Rules Browser assists in creating the rules needed for your device.

## **Qcell—View Device Configuration**

You can click **View Device Configuration** at any time to display a window showing the quick cell as it would appear with the current settings. The button is enabled after you select the layers for qcell. Click it again whenever the qcell is modified.




Click on **View Device Configuration** to refresh the open View Device Configuration window.

Using the right mouse to select an area and zoom in on it.

### **Qcells—Create Device**

The **Create—Device** command allows you to instantiate and rapidly create chains of abutted devices. It also allows you to insert substrate ties in chains of devices.




Auto Complete Contact only affects the two ends of the device chain.

Qcell folding, chaining and abutment only work within VXL since connectivity is required.

The highlighted box shows you where the next action icon will go. Clicking on a non-highlighted box makes it the highlighted box. Clicking again on the highlighted box toggles the source and drain values.

**Insert**, **Delete**, and **Delete All** allow you to modify the chain. For example, the **Insert** button inserts a display icon to the left of the highlighted box. When you click the **Insert** button, an empty highlighted box is added to the left of the selected box. Once you click a new action icon, the empty highlighted box immediately reflects the values of the Finger Definition section of the form.




## **Qcells—Create Guard-Ring**

The **Create—Guard Ring** command places guard-rings around one or more selected objects in your layout.


The command treats a chain of instances as a single object. It evaluates the selected set and puts in as many guard-rings as are design rule correct.




Larger area: Two guard-rings created



Limited area:
One guard-ring created






To create guard-rings for multiple objects:


- 1. Choose Create—Guard Ring.
- 2. Fill in the command options form, then click on **Apply**. The system prompts you to select objects.
- 3. Select the first figure. Press the **Shift** key while selecting additional figures. The outline of the guard-ring you are creating is displayed around the selected objects.
- 4. When selection is complete, press **Return**.

## **Editing Placed Qcells**


You can edit a single quell or a chain of quells or pieces of the abutted chain.



Press the middle mouse button for a shortcut



Adjust the cellview placement of a chain of instances after the **Subtract Finger** or **Add Finger** command is used. The commands toggle to **Anchor to Right** when clicked. The example is a chain of three instances: I1, I2, and I3.



This is a chain of 3 instances, instance I2 has 3 fingers. If the user selects I2 and uses the Subtract Fingers command, I2 will have 2 remaining fingers.

This is the result of Quick Cell Anchor => Left. I1 will remain in place, I2 will compress, and I3 will move to the left.

This is the result of Quick Cell Anchor => Right. I1 will move to the right, I2 will compress, and I3 will remain in place.


## **Editing Qcells—Options**

The Move, Copy, Delete, and Stretch commands are enhanced to interactively support individual devices, entire device chains or pieces of abutted device chains.

Chain mode can be enabled from within the Move, Copy, Delete or Stretch commands by pressing the **F3** key.



Chain mode is also accessed with the middle mouse button in the layout window while you are the Move, Copy, Delete or Stretch commands.



Chain mode chains devices together, sharing the source or drain of the device. Chain mode options are:

- All—Moves, copies, stretches or deletes all devices in the chain, even if only one device is selected.
- Selected—Moves, copies, stretches or deletes only the currently selected devices in the chain.
- Selected Plus Left—Moves, copies, stretches or deletes the currently selected devices and all devices to the left of the selected devices in the chain.
- Selected Plus Right—Moves, copies, stretches or deletes the currently selected devices and all devices to the right of the selected devices in the chain.

### **Lab Overview**

Lab 6-1: Installing cdsMos Qcells

Lab 6-2: Installing cdsVia Qcells

Lab 6-3: Installing Guard-Ring Qcells

Lab 6-4: Creating Devices

Lab 6-5: Editing Devices



# **Technology File and Translator Information**

#### **Appendix A**

## **Module Objectives**

- Understand Design Framework II technology file requirements for Virtuoso® XL Layout Editor
- Define MPPs in the technology file
- Understand the translation rules for Virtuoso Chip Assembly Router (VCAR).

# **DFII Technology Files—Controls**

#### techParams

Basic rule

```
( NWELL_width 2.0 )
```

- Equates data to a name in the techfile
- Holds design rules, layer mapping, higher-level parameters
- Used throughout the tech file
- Single place for changes
- Complex rules

```
( minWidth "nwell" techParam( "NWELL_width" ) )
```

Extractable through SKILL

```
techGetTechParam( tfId "NWELL_width" )
```

# DFII Technology Files—layerRules

### equivalentLayers

Layers which are created by the same manufacturing step

Abutment only works for the same or equivalent layers

```
( M1 Mlvdd Mlvss Mlagnd Mlvcc )
( ndiff pdiff ) ;; Abutting substrate tie
```

# DFII Technology Files—layerRules (continued)

### viaLayers

- Defines connectivity for extractor
- Defines connectivity for leMarkNet
- Via layer necessary—pseudo layer for local interconnect
- VXL extractor and leMarkNet layers can conflict

```
list( "poly" "contact" "metall" )
;; Local interconnect layer - connects directly to diff
  list( "LI" list( "LI" "boundary" ) "diff" )
```

# DFII Technology Files—physicalRules

### spacingRules

- minWidth
  - Used for path command and MPPs
  - Used by compactor
- minSpacing
  - Used for MPP subrectangles
  - Used by compactor
- Extracted from tech file for pcell design rules

```
pw = techGetSpacingRule( tfId "minWidth" "poly" )
pcs = techGetSpacingRule( tfId "minSpacing" "poly" "cont")
```

# DFII Technology Files—physicalRules (continued)

### orderedSpacingRules

- minEnclosure
  - Used by compactor
  - Extracted from tech file for pcell design rules

```
mlovV1 =
techGetOrderedSpacingRule( tfId "minEnclosure" "metall" "vial" )
```

# DFII Technology Files—electricalRules

#### characterizationRules

- areaCap
- sheetRes
- minCap
- maxCap
- Extracted from tech file for pcell process characteristics

```
sheetRho =
techGetElectricalRule( tfId "sheetRes" techGetParam( tfId "poly_layer"
) )
```

# **DFII Technology File—Devices**

Pcells can be created as devices within the technology file.

This has the advantage of being able to create a device class with class parameters as well as formal parameters.

The class parameters can be used to modify the device for a different type, such as the class MOS with the class parameters to define an NMOS or PMOS.

This has some advantages when installing generic pcells with all modifications done from a script.

However, debugging pcells defined as devices is much harder because you have to track the problem to the specific section causing the problem and are constantly reloading the tech file.

Do not define devices other than contacts in the technology file.

# DFII Technology File—Devices (continued)

## symContactDevice

- Symmetrical via
- Used by the path stitch command
- Exported to the router

### symEnhContactDevice

- Asymmetrical via
- Can be used by stitch if no symContactDevice is defined for the layer pair
- Exported to the router

# DFII Technology File—Devices (continued)

### ruleContactDevice

- Fixed size
- Used by routers

### symPinDevice

Square symbolic pins

### symRectPinDevice

Rectangular symbolic pins

# DFII Technology File—IxRules

### **IxExtractLayers**

- List of layers for the extractor
- The more layers in the extract list, the slower the extraction
- Conductor and via layers must be in the extract list
- If the layer is used for an abuttable pin, it must be in the extract list

```
lxExtractLayers(
  ( ndiff pdiff poly poly2 cont metal1 via1 metal2 via2 metal3 via3 metal4
)
```

# DFII Technology File—IxRules (continued)

### **IxNoOverlapLayers**

- Defines forbidden overlap layer pairs for the extractor
- IxBlockOverlapCheck overrides the IxNoOverlapLayers within a cellview, such as poly overlapping diffusion to form a gate

```
lxNoOverlapLayers(
( poly ndiff )
( poly pdiff )
( via1 via2 )
( via1 via3 )
)
```

# DFII Technology File—IxRules—MPPs

### **IxMPPTemplates**

- Defines MPP saved templates
- nil values default to technology file min spacing and width for the layer
- Will be able to be defined in SKILL in a future release

```
( name { masterPath } { offsetSubPaths } { encSubPath } { subRects
} )
```

#### masterPath:

```
( layer [ width ] [ choppable ] [ endType ] [ beginExt ] [ endExt
] [ offset ] { connectivity } )
```

# DFII Technology File—IxRules—MPPs (continued)

### offsetSubPath:

```
( layer [ width ] [ choppable ] [ separation ] [ justification ]
[ beginOffset ] [ endOffset ] { connectivity } )
```

#### encSubPath:

```
( layer [ enclosure ] [ choppable ] [ separation ] [ beginOffset ]
[ endOffset ] { connectivity } )
```

#### subRects:

```
( layer [ width ] [ length] [ choppable ] [ separation ]
[ justification ] [ space ] [ beginOffset ] [ endOffset ]
{ connectivity } )
```

### connectivity:

```
( [ I/O type ] [ pin ] [ accessDir ] [ pinLabel ] [ height ]
[ layer ] [ labelJust ] [ font ] [ drafting ] [ orient ]
[ refHandle ] [ labelOffset ] )
```

## DFII Technology File—IxRules—MPPs (continued)

```
( Ngaurdring
( ( "ndiff" "drawing" ) 0.75 nil )
( ( "metall" "drawing" ) 0.45 t nil nil -0.15 ) )
 nil
((( "cont" "drawing") nil nil t nil nil nil -0.25))
( M1sheild
    ( ( "metall" "drawing" ) nil nil )
    ( ( "metall" "drawing" ) nil t 0.6 left -1.25 -1.25 "jumper"
"AGND!" )
       ( "metall" "drawing") nil t 0.6 right -1.25 -1.25 "jumper"
"AGND!" ) )
  nil
  nil
```

## **VCAR Rules**

- VCAR rule file is used for translation between VXL and VCAR
- Use technology file functions in rules files to base the rules on the current technology file
- Different VCAR rule files can be used for different regions and levels
  - Digital device level
  - Analog device level
  - Block level
  - Chip assembly level

# **VCAR Rules—Layers**

### iccLayers

- Translation layers—master layers
- Order determines router palette order
- Reference layers should be at bottom of list
- Cut layers must be placed between the corresponding routing layers
- Function: metal, cut, reference, polysilicon, user-defined
- Direction: horizontal, vertical, orthogonal, off

```
list( layerPurposePair function direction width spacing reference?
translate? )
```

# **VCAR Rules—Layers Example**

### iccLayers

```
list( '( "metal4" "drawing" ) "metal" "horizontal" 0.35 0.35 nil t )
list( '( "via3" "drawing" ) "cut" "off" 0.25 0.25 nil t )
list( '( "metal3" "drawing" ) "metal" "horizontal" 0.30 0.30 nil t )
list( '( "poly" "drawing" ) "polysilicon" "orthogonal" 0.25 0.25 nil t )
list( '( "ndiff" "drawing" ) "n_diffusion" "off" 0.35 0.35 t nil )
```

## VCAR Rules—Vias

#### iccVias

- Specifies cell views and local interconnect vias
- Regular via cell views
  - Cell view template for via arrays
  - Two-item list

```
list( list( library cellName viewName ) translate? )
```

- Local interconnect vias
  - Self conducting layers
  - Three-item list

```
list( pseudoViaName list( layer1 layer2) translate? )
```

# VCAR Rules—Via Example

### iccVias

# VCAR Rules—Equivalent Layers

#### iccEquivalentLayers

- List of layers the router should treat as equivalent
- Master layer is defined in the iccLayers structure
- Layer purpose pair of equivalent layers

list( masterLayer equivLayer1 equivLayer2 ... )

```
list(
    '( "ml" "drawing" ) '( "mlvdd" "drawing" ) '( "mlvss" "drawing" ) )
list( '( "poly" "drawing" ) '( "poly" "pin" ) )
```

### VCAR Rules—Boundary Layers

### iccBoundaryLayers

- Defines regions within which the router is permitted to route
- Set for routing and via layers

list( masterLayer boundaryLayer clearance )

```
list( list( "metall" "drawing" ) list( "prBoundary" "boundary" ) 0.0 )
list( list( "via" "drawing" ) list( "prBoundary" "boundary" ) 1.0 )
```

### VCAR Rules—Scopes

### iccScopes

- Names scopes for keepout and conductor rules
- Assigns the scopes to named cellviews
- Rules, with appropriate depth values, apply to the particular scope
- UNIX regular expressions can be used in names
- nil matches all names
- Final scope definition takes precedence

```
list( scopeName
list( libName )
list( libName cellName )
list( libName cellName viewName )
)
```

## VCAR Rules—Scopes Example

### iccScopes

```
list( "blackBox" ;; Block rules
  list( "design" )
  list( "blocks" nil "layout" )
)
list( "stdCell" ;; Standard cell rules
  list(
    list( "stdCellLib" nil "abstract" )
    list( "stdCellLib" nil "layout" )
)
```

### VCAR Rules—Keepouts

### iccKeepouts

- Keepouts are generated automatically by default
- Special keepouts can be defined or generated
- Boolean operations create keepouts

```
AND
ANDNOT
OR
XOR
SIZE
=> (Assignment)
```

### VCAR Rules—Keepouts (continued)

### iccKeepouts

- Scope can be a defined scope name, a library cell view name, or nil for the global scope
- Keepout types are via or routing

```
( list( scope list(
        list( logicalOperator
            list( layer1 [ layer2 | size ] )
            keepoutLayer type translate?
        )
   ;; More keepout definitions for this scope
        ) keepoutDepth
)
```

### VCAR Rules—Keepouts Example

### iccKeepouts

### VCAR Rules—Conductors

#### iccConductors

- Conductors define MOSFET conductor shapes
- Special Boolean operation C-NOT
- Sets shape as a keepout, not a conductor
- Connectivity ignored during routing

```
( list( scope
    list( logicalOperator
        list( layer1 [ layer2 | size ] )
        conductorLayer "MOSFET" translate?
    )
    conductorDepth
)
```

# VCAR Rules—Conductors Example

#### iccConductors

```
list( "MOSdevices"
    list(
       list( "c-not" list( '( "ndiff" "drawing" )
             '( "prBoundary" "boundary" ) )
         ( "ndiff" "drawing" )
         "routing" t )
       list( "c-not" list( '( "pdiff" "drawing" )
             '( "prBoundary" "boundary" ) )
       ( "pdiff" "drawing" )
        "routing" t )
    32
```