Performance: Digital Data, Analog Signals

Radhika Sukapuram

September 10, 2020

Radhika Sukapuram Lecture 7 September 10, 2020 1 / 16

Performance of various modulation schemes

- Measured by the bandwidth of the modulated signal (not the channel)
- ullet -depends on a factor r^{-1} , which is determined by the modulation and filtering process
- Filters are used to filter out unwanted frequency components
- 0 < r < 1

 1 Don't confuse this with r=no of data elements / no of signal elements $\frac{1}{2}$ $\frac{1}{2}$ $\frac{1}{2}$ $\frac{1}{2}$

Radhika Sukapuram Lecture 7 September 10, 2020 2 / 16

Performance of various modulation schemes

- ASK and PSK, and under some assumptions, FSK: $B_T = (1 + r)R$ where R is the bit rate
- MPSK: $B_T = \frac{1+r}{L}R = \frac{1+r}{\log_2 M}R$ where L is the number of bits encoded per signal element, M is the number of signal elements
- MFSK: $B_T = \frac{(1+r)M}{\log_2 M} R$
- Bandwidth efficiency: $\frac{R}{B_T}$

Question

If a modulation scheme is highly bandwidth efficient, it means that

- (A) it can send a higher number of bits per unit of bandwidth
- (B) it can send a lower number of bits per unit of bandwidth

Performance of various modulation schemes

- ASK and PSK and under some assumptions, FSK: $B_T = (1 + r)R$ where R is the bit rate
- MPSK: $B_T = \frac{1+r}{L}R = \frac{1+r}{\log_2 M}R$ where L is the number of bits encoded per signal element, M is the number of signal elements
- MFSK: $B_T = \frac{(1+r)M}{\log_2 M} R$
- Bandwidth efficiency: $\frac{R}{B_T}$

	r=0	r = 0.5	r=1
ASK	1.0	0.67	0.5
Multilevel FSK			
M = 4, L = 2	0.5	0.33	0.25
M = 8, L = 3	0.375	0.25	0.1875
M = 16, L = 4	0.25	0.167	0.125
M = 32, L = 5	0.156	0.104	0.078
PSK	1.0	0.67	0.5
Multilevel PSK			
M = 4, L = 2	2.00	1.33	1.00
M = 8, L = 3	3.00	2.00	1.50
M = 16, L = 4	4.00	2.67	2.00
M = 32, L = 5	5.00	3.33	2.50

E_b/N_0

- E_b/N_0 : the ratio of signal energy per bit to noise power density per hertz
- A parameter related to SNR that is more convenient for determining digital data rates and error rates
- Bit Error Rate is a function of E_b/N_0

Energy = Power * time

Energy per bit in a signal (analog or digital) that contains binary digital data, $E_b = ST_b$

S: signal power, T_b : time required to send 1 bit. Since $R = \frac{1}{T_b}$, where R is the data rate, $E_b = \frac{S}{R}$

$$\frac{E_b}{N_0} = \frac{S}{N_0 R} = \frac{S}{kTR}$$



Radhika Sukapuram Lecture 7 September 10, 2020 6 / 16

Why is E_b/N_0 important?

- E_b/N_0 : the ratio of signal energy per bit to noise power density per hertz
- Bit Error Rate is a **decreasing** function of E_b/N_0

$$\frac{E_b}{N_0} = \frac{S}{N_0 R} = \frac{S}{kTR}$$

- As the bit rate R increases, the transmitted signal power must increase relative to noise, to maintain the required E_b/N_0
- If the data rate were doubled, the bits would be more tightly packed together, and the same passage of noise might destroy more bits

◆ロト ◆個ト ◆差ト ◆差ト 差 めるの

Question

For binary phase-shift keying $E_b/N_0=8.4dB$ is required for a bit error rate of 10^{-4} (1 bit error out of every 10,000). If the effective noise temperature is 290 K (room temperature) and the data rate is 2400 bps, what received signal level is required? Express the answer in dBW. $k=1.38*10^{-23}J/K$

Relating E_b/N_0 to SNR

$$\frac{E_b}{N_0} = \frac{S}{N_0 R}$$

 N_0 is the noise power density in watts per hertz.

The noise N in a signal with bandwidth B is $N = BN_0$.

Substituting for N_0 ,

$$\frac{E_b}{N_0} = \frac{S}{N_0 R} = \frac{SB}{NR}$$

Relating E_b/N_0 to Spectral Efficiency

As per Shannon's formula, $C = B \log_2(1 + S/N)$. That is, $\frac{S}{N} = 2^{C/B} - 1$

$$\frac{E_b}{N_0} * \frac{R}{B} = \frac{S}{N}$$

Therefore $\frac{E_b}{N_0} = \frac{B}{R} * \frac{S}{N} = \frac{B}{R} (2^{C/B} - 1)$

Assuming R = C,

$$\frac{E_b}{N_0} = \frac{B}{C}(2^{C/B} - 1)$$

This relates the achievable spectral efficiency C/B to E_b/N_0

10 / 16

Radhika Sukapuram Lecture 7 September 10, 2020

Question

For constant signal-to-noise ratio, an increase in data rate

increases the error rate

(B) decreases the error rate

(C) has no effect on the error rate

Eb of

BER


Bandwidth Efficiency for MFSK and MPSK

	r=0	r = 0.5	r=1
ASK	1.0	0.67	0.5
Multilevel FSK			
M = 4, L = 2	0.5	0.33	0.25
M = 8, L = 3	0.375	0.25	0.1875
M = 16, L = 4	0.25	0.167	0.125
M = 32, L = 5	0.156	0.104	0.078
PSK	1.0	0.67	0.5
Multilevel PSK			
M = 4, L = 2	2.00	1.33	1.00
M = 8, L = 3	3.00	2.00	1.50
M = 16, L = 4	4.00	2.67	2.00
M = 32, L = 5	5.00	3.33	2.50

Lecture 7


12 / 16

Theoretical Bit Error Rate for MFSK and MPSK



- For MFSK, BER decreases as M increases
- For MFSK, Bandwidth efficiency decreases as M increases
- For MPSK, BER increases as M increases
- For MPSK, Bandwidth efficiency increases as M increases
- For both, there is a tradeoff between bandwidth efficiency and BER

BER for FSK, ASK, PSK, and QPSK



What is the bandwidth efficiency for FSK, ASK, PSK, and QPSK for a bit error rate of 10^{-7} on a channel with an SNR of 12 dB? For FSK and ASK, $(\frac{E_b}{N_c})dB$ =14.2dB

$$\frac{E_b}{N_0} * \frac{R}{B} = \frac{S}{N}$$

$$\frac{R}{B_T} = \frac{S}{N} / (\frac{E_b}{N_0})$$

Radhika Sukapuram

Lecture 7

September 10, 2020

14 / 16

Bandwidth efficiency for FSK, ASK, PSK, and QPSK

$$(\frac{R}{B_T})dB = (\frac{S}{N})dB - (\frac{E_b}{N_0})dB$$

For FSK and ASK, $(\frac{R}{B_T})dB = 12dB - 14.2dB = -2.2dB$

$$\left(\frac{R}{B_T}\right) = 0.6$$

Similarly, for PSK,

$$\left(\frac{R}{B_T}\right) = 12dB - 11.2dB = 0.8dB$$

$$\left(\frac{R}{B_T}\right) = 1.2$$

For QPSK, since the modulation rate determines the bandwidth and it is twice that of the data rate for PSK,

$$\left(\frac{R}{B_T}\right) = 2.4$$

Bandwidth efficiency for FSK, ASK, PSK, and QPSK

- ASK and FSK exhibit the same bandwidth efficiency
- PSK is better, and even greater improvement can be achieved with multilevel signaling.

16 / 16