# Monolith - User Manual

# Firmware 0.0.1



# **Dictionary**

- CV control voltage
- FM frequency modulation
- VOCT voltage per octave (pitch CV)

### Hardware Specs

- 14 HP
- 35 mm deep
- 150 mA +12V
- 30 mA -12V
- 0 mA 5V

### Usage

monolith is a pitch-shifter reverb inspired by west coast synthesis techniques. It utilizes a time-domain based exponential FM algorithm that acts as a shimmer.

### Inputs:

Note: CV inputs do NOT have a circle graphics around their hex nuts

- **in I and in r** audio input; left will be converted from mono to stereo input if the right input CV jack remains unplugged.
- **blend** knob and CV for controlling the fade between the dry and FM effect audio signals.
- **dj filter** knob and CV for controlling the reverb delay line filtering.
- wet knob and CV for controlling the reverb decay
- mod knob and CV for controlling the scale of FM modulation. A low mod value will correspond with microtonal pitch shifts. high mod values correspond with multiple octave shifts.
- **on** button, CV gate and LED for toggling on/off FM modulation. when FM modulation is turned on, the FM modulator oscillator is reset.
- quant button, CV gate and LED for toggling on/off FM pitch quantization.
- freq and v/oct knob and CV for controlling the frequency of the FM modulator oscillator. This control also influences reverb pre-delay.
- **shape** knob and CV for controlling FM modulator oscillator shape. shape wavetable transitions from sine wave (8 o'clock) to triangle wave (12 o'clock) to square wave (4 o'clock).
- clock CV gate and LED for tempo syncing modulator oscillator period.

### Outputs:

Note: CV outputs have a circle graphic around their hex nuts

- out I and out r audio output
- gate CV gate out and LED that are period synced with the FM modulator oscillator. The period of this gate can be reset by turning off and on the FM shimmer effect. Changes to the FM modulator oscillator frequency will cause this gate to move in and out of phase with an input clock signal.

#### Additional Resources

https://github.com/rawyawmedia/eurorack/tree/main/firmware