

Amplifier Characterization by doing harmonic load pull and large signal measurements




European master distributor of:



Maury Microwave

Your Calibration, Measurement & Modeling Solutions Partner!




AMCAD Engineering

Advanced Modeling for Computer-Aided Design



Agenda



- Considerations
- Setup and calibration of Vector receiver load pull configuration
- Harmonic vector receiver loadpull
- Large signal and time domain

Passive & hybrid active vector-receiver load pull

- Measures vector incident and reflected (a_x and b_x) waves
- Enables calculation of $P_{in,del}$, Power Gain (G_p) and Power Added Efficiency (PAE)
- Measurements performed at calibrated DUT reference plane


$$P_{in,del} = \frac{1}{2}(|a_1|^2 - |b_1|^2) = \frac{1}{2}|a_1|^2(1 - |\Gamma_{in}|^2)$$

$$P_{out} = \frac{1}{2}(|b_2|^2 - |a_2|^2) = \frac{1}{2}|b_2|^2(1 - |\Gamma_{load}|^2)$$


$$G_p = \frac{P_{out}}{P_{in,del}} = \frac{|b_2|^2(1 - |\Gamma_{load}|^2)}{|a_1|^2(1 - |\Gamma_{in}|^2)}$$

$$PAE = \frac{P_{out} - P_{in,del}}{P_{DC}}$$

Passive VRLP Configuration




Hybrid active VRLP Configuration (high power, high gamma applications)



VRLP setup considerations

Choice of the measurement mode (CW or Pulsed)

- CW means power is always on during measurement
- CW is easy to setup since no timing / triggering is required
 - Relatively simple instruments can be used
- CW is mainly used for amplifier characterization /validation on circuit level
- Pulsed means short RF-Pulses; ~100µs with a duty cycle of 10%
- Pulsed is more difficult to setup due to:
 - Timing and triggering
 - Bandwidth filter (NBF or WBF)
 - Choice of equipment
 - VNA with internal pulse modulators or not
 - Source with pulse RF-option or use CW source with external modulator
 - Power meter with pulsed measurement capability
 - DC Power supply or SMU with pulse capability



Fixturing

As important as the rest of a load pull! It can make and break measurement results.

Consideration to take:

- Water cooling avoids thermal effects
- Integrated biasing on fixture avoids instabilities
- 50Ω to 10Ω impedance transformation increases power transfer
- High quality connectors for low insertion loss
- Include TRL Calibration Kit
- Etc.

Almost every loadpull configuration requires a custom fixture




Wideband vs Narrowband detection

Wideband detection (WBF) is a synchronous detection; A pulse acquisition trigger is required.

Advantages:

- Fast Measurement Speed
- No loss of dynamic range in function of the duty cycle
- Acquisition window within the pulse is defined. No transient effects take into account (overshoot, rise time, fall time, ringing, ...)



Disadvantages:


- Higher Noise Floor due to the wider IFBW (Dynamic Range = $f(\text{IFBW})$, Averaging) = $f(\text{Ton})$)
- Pulse Width limitations. As pulse width gets smaller, the spectral energy spreads out.
 - IF bandwidth ($=1/\text{Ton}$) has to be high compared to the Pulse Width (e.g. : $\text{Ton}=100 \text{ usec} \Rightarrow \text{IFBW}=1/(\text{Ton}) > 10\text{KHz}$)

Wideband vs Narrowband detection

Narrowband detection (NBF) is an asynchronous detection.; A pulse acquisition trigger is not required.

Advantages:

- No lower pulse-width limitations
- Measurement dynamic range is sufficiently high for 1% to 100% of duty cycles




Disadvantages:

- Measurement dynamic range decreases as duty cycle decreases. Average power of the pulses gets smaller, resulting in less SNR (Dynamic range degradation = $20 \cdot \log(\text{duty cycle})$)
- Higher PRF is, slower measurement speed will be but has to be high compared to the IF bandwidth
(e.g. : $T=1\text{msec} \Rightarrow \text{IFBW}=1/(20 \cdot T)= 50\text{Hz}$; $T=10\text{msec} \Rightarrow \text{IFBW}=5\text{Hz}$)
- No acquisition windows within the pulse is defined. Possibility to measure wrong results in function of the transient effects (overshoot, rise time, fall time, ringing, ...) => Average Pulse measurement


Bench Calibration process

12 Terms error model with classic VNA Calibration



- 10 terms error + 2 terms error for isolation (optional)

8 terms error model




- 8 terms error model applicable only in forward

Bench Calibration process

8 Terms error model

1st step :
UOSM Calibration between
 P_{1DUT} & P_{2DUT}

- Vectorial correction allow to correct only wave ratio
- $A_1/B_1, A_2/B_2\dots$ real/imaginary corrected
 - $\text{Mag}(A1), \text{Mag}(B2)\dots ?$




Coefficient $e_{00}, e_{11}, e_{10}, e_{01}, e_{22}, e_{33}, e_{32}, e_{23}$

$$\begin{pmatrix} A_1 \\ B_1 \end{pmatrix} = \begin{pmatrix} -\Delta e_{in} & e_{11} \\ -e_{00} & 1 \end{pmatrix} \cdot \begin{pmatrix} A_0 \\ B_0 \end{pmatrix}$$


$$\begin{pmatrix} A_2 \\ B_2 \end{pmatrix} = \begin{pmatrix} -\Delta e_{out} & e_{22} \\ -e_{33} & 1 \end{pmatrix} \cdot \begin{pmatrix} A_3 \\ B_3 \end{pmatrix}$$

Bench Calibration process

Power Calibration



Mag(A1), Mag(B2)...
Arg(A1), Arg(B2)... ?



Coefficient $|e_{10}|$


Bench Calibration process

Phase Calibration

1st step :
UOSM Calibration between
 P_{1DUT} & P_{2DUT}

2nd step :
Power Calibration between
 P_{1DUT} ou P_{2DUT}

3rd step :
Phase Calibration between
 P_{1DUT} ou P_{2DUT}



Measin3 A_{HPR1}

Refin1 A_1


Refin4 A_4

Measin1 B_1

Measin4 B_4

Bench Calibration process

Summary



The transmission term $\frac{e_{01}}{e_{32}}$ is calculated from the thru measurement. Using the assumption that the thru is reciprocal ($S_{12} = S_{21}$) it can be shown that [5]:

$$\frac{e_{01}}{e_{32}} = \pm \sqrt{\frac{S_{12M}(e_{00}e_{11} - \Delta_X)}{S_{21M}(e_{22}e_{33} - \Delta_Y)}} \quad (1)$$

$$\begin{bmatrix} b_1 \\ b_2 \\ a_1 \\ a_2 \end{bmatrix} = \frac{1}{e_{01}} \begin{bmatrix} 1 & 0 & -e_{00} & 0 \\ 0 & k & 0 & -ke_{33} \\ e_{11} & 0 & -\Delta_X & 0 \\ 0 & ke_{22} & 0 & -k\Delta_Y \end{bmatrix} \begin{bmatrix} b_0 \\ b_3 \\ a_0 \\ a_3 \end{bmatrix}$$

$$|e_{01}|^2 = \frac{|b_0 e_{11} - a_0 \Delta_X|^2 - |b_0 - a_0 e_{00}|^2}{P_{meter}}$$

$$\varphi(e_{01}) = \varphi\left(\frac{b_0 - b_0 \Gamma_R e_{11} - a_0 e_{00} + a_0 \Delta_X \Gamma_R}{a_R}\right)$$


where P_{meter} is the power measured by the power meter, a_R the incident wave and Γ_R the reflection coefficient of the phase reference.

Bench Calibration process

Coaxial Calibration

- 3 steps Calibration :




- Full 2 Port Calibration



Bench Calibration process

Coaxial Calibration


- 3 steps Calibration :
- Full 2 Port Calibration



Bench Calibration process

On Wafer Calibration

- 4 steps Calibration :
- Full 2 Port Calibration






Bench Calibration process



On Wafer Calibration

- 4 steps Calibration :
 - Full 2 Port Calibration




- SOL Calibration

Tuner Auto De-embedding





Energy Efficiency

- Radio Frontend (RFFE) performance is defined by 4 headline parameters:
 - Output Power
 - Bandwidth/Frequency
 - Linearity
 - Efficiency
- The first three of those are governed or dictated by specification or regulation
- Efficiency is the market differentiator.
- In battery powered applications, it drives time between-charges, in prime- or higher-powered applications, it drives cooling requirements; size and weight.









Maximum Efficiency of Transistor

Continuous Mode: Class A, AB, B & C based on Biasing point



Maximum Efficiency of Transistor

Switching Mode : Class F, E, J ... Harmonics controlled




Maximum Efficiency of Transistor

Harmonics Load-Pull measurement, over a range of bias condition can explore the device efficiency potential to find the best design topology.



Harmonic VRLP ... when?


- Amplifiers operating under linear (small signal) conditions **do not** produce power at harmonic frequencies, and the output power of a device under test is **linearly proportional** to its input power.
- Highest efficiency is achieved under non-linear (large signal) conditions. Highly non-linear PAs operating in advanced classes (E, F, G, J and their inverses) are commonly used in modern wireless communication systems.
- Amplifiers operating under non-linear (Large signal) conditions **do** produce power at harmonic frequencies, and the output power of a device under test is **non-linearly proportional** to its input power.



Harmonic VR LP -> Wide band amplifiers


It may occur harmonic frequencies ($2f_0, 3f_0\dots$) of the lower frequency band overlap a fundamental frequency in the middle or upper portion of the frequency band.

For a fundamental frequency of, a theoretical ClassF amplifier would require a short at the second and an open on the third harmonic. This will yield in low performance for second- and third fundamental frequencies.




Harmonic LP, does it have effect?

PAE Fundamental LP only



PAE Fundamental plus f2 and f3 harmonic LP




Increase of PAE of 14% by tuning f2 and f3 on optimum load


How to control Load Harmonics

- Harmonic Load Pull with passive tuner
 - One mechanical tuner per frequency
 - To tune f_0 , $2f_0$ & $3f_0$ at the same time = 3 tuners

Multiplexer




Cascaded



- Filters use to separate the f_0 & harmonics signal
 - f_0 & harmonics may be tune independently
 - Triplexer as filter
 - f_0 = low pass filter
 - $2f_0$ = band pass
 - $3f_0$ = high pass filter
- Two or three cascaded tuners
 - $\approx 240,000,000$ available impedances states
 - Multiple states produce any specified f_0 impedance & variety of f_2 , f_3 impedances
 - Robust and advanced algorithm to achieve the combination targeted





How to control Load Harmonics



Harmonic Tuning Method	Advantages	Disadvantages
Multiplexer	<ul style="list-style-type: none">High tuning isolation	<ul style="list-style-type: none">Insertion loss due to the triplexer, reduced matching rangeTriplexer has to be characterized in S-parameters / narrow band
Cascaded Tuner	<ul style="list-style-type: none">Operates over full tuner BW with no setup changesNo loss in front of any tunersFast measurements	<ul style="list-style-type: none">Less tuning isolation

Cascaded Harmonic Tuner

With harmonic tuners loads for f0, f1 and for a three-stage tuner also f2 independently controlled






Harmonic passive & hybrid active VRLP

Advantage: Available (2-port VNA's) like ZVA / ZNA can be used with Harmonic tuners


Maximum reflection of f2 and/or f3 depends on combination of device and setup.

The use of an amplifier overcome losses and the outside of the Smith chart can be reached. Recommended for high power devices



Hybrid active harmonic VR LP with 4-Port ZNA

Power and phase can be controlled independently with a ZNA with four sources. Fundamental control using passive tuners and harmonics using active injection (hybrid load pull)



Advantages:


- No extra investments are required for harmonic tuner tuners
- No extra investments are required for extra sources.
- Most power is handled by passive fundamental tuner. Therefore, very suitable for high power devices.
- Very flexible and stable one-box solution.

Active harmonic VRLP with R&S 4-Port ZNA

Fully active impedance control using multiple signal generators and load amplifiers (active load pull)

Advantages:





- No extra investments are required passive tuners
- No extra investments are required for extra sources.



Depending on the output power of the DUT, a high-power amplifier may be required to tune the load for f_0 at high gammas!

Harmonic LP to maximize Efficiency

- Multiple load-pull measurements for PAE optimization:
 - Swept impedances at f_0 ; $2f_0$ and $3f_0$ fixed at $50\ \Omega$
 - Swept impedances at $2f_0$; f_0 fixed for optimum PAE at $3 P_{3dB}$, $3f_0$ fixed at $50\ \Omega$
 - Swept impedances at $3f_0$; f_0 and $2f_0$ fixed for optimum PAE at $3 P_{3dB}$
 - Swept impedances at f_0 ; $2f_0$ and $3f_0$ fixed for optimum PAE at $3 P_{3dB}$
- Measurements performed at the transistor package plane



Waveform Engineering

At RF and microwave frequencies, such conditions can be achieved using current and voltage waveform shaping at the drain level.

Thanks to the understanding **waveform shaping**, designers have now widely adopted Power Amplifier (PA) design methodologies which employ high efficiency class of operating conditions, such as Class F or inverse Class F amplifiers

Waveform Engineering & Behavioral Modelling request cross-harmonics phase relationship




Figure III-12 : Simulation load-pull à puissance disponible d'entrée constante ($f_0=2.5$ GHz).

a) Rouge : Contours de puissance de sortie (dBm). Bleu : Contours de PAE (%). b) Formes d'ondes de tension et courant pour la PAE maximale (bleu) et pour la puissance maximale (rouge). c) Cycles de charge pour la PAE maximale (bleu) et pour la puissance maximale (rouge).

Context – Phase Coherence

- With standard VNA, Magnitude measurements of travelling waves don't present difference between two consecutive sweeps




Sweep 1




Sweep 2

Context – Phase Coherence

- Phase response changes from one sweep to another.
- Change of the phase of the LO signal from one sweep to another.
- Measurements of the phase will not be the same at a given frequency between two sweeps at the same frequency




Sweep 1




Sweep 2

VNA architecture for incident and reflected wave acquisition




Large signal analysis with ZNA




- VNA's are mixer-based systems. The LO-phase will change during frequency sweep.
- This means that we cannot directly measure the phase across frequency using unrationed (a_1, b_1) measurements.

Context – Phase Coherence

Incident and reflected a and b waves are ratioed against the harmonic phase reference with constant phase relationship versus frequency and from sweep to sweep => **Phase coherence**



Sweep 1



Sweep 2

Harmonic Phase Reference

The LSA requires two phase reference modules:

- One phase reference module is used to maintain a static cross-frequency phase relationship.
- A second phase reference standard is used to calibrate the cross-frequency phase at the device reference plane.



AMCAD HPR727A

can generate signals up to 26.5GHz at frequency intervals as small as 10MHz.






Figure 1:6 Time domain HPR signal

When the phase reference is driven with F_{in} frequency, it generates $* F_{in}$ at the output.

AMCAD & R&S ZNA Large Signal Application





HITECH
RF & Microwave solutions

AMCAD Engineering
Advanced Modeling for Computer-Aided Design

